
Keysight InfiniiVision 6000 X-Series Oscilloscopes

Notices

© Keysight Technologies, Inc. 2005-2023

No part of this manual may be reproduced in any form or by any means (including electronic storage and retrieval or translation into a foreign language) without prior agreement and written consent from Keysight Technologies, Inc. as governed by United States and international copyright laws.

Revision

Version 07.60.0000

Edition

October 5, 2023

Available in electronic format only

Published by:

Keysight Technologies, Inc.
1900 Garden of the Gods Road
Colorado Springs, CO 80907 USA

Warranty

The material contained in this document is provided "as is," and is subject to being changed, without notice, in future editions. Further, to the maximum extent permitted by applicable law, Keysight disclaims all warranties, either express or implied, with regard to this manual and any information contained herein, including but not limited to the implied warranties of merchantability and fitness for a particular purpose. Keysight shall not be liable for errors or for incidental or consequential damages in connection with the furnishing, use, or performance of this document or of any information contained herein. Should Keysight and the user have a separate written agreement with warranty terms covering the material in this document that conflict with these terms, the warranty terms in the separate agreement shall control.

Technology License

The hardware and/or software described in this document are furnished under a license and may be used or copied only in accordance with the terms of such license.

U.S. Government Rights

The Software is "commercial computer software," as defined by Federal Acquisition Regulation ("FAR") 2.101. Pursuant to FAR 12.212 and 27.405-3 and Department of Defense FAR Supplement ("DFARS") 227.7202, the U.S. government acquires commercial computer software under the same terms by which the software is customarily provided to the public. Accordingly, Keysight provides the Software to U.S. government customers under its standard commercial license, which is embodied in its End User License Agreement (EULA), a copy of which can be found at www.keysight.com/find/sweula. The license set forth in the EULA represents the exclusive authority by which the U.S. government may use, modify, distribute, or disclose the Software. The EULA and the license set forth therein, does not require or permit, among other things, that Keysight: (1) Furnish technical information related to commercial computer software or commercial computer software documentation that is not customarily provided to the public; or (2) Relinquish to, or otherwise provide, the government rights in excess of these rights customarily provided to the public to use, modify, reproduce, release, perform, display, or disclose commercial computer software or commercial computer software documentation. No additional government requirements beyond those set forth in the EULA shall apply, except to the extent that those terms, rights, or licenses are explicitly required from all providers of commercial computer software pursuant to the FAR and the DFARS and are set forth specifically in writing elsewhere in the EULA. Keysight shall be under no obligation to update, revise or otherwise modify the Software. With respect to any technical data as defined by FAR 2.101, pursuant to FAR 12.211 and 27.404.2 and DFARS 227.7102, the U.S. government acquires no greater than Limited Rights as defined in FAR 27.401 or DFAR 227.7103-5 (c), as applicable in any technical data.

Safety Notices

CAUTION

A **CAUTION** notice denotes a hazard. It calls attention to an operating procedure, practice, or the like that, if not correctly performed or adhered to, could result in damage to the product or loss of important data. Do not proceed beyond a **CAUTION** notice until the indicated conditions are fully understood and met.

WARNING

A **WARNING** notice denotes a hazard. It calls attention to an operating procedure, practice, or the like that, if not correctly performed or adhered to, could result in personal injury or death. Do not proceed beyond a **WARNING** notice until the indicated conditions are fully understood and met.

In This Book

This book is your guide to programming the 6000 X-Series oscilloscopes:

Table 1 6000 X-Series Model Numbers, Bandwidths, Sample Rates

Model	Analog Channels	Digital Channels	Bandwidth Options	Sample Rate (interleaved, non-interleaved)
DSO-X 6002A	2		<ul style="list-style-type: none"> ▪ (none) = 1 GHz ▪ BW250 = 2.5 GHz ▪ BW400 = 4 GHz ▪ BW600 = 6 GHz 	20 GSa/s, 10 GSa/s
DSO-X 6004A	4			
MSO-X 6002A	2	16		
MSO-X 6004A	4	16		

The first few chapters describe how to set up and get started:

- **Chapter 1**, “What’s New,” starting on page 41, describes programming command changes in the latest version of oscilloscope software.
- **Chapter 2**, “Setting Up,” starting on page 65, describes the steps you must take before you can program the oscilloscope.
- **Chapter 3**, “Getting Started,” starting on page 73, gives a general overview of oscilloscope program structure and shows how to program the oscilloscope using a few simple examples.
- **Chapter 4**, “Sequential (Blocking) vs. Overlapped Commands,” starting on page 87, describes these command types and how they affect the oscilloscope and synchronization.
- **Chapter 5**, “Commands Quick Reference,” starting on page 89, is a brief listing of the 6000 X-Series oscilloscope commands and syntax.

The next chapters provide reference information on common commands, root level commands, other subsystem commands, and error messages:

- **Chapter 6**, “Common (*) Commands,” starting on page 229, describes commands defined by the IEEE 488.2 standard that are common to all instruments.
- **Chapter 7**, “Root (:) Commands,” starting on page 257, describes commands that reside at the root level of the command tree and control many of the basic functions of the oscilloscope.
- **Chapter 8**, “:ACQuire Commands,” starting on page 301, describes commands for setting the parameters used when acquiring and storing data.
- **Chapter 9**, “:BUS<n> Commands,” starting on page 321, describes commands that control all oscilloscope functions associated with the digital channels bus display.
- **Chapter 10**, “:CALibrate Commands,” starting on page 331, describes utility commands for determining the state of the calibration factor protection button.

- **Chapter 11**, “:CGRade Commands,” starting on page 341, describes commands that control the color grade waveform analysis feature.
- **Chapter 12**, “:CHANnel<n> Commands,” starting on page 349, describes commands that control all oscilloscope functions associated with individual analog channels or groups of channels.
- **Chapter 13**, “:CLOCK Commands,” starting on page 383, describes clock recovery commands.
- **Chapter 14**, “:COMpliance Commands,” starting on page 389, describes commands that control the license-enabled USB 2.0 signal quality analysis feature.
- **Chapter 15**, “:COUNTER Commands,” starting on page 401, describes commands that control the counter analysis feature.
- **Chapter 16**, “:DEMO Commands,” starting on page 413, describes commands that control the education kit demonstration signals that can be output on the oscilloscope's Demo 1 and Demo 2 terminals.
- **Chapter 17**, “:DIGital<d> Commands,” starting on page 421, describes commands that control all oscilloscope functions associated with individual digital channels.
- **Chapter 18**, “:DISPlay Commands,” starting on page 429, describes commands that control how waveforms, graticule, and text are displayed and written on the screen.
- **Chapter 19**, “:DVM Commands,” starting on page 455, describes commands that control the digital voltmeter analysis feature.
- **Chapter 20**, “:EXTernal Trigger Commands,” starting on page 461, describes commands that control the input characteristics of the external trigger input.
- **Chapter 21**, “:FRANalysis Commands,” starting on page 467, describes commands that control oscilloscope functions associated with the Frequency Response Analysis (FRA) feature, which is available is with the license-enabled built-in waveform generator).
- **Chapter 22**, “:FUNCTION<m> Commands,” starting on page 483, describes commands that control math waveforms.
- **Chapter 23**, “:HARDcopy/:HCOPY Commands,” starting on page 539, describes commands that set and query the selection of hardcopy device and formatting options.
- **Chapter 24**, “:HISTogram Commands,” starting on page 559, describes commands that control the histogram analysis feature.
- **Chapter 25**, “:JITTer Commands,” starting on page 575, describes commands that control the license-enabled jitter analysis feature.
- **Chapter 26**, “:LISTer Commands,” starting on page 595, describes commands that turn on/off the Lister display for decoded serial data and get the Lister data.
- **Chapter 27**, “:LTEST Commands,” starting on page 599, describes commands that control the Measurement Limit Test feature.

- **Chapter 28**, “:MARKer Commands,” starting on page 613, describes commands that set and query the settings of X-axis markers (X1 and X2 cursors) and the Y-axis markers (Y1 and Y2 cursors).
- **Chapter 29**, “:MEASure Commands,” starting on page 635, describes commands that select automatic measurements (and control markers).
- **Chapter 30**, “:MEASure Power Commands,” starting on page 757, describes measurement commands that are available when the power measurements and analysis application is licensed and enabled.
- **Chapter 31**, “:MTEST Commands,” starting on page 781, describes commands that control the license-enabled mask test feature.
- **Chapter 32**, “:POD Commands,” starting on page 815, describes commands that control all oscilloscope functions associated with groups of digital channels.
- **Chapter 33**, “:POWER Commands,” starting on page 821, describes commands that control the license-enabled power measurement application.
- **Chapter 34**, “:RECall Commands,” starting on page 925, describes commands that recall previously saved oscilloscope setups, reference waveforms, or masks.
- **Chapter 35**, “:RTEYe Commands,” starting on page 937, describes commands for controlling the real-time eye analysis feature.
- **Chapter 36**, “:SAVE Commands,” starting on page 943, describes commands that save oscilloscope setups, screen images, and data.
- **Chapter 37**, “:SBUS<n> Commands,” starting on page 977, describes commands that control oscilloscope functions associated with the serial decode bus and serial triggering.
- **Chapter 38**, “:SEARch Commands,” starting on page 1273, describes commands that control oscilloscope functions associated with searching for waveform events.
- **Chapter 39**, “:SYSTem Commands,” starting on page 1383, describes commands that control basic system functions of the oscilloscope.
- **Chapter 40**, “:TIMEbase Commands,” starting on page 1411, describes commands that control all horizontal sweep functions.
- **Chapter 41**, “:TRIGger Commands,” starting on page 1425, describes commands that control the trigger modes and parameters for each trigger type.
- **Chapter 42**, “:WAVEform Commands,” starting on page 1513, describes commands that provide access to waveform data.
- **Chapter 43**, “:WGEN<w> Commands,” starting on page 1551, describes commands that control waveform generator (WAVEGEN license) functions and parameters.
- **Chapter 44**, “:WMEMory<r> Commands,” starting on page 1601, describes commands that control reference waveforms.

- **Chapter 45**, “Obsolete and Discontinued Commands,” starting on page 1611, describes obsolete commands which still work but have been replaced by newer commands and discontinued commands which are no longer supported.
- **Chapter 46**, “Error Messages,” starting on page 1669, lists the instrument error messages that can occur while programming the oscilloscope.

The command descriptions in this reference show upper and lowercase characters. For example, :AUToscale indicates that the entire command name is :AUTOSCALE. The short form, :AUT, is also accepted by the oscilloscope.

Then, there are chapters that describe programming topics and conceptual information in more detail:

- **Chapter 47**, “Status Reporting,” starting on page 1677, describes the oscilloscope's status registers and how to check the status of the instrument.
- **Chapter 48**, “Synchronizing Acquisitions,” starting on page 1709, describes how to wait for acquisitions to complete before querying measurement results or performing other operations with the captured data.
- **Chapter 49**, “More About Oscilloscope Commands,” starting on page 1729, contains additional information about oscilloscope programming commands.

Finally, there is a chapter that contains programming examples:

- **Chapter 50**, “Programming Examples,” starting on page 1739.

Mixed-Signal Oscilloscope Channel Differences

Because both the “analog channels only” oscilloscopes (DSO models) and the mixed-signal oscilloscopes (MSO models) have analog channels, topics that describe analog channels refer to all oscilloscope models. Whenever a topic describes digital channels, that information applies only to the mixed-signal oscilloscope models.

See Also

- For more information on using the SICL, VISA, and VISA COM libraries in general, see the documentation that comes with the Keysight IO Libraries Suite.
- For information on controller PC interface configuration, see the documentation for the interface card used (for example, the Keysight 82350B GPIB interface).
- For information on oscilloscope front-panel operation, see the *User's Guide*.
- For detailed connectivity information, refer to the *Keysight Technologies USB/LAN/GPIB Connectivity Guide*. For a printable electronic copy of the *Connectivity Guide*, direct your Web browser to www.keysight.com and search for “Connectivity Guide”.
- For the latest versions of this and other manuals, see: <http://www.keysight.com/find/6000X-Series-manual>

Contents

In This Book / 3

1 What's New

What's New in Version 7.60	/ 42
What's New in Version 7.35	/ 43
What's New in Version 7.30	/ 45
What's New in Version 7.20	/ 47
What's New in Version 7.10	/ 49
What's New in Version 6.10	/ 55
Version 6.00 at Introduction	/ 59
Command Differences From 4000 X-Series Oscilloscopes	/ 60

2 Setting Up

Step 1. Install Keysight IO Libraries Suite software	/ 66
Step 2. Connect and set up the oscilloscope	/ 67
Using the USB (Device) Interface	/ 67
Using the LAN Interface	/ 67
Step 3. Verify the oscilloscope connection	/ 69

3 Getting Started

Basic Oscilloscope Program Structure	/ 74
Initializing	/ 74
Capturing Data	/ 74
Analyzing Captured Data	/ 75

Programming the Oscilloscope /	76
Referencing the IO Library /	76
Opening the Oscilloscope Connection via the IO Library /	77
Initializing the Interface and the Oscilloscope /	77
Using :AUToscale to Automate Oscilloscope Setup /	78
Using Other Oscilloscope Setup Commands /	78
Capturing Data with the :DIGitize Command /	79
Reading Query Responses from the Oscilloscope /	81
Reading Query Results into String Variables /	82
Reading Query Results into Numeric Variables /	82
Reading Definite-Length Block Query Response Data /	82
Sending Multiple Queries and Reading Results /	83
Checking Instrument Status /	84
Other Ways of Sending Commands /	85
Telnet Sockets /	85
Sending SCPI Commands Using Browser Web Control /	85

4 Sequential (Blocking) vs. Overlapped Commands

5 Commands Quick Reference

Command Summary /	90
Syntax Elements /	225
Number Format /	225
<NL> (Line Terminator) /	225
[] (Optional Syntax Terms) /	225
{} (Braces) /	225
::= (Defined As) /	225
< > (Angle Brackets) /	226
... (Ellipsis) /	226
n,...,p (Value Ranges) /	226
d (Digits) /	226
Quoted ASCII String /	226
Definite-Length Block Response Data /	226

6 Common (*) Commands

*CLS (Clear Status) /	235
*ESE (Standard Event Status Enable) /	236
*ESR (Standard Event Status Register) /	238
*IDN (Identification Number) /	240
*LRN (Learn Device Setup) /	241
*OPC (Operation Complete) /	242

- *OPT (Option Identification) / 243
- *RCL (Recall) / 245
- *RST (Reset) / 246
- *SAV (Save) / 249
- *SRE (Service Request Enable) / 250
- *STB (Read Status Byte) / 252
- *TRG (Trigger) / 254
- *TST (Self Test) / 255
- *WAI (Wait To Continue) / 256

7 Root (:) Commands

- :ACTivity / 261
- :AER (Arm Event Register) / 262
- :AUToscale / 263
- :AUToscale:AMODE / 265
- :AUToscale:CHANnels / 266
- :AUToscale:FDEBug / 267
- :BLANk / 268
- :DIGitize / 270
- :HWEenable (Hardware Event Enable Register) / 272
- :HWERegister:CONDition (Hardware Event Condition Register) / 274
- :HWERegister[:EVENT] (Hardware Event Event Register) / 275
- :MTEenable (Mask Test Event Enable Register) / 276
- :MTERegister[:EVENT] (Mask Test Event Event Register) / 278
- :OPEE (Operation Status Enable Register) / 280
- :OPERRegister:CONDition (Operation Status Condition Register) / 282
- :OPERRegister[:EVENT] (Operation Status Event Register) / 285
- :OVLenable (Overload Event Enable Register) / 288
- :OVLRegister (Overload Event Register) / 290
- :PRINt / 292
- :RSTate? / 293
- :RUN / 294
- :SERial / 295
- :SINGle / 296
- :STATus / 297
- :STOP / 298
- :TER (Trigger Event Register) / 299
- :VIEW / 300

8 :ACquire Commands

- :ACquire:AALias / 304

:ACQUIRE:COMPLETE / 305
:ACQUIRE:COUNT / 306
:ACQUIRE:DAALIAS / 307
:ACQUIRE:MODE / 308
:ACQUIRE:POINTS / 310
:ACQUIRE:RSIGNAL / 311
:ACQUIRE:SEGMENTED:ANALYZE / 312
:ACQUIRE:SEGMENTED:COUNT / 313
:ACQUIRE:SEGMENTED:INDEX / 314
:ACQUIRE:SRATE / 317
:ACQUIRE:TYPE / 318

9 :BUS<n> Commands

:BUS<n>:BIT<m> / 323
:BUS<n>:BITS / 324
:BUS<n>:CLEAR / 326
:BUS<n>:DISPLAY / 327
:BUS<n>:LABEL / 328
:BUS<n>:MASK / 329

10 :CALIBRATE Commands

:CALIBRATE:DATE / 333
:CALIBRATE:LABEL / 334
:CALIBRATE:OUTPUT / 335
:CALIBRATE:PROTECTED / 336
:CALIBRATE:START / 337
:CALIBRATE:STATUS / 338
:CALIBRATE:TEMPERATURE / 339
:CALIBRATE:TIME / 340

11 :CGRATE Commands

:CGRATE:LEVELS / 343
:CGRATE:LEVELS:DISPLAY / 344
:CGRATE:RESET / 345
:CGRATE:SCHEME / 346
:CGRATE:SOURCE / 347
:CGRATE:STATE / 348

12 :CHANNEL<n> Commands

:CHANNEL<n>:BANDWIDTH / 353
:CHANNEL<n>:BWLIMIT / 355

:CHANnel<n>:COUPling / 356
:CHANnel<n>:DISPlay / 357
:CHANnel<n>:IMPedance / 358
:CHANnel<n>:INVert / 359
:CHANnel<n>:LABel / 360
:CHANnel<n>:OFFSet / 361
:CHANnel<n>:PROBe / 362
:CHANnel<n>:PROBe:BTN / 363
:CHANnel<n>:PROBe:CALibration / 364
:CHANnel<n>:PROBe:BTN / 365
:CHANnel<n>:PROBe:EXTernal / 366
:CHANnel<n>:PROBe:EXTernal:GAIN / 367
:CHANnel<n>:PROBe:EXTernal:UNITs / 368
:CHANnel<n>:PROBe:HEAD[:TYPE] / 369
:CHANnel<n>:PROBe:ID / 370
:CHANnel<n>:PROBe:MMODEl / 371
:CHANnel<n>:PROBe:MODE / 372
:CHANnel<n>:PROBe:RSENse / 373
:CHANnel<n>:PROBe:SKEW / 374
:CHANnel<n>:PROBe:STYPe / 375
:CHANnel<n>:PROBe:ZOOM / 376
:CHANnel<n>:PROTection / 377
:CHANnel<n>:RANGe / 378
:CHANnel<n>:SCALE / 379
:CHANnel<n>:UNITs / 380
:CHANnel<n>:VERNier / 381

13 :CLOCK Commands

:CLOCK / 385
:CLOCK:METHOD / 386

14 :COMPLIANCE Commands

:COMPLIance:USB:AUTOsetup / 390
:COMPLIance:USB:HUBS / 391
:COMPLIance:USB:RUN / 392
:COMPLIance:USB:SOURce:ADJacent / 393
:COMPLIance:USB:SOURce:DIFFerential / 394
:COMPLIance:USB:SOURce:DMINus / 395
:COMPLIance:USB:SOURce:DPLus / 396
:COMPLIance:USB:TEST / 397
:COMPLIance:USB:TEST:CONNection / 398

:COMPLIance:USB:TEST:TYPE / 399

15 :COUNter Commands

:COUNter:CURRent / 403
:COUNter:ENABle / 404
:COUNter:MODE / 405
:COUNter:NDIGits / 406
:COUNter:SOURce / 407
:COUNter:TOTALize:CLEar / 408
:COUNter:TOTALize:GATE:ENABle / 409
:COUNter:TOTALize:GATE:POLarity / 410
:COUNter:TOTALize:GATE:SOURce / 411
:COUNter:TOTALize:SLOPe / 412

16 :DEMO Commands

:DEMO:FUNCTion / 414
:DEMO:FUNCTion:PHASe:PHASe / 419
:DEMO:OUTPut / 420

17 :DIGital<d> Commands

:DIGital<d>:DISPlay / 423
:DIGital<d>:LABel / 424
:DIGital<d>:POSition / 425
:DIGital<d>:SIZE / 426
:DIGital<d>:THReshold / 427

18 :DISPlay Commands

:DISPlay:ANNotation<n> / 432
:DISPlay:ANNotation<n>:BACKground / 433
:DISPlay:ANNotation<n>:COLor / 434
:DISPlay:ANNotation<n>:TEXT / 435
:DISPlay:ANNotation<n>:X1Position / 436
:DISPlay:ANNotation<n>:Y1Position / 437
:DISPlay:BACKlight / 438
:DISPlay:CLEar / 439
:DISPlay:DATA / 440
:DISPlay:GRATicule:ALABels / 442
:DISPlay:GRATicule:INTensity / 443
:DISPlay:GRATicule:TYPE / 444
:DISPlay:INTensity:WAVEform / 445
:DISPlay:LABel / 446

:DISPlay:LABList / 447
:DISPlay:MENU / 448
:DISPlay:MESSAge:CLEAr / 449
:DISPlay:PERsistence / 450
:DISPlay:PERsistence:CLEAr / 451
:DISPlay:SIDeBar / 452
:DISPlay:TRANSPARENT / 453
:DISPlay:VECTors / 454

19 :DVM Commands

:DVM:ARANge / 456
:DVM:CURRent / 457
:DVM:ENABle / 458
:DVM:MODE / 459
:DVM:SOURce / 460

20 :EXTErnal Trigger Commands

:EXTErnal:BWLimit / 462
:EXTErnal:PROBe / 463
:EXTErnal:RANGe / 464
:EXTErnal:UNITs / 465

21 :FRANalysis Commands

:FRANalysis:DATA / 469
:FRANalysis:ENABle / 470
:FRANalysis:FREQuency:MODE / 471
:FRANalysis:FREQuency:SINGle / 472
:FRANalysis:FREQuency:STARt / 473
:FRANalysis:FREQuency:STOP / 474
:FRANalysis:PPDecade / 475
:FRANalysis:RUN / 476
:FRANalysis:SOURce:INPut / 477
:FRANalysis:SOURce:OUTPut / 478
:FRANalysis:TRACe / 479
:FRANalysis:WGEN:LOAD / 480
:FRANalysis:WGEN:VOLTage / 481
:FRANalysis:WGEN:VOLTage:PROFile / 482

22 :FUNCTion<m> Commands

:FUNCTion<m>:AVERAge:COUNT / 490
:FUNCTion<m>:BUS:CLOCK / 491

:FUNCTION<m>:BUS:SLOPe / 492
:FUNCTION<m>:BUS:YINCrement / 493
:FUNCTION<m>:BUS:YORigin / 494
:FUNCTION<m>:BUS:YUNits / 495
:FUNCTION<m>:CLEar / 496
:FUNCTION<m>:DISPlay / 497
:FUNCTION<m>[:FFT]:BSIZe / 498
:FUNCTION<m>[:FFT]:CENTer / 499
:FUNCTION<m>[:FFT]:DETection:POINts / 500
:FUNCTION<m>[:FFT]:DETection:TYPE / 501
:FUNCTION<m>[:FFT]:FREQuency:STARt / 502
:FUNCTION<m>[:FFT]:FREQuency:STOP / 503
:FUNCTION<m>[:FFT]:GATE / 504
:FUNCTION<m>[:FFT]:PHASe:REFerence / 505
:FUNCTION<m>[:FFT]:RBWidTh / 506
:FUNCTION<m>[:FFT]:READout<n> / 507
:FUNCTION<m>[:FFT]:SPAN / 508
:FUNCTION<m>[:FFT]:SRATe / 509
:FUNCTION<m>[:FFT]:VTYPe / 510
:FUNCTION<m>[:FFT]:WINDow / 511
:FUNCTION<m>:FREQuency:BANDpass:CENTer / 512
:FUNCTION<m>:FREQuency:BANDpass:WIDTh / 513
:FUNCTION<m>:FREQuency:HIGHPass / 514
:FUNCTION<m>:FREQuency:LOWPass / 515
:FUNCTION<m>:INTegrate:IICondition / 516
:FUNCTION<m>:INTegrate:IOFFset / 517
:FUNCTION<m>:LINear:GAIN / 518
:FUNCTION<m>:LINear:OFFSet / 519
:FUNCTION<m>:OFFSet / 520
:FUNCTION<m>:OPERation / 521
:FUNCTION<m>:RANGe / 526
:FUNCTION<m>:REFerence / 527
:FUNCTION<m>:SCALE / 528
:FUNCTION<m>:SERChart:SOURce / 529
:FUNCTION<m>:SERChart:TIME:MODE / 530
:FUNCTION<m>:SERChart:TIME:RANGe / 532
:FUNCTION<m>:SERChart:TIME:OFFSet / 533
:FUNCTION<m>:SMOoth:POINts / 534
:FUNCTION<m>:SOURce1 / 535
:FUNCTION<m>:SOURce2 / 537
:FUNCTION<m>:TRENd:NMEasurement / 538

23 :HARDcopy/:HCOPY Commands

- :HARDcopy:AREA / 542
- :HARDcopy:APRinter / 543
- :HARDcopy:FACTors / 544
- :HARDcopy:FFEed / 545
- :HARDcopy:INKSaver / 546
- :HARDcopy:LAYout / 547
- :HARDcopy:NETWork:ADDRes / 548
- :HARDcopy:NETWork:APPLy / 549
- :HARDcopy:NETWork:DOMain / 550
- :HARDcopy:NETWork:PASSword / 551
- :HARDcopy:NETWork:SLOT / 552
- :HARDcopy:NETWork:USERname / 553
- :HARDcopy:PALette / 554
- :HARDcopy:PRINter:LIST / 555
- :HARDcopy:STARt / 556
- :HCOPY:SDUMp:DATA / 557
- :HCOPY:SDUMp:FORMat / 558

24 :HISTogram Commands

- :HISTogram:AXIS / 562
- :HISTogram:DISPlay / 563
- :HISTogram:MEASurement / 564
- :HISTogram:MODE / 565
- :HISTogram:RESet / 566
- :HISTogram:SIZE / 567
- :HISTogram:TYPE / 568
- :HISTogram:WINDow:BLIMit / 569
- :HISTogram:WINDow:LLIMit / 570
- :HISTogram:WINDow:RLIMit / 571
- :HISTogram:WINDow:SOURce / 572
- :HISTogram:WINDow:TLIMit / 573

25 :JITTer Commands

- :JITTer:HISTogram:APPLy / 577
- :JITTer:MEASurement / 578
- :JITTer:SPECTrum:APPLy / 580
- :JITTer:SPECTrum:HORizontal:POSition / 581
- :JITTer:SPECTrum:HORizontal:RANGe / 582
- :JITTer:SPECTrum:VERTical:OFFSet / 583
- :JITTer:SPECTrum:VERTical:RANGe / 584

:JITTer:SPECtrum:VERTical:TYPE / 585
:JITTer:SPECtrum:WINDow / 586
:JITTer:STATe / 588
:JITTer:TREnd:APPLy / 590
:JITTer:TREnd:SMOoth:APPLy / 591
:JITTer:TREnd:SMOoth:POINts / 592
:JITTer:TREnd:VERTical:OFFSet / 593
:JITTer:TREnd:VERTical:RANGe / 594

26 :LISTer Commands

:LISTer:DATA / 596
:LISTer:DISPlay / 597
:LISTer:REFeRence / 598

27 :LTEST Commands

:LTEST:COPIY / 601
:LTEST:COPIY:ALL / 602
:LTEST:COPIY:MARGIn / 603
:LTEST:ENABle / 604
:LTEST:FAIL / 605
:LTEST:LLIMit / 606
:LTEST:MEASurement / 607
:LTEST:RESults / 608
:LTEST:RUMode:SOFailure / 609
:LTEST:TEST / 610
:LTEST:ULIMit / 611

28 :MARKer Commands

:MARKer:DYDX / 616
:MARKer:MODE / 617
:MARKer:X1:DISPlay / 618
:MARKer:X1Position / 619
:MARKer:X1Y1source / 620
:MARKer:X2:DISPlay / 621
:MARKer:X2Position / 622
:MARKer:X2Y2source / 623
:MARKer:XDELta / 624
:MARKer:XUNits / 625
:MARKer:XUNits:USE / 626
:MARKer:Y1:DISPlay / 627
:MARKer:Y1Position / 628

:MARKer:Y2:DISPlay / 629
:MARKer:Y2Position / 630
:MARKer:YDELta / 631
:MARKer:YUNits / 632
:MARKer:YUNits:USE / 633

29 :MEASure Commands

:MEASure:ALL / 660
:MEASure:AREa / 661
:MEASure:BRATe / 662
:MEASure:BWIDth / 663
:MEASure:CLEar / 664
:MEASure:COUNter / 665
:MEASure:CTCNwidth / 667
:MEASure:CTCPwidth / 669
:MEASure:DEFine / 671
:MEASure:DELay / 674
:MEASure:DELay:DEFine / 676
:MEASure:DUAL:CHARge / 677
:MEASure:DUAL:VAMPLitude / 678
:MEASure:DUAL:VAverage / 679
:MEASure:DUAL:VBASe / 680
:MEASure:DUAL:VPP / 681
:MEASure:DUAL:VRMS / 682
:MEASure:DUTYcycle / 683
:MEASure:FALLtime / 684
:MEASure:FFT:ACPR / 685
:MEASure:FFT:CPOWer / 686
:MEASure:FFT:OBW / 687
:MEASure:FFT:THD / 688
:MEASure:FREQuency / 689
:MEASure:HISTogram:BWIDth / 690
:MEASure:HISTogram:HITS / 691
:MEASure:HISTogram:M1S / 692
:MEASure:HISTogram:M2S / 693
:MEASure:HISTogram:M3S / 694
:MEASure:HISTogram:MAXimum / 695
:MEASure:HISTogram:MEAN / 696
:MEASure:HISTogram:MEDian / 697
:MEASure:HISTogram:MINimum / 698
:MEASure:HISTogram:MODE / 699

:MEASure:HISTogram:PEAK / 700
:MEASure:HISTogram:PPEak / 701
:MEASure:HISTogram:SDEVIation / 702
:MEASure:NCJitter / 703
:MEASure:NDUTy / 705
:MEASure:NEDGes / 706
:MEASure:NPERiod / 707
:MEASure:NPULses / 708
:MEASure:NWIDth / 709
:MEASure:OVERshoot / 710
:MEASure:PEDGes / 712
:MEASure:PERiod / 713
:MEASure:PHASe / 714
:MEASure:PPULses / 715
:MEASure:PREShoot / 716
:MEASure:PWIDth / 717
:MEASure:RESults / 718
:MEASure:RISetime / 721
:MEASure:RTEYe:EHEight / 722
:MEASure:RTEYe:EWIDth / 723
:MEASure:SDEVIation / 724
:MEASure:SHOW / 725
:MEASure:SLEWrate / 726
:MEASure:SOURce / 727
:MEASure:STATistics / 729
:MEASure:STATistics:DISPlay / 730
:MEASure:STATistics:INCRement / 731
:MEASure:STATistics:MCOunt / 732
:MEASure:STATistics:RESet / 733
:MEASure:STATistics:RSDeVIation / 734
:MEASure:TEDGe / 735
:MEASure:TIEData / 738
:MEASure:TIEClock / 740
:MEASure:TVALue / 742
:MEASure:VAMPLitude / 744
:MEASure:VAverage / 745
:MEASure:VBASe / 746
:MEASure:VMAX / 747
:MEASure:VMIN / 748
:MEASure:VPP / 749
:MEASure:VRATio / 750
:MEASure:VRMS / 751

:MEASure:VTOp / 752
:MEASure:WINDow / 753
:MEASure:XMAX / 754
:MEASure:XMIN / 755
:MEASure:YATX / 756

30 :MEASure Power Commands

:MEASure:ANGLe / 762
:MEASure:APParent / 763
:MEASure:CPLoss / 764
:MEASure:CRESt / 765
:MEASure:EFFiciency / 766
:MEASure:ELOSs / 767
:MEASure:FACTor / 768
:MEASure:IPOWER / 769
:MEASure:OFFTime / 770
:MEASure:ONTime / 771
:MEASure:OPOWER / 772
:MEASure:PCURrent / 773
:MEASure:PLOSs / 774
:MEASure:RDSON / 775
:MEASure:REACTive / 776
:MEASure:REAL / 777
:MEASure:RIPple / 778
:MEASure:TRESponse / 779
:MEASure:VCESat / 780

31 :MTEST Commands

:MTEST:ALL / 786
:MTEST:AMASK:CREate / 787
:MTEST:AMASK:SOURce / 788
:MTEST:AMASK:UNITs / 789
:MTEST:AMASK:XDELta / 790
:MTEST:AMASK:YDELta / 791
:MTEST:COUNt:FWAVEforms / 792
:MTEST:COUNt:RESet / 793
:MTEST:COUNt:TIME / 794
:MTEST:COUNt:WAVEforms / 795
:MTEST:DATA / 796
:MTEST:DELeTe / 797
:MTEST:ENABle / 798

:MTEST:LOCK / 799
:MTEST:RMODE / 800
:MTEST:RMODE:FACTion:MEASure / 801
:MTEST:RMODE:FACTion:PRINT / 802
:MTEST:RMODE:FACTion:SAVE / 803
:MTEST:RMODE:FACTion:STOP / 804
:MTEST:RMODE:SIGMa / 805
:MTEST:RMODE:TIME / 806
:MTEST:RMODE:WAVEforms / 807
:MTEST:SCALE:BIND / 808
:MTEST:SCALE:X1 / 809
:MTEST:SCALE:XDELta / 810
:MTEST:SCALE:Y1 / 811
:MTEST:SCALE:Y2 / 812
:MTEST:SOURce / 813
:MTEST:TITLe / 814

32 :POD Commands

:POD<n>:DISPlay / 817
:POD<n>:SIZE / 818
:POD<n>:THReshold / 819

33 :POWer Commands

:POWer:CLResponse / 829
:POWer:CLResponse:APPLY / 830
:POWer:CLResponse:DATA / 831
:POWer:CLResponse:DATA:GMARgin / 832
:POWer:CLResponse:DATA:GMARgin:FREQuency / 833
:POWer:CLResponse:DATA:PMARgin / 834
:POWer:CLResponse:DATA:PMARgin:FREQuency / 835
:POWer:CLResponse:FREQuency:MODE / 836
:POWer:CLResponse:FREQuency:SINGLE / 837
:POWer:CLResponse:FREQuency:STARt / 838
:POWer:CLResponse:FREQuency:STOP / 839
:POWer:CLResponse:PPDecade / 840
:POWer:CLResponse:SOURce:INPut / 841
:POWer:CLResponse:SOURce:OUTPut / 842
:POWer:CLResponse:TRACe / 843
:POWer:CLResponse:WGEN:LOAD / 844
:POWer:CLResponse:WGEN:VOLTage / 845
:POWer:CLResponse:WGEN:VOLTage:PROFile / 846

:POWer:DESKew / 847
:POWer:EFFiciency:APPLy / 848
:POWer:EFFiciency:TYPE / 849
:POWer:ENABle / 850
:POWer:HARMonics:APPLy / 851
:POWer:HARMonics:DATA / 852
:POWer:HARMonics:DISPlay / 853
:POWer:HARMonics:FAILcount / 854
:POWer:HARMonics:LINE / 855
:POWer:HARMonics:POWerfactor / 856
:POWer:HARMonics:RPOWer / 857
:POWer:HARMonics:RPOWer:USER / 858
:POWer:HARMonics:RUNCount / 859
:POWer:HARMonics:STANdard / 860
:POWer:HARMonics:STATus / 861
:POWer:HARMonics:THD / 862
:POWer:INRush:APPLy / 863
:POWer:INRush:EXIT / 864
:POWer:INRush:NEXT / 865
:POWer:ITYPE / 866
:POWer:MODulation:APPLy / 867
:POWer:MODulation:SOURce / 868
:POWer:MODulation:TYPE / 869
:POWer:ONOFF:APPLy / 870
:POWer:ONOFF:EXIT / 871
:POWer:ONOFF:NEXT / 872
:POWer:ONOFF:TEST / 873
:POWer:ONOFF:THResholds / 874
:POWer:PSRR / 876
:POWer:PSRR:APPLy / 877
:POWer:PSRR:DATA / 878
:POWer:PSRR:FREQuency:MAXimum / 879
:POWer:PSRR:FREQuency:MINimum / 880
:POWer:PSRR:FREQuency:MODE / 881
:POWer:PSRR:FREQuency:SINGle / 882
:POWer:PSRR:PPDecade / 883
:POWer:PSRR:SOURce:INPut / 884
:POWer:PSRR:SOURce:OUTPut / 885
:POWer:PSRR:TRACe / 886
:POWer:PSRR:WGEN:LOAD / 887
:POWer:PSRR:WGEN:VOLTage / 888
:POWer:PSRR:WGEN:VOLTage:PROFile / 889

:POWer:QUALity:APPLy / 890
:POWer:RIPPLe:APPLy / 891
:POWer:SIGNals:AUTOsetuP / 892
:POWer:SIGNals:CYCLes:HARMonics / 893
:POWer:SIGNals:CYCLes:QUALity / 894
:POWer:SIGNals:DURation:EFFiciency / 895
:POWer:SIGNals:DURation:MODulation / 896
:POWer:SIGNals:DURation:ONOFF:OFF / 897
:POWer:SIGNals:DURation:ONOFF:ON / 898
:POWer:SIGNals:DURation:RIPPLe / 899
:POWer:SIGNals:DURation:TRANsient / 900
:POWer:SIGNals:IEXPeCted / 901
:POWer:SIGNals:OVERshoot / 902
:POWer:SIGNals:VMAXimum:INRush / 903
:POWer:SIGNals:VMAXimum:ONOFF:OFF / 904
:POWer:SIGNals:VMAXimum:ONOFF:ON / 905
:POWer:SIGNals:VSTeady:ONOFF:OFF / 906
:POWer:SIGNals:VSTeady:ONOFF:ON / 907
:POWer:SIGNals:VSTeady:TRANsient / 908
:POWer:SIGNals:SOURce:CURRent<i> / 909
:POWer:SIGNals:SOURce:VOLTage<i> / 910
:POWer:SLEW:APPLy / 911
:POWer:SLEW:SOURce / 912
:POWer:SWITCh:APPLy / 913
:POWer:SWITCh:CONDUction / 914
:POWer:SWITCh:IREFERENCE / 915
:POWer:SWITCh:RDS / 916
:POWer:SWITCh:VCE / 917
:POWer:SWITCh:VREFERENCE / 918
:POWer:TRANsient:APPLy / 919
:POWer:TRANsient:EXIT / 920
:POWer:TRANsient:INitial / 921
:POWer:TRANsient:INEW / 922
:POWer:TRANsient:NEXT / 923

34 :RECall Commands

:RECall:ARBitrary[:START] / 928
:RECall:DBC[:START] / 929
:RECall:FILEname / 930
:RECall:LDF[:START] / 931
:RECall:MASK[:START] / 932

:RECall:PWD / 933
:RECall:SETup[:START] / 934
:RECall:WMEMory<r>[:START] / 935

35 :RTEYe Commands

:RTEYe:ACQuire / 938
:RTEYe:SOURce / 939
:RTEYe:STATe / 940
:RTEYe:TUINtervals / 941

36 :SAVE Commands

:SAVE:ARBitrary[:START] / 947
:SAVE:COMPLiance:USB[:START] / 948
:SAVE:FILEname / 949
:SAVE:IMAGe[:START] / 950
:SAVE:IMAGe:FACTors / 951
:SAVE:IMAGe:FORMat / 952
:SAVE:IMAGe:INKSaver / 953
:SAVE:IMAGe:PALette / 954
:SAVE:LISTer[:START] / 955
:SAVE:MASK[:START] / 956
:SAVE:MULTi[:START] / 957
:SAVE:POWER[:START] / 958
:SAVE:PWD / 959
:SAVE:RESults[:START] / 960
:SAVE:RESults:FORMat:CGRade / 961
:SAVE:RESults:FORMat:CURSor / 962
:SAVE:RESults:FORMat:HISTogram / 963
:SAVE:RESults:FORMat:MASK / 964
:SAVE:RESults:FORMat:MEASurement / 965
:SAVE:RESults:FORMat:SEARch / 966
:SAVE:RESults:FORMat:SEGmented / 967
:SAVE[:SETup[:START]] / 968
:SAVE:WAVEform[:START] / 969
:SAVE:WAVEform:FORMat / 970
:SAVE:WAVEform:LENGth / 971
:SAVE:WAVEform:LENGth:MAX / 972
:SAVE:WAVEform:SEGmented / 973
:SAVE:WMEMory:SOURce / 974
:SAVE:WMEMory[:START] / 975

37 :SBUS<n> Commands

General :SBUS<n> Commands /	979
:SBUS<n>:DISPlay /	980
:SBUS<n>:MODE /	981
:SBUS<n>:A429 Commands /	982
:SBUS<n>:A429:AUTosetup /	984
:SBUS<n>:A429:BASE /	985
:SBUS<n>:A429:BAUDrate /	986
:SBUS<n>:A429:COUNt:ERRor /	987
:SBUS<n>:A429:COUNt:RESet /	988
:SBUS<n>:A429:COUNt:WORD /	989
:SBUS<n>:A429:FORMat /	990
:SBUS<n>:A429:SIGNal /	991
:SBUS<n>:A429:SOURce /	992
:SBUS<n>:A429:SPeEd /	993
:SBUS<n>:A429:TRIGger:LABel /	994
:SBUS<n>:A429:TRIGger:PATtern:DATA /	995
:SBUS<n>:A429:TRIGger:PATtern:SDI /	996
:SBUS<n>:A429:TRIGger:PATtern:SSM /	997
:SBUS<n>:A429:TRIGger:RANGe /	998
:SBUS<n>:A429:TRIGger:TYPE /	999
:SBUS<n>:CAN Commands /	1001
:SBUS<n>:CAN:COUNt:ERRor /	1004
:SBUS<n>:CAN:COUNt:OVERload /	1005
:SBUS<n>:CAN:COUNt:RESet /	1006
:SBUS<n>:CAN:COUNt:SPEC /	1007
:SBUS<n>:CAN:COUNt:TOTal /	1008
:SBUS<n>:CAN:COUNt:UTILization /	1009
:SBUS<n>:CAN:DISPlay /	1010
:SBUS<n>:CAN:FDSPoint /	1011
:SBUS<n>:CAN:FDStandard /	1012
:SBUS<n>:CAN:SAMPlepoint /	1013
:SBUS<n>:CAN:SIGNal:BAUDrate /	1014
:SBUS<n>:CAN:SIGNal:DEFinition /	1015
:SBUS<n>:CAN:SIGNal:FDBaudrate /	1016
:SBUS<n>:CAN:SOURce /	1017
:SBUS<n>:CAN:TRIGger /	1018
:SBUS<n>:CAN:TRIGger:IDFilter /	1021
:SBUS<n>:CAN:TRIGger:PATtern:DATA /	1022
:SBUS<n>:CAN:TRIGger:PATtern:DATA:DLC /	1023

- :SBUS<n>:CAN:TRIGger:PATtern:DATA:LENGth / 1024
- :SBUS<n>:CAN:TRIGger:PATtern:DATA:STARt / 1025
- :SBUS<n>:CAN:TRIGger:PATtern:ID / 1026
- :SBUS<n>:CAN:TRIGger:PATtern:ID:MODE / 1027
- :SBUS<n>:CAN:TRIGger:SYMBolic:MESSAge / 1028
- :SBUS<n>:CAN:TRIGger:SYMBolic:SIGNal / 1029
- :SBUS<n>:CAN:TRIGger:SYMBolic:VALue / 1030
- :SBUS<n>:CXPI Commands / 1031
 - :SBUS<n>:CXPI:BAUDrate / 1033
 - :SBUS<n>:CXPI:PARity / 1034
 - :SBUS<n>:CXPI:SOURce / 1035
 - :SBUS<n>:CXPI:TOLerance / 1036
 - :SBUS<n>:CXPI:TRIGger / 1037
 - :SBUS<n>:CXPI:TRIGger:IDFilter / 1039
 - :SBUS<n>:CXPI:TRIGger:PTYPe / 1040
 - :SBUS<n>:CXPI:TRIGger:PATtern:DATA / 1041
 - :SBUS<n>:CXPI:TRIGger:PATtern:DATA:LENGth / 1042
 - :SBUS<n>:CXPI:TRIGger:PATtern:DATA:STARt / 1043
 - :SBUS<n>:CXPI:TRIGger:PATtern:ID / 1044
 - :SBUS<n>:CXPI:TRIGger:PATtern:INFO:CT / 1045
 - :SBUS<n>:CXPI:TRIGger:PATtern:INFO:DLC / 1046
 - :SBUS<n>:CXPI:TRIGger:PATtern:INFO:NM / 1047
- :SBUS<n>:FLEXray Commands / 1048
 - :SBUS<n>:FLEXray:AUTosetup / 1050
 - :SBUS<n>:FLEXray:BAUDrate / 1051
 - :SBUS<n>:FLEXray:CHANnel / 1052
 - :SBUS<n>:FLEXray:COUNt:NULL / 1053
 - :SBUS<n>:FLEXray:COUNt:RESet / 1054
 - :SBUS<n>:FLEXray:COUNt:SYNC / 1055
 - :SBUS<n>:FLEXray:COUNt:TOTal / 1056
 - :SBUS<n>:FLEXray:SOURce / 1057
 - :SBUS<n>:FLEXray:TRIGger / 1058
 - :SBUS<n>:FLEXray:TRIGger:ERRor:TYPE / 1059
 - :SBUS<n>:FLEXray:TRIGger:EVENT:AUToset / 1060
 - :SBUS<n>:FLEXray:TRIGger:EVENT:BSS:ID / 1061
 - :SBUS<n>:FLEXray:TRIGger:EVENT:TYPE / 1062
 - :SBUS<n>:FLEXray:TRIGger:FRAMe:CCBase / 1063
 - :SBUS<n>:FLEXray:TRIGger:FRAMe:CCRepetition / 1064
 - :SBUS<n>:FLEXray:TRIGger:FRAMe:ID / 1065
 - :SBUS<n>:FLEXray:TRIGger:FRAMe:TYPE / 1066

```

:SBUS<n>:I2S Commands / 1067
  :SBUS<n>:I2S:ALIGnment / 1070
  :SBUS<n>:I2S:BASE / 1071
  :SBUS<n>:I2S:CLOCK:SLOPe / 1072
  :SBUS<n>:I2S:RWIDth / 1073
  :SBUS<n>:I2S:SOURce:CLOCK / 1074
  :SBUS<n>:I2S:SOURce:DATA / 1075
  :SBUS<n>:I2S:SOURce:WSElect / 1076
  :SBUS<n>:I2S:TRIGger / 1077
  :SBUS<n>:I2S:TRIGger:AUDio / 1079
  :SBUS<n>:I2S:TRIGger:PATtern:DATA / 1080
  :SBUS<n>:I2S:TRIGger:PATtern:FORMat / 1082
  :SBUS<n>:I2S:TRIGger:RANGe / 1083
  :SBUS<n>:I2S:TWIDth / 1084
  :SBUS<n>:I2S:WSLow / 1085
:SBUS<n>:IIC Commands / 1086
  :SBUS<n>:IIC:ASIZe / 1088
  :SBUS<n>:IIC[:SOURce]:CLOCK / 1089
  :SBUS<n>:IIC[:SOURce]:DATA / 1090
  :SBUS<n>:IIC:TRIGger:PATtern:ADDRess / 1091
  :SBUS<n>:IIC:TRIGger:PATtern:DATA / 1092
  :SBUS<n>:IIC:TRIGger:PATtern:DATA2 / 1093
  :SBUS<n>:IIC:TRIGger:QUALifier / 1094
  :SBUS<n>:IIC:TRIGger[:TYPE] / 1095
:SBUS<n>:LIN Commands / 1097
  :SBUS<n>:LIN:DISPlay / 1099
  :SBUS<n>:LIN:PARity / 1100
  :SBUS<n>:LIN:SAMPlepoint / 1101
  :SBUS<n>:LIN:SIGNal:BAUDrate / 1102
  :SBUS<n>:LIN:SOURce / 1103
  :SBUS<n>:LIN:STANDard / 1104
  :SBUS<n>:LIN:SYNCbreak / 1105
  :SBUS<n>:LIN:TRIGger / 1106
  :SBUS<n>:LIN:TRIGger:ID / 1108
  :SBUS<n>:LIN:TRIGger:PATtern:DATA / 1109
  :SBUS<n>:LIN:TRIGger:PATtern:DATA:LENGth / 1111
  :SBUS<n>:LIN:TRIGger:PATtern:FORMat / 1112
  :SBUS<n>:LIN:TRIGger:SYMBolic:FRAMe / 1113
  :SBUS<n>:LIN:TRIGger:SYMBolic:SIGNal / 1114
  :SBUS<n>:LIN:TRIGger:SYMBolic:VALue / 1115

```

```

:SBUS<n>:M1553 Commands / 1116
  :SBUS<n>:M1553:AUTosetup / 1117
  :SBUS<n>:M1553:BASE / 1118
  :SBUS<n>:M1553:SOURce / 1119
  :SBUS<n>:M1553:TRIGger:PATtern:DATA / 1120
  :SBUS<n>:M1553:TRIGger:RTA / 1121
  :SBUS<n>:M1553:TRIGger:TYPE / 1122
:SBUS<n>:MANChester Commands / 1123
  :SBUS<n>:MANChester:BASE / 1125
  :SBUS<n>:MANChester:BAUDrate / 1126
  :SBUS<n>:MANChester:BITorder / 1127
  :SBUS<n>:MANChester:DISPlay / 1128
  :SBUS<n>:MANChester:DSIZe / 1129
  :SBUS<n>:MANChester:HSIZe / 1130
  :SBUS<n>:MANChester:IDLE:BITS / 1131
  :SBUS<n>:MANChester:LOGic / 1132
  :SBUS<n>:MANChester:SOURce / 1133
  :SBUS<n>:MANChester:SSIZe / 1134
  :SBUS<n>:MANChester:START / 1135
  :SBUS<n>:MANChester:TOLerance / 1136
  :SBUS<n>:MANChester:TRIGger / 1137
  :SBUS<n>:MANChester:TRIGger:PATtern:VALue:DATA / 1138
  :SBUS<n>:MANChester:TRIGger:PATtern:VALue:WIDTh / 1139
  :SBUS<n>:MANChester:TSIZe / 1140
  :SBUS<n>:MANChester:WSIZe / 1141
:SBUS<n>:NRZ Commands / 1142
  :SBUS<n>:NRZ:BASE / 1144
  :SBUS<n>:NRZ:BAUDrate / 1145
  :SBUS<n>:NRZ:BITorder / 1146
  :SBUS<n>:NRZ:DISPlay / 1147
  :SBUS<n>:NRZ:DSIZe / 1148
  :SBUS<n>:NRZ:FSIZe / 1149
  :SBUS<n>:NRZ:HSIZe / 1150
  :SBUS<n>:NRZ:IDLE:BITS / 1151
  :SBUS<n>:NRZ:IDLE:STATe / 1152
  :SBUS<n>:NRZ:LOGic / 1153
  :SBUS<n>:NRZ:SOURce / 1154
  :SBUS<n>:NRZ:START / 1155
  :SBUS<n>:NRZ:TRIGger / 1156
  :SBUS<n>:NRZ:TRIGger:PATtern:VALue:DATA / 1157
  :SBUS<n>:NRZ:TRIGger:PATtern:VALue:WIDTh / 1158

```

:SBUS<n>:NRZ:TSIZe / 1159
 :SBUS<n>:NRZ:WSIZe / 1160
 :SBUS<n>:SENT Commands / 1161
 :SBUS<n>:SENT:CLOCK / 1164
 :SBUS<n>:SENT:CRC / 1165
 :SBUS<n>:SENT:DISPlay / 1166
 :SBUS<n>:SENT:FORMat / 1168
 :SBUS<n>:SENT:IDLE / 1170
 :SBUS<n>:SENT:LENGth / 1171
 :SBUS<n>:SENT:PPULse / 1172
 :SBUS<n>:SENT:SIGNa<s>:DISPlay / 1174
 :SBUS<n>:SENT:SIGNa<s>:LENGth / 1175
 :SBUS<n>:SENT:SIGNa<s>:MULTIplier / 1177
 :SBUS<n>:SENT:SIGNa<s>:OFFSet / 1179
 :SBUS<n>:SENT:SIGNa<s>:ORDer / 1181
 :SBUS<n>:SENT:SIGNa<s>:STARt / 1183
 :SBUS<n>:SENT:SOURce / 1185
 :SBUS<n>:SENT:TOLerance / 1187
 :SBUS<n>:SENT:TRIGger / 1188
 :SBUS<n>:SENT:TRIGger:FAST:DATA / 1190
 :SBUS<n>:SENT:TRIGger:SLOW:DATA / 1191
 :SBUS<n>:SENT:TRIGger:SLOW:ID / 1193
 :SBUS<n>:SENT:TRIGger:SLOW:ILENght / 1195
 :SBUS<n>:SENT:TRIGger:TOLerance / 1196
 :SBUS<n>:SPI Commands / 1197
 :SBUS<n>:SPI:BITOrder / 1199
 :SBUS<n>:SPI:CLOCK:SLOPe / 1200
 :SBUS<n>:SPI:CLOCK:TIMeout / 1201
 :SBUS<n>:SPI:DELay / 1202
 :SBUS<n>:SPI:FRAMing / 1203
 :SBUS<n>:SPI:SOURce:CLOCK / 1204
 :SBUS<n>:SPI:SOURce:FRAME / 1205
 :SBUS<n>:SPI:SOURce:MISO / 1206
 :SBUS<n>:SPI:SOURce:MOSI / 1207
 :SBUS<n>:SPI:TRIGger:PATtern:MISO:DATA / 1208
 :SBUS<n>:SPI:TRIGger:PATtern:MISO:WIDTh / 1209
 :SBUS<n>:SPI:TRIGger:PATtern:MOSI:DATA / 1210
 :SBUS<n>:SPI:TRIGger:PATtern:MOSI:WIDTh / 1211
 :SBUS<n>:SPI:TRIGger:TYPE / 1212
 :SBUS<n>:SPI:WIDTh / 1213

```

:SBUS<n>:UART Commands / 1214
  :SBUS<n>:UART:BASE / 1217
  :SBUS<n>:UART:BAUDrate / 1218
  :SBUS<n>:UART:BITorder / 1219
  :SBUS<n>:UART:COUNT:ERRor / 1220
  :SBUS<n>:UART:COUNT:RESet / 1221
  :SBUS<n>:UART:COUNT:RXFRames / 1222
  :SBUS<n>:UART:COUNT:TXFRames / 1223
  :SBUS<n>:UART:FRAMing / 1224
  :SBUS<n>:UART:PARity / 1225
  :SBUS<n>:UART:POLarity / 1226
  :SBUS<n>:UART:SOURce:RX / 1227
  :SBUS<n>:UART:SOURce:TX / 1228
  :SBUS<n>:UART:TRIGger:BASE / 1229
  :SBUS<n>:UART:TRIGger:BURSt / 1230
  :SBUS<n>:UART:TRIGger:DATA / 1231
  :SBUS<n>:UART:TRIGger:IDLE / 1232
  :SBUS<n>:UART:TRIGger:QUALifier / 1233
  :SBUS<n>:UART:TRIGger:TYPE / 1234
  :SBUS<n>:UART:WIDTh / 1235
:SBUS<n>:USB Commands / 1236
  :SBUS<n>:USB:BASE / 1239
  :SBUS<n>:USB:SOURce:DMINus / 1240
  :SBUS<n>:USB:SOURce:DPLus / 1241
  :SBUS<n>:USB:SOURce:DIFFerential / 1242
  :SBUS<n>:USB:SPEEd / 1243
  :SBUS<n>:USB:TRIGger / 1244
  :SBUS<n>:USB:TRIGger:ADDRes / 1245
  :SBUS<n>:USB:TRIGger:CRC / 1246
  :SBUS<n>:USB:TRIGger:DATA / 1247
  :SBUS<n>:USB:TRIGger:DATA:LENGth / 1248
  :SBUS<n>:USB:TRIGger:ENDPoint / 1249
  :SBUS<n>:USB:TRIGger:ET / 1250
  :SBUS<n>:USB:TRIGger:FRAME / 1251
  :SBUS<n>:USB:TRIGger:HADDress / 1252
  :SBUS<n>:USB:TRIGger:PCHeck / 1253
  :SBUS<n>:USB:TRIGger:PID:DATA / 1254
  :SBUS<n>:USB:TRIGger:PID:HANDshake / 1255
  :SBUS<n>:USB:TRIGger:PID:SPECial / 1256
  :SBUS<n>:USB:TRIGger:PID:TOKen / 1257
  :SBUS<n>:USB:TRIGger:PORT / 1258

```

- :SBUS<n>:USB:TRIGger:SC / 1259
- :SBUS<n>:USB:TRIGger:SEU / 1260
- :SBUS<n>:USBPd Commands / 1261
 - :SBUS<n>:USBPd:SOURce / 1262
 - :SBUS<n>:USBPd:TRIGger / 1263
 - :SBUS<n>:USBPd:TRIGger:HEADer / 1264
 - :SBUS<n>:USBPd:TRIGger:HEADer:CMESsage / 1266
 - :SBUS<n>:USBPd:TRIGger:HEADer:DMESsage / 1268
 - :SBUS<n>:USBPd:TRIGger:HEADer:EMESsage / 1269
 - :SBUS<n>:USBPd:TRIGger:HEADer:VALue / 1271
 - :SBUS<n>:USBPd:TRIGger:HEADer:QUALifier / 1272

38 :SEARch Commands

- General :SEARch Commands / 1274
 - :SEARch:COUNT / 1275
 - :SEARch:EVENT / 1276
 - :SEARch:MODE / 1277
 - :SEARch:STATe / 1278
- :SEARch:EDGE Commands / 1279
 - :SEARch:EDGE:SLOPe / 1280
 - :SEARch:EDGE:SOURce / 1281
- :SEARch:GLITCh Commands / 1282
 - :SEARch:GLITCh:GREaterthan / 1283
 - :SEARch:GLITCh:LESSthan / 1284
 - :SEARch:GLITCh:POLarity / 1285
 - :SEARch:GLITCh:QUALifier / 1286
 - :SEARch:GLITCh:RANGe / 1287
 - :SEARch:GLITCh:SOURce / 1288
- :SEARch:PEAK Commands / 1289
 - :SEARch:PEAK:EXCursion / 1290
 - :SEARch:PEAK:NPEaks / 1291
 - :SEARch:PEAK:SOURce / 1292
 - :SEARch:PEAK:THReshold / 1293
- :SEARch:RUNT Commands / 1294
 - :SEARch:RUNT:POLarity / 1295
 - :SEARch:RUNT:QUALifier / 1296
 - :SEARch:RUNT:SOURce / 1297
 - :SEARch:RUNT:TIME / 1298
- :SEARch:TRANSition Commands / 1299

- :SEARch:TRANsition:QUALifier / 1300
- :SEARch:TRANsition:SLOPe / 1301
- :SEARch:TRANsition:SOURce / 1302
- :SEARch:TRANsition:TIME / 1303
- :SEARch:SERial:A429 Commands / 1304
 - :SEARch:SERial:A429:LABel / 1305
 - :SEARch:SERial:A429:MODE / 1306
 - :SEARch:SERial:A429:PATtern:DATA / 1307
 - :SEARch:SERial:A429:PATtern:SDI / 1308
 - :SEARch:SERial:A429:PATtern:SSM / 1309
- :SEARch:SERial:CAN Commands / 1310
 - :SEARch:SERial:CAN:MODE / 1311
 - :SEARch:SERial:CAN:PATtern:DATA / 1313
 - :SEARch:SERial:CAN:PATtern:DATA:LENGth / 1314
 - :SEARch:SERial:CAN:PATtern:ID / 1315
 - :SEARch:SERial:CAN:PATtern:ID:MODE / 1316
 - :SEARch:SERial:CAN:SYMBolic:MESSAge / 1317
 - :SEARch:SERial:CAN:SYMBolic:SIGNal / 1318
 - :SEARch:SERial:CAN:SYMBolic:VALue / 1319
- :SEARch:SERial:FLEXray Commands / 1320
 - :SEARch:SERial:FLEXray:CYCLe / 1321
 - :SEARch:SERial:FLEXray:DATA / 1322
 - :SEARch:SERial:FLEXray:DATA:LENGth / 1323
 - :SEARch:SERial:FLEXray:FRAMe / 1324
 - :SEARch:SERial:FLEXray:MODE / 1325
- :SEARch:SERial:I2S Commands / 1326
 - :SEARch:SERial:I2S:AUDio / 1327
 - :SEARch:SERial:I2S:MODE / 1328
 - :SEARch:SERial:I2S:PATtern:DATA / 1329
 - :SEARch:SERial:I2S:PATtern:FORMat / 1330
 - :SEARch:SERial:I2S:RANGe / 1331
- :SEARch:SERial:IIC Commands / 1332
 - :SEARch:SERial:IIC:MODE / 1333
 - :SEARch:SERial:IIC:PATtern:ADDRes / 1335
 - :SEARch:SERial:IIC:PATtern:DATA / 1336
 - :SEARch:SERial:IIC:PATtern:DATA2 / 1337
 - :SEARch:SERial:IIC:QUALifier / 1338
- :SEARch:SERial:LIN Commands / 1339
 - :SEARch:SERial:LIN:ID / 1340

- :SEARch:SERial:LIN:MODE / 1341
- :SEARch:SERial:LIN:PATtern:DATA / 1342
- :SEARch:SERial:LIN:PATtern:DATA:LENGth / 1343
- :SEARch:SERial:LIN:PATtern:FORMat / 1344
- :SEARch:SERial:LIN:SYMBolic:FRAMe / 1345
- :SEARch:SERial:LIN:SYMBolic:SIGNal / 1346
- :SEARch:SERial:LIN:SYMBolic:VALue / 1347
- :SEARch:SERial:M1553 Commands / 1348
 - :SEARch:SERial:M1553:MODE / 1349
 - :SEARch:SERial:M1553:PATtern:DATA / 1350
 - :SEARch:SERial:M1553:RTA / 1351
- :SEARch:SERial:SENT Commands / 1352
 - :SEARch:SERial:SENT:FAST:DATA / 1353
 - :SEARch:SERial:SENT:MODE / 1354
 - :SEARch:SERial:SENT:SLOW:DATA / 1355
 - :SEARch:SERial:SENT:SLOW:ID / 1356
- :SEARch:SERial:SPI Commands / 1357
 - :SEARch:SERial:SPI:MODE / 1358
 - :SEARch:SERial:SPI:PATtern:DATA / 1359
 - :SEARch:SERial:SPI:PATtern:WIDTh / 1360
- :SEARch:SERial:UART Commands / 1361
 - :SEARch:SERial:UART:DATA / 1362
 - :SEARch:SERial:UART:MODE / 1363
 - :SEARch:SERial:UART:QUALifier / 1364
- :SEARch:SERial:USB Commands / 1365
 - :SEARch:SERial:USB:MODE / 1367
 - :SEARch:SERial:USB:ADDResS / 1368
 - :SEARch:SERial:USB:CRC / 1369
 - :SEARch:SERial:USB:DATA / 1370
 - :SEARch:SERial:USB:DATA:LENGth / 1371
 - :SEARch:SERial:USB:ENDPoint / 1372
 - :SEARch:SERial:USB:ET / 1373
 - :SEARch:SERial:USB:FRAMe / 1374
 - :SEARch:SERial:USB:HADDress / 1375
 - :SEARch:SERial:USB:PID:DATA / 1376
 - :SEARch:SERial:USB:PID:HANDshake / 1377
 - :SEARch:SERial:USB:PID:SPECial / 1378
 - :SEARch:SERial:USB:PID:TOKen / 1379
 - :SEARch:SERial:USB:PORT / 1380
 - :SEARch:SERial:USB:SC / 1381

:SEARCh:SERial:USB:SEU / 1382

39 :SYSTem Commands

:SYSTem:DATE / 1386
:SYSTem:DIentifier / 1387
:SYSTem:DSP / 1388
:SYSTem:ERRor / 1389
:SYSTem:LOCK / 1390
:SYSTem:PERSonA[:MANufacturer] / 1391
:SYSTem:PERSonA[:MANufacturer]:DEFault / 1392
:SYSTem:PRECision / 1393
:SYSTem:PRECision:LENGth / 1394
:SYSTem:PRESet / 1395
:SYSTem:PROTectio:n:LOCK / 1398
:SYSTem:RLOGger / 1399
:SYSTem:RLOGger:DESTination / 1400
:SYSTem:RLOGger:DISPlay / 1401
:SYSTem:RLOGger:FNAME / 1402
:SYSTem:RLOGger:STATe / 1403
:SYSTem:RLOGger:TRANSPARENT / 1404
:SYSTem:RLOGger:WMODE / 1405
:SYSTem:SETup / 1406
:SYSTem:TIME / 1408
:SYSTem:TOUCh / 1409

40 :TIMEbase Commands

:TIMEbase:MODE / 1413
:TIMEbase:POSition / 1414
:TIMEbase:RANGe / 1415
:TIMEbase:REFClock / 1416
:TIMEbase:REFerence / 1417
:TIMEbase:REFerence:LOCation / 1418
:TIMEbase:SCALE / 1419
:TIMEbase:VERNier / 1420
:TIMEbase:WINDow:POSition / 1421
:TIMEbase:WINDow:RANGe / 1422
:TIMEbase:WINDow:SCALE / 1423

41 :TRIGger Commands

General :TRIGger Commands / 1427
:TRIGger:FORCe / 1429

- :TRIGger:HFReject / 1430
- :TRIGger:HOLDoff / 1431
- :TRIGger:HOLDoff:MAXimum / 1432
- :TRIGger:HOLDoff:MINimum / 1433
- :TRIGger:HOLDoff:RANDom / 1434
- :TRIGger:JFRee / 1435
- :TRIGger:LEVel:ASETup / 1436
- :TRIGger:LEVel:HIGH / 1437
- :TRIGger:LEVel:LOW / 1438
- :TRIGger:MODE / 1439
- :TRIGger:NREject / 1440
- :TRIGger:SWEEp / 1441
- :TRIGger:DElay Commands / 1442
 - :TRIGger:DElay:ARM:SLOPe / 1443
 - :TRIGger:DElay:ARM:SOURce / 1444
 - :TRIGger:DElay:TDElay:TIME / 1445
 - :TRIGger:DElay:TRIGger:COUNt / 1446
 - :TRIGger:DElay:TRIGger:SLOPe / 1447
 - :TRIGger:DElay:TRIGger:SOURce / 1448
- :TRIGger:EBURst Commands / 1449
 - :TRIGger:EBURst:COUNt / 1450
 - :TRIGger:EBURst:IDLE / 1451
 - :TRIGger:EBURst:SLOPe / 1452
 - :TRIGger:EBURst:SOURce / 1453
- :TRIGger[:EDGE] Commands / 1454
 - :TRIGger[:EDGE]:COUPling / 1456
 - :TRIGger[:EDGE]:LEVel / 1457
 - :TRIGger[:EDGE]:REject / 1458
 - :TRIGger[:EDGE]:SLOPe / 1459
 - :TRIGger[:EDGE]:SOURce / 1460
- :TRIGger:GLITch Commands / 1461
 - :TRIGger:GLITch:GREaterthan / 1463
 - :TRIGger:GLITch:LESSthan / 1464
 - :TRIGger:GLITch:LEVel / 1465
 - :TRIGger:GLITch:POLarity / 1466
 - :TRIGger:GLITch:QUALifier / 1467
 - :TRIGger:GLITch:RANGe / 1468
 - :TRIGger:GLITch:SOURce / 1469
- :TRIGger:OR Commands / 1470
 - :TRIGger:OR / 1471

- :TRIGger:PATtern Commands / 1472
 - :TRIGger:PATtern / 1473
 - :TRIGger:PATtern:FORMat / 1475
 - :TRIGger:PATtern:GREaterthan / 1476
 - :TRIGger:PATtern:LESSthan / 1477
 - :TRIGger:PATtern:QUALifier / 1478
 - :TRIGger:PATtern:RANGe / 1479
- :TRIGger:RUNT Commands / 1480
 - :TRIGger:RUNT:POLarity / 1481
 - :TRIGger:RUNT:QUALifier / 1482
 - :TRIGger:RUNT:SOURce / 1483
 - :TRIGger:RUNT:TIME / 1484
- :TRIGger:SHOLd Commands / 1485
 - :TRIGger:SHOLd:SLOPe / 1486
 - :TRIGger:SHOLd:SOURce:CLOCK / 1487
 - :TRIGger:SHOLd:SOURce:DATA / 1488
 - :TRIGger:SHOLd:TIME:HOLD / 1489
 - :TRIGger:SHOLd:TIME:SETup / 1490
- :TRIGger:TRANSition Commands / 1491
 - :TRIGger:TRANSition:QUALifier / 1492
 - :TRIGger:TRANSition:SLOPe / 1493
 - :TRIGger:TRANSition:SOURce / 1494
 - :TRIGger:TRANSition:TIME / 1495
- :TRIGger:TV Commands / 1496
 - :TRIGger:TV:LINE / 1497
 - :TRIGger:TV:MODE / 1498
 - :TRIGger:TV:POLarity / 1499
 - :TRIGger:TV:SOURce / 1500
 - :TRIGger:TV:STANdard / 1501
 - :TRIGger:TV:UDTV:ENUMber / 1502
 - :TRIGger:TV:UDTV:HSYNc / 1503
 - :TRIGger:TV:UDTV:HTIME / 1504
 - :TRIGger:TV:UDTV:PGTHan / 1505
- :TRIGger:ZONE Commands / 1506
 - :TRIGger:ZONE:SOURce / 1507
 - :TRIGger:ZONE:STATe / 1508
 - :TRIGger:ZONE<n>:MODE / 1509
 - :TRIGger:ZONE<n>:PLACement / 1510
 - :TRIGger:ZONE<n>:VALidity / 1511

:TRIGger:ZONE<n>:STATe / 1512

42 :WAVeform Commands

:WAVeform:BYTeorder / 1521
:WAVeform:COUNT / 1522
:WAVeform:DATA / 1523
:WAVeform:FORMat / 1525
:WAVeform:POINts / 1526
:WAVeform:POINts:MODE / 1528
:WAVeform:PREamble / 1530
:WAVeform:SEGMented:ALL / 1533
:WAVeform:SEGMented:COUNT / 1534
:WAVeform:SEGMented:TTAG / 1535
:WAVeform:SEGMented:XLISt / 1536
:WAVeform:SOURce / 1537
:WAVeform:SOURce:SUBSource / 1541
:WAVeform:TYPE / 1542
:WAVeform:UNSigned / 1543
:WAVeform:VIEW / 1544
:WAVeform:XINCrement / 1545
:WAVeform:XORigin / 1546
:WAVeform:XREFerence / 1547
:WAVeform:YINCrement / 1548
:WAVeform:YORigin / 1549
:WAVeform:YREFerence / 1550

43 :WGEN<w> Commands

:WGEN<w>:ARBitrary:BYTeorder / 1556
:WGEN<w>:ARBitrary:DATA / 1557
:WGEN<w>:ARBitrary:DATA:ATTRibute:POINts / 1560
:WGEN<w>:ARBitrary:DATA:CLEar / 1561
:WGEN<w>:ARBitrary:DATA:DAC / 1562
:WGEN<w>:ARBitrary:INTErpolate / 1563
:WGEN<w>:ARBitrary:STORe / 1564
:WGEN<w>:FREQuency / 1565
:WGEN<w>:FUNCTion / 1566
:WGEN<w>:FUNCTion:PULSe:WIDTh / 1570
:WGEN<w>:FUNCTion:RAMP:SYMMetry / 1571
:WGEN<w>:FUNCTion:SQUare:DCYCLE / 1572
:WGEN<w>:MODulation:AM:DEPTH / 1573
:WGEN<w>:MODulation:AM:FREQuency / 1574

:WGEN<w>:MODulation:FM:DEVIation / 1575
 :WGEN<w>:MODulation:FM:FREQuency / 1576
 :WGEN<w>:MODulation:FSKey:FREQuency / 1577
 :WGEN<w>:MODulation:FSKey:RATE / 1578
 :WGEN<w>:MODulation:FUNCTion / 1579
 :WGEN<w>:MODulation:FUNCTion:RAMP:SYMMetry / 1580
 :WGEN<w>:MODulation:NOISe / 1581
 :WGEN<w>:MODulation:STATe / 1582
 :WGEN<w>:MODulation:TYPE / 1583
 :WGEN<w>:OUTPut / 1585
 :WGEN<w>:OUTPut:LOAD / 1586
 :WGEN<w>:OUTPut:MODE / 1587
 :WGEN<w>:OUTPut:POLarity / 1588
 :WGEN<w>:OUTPut:SINGLE / 1589
 :WGEN<w>:PERiod / 1590
 :WGEN<w>:RST / 1591
 :WGEN<w>:TRACk / 1592
 :WGEN<w>:TRACk:AMPLitude / 1593
 :WGEN<w>:TRACk:CSIGnal / 1594
 :WGEN<w>:TRACk:FREQuency / 1595
 :WGEN<w>:TRACk:PHASe / 1596
 :WGEN<w>:VOLTage / 1597
 :WGEN<w>:VOLTage:HIGH / 1598
 :WGEN<w>:VOLTage:LOW / 1599
 :WGEN<w>:VOLTage:OFFSet / 1600

44 :WMemory<r> Commands

:WMemory<r>:CLEar / 1603
 :WMemory<r>:DISPlay / 1604
 :WMemory<r>:LABel / 1605
 :WMemory<r>:SAVE / 1606
 :WMemory<r>:SKEW / 1607
 :WMemory<r>:YOFFset / 1608
 :WMemory<r>:YRANge / 1609
 :WMemory<r>:YSCale / 1610

45 Obsolete and Discontinued Commands

:CHANnel:ACTivity / 1618
 :CHANnel:LABel / 1619
 :CHANnel:THReshold / 1620
 :CHANnel2:SKEW / 1621

:CHANnel<n>:INPut / 1622
:CHANnel<n>:PMODE / 1623
:DISPlay:CONNect / 1624
:DISPlay:ORDer / 1625
:ERASe / 1626
:EXTernal:PMODE / 1627
:FUNcTion:GOFT:OPERation / 1628
:FUNcTion:GOFT:SOURce1 / 1629
:FUNcTion:GOFT:SOURce2 / 1630
:FUNcTion:SOURce / 1631
:FUNcTion:VIEW / 1632
:HARDcopy:DESTination / 1633
:HARDcopy:FILename / 1634
:HARDcopy:GRAYscale / 1635
:HARDcopy:IGColors / 1636
:HARDcopy:PDRiver / 1637
:MEASure:LOWer / 1638
:MEASure:SCRatch / 1639
:MEASure:TDELta / 1640
:MEASure:THResholds / 1641
:MEASure:TMAX / 1642
:MEASure:TMIN / 1643
:MEASure:TSTArt / 1644
:MEASure:TSTOp / 1645
:MEASure:TVOLt / 1646
:MEASure:UPPer / 1647
:MEASure:VDELta / 1648
:MEASure:VSTArt / 1649
:MEASure:VSTOp / 1650
:MEASure:VTIme / 1651
:MTEST:AMASK:{SAVE | STORe} / 1652
:MTEST:AVERage / 1653
:MTEST:AVERage:COUNT / 1654
:MTEST:LOAD / 1655
:MTEST:RUMode / 1656
:MTEST:RUMode:SOFailure / 1657
:MTEST:{STARt | STOp} / 1658
:MTEST:TRIGger:SOURce / 1659
:PRINt? / 1660
:SAVE:IMAGe:AREA / 1662
:SBUS<n>:LIN:SIGNal:DEFinition / 1663
:SBUS<n>:SPI:SOURce:DATA / 1664

:SYSTem:MENU / 1665
:TIMebase:DELay / 1666
:TRIGger:THReshold / 1667
:TRIGger:TV:TVMode / 1668

46 Error Messages

47 Status Reporting

Status Reporting Data Structures / 1679
Status Byte Register (STB) / 1682
Service Request Enable Register (SRE) / 1684
Trigger Event Register (TER) / 1685
Output Queue / 1686
Message Queue / 1687
(Standard) Event Status Register (ESR) / 1688
(Standard) Event Status Enable Register (ESE) / 1689
Error Queue / 1690
Operation Status Event Register (:OPERRegister[:EVENT]) / 1691
Operation Status Condition Register (:OPERRegister:CONDition) / 1693
Arm Event Register (AER) / 1694
Overload Event Register (:OVLRegister) / 1695
Hardware Event Event Register (:HWERRegister[:EVENT]) / 1696
Hardware Event Condition Register (:HWERRegister:CONDition) / 1697
Mask Test Event Event Register (:MTERRegister[:EVENT]) / 1698
Clearing Registers and Queues / 1699
Status Reporting Decision Chart / 1700
Example: Checking for Armed Status / 1701
Example: Waiting for IO Operation Complete / 1706

48 Synchronizing Acquisitions

Synchronization in the Programming Flow / 1710
 Set Up the Oscilloscope / 1710
 Acquire a Waveform / 1710
 Retrieve Results / 1710
Blocking Synchronization / 1711

Polling Synchronization With Timeout / 1712
Synchronizing with a Single-Shot Device Under Test (DUT) / 1714
Synchronization with an Averaging Acquisition / 1716
Example: Blocking and Polling Synchronization / 1718

49 More About Oscilloscope Commands

Command Classifications / 1730
 Core Commands / 1730
 Non-Core Commands / 1730
 Obsolete Commands / 1730
Valid Command/Query Strings / 1731
 Program Message Syntax / 1731
 Duplicate Mnemonics / 1735
 Tree Traversal Rules and Multiple Commands / 1735
Query Return Values / 1737

50 Programming Examples

VISA COM Examples / 1740
 VISA COM Example in Visual Basic / 1740
 VISA COM Example in C# / 1749
 VISA COM Example in Visual Basic .NET / 1758
 VISA COM Example in Python / 1766
VISA Examples / 1774
 VISA Example in C / 1774
 VISA Example in Visual Basic / 1783
 VISA Example in C# / 1793
 VISA Example in Visual Basic .NET / 1804
 VISA Example in Python / 1814
VISA.NET Examples / 1821
 VISA.NET Example in C# / 1821
 VISA.NET Example in Visual Basic .NET / 1827
 VISA.NET Example in Python / 1833
SICL Examples / 1840
 SICL Example in C / 1840
 SICL Example in Visual Basic / 1849
SCPI.NET Examples / 1860

Index

1 What's New

What's New in Version 7.60 / 42

What's New in Version 7.35 / 43

What's New in Version 7.30 / 45

What's New in Version 7.20 / 47

What's New in Version 7.10 / 49

What's New in Version 6.10 / 55

Version 6.00 at Introduction / 59

Command Differences From 4000 X-Series Oscilloscopes / 60

What's New in Version 7.60

New features in version 7.60 of the InfiniiVision 6000 X-Series oscilloscope software are:

- New commands for reading and setting the manufacturer string.

More detailed descriptions of the new and changed commands appear below.

New Commands

Command	Description
<code>:SYSTem:PERSonA[:MANUFACTURer]</code> (see page 1391)	Lets you change the manufacturer string portion of the identification string returned by the <code>*IDN?</code> query.
<code>:SYSTem:PERSonA[:MANUFACTURer]:DEFault</code> (see page 1392)	Sets manufacturer string to "KEYSIGHT TECHNOLOGIES".

What's New in Version 7.35

New features in version 7.35 of the InfiniiVision 6000 X-Series oscilloscope software are:

- New commands for clearing persistence data from the display and querying the run state.
- New commands for measurement limit test.
- New commands for external scaling on analog input channels.
- New commands for the band-pass filter and Chart Serial Signal math functions.
- New command for setting the INTeGrate math function initial condition.
- New commands for the N275xA probe's InfiniiMode and Single button controls.

More detailed descriptions of the new and changed commands appear below.

New Commands

Command	Description
:CHANnel<n>:PROBe:BTn (see page 363)	For N275xA InfiniiMode probes, this command sets the probe's quick-action button mode.
:CHANnel<n>:PROBe:CALibrati on (see page 364)	Begins the probe degauss operation. For the N7026A and N2893A probes only.
:CHANnel<n>:PROBe:EXTernal (see page 366)	Enables or disables External Scaling on the analog input channel.
:CHANnel<n>:PROBe:EXTernal:GAIN (see page 367)	Sets the gain associated with External Scaling.
:CHANnel<n>:PROBe:EXTernal:UNITs (see page 368)	Sets the units to associated with the analog input channel.
:CHANnel<n>:PROBe:MODE (see page 372)	For N275xA InfiniiMode probes, this command sets the probe's mode.
:DISPlay:PERSiStence:CLEar (see page 451)	Erases all persistence data from the display, leaving the data from the last acquisition.
:FUNctiOn<m>:FREQuency:BA NDpass:CENTer (see page 512)	Sets the center frequency of the band-pass filter.
:FUNctiOn<m>:FREQuency:BA NDpass:WIDth (see page 513)	Sets the frequency width of the band-pass filter.
:FUNctiOn<m>:INTegrate:ICon dition (see page 516)	Sets the Initial Condition of the Integrate math function waveform.
:FUNctiOn<m>:SERChart:SOUR ce (see page 529)	Sets the serial bus source for the Chart Serial Signal math function.

Command	Description
:FUNction<m>:SERChart:TIME:MODE (see page 530)	Sets the time mode for the Chart Serial Signal math function.
:FUNction<m>:SERChart:TIME:RANGe (see page 532)	When the ROLL serial chart time mode is selected, this command sets the full-scale range value for the Chart Serial Signal math function.
:FUNction<m>:SERChart:TIME:OFFSet (see page 533)	When the ROLL serial chart time mode is selected, this command sets the time offset for the Chart Serial Signal math function.
:LTEST Commands (see page 599)	Commands for using the Measurement Limit Test feature.
:RState? (see page 293)	Returns the run state.

Changed Commands

Command	Differences
:FUNction<m>:OPERation (see page 521)	The BAND and SERChart (Chart Serial Signal) operations have been added.
:MEASure:DElay:DEFine (see page 676)	Adds the ability to specify LOWER or UPPER edge thresholds (in addition to MIDDLE) for both source 1 and source 2.

What's New in Version 7.30

New features in version 7.30 of the InfiniiVision 6000 X-Series oscilloscope software are:

- New Slew Rate and Y at X measurements along with improvements to the Time at Edge measurement and support for digital channels in the Delay, Positive Pulse Count, and Negative Pulse Count measurements.
- Added support for getting waveform data for all segments at once (when in the segmented acquisition mode).
- Added support for licenses that allow support subscriptions.

More detailed descriptions of the new and changed commands appear below.

New Commands

Command	Description
:MEASure:SLEWrate (see page 726)	Installs a slew rate measurement on screen or returns the measured value.
:MEASure:YATX (see page 756)	Installs a Y at X (vertical value at horizontal location) measurement on screen or returns the measured value.
:SYSTem:DIIdentifier? (see page 1387)	Returns the oscilloscope's Host ID string.
:WAVEform:SEGmented:ALL (see page 1533)	Enables or disables the "waveform data for all segments" setting.
:WAVEform:SEGmented:XLIST? (see page 1536)	Returns the X (time) information for all segments at once.

Changed Commands

Command	Differences
:MEASure:DElay (see page 674)	You are now able to perform delay measurements on digital input channels.
:MEASure:NPULses (see page 708)	You are now able to perform delay measurements on digital input channels.
:MEASure:PPULses (see page 715)	You are now able to perform delay measurements on digital input channels.
:MEASure:TEDGE (see page 735)	There is now a command to install the measurement on the oscilloscope's display and there is a new optional <slope> parameter.
*OPT? (see page 243)	New license information is possible in the returned string.

Obsolete
Commands

Obsolete Command	Current Command Equivalent	Behavior Differences
:MEASure:VTIME (see page 1651)	:MEASure:YATX (see page 756)	With :MEASure:YATX, there is a command for installing the measurement on the oscilloscope's display. :MEASure:VTIME had no command, only a query.

What's New in Version 7.20

New features in version 7.20 of the InfiniiVision 6000 X-Series oscilloscope software are:

- USB PD (Power Delivery) serial decode and triggering option.

More detailed descriptions of the new and changed commands appear below.

New Commands

Command	Description
:DISPlay:MESSage:CLEar (see page 449)	Removes all user messages that are currently on screen.
:FRANalysis:FREQuency:SINgLe (see page 472)	Sets the single frequency value.
:FRANalysis:TRACe (see page 479)	Specifies whether to include gain, phase, both gain and phase, or neither in the frequency response analysis results.
:POWer:CLResponse:DATA:GMARgin? (see page 832)	Returns the gain margin in dB.
:POWer:CLResponse:DATA:GMARgin:FREQuency? (see page 833)	Returns the 0° phase crossover frequency in Hz.
:POWer:CLResponse:DATA:PMARgin? (see page 834)	Returns the phase margin in degrees.
:POWer:CLResponse:DATA:PMARgin:FREQuency? (see page 835)	Returns the 0 dB gain crossover frequency in Hz.
:POWer:CLResponse:FREQuency:SINgLe (see page 837)	Sets the single frequency value.
:POWer:CLResponse:TRACe (see page 843)	Specifies whether to include gain, phase, both gain and phase, or neither in the control loop response analysis results.
:POWer:PSRR:FREQuency:SINgLe (see page 882)	Sets the single frequency value.
:POWer:PSRR:TRACe (see page 886)	Specifies whether to include gain (PSRR) data in the power supply rejection ratio analysis results.
:SBUS<n>:A429:BAUDrate (see page 986)	Specifies the user-defined baud rate.
:SBUS<n>:SPI:DELay (see page 1202)	Specifies the number of bits to ignore (delay) before decoding the MISO stream.
:SBUS<n>:USBPd Commands (see page 1261)	Commands for using the USB PD triggering and serial decode feature.

Changed Commands

Command	Differences
:DEMO:FUNCTION (see page 414)	The USBPd function is now available.
:RECall:WMEMory<r>:[START] (see page 935)	There is now a <data> option for recalling waveform data from the controller PC.
:SBUS<n>:A429:SPEEd (see page 993)	The USER option is now available to select a user-defined baud rate.
:SBUS<n>:MANChester:BAUDRate (see page 1126)	The minimum baud rate is changed from "2000" to "500".
:SBUS<n>:MODE (see page 981)	The USBPd mode is now available with the USB PD serial decode and triggering license.
:SBUS<n>:SENT:PPULse (see page 1172)	The pause mode now, in addition supporting pause pulses off and on, supports SENT SPC (Short PWM Code) where message events are triggered by the master.

What's New in Version 7.10

New features in version 7.10 of the InfiniiVision 6000 X-Series oscilloscope software are:

- Random trigger holdoff mode.
- FFT detectors are added.
- FFT measurements are added: Adjacent Channel Power Ratio (ACPR), Channel Power, Occupied Bandwidth, and Total Harmonic Distortion.
- Frequency Response Analysis feature is added.
- CXPI (Clock Extension Peripheral Interface) serial decode and triggering option.
- Power measurements application updates.
- Added FFTPhase math function.
- Custom timebase reference—as a percent, from the left edge to the right edge of the graticule.
- Added remote commands for specifying N2820A high-sensitivity current probe zoom-in channel and N2825A user-defined R-sense head resistor value.
- Remote commands for remote command logging.

More detailed descriptions of the new and changed commands appear below.

New Commands

Command	Description
:CHANnel<n>:PROBe:RSENse (see page 373)	When the N2820A high-sensitivity current probe is used with the N2825A user-defined R-sense head, this command specifies the value of the R-sense resistor that is being probed in the device under test (DUT).
:CHANnel<n>:PROBe:ZOOM (see page 376)	When the N2820A high-sensitivity current probe is used with both the Primary and Secondary cables, this command specifies whether this cable will have the Zoom In waveform (ON) or the Zoom Out waveform (OFF).
:DISPlay:GRATicule:ALABels (see page 442)	Turns graticule (grid) axis labels on or off.
:DISPlay:GRATicule:INTensity (see page 443)	Sets the graticule (grid) intensity.
:DISPlay:GRATicule:TYPE (see page 444)	Sets the graticule (grid) type.
:FRANalysis Commands (see page 467)	Commands for using the Frequency Response Analysis feature.
:FUNction<m>[:FFT]:BSIZE? (see page 498)	Returns the Bin Size setting for the FFT.

Command	Description
:FUNction<m>[:FFT]:DETEction :POINts (see page 500)	Specifies the maximum number of points that the FFT detector should decimate to.
:FUNction<m>[:FFT]:DETEction :TYPE (see page 501)	Sets the FFT detector decimation type.
:FUNction<m>[:FFT]:GATE (see page 504)	Specifies whether the FFT is performed on the Main time base window or the Zoom window when the zoomed time base is displayed.
:FUNction<m>[:FFT]:PHASe:RE FERENCE (see page 505)	Sets the reference point for calculating the FFT Phase function to either the trigger point or beginning of the displayed waveform.
:FUNction<m>[:FFT]:RBWidth? (see page 506)	Returns the Resolution Bandwidth setting for the FFT.
:FUNction<m>[:FFT]:READout<n> (see page 507)	For the FFT, selects from these types of readouts: Resolution Bandwidth, Bin Size, or Sample Rate.
:FUNction<m>[:FFT]:SRATE? (see page 509)	Returns the Sample Rate setting for the FFT.
:HCOPY:SDUMp:DATA? (see page 557)	Reads screen image data.
:HCOPY:SDUMp:FORMat (see page 558)	Specifies the format for screen image data: 24-bit PNG, 24-bit BMP, or 8-bit BMP8bit.
:MEASure:FFT:ACPR (see page 685)	Installs an FFT analysis Adjacent Channel Power Ratio (ACPR) measurement on screen or returns the measured value.
:MEASure:FFT:CPOWER (see page 686)	Installs an FFT analysis Channel Power measurement on screen or returns the measured value.
:MEASure:FFT:OBW (see page 687)	Installs an FFT analysis Occupied Bandwidth measurement on screen or returns the measured value.
:MEASure:FFT:THD (see page 688)	Installs an FFT analysis Total Harmonic Distortion measurement on screen or returns the measured value.
:MARKer:X1:DISPlay (see page 618)	Specifies whether the X1 cursor is displayed.
:MARKer:X2:DISPlay (see page 621)	Specifies whether the X2 cursor is displayed.
:MARKer:Y1:DISPlay (see page 627)	Specifies whether the Y1 cursor is displayed.
:MARKer:Y2:DISPlay (see page 629)	Specifies whether the Y2 cursor is displayed.
:MEASure:DELAy:DEFine (see page 676)	Defines slope directions and edge numbers for the :MEASure:DELAy command.
:POWER:CLResponse? (see page 829)	Returns the Control Loop Response (Bode) power analysis settings.

Command	Description
:POWer:CLResponse:DATA? (see page 831)	Returns data from the Control Loop Response (Bode) power analysis.
:POWer:CLResponse:FREQuency:MODE (see page 836)	Specifies whether the analysis should be performed by sweeping through a range of frequencies (SWEep) or at a single frequency (SINGle).
:POWer:CLResponse:PPDecade (see page 840)	Selects the number of frequency test points per decade (in the log scale).
:POWer:CLResponse:SOURce:INPut (see page 841)	Selects the oscilloscope channel that is probing the power supply input.
:POWer:CLResponse:SOURce:OUTPut (see page 842)	Selects the oscilloscope channel that is probing the power supply output.
:POWer:CLResponse:WGEN:LOAD (see page 844)	Sets the waveform generator expected output load impedance.
:POWer:CLResponse:WGEN:VOLTagE (see page 845)	Sets the waveform generator output amplitude(s).
:POWer:CLResponse:WGEN:VOLTagE:PROFile (see page 846)	Enables or disables the ability to set initial waveform generator ramp amplitudes for each frequency range.
:POWer:ITYPe (see page 866)	Specifies the type of input power that is being converted to the output.
:POWer:ONOFF:THResholds (see page 874)	Specifies the input and output thresholds used in the Turn On/Turn Off analysis.
:POWer:PSRR? (see page 876)	Returns the Power Supply Rejection Ratio (PSRR) power analysis settings.
:POWer:PSRR:DATA? (see page 878)	Returns data from the Power Supply Rejection Ratio (PSRR) power analysis.
:POWer:PSRR:FREQuency:MODE (see page 881)	Specifies whether the analysis should be performed by sweeping through a range of frequencies (SWEep) or at a single frequency (SINGle).
:POWer:PSRR:PPDecade (see page 883)	Selects the number of frequency test points per decade (in the log scale).
:POWer:PSRR:SOURce:INPut (see page 884)	Selects the oscilloscope channel that is probing the power supply input.
:POWer:PSRR:SOURce:OUTPut (see page 885)	Selects the oscilloscope channel that is probing the power supply output.
:POWer:PSRR:WGEN:LOAD (see page 887)	Sets the waveform generator expected output load impedance.
:POWer:PSRR:WGEN:VOLTagE (see page 888)	Sets the waveform generator output amplitude(s).

Command	Description
:POWer:PSRR:WGEN:VOLTage:PROFile (see page 889)	Enables or disables the ability to set initial waveform generator ramp amplitudes for each frequency range.
:SBUS<n>:CXPI Commands (see page 1031)	Commands for using the CXPI triggering and serial decode feature.
:SBUS<n>:MANChester Commands (see page 1123)	Commands for using the Manchester triggering and serial decode feature.
:SBUS<n>:NRZ Commands (see page 1142)	Commands for using the NRZ triggering and serial decode feature.
:SYSTem:RLOGger (see page 1399)	Enables or disables remote command logging, optionally specifying the log file name and write mode.
:SYSTem:RLOGger:DESTination (see page 1400)	Specifies whether remote commands are logged to a text file (on a connected USB storage device), logged to the screen, or both.
:SYSTem:RLOGger:DISPlay (see page 1401)	Enables or disables the screen display of logged remote commands and their return values (if applicable).
:SYSTem:RLOGger:FNAME (see page 1402)	Specifies the remote command log file name.
:SYSTem:RLOGger:STATe (see page 1403)	Enables or disables remote command logging.
:SYSTem:RLOGger:TRANsparen t (see page 1404)	Specifies whether the screen display background for remote command logging is transparent or solid.
:SYSTem:RLOGger:WMODE (see page 1405)	Specifies the remote command logging write mode (either CREate or APPend).
:TIMEbase:REFerence:LOCation (see page 1418)	When the :TIMEbase:REFerence is set to CUSTom, this command lets you place the time reference location at a percent of the graticule width (where 0.0 is the left edge and 1.0 is the right edge).
:TRIGger:HOLDoff:MAXimum (see page 1432)	When the random trigger holdoff mode is enabled, this command specifies the maximum trigger holdoff time.
:TRIGger:HOLDoff:MINimum (see page 1433)	When the random trigger holdoff mode is enabled, this command specifies the minimum trigger holdoff time.
:TRIGger:HOLDoff:RANDom (see page 1434)	Enables or disables the random trigger holdoff mode.

Changed Commands

Command	Differences
:CHANnel<n>:PROBe (see page 362)	The probe attenuation factor can now be set from 0.001:1 to 10000:1.
:CHANnel<n>:PROBe:HEAD:TY PE (see page 369)	The DSMA and DSMA6 probe head types can now be selected.

Command	Differences
:DEMO:FUNCTION (see page 414)	The CXPI and MANchester functions are now available with the educator's kit.
:FUNCTION<m>[:FFT]:VTYPE (see page 510)	With the FFTPhase operation, you can select vertical units in DEGRees or RADians.
:FUNCTION<m>[:FFT]:WINDOW (see page 511)	The BARTlett window is now available.
:FUNCTION<m>:OPERation (see page 521)	The MAXimum, MINimum, PEAK, and FFTPhase operations are added.
:FUNCTION<m>:SOURce1 (see page 535)	Reference waveforms can now be specified as source 1.
:FUNCTION<m>:SOURce2 (see page 537)	Reference waveforms can now be specified as source 2.
:JITTER:SPECTrum:WINDOW (see page 586)	The BARTlett window is now available.
:MEASURE:DELAY (see page 674)	You can now specify an <edge_select_mode> with the command and query.
:OPERRegister:CONDition (see page 282)	Bit 4 in the Operation Status Condition Register now shows whether the remote user interface is enabled.
:OPERRegister[:EVENT] (see page 285)	Bit 4 in the Operation Status Event Register now indicates when the remote user interface has gone from a disabled state to an enabled state.
:POWER:HARMONics:LINE (see page 855)	The AUTO frequency option is added. This option automatically determines the frequency of the Current waveform.
:SBUS<n>:LIN:STANdard (see page 1104)	The LIN13NLC option is added for selecting LIN 1.3 (no length control).
:SBUS<n>:MODE (see page 981)	The CXPI mode is now available with the CXPI serial decode and triggering license, and the MANchester and NRZ modes are now available with the Manchester/NRZ serial decode and triggering license.
:TIMEbase:REFerence (see page 1417)	The CUSTom option is added for placing the time reference location at a percent of the graticule width.

Discontinued
Commands

Discontinued Command	Current Command Equivalent	Comments
:POWer:CLResponse:VIEW	none	Because the plot now appears in its own dialog box and contains both gain and phase plots, there is no longer a need to select one or the other.
:POWer:CLResponse:YMAXimum	none	Specifying the plot's initial vertical scale maximum value is no longer necessary because the plot now appears in its own dialog box and is autoscaled.
:POWer:CLResponse:YMINimum	none	Specifying the plot's initial vertical scale minimum value is no longer necessary because the plot now appears in its own dialog box and is autoscaled.
:POWer:PSRR:RMAXimum	none	Specifying the plot's initial vertical scale value is no longer necessary because the plot now appears in its own dialog box and is autoscaled.

What's New in Version 6.10

New features in version 6.10 of the InfiniiVision 6000 X-Series oscilloscope software are:

- The Control Loop Response (Bode) power analysis now lets you select a phase plot as well as a gain plot.
- Updates to support CAN FD serial decode and triggering, including the ISO standard.
- Up to 10 annotations are supported.
- Being able to load LIN symbolic data from an LDF (*.ldf) file into the oscilloscope, display it in the decode, and use it to set up triggers and protocol decode searches.
- SENT serial decode and triggering option.
- New built-in demo signals (with education kit).

More detailed descriptions of the new and changed commands appear below.

New Commands

Command	Description
:CHANnel<n>:PROBe:MMODEl (see page 371)	Sets the model number of the supported Tektronix probe.
:DISPlay:ANNotation<n>:X1Pos ition (see page 436)	Sets the horizontal position of one of the 10 annotations.
:DISPlay:ANNotation<n>:Y1Pos ition (see page 437)	Sets the vertical position of one of the 10 annotations.
:DISPlay:BACKlight (see page 438)	Turns the display's backlight off or on.
:MEASure:BRATe (see page 662)	Installs a bit rate measurement on screen or returns the measured value.
:MEASure:RDSon (see page 775)	Installs an RDS(on) power measurement on screen or returns the measured value.
:MEASure:VCESat (see page 780)	Installs a VCE(sat) power measurement on screen or returns the measured value.
:POWer:CLResponse:APPLY (see page 830)	Performs the Control Loop Response (Bode) power analysis.
:POWer:CLResponse:FREQuen cy:START (see page 838)	Sets the sweep start frequency value.
:POWer:CLResponse:FREQuen cy:STOP (see page 839)	Sets the sweep stop frequency value.

Command	Description
:POWer:CLResponse:VIEW	When the Control Loop Response (Bode) power analysis is selected, this command selects whether to display a gain or phase plot.
:POWer:CLResponse:YMAXimum	Specifies the Bode plot's initial vertical scale maximum value.
:POWer:CLResponse:YMINimum	Specifies the Bode plot's initial vertical scale minimum value.
:POWer:EFFiciency:TYPE (see page 849)	Specifies the type of power that is being converted from the input to the output.
:POWer:HARMonics:RPOWer (see page 857)	When Class D is selected as the current harmonics analysis standard, this command specifies whether the Real Power value used for the current-per-watt measurement is measured by the oscilloscope or is defined by the user.
:POWer:HARMonics:RPOWer:USER (see page 858)	When Class D is selected as the current harmonics analysis standard and you have chosen to use a user-defined Real Power value, this command specifies the Real Power value used in the current-per-watt measurement.
:RECall:LDF[:START] (see page 931)	Loads a LIN description file (LDF) into the oscilloscope.
:SBUS<n>:CAN:COUNT:SPEC (see page 1007)	Returns the count for the number of Spec errors (Ack + Form + Stuff + CRC errors).
:SBUS<n>:CAN:FDSPoint (see page 1011)	Sets the CAN FD sample point.
:SBUS<n>:CAN:FDStandard (see page 1012)	Lets you pick the standard that will be used when decoding or triggering on FD frames, ISO, or non-ISO.
:SBUS<n>:CAN:SIGNal:FDbaud rate (see page 1016)	Sets the CAN FD baud rate.
:SBUS<n>:CAN:TRIGger:IDFilter (see page 1021)	Specifies, in certain error and bit trigger modes, whether triggers are filtered by CAN IDs.
:SBUS<n>:CAN:TRIGger:PATTERN:DATA:DLC (see page 1023)	Specifies the DLC value to be used in the CAN FD data trigger mode.
:SBUS<n>:CAN:TRIGger:PATTERN:DATA:START (see page 1025)	Specifies the starting byte position for CAN FD data triggers.
:SBUS<n>:LIN:DISPlay (see page 1099)	Specifies whether symbolic values (from a loaded LDF file) or hexadecimal values are displayed in the decode waveform and the Lister window
:SBUS<n>:LIN:TRIGger:SYMBOLic:FRAME (see page 1113)	Specifies the frame to trigger on when LIN symbolic data has been loaded (recalled) into the oscilloscope and the LIN trigger mode is set to FRAME or FSIGNAL.

Command	Description
:SBUS<n>:LIN:TRIGger:SYMBOLic:SIGNal (see page 1114)	Specifies signal to trigger on when LIN symbolic data has been loaded (recalled) into the oscilloscope and the LIN trigger mode is set to FSIGNal.
:SBUS<n>:LIN:TRIGger:SYMBOLic:VALue (see page 1115)	Specifies signal value to trigger on when LIN symbolic data has been loaded (recalled) into the oscilloscope and the LIN trigger mode is set to FSIGNal.
:SBUS<n>:SENT Commands (see page 1161)	Commands for using the SENT triggering and serial decode feature.
:SEARch:SERial:LIN:SYMBOLic:FRAME (see page 1345)	Specifies the message to search for when LIN symbolic data has been loaded (recalled) into the oscilloscope and the LIN serial search mode is set to FRAME or FSIGNal.
:SEARch:SERial:LIN:SYMBOLic:SIGNal (see page 1346)	Specifies signal to search for when LIN symbolic data has been loaded (recalled) into the oscilloscope and the LIN serial search mode is set to FSIGNal.
:SEARch:SERial:LIN:SYMBOLic:VALue (see page 1347)	Specifies signal value to search for when LIN symbolic data has been loaded (recalled) into the oscilloscope and the LIN serial search mode is set to FSIGNal.
:SEARch:SERial:SENT Commands (see page 1352)	Commands for searching SENT serial decode events.
:WGEN<w>:OUTPut:MODE (see page 1587)	Specifies whether the defined waveform is output continuously or as a single cycle (single-shot).
:WGEN<w>:OUTPut:SINGLE (see page 1589)	When the single-shot output mode is selected, this command causes a single cycle of the defined waveform to be output.
:WGEN<w>:TRACk:PHASe (see page 1596)	Sets the phase relationship of a frequency-tracked waveform generator output.

Changed Commands

Command	Differences
:DEMO:FUNCTion (see page 414)	The HARMonics, COUPling, CFD, and SENT functions are now available with the educator's kit.
:DISPlay:ANNotation<n> (see page 432)	You can now define up to 10 annotations.
:DISPlay:ANNotation<n>:BACKground (see page 433)	
:DISPlay:ANNotation<n>:COLor (see page 434)	
:DISPlay:ANNotation<n>:TEXT (see page 435)	
:DISPlay:SIDebar (see page 452)	The EVENTs and COUNter options are now available.

Command	Differences
:FUNction<m>:OPERation (see page 521)	The ENvelope operations are added.
:POWER:SIGNals:AUTOsetup (see page 892)	The RDSVce option is now available.
:SBUS<n>:CAN:COUNT:OVERload (see page 1005)	Always returns zero.
:SBUS<n>:CAN:TRIGger (see page 1018)	Additional parameters added to support CAN FD triggering and CAN FD ISO support.
:SBUS<n>:IIC:TRIGger[:TYPE] (see page 1095)	There are new ADDRESS and DNACK modes.
:SBUS<n>:LIN:TRIGger (see page 1106)	You can now trigger on symbolic frames (with parameter FRAME) or frames and signal values (with parameter FSIGNAL).
:SBUS<n>:MODE (see page 981)	The SENT mode is now available with the SENT serial decode and triggering license.
:SEARch:SERial:CAN:MODE (see page 1311)	Has additional parameters that support CAN FD searching.
:SEARch:SERial:IIC:MODE (see page 1333)	There is new ADDRESS mode.
:SEARch:SERial:LIN:MODE (see page 1341)	You can now search for symbolic messages (with parameter FRAME) or frames and signal values (with parameter FSIGNAL).
:WAVEform:SOURce:SUBSource (see page 1541)	You can use FAST (alias for SUB0) to get SENT fast channel data or SLOW (alias for SBUS1) to get SENT slow channel data.

Version 6.00 at Introduction

The Keysight InfiniiVision 6000 X-Series oscilloscopes were introduced with version 6.00 of oscilloscope operating software.

The command set is most closely related to the InfiniiVision 3000 X-Series oscilloscopes (and the 7000A/B Series, 6000 Series, and 54620/54640 Series oscilloscopes before them). For more information, see "[Command Differences From 4000 X-Series Oscilloscopes](#)" on page 60.

Command Differences From 4000 X-Series Oscilloscopes

The Keysight InfiniiVision 6000 X-Series oscilloscopes command set is most closely related to the InfiniiVision 4000 X-Series oscilloscopes (and the 3000 X-Series, 7000A/B Series, 6000 Series, and 54620/54640 Series oscilloscopes before them).

The main differences between the version 6.00 programming command set for the InfiniiVision 6000 X-Series oscilloscopes and the 3.20 programming command set for the InfiniiVision 4000 X-Series oscilloscopes are related to:

- Histogram feature.
- Color grade waveform analysis feature.
- Clock recovery feature.
- Precision measurements and math functions feature.
- Jitter analysis feature (license-enabled).
- Counter feature.
- A couple new built-in demo signals (with education kit).

More detailed descriptions of the new, changed, obsolete, and discontinued commands appear below.

New Commands

Command	Description
:CLOCK Commands (see page 383)	Commands for controlling the clock recovery feature.
:CGRade Commands (see page 341)	Commands for controlling the color grade waveform analysis feature.
:CHANnel<n>:BANDwidth (see page 353)	Sets bandwidth limiting for an analog input channel.
:COUNter Commands (see page 401)	Commands for controlling the counter feature.
:FUNction<m>:CLEar (see page 496)	When the :FUNction<m>:OPERation is AVERage, MAXHold, or MINHold, this command clears the number of evaluated waveforms.
:FUNction<m>[:FFT]:FREQuency:STARt (see page 502)	Lets you set the displayed frequency range using start and stop frequency values.
:FUNction<m>[:FFT]:FREQuency:STOP (see page 503)	
:FUNction<m>:SMOoth:POINts (see page 534)	Sets the number of smoothing points for the new SMOoth :FUNction<m>:OPERation.
:HISTogram Commands (see page 559)	Commands for controlling the histogram analysis feature.

Command	Description
:JITter Commands (see page 575)	Commands for controlling the license-enabled jitter analysis feature.
:MEASure:CTCNwidth (see page 667)	Returns the -Width to -Width jitter value.
:MEASure:CTCPwidth (see page 669)	Returns the +Width to +Width jitter value.
:MEASure:HISTogram:BWIDth (see page 690)	Returns the histogram bin width.
:MEASure:HISTogram:HITS (see page 691)	Returns the histogram total number of hits.
:MEASure:HISTogram:M1S (see page 692)	Returns the histogram percentage of hits within +/-1 standard deviation.
:MEASure:HISTogram:M2S (see page 693)	Returns the histogram percentage of hits within +/-2 standard deviations.
:MEASure:HISTogram:M3S (see page 694)	Returns the histogram percentage of hits within +/-3 standard deviations.
:MEASure:HISTogram:MAXimu m (see page 695)	Returns the histogram maximum bin value.
:MEASure:HISTogram:MEAN (see page 696)	Returns the histogram mean value.
:MEASure:HISTogram:MEDian (see page 697)	Returns the histogram median value.
:MEASure:HISTogram:MINimu m (see page 698)	Returns the histogram minimum bin value.
:MEASure:HISTogram:MODE (see page 699)	Returns the histogram mode value.
:MEASure:HISTogram:PEAK (see page 700)	Returns the histogram number of hits in max bin.
:MEASure:HISTogram:PPEak (see page 701)	Returns the histogram delta value between max bin and min bin.
:MEASure:HISTogram:SDEViati on (see page 702)	Returns the histogram standard deviation value.
:MEASure:NCJitter (see page 703)	Returns the N-Period to N-Period jitter value.
:MEASure:NPERiod (see page 707)	Returns the N-Period jitter value.
:MEASure:RTEYe:EHEight (see page 722)	Returns the real-time eye vertical eye opening.

Command	Description
:MEASure:RTEYe:EWIDth (see page 723)	Returns the real-time eye horizontal eye opening.
:MEASure:TIEData (see page 738)	Returns the Data TIE jitter value.
:MEASure:TIEClock (see page 740)	Returns the Clock TIE jitter value.
:RTEYe Commands (see page 937)	Commands for controlling the real-time eye analysis feature.
:SAVE:RESults:[START] (see page 960)	Saves analysis results to a comma-separated values (*.csv) file on a USB storage device.
:SAVE:RESults:FORMat:CGRad e (see page 961)	Specifies whether color grade bin counts will be included when analysis results are saved.
:SAVE:RESults:FORMat:CURSo r (see page 962)	Specifies whether cursor values will be included when analysis results are saved.
:SAVE:RESults:FORMat:HISTog ram (see page 963)	Specifies whether histogram statistics will be included when analysis results are saved.
:SAVE:RESults:FORMat:MASK (see page 964)	Specifies whether mask statistics will be included when analysis results are saved.
:SAVE:RESults:FORMat:MEASu rement (see page 965)	Specifies whether measurement results will be included when analysis results are saved.
:SAVE:RESults:FORMat:SEARc h (see page 966)	Specifies whether found search event times will be included when analysis results are saved.
:SAVE:RESults:FORMat:SEGMe nted (see page 967)	Specifies whether segmented memory acquisition times will be included when analysis results are saved.
:SEARch:PEAK Commands (see page 1289)	Commands to set up searching for FFT peaks.
:SYSTem:PRECision (see page 1393)	Enables or disables the precision measurements and math functions feature.
:SYSTem:PRECision:LENGth (see page 1394)	Specifies the length of the precision analysis record.
:TRIGger:JFRee (see page 1435)	Disables or enables the Jitter-Free Trigger option.

Changed Commands

Command	Differences From InfiniiVision 4000 X-Series Oscilloscopes
:ACQUIRE:MODE (see page 308)	The MRTime max update rate real-time mode is available on all 6000 X-Series models, and the ETIME mode is available with the 6 GHz bandwidth models.
:DEMO:FUNCTION (see page 414)	The JITTER, DCMotor, RTEYE, and SJITTER functions are now available with the educator's kit.
:DISPLAY:SIDEBAR (see page 452)	The HISTOGRAM option is available.
:DVM:MODE (see page 459)	The FREQUENCY option has been replaced by the new Chapter 15 , “:COUNTER Commands,” starting on page 401.
:FUNCTION<m>:OPERATION (see page 521)	The SMOOTH, MAXHOLD, MINHOLD, and CLOCK operations are added.
:MARKER:X1Y1SOURCE (see page 620)	The HISTOGRAM and CGRADE sources are available in certain modes.
:MARKER:X2Y2SOURCE (see page 623)	The HISTOGRAM and CGRADE sources are available in certain modes.
:SEARCH:MODE (see page 1277)	The PEAK option has been added to enable searching for FFT peaks (see “:SEARCH:PEAK Commands” on page 1289).

Discontinued Commands

Discontinued Command	Current Command Equivalent	Comments
:DVM:FREQUENCY?	:COUNTER:CURRENT? (see page 403)	The :DVM:FREQUENCY? query has been replaced by the new Chapter 15 , “:COUNTER Commands,” starting on page 401.
:FUNCTION<m>:TREND:MEASUREMENT	:FUNCTION<m>:TREND:NMEASUREMENT (see page 538)	The current command specifies the number of an installed measurement instead of a measurement name.

2 Setting Up

Step 1. Install Keysight IO Libraries Suite software / 66

Step 2. Connect and set up the oscilloscope / 67

Step 3. Verify the oscilloscope connection / 69

This chapter explains how to install the Keysight IO Libraries Suite software, connect the oscilloscope to the controller PC, set up the oscilloscope, and verify the oscilloscope connection.

Step 1. Install Keysight IO Libraries Suite software

- 1 Download the Keysight IO Libraries Suite software from the Keysight web site at:
 - <http://www.keysight.com/find/iolib>
- 2 Run the setup file, and follow its installation instructions.

Step 2. Connect and set up the oscilloscope

The 6000 X-Series oscilloscope has two different interfaces you can use for programming:

- USB (device port).
- LAN. To configure the LAN interface, press the **[Utility]** key on the front panel, then press the **I/O** softkey, then press the **Configure** softkey.

These interfaces are always active.




Figure 1 Control Connectors on Rear Panel

Using the USB (Device) Interface

- 1 Connect a USB cable from the controller PC's USB port to the "USB DEVICE" port on the back of the oscilloscope.

This is a USB 2.0 high-speed port.

Using the LAN Interface

- 1 If the controller PC is not already connected to the local area network (LAN), do that first.
- 2 Contact your network administrator about adding the oscilloscope to the network.

Find out if automatic configuration via DHCP or AutoIP can be used. Also, find out whether your network supports Dynamic DNS or Multicast DNS.

If automatic configuration is not supported, get the oscilloscope's network parameters (hostname, domain, IP address, subnet mask, gateway IP, DNS IP, etc.).

- 3 Connect the oscilloscope to the local area network (LAN) by inserting LAN cable into the "LAN" port on the back of the oscilloscope.
- 4 Configure the oscilloscope's LAN interface:
 - a Press the **Configure** softkey until "LAN" is selected.
 - b Press the **LAN Settings** softkey.
 - c Press the **Config** softkey, and enable all the configuration options supported by your network.
 - d If automatic configuration is not supported, press the **Addresses** softkey.

Use the **Modify** softkey (and the other softkeys and the Entry knob) to enter the IP Address, Subnet Mask, Gateway IP, and DNS IP values.


When you are done, press the **[Back up]** key.

- e Press the **Host name** softkey. Use the softkeys and the Entry knob to enter the Host name.


When you are done, press the **[Back up]** key.

Step 3. Verify the oscilloscope connection


- 1 On the controller PC, click on the Keysight IO Control icon in the taskbar and choose **Connection Expert** from the popup menu.



- 2 In the Keysight Connection Expert application, instruments connected to the controller's USB and GPIB interfaces as well as instruments on the same LAN subnet should automatically appear in the Instruments tab.



- 3 If your instrument does not appear, you can add it using the Manual Configuration tab.




For example, to add a device:


- a Select **LAN instrument** in the list on the left.
- b Enter the oscilloscope's **Hostname** or **IP address**.
- c Select the protocol.
- d Select **Instrument** under Set Protocol.
- e Click **Test This VISA Address** to verify the connection.
- f If the connection test is successful, click **Accept** to add the instrument.

If the connection test is not successful, go back and verify the LAN connections and the oscilloscope setup.

- 4 Test some commands on the instrument:
 - a In the Details for the selected instrument, click **Send Commands To This Instrument**.



- b In the Keysight Interactive IO application, enter commands in the **Command** field and press **Send Command**, **Read Response**, or **Send & Read**.



- c Choose **Connect > Exit** from the menu to exit the Keysight Interactive IO application.
- 5 In the Keysight Connection Expert application, choose **File > Exit** from the menu to exit the application.

3 Getting Started

Basic Oscilloscope Program Structure / 74

Programming the Oscilloscope / 76

Other Ways of Sending Commands / 85

This chapter gives you an overview of programming the 6000 X-Series oscilloscopes. It describes basic oscilloscope program structure and shows how to program the oscilloscope using a few simple examples.

The getting started examples show how to send oscilloscope setup, data capture, and query commands, and they show how to read query results.


NOTE

Language for Program Examples

The programming examples in this guide are written in Visual Basic using the Keysight VISA COM library.

Basic Oscilloscope Program Structure

The following figure shows the basic structure of every program you will write for the oscilloscope.



Initializing

To ensure consistent, repeatable performance, you need to start the program, controller, and oscilloscope in a known state. Without correct initialization, your program may run correctly in one instance and not in another. This might be due to changes made in configuration by previous program runs or from the front panel of the oscilloscope.

- Program initialization defines and initializes variables, allocates memory, or tests system configuration.
- Controller initialization ensures that the interface to the oscilloscope is properly set up and ready for data transfer.
- Oscilloscope initialization sets the channel configuration, channel labels, threshold voltages, trigger specification, trigger mode, timebase, and acquisition type.

Capturing Data

Once you initialize the oscilloscope, you can begin capturing data for analysis. Remember that while the oscilloscope is responding to commands from the controller, it is not performing acquisitions. Also, when you change the oscilloscope configuration, any data already captured will most likely be rendered.

To collect data, you use the `:DIGitize` command. This command clears the waveform buffers and starts the acquisition process. Acquisition continues until acquisition memory is full, then stops. The acquired data is displayed by the oscilloscope, and the captured data can be measured, stored in acquisition memory in the oscilloscope, or transferred to the controller for further analysis. Any additional commands sent while `:DIGitize` is working are buffered until `:DIGitize` is complete.

You could also put the oscilloscope into run mode, then use a wait loop in your program to ensure that the oscilloscope has completed at least one acquisition before you make a measurement. Keysight does not recommend this because the needed length of the wait loop may vary, causing your program to fail. `:DIGitize`, on the other hand, ensures that data capture is complete. Also, `:DIGitize`, when complete, stops the acquisition process so that all measurements are on displayed data, not on a constantly changing data set.

Analyzing Captured Data

After the oscilloscope has completed an acquisition, you can find out more about the data, either by using the oscilloscope measurements or by transferring the data to the controller for manipulation by your program. Built-in measurements include: frequency, duty cycle, period, positive pulse width, and negative pulse width.

Using the `:WAVEform` commands, you can transfer the data to your controller. You may want to display the data, compare it to a known good measurement, or simply check logic patterns at various time intervals in the acquisition.

Programming the Oscilloscope

- "Referencing the IO Library" on page 76
- "Opening the Oscilloscope Connection via the IO Library" on page 77
- "Using :AUToscale to Automate Oscilloscope Setup" on page 78
- "Using Other Oscilloscope Setup Commands" on page 78
- "Capturing Data with the :DIGitize Command" on page 79
- "Reading Query Responses from the Oscilloscope" on page 81
- "Reading Query Results into String Variables" on page 82
- "Reading Query Results into Numeric Variables" on page 82
- "Reading Definite-Length Block Query Response Data" on page 82
- "Sending Multiple Queries and Reading Results" on page 83
- "Checking Instrument Status" on page 84


Referencing the IO Library

No matter which instrument programming library you use (SICL, VISA, or VISA COM), you must reference the library from your program.

In C/C++, you must tell the compiler where to find the include and library files (see the Keysight IO Libraries Suite documentation for more information).

To reference the Keysight VISA COM library in Visual Basic for Applications (VBA, which comes with Microsoft Office products like Excel):

- 1 Choose **Tools > References...** from the main menu.
- 2 In the References dialog, check the "VISA COM 5.5 Type Library".



- 3 Click **OK**.

To reference the Keysight VISA COM library in Microsoft Visual Basic 6.0:

- 1 Choose **Project > References...** from the main menu.
- 2 In the References dialog, check the "VISA COM 5.5 Type Library".
- 3 Click **OK**.

Opening the Oscilloscope Connection via the IO Library

PC controllers communicate with the oscilloscope by sending and receiving messages over a remote interface. Once you have opened a connection to the oscilloscope over the remote interface, programming instructions normally appear as ASCII character strings embedded inside write statements of the programming language. Read statements are used to read query responses from the oscilloscope.

For example, when using the Keysight VISA COM library in Visual Basic (after opening the connection to the instrument using the ResourceManager object's Open method), the FormattedIO488 object's WriteString, WriteNumber, WriteList, or WriteIIEEEBlock methods are used for sending commands and queries. After a query is sent, the response is read using the ReadString, ReadNumber, ReadList, or ReadIIEEEBlock methods.

The following Visual Basic statements open the connection and send a command that turns on the oscilloscope's label display.

```
Dim myMgr As VisaComLib.ResourceManager
Dim myScope As VisaComLib.FormattedIO488

Set myMgr = New VisaComLib.ResourceManager
Set myScope = New VisaComLib.FormattedIO488

' Open the connection to the oscilloscope. Get the VISA Address from the
' Keysight Connection Expert (installed with Keysight IO Libraries Suite
').
Set myScope.IO = myMgr.Open("<VISA Address>")

' Send a command.
myScope.WriteString ":DISPlay:LABel ON"
```

The ":DISPLAY:LABEL ON" in the above example is called a *program message*. Program messages are explained in more detail in "[Program Message Syntax](#)" on page 1731.

Initializing the Interface and the Oscilloscope

To make sure the bus and all appropriate interfaces are in a known state, begin every program with an initialization statement. When using the Keysight VISA COM library, you can use the resource session object's Clear method to clear the interface buffer:

```

Dim myMgr As VisaComLib.ResourceManager
Dim myScope As VisaComLib.FormattedIO488

Set myMgr = New VisaComLib.ResourceManager
Set myScope = New VisaComLib.FormattedIO488

' Open the connection to the oscilloscope. Get the VISA Address from the
' Keysight Connection Expert (installed with Keysight IO Libraries Suite
').
Set myScope.IO = myMgr.Open("<VISA Address>")

' Clear the interface buffer and set the interface timeout to 10 seconds
.
myScope.IO.Clear
myScope.IO.Timeout = 10000

```

When you are using GPIB, CLEAR also resets the oscilloscope's parser. The parser is the program which reads in the instructions which you send it.

After clearing the interface, initialize the instrument to a preset state:

```
myScope.WriteString "*RST"
```

NOTE**Information for Initializing the Instrument**

The actual commands and syntax for initializing the instrument are discussed in [Chapter 6, "Common \(*\) Commands,"](#) starting on page 229.

Refer to the Keysight IO Libraries Suite documentation for information on initializing the interface.

Using :AUToscale to Automate Oscilloscope Setup

The :AUToscale command performs a very useful function for unknown waveforms by setting up the vertical channel, time base, and trigger level of the instrument.

The syntax for the autoscale command is:

```
myScope.WriteString ":AUToscale"
```

Using Other Oscilloscope Setup Commands

A typical oscilloscope setup would set the vertical range and offset voltage, the horizontal range, delay time, delay reference, trigger mode, trigger level, and slope. An example of the commands that might be sent to the oscilloscope are:

```

myScope.WriteString ":CHANnel1:PROBe 10"
myScope.WriteString ":CHANnel1:RANGe 16"
myScope.WriteString ":CHANnel1:OFFSet 1.00"
myScope.WriteString ":TIMEbase:MODE MAIN"
myScope.WriteString ":TIMEbase:RANGe 1E-3"
myScope.WriteString ":TIMEbase:DELay 100E-6"

```

Vertical is set to 16 V full-scale (2 V/div) with center of screen at 1 V and probe attenuation set to 10. This example sets the time base at 1 ms full-scale (100 ms/div) with a delay of 100 μ s.

Example Oscilloscope Setup Code

This program demonstrates the basic command structure used to program the oscilloscope.

```
' Initialize the instrument interface to a known state.
myScope.IO.Clear
myScope.IO.Timeout = 10000 ' Set interface timeout to 10 seconds.

' Initialize the instrument to a preset state.
myScope.WriteString "*RST"

' Set the time base mode to normal with the horizontal time at
' 50 ms/div with 0 s of delay referenced at the center of the
' graticule.
myScope.WriteString ":TIMEbase:RANGE 5E-4" ' Time base to 50 us/div.
myScope.WriteString ":TIMEbase:DElay 0" ' Delay to zero.
myScope.WriteString ":TIMEbase:REfERENCE CENTER" ' Display ref. at
' center.

' Set the vertical range to 1.6 volts full scale with center screen
' at -0.4 volts with 10:1 probe attenuation and DC coupling.
myScope.WriteString ":CHANnel:PROBe 10" ' Probe attenuation
' to 10:1.
myScope.WriteString ":CHANnel:RANGE 1.6" ' Vertical range
' 1.6 V full scale.
myScope.WriteString ":CHANnel:OFFSet -0.4" ' Offset to -0.4.
myScope.WriteString ":CHANnel:COUPling DC" ' Coupling to DC.

' Configure the instrument to trigger at -0.4 volts with normal
' triggering.
myScope.WriteString ":TRIGger:SWEep NORMal" ' Normal triggering.
myScope.WriteString ":TRIGger:LEVel -0.4" ' Trigger level to -0.4.
myScope.WriteString ":TRIGger:SLOPe POSitive" ' Trigger on pos. slope.

' Configure the instrument for normal acquisition.
myScope.WriteString ":ACQuire:TYPE NORMal" ' Normal acquisition.
```

Capturing Data with the :DIGitize Command

The :DIGitize command captures data that meets the specifications set up by the :ACQuire subsystem. When the digitize process is complete, the acquisition is stopped. The captured data can then be measured by the instrument or transferred to the controller for further analysis. The captured data consists of two parts: the waveform data record, and the preamble.

NOTE**Ensure New Data is Collected**

When you change the oscilloscope configuration, the waveform buffers are cleared. Before doing a measurement, send the :DIGitize command to the oscilloscope to ensure new data has been collected.

When you send the :DIGitize command to the oscilloscope, the specified channel signal is digitized with the current :ACQUIRE parameters. To obtain waveform data, you must specify the :WAVEform parameters for the SOURce channel, the FORMat type, and the number of POINTs prior to sending the :WAVEform:DATA? query.

NOTE**Set :TIMEbase:MODE to MAIN when using :DIGitize**

:TIMEbase:MODE must be set to MAIN to perform a :DIGitize command or to perform any :WAVEform subsystem query. A "Settings conflict" error message will be returned if these commands are executed when MODE is set to ROLL, XY, or WINDow (zoomed). Sending the *RST (reset) command will also set the time base mode to normal.

The number of data points comprising a waveform varies according to the number requested in the :ACQUIRE subsystem. The :ACQUIRE subsystem determines the number of data points, type of acquisition, and number of averages used by the :DIGitize command. This allows you to specify exactly what the digitized information contains.

The following program example shows a typical setup:

```
myScope.WriteString ":ACQUIRE:TYPE AVERage"
myScope.WriteString ":ACQUIRE:COMPLete 100"
myScope.WriteString ":ACQUIRE:COUNt 8"
myScope.WriteString ":DIGitize CHANnel1"
myScope.WriteString ":WAVEform:SOURce CHANnel1"
myScope.WriteString ":WAVEform:FORMat BYTE"
myScope.WriteString ":WAVEform:POINTs 500"
myScope.WriteString ":WAVEform:DATA?"
```

This setup places the instrument into the averaged mode with eight averages. This means that when the :DIGitize command is received, the command will execute until the signal has been averaged at least eight times.

After receiving the :WAVEform:DATA? query, the instrument will start passing the waveform information.

Digitized waveforms are passed from the instrument to the controller by sending a numerical representation of each digitized point. The format of the numerical representation is controlled with the :WAVEform:FORMat command and may be selected as BYTE, WORD, or ASCii.

The easiest method of transferring a digitized waveform depends on data structures, formatting available and I/O capabilities. You must scale the integers to determine the voltage value of each point. These integers are passed starting with the left most point on the instrument's display.

For more information, see the waveform subsystem commands and corresponding program code examples in [Chapter 42](#), “:WAVEform Commands,” starting on page 1513.

NOTE**Aborting a Digitize Operation Over the Programming Interface**

When using the programming interface, you can abort a digitize operation by sending a Device Clear over the bus (for example, `myScope.IO.Clear`).

Reading Query Responses from the Oscilloscope

After receiving a query (command header followed by a question mark), the instrument interrogates the requested function and places the answer in its output queue. The answer remains in the output queue until it is read or another command is issued. When read, the answer is transmitted across the interface to the designated listener (typically a controller).

The statement for reading a query response message from an instrument's output queue typically has a format specification for handling the response message.

When using the VISA COM library in Visual Basic, you use different read methods (`ReadString`, `ReadNumber`, `ReadList`, or `ReadIEEEBlock`) for the various query response formats. For example, to read the result of the query command `:CHANnel1:COUPLing?` you would execute the statements:

```
myScope.WriteString ":CHANnel1:COUPLing?"
Dim strQueryResult As String
strQueryResult = myScope.ReadString
```

This reads the current setting for the channel one coupling into the string variable `strQueryResult`.

All results for queries (sent in one program message) must be read before another program message is sent.

Sending another command before reading the result of the query clears the output buffer and the current response. This also causes an error to be placed in the error queue.

Executing a read statement before sending a query causes the controller to wait indefinitely.

The format specification for handling response messages depends on the programming language.

Reading Query Results into String Variables

The output of the instrument may be numeric or character data depending on what is queried. Refer to the specific command descriptions for the formats and types of data returned from queries.

NOTE

Express String Variables Using Exact Syntax

In Visual Basic, string variables are case sensitive and must be expressed exactly the same each time they are used.

The following example shows numeric data being returned to a string variable:

```
myScope.WriteString ":CHANnel1:RANGe?"
Dim strQueryResult As String
strQueryResult = myScope.ReadString
MsgBox "Range (string):" + strQueryResult
```

After running this program, the controller displays:

Range (string): +40.0E+00

Reading Query Results into Numeric Variables

The following example shows numeric data being returned to a numeric variable:

```
myScope.WriteString ":CHANnel1:RANGe?"
Dim varQueryResult As Variant
varQueryResult = myScope.ReadNumber
MsgBox "Range (variant):" + CStr(varQueryResult)
```

After running this program, the controller displays:

Range (variant): 40

Reading Definite-Length Block Query Response Data

Definite-length block query response data allows any type of device-dependent data to be transmitted over the system interface as a series of 8-bit binary data bytes. This is particularly useful for sending large quantities of data or 8-bit extended ASCII codes. The syntax is a pound sign (#) followed by a non-zero digit representing the number of digits in the decimal integer. After the non-zero digit is the decimal integer that states the number of 8-bit data bytes being sent. This is followed by the actual data.

For example, for transmitting 1000 bytes of data, the syntax would be:




Figure 2 Definite-length block response data

The "8" states the number of digits that follow, and "00001000" states the number of bytes to be transmitted.

The VISA COM library's `ReadIEEEBlock` and `WriteIEEEBlock` methods understand the definite-length block syntax, so you can simply use variables that contain the data:

```
' Read oscilloscope setup using ":SYSTEM:SETup?" query.
myScope.WriteString ":SYSTEM:SETup?"
Dim varQueryResult As Variant
varQueryResult = myScope.ReadIEEEBlock(BinaryType_UI1)

' Write learn string back to oscilloscope using ":SYSTEM:SETup" command:
myScope.WriteIEEEBlock ":SYSTEM:SETup ", varQueryResult
```

Sending Multiple Queries and Reading Results

You can send multiple queries to the instrument within a single command string, but you must also read them back as a single query result. This can be accomplished by reading them back into a single string variable, multiple string variables, or multiple numeric variables.

For example, to read the `:TIMEbase:RANGe?;DELay?` query result into a single string variable, you could use the commands:

```
myScope.WriteString ":TIMEbase:RANGe?;DELay?"
Dim strQueryResult As String
strQueryResult = myScope.ReadString
MsgBox "Timebase range; delay:" + strQueryResult
```

When you read the result of multiple queries into a single string variable, each response is separated by a semicolon. For example, the output of the previous example would be:

```
Timebase range; delay: <range_value>;<delay_value>
```

To read the `:TIMEbase:RANGe?;DELay?` query result into multiple string variables, you could use the `ReadList` method to read the query results into a string array variable using the commands:

```
myScope.WriteString ":TIMEbase:RANGe?;DELay?"
Dim strResults() As String
strResults() = myScope.ReadList(ASCIIType_BSTR)
MsgBox "Timebase range: " + strResults(0) + ", delay: " + strResults(1)
```

To read the :TIMEbase:RANGe?;DELay? query result into multiple numeric variables, you could use the ReadList method to read the query results into a variant array variable using the commands:

```
myScope.WriteString ":TIMEbase:RANGe?;DELay?"  
Dim varResults() As Variant  
varResults() = myScope.ReadList  
MsgBox "Timebase range: " + FormatNumber(varResults(0) * 1000, 4) + _  
      " ms, delay: " + FormatNumber(varResults(1) * 1000000, 4) + " us"
```

Checking Instrument Status

Status registers track the current status of the instrument. By checking the instrument status, you can find out whether an operation has been completed, whether the instrument is receiving triggers, and more.

For more information, see [Chapter 47](#), “Status Reporting,” starting on page 1677 which explains how to check the status of the instrument.

Other Ways of Sending Commands

Standard Commands for Programmable Instrumentation (SCPI) can also be sent via a Telnet socket or through the Browser Web Control:

- **"Telnet Sockets"** on page 85
- **"Sending SCPI Commands Using Browser Web Control"** on page 85

Telnet Sockets

The following information is provided for programmers who wish to control the oscilloscope with SCPI commands in a Telnet session.

To connect to the oscilloscope via a telnet socket, issue the following command:

```
telnet <hostname> 5024
```

where <hostname> is the hostname of the oscilloscope. This will give you a command line with prompt.

For a command line without a prompt, use port 5025. For example:

```
telnet <hostname> 5025
```

Sending SCPI Commands Using Browser Web Control

To send SCPI commands using the Browser Web Control feature, establish a connection to the oscilloscope via LAN as described in the *InfiniiVision 6000 X-Series Oscilloscopes User's Guide*. When you make the connection to the oscilloscope via LAN and the instrument's welcome page is displayed, select the **Browser Web Control** tab, then select the **Remote Programming** link.

4 Sequential (Blocking) vs. Overlapped Commands

IEEE 488.2 makes the distinction between sequential and overlapped commands (and queries):

- *Sequential commands* also known as *blocking commands*, finish their task before the execution of the next command starts.

These oscilloscope commands and queries are sequential (blocking):

- :AUToscale
- :DIGitize
- :WMEMory<r>:SAVE <source>
- :WAVEform:DATA?
- *Overlapped commands* run concurrently. Commands following an overlapped command may be started before the overlapped command is completed.

Some oscilloscope commands are overlapped. For example, the oscilloscope's save and recall commands are overlapped as well as some commands that perform analysis.

With sequential (blocking) commands and queries, the oscilloscope is expected to stop processing inputs, including additional remote commands and queries as well as front panel knobs, until completed.

Pausing Execution Between Overlapped Commands

With overlapped commands, you can use the *OPC? query to prevent any more commands from being executed until the overlapped command is complete. This may be necessary when a command that follows an overlapped command interferes with the overlapped command's processing or analysis. For example:

```
:RECall:SETup "setup.scp";*OPC?;:RECall:ARBitrary "arb_wfm.csv"
```

You can also use the *ESR? query to look at the OPC bit (bit 0) in the Standard Event Status Register to determine when an operation is complete.

Pausing Programs Until Sequential (Blocking) Commands are Complete

Sequential (blocking) commands do not prevent additional commands from being sent to the queue or cause the remote program to wait. For example, if your program does something like:

```
myScope.WriteString ":DIGitize"
Debug.Print "Signal acquired."
```

The "Signal acquired" message will be written immediately after the :DIGitize is sent, not after the acquisition and processing is complete.

To pause the program until a sequential (blocking) command is complete, you must wait for a query result after the sequential (blocking) command. For example, in this case:

```
Public strQueryResult As String
myScope.WriteString ":DIGitize;*OPC?"
strQueryResult = myScope.ReadString
Debug.Print "Signal acquired."
```

The "Signal acquired" message will be written after the acquisition and processing is complete. The *OPC? query is appended to :DIGitize with a semi-colon (;), which essentially ties it to the same thread in the parser. It is immediately dealt with once :DIGitize finishes and gives a "1" back to the program (whether the program uses it or not), allowing the program to move on.

When using a query to wait until a sequential (blocking) command is complete, it is possible for the sequential (blocking) command execution to take longer than the I/O timeout, in which case, there will be a timeout error while waiting for the query results. You can increase the I/O timeout or have your program poll the Status Byte Register using the IO libraries' unblocked ReadSTB function to wait for execution completion.

Using Device Clear to Abort a Sequential (Blocking) Command

When sequential (blocking) commands take too long or fail to complete for some reason, you can send a Device Clear over the bus to clear the input buffer and output queue, reset the parser, and clear any pending commands.

- See Also
- ["*OPC \(Operation Complete\)"](#) on page 242
 - ["*ESR \(Standard Event Status Register\)"](#) on page 238
 - [Chapter 48](#), "Synchronizing Acquisitions," starting on page 1709

5 Commands Quick Reference

Command Summary / 90

Syntax Elements / 225

Command Summary

- Common (*) Commands Summary (see [page 92](#))
- Root (:) Commands Summary (see [page 97](#))
- :ACQuire Commands Summary (see [page 101](#))
- :BUS<n> Commands Summary (see [page 102](#))
- :CALibrate Commands Summary (see [page 103](#))
- :CGRade Commands Summary (see [page 104](#))
- :CHANnel<n> Commands Summary (see [page 105](#))
- :CLOCK Commands Summary (see [page 108](#))
- :COMPLiance Commands Summary (see [page 108](#))
- :COUNter Commands Summary (see [page 109](#))
- :DEMO Commands Summary (see [page 110](#))
- :DIGital<n> Commands Summary (see [page 111](#))
- :DISPlay Commands Summary (see [page 111](#))
- :DVM Commands Summary (see [page 113](#))
- :EXTernal Trigger Commands Summary (see [page 114](#))
- :FRANalysis Commands Summary (see [page 114](#))
- :FUNCTion Commands Summary (see [page 116](#))
- :HARDcopy Commands Summary (see [page 122](#))
- :HISTogram Commands Summary (see [page 123](#))
- :JITTer Commands Summary (see [page 124](#))
- :LISTer Commands Summary (see [page 125](#))
- :LTEST Commands Summary (see [page 126](#))
- :MARKer Commands Summary (see [page 126](#))
- :MEASure Commands Summary (see [page 129](#))
- :MTEST Commands Summary (see [page 151](#))
- :POD<n> Commands Summary (see [page 154](#))
- :POWer Commands Summary (see [page 154](#))
- :RECall Commands Summary (see [page 162](#))
- :RTEYe Commands Summary (see [page 163](#))
- :SAVE Commands Summary (see [page 164](#))
- General :SBUS<n> Commands Summary (see [page 167](#))
- :SBUS<n>:A429 Commands Summary (see [page 167](#))
- :SBUS<n>:CAN Commands Summary (see [page 169](#))

- :SBUS<n>:CXPI Commands Summary (see [page 171](#))
- :SBUS<n>:FLEXray Commands Summary (see [page 173](#))
- :SBUS<n>:I2S Commands Summary (see [page 174](#))
- :SBUS<n>:IIC Commands Summary (see [page 176](#))
- :SBUS<n>:LIN Commands Summary (see [page 177](#))
- :SBUS<n>:M1553 Commands Summary (see [page 179](#))
- :SBUS<n>:MANChester Commands Summary (see [page 180](#))
- :SBUS<n>:NRZ Commands Summary (see [page 181](#))
- :SBUS<n>:SENT Commands Summary (see [page 183](#))
- :SBUS<n>:SPI Commands Summary (see [page 185](#))
- :SBUS<n>:UART Commands Summary (see [page 186](#))
- :SBUS<n>:USB Commands Summary (see [page 189](#))
- :SBUS<n>:USBPd Commands Summary (see [page 191](#))
- General :SEARch Commands Summary (see [page 192](#))
- :SEARch:EDGE Commands Summary (see [page 192](#))
- :SEARch:GLITCh Commands Summary (see [page 193](#))
- :SEARch:PEAK Commands Summary (see [page 193](#))
- :SEARch:RUNT Commands Summary (see [page 194](#))
- :SEARch:TRANSition Commands Summary (see [page 194](#))
- :SEARch:SERial:A429 Commands Summary (see [page 195](#))
- :SEARch:SERial:CAN Commands Summary (see [page 196](#))
- :SEARch:SERial:FLEXray Commands Summary (see [page 196](#))
- :SEARch:SERial:I2S Commands Summary (see [page 197](#))
- :SEARch:SERial:IIC Commands Summary (see [page 198](#))
- :SEARch:SERial:LIN Commands Summary (see [page 198](#))
- :SEARch:SERial:M1553 Commands Summary (see [page 199](#))
- :SEARch:SERial:SENT Commands Summary (see [page 200](#))
- :SEARch:SERial:SPI Commands Summary (see [page 200](#))
- :SEARch:SERial:UART Commands Summary (see [page 201](#))
- :SEARch:SERial:USB Commands Summary (see [page 201](#))
- :SYSTem Commands Summary (see [page 203](#))
- :TIMebase Commands Summary (see [page 205](#))
- General :TRIGger Commands Summary (see [page 206](#))
- :TRIGger:DELaY Commands Summary (see [page 207](#))
- :TRIGger:EBURst Commands Summary (see [page 208](#))

- :TRIGger[:EDGE] Commands Summary (see [page 209](#))
- :TRIGger:GLITCh Commands Summary (see [page 210](#))
- :TRIGger:OR Commands Summary (see [page 211](#))
- :TRIGger:PATtern Commands Summary (see [page 212](#))
- :TRIGger:RUNT Commands Summary (see [page 213](#))
- :TRIGger:SHOLd Commands Summary (see [page 213](#))
- :TRIGger:TRANSition Commands Summary (see [page 214](#))
- :TRIGger:TV Commands Summary (see [page 214](#))
- :TRIGger:ZONE Commands Summary (see [page 215](#))
- :WAVEform Commands Summary (see [page 216](#))
- :WGEN Commands Summary (see [page 219](#))
- :WMEMory<r> Commands Summary (see [page 223](#))

Table 2 Common (*) Commands Summary

Command	Query	Options and Query Returns																																				
*CLS (see page 235)	n/a	n/a																																				
*ESE <mask> (see page 236)	*ESE? (see page 236)	<p><mask> ::= 0 to 255; an integer in NR1 format:</p> <table border="0"> <thead> <tr> <th>Bit</th> <th>Weight</th> <th>Name</th> <th>Enables</th> </tr> </thead> <tbody> <tr> <td>7</td> <td>128</td> <td>PON</td> <td>Power On</td> </tr> <tr> <td>6</td> <td>64</td> <td>URQ</td> <td>User Request</td> </tr> <tr> <td>5</td> <td>32</td> <td>CME</td> <td>Command Error</td> </tr> <tr> <td>4</td> <td>16</td> <td>EXE</td> <td>Execution Error</td> </tr> <tr> <td>3</td> <td>8</td> <td>DDE</td> <td>Dev. Dependent Error</td> </tr> <tr> <td>2</td> <td>4</td> <td>QYE</td> <td>Query Error</td> </tr> <tr> <td>1</td> <td>2</td> <td>RQL</td> <td>Request Control</td> </tr> <tr> <td>0</td> <td>1</td> <td>OPC</td> <td>Operation Complete</td> </tr> </tbody> </table>	Bit	Weight	Name	Enables	7	128	PON	Power On	6	64	URQ	User Request	5	32	CME	Command Error	4	16	EXE	Execution Error	3	8	DDE	Dev. Dependent Error	2	4	QYE	Query Error	1	2	RQL	Request Control	0	1	OPC	Operation Complete
Bit	Weight	Name	Enables																																			
7	128	PON	Power On																																			
6	64	URQ	User Request																																			
5	32	CME	Command Error																																			
4	16	EXE	Execution Error																																			
3	8	DDE	Dev. Dependent Error																																			
2	4	QYE	Query Error																																			
1	2	RQL	Request Control																																			
0	1	OPC	Operation Complete																																			
n/a	*ESR? (see page 238)	<status> ::= 0 to 255; an integer in NR1 format																																				
n/a	*IDN? (see page 238)	<p>AGILENT TECHNOLOGIES,<model>,<serial number>,X.XX.XX</p> <p><model> ::= the model number of the instrument</p> <p><serial number> ::= the serial number of the instrument</p> <p><X.XX.XX> ::= the software revision of the instrument</p>																																				

Table 2 Common (*) Commands Summary (continued)

Command	Query	Options and Query Returns
n/a	*LRN? (see page 241)	<learn_string> ::= current instrument setup as a block of data in IEEE 488.2 # format
*OPC (see page 242)	*OPC? (see page 242)	ASCII "1" is placed in the output queue when all pending device operations have completed.

Table 2 Common (*) Commands Summary (continued)

Command	Query	Options and Query Returns
n/a	*OPT? (see page 243)	<pre> <return_value> ::= 0,0,<license info> <license info> ::= <All field>, <reserved>, <reserved>, <MSO>, <reserved>, <Memory>, <Low Speed Serial>, <Automotive Serial>, <FlexRay Serial>, <Frequency Response Analysis>, <Power Measurements>, <RS-232/UART Serial>, <Segmented Memory>, <Mask Test>, <reserved>, <Bandwidth>, <reserved>, <reserved>, <reserved>, <reserved>, <reserved>, <reserved>, <I2S Serial>, <reserved>, <Educator's Kit>, <Waveform Generator>, <MIL-1553/ARINC 429 Serial>, <Extended Video>, <Advanced Math>, <reserved>, <reserved>, <reserved>, <reserved>, <Digital Voltmeter/Counter>, <reserved>, <reserved>, <USB 2.0 Low/Full Speed>, <USB 2.0 High Speed>, <USB 2.0 Signal Quality Analysis >, <Remote Command Logging>, <reserved>, <SENT Serial>, <CAN FD Serial>, <CXPI Serial>, <reserved>, <Jitter Analysis>, <reserved>, <reserved>, <Manchester/NRZ Serial>, <USB PD Serial>, <reserved>, <Automotive Software>, <General Purpose Software>, <Aerospace Software>, <Power Supply Test Software>, <USB Test Software>, <reserved>, <Software Bundle> </pre>

Table 2 Common (*) Commands Summary (continued)

Command	Query	Options and Query Returns
n/a	*OPT? (see page 243) (cont'd)	<All field> ::= {0 All} <reserved> ::= 0 <MSO> ::= {0 MSO} <Memory> ::= {0 MEMUP} <Low Speed Serial> ::= {0 EMBD} <Automotive Serial> ::= {0 AUTO} <FlexRay Serial> ::= {0 FLEX} <Frequency Response Analysis> ::= {0 FRA} <Power Measurements> ::= {0 PWR} <RS-232/UART Serial> ::= {0 COMP} <Mask Test> ::= {0 MASK} <Bandwidth> ::= {0 BW20 BW50} <I2S Serial> ::= {0 AUDIO} <Educator's Kit> ::= {0 EDK} <Waveform Generator> ::= {0 WAVEGEN} <MIL-1553/ARINC 429 Serial> ::= {0 AERO} <Extended Video> ::= {0 VID} <Digital Voltmeter> ::= {0 DVM} <USB 2.0 Low/Full Speed> ::= {0 USF} <USB 2.0 High Speed> ::= {0 U2H} <USB 2.0 Signal Quality Analysis> ::= {0 USBSQ} <Remote Command Logging> ::= {0 RML}

Table 2 Common (*) Commands Summary (continued)

Command	Query	Options and Query Returns
n/a	*OPT? (see page 243) (cont'd)	<pre><SENT Serial> ::= {0 SENSOR} <CAN FD Serial> ::= {0 CANFD} <CXPI Serial> ::= {0 CXPI} <Jitter Analysis> ::= {0 JITTER} <Manchester/NRZ Serial> ::= {0 NRZ} <USB PD Serial> ::= {0 USBPD} <Automotive Software> ::= {0 D6000AUTA} <General Purpose Software> ::= {0 D6000GENA} <Aerospace Software> ::= {0 D6000AERA} <Power Supply Test Software> ::= {0 D6000PWRA} <USB Test Software> ::= {0 D6000USBA} <Software Bundle> ::= {0 D6000BDLA}</pre>
*RCL <value> (see page 245)	n/a	<value> ::= {0 1 4 5 6 7 8 9}
*RST (see page 246)	n/a	See *RST (Reset) (see page 246)
*SAV <value> (see page 249)	n/a	<value> ::= {0 1 4 5 6 7 8 9}
*SRE <mask> (see page 250)	*SRE? (see page 251)	<pre><mask> ::= sum of all bits that are set, 0 to 255; an integer in NR1 format. <mask> ::= following values: Bit Weight Name Enables ----- 7 128 OPER Operation Status Reg 6 64 ---- (Not used.) 5 32 ESB Event Status Bit 4 16 MAV Message Available 3 8 ---- (Not used.) 2 4 MSG Message 1 2 USR User 0 1 TRG Trigger</pre>

Table 2 Common (*) Commands Summary (continued)

Command	Query	Options and Query Returns
n/a	*STB? (see page 252)	<p><value> ::= 0 to 255; an integer in NR1 format, as shown in the following:</p> <p>Bit Weight Name "1" Indicates</p> <pre> ----- 7 128 OPER Operation status condition occurred. 6 64 RQS/ Instrument is MSS requesting service. 5 32 ESB Enabled event status condition occurred. 4 16 MAV Message available. 3 8 ---- (Not used.) 2 4 MSG Message displayed. 1 2 USR User event condition occurred. 0 1 TRG A trigger occurred. </pre>
*TRG (see page 254)	n/a	n/a
n/a	*TST? (see page 255)	<result> ::= 0 or non-zero value; an integer in NR1 format
*WAI (see page 256)	n/a	n/a

Table 3 Root (:) Commands Summary

Command	Query	Options and Query Returns
:ACTivity (see page 261)	:ACTivity? (see page 261)	<p><return value> ::= <edges>, <levels></p> <p><edges> ::= presence of edges (32-bit integer in NR1 format)</p> <p><levels> ::= logical highs or lows (32-bit integer in NR1 format)</p>
n/a	:AER? (see page 262)	{0 1}; an integer in NR1 format

Table 3 Root (:): Commands Summary (continued)

Command	Query	Options and Query Returns
:AUToscale [<source>[, ..., <source>]] (see page 263)	n/a	<source> ::= CHANNEL<n> for DSO models <source> ::= {CHANNEL<n> DIGital<d> POD1 POD2} for MSO models <source> can be repeated up to 5 times <n> ::= 1 to (# analog channels) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format
:AUToscale:AMODE <value> (see page 265)	:AUToscale:AMODE? (see page 265)	<value> ::= {NORMAL CURRENT}}
:AUToscale:CHANnels <value> (see page 266)	:AUToscale:CHANnels? (see page 266)	<value> ::= {ALL DISPLAYed}}
:AUToscale:FDEBug { {0 OFF} {1 ON} } (see page 267)	:AUToscale:FDEBug? (see page 267)	{0 1}
:BLANK [<source>] (see page 268)	n/a	<source> ::= {CHANNEL<n> FUNCTION<m> MATH<m> SBUS{1 2} WMemory<r>} for DSO models <source> ::= {CHANNEL<n> DIGital<d> POD{1 2} BUS{1 2} FUNCTION<m> MATH<m> SBUS{1 2} WMemory<r>} for MSO models <n> ::= 1 to (# analog channels) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format

Table 3 Root (:): Commands Summary (continued)

Command	Query	Options and Query Returns
:DIGitize [<source>[,...,<source>]] (see page 270)	n/a	<source> ::= {CHANnel<n> FUNction<m> MATH<m> SBUS{1 2}} for DSO models <source> ::= {CHANnel<n> DIGital<d> POD{1 2} BUS{1 2} FUNction<m> MATH<m> SBUS{1 2}} for MSO models <source> can be repeated up to 5 times <n> ::= 1 to (# analog channels) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format <m> ::= 1 to (# math functions) in NR1 format
:HWEenable <n> (see page 272)	:HWEenable? (see page 272)	<n> ::= 16-bit integer in NR1 format
n/a	:HWERegister:CONDition? (see page 274)	<n> ::= 16-bit integer in NR1 format
n/a	:HWERegister[:EVENT]? (see page 275)	<n> ::= 16-bit integer in NR1 format
:MTEenable <n> (see page 276)	:MTEenable? (see page 276)	<n> ::= 16-bit integer in NR1 format
n/a	:MTERegister[:EVENT]? (see page 278)	<n> ::= 16-bit integer in NR1 format
:OPEE <n> (see page 280)	:OPEE? (see page 281)	<n> ::= 15-bit integer in NR1 format
n/a	:OPERRegister:CONDition? (see page 282)	<n> ::= 15-bit integer in NR1 format
n/a	:OPERRegister[:EVENT]? (see page 285)	<n> ::= 15-bit integer in NR1 format

Table 3 Root (:): Commands Summary (continued)

Command	Query	Options and Query Returns
:OVLenable <mask> (see page 288)	:OVLenable? (see page 289)	<mask> ::= 16-bit integer in NR1 format as shown: Bit Weight Input ----- 10 1024 Ext Trigger Fault 9 512 Channel 4 Fault 8 256 Channel 3 Fault 7 128 Channel 2 Fault 6 64 Channel 1 Fault 4 16 Ext Trigger OVL 3 8 Channel 4 OVL 2 4 Channel 3 OVL 1 2 Channel 2 OVL 0 1 Channel 1 OVL
n/a	:OVLRegister? (see page 290)	<value> ::= integer in NR1 format. See OVLenable for <value>
:PRINT [<options>] (see page 292)	n/a	<options> ::= [<print option>][,...,<print option>] <print option> ::= {COLor GRAYscale PRINter0 BMP8bit BMP PNG NOFactoRs FACToRs} <print option> can be repeated up to 5 times.
n/a	:RState? (see page 293)	n/a
:RUN (see page 294)	n/a	n/a
n/a	:SERial (see page 295)	<return value> ::= unquoted string containing serial number
:SINGle (see page 296)	n/a	n/a
n/a	:STATus? <display> (see page 297)	{0 1} <display> ::= {CHANnel<n> DIGital<d> POD{1 2} BUS{1 2} FUNctioN<m> MATH<m> SBUS{1 2} WMEMory<r>} <n> ::= 1 to (# analog channels) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format

Table 3 Root (:): Commands Summary (continued)

Command	Query	Options and Query Returns
:STOP (see page 298)	n/a	n/a
n/a	:TER? (see page 299)	{0 1}
:VIEW <source> (see page 300)	n/a	<source> ::= {CHANnel<n> FUNction<m> MATH<m> SBUS{1 2} WMEMory<r>} for DSO models <source> ::= {CHANnel<n> DIGital<d> POD{1 2} BUS{1 2} FUNction<m> MATH<m> SBUS{1 2} WMEMory<r>} for MSO models <n> ::= 1 to (# analog channels) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format

Table 4 :ACquire Commands Summary

Command	Query	Options and Query Returns
n/a	:ACquire:AAlias? (see page 304)	{1 0}
:ACquire:COMplete <complete> (see page 305)	:ACquire:COMplete? (see page 305)	<complete> ::= 100; an integer in NR1 format
:ACquire:COUNT <count> (see page 306)	:ACquire:COUNT? (see page 306)	<count> ::= an integer from 2 to 65536 in NR1 format
:ACquire:DAALias <mode> (see page 307)	:ACquire:DAALias? (see page 307)	<mode> ::= {DISable AUTO}
:ACquire:MODE <mode> (see page 308)	:ACquire:MODE? (see page 308)	<mode> ::= {RTIME MRTime ETIME SEGmented}
n/a	:ACquire:POINTs? (see page 310)	<# points> ::= an integer in NR1 format
:ACquire:RSIGnal <ref_signal_mode> (see page 311)	:ACquire:RSIGnal? (see page 311)	<ref_signal_mode> ::= {OFF OUT IN}

Table 4 :ACQUIRE Commands Summary (continued)

Command	Query	Options and Query Returns
:ACQUIRE:SEGMENTED:ANALYZE (see page 312)	n/a	n/a
:ACQUIRE:SEGMENTED:COUNT <count> (see page 313)	:ACQUIRE:SEGMENTED:COUNT? (see page 313)	<count> ::= an integer from 2 to 1000 in NR1 format
:ACQUIRE:SEGMENTED:INDEX <index> (see page 314)	:ACQUIRE:SEGMENTED:INDEX? (see page 314)	<index> ::= an integer from 1 to 1000 in NR1 format
n/a	:ACQUIRE:SRATE? [MAXIMUM] (see page 317)	<sample_rate> ::= sample rate (samples/s) in NR3 format
:ACQUIRE:TYPE <type> (see page 318)	:ACQUIRE:TYPE? (see page 318)	<type> ::= {NORMAL AVERAGE HRESOLUTION PEAK}

Table 5 :BUS<n> Commands Summary

Command	Query	Options and Query Returns
:BUS<n>:BIT<m> {{0 OFF} {1 ON}} (see page 323)	:BUS<n>:BIT<m>? (see page 323)	{0 1} <n> ::= 1 or 2; an integer in NR1 format <m> ::= 0-15; an integer in NR1 format
:BUS<n>:BITS <channel_list>, {{0 OFF} {1 ON}} (see page 324)	:BUS<n>:BITS? (see page 324)	<channel_list>, {0 1} <channel_list> ::= (@<m>, <m>:<m> ...) where "," is separator and ":" is range <n> ::= 1 or 2; an integer in NR1 format <m> ::= 0-15; an integer in NR1 format
:BUS<n>:CLEAR (see page 326)	n/a	<n> ::= 1 or 2; an integer in NR1 format
:BUS<n>:DISPLAY {{0 OFF} {1 ON}} (see page 327)	:BUS<n>:DISPLAY? (see page 327)	{0 1} <n> ::= 1 or 2; an integer in NR1 format

Table 5 :BUS<n> Commands Summary (continued)

Command	Query	Options and Query Returns
:BUS<n>:LAbel <string> (see page 328)	:BUS<n>:LAbel? (see page 328)	<string> ::= quoted ASCII string up to 10 characters <n> ::= 1 or 2; an integer in NR1 format
:BUS<n>:MAsK <mask> (see page 329)	:BUS<n>:MAsK? (see page 329)	<mask> ::= 32-bit integer in decimal, <nondecimal>, or <string> <nondecimal> ::= #Hnn...n where n ::= {0,...,9 A,...,F} for hexadecimal <nondecimal> ::= #Bnn...n where n ::= {0 1} for binary <string> ::= "0xnn...n" where n ::= {0,...,9 A,...,F} for hexadecimal <n> ::= 1 or 2; an integer in NR1 format

Table 6 :CALibrate Commands Summary

Command	Query	Options and Query Returns
n/a	:CALibrate:DATE? (see page 333)	<return value> ::= <year>,<month>,<day>; all in NR1 format
:CALibrate:LAbel <string> (see page 334)	:CALibrate:LAbel? (see page 334)	<string> ::= quoted ASCII string up to 32 characters
:CALibrate:OUTPut <signal> (see page 335)	:CALibrate:OUTPut? (see page 335)	<signal> ::= {TRIGgers MASK WAVEgen WGEN1 WGEN2 TSource} Note: WAVE and WGEN1 are equivalent. Note: WGEN2 only available on models with 2 WaveGen outputs.
n/a	:CALibrate:PROtected? (see page 336)	{"PROtected" "UNPROtected"}
:CALibrate:STARt (see page 337)	n/a	n/a

Table 6 :CALibrate Commands Summary (continued)

Command	Query	Options and Query Returns
n/a	:CALibrate:STATus? (see page 338)	<return value> ::= <status_code>,<status_string> <status_code> ::= an integer status code <status_string> ::= an ASCII status string
n/a	:CALibrate:TEMPeratur e? (see page 339)	<return value> ::= degrees C delta since last cal in NR3 format
n/a	:CALibrate:TIME? (see page 340)	<return value> ::= <hours>,<minutes>,<seconds>; all in NR1 format

Table 7 :CGRade Commands Summary

Command	Query	Options and Query Returns
n/a	:CGRade:LEVels? (see page 343)	<levels> ::= comma-delimited list of color range levels
:CGRade:LEVels:DISPla y {{0 OFF} {1 ON}} (see page 344)	:CGRade:LEVels:DISPla y? (see page 344)	{0 1}
:CGRade:RESet (see page 345)	n/a	n/a
:CGRade:SCHEME <theme> (see page 346)	:CGRade:SCHEME? (see page 346)	<theme> ::= {TEMPerature INTensity}
:CGRade:SOURce <source> (see page 347)	:CGRade:SOURce? (see page 347)	<source> ::= {CHANnel<n> FUNctIon<m> MATH<m> WMEMory<r>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format
:CGRade:STATe {{0 OFF} {1 ON}} (see page 348)	:CGRade:STATe? (see page 348)	{0 1}

Table 8 :CHANnel<n> Commands Summary

Command	Query	Options and Query Returns
:CHANnel<n>:BANDwidth <limit> (see page 353)	:CHANnel<n>:BANDwidth ? [MAXimum] (see page 353)	<limit> ::= 20E6, 200E6, 1.5E9, or 3E9 in NR3 format (depending on oscilloscope bandwidth and settings) <n> ::= 1 to (# analog channels) in NR1 format
:CHANnel<n>:BWLimit {{0 OFF} {1 ON}} (see page 355)	:CHANnel<n>:BWLimit? (see page 355)	{0 1} <n> ::= 1 to (# analog channels) in NR1 format
:CHANnel<n>:COUpling <coupling> (see page 356)	:CHANnel<n>:COUpling? (see page 356)	<coupling> ::= {AC DC} <n> ::= 1 to (# analog channels) in NR1 format
:CHANnel<n>:DISPlay {{0 OFF} {1 ON}} (see page 357)	:CHANnel<n>:DISPlay? (see page 357)	{0 1} <n> ::= 1 to (# analog channels) in NR1 format
:CHANnel<n>:IMPedance <impedance> (see page 358)	:CHANnel<n>:IMPedance ? (see page 358)	<impedance> ::= {ONEMeg FIFTy} <n> ::= 1 to (# analog channels) in NR1 format
:CHANnel<n>:INVert {{0 OFF} {1 ON}} (see page 359)	:CHANnel<n>:INVert? (see page 359)	{0 1} <n> ::= 1 to (# analog channels) in NR1 format
:CHANnel<n>:LABel <string> (see page 360)	:CHANnel<n>:LABel? (see page 360)	<string> ::= any series of 32 or less ASCII characters enclosed in quotation marks <n> ::= 1 to (# analog channels) in NR1 format
:CHANnel<n>:OFFSet <offset>[suffix] (see page 361)	:CHANnel<n>:OFFSet? (see page 361)	<offset> ::= Vertical offset value in NR3 format [suffix] ::= {V mV} <n> ::= 1-2 or 1-4; in NR1 format
:CHANnel<n>:PROBe <attenuation> (see page 362)	:CHANnel<n>:PROBe? (see page 362)	<attenuation> ::= Probe attenuation ratio in NR3 format <n> ::= 1-2 or 1-4; in NR1 format

Table 8 :CHANnel<n> Commands Summary (continued)

Command	Query	Options and Query Returns
:CHANnel<n>:PROBe:BTN <setting> (see page 363)	:CHANnel<n>:PROBe:BTN ? (see page 363)	<n> ::= 1 to (# analog channels) in NR1 format <setting> ::= {HEADlight INFinimode RSTop SINGLE CDISplay AUToscale FTRigger QACTion NACTion NONE}
:CHANnel<n>:PROBe:CAL ibration (see page 364)	n/a	n/a
:CHANnel<n>:PROBe:EXT ernal {{0 OFF} {1 ON}} (see page 366)	:CHANnel<n>:PROBe:EXT ernal? (see page 366)	<n> ::= 1 to (# analog channels) in NR1 format <setting> ::= {0 1}
:CHANnel<n>:PROBe:EXT ernal:GAIN <gain_factor> (see page 367)	:CHANnel<n>:PROBe:EXT ernal:GAIN? (see page 367)	<n> ::= 1 to (# analog channels) in NR1 format <gain_factor> ::= a real number from 0.0001 to 1000 in NR3 format
:CHANnel<n>:PROBe:EXT ernal:UNITs <units> (see page 368)	:CHANnel<n>:PROBe:EXT ernal:UNITs? (see page 368)	<n> ::= 1 to (# analog channels) in NR1 format <units> ::= {VOLT AMPere}
:CHANnel<n>:PROBe:HEA D[:TYPE] <head_param> (see page 369)	:CHANnel<n>:PROBe:HEA D[:TYPE]? (see page 369)	<head_param> ::= {SEND0 SEND6 SEND12 SEND20 DIFF0 DIFF6 DIFF12 DIFF20 DSMA DSMA6 NONE} <n> ::= 1 to (# analog channels) in NR1 format
n/a	:CHANnel<n>:PROBe:ID? (see page 370)	<probe id> ::= unquoted ASCII string up to 11 characters <n> ::= 1 to (# analog channels) in NR1 format
:CHANnel<n>:PROBe:MMO Del <value> (see page 371)	:CHANnel<n>:PROBe:MMO Del? (see page 371)	<value> ::= {P5205 P5210 P6205 P6241 P6243 P6245 P6246 P6247 P6248 P6249 P6250 P6251 P670X P671X TCP202} <n> ::= 1 to (# analog channels) in NR1 format
:CHANnel<n>:PROBe:MOD E <setting> (see page 372)	:CHANnel<n>:PROBe:MOD E? (see page 372)	<n> ::= 1 to (# analog channels) in NR1 format <setting> ::= {DIFFerential DOFFset SEA SEB CM}

Table 8 :CHANnel<n> Commands Summary (continued)

Command	Query	Options and Query Returns
:CHANnel<n>:PROBe:RSE Nse <value> (see page 373)	:CHANnel<n>:PROBe:RSE Nse? (see page 373)	<value> ::= Ohms in NR3 format <n> ::= 1 to (# analog channels) in NR1 format
:CHANnel<n>:PROBe:SKE W <skew_value> (see page 374)	:CHANnel<n>:PROBe:SKE W? (see page 374)	<skew_value> ::= -100 ns to +100 ns in NR3 format <n> ::= 1 to (# analog channels) in NR1 format
:CHANnel<n>:PROBe:STY Pe <signal type> (see page 375)	:CHANnel<n>:PROBe:STY Pe? (see page 375)	<signal type> ::= {DIFFerential SINGle} <n> ::= 1 to (# analog channels) in NR1 format
:CHANnel<n>:PROBe:ZOO M {{0 OFF} {1 ON}} (see page 376)	:CHANnel<n>:PROBe:ZOO M? (see page 376)	<setting> ::= {0 1} <n> ::= 1 to (# analog channels) in NR1 format
:CHANnel<n>:PROTection (see page 377)	:CHANnel<n>:PROTection? (see page 377)	{NORM TRIP} <n> ::= 1 to (# analog channels) in NR1 format
:CHANnel<n>:RANGe <range>[suffix] (see page 378)	:CHANnel<n>:RANGe? (see page 378)	<range> ::= Vertical full-scale range value in NR3 format [suffix] ::= {V mV} <n> ::= 1 to (# analog channels) in NR1 format
:CHANnel<n>:SCALe <scale>[suffix] (see page 379)	:CHANnel<n>:SCALe? (see page 379)	<scale> ::= Vertical units per division value in NR3 format [suffix] ::= {V mV} <n> ::= 1 to (# analog channels) in NR1 format
:CHANnel<n>:UNITs <units> (see page 380)	:CHANnel<n>:UNITs? (see page 380)	<units> ::= {VOLT AMPere} <n> ::= 1 to (# analog channels) in NR1 format
:CHANnel<n>:VERNier {{0 OFF} {1 ON}} (see page 381)	:CHANnel<n>:VERNier? (see page 381)	{0 1} <n> ::= 1 to (# analog channels) in NR1 format

Table 9 :CLOCK Commands Summary

Command	Query	Options and Query Returns
:CLOCK {{0 OFF} {1 ON}} (see page 385)	:CLOCK? (see page 385)	{0 1}
:CLOCK:METHOD <method> (see page 386)	:CLOCK:METHOD? (see page 387)	<p><method> ::= {<fixed> <fopll> <sopll> <explicit>}</p> <p><fixed> ::= FIXEd, {AUTO SEMI[, <data_rate>] <data_rate>}</p> <p><fopll> ::= FOPLL, <data_rate>, <loop_bandwidth></p> <p><sopll> ::= SOPLL, <data_rate>, <loop_bandwidth>, <damping_factor></p> <p><explicit> ::= EXPLiCit, <source>, {RISing FALLing BOTH}[, <multiplier>]</p> <p><data_rate> ::= the data signal's expected bits/second rate in NR3 format</p> <p><loop_bandwidth> ::= the -3 dB bandwidth specification of PLL in NR3 format</p> <p><damping_factor> ::= of the PLL's observed jitter transfer function in NR3 format</p> <p><source> ::= explicit clock source, CHANnel<n></p> <p><n> ::= 1 to (# analog channels) in NR1 format</p> <p><multiplier> ::= explicit clock multiplier from 1 to 1000 in NR1 format</p>

Table 10 :COMPLIANCE Commands Summary

Command	Query	Options and Query Returns
:COMPLIANCE:USB:AUTOSetup (see page 390)	n/a	n/a
:COMPLIANCE:USB:HUBS <number> (see page 391)	:COMPLIANCE:USB:HUBS? (see page 391)	<number> ::= 0-5 in NR1 format

Table 10 :COMPLIance Commands Summary (continued)

Command	Query	Options and Query Returns
:COMPLIance:USB:RUN (see page 392)	n/a	n/a
:COMPLIance:USB:SOURc e:ADJacent <source> (see page 393)	:COMPLIance:USB:SOURc e:ADJacent? (see page 393)	<source> ::= {CHANnel<n>}
:COMPLIance:USB:SOURc e:DIFFerential <source> (see page 394)	:COMPLIance:USB:SOURc e:DIFFerential? (see page 394)	<source> ::= {CHANnel<n>}
:COMPLIance:USB:SOURc e:DMINus <source> (see page 395)	:COMPLIance:USB:SOURc e:DMINus? (see page 395)	<source> ::= {CHANnel<n>}
:COMPLIance:USB:SOURc e:DPLus <source> (see page 396)	:COMPLIance:USB:SOURc e:DPLus? (see page 396)	<source> ::= {CHANnel<n>}
:COMPLIance:USB:TEST <test> (see page 397)	:COMPLIance:USB:TEST? (see page 397)	<test> ::= {DHSS HHSS DLSS HLSS DFSS HFSS}
:COMPLIance:USB:TEST: CONNECTION <connection> (see page 398)	:COMPLIance:USB:TEST: CONNECTION? (see page 398)	<connection> ::= {SINGLEended DIFFerential}
:COMPLIance:USB:TEST: TYPE <type> (see page 399)	:COMPLIance:USB:TEST: TYPE? (see page 399)	<type> ::= {NEARend FARend}

Table 11 :COUNter Commands Summary

Command	Query	Options and Query Returns
n/a	:COUNter:CURRent? (see page 403)	<value> ::= current counter value in NR3 format
:COUNter:ENABle {{0 OFF} {1 ON}} (see page 404)	:COUNter:ENABle? (see page 404)	{0 1}
:COUNter:MODE <mode> (see page 405)	:COUNter:MODE (see page 405)	<mode> ::= {FREQuency PERiod TOTAlize}
:COUNter:NDIGits <value> (see page 406)	:COUNter:NDIGits (see page 406)	<value> ::= 3 to 10 in NR1 format

Table 11 :COUNTER Commands Summary (continued)

Command	Query	Options and Query Returns
:COUNTER:SOURce <source> (see page 407)	:COUNTER:SOURce? (see page 407)	<source> ::= {CHANnel<n> TQEvent} <n> ::= 1 to (# analog channels) in NR1 format
:COUNTER:TOTAlize:CLEAr (see page 408)	n/a	n/a
:COUNTER:TOTAlize:GATE:ENABle {{0 OFF} {1 ON}} (see page 409)	:COUNTER:TOTAlize:GATE:ENABle? (see page 409)	{0 1}
:COUNTER:TOTAlize:GATE:POLArity <polarity> (see page 410)	:COUNTER:TOTAlize:GATE:POLArity? (see page 410)	<polarity> ::= {{NEGative FALLing} {POSitive RISing}}
:COUNTER:TOTAlize:GATE:SOURce <source> (see page 411)	:COUNTER:TOTAlize:GATE:SOURce? (see page 411)	<source> ::= CHANnel<n> <n> ::= 1 to (# analog channels) in NR1 format
:COUNTER:TOTAlize:SLOPe <slope> (see page 412)	:COUNTER:TOTAlize:SLOPe? (see page 412)	<slope> ::= {{NEGative FALLing} {POSitive RISing}}

Table 12 :DEMO Commands Summary

Command	Query	Options and Query Returns
:DEMO:FUNCTion <signal> (see page 414)	:DEMO:FUNCTion? (see page 418)	<signal> ::= {SINusoid NOISy PHASe RINGing SINGle AM CLK GLITCh BURSt MSO RUNT TRANSition RFBurst SHOLd LFSine FMBurst ETE CAN LIN UART I2C SPI I2S CANLin CXPI ARINc FLEXray MIL MIL2 USB NMONotonic JITTer DCMotor RTEYe SJITTer}
:DEMO:FUNCTion:PHASe: PHASe <angle> (see page 419)	:DEMO:FUNCTion:PHASe: PHASe? (see page 419)	<angle> ::= angle in degrees from 0 to 360 in NR3 format
:DEMO:OUTPut {{0 OFF} {1 ON}} (see page 420)	:DEMO:OUTPut? (see page 420)	{0 1}

Table 13 :DIGital<d> Commands Summary

Command	Query	Options and Query Returns
:DIGital<d>:DISPlay {0 OFF} {1 ON} (see page 423)	:DIGital<d>:DISPlay? (see page 423)	<d> ::= 0 to (# digital channels - 1) in NR1 format {0 1}
:DIGital<d>:LABel <string> (see page 424)	:DIGital<d>:LABel? (see page 424)	<d> ::= 0 to (# digital channels - 1) in NR1 format <string> ::= any series of 10 or less ASCII characters enclosed in quotation marks
:DIGital<d>:POSition <position> (see page 425)	:DIGital<d>:POSition? (see page 425)	<d> ::= 0 to (# digital channels - 1) in NR1 format <position> ::= 0-7 if display size = large, 0-15 if size = medium, 0-31 if size = small Returns -1 when there is no space to display the digital waveform.
:DIGital<d>:SIZE <value> (see page 426)	:DIGital<d>:SIZE? (see page 426)	<d> ::= 0 to (# digital channels - 1) in NR1 format <value> ::= {SMALl MEDium LARGe}
:DIGital<d>:THReshold <value>[suffix] (see page 427)	:DIGital<d>:THReshold? (see page 427)	<d> ::= 0 to (# digital channels - 1) in NR1 format <value> ::= {CMOS ECL TTL <user defined value>} <user defined value> ::= value in NR3 format from -8.00 to +8.00 [suffix] ::= {V mV uV}

Table 14 :DISPlay Commands Summary

Command	Query	Options and Query Returns
:DISPlay:ANNotation<n> > {{0 OFF} {1 ON}} (see page 432)	:DISPlay:ANNotation<n> >? (see page 432)	{0 1} <n> ::= an integer from 1 to 4 in NR1 format.
:DISPlay:ANNotation<n> >:BACKground <mode> (see page 433)	:DISPlay:ANNotation<n> >:BACKground? (see page 433)	<mode> ::= {OPAQue INVerted TRANSPARENT} <n> ::= an integer from 1 to 4 in NR1 format.

Table 14 :DISPlay Commands Summary (continued)

Command	Query	Options and Query Returns
:DISPlay:ANNotation<n>:COLor <color> (see page 434)	:DISPlay:ANNotation<n>:COLor? (see page 434)	<color> ::= {CH1 CH2 CH3 CH4 DIG MATH REF MARKer WHITE RED} <n> ::= an integer from 1 to 4 in NR1 format.
:DISPlay:ANNotation<n>:TEXT <string> (see page 435)	:DISPlay:ANNotation<n>:TEXT? (see page 435)	<string> ::= quoted ASCII string (up to 254 characters) <n> ::= an integer from 1 to 4 in NR1 format.
:DISPlay:ANNotation<n>:X1Position <value> (see page 436)	:DISPlay:ANNotation<n>:X1Position? (see page 436)	<value> ::= an integer from 0 to (800 - width of annotation) in NR1 format. <n> ::= an integer from 1 to 4 in NR1 format.
:DISPlay:ANNotation<n>:Y1Position <value> (see page 437)	:DISPlay:ANNotation<n>:Y1Position? (see page 437)	<value> ::= an integer from 0 to (480 - height of annotation) in NR1 format. <n> ::= an integer from 1 to 4 in NR1 format.
:DISPlay:BACKlight {{0 OFF} {1 ON}} (see page 438)	n/a	n/a
:DISPlay:CLear (see page 439)	n/a	n/a
n/a	:DISPlay:DATA? [<format>][,][<palette>] (see page 440)	<format> ::= {BMP BMP8bit PNG} <palette> ::= {COLor GRAYscale} <display data> ::= data in IEEE 488.2 # format
:DISPlay:GRATicule:ALABels {{0 OFF} {1 ON}} (see page 442)	:DISPlay:GRATicule:ALABels? (see page 442)	<setting> ::= {0 1}
:DISPlay:GRATicule:INTensity <value> (see page 443)	:DISPlay:GRATicule:INTensity? (see page 443)	<value> ::= an integer from 0 to 100 in NR1 format.
:DISPlay:GRATicule:TYPE <type> (see page 444)	:DISPlay:GRATicule:TYPE? (see page 444)	<type> ::= {FULL MVOLt IRE}

Table 14 :DISPlay Commands Summary (continued)

Command	Query	Options and Query Returns
:DISPlay:INTensity:WA Veform <value> (see page 445)	:DISPlay:INTensity:WA Veform? (see page 445)	<value> ::= an integer from 0 to 100 in NR1 format.
:DISPlay:LABel {{0 OFF} {1 ON}} (see page 446)	:DISPlay:LABel? (see page 446)	{0 1}
:DISPlay:LABList <binary block> (see page 447)	:DISPlay:LABList? (see page 447)	<binary block> ::= an ordered list of up to 75 labels, each 32 characters maximum, separated by newline characters
:DISPlay:MENU <menu> (see page 448)	n/a	<menu> ::= {MASK MEASure SEGmented LISTer POWER}
:DISPlay:MESSAge:CLEa r (see page 449)	n/a	n/a
:DISPlay:PERsistence <value> (see page 450)	:DISPlay:PERsistence? (see page 450)	<value> ::= {MINimum INFinite <time>} <time> ::= seconds in in NR3 format from 100E-3 to 60E0
:DISPlay:PERsistence: CLEar (see page 451)	n/a	n/a
:DISPlay:SIDebar <sidebar> (see page 452)	n/a	<sidebar> ::= {SUMMery CURSors MEASurements DVM NAVigate CONTROLS}
:DISPlay:TRANSPARENT {OFF ON} (see page 453)	:DISPlay:TRANSPARENT? (see page 453)	{OFF ON}
:DISPlay:VECTors {{0 OFF} {1 ON}} (see page 454)	:DISPlay:VECTors? (see page 454)	{0 1} OFF or 0 can only be selected with the 1 GHz or 1.5 GHz bandwidth models

Table 15 :DVM Commands Summary

Command	Query	Options and Query Returns
:DVM:ARANge {{0 OFF} {1 ON}} (see page 456)	:DVM:ARANge? (see page 456)	{0 1}
n/a	:DVM:CURRent? (see page 457)	<dvm_value> ::= floating-point number in NR3 format

Table 15 :DVM Commands Summary (continued)

Command	Query	Options and Query Returns
:DVM:ENABle {{0 OFF} {1 ON}} (see page 458)	:DVM:ENABle? (see page 458)	{0 1}
:DVM:MODE <mode> (see page 459)	:DVM:MODE? (see page 459)	<dvm_mode> ::= {ACRMs DC DCRMs}
:DVM:SOURce <source> (see page 460)	:DVM:SOURce? (see page 460)	<source> ::= {CHANnel<n>} <n> ::= 1-2 or 1-4 in NR1 format

Table 16 :EXTernal Trigger Commands Summary

Command	Query	Options and Query Returns
:EXTernal:BWLimit <bwlimit> (see page 462)	:EXTernal:BWLimit? (see page 462)	<bwlimit> ::= {0 OFF}
:EXTernal:PROBe <attenuation> (see page 463)	:EXTernal:PROBe? (see page 463)	<attenuation> ::= probe attenuation ratio in NR3 format
:EXTernal:RANGe <range>[<suffix>] (see page 464)	:EXTernal:RANGe? (see page 464)	<range> ::= vertical full-scale range value in NR3 format <suffix> ::= {V mV}
:EXTernal:UNITs <units> (see page 465)	:EXTernal:UNITs? (see page 465)	<units> ::= {VOLT AMPere}

Table 17 :FRANalysis Commands Summary

Command	Query	Options and Query Returns
n/a	:FRANalysis:DATA? [SWEep SINGLE] (see page 469)	<binary_block> ::= comma-separated data with newlines at the end of each row
:FRANalysis:ENABle {{0 OFF} {1 ON}} (see page 470)	:FRANalysis:ENABle? (see page 470)	{0 1}
:FRANalysis:FREQuency :MODE <setting> (see page 471)	:FRANalysis:FREQuency :MODE? (see page 471)	<setting> ::= {SWEep SINGLE}
:FRANalysis:FREQuency :SINGle <value>[suffix] (see page 472)	:FRANalysis:FREQuency :SINGle? (see page 472)	<value> ::= {20 100 1000 10000 100000 1000000 10000000 20000000} [suffix] ::= {Hz kHz MHz}

Table 17 :FRANalysis Commands Summary (continued)

Command	Query	Options and Query Returns
:FRANalysis:FREQuency :START <value>[suffix] (see page 473)	:FRANalysis:FREQuency :START? (see page 473)	<value> ::= {20 100 1000 10000 100000 1000000 10000000} [suffix] ::= {Hz kHz MHz}
:FRANalysis:FREQuency :STOP <value>[suffix] (see page 474)	:FRANalysis:FREQuency :STOP? (see page 474)	<value> ::= {100 1000 10000 100000 1000000 10000000 20000000} [suffix] ::= {Hz kHz MHz}
:FRANalysis:PPDecade <value> (see page 475)	:FRANalysis:PPDecade? (see page 475)	<value> ::= {10 20 30 40 50 60 70 80 90 100}
:FRANalysis:RUN (see page 476)	n/a	n/a
:FRANalysis:SOURce:IN Put <source> (see page 477)	:FRANalysis:SOURce:IN Put? (see page 477)	<source> ::= CHANnel<n> <n> ::= 1 to (# analog channels) in NR1 format
:FRANalysis:SOURce:OU TPut <source> (see page 478)	:FRANalysis:SOURce:OU TPut? (see page 478)	<source> ::= CHANnel<n> <n> ::= 1 to (# analog channels) in NR1 format
:FRANalysis:TRACe <selection> (see page 479)	:FRANalysis:TRACe? (see page 479)	<selection> ::= {NONE ALL GAIN PHASE}[,{GAIN PHASE}]
:FRANalysis:WGEN:LOAD <impedance> (see page 480)	:FRANalysis:WGEN:LOAD ? (see page 480)	<impedance> ::= {ONEMeg FIFTy}
:FRANalysis:WGEN:VOLT age <amplitude>, [<range>] (see page 481)	:FRANalysis:WGEN:VOLT age? [<range>] (see page 481)	<amplitude> ::= amplitude in volts in NR3 format <range> ::= {F20HZ F100HZ F1KHZ F10KHZ F100KHZ F1MHZ F10MHZ F20MHZ}
:FRANalysis:WGEN:VOLT age:PROFile {{0 OFF} {1 ON}} (see page 482)	:FRANalysis:WGEN:VOLT age:PROFile? (see page 482)	{0 1}

Table 18 :FUNction<m> Commands Summary

Command	Query	Options and Query Returns
:FUNction<m>:AVERAge:COUNT <count> (see page 490)	:FUNction<m>:AVERAge:COUNT? (see page 490)	<count> ::= an integer from 2 to 65536 in NR1 format <m> ::= 1 to (# math functions) in NR1 format
:FUNction<m>:BUS:CLOCK <source> (see page 491)	:FUNction<m>:BUS:CLOCK? (see page 491)	<source> ::= {CHANnel<n> DIGital<d>} <n> ::= 1 to (# analog channels) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format <m> ::= 1 to (# math functions) in NR1 format
:FUNction<m>:BUS:SLOPE <slope> (see page 492)	:FUNction<m>:BUS:SLOPE? (see page 492)	<slope> ::= {NEGative POSitive EITHer} <m> ::= 1 to (# math functions) in NR1 format
:FUNction<m>:BUS:YINCrement <value> (see page 493)	:FUNction<m>:BUS:YINCrement? (see page 493)	<value> ::= value per bus code, in NR3 format <m> ::= 1 to (# math functions) in NR1 format
:FUNction<m>:BUS:YORigin <value> (see page 494)	:FUNction<m>:BUS:YORigin? (see page 494)	<value> ::= value at bus code = 0, in NR3 format <m> ::= 1 to (# math functions) in NR1 format
:FUNction<m>:BUS:YUNits <units> (see page 495)	:FUNction<m>:BUS:YUNits? (see page 495)	<units> ::= {VOLT AMPere NONE} <m> ::= 1 to (# math functions) in NR1 format
:FUNction<m>:CLEAr (see page 496)	n/a	n/a
:FUNction<m>:DISPlay {{0 OFF} {1 ON}} (see page 497)	:FUNction<m>:DISPlay? (see page 497)	{0 1} <m> ::= 1 to (# math functions) in NR1 format
n/a	:FUNction<m>[:FFT]:BSIZE? (see page 498)	<bin_size> ::= Hz in NR3 format <m> ::= 1 to (# math functions) in NR1 format

Table 18 :FUNction<m> Commands Summary (continued)

Command	Query	Options and Query Returns
:FUNction<m>[:FFT]:CENTer <frequency> (see page 499)	:FUNction<m>[:FFT]:CENTer? (see page 499)	<frequency> ::= the current center frequency in NR3 format. The range of legal values is from -25 GHz to 25 GHz. <m> ::= 1 to (# math functions) in NR1 format
:FUNction<m>[:FFT]:DETEction:POINTs <number_of_buckets> (see page 500)	:FUNction<m>[:FFT]:DETEction:POINTs? (see page 500)	<number_of_buckets> ::= an integer in NR1 format <m> ::= 1 to (# math functions) in NR1 format
:FUNction<m>[:FFT]:DETEction:TYPE <type> (see page 501)	:FUNction<m>[:FFT]:DETEction:TYPE? (see page 501)	<type> ::= {OFF SAMPlE PPOSitive PNENegative NORMAl AVERAge} <m> ::= 1 to (# math functions) in NR1 format
:FUNction<m>[:FFT]:FREQuency:START <frequency> (see page 502)	:FUNction<m>[:FFT]:FREQuency:START? (see page 502)	<frequency> ::= the start frequency in NR3 format. <m> ::= 1 to (# math functions) in NR1 format
:FUNction<m>[:FFT]:FREQuency:STOP <frequency> (see page 503)	:FUNction<m>[:FFT]:FREQuency:STOP? (see page 503)	<frequency> ::= the stop frequency in NR3 format. <m> ::= 1 to (# math functions) in NR1 format
:FUNction<m>[:FFT]:GATE <gating> (see page 504)	:FUNction<m>[:FFT]:GATE? (see page 504)	<gating> ::= {NONE ZOOM} <m> ::= 1-4 in NR1 format
:FUNction<m>[:FFT]:PHASe:REfERENCE <ref_point> (see page 505)	:FUNction<m>[:FFT]:PHASe:REfERENCE? (see page 505)	<ref_point> ::= {TRIGger DISPlay} <m> ::= 1-4 in NR1 format
n/a	:FUNction<m>[:FFT]:RBWidth? (see page 506)	<resolution_bw> ::= Hz in NR3 format <m> ::= 1 to (# math functions) in NR1 format
:FUNction<m>[:FFT]:READout<n> <readout_type> (see page 507)	:FUNction<m>[:FFT]:READout<n>? (see page 507)	<readout_type> ::= {SRATe BSIZE RBWidth} <m> ::= 1 to (# math functions) in NR1 format <n> ::= 1-2 in NR1 format, 2 is for dedicated FFT function

Table 18 :FUNction<m> Commands Summary (continued)

Command	Query	Options and Query Returns
:FUNction<m>[:FFT]:SPAN (see page 508)	:FUNction<m>[:FFT]:SPAN? (see page 508)	 ::= the current frequency span in NR3 format. Legal values are 1 Hz to 100 GHz. <m> ::= 1 to (# math functions) in NR1 format
n/a	:FUNction<m>[:FFT]:SRATE? (see page 509)	<sample_rate> ::= Hz in NR3 format <m> ::= 1 to (# math functions) in NR1 format
:FUNction<m>[:FFT]:VTYPe <units> (see page 510)	:FUNction<m>[:FFT]:VTYPe? (see page 510)	<units> ::= {DECibel VRMS} for the FFT (magnitude) operation <units> ::= {DEGREes RADians} for the FFTPhase operation <m> ::= 1 to (# math functions) in NR1 format
:FUNction<m>[:FFT]:WINDow <window> (see page 511)	:FUNction<m>[:FFT]:WINDow? (see page 511)	<window> ::= {RECTangular HANNing FLATtop BHARRis BARTlett} <m> ::= 1 to (# math functions) in NR1 format
:FUNction<m>:FREQuency:Bandpass:CENTer <center_freq> (see page 512)	:FUNction<m>:FREQuency:Bandpass:CENTer? (see page 512)	<center_freq> ::= center frequency of band-pass filter in NR3 format
:FUNction<m>:FREQuency:Bandpass:WIDTh <freq_width> (see page 513)	:FUNction<m>:FREQuency:Bandpass:WIDTh? (see page 513)	<freq_width> ::= frequency width of band-pass filter in NR3 format
:FUNction<m>:FREQuency:HIGHPass <3dB_freq> (see page 514)	:FUNction<m>:FREQuency:HIGHPass? (see page 514)	<3dB_freq> ::= 3dB cutoff frequency value in NR3 format <m> ::= 1 to (# math functions) in NR1 format
:FUNction<m>:FREQuency:LOWPass <3dB_freq> (see page 515)	:FUNction<m>:FREQuency:LOWPass? (see page 515)	<3dB_freq> ::= 3dB cutoff frequency value in NR3 format <m> ::= 1 to (# math functions) in NR1 format
:FUNction<m>:INTegrate:IICondition {{0 OFF} {1 ON}} (see page 516)	:FUNction<m>:INTegrate:IICondition? (see page 516)	{0 1} <m> ::= 1 to (# math functions) in NR1 format

Table 18 :FUNCTION<m> Commands Summary (continued)

Command	Query	Options and Query Returns
:FUNCTION<m>:INTEGRate:IOFFset <input_offset> (see page 517)	:FUNCTION<m>:INTEGRate:IOFFset? (see page 517)	<input_offset> ::= DC offset correction in NR3 format. <m> ::= 1 to (# math functions) in NR1 format
:FUNCTION<m>:LINear:GAIN <value> (see page 518)	:FUNCTION<m>:LINear:GAIN? (see page 518)	<value> ::= 'A' in Ax + B, value in NR3 format <m> ::= 1 to (# math functions) in NR1 format
:FUNCTION<m>:LINear:OFFSet <value> (see page 519)	:FUNCTION<m>:LINear:OFFSet? (see page 519)	<value> ::= 'B' in Ax + B, value in NR3 format <m> ::= 1 to (# math functions) in NR1 format
:FUNCTION<m>:OFFSet <offset> (see page 520)	:FUNCTION<m>:OFFSet? (see page 520)	<offset> ::= the value at center screen in NR3 format. The range of legal values is +/-10 times the current sensitivity of the selected function. <m> ::= 1 to (# math functions) in NR1 format
:FUNCTION<m>:OPERation <operation> (see page 521)	:FUNCTION<m>:OPERation? (see page 524)	<operation> ::= {ADD SUBTRACT MULTIPLY DIVIDE INTEGRATE DIFF FFT FFTPhase SQRT MAGNIFY ABSOLUTE SQUARE LN LOG EXP TEN LOWPASS HIGHPASS BANDPASS AVERAGE LINEAR MAXIMUM MINIMUM PEAK MAXHOLD MINHOLD TREND BTIMING BSTATE SERChart CLOCK} <m> ::= 1 to (# math functions) in NR1 format

Table 18 :FUNction<m> Commands Summary (continued)

Command	Query	Options and Query Returns
:FUNction<m>:RANGe <range> (see page 526)	:FUNction<m>:RANGe? (see page 526)	<range> ::= the full-scale vertical axis value in NR3 format. The range for ADD, SUBT, MULT is 8E-6 to 800E+3. The range for the INTegrate function is 8E-9 to 400E+3. The range for the DIFF function is 80E-3 to 8.0E12 (depends on current sweep speed). The range for the FFT function is 8 to 800 dBV. <m> ::= 1 to (# math functions) in NR1 format
:FUNction<m>:REFerence <level> (see page 527)	:FUNction<m>:REFerence? (see page 527)	<level> ::= the value at center screen in NR3 format. The range of legal values is +/-10 times the current sensitivity of the selected function. <m> ::= 1 to (# math functions) in NR1 format
:FUNction<m>:SCALE <scale value>[<suffix>] (see page 528)	:FUNction<m>:SCALE? (see page 528)	<scale value> ::= integer in NR1 format <suffix> ::= {V dB} <m> ::= 1 to (# math functions) in NR1 format
:FUNction<m>:SERChart :SOURce <serialbus> (see page 529)	:FUNction<m>:SERChart :SOURce? (see page 529)	<m> ::= 1 to (# math functions) in NR1 format <serialbus> ::= {SBUS<n>} <n> :: 1 to (# of serial bus) in NR1 format
:FUNction<m>:SERChart :TIME:MODE <value> (see page 530)	:FUNction<m>:SERChart :TIME:MODE? (see page 530)	<m> ::= 1 to (# math functions) in NR1 format <value> ::= {MAIN ROLL}
:FUNction<m>:SERChart :TIME:RANGe <range_value> (see page 532)	:FUNction<m>:SERChart :TIME:RANGe? (see page 532)	<m> ::= 1 to (# math functions) in NR1 format <range_value> ::= time value in NR3 format

Table 18 :FUNction<m> Commands Summary (continued)

Command	Query	Options and Query Returns
:FUNction<m>:SERChart :TIME:OFFSet <offset> (see page 533)	:FUNction<m>:SERChart :TIME:OFFSet? (see page 533)	<m> ::= 1 to (# math functions) in NR1 format <offset> ::= vertical offset value in NR3 format
:FUNction<m>:SMOoth:POINTs <points> (see page 534)	:FUNction<m>:SMOoth:POINTs? (see page 534)	<points> ::= odd integer in NR1 format
:FUNction<m>:SOURcel <source> (see page 535)	:FUNction<m>:SOURcel? (see page 535)	<source> ::= {CHANnel<n> FUNction<c> MATH<c> WMEMemory<r> BUS} <n> ::= 1 to (# analog channels) in NR1 format <c> ::= {1 2 3}, must be lower than <m> <r> ::= 1 to (# ref waveforms) in NR1 format ::= {1 2} <m> ::= 1 to (# math functions) in NR1 format
:FUNction<m>:SOURce2 <source> (see page 537)	:FUNction<m>:SOURce2? (see page 537)	<source> ::= {CHANnel<n> WMEMemory<r> NONE} <n> ::= 1 to (# analog channels) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <m> ::= 1 to (# math functions) in NR1 format
:FUNction<m>:TREND:NM Easurement MEAS<n> (see page 538)	:FUNction<m>:TREND:NM Easurement? (see page 538)	<n> ::= # of installed measurement, from 1 to 10 <m> ::= 1 to (# math functions) in NR1 format

Table 19 :HARDcopy/:HCOPIY Commands Summary

Command	Query	Options and Query Returns
:HARDcopy:AREA <area> (see page 542)	:HARDcopy:AREA? (see page 542)	<area> ::= SCreen
:HARDcopy:APRinter <active_printer> (see page 543)	:HARDcopy:APRinter? (see page 543)	<active_printer> ::= {<index> <name>} <index> ::= integer index of printer in list <name> ::= name of printer in list
:HARDcopy:FACTors {{0 OFF}} {{1 ON}}} (see page 544)	:HARDcopy:FACTors? (see page 544)	{0 1}
:HARDcopy:FFEed {{0 OFF}} {{1 ON}} (see page 545)	:HARDcopy:FFEed? (see page 545)	{0 1}
:HARDcopy:INKSaver {{0 OFF}} {{1 ON}} (see page 546)	:HARDcopy:INKSaver? (see page 546)	{0 1}
:HARDcopy:LAYout <layout> (see page 547)	:HARDcopy:LAYout? (see page 547)	<layout> ::= {LANDscape PORTRait}
:HARDcopy:NETWork:ADD Ress <address> (see page 548)	:HARDcopy:NETWork:ADD Ress? (see page 548)	<address> ::= quoted ASCII string
:HARDcopy:NETWork:APP Ly (see page 549)	n/a	n/a
:HARDcopy:NETWork:DOM ain <domain> (see page 550)	:HARDcopy:NETWork:DOM ain? (see page 550)	<domain> ::= quoted ASCII string
:HARDcopy:NETWork:PAS Sword <password> (see page 551)	n/a	<password> ::= quoted ASCII string
:HARDcopy:NETWork:SLO T <slot> (see page 552)	:HARDcopy:NETWork:SLO T? (see page 552)	<slot> ::= {NET0 NET1}
:HARDcopy:NETWork:USE Rname <username> (see page 553)	:HARDcopy:NETWork:USE Rname? (see page 553)	<username> ::= quoted ASCII string
:HARDcopy:PALETTE <palette> (see page 554)	:HARDcopy:PALETTE? (see page 554)	<palette> ::= {COLor GRAYscale NONE}

Table 19 :HARDcopy/:HCOPIY Commands Summary (continued)

Command	Query	Options and Query Returns
n/a	:HARDcopy:PRINter:LIST? (see page 555)	<list> ::= [<printer_spec>] ... [printer_spec] <printer_spec> ::= "<index>,<active>,<name>;" <index> ::= integer index of printer <active> ::= {Y N} <name> ::= name of printer
:HARDcopy:START (see page 556)	n/a	n/a
n/a	:HCOPIY:SDUMp:DATA? (see page 557)	<display_data> ::= binary block data in IEEE-488.2 # format.
:HCOPIY:SDUMp:FORMat <format> (see page 558)	:HCOPIY:SDUMp:FORMat? (see page 558)	<format> ::= {BMP BMP8bit PNG}

Table 20 :HISTogram Commands Summary

Command	Query	Options and Query Returns
:HISTogram:AXIS <axis> (see page 562)	:HISTogram:AXIS? (see page 562)	<axis> ::= {VERTical HORizontal}
:HISTogram:DISPlay {{0 OFF} {1 ON}} (see page 563)	:HISTogram:DISPlay? (see page 563)	{0 1}
:HISTogram:MEASurement MEAS<n> (see page 564)	:HISTogram:MEASurement? (see page 564)	<n> ::= # of installed measurement, from 1 to 10
:HISTogram:MODE <mode> (see page 565)	:HISTogram:MODE? (see page 565)	<mode> ::= {OFF WAVEform MEASurement}
:HISTogram:RESet (see page 566)	n/a	n/a
:HISTogram:SIZE <size> (see page 567)	:HISTogram:SIZE? (see page 567)	<size> ::= 1.0 to 5.0 for vertical histograms, 1.0 to 4.0 for horizontal histograms, in NR3 format
:HISTogram:TYPE <type> (see page 568)	:HISTogram:TYPE? (see page 568)	<type> ::= {VERTical HORizontal MEASurement}

Table 20 :HISTogram Commands Summary (continued)

Command	Query	Options and Query Returns
:HISTogram:WINDow:BLI Mit <limit> (see page 569)	:HISTogram:WINDow:BLI Mit? (see page 569)	<limit> ::= bottom value in NR3 format
:HISTogram:WINDow:LLI Mit <limit> (see page 570)	:HISTogram:WINDow:LLI Mit? (see page 570)	<limit> ::= left value in NR3 format
:HISTogram:WINDow:RLI Mit <limit> (see page 571)	:HISTogram:WINDow:RLI Mit? (see page 571)	<limit> ::= right value in NR3 format
:HISTogram:WINDow:SOU Rce <source> (see page 572)	:HISTogram:WINDow:SOU Rce? (see page 572)	<source> ::= {CHANnel<n> FUNctIon<m> MATH<m> WMEMoRY<r> CGRaDe} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format
:HISTogram:WINDow:TLI Mit <limit> (see page 573)	:HISTogram:WINDow:TLI Mit? (see page 573)	<limit> ::= top value in NR3 format

Table 21 :JITter Commands Summary

Command	Query	Options and Query Returns
:JITter:HISTogram:APP Ly (see page 577)	n/a	n/a
:JITter:MEASurement MEAS<n> (see page 578)	:JITter:MEASurement? (see page 578)	<n> ::= # of installed measurement, from 1 to 10
:JITter:SPECTrum:APPL y (see page 580)	n/a	n/a
:JITter:SPECTrum:HORI zontal:POSition <value> (see page 581)	:JITter:SPECTrum:HORI zontal:POSition? (see page 581)	<value> ::= X position (center), in NR3 format
:JITter:SPECTrum:HORI zontal:RANGe <value> (see page 582)	:JITter:SPECTrum:HORI zontal:RANGe? (see page 582)	<value> ::= X scaling (span), in NR3 format
:JITter:SPECTrum:VERT ical:OFFSet <value> (see page 583)	:JITter:SPECTrum:VERT ical:OFFSet? (see page 583)	<value> ::= Y offset, in NR3 format

Table 21 :JITter Commands Summary (continued)

Command	Query	Options and Query Returns
:JITter:SPECTrum:VERTical:RANGe <value> (see page 584)	:JITter:SPECTrum:VERTical:RANGe? (see page 584)	<value> ::= Y scaling, in NR3 format
:JITter:SPECTrum:VERTical:TYPE <type> (see page 585)	:JITter:SPECTrum:VERTical:TYPE? (see page 585)	<type> ::= {DECibel VRMS}
:JITter:SPECTrum:WINDow <window> (see page 586)	:JITter:SPECTrum:WINDow? (see page 586)	<window> ::= {RECTangular HANNing FLATtop BHARRis BARTlett}
:JITter:STATe {{0 OFF} {1 ON}} (see page 588)	:JITter:STATe? (see page 588)	{0 1}
:JITter:TREND:APPLy (see page 590)	n/a	n/a
:JITter:TREND:SMOoth:APPLy (see page 591)	n/a	n/a
:JITter:TREND:SMOoth:POINTs <points> (see page 592)	:JITter:TREND:SMOoth:POINTs? (see page 592)	<points> ::= odd integer in NR1 format
:JITter:TREND:VERTical:OFFSet <value> (see page 593)	:JITter:TREND:VERTical:OFFSet? (see page 593)	<value> ::= Y offset, in NR3 format
:JITter:TREND:VERTical:RANGe <value> (see page 594)	:JITter:TREND:VERTical:RANGe? (see page 594)	<value> ::= Y scaling, in NR3 format

Table 22 :LISTer Commands Summary

Command	Query	Options and Query Returns
n/a	:LISTer:DATA? (see page 596)	<binary_block> ::= comma-separated data with newlines at the end of each row
:LISTer:DISPlay {{OFF 0} {SBUS1 ON 1} {SBUS2 2} ALL} (see page 597)	:LISTer:DISPlay? (see page 597)	{OFF SBUS1 SBUS2 ALL}
:LISTer:REFerence <time_ref> (see page 598)	:LISTer:REFerence? (see page 598)	<time_ref> ::= {TRIGger PREVIOUS}

Table 23 :LTEST Commands Summary

Command	Query	Options and Query Returns
:LTEST:COPY (see page 601)	n/a	n/a
:LTEST:COPY:ALL (see page 602)	n/a	n/a
:LTEST:COPY:MARGin <percent> (see page 603)	:LTEST:COPY:MARGin? (see page 603)	<percent> ::= copy margin percent in NR1 format
:LTEST:ENABle {{0 OFF} {1 ON}} (see page 604)	:LTEST:ENABle? (see page 604)	<setting> ::= {0 1}
:LTEST:FAIL <condition> (see page 605)	:LTEST:FAIL? (see page 605)	<condition> ::= {INSide OUTSide}
:LTEST:LLIMit <lower_value> (see page 606)	:LTEST:LLIMit? (see page 606)	<lower_value> ::= a real number in NR3 format
:LTEST:MEASurement {MEAS<n>} (see page 607)	:LTEST:MEASurement? (see page 607)	<n> ::= # of installed measurement, from 1 to 10
n/a	:LTEST:RESults? [{MEAS<n>}] (see page 608)	<n> ::= # of installed measurement, from 1 to 10
:LTEST:RUMode:SOFailu re {{0 OFF} {1 ON}} (see page 609)	:LTEST:RUMode:SOFailu re? (see page 609)	<setting> ::= {0 1}
:LTEST:TEST {{0 OFF} {1 ON}} (see page 610)	:LTEST:TEST? (see page 610)	<setting> ::= {0 1}
:LTEST:ULIMit <upper_value> (see page 611)	:LTEST:ULIMit? (see page 611)	<upper_value> ::= a real number in NR3 format

Table 24 :MARKer Commands Summary

Command	Query	Options and Query Returns
n/a	:MARKer:DYDX? (see page 616)	<return_value> ::= •Y/•X value in NR3 format
:MARKer:MODE <mode> (see page 617)	:MARKer:MODE? (see page 617)	<mode> ::= {OFF MEASurement MANual WAVeform BINary HEX}

Table 24 :MARKer Commands Summary (continued)

Command	Query	Options and Query Returns
:MARKer:X1:DISPlay {0 OFF} {1 ON} (see page 618)	:MARKer:X1:DISPlay? (see page 618)	<setting> ::= {0 1}
:MARKer:X1Position <position>[suffix] (see page 619)	:MARKer:X1Position? (see page 619)	<position> ::= X1 cursor position value in NR3 format [suffix] ::= {s ms us ns ps Hz kHz MHz} <return_value> ::= X1 cursor position value in NR3 format
:MARKer:X1Y1source <source> (see page 620)	:MARKer:X1Y1source? (see page 620)	<source> ::= {CHANnel<n> FUNCTION<m> MATH<m> WMemory<r>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <return_value> ::= <source>
:MARKer:X2:DISPlay {0 OFF} {1 ON} (see page 621)	:MARKer:X2:DISPlay? (see page 621)	<setting> ::= {0 1}
:MARKer:X2Position <position>[suffix] (see page 622)	:MARKer:X2Position? (see page 622)	<position> ::= X2 cursor position value in NR3 format [suffix] ::= {s ms us ns ps Hz kHz MHz} <return_value> ::= X2 cursor position value in NR3 format
:MARKer:X2Y2source <source> (see page 623)	:MARKer:X2Y2source? (see page 623)	<source> ::= {CHANnel<n> FUNCTION<m> MATH<m> WMemory<r>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <return_value> ::= <source>
n/a	:MARKer:XDELta? (see page 624)	<return_value> ::= X cursors delta value in NR3 format

Table 24 :MARKer Commands Summary (continued)

Command	Query	Options and Query Returns
:MARKer:XUNits <mode> (see page 625)	:MARKer:XUNits? (see page 625)	<units> ::= {SECOnds HERTz DEGREes PERCent}
:MARKer:XUNits:USE (see page 626)	n/a	n/a
:MARKer:Y1:DISPlay {{0 OFF} {1 ON}} (see page 627)	:MARKer:Y1:DISPlay? (see page 627)	<setting> ::= {0 1}
:MARKer:Y1Position <position>[suffix] (see page 628)	:MARKer:Y1Position? (see page 628)	<position> ::= Y1 cursor position value in NR3 format [suffix] ::= {V mV dB} <return_value> ::= Y1 cursor position value in NR3 format
:MARKer:Y2:DISPlay {{0 OFF} {1 ON}} (see page 629)	:MARKer:Y2:DISPlay? (see page 629)	<setting> ::= {0 1}
:MARKer:Y2Position <position>[suffix] (see page 630)	:MARKer:Y2Position? (see page 630)	<position> ::= Y2 cursor position value in NR3 format [suffix] ::= {V mV dB} <return_value> ::= Y2 cursor position value in NR3 format
n/a	:MARKer:YDELta? (see page 631)	<return_value> ::= Y cursors delta value in NR3 format
:MARKer:YUNits <mode> (see page 632)	:MARKer:YUNits? (see page 632)	<units> ::= {BASE PERCent}
:MARKer:YUNits:USE (see page 633)	n/a	n/a

Table 25 :MEASure Commands Summary

Command	Query	Options and Query Returns
:MEASure:ALL (see page 660)	n/a	n/a
:MEASure:AREa [<interval>] [, <source>] >] (see page 661)	:MEASure:AREa? [<interval>] [, <source>] >] (see page 661)	<interval> ::= {CYCLE DISPLAY} <source> ::= {CHANnel<n> FUNctIon<m> MATH<m> WMEMory<r>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <return_value> ::= area in volt-seconds, NR3 format
:MEASure:BRATe [<source>] (see page 662)	:MEASure:BRATe? [<source>] (see page 662)	<source> ::= {<digital channels> CHANnel<n> FUNctIon<m> MATH<m> WMEMory<r>} <digital channels> ::= DIGital<d> for the MSO models <d> ::= 0 to (# digital channels - 1) in NR1 format <n> ::= 1 to (# of analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <return_value> ::= bit rate in Hz, NR3 format
:MEASure:BWIDth [<source>] (see page 663)	:MEASure:BWIDth? [<source>] (see page 663)	<source> ::= {CHANnel<n> FUNctIon<m> MATH<m> WMEMory<r>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <return_value> ::= burst width in seconds, NR3 format

Table 25 :MEASure Commands Summary (continued)

Command	Query	Options and Query Returns
:MEASure:CLEar (see page 664)	n/a	n/a
:MEASure:COUNter [<source>] (see page 665)	:MEASure:COUNter? [<source>] (see page 665)	<source> ::= {CHANnel<n> EXTErnal} for DSO models <source> ::= {CHANnel<n> DIGital<d> EXTErnal} for MSO models <n> ::= 1 to (# analog channels) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format <return_value> ::= counter frequency in Hertz in NR3 format
:MEASure:CTCNwidth [<source>] (see page 667)	:MEASure:CTCNwidth? [<source>] (see page 667)	<source> ::= CHANnel<n> <n> ::= 1 to (# analog channels) in NR1 format <return_value> ::= -Width to -Width jitter in NR3 format
:MEASure:CTCPwidth [<source>] (see page 669)	:MEASure:CTCPwidth? [<source>] (see page 669)	<source> ::= CHANnel<n> <n> ::= 1 to (# analog channels) in NR1 format <return_value> ::= +Width to +Width jitter in NR3 format
:MEASure:DEFine DElay, <delay spec> (see page 671)	:MEASure:DEFine? DElay (see page 673)	<delay spec> ::= <edge_spec1>,<edge_spec2> edge_spec1 ::= [<slope>]<occurrence> edge_spec2 ::= [<slope>]<occurrence> <slope> ::= {+ -} <occurrence> ::= integer
:MEASure:DEFine THResholds, <threshold spec> (see page 671)	:MEASure:DEFine? THResholds (see page 673)	<threshold spec> ::= {STANdard} {<threshold mode>,<upper>,<middle>,<lower>} <threshold mode> ::= {PERCent ABSolute}

Table 25 :MEASure Commands Summary (continued)

Command	Query	Options and Query Returns
:MEASure:DElay [<source1>] [,<source2>] (see page 674)	:MEASure:DElay? [<source1>] [,<source2>] (see page 674)	<source1,2> ::= {CHANnel<n> FUNctIon<m> MATH<m> WMEMory<r> <digital channels>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <digital channels> ::= DIGital<d> for the MSO models <d> ::= 0 to (# digital channels - 1) in NR1 format <return_value> ::= floating-point number delay time in seconds in NR3 format
:MEASure:DElay:DEFine <source1_edge_slope>, <source1_edge_number> , <source1_edge_thresho ld>, <source2_edge_slope>, <source2_edge_number> , <source2_edge_thresho ld> (see page 676)	:MEASure:DElay:DEFine ? (see page 676)	<source1_edge_slope>, <source2_edge_slope> ::= {RISing FALLing} <source1_edge_number>, <source2_edge_number> ::= 0 to 1000 in NR1 format <source1_edge_threshold>, <source2_edge_threshold> ::= {LOWer MIDDle UPPer}
:MEASure:DUAL:CHARge [<interval>] [,<source1>] [,<source 2>] (see page 677)	:MEASure:DUAL:CHARge? [<interval>] [,<source1>] [,<source 2>] (see page 677)	<interval> ::= {CYCLE DISPlay} <source1>,<source2> ::= CHANnel<n> with N2820A probe connected} <n> ::= 1 to (# analog channels) in NR1 format <return_value> ::= area in Amp-hours, NR3 format

Table 25 :MEASure Commands Summary (continued)

Command	Query	Options and Query Returns
:MEASure:DUAL:VAMplitude [<source1>] [,<source2>] >] (see page 678)	:MEASure:DUAL:VAMplitude? [<source1>] [,<source2>] >] (see page 678)	<source1>,<source2> ::= CHANNEL<n> with N2820A probe connected <n> ::= 1 to (# analog channels) in NR1 format <return_value> ::= the amplitude of the selected waveform in volts in NR3 format
:MEASure:DUAL:VAverage [<interval>] [,<source1>] [,<source2>] >] (see page 679)	:MEASure:DUAL:VAverage? [<interval>] [,<source1>] [,<source2>] >] (see page 679)	<interval> ::= {CYCLE DISPLAY} <source1>,<source2> ::= CHANNEL<n> with N2820A probe connected <n> ::= 1 to (# analog channels) in NR1 format <return_value> ::= calculated average voltage in NR3 format
:MEASure:DUAL:VBASE [<source1>] [,<source2>] >] (see page 680)	:MEASure:DUAL:VBASE? [<source1>] [,<source2>] >] (see page 680)	<source1>,<source2> ::= CHANNEL<n> with N2820A probe connected <n> ::= 1 to (# analog channels) in NR1 format <base_voltage> ::= voltage at the base of the selected waveform in NR3 format
:MEASure:DUAL:VPP [<source1>] [,<source2>] >] (see page 681)	:MEASure:DUAL:VPP? [<source1>] [,<source2>] >] (see page 681)	<source1>,<source2> ::= CHANNEL<n> with N2820A probe connected <n> ::= 1 to (# analog channels) in NR1 format <return_value> ::= voltage peak-to-peak of the selected waveform in NR3 format
:MEASure:DUAL:VRMS [<interval>] [,<type>] [,<source1>] [,<source2>] >] (see page 682)	:MEASure:DUAL:VRMS? [<interval>] [,<type>] [,<source1>] [,<source2>] >] (see page 682)	<interval> ::= {CYCLE DISPLAY} <type> ::= {AC DC} <source1>,<source2> ::= CHANNEL<n> with N2820A probe connected <n> ::= 1 to (# analog channels) in NR1 format <return_value> ::= calculated RMS voltage in NR3 format

Table 25 :MEASure Commands Summary (continued)

Command	Query	Options and Query Returns
:MEASure:DUTYcycle [<source>] (see page 683)	:MEASure:DUTYcycle? [<source>] (see page 683)	<source> ::= {CHANnel<n> FUNction<m> MATH<m> WMEMory<r>} for DSO models <source> ::= {CHANnel<n> DIGital<d> FUNction<m> MATH<m> WMEMory<r>} for MSO models <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format <return_value> ::= ratio of positive pulse width to period in NR3 format
:MEASure:FALLtime [<source>] (see page 684)	:MEASure:FALLtime? [<source>] (see page 684)	<source> ::= {CHANnel<n> FUNction<m> MATH<m> WMEMory<r>} for DSO models <source> ::= {CHANnel<n> DIGital<d> FUNction<m> MATH<m> WMEMory<r>} for MSO models <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format <return_value> ::= time in seconds between the lower and upper thresholds in NR3 format

Table 25 :MEASure Commands Summary (continued)

Command	Query	Options and Query Returns
:MEASure:FFT:ACPR <chan_width>, <chan_spacing>, <chan>[,<source>] (see page 685)	:MEASure:FFT:ACPR? <chan_width>, <chan_spacing>, <chan>[,<source>] (see page 685)	<chan_width> ::= width of main range and sideband channels, Hz in NR3 format <chan_spacing> ::= spacing between main range and sideband channels, Hz in NR3 format <chan> ::= {CENTer HIGH<sb> LOW<sb>} <sb> ::= sideband 1 to 5 <source> ::= {FUNCTION<m> MATH<m> FFT} (source must be an FFT waveform) <m> ::= 1 to (# math functions) in NR1 format <return_value> ::= adjacent channel power ratio, dBV in NR3 format
:MEASure:FFT:CPOWER [<source>] (see page 686)	:MEASure:FFT:CPOWER? [<source>] (see page 686)	<source> ::= {FUNCTION<m> MATH<m> FFT} (source must be an FFT waveform) <m> ::= 1 to (# math functions) in NR1 format <return_value> ::= spectral channel power, dBV in NR3 format
:MEASure:FFT:OBW <percentage>[,<source>] >] (see page 687)	:MEASure:FFT:OBW? <percentage>[,<source>] >] (see page 687)	<percentage> ::= percent of spectral power occupied bandwidth is measured for in NR3 format <source> ::= {FUNCTION<m> MATH<m> FFT} (source must be an FFT waveform) <m> ::= 1 to (# math functions) in NR1 format <return_value> ::= occupied bandwidth, Hz in NR3 format

Table 25 :MEASure Commands Summary (continued)

Command	Query	Options and Query Returns
:MEASure:FFT:THD [<source>] (see page 688)	:MEASure:FFT:THD? [<source>] (see page 688)	<source> ::= {FUNCTION<m> MATH<m> FFT} (source must be an FFT waveform) <m> ::= 1 to (# math functions) in NR1 format <return_value> ::= total harmonic distortion ratio percent in NR3 format
:MEASure:FREQuency [<source>] (see page 689)	:MEASure:FREQuency? [<source>] (see page 689)	<source> ::= {CHANnel<n> FUNCTION<m> MATH<m> WMEMory<r>} for DSO models <source> ::= {CHANnel<n> DIGital<d> FUNCTION<m> MATH<m> WMEMory<r>} for MSO models <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format <return_value> ::= frequency in Hertz in NR3 format
n/a	:MEASure:HISTogram:BWIDth? (see page 690)	<value> ::= bin width in NR3 format
n/a	:MEASure:HISTogram:HITS? (see page 691)	<value> ::= # of total hits in NR3 format
n/a	:MEASure:HISTogram:M1S? (see page 692)	<value> ::= % of hits within +/-1 std dev in NR3 format
n/a	:MEASure:HISTogram:M2S? (see page 693)	<value> ::= % of hits within +/-2 std devs in NR3 format
n/a	:MEASure:HISTogram:M3S? (see page 694)	<value> ::= % of hits within +/-3 std devs in NR3 format
n/a	:MEASure:HISTogram:MAXimum? (see page 695)	<value> ::= value of max bin in NR3 format
n/a	:MEASure:HISTogram:MEAN? (see page 696)	<value> ::= mean of histogram in NR3 format

Table 25 :MEASure Commands Summary (continued)

Command	Query	Options and Query Returns
n/a	:MEASure:HISTogram:ME Dian? (see page 697)	<value> ::= median of histogram in NR3 format
n/a	:MEASure:HISTogram:MI Nimum? (see page 698)	<value> ::= value of min bin in NR3 format
n/a	:MEASure:HISTogram:MO DE? (see page 699)	<value> ::= mode of histogram in NR3 format
n/a	:MEASure:HISTogram:PE AK? (see page 700)	<value> ::= # of hits in max bin in NR3 format
n/a	:MEASure:HISTogram:PP Eak? (see page 701)	<value> ::= delta value between max bin and min bin in NR3 format
n/a	:MEASure:HISTogram:SD EVIation? (see page 702)	<value> ::= standard deviation of histogram in NR3 format
:MEASure:NCJitter <config> (see page 703)	:MEASure:NCJitter? <config> (see page 704)	<config> ::= <source>, <direction>, <num_periods> <source> ::= {CHANnel<n> FUNctIon<m> MATH<m> WMEMemory<r>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <direction> ::= {RISing FALLing} <num_periods> ::= 1 to 10000 in NR1 format <return_value> ::= N-Period to N-Period jitter in NR3 format

Table 25 :MEASure Commands Summary (continued)

Command	Query	Options and Query Returns
:MEASure:NDUTy [<source>] (see page 705)	:MEASure:NDUTy? [<source>] (see page 705)	<source> ::= {CHANnel<n> FUNctIon<m> MATH<m> WMEMory<r>} for DSO models <source> ::= {CHANnel<n> DIGital<d> FUNctIon<m> MATH<m> WMEMory<r>} for MSO models <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format <return_value> ::= ratio of negative pulse width to period in NR3 format
:MEASure:NEDGes [<source>] (see page 706)	:MEASure:NEDGes? [<source>] (see page 706)	<source> ::= {CHANnel<n> FUNctIon<m> MATH<m> WMEMory<r>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <return_value> ::= the falling edge count in NR3 format

Table 25 :MEASure Commands Summary (continued)

Command	Query	Options and Query Returns
:MEASure:NPERiod <config> (see page 707)	:MEASure:NPERiod? <config> (see page 707)	<config> ::= <source>, <slope>, <num_periods> <source> ::= {CHANnel<n> FUNction<m> MATH<m> WMEMory<r>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <slope> ::= {RISing FALLing} <num_periods> ::= 1 to 10000 in NR1 format <return_value> ::= N-Period jitter in NR3 format
:MEASure:NPULses [<source>] (see page 708)	:MEASure:NPULses? [<source>] (see page 708)	<source> ::= {CHANnel<n> FUNction<m> MATH<m> WMEMory<r> <digital channels>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <digital channels> ::= DIGital<d> for the MSO models <d> ::= 0 to (# digital channels - 1) in NR1 format <return_value> ::= the falling pulse count in NR3 format

Table 25 :MEASure Commands Summary (continued)

Command	Query	Options and Query Returns
:MEASure:NWIDth [<source>] (see page 709)	:MEASure:NWIDth? [<source>] (see page 709)	<source> ::= {CHANnel<n> FUNction<m> MATH<m> WMEMory<r>} for DSO models <source> ::= {CHANnel<n> DIGital<d> FUNction<m> MATH<m> WMEMory<r>} for MSO models <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format <return_value> ::= negative pulse width in seconds-NR3 format
:MEASure:OVERshoot [<source>] (see page 710)	:MEASure:OVERshoot? [<source>] (see page 710)	<source> ::= {CHANnel<n> FUNction<m> MATH<m> WMEMory<r>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <return_value> ::= the percent of the overshoot of the selected waveform in NR3 format
:MEASure:PEDGes [<source>] (see page 712)	:MEASure:PEDGes? [<source>] (see page 712)	<source> ::= {CHANnel<n> FUNction<m> MATH<m> WMEMory<r>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <return_value> ::= the rising edge count in NR3 format

Table 25 :MEASure Commands Summary (continued)

Command	Query	Options and Query Returns
:MEASure:PERiod [<source>] (see page 713)	:MEASure:PERiod? [<source>] (see page 713)	<p><source> ::= {CHANnel<n> FUNctIon<m> MATH<m> WMEMory<r>} for DSO models</p> <p><source> ::= {CHANnel<n> DIGital<d> FUNctIon<m> MATH<m> WMEMory<r>} for MSO models</p> <p><n> ::= 1 to (# analog channels) in NR1 format</p> <p><m> ::= 1 to (# math functions) in NR1 format</p> <p><r> ::= 1 to (# ref waveforms) in NR1 format</p> <p><d> ::= 0 to (# digital channels - 1) in NR1 format</p> <p><return_value> ::= waveform period in seconds in NR3 format</p>
:MEASure:PHASe [<source1>] [,<source2>] (see page 714)	:MEASure:PHASe? [<source1>] [,<source2>] (see page 714)	<p><source1,2> ::= {CHANnel<n> FUNctIon<m> MATH<m> WMEMory<r>} in NR1 format</p> <p><n> ::= 1 to (# analog channels) in NR1 format</p> <p><m> ::= 1 to (# math functions) in NR1 format</p> <p><r> ::= 1 to (# ref waveforms) in NR1 format</p> <p><return_value> ::= the phase angle value in degrees in NR3 format</p>

Table 25 :MEASure Commands Summary (continued)

Command	Query	Options and Query Returns
:MEASure:PPULses [<source>] (see page 715)	:MEASure:PPULses? [<source>] (see page 715)	<source> ::= {CHANnel<n> FUNCTION<m> MATH<m> WMEMory<r> <digital channels>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <digital channels> ::= DIGital<d> for the MSO models <d> ::= 0 to (# digital channels - 1) in NR1 format <return_value> ::= the rising pulse count in NR3 format
:MEASure:PREShoot [<source>] (see page 716)	:MEASure:PREShoot? [<source>] (see page 716)	<source> ::= {CHANnel<n> FUNCTION<m> MATH<m> WMEMory<r>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <return_value> ::= the percent of preshoot of the selected waveform in NR3 format

Table 25 :MEASure Commands Summary (continued)

Command	Query	Options and Query Returns
:MEASure:PWIDth [<source>] (see page 717)	:MEASure:PWIDth? [<source>] (see page 717)	<source> ::= {CHANnel<n> FUNctIon<m> MATH<m> WMEMory<r>} for DSO models <source> ::= {CHANnel<n> DIGital<d> FUNctIon<m> MATH<m> WMEMory<r>} for MSO models <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format <return_value> ::= width of positive pulse in seconds in NR3 format
n/a	:MEASure:RESults? <result_list> (see page 718)	<result_list> ::= comma-separated list of measurement results
:MEASure:RISetime [<source>] (see page 721)	:MEASure:RISetime? [<source>] (see page 721)	<source> ::= {CHANnel<n> FUNctIon<m> MATH<m> WMEMory<r>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <return_value> ::= rise time in seconds in NR3 format
:MEASure:RTEYe:EHEigh t (see page 722)	:MEASure:RTEYe:EHEigh t? (see page 722)	<return_value> ::= eye opening height in NR3 format
:MEASure:RTEYe:EWIDth (see page 723)	:MEASure:RTEYe:EWIDth ? (see page 723)	<return_value> ::= eye opening width in NR3 format

Table 25 :MEASure Commands Summary (continued)

Command	Query	Options and Query Returns
:MEASure:SDEVIation [<source>] (see page 724)	:MEASure:SDEVIation? [<source>] (see page 724)	<source> ::= {CHANnel<n> FUNctIon<m> MATH<m> WMEMory<r>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <return_value> ::= calculated std deviation in NR3 format
:MEASure:SHOW {{0 OFF} {1 ON}} (see page 725)	:MEASure:SHOW? (see page 725)	{0 1}
:MEASure:SLEWrate [<source>[,<slope>]] (see page 726)	:MEASure:SLEWrate? [<source>[,<slope>]] (see page 726)	<source> ::= {CHANnel<n> FUNctIon<m> MATH<m> WMEMory<r>} <n> ::= 1 to (# of analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format
:MEASure:SOURce <source1> [,<source2>] (see page 727)	:MEASure:SOURce? (see page 727)	<source1,2> ::= {CHANnel<n> FUNctIon<m> MATH<m> WMEMory<r> EXTErnal} for DSO models <source1,2> ::= {CHANnel<n> DIGital<d> FUNctIon<m> MATH<m> WMEMory<r> EXTErnal} for MSO models <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format <return_value> ::= {<source> NONE}

Table 25 :MEASure Commands Summary (continued)

Command	Query	Options and Query Returns
:MEASure:STATistics <type> (see page 729)	:MEASure:STATistics? (see page 729)	<type> ::= {{ON 1} CURRENT MEAN MINimum MAXimum STDDev COUNT} ON ::= all statistics returned
:MEASure:STATistics:DISPlay {{0 OFF} {1 ON}} (see page 730)	:MEASure:STATistics:DISPlay? (see page 730)	{0 1}
:MEASure:STATistics:INCRement (see page 731)	n/a	n/a
:MEASure:STATistics:MCOUNT <setting> (see page 732)	:MEASure:STATistics:MCOUNT? (see page 732)	<setting> ::= {INFinite <count>} <count> ::= 2 to 2000 in NR1 format
:MEASure:STATistics:RESet (see page 733)	n/a	n/a
:MEASure:STATistics:RSSDeviation {{0 OFF} {1 ON}} (see page 734)	:MEASure:STATistics:RSSDeviation? (see page 734)	{0 1}

Table 25 :MEASure Commands Summary (continued)

Command	Query	Options and Query Returns
:MEASure:TEDGe [<slope>,<occurrence>] >[,<source>] (see page 735)	:MEASure:TEDGe? [<slope>,<occurrence>] >[,<source>] (see page 736)	<slope> ::= {RISing FALLing EITHER} <occurrence> ::= [+ -]<number> <number> ::= the edge number in NR1 format <source> ::= {<digital channels> CHANNEL<n> FUNCTION<m> MATH<m> WMEMORY<r>} <digital channels> ::= DIGital<d> for the MSO models <n> ::= 1 to (# of analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format <return_value> ::= time in seconds of the specified transition
:MEASure:TIEData <config> (see page 738)	:MEASure:TIEData? <config> (see page 738)	<config> ::= <source>, {SECond UNITinterval} <source> ::= {CHANnel<n> FUNCTION<m> MATH<m> WMEMORY<r>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <return_value> ::= Clock TIE jitter in NR3 format

Table 25 :MEASure Commands Summary (continued)

Command	Query	Options and Query Returns
:MEASure:TIEClock <config> (see page 740)	:MEASure:TIEClock? <config> (see page 740)	<p><config> ::= <source>, {SECond UNITinterval}, <direction></p> <p><source> ::= {CHANnel<n> FUNction<m> MATH<m> WMEMory<r>}</p> <p><n> ::= 1 to (# analog channels) in NR1 format</p> <p><m> ::= 1 to (# math functions) in NR1 format</p> <p><r> ::= 1 to (# ref waveforms) in NR1 format</p> <p><direction> ::= {RISing FALLing BOTH}</p> <p><return_value> ::= Clock TIE jitter in NR3 format</p>
n/a	:MEASure:TVALue? <value>, [<slope>]<occurrence> [,<source>] (see page 742)	<p><value> ::= voltage level that the waveform must cross.</p> <p><slope> ::= direction of the waveform when <value> is crossed.</p> <p><occurrence> ::= transitions reported.</p> <p><source> ::= {CHANnel<n> FUNction<m> MATH<m> WMEMory<r>} for DSO models</p> <p><source> ::= {CHANnel<n> DIGital<d> FUNction<m> MATH<m> WMEMory<r>} for MSO models</p> <p><n> ::= 1 to (# analog channels) in NR1 format</p> <p><m> ::= 1 to (# math functions) in NR1 format</p> <p><r> ::= 1 to (# ref waveforms) in NR1 format</p> <p><d> ::= 0 to (# digital channels - 1) in NR1 format</p> <p><return_value> ::= time in seconds of specified voltage crossing in NR3 format</p>

Table 25 :MEASure Commands Summary (continued)

Command	Query	Options and Query Returns
:MEASure:VAMplitude [<source>] (see page 744)	:MEASure:VAMplitude? [<source>] (see page 744)	<source> ::= {CHANnel<n> FUNCTION<m> MATH<m> WMEMory<r>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <return_value> ::= the amplitude of the selected waveform in volts in NR3 format
:MEASure:VAverage [<interval>] [, <source >] (see page 745)	:MEASure:VAverage? [<interval>] [, <source >] (see page 745)	<interval> ::= {CYCLE DISPLAY} <source> ::= {CHANnel<n> FUNCTION<m> MATH<m> WMEMory<r>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <return_value> ::= calculated average voltage in NR3 format
:MEASure:VBASe [<source>] (see page 746)	:MEASure:VBASe? [<source>] (see page 746)	<source> ::= {CHANnel<n> FUNCTION<m> MATH<m> WMEMory<r>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <base_voltage> ::= voltage at the base of the selected waveform in NR3 format

Table 25 :MEASure Commands Summary (continued)

Command	Query	Options and Query Returns
:MEASure:VMAX [<source>] (see page 747)	:MEASure:VMAX? [<source>] (see page 747)	<source> ::= {CHANnel<n> FUNction<m> MATH<m> WMEMory<r>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <return_value> ::= maximum voltage of the selected waveform in NR3 format
:MEASure:VMIN [<source>] (see page 748)	:MEASure:VMIN? [<source>] (see page 748)	<source> ::= {CHANnel<n> FUNction<m> MATH<m> WMEMory<r>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <return_value> ::= minimum voltage of the selected waveform in NR3 format
:MEASure:VPP [<source>] (see page 749)	:MEASure:VPP? [<source>] (see page 749)	<source> ::= {CHANnel<n> FUNction<m> MATH<m> WMEMory<r>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <return_value> ::= voltage peak-to-peak of the selected waveform in NR3 format

Table 25 :MEASure Commands Summary (continued)

Command	Query	Options and Query Returns
:MEASure:VRATio [<interval>] [, <source 1>] [, <source 2>] (see page 750)	:MEASure:VRATio? [<interval>] [, <source 1>] [, <source 2>] (see page 750)	<interval> ::= {CYCLe DISPlay} <source1,2> ::= {CHANnel<n> FUNCTION<m> MATH<m> WMEMory<r>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <return_value> ::= the ratio value in dB in NR3 format
:MEASure:VRMS [<interval>] [, <type>] [, <source>] (see page 751)	:MEASure:VRMS? [<interval>] [, <type>] [, <source>] (see page 751)	<interval> ::= {CYCLe DISPlay} <type> ::= {AC DC} <source> ::= {CHANnel<n> FUNCTION<m> MATH<m> WMEMory<r>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <return_value> ::= calculated dc RMS voltage in NR3 format
:MEASure:VTOP [<source>] (see page 752)	:MEASure:VTOP? [<source>] (see page 752)	<source> ::= {CHANnel<n> FUNCTION<m> MATH<m> WMEMory<r>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <return_value> ::= voltage at the top of the waveform in NR3 format
:MEASure:WINDow <type> (see page 753)	:MEASure:WINDow? (see page 753)	<type> ::= {MAIN ZOOM AUTO GATE}

Table 25 :MEASure Commands Summary (continued)

Command	Query	Options and Query Returns
:MEASure:XMAX [<source>] (see page 754)	:MEASure:XMAX? [<source>] (see page 754)	<source> ::= {CHANnel<n> FUNCTION<m> MATH<m> WMemory<r>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <return_value> ::= horizontal value of the maximum in NR3 format

Table 25 :MEASure Commands Summary (continued)

Command	Query	Options and Query Returns
:MEASure:XMIn [<source>] (see page 755)	:MEASure:XMIn? [<source>] (see page 755)	<source> ::= {CHANnel<n> FUNctIon<m> MATH<m> WMEMory<r>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <return_value> ::= horizontal value of the minimum in NR3 format
:MEASure:YATX <horiz_location>[,<so urce>] (see page 756)	:MEASure:YATX? <horiz_location>[,<so urce>] (see page 756)	<horiz_location> ::= displayed time from trigger in seconds in NR3 format <source> ::= {CHANnel<n> FUNctIon<m> MATH<m> WMEMory<r>} for DSO models <source> ::= {CHANnel<n> DIGital<d> FUNctIon<m> MATH<m> WMEMory<r>} for MSO models <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format <return_value> ::= voltage at the specified time in NR3 format

Table 26 :MTESt Commands Summary

Command	Query	Options and Query Returns
:MTESt:ALL {{0 OFF} {1 ON}} (see page 786)	:MTESt:ALL? (see page 786)	{0 1}
:MTESt:AMASk:CREate (see page 787)	n/a	n/a

Table 26 :MTESt Commands Summary (continued)

Command	Query	Options and Query Returns
:MTESt:AMASk:SOURce <source> (see page 788)	:MTESt:AMASk:SOURce? (see page 788)	<source> ::= CHANnel<n> <n> ::= {1 2 3 4} for 4ch models <n> ::= {1 2} for 2ch models
:MTESt:AMASk:UNITs <units> (see page 789)	:MTESt:AMASk:UNITs? (see page 789)	<units> ::= {CURRent DIVisions}
:MTESt:AMASk:XDELta <value> (see page 790)	:MTESt:AMASk:XDELta? (see page 790)	<value> ::= X delta value in NR3 format
:MTESt:AMASk:YDELta <value> (see page 791)	:MTESt:AMASk:YDELta? (see page 791)	<value> ::= Y delta value in NR3 format
n/a	:MTESt:COUNT:FWAVEfor ms? [CHANnel<n>] (see page 792)	<failed> ::= number of failed waveforms in NR1 format
:MTESt:COUNT:RESet (see page 793)	n/a	n/a
n/a	:MTESt:COUNT:TIME? (see page 794)	<time> ::= elapsed seconds in NR3 format
n/a	:MTESt:COUNT:WAVEform s? (see page 795)	<count> ::= number of waveforms in NR1 format
:MTESt:DATA <mask> (see page 796)	:MTESt:DATA? (see page 796)	<mask> ::= data in IEEE 488.2 # format.
:MTESt:DELeTe (see page 797)	n/a	n/a
:MTESt:ENABle {{0 OFF} {1 ON}} (see page 798)	:MTESt:ENABle? (see page 798)	{0 1}
:MTESt:LOCK {{0 OFF} {1 ON}} (see page 799)	:MTESt:LOCK? (see page 799)	{0 1}
:MTESt:RMODE <rmode> (see page 800)	:MTESt:RMODE? (see page 800)	<rmode> ::= {FORever TIME SIGMa WAVEforms}
:MTESt:RMODE:FACTION:MEASure {{0 OFF} {1 ON}} (see page 801)	:MTESt:RMODE:FACTION:MEASure? (see page 801)	{0 1}
:MTESt:RMODE:FACTION:PRINT {{0 OFF} {1 ON}} (see page 802)	:MTESt:RMODE:FACTION:PRINT? (see page 802)	{0 1}

Table 26 :MTESt Commands Summary (continued)

Command	Query	Options and Query Returns
:MTESt:RMODe:FACTion:SAVE {{0 OFF} {1 ON}} (see page 803)	:MTESt:RMODe:FACTion:SAVE? (see page 803)	{0 1}
:MTESt:RMODe:FACTion:STOP {{0 OFF} {1 ON}} (see page 804)	:MTESt:RMODe:FACTion:STOP? (see page 804)	{0 1}
:MTESt:RMODe:SIGMa <level> (see page 805)	:MTESt:RMODe:SIGMa? (see page 805)	<level> ::= from 0.1 to 9.3 in NR3 format
:MTESt:RMODe:TIME <seconds> (see page 806)	:MTESt:RMODe:TIME? (see page 806)	<seconds> ::= from 1 to 86400 in NR3 format
:MTESt:RMODe:WAVeforms <count> (see page 807)	:MTESt:RMODe:WAVeforms? (see page 807)	<count> ::= number of waveforms in NR1 format
:MTESt:SCALe:BIND {{0 OFF} {1 ON}} (see page 808)	:MTESt:SCALe:BIND? (see page 808)	{0 1}
:MTESt:SCALe:X1 <x1_value> (see page 809)	:MTESt:SCALe:X1? (see page 809)	<x1_value> ::= X1 value in NR3 format
:MTESt:SCALe:XDELta <xdelta_value> (see page 810)	:MTESt:SCALe:XDELta? (see page 810)	<xdelta_value> ::= X delta value in NR3 format
:MTESt:SCALe:Y1 <y1_value> (see page 811)	:MTESt:SCALe:Y1? (see page 811)	<y1_value> ::= Y1 value in NR3 format
:MTESt:SCALe:Y2 <y2_value> (see page 812)	:MTESt:SCALe:Y2? (see page 812)	<y2_value> ::= Y2 value in NR3 format
:MTESt:SOURce <source> (see page 813)	:MTESt:SOURce? (see page 813)	<source> ::= {CHANnel<n> NONE} <n> ::= {1 2 3 4} for 4ch models <n> ::= {1 2} for 2ch models
n/a	:MTESt:TITLe? (see page 814)	<title> ::= a string of up to 128 ASCII characters

Table 27 :POD<n> Commands Summary

Command	Query	Options and Query Returns
:POD<n>:DISPlay {{0 OFF} {1 ON}} (see page 817)	:POD<n>:DISPlay? (see page 817)	{0 1} <n> ::= 1-2 in NR1 format
:POD<n>:SIZE <value> (see page 818)	:POD<n>:SIZE? (see page 818)	<value> ::= {SMALl MEDium LARGe}
:POD<n>:THReshold <type>[suffix] (see page 819)	:POD<n>:THReshold? (see page 819)	<n> ::= 1-2 in NR1 format <type> ::= {CMOS ECL TTL <user defined value>} <user defined value> ::= value in NR3 format [suffix] ::= {V mV uV }

Table 28 :POWer Commands Summary

Command	Query	Options and Query Returns
n/a	:POWer:CLResponse? (see page 829)	n/a
:POWer:CLResponse:APP Ly (see page 830)	n/a	n/a
n/a	:POWer:CLResponse:DATA? [SWEep SINGle] (see page 831)	<binary_block> ::= comma-separated data with newlines at the end of each row
n/a	:POWer:CLResponse:DATA:GMARgin? (see page 832)	<gain_margin> ::= gain margin in dB in NR3 format.
n/a	:POWer:CLResponse:DATA:GMARgin:FREQuency? (see page 833)	<frequency> ::= 0 degrees phase crossover frequency in Hz in NR3 format
n/a	:POWer:CLResponse:DATA:PMARgin? (see page 834)	<phase_margin> ::= phase margin in degrees in NR3 format.
n/a	:POWer:CLResponse:DATA:PMARgin:FREQuency? (see page 835)	<frequency> ::= 0dB gain crossover frequency in Hz in NR3 format.
:POWer:CLResponse:FREQuency:MODE <mode> (see page 836)	:POWer:CLResponse:FREQuency:MODE? (see page 836)	<mode> ::= {SWEep SINGle}

Table 28 :POWer Commands Summary (continued)

Command	Query	Options and Query Returns
:POWer:CLResponse:FREQuency:SINGLE <value>[suffix] (see page 837)	:POWer:CLResponse:FREQuency:SINGLE? (see page 837)	<value> ::= {20 100 1000 10000 100000 1000000 10000000 20000000} [suffix] ::= {Hz kHz MHz}
:POWer:CLResponse:FREQuency:START <value>[suffix] (see page 838)	:POWer:CLResponse:FREQuency:START? (see page 838)	<value> ::= {20 100 1000 10000 100000 1000000 10000000} [suffix] ::= {Hz kHz MHz}
:POWer:CLResponse:FREQuency:STOP <value>[suffix] (see page 839)	:POWer:CLResponse:FREQuency:STOP? (see page 839)	<value> ::= {100 1000 10000 100000 1000000 10000000 20000000} [suffix] ::= {Hz kHz MHz}
:POWer:CLResponse:PPDecade <pts> (see page 840)	:POWer:CLResponse:PPDecade? (see page 840)	<pts> ::= {10 20 30 40 50 60 70 80 90 100}
:POWer:CLResponse:SOURce:INPut <source> (see page 841)	:POWer:CLResponse:SOURce:INPut? (see page 841)	<source> ::= CHANnel<n> <n> ::= 1 to (# analog channels) in NR1 format
:POWer:CLResponse:SOURce:OUTPut <source> (see page 842)	:POWer:CLResponse:SOURce:OUTPut? (see page 842)	<source> ::= CHANnel<n> <n> ::= 1 to (# analog channels) in NR1 format
:POWer:CLResponse:TRACe <selection> (see page 843)	:POWer:CLResponse:TRACe? (see page 843)	<selection> ::= {NONE ALL GAIN PHASe}[, {GAIN PHASe}]
:POWer:CLResponse:WGEN:LOAD <impedance> (see page 844)	:POWer:CLResponse:WGEN:LOAD? (see page 844)	<impedance> ::= {ONEMeg FIFTy}
:POWer:CLResponse:WGEN:VOLTagE <amplitude>[, <range>] (see page 845)	:POWer:CLResponse:WGEN:VOLTagE? [<range>] (see page 845)	<amplitude> ::= amplitude in volts in NR3 format <range> ::= {F20HZ F100HZ F1KHZ F10KHZ F100KHZ F1MHZ F10MHZ F20MHZ}
:POWer:CLResponse:WGEN:VOLTagE:PROFile {0 OFF} {1 ON} (see page 846)	:POWer:CLResponse:WGEN:VOLTagE:PROFile? (see page 846)	{0 1}
:POWer:DESKew (see page 847)	n/a	n/a

Table 28 :POWer Commands Summary (continued)

Command	Query	Options and Query Returns
:POWer:EFFiciency:APPLy (see page 848)	n/a	n/a
:POWer:EFFiciency:TYP E <type> (see page 849)	:POWer:EFFiciency:TYP E? (see page 849)	<type> ::= {DCDC DCAC ACDC ACAC}
:POWer:ENABle {{0 OFF} {1 ON}} (see page 850)	:POWer:ENABle? (see page 850)	{0 1}
:POWer:HARMonics:APPLy (see page 851)	n/a	n/a
n/a	:POWer:HARMonics:DATA ? (see page 852)	<binary_block> ::= comma-separated data with newlines at the end of each row
:POWer:HARMonics:DISP lay <display> (see page 853)	:POWer:HARMonics:DISP lay? (see page 853)	<display> ::= {TABLE BAR OFF}
n/a	:POWer:HARMonics:FAIL count? (see page 854)	<count> ::= integer in NR1 format
:POWer:HARMonics:LINE <frequency> (see page 855)	:POWer:HARMonics:LINE ? (see page 855)	<frequency> ::= {F50 F60 F400 AUTO}
n/a	:POWer:HARMonics:POWerfactor? (see page 856)	<value> ::= Class C power factor in NR3 format
:POWer:HARMonics:RPOWer <source> (see page 857)	:POWer:HARMonics:RPOWer? (see page 857)	<source> ::= {MEASured USER}
:POWer:HARMonics:RPOWer:USER <value> (see page 858)	:POWer:HARMonics:RPOWer:USER? (see page 858)	<value> ::= Watts from 1.0 to 600.0 in NR3 format
n/a	:POWer:HARMonics:RUNC ount? (see page 859)	<count> ::= integer in NR1 format
:POWer:HARMonics:STAN dard <class> (see page 860)	:POWer:HARMonics:STAN dard? (see page 860)	<class> ::= {A B C D}
n/a	:POWer:HARMonics:STAT us? (see page 861)	<status> ::= {PASS FAIL UNTested}
n/a	:POWer:HARMonics:THD? (see page 862)	<value> ::= Total Harmonics Distortion in NR3 format

Table 28 :POWer Commands Summary (continued)

Command	Query	Options and Query Returns
:POWer:INRush:APPLY (see page 863)	n/a	n/a
:POWer:INRush:EXIT (see page 864)	n/a	n/a
:POWer:INRush:NEXT (see page 865)	n/a	n/a
:POWer:ITYPE <type> (see page 866)	:POWer:ITYPE? (see page 866)	<type> ::= {DC AC}
:POWer:MODulation:APPLY (see page 867)	n/a	n/a
:POWer:MODulation:SOURCe <source> (see page 868)	:POWer:MODulation:SOURCe? (see page 868)	<source> ::= {V I}
:POWer:MODulation:TYPE <modulation> (see page 869)	:POWer:MODulation:TYPE? (see page 869)	<modulation> ::= {VAverage ACRMs VRatio PERiod FREquency PWIDith NWIDth DUTYcycle RISetime FALLtime}
:POWer:ONOFF:APPLY (see page 870)	n/a	n/a
:POWer:ONOFF:EXIT (see page 871)	n/a	n/a
:POWer:ONOFF:NEXT (see page 872)	n/a	n/a
:POWer:ONOFF:TEST {{0 OFF} {1 ON}} (see page 873)	:POWer:ONOFF:TEST? (see page 873)	{0 1}
:POWer:ONOFF:THReshOlDs <type>, <input_thr>, <output_thr> (see page 874)	:POWer:ONOFF:THReshOlDs? <type> (see page 874)	<type> ::= {0 1} <input_thr> ::= percent from 0-100 in NR1 format <output_thr> ::= percent from 0-100 in NR1 format
n/a	:POWer:PSRR? (see page 876)	n/a
:POWer:PSRR:APPLY (see page 877)	n/a	n/a
n/a	:POWer:PSRR:DATA? [SWEp SINGLE] (see page 878)	<binary_block> ::= comma-separated data with newlines at the end of each row

Table 28 :POWer Commands Summary (continued)

Command	Query	Options and Query Returns
:POWer:PSRR:FREQuency:MAXimum <value>[suffix] (see page 879)	:POWer:PSRR:FREQuency:MAXimum? (see page 879)	<value> ::= {10 100 1000 10000 100000 1000000 10000000 20000000} [suffix] ::= {Hz kHz MHz}
:POWer:PSRR:FREQuency:MINimum <value>[suffix] (see page 880)	:POWer:PSRR:FREQuency:MINimum? (see page 880)	<value> ::= {1 10 100 1000 10000 100000 1000000 10000000} [suffix] ::= {Hz kHz MHz}
:POWer:PSRR:FREQuency:MODE <mode> (see page 881)	:POWer:PSRR:FREQuency:MODE? (see page 881)	<mode> ::= {SWEep SINGle}
:POWer:PSRR:FREQuency:SINGLE <value>[suffix] (see page 882)	:POWer:PSRR:FREQuency:SINGLE? (see page 882)	<value> ::= {1 10 100 1000 10000 100000 1000000 10000000 20000000} [suffix] ::= {Hz kHz MHz}
:POWer:PSRR:PPDecade <pts> (see page 883)	:POWer:PSRR:PPDecade? (see page 883)	<pts> ::= {10 20 30 40 50 60 70 80 90 100}
:POWer:PSRR:SOURce:INPut <source> (see page 884)	:POWer:PSRR:SOURce:INPut? (see page 884)	<source> ::= CHANNEL<n> <n> ::= 1 to (# analog channels) in NR1 format
:POWer:PSRR:SOURce:OUTPut <source> (see page 885)	:POWer:PSRR:SOURce:OUTPut? (see page 885)	<source> ::= CHANNEL<n> <n> ::= 1 to (# analog channels) in NR1 format
:POWer:PSRR:TRACe <selection> (see page 886)	:POWer:PSRR:TRACe? (see page 886)	<selection> ::= {NONE GAIN}
:POWer:PSRR:WGEN:LOAD <impedance> (see page 887)	:POWer:PSRR:WGEN:LOAD? (see page 887)	<impedance> ::= {ONEMeg FIFTy}
:POWer:PSRR:WGEN:VOLTage <amplitude>[,<range>] (see page 888)	:POWer:PSRR:WGEN:VOLTage? [<range>] (see page 888)	<amplitude> ::= amplitude in volts in NR3 format <range> ::= {F20HZ F100HZ F1KHZ F10KHZ F100KHZ F1MHZ F10MHZ F20MHZ}
:POWer:PSRR:WGEN:VOLTage:PROFile {{0 OFF} {1 ON}} (see page 889)	:POWer:PSRR:WGEN:VOLTage:PROFile? (see page 889)	{0 1}

Table 28 :POWer Commands Summary (continued)

Command	Query	Options and Query Returns
:POWer:QUALity:APPLy (see page 890)	n/a	n/a
:POWer:RIPPLe:APPLy (see page 891)	n/a	n/a
:POWer:SIGNals:AUTose tup <analysis> (see page 892)	n/a	<analysis> ::= {HARMONics EFFiciency RIPPLe MODulation QUALity SLEW SWITCh RDSVce}
:POWer:SIGNals:CYCLes :HARMONics <count> (see page 893)	:POWer:SIGNals:CYCLes :HARMONics? (see page 893)	<count> ::= integer in NR1 format Legal values are 1 to 100.
:POWer:SIGNals:CYCLes :QUALity <count> (see page 894)	:POWer:SIGNals:CYCLes :QUALity? (see page 894)	<count> ::= integer in NR1 format Legal values are 1 to 100.
:POWer:SIGNals:DURati on:EFFiciency <value>[suffix] (see page 895)	:POWer:SIGNals:DURati on:EFFiciency? (see page 895)	<value> ::= value in NR3 format [suffix] ::= {s ms us ns}
:POWer:SIGNals:DURati on:MODulation <value>[suffix] (see page 896)	:POWer:SIGNals:DURati on:MODulation? (see page 896)	<value> ::= value in NR3 format [suffix] ::= {s ms us ns}
:POWer:SIGNals:DURati on:ONOFF:OFF <value>[suffix] (see page 897)	:POWer:SIGNals:DURati on:ONOFF:OFF? (see page 897)	<value> ::= value in NR3 format [suffix] ::= {s ms us ns}
:POWer:SIGNals:DURati on:ONOFF:ON <value>[suffix] (see page 898)	:POWer:SIGNals:DURati on:ONOFF:ON? (see page 898)	<value> ::= value in NR3 format [suffix] ::= {s ms us ns}
:POWer:SIGNals:DURati on:RIPPLe <value>[suffix] (see page 899)	:POWer:SIGNals:DURati on:RIPPLe? (see page 899)	<value> ::= value in NR3 format [suffix] ::= {s ms us ns}
:POWer:SIGNals:DURati on:TRANsient <value>[suffix] (see page 900)	:POWer:SIGNals:DURati on:TRANsient? (see page 900)	<value> ::= value in NR3 format [suffix] ::= {s ms us ns}
:POWer:SIGNals:IEXPe cted <value>[suffix] (see page 901)	:POWer:SIGNals:IEXPe cted? (see page 901)	<value> ::= Expected current value in NR3 format [suffix] ::= {A mA}

Table 28 :POWER Commands Summary (continued)

Command	Query	Options and Query Returns
:POWER:SIGNals:OVERshoot <percent> (see page 902)	:POWER:SIGNals:OVERshoot? (see page 902)	<percent> ::= percent of overshoot value in NR1 format [suffix] ::= {V mV}
:POWER:SIGNals:VMAXimum:INRush <value>[suffix] (see page 903)	:POWER:SIGNals:VMAXimum:INRush? (see page 903)	<value> ::= Maximum expected input Voltage in NR3 format [suffix] ::= {V mV}
:POWER:SIGNals:VMAXimum:ONOff:OFF <value>[suffix] (see page 904)	:POWER:SIGNals:VMAXimum:ONOff:OFF? (see page 904)	<value> ::= Maximum expected input Voltage in NR3 format [suffix] ::= {V mV}
:POWER:SIGNals:VMAXimum:ONOff:ON <value>[suffix] (see page 905)	:POWER:SIGNals:VMAXimum:ONOff:ON? (see page 905)	<value> ::= Maximum expected input Voltage in NR3 format [suffix] ::= {V mV}
:POWER:SIGNals:VSTeady:ONOff:OFF <value>[suffix] (see page 906)	:POWER:SIGNals:VSTeady:ONOff:OFF? (see page 906)	<value> ::= Expected steady stage output Voltage value in NR3 format [suffix] ::= {V mV}
:POWER:SIGNals:VSTeady:ONOff:ON <value>[suffix] (see page 907)	:POWER:SIGNals:VSTeady:ONOff:ON? (see page 907)	<value> ::= Expected steady stage output Voltage value in NR3 format [suffix] ::= {V mV}
:POWER:SIGNals:VSTeady:TRANSient <value>[suffix] (see page 908)	:POWER:SIGNals:VSTeady:TRANSient? (see page 908)	<value> ::= Expected steady stage output Voltage value in NR3 format [suffix] ::= {V mV}
:POWER:SIGNals:SOURce:CURRENT<i> <source> (see page 909)	:POWER:SIGNals:SOURce:CURRENT<i>? (see page 909)	<i> ::= 1, 2 in NR1 format <source> ::= CHANNEL<n> <n> ::= 1 to (# analog channels) in NR1 format
:POWER:SIGNals:SOURce:VOLTage<i> <source> (see page 910)	:POWER:SIGNals:SOURce:VOLTage<i>? (see page 910)	<i> ::= 1, 2 in NR1 format <source> ::= CHANNEL<n> <n> ::= 1 to (# analog channels) in NR1 format
:POWER:SLEW:APPLy (see page 911)	n/a	n/a

Table 28 :POWer Commands Summary (continued)

Command	Query	Options and Query Returns
:POWer:SLEW:SOURce <source> (see page 912)	:POWer:SLEW:SOURce? (see page 912)	<source> ::= {V I}
:POWer:SWITCh:APPLy (see page 913)	n/a	n/a
:POWer:SWITCh:CONduct ion <conduction> (see page 914)	:POWer:SWITCh:CONduct ion? (see page 914)	<conduction> ::= {WAVEform RDS VCE}
:POWer:SWITCh:IREFere nce <percent> (see page 915)	:POWer:SWITCh:IREFere nce? (see page 915)	<percent> ::= percent in NR1 format
:POWer:SWITCh:RDS <value>[suffix] (see page 916)	:POWer:SWITCh:RDS? (see page 916)	<value> ::= Rds(on) value in NR3 format [suffix] ::= {OHM mOHM}
:POWer:SWITCh:VCE <value>[suffix] (see page 917)	:POWer:SWITCh:VCE? (see page 917)	<value> ::= Vce(sat) value in NR3 format [suffix] ::= {V mV}
:POWer:SWITCh:VREFere nce <percent> (see page 918)	:POWer:SWITCh:VREFere nce? (see page 918)	<percent> ::= percent in NR1 format
:POWer:TRANSient:APPL y (see page 919)	n/a	n/a
:POWer:TRANSient:EXIT (see page 920)	n/a	n/a
:POWer:TRANSient:IINi tial <value>[suffix] (see page 921)	:POWer:TRANSient:IINi tial? (see page 921)	<value> ::= Initial current value in NR3 format [suffix] ::= {A mA}
:POWer:TRANSient:INEW <value>[suffix] (see page 922)	:POWer:TRANSient:INEW ? (see page 922)	<value> ::= New current value in NR3 format [suffix] ::= {A mA}
:POWer:TRANSient:NEXT (see page 923)	n/a	n/a

Table 29 :RECall Commands Summary

Command	Query	Options and Query Returns
:RECall:ARBitrary:[ST ART] [<file_spec>] [, <column>] [, <wavegen_id>] (see page 928)	n/a	<file_spec> ::= {<internal_loc> <file_name>} <column> ::= Column in CSV file to load. Column number starts from 1. <internal_loc> ::= 0-3; an integer in NR1 format <file_name> ::= quoted ASCII string <wavegen_id> ::= {WGEN1 WGEN2}
:RECall:DBC[:START] [<file_name>] [, <serialbus>] (see page 929)	n/a	<file_name> ::= quoted ASCII string If extension included in file name, it must be ".dbc". <serialbus> ::= {SBUS<n>} <n> ::= 1 to (# of serial bus) in NR1 format
:RECall:FIleName <base_name> (see page 930)	:RECall:FIleName? (see page 930)	<base_name> ::= quoted ASCII string
:RECall:LDF[:START] [<file_name>] [, <serialbus>] (see page 931)	n/a	<file_name> ::= quoted ASCII string If extension included in file name, it must be ".ldf". <serialbus> ::= {SBUS<n>} <n> ::= 1 to (# of serial bus) in NR1 format
:RECall:MASk[:START] [<file_spec>] (see page 932)	n/a	<file_spec> ::= {<internal_loc> <file_name>} <internal_loc> ::= 0-3; an integer in NR1 format <file_name> ::= quoted ASCII string
:RECall:PWD <path_name> (see page 933)	:RECall:PWD? (see page 933)	<path_name> ::= quoted ASCII string

Table 29 :RECall Commands Summary (continued)

Command	Query	Options and Query Returns
:RECall:SETup[:START] [<file_spec>] (see page 934)	n/a	<file_spec> ::= {<internal_loc> <file_name>} <internal_loc> ::= 0-9; an integer in NR1 format <file_name> ::= quoted ASCII string
:RECall:WMEMemory<r>[:START] [<file_name> <data>] (see page 935)	n/a	<r> ::= 1 to (# ref waveforms) in NR1 format <file_name> ::= quoted ASCII string If extension included in file name, it must be ".h5". <data> ::= binary block data in IEEE 488.2 # format

Table 30 :RTEYe Commands Summary

Command	Query	Options and Query Returns
:RTEYe:ACQuire (see page 938)	n/a	n/a
:RTEYe:SOURce <source> (see page 939)	:RTEYe:SOURce? (see page 939)	<source> ::= CHANnel<n> <n> ::= 1 to (# analog channels) in NR1 format
:RTEYe:STATe {{0 OFF} {1 ON}} (see page 940)	:RTEYe:STATe? (see page 940)	{0 1}
n/a	:RTEYe:TUINtervals? (see page 941)	<UI_intervals> ::= total number of UI intervals folded in eye diagram in NR1 format

Table 31 :SAVE Commands Summary

Command	Query	Options and Query Returns
:SAVE:ARBitrary:[STARt] [<file_spec>][,<wavegen_id>] (see page 947)	n/a	<file_spec> ::= {<internal_loc> <file_name>} <internal_loc> ::= 0-3; an integer in NR1 format <file_name> ::= quoted ASCII string <wavegen_id> ::= {WGEN1 WGEN2}
:SAVE:COMPliance:USB[:STARt] [<file_name>] (see page 948)	n/a	<file_name> ::= quoted ASCII string
:SAVE:FIleName <base_name> (see page 949)	:SAVE:FIleName? (see page 949)	<base_name> ::= quoted ASCII string
:SAVE:IMAGe[:STARt] [<file_name>] (see page 950)	n/a	<file_name> ::= quoted ASCII string
:SAVE:IMAGe:FACTORs{{0 OFF} {1 ON}} (see page 951)	:SAVE:IMAGe:FACTORs? (see page 951)	{0 1}
:SAVE:IMAGe:FORMat <format> (see page 952)	:SAVE:IMAGe:FORMat? (see page 952)	<format> ::= {{BMP BMP24bit} BMP8bit PNG NONE}
:SAVE:IMAGe:INKSaver{{0 OFF} {1 ON}} (see page 953)	:SAVE:IMAGe:INKSaver? (see page 953)	{0 1}
:SAVE:IMAGe:PALette <palette> (see page 954)	:SAVE:IMAGe:PALette? (see page 954)	<palette> ::= {COLor GRAYscale}
:SAVE:LISter[:STARt] [<file_name>] (see page 955)	n/a	<file_name> ::= quoted ASCII string
:SAVE:MASK[:STARt] [<file_spec>] (see page 956)	n/a	<file_spec> ::= {<internal_loc> <file_name>} <internal_loc> ::= 0-3; an integer in NR1 format <file_name> ::= quoted ASCII string
:SAVE:MULTi[:STARt] [<file_name>] (see page 957)	n/a	<file_name> ::= quoted ASCII string

Table 31 :SAVE Commands Summary (continued)

Command	Query	Options and Query Returns
:SAVE:POWer[:START] [<file_name>] (see page 958)	n/a	<file_name> ::= quoted ASCII string
:SAVE:PWD <path_name> (see page 959)	:SAVE:PWD? (see page 959)	<path_name> ::= quoted ASCII string
:SAVE:RESults[:START] [<file_spec>] (see page 960)	n/a	<file_name> ::= quoted ASCII string
:SAVE:RESults:FORMat: CGRade {{0 OFF} {1 ON}} (see page 961)	:SAVE:RESults:FORMat: CGRade? (see page 961)	{0 1}
:SAVE:RESults:FORMat: CURSor {{0 OFF} {1 ON}} (see page 962)	:SAVE:RESults:FORMat: CURSor? (see page 962)	{0 1}
:SAVE:RESults:FORMat: HISTogram {{0 OFF} {1 ON}} (see page 963)	:SAVE:RESults:FORMat: HISTogram? (see page 963)	{0 1}
:SAVE:RESults:FORMat: MASK {{0 OFF} {1 ON}} (see page 964)	:SAVE:RESults:FORMat: MASK? (see page 964)	{0 1}
:SAVE:RESults:FORMat: MEASurement {{0 OFF} {1 ON}} (see page 965)	:SAVE:RESults:FORMat: MEASurement? (see page 965)	{0 1}
:SAVE:RESults:FORMat: SEARch {{0 OFF} {1 ON}} (see page 966)	:SAVE:RESults:FORMat: SEARch? (see page 966)	{0 1}
:SAVE:RESults:FORMat: SEGmented {{0 OFF} {1 ON}} (see page 967)	:SAVE:RESults:FORMat: SEGmented? (see page 967)	{0 1}
:SAVE[:SETup[:START]] [<file_spec>] (see page 968)	n/a	<file_spec> ::= {<internal_loc> <file_name>} <internal_loc> ::= 0-9; an integer in NR1 format <file_name> ::= quoted ASCII string

Table 31 :SAVE Commands Summary (continued)

Command	Query	Options and Query Returns
:SAVE:WAVEform[:START] [<file_name>] (see page 969)	n/a	<file_name> ::= quoted ASCII string
:SAVE:WAVEform:FORMat <format> (see page 970)	:SAVE:WAVEform:FORMat ? (see page 970)	<format> ::= {ASCIixy CSV BINary NONE}
:SAVE:WAVEform:LENGth <length> (see page 971)	:SAVE:WAVEform:LENGth ? (see page 971)	<length> ::= 100 to max. length; an integer in NR1 format
:SAVE:WAVEform:LENGth:MAX {{0 OFF} {1 ON}} (see page 972)	:SAVE:WAVEform:LENGth:MAX? (see page 972)	{0 1}
:SAVE:WAVEform:SEGMent <option> (see page 973)	:SAVE:WAVEform:SEGMent? (see page 973)	<option> ::= {ALL CURRent}
:SAVE:WMEMory:SOURce <source> (see page 974)	:SAVE:WMEMory:SOURce? (see page 974)	<source> ::= {CHANnel<n> FUNCTION<m> MATH<m> WMEMory<r>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format NOTE: Only ADD or SUBtract math operations can be saved as reference waveforms. <return_value> ::= <source>
:SAVE:WMEMory[:START] [<file_name>] (see page 975)	n/a	<file_name> ::= quoted ASCII string If extension included in file name, it must be ".h5".

Table 32 General :SBUS<n> Commands Summary

Command	Query	Options and Query Returns
:SBUS<n>:DISPlay {{0 OFF} {1 ON}} (see page 980)	:SBUS<n>:DISPlay? (see page 980)	{0 1}
:SBUS<n>:MODE <mode> (see page 981)	:SBUS<n>:MODE? (see page 981)	<mode> ::= {A429 CAN CXPI FLEXray I2S IIC LIN M1553 MANchester NRZ SENT SPI UART USB USBPd}

Table 33 :SBUS<n>:A429 Commands Summary

Command	Query	Options and Query Returns
:SBUS<n>:A429:AUToset up (see page 984)	n/a	n/a
:SBUS<n>:A429:BASE <base> (see page 985)	:SBUS<n>:A429:BASE? (see page 985)	<base> ::= {BINary HEX}
:SBUS<n>:A429:BAUDrate <baudrate> (see page 986)	:SBUS<n>:A429:BAUDrate? (see page 986)	<baudrate> ::= integer from 10000 to 1000000
n/a	:SBUS<n>:A429:COUNT:ERRor? (see page 987)	<error_count> ::= integer in NR1 format
:SBUS<n>:A429:COUNT:RESet (see page 988)	n/a	n/a
n/a	:SBUS<n>:A429:COUNT:WORD? (see page 989)	<word_count> ::= integer in NR1 format
:SBUS<n>:A429:FORMat <format> (see page 990)	:SBUS<n>:A429:FORMat? (see page 990)	<format> ::= {LDSDi LDSSm LDATa}
:SBUS<n>:A429:SIGNal <signal> (see page 991)	:SBUS<n>:A429:SIGNal? (see page 991)	<signal> ::= {A B DIFFerential}
:SBUS<n>:A429:SOURce <source> (see page 992)	:SBUS<n>:A429:SOURce? (see page 992)	<source> ::= {CHANnel<n>} <n> ::= 1 to (# analog channels) in NR1 format
:SBUS<n>:A429:SPEed <speed> (see page 993)	:SBUS<n>:A429:SPEed? (see page 993)	<speed> ::= {LOW HIGH USER}

Table 33 :SBUS<n>:A429 Commands Summary (continued)

Command	Query	Options and Query Returns
:SBUS<n>:A429:TRIGger :LAbel <value> (see page 994)	:SBUS<n>:A429:TRIGger :LAbel? (see page 994)	<value> ::= 8-bit integer in decimal, <hex>, <octal>, or <string> from 0-255 or "0xXX" (don't care) <hex> ::= #Hnn where n ::= {0,...,9 A,...,F} <octal> ::= #Qnnn where n ::= {0,...,7} <string> ::= "0xnn" where n ::= {0,...,9 A,...,F}
:SBUS<n>:A429:TRIGger :PATtern:DATA <string> (see page 995)	:SBUS<n>:A429:TRIGger :PATtern:DATA? (see page 995)	<string> ::= "nn...n" where n ::= {0 1 X}, length depends on FORMat
:SBUS<n>:A429:TRIGger :PATtern:SDI <string> (see page 996)	:SBUS<n>:A429:TRIGger :PATtern:SDI? (see page 996)	<string> ::= "nn" where n ::= {0 1 X}, length always 2 bits
:SBUS<n>:A429:TRIGger :PATtern:SSM <string> (see page 997)	:SBUS<n>:A429:TRIGger :PATtern:SSM? (see page 997)	<string> ::= "nn" where n ::= {0 1 X}, length always 2 bits
:SBUS<n>:A429:TRIGger :RANGe <min>,<max> (see page 998)	:SBUS<n>:A429:TRIGger :RANGe? (see page 998)	<min> ::= 8-bit integer in decimal, <hex>, <octal>, or <string> from 0-255 <max> ::= 8-bit integer in decimal, <hex>, <octal>, or <string> from 0-255 <hex> ::= #Hnn where n ::= {0,...,9 A,...,F} <octal> ::= #Qnnn where n ::= {0,...,7} <string> ::= "0xnn" where n ::= {0,...,9 A,...,F}
:SBUS<n>:A429:TRIGger :TYPE <condition> (see page 999)	:SBUS<n>:A429:TRIGger :TYPE? (see page 999)	<condition> ::= {WSTArt WSTOp LAbel LBITs PERror WERror GERror WGERrors ALLerrors LRANGe ABITs AOBits AZBits}

Table 34 :SBUS<n>:CAN Commands Summary

Command	Query	Options and Query Returns
n/a	:SBUS<n>:CAN:COUNT:ER Ror? (see page 1004)	<frame_count> ::= integer in NR1 format
n/a	:SBUS<n>:CAN:COUNT:OV ERload? (see page 1005)	<frame_count> ::= 0 in NR1 format
:SBUS<n>:CAN:COUNT:RE Set (see page 1006)	n/a	n/a
n/a	:SBUS<n>:CAN:COUNT:SP EC? (see page 1007)	<spec_error_count> ::= integer in NR1 format
n/a	:SBUS<n>:CAN:COUNT:TO Tal? (see page 1008)	<frame_count> ::= integer in NR1 format
n/a	:SBUS<n>:CAN:COUNT:UT ILization? (see page 1009)	<percent> ::= floating-point in NR3 format
:SBUS<n>:CAN:DISPlay <type> (see page 1010)	:SBUS<n>:CAN:DISPlay? (see page 1010)	<type> ::= {HEXadecimal SYMBOLic}
:SBUS<n>:CAN:FDSPoint <value> (see page 1011)	:SBUS<n>:CAN:FDSPoint ? (see page 1011)	<value> ::= even numbered percentages from 30 to 90 in NR3 format.
:SBUS<n>:CAN:FDSTanda rd <std> (see page 1012)	:SBUS<n>:CAN:FDSTanda rd? (see page 1012)	<std> ::= {ISO NISO}
:SBUS<n>:CAN:SAMplepo int <percent> (see page 1013)	:SBUS<n>:CAN:SAMplepo int? (see page 1013)	<percent> ::= 30.0 to 90.0 in NR3 format
:SBUS<n>:CAN:SIGNAL:BA UDrate <baudrate> (see page 1014)	:SBUS<n>:CAN:SIGNAL:BA UDrate? (see page 1014)	<baudrate> ::= integer from 10000 to 4000000 in 100 b/s increments, or 5000000
:SBUS<n>:CAN:SIGNAL:DE Finition <value> (see page 1015)	:SBUS<n>:CAN:SIGNAL:DE Finition? (see page 1015)	<value> ::= {CANH CANL RX TX DIFFerential DIFL DIFH}
:SBUS<n>:CAN:SIGNAL:FB DBaudrate <baudrate> (see page 1016)	:SBUS<n>:CAN:SIGNAL:FB DBaudrate? (see page 1016)	<baudrate> ::= integer from 10000 to 10000000 in 100 b/s increments.

Table 34 :SBUS<n>:CAN Commands Summary (continued)

Command	Query	Options and Query Returns
:SBUS<n>:CAN:SOURce <source> (see page 1017)	:SBUS<n>:CAN:SOURce? (see page 1017)	<source> ::= {CHANnel<n> EXTernal} for DSO models <source> ::= {CHANnel<n> DIGital<d> } for MSO models <n> ::= 1 to (# analog channels) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format
:SBUS<n>:CAN:TRIGger <condition> (see page 1018)	:SBUS<n>:CAN:TRIGger? (see page 1019)	<condition> ::= {SOF EOF IDData DATA FDData IDRemote IDEither ERRor ACKerror FORMerror STUFFerror CRCerror SPECerror ALLerrors BRsBit CRCDbit EBActive EBPAssive OVERload MESSage MSIGnal FDMSignal}
:SBUS<n>:CAN:TRIGger:IDFilter {{0 OFF} {1 ON}} (see page 1021)	:SBUS<n>:CAN:TRIGger:IDFilter? (see page 1021)	{0 1}
:SBUS<n>:CAN:TRIGger:PATtern:DATA <string> (see page 1022)	:SBUS<n>:CAN:TRIGger:PATtern:DATA? (see page 1022)	<string> ::= "nn...n" where n ::= {0 1 X \$} <string ::= "0xnn...n" where n ::= {0,...,9 A,...,F X \$}
:SBUS<n>:CAN:TRIGger:PATtern:DATA:DLC <dlc> (see page 1023)	:SBUS<n>:CAN:TRIGger:PATtern:DATA:DLC? (see page 1023)	<dlc> ::= integer between -1 (don't care) and 64, in NR1 format.
:SBUS<n>:CAN:TRIGger:PATtern:DATA:LENGth <length> (see page 1024)	:SBUS<n>:CAN:TRIGger:PATtern:DATA:LENGth? (see page 1024)	<length> ::= integer from 1 to 8 in NR1 format
:SBUS<n>:CAN:TRIGger:PATtern:DATA:STARt <start> (see page 1025)	:SBUS<n>:CAN:TRIGger:PATtern:DATA:STARt? (see page 1025)	<start> ::= integer between 0 and 63, in NR1 format.
:SBUS<n>:CAN:TRIGger:PATtern:ID <string> (see page 1026)	:SBUS<n>:CAN:TRIGger:PATtern:ID? (see page 1026)	<string> ::= "nn...n" where n ::= {0 1 X \$} <string ::= "0xnn...n" where n ::= {0,...,9 A,...,F X \$}

Table 34 :SBUS<n>:CAN Commands Summary (continued)

Command	Query	Options and Query Returns
:SBUS<n>:CAN:TRIGger: PATtern:ID:MODE <value> (see page 1027)	:SBUS<n>:CAN:TRIGger: PATtern:ID:MODE? (see page 1027)	<value> ::= {STANdard EXTended}
:SBUS<n>:CAN:TRIGger: SYMBolic:MESSAge <name> (see page 1028)	:SBUS<n>:CAN:TRIGger: SYMBolic:MESSAge? (see page 1028)	<name> ::= quoted ASCII string
:SBUS<n>:CAN:TRIGger: SYMBolic:SIGNal <name> (see page 1029)	:SBUS<n>:CAN:TRIGger: SYMBolic:SIGNal? (see page 1029)	<name> ::= quoted ASCII string
:SBUS<n>:CAN:TRIGger: SYMBolic:VALue <data> (see page 1030)	:SBUS<n>:CAN:TRIGger: SYMBolic:VALue? (see page 1030)	<data> ::= value in NR3 format

Table 35 :SBUS<n>:CXPI Commands Summary

Command	Query	Options and Query Returns
:SBUS<n>:CXPI:BAUDrat e <baudrate> (see page 1033)	:SBUS<n>:CXPI:BAUDrat e? (see page 1033)	<baudrate> ::= integer from 9600 to 40000 in 100 b/s increments.
:SBUS<n>:CXPI:PARity {0 OFF} {1 ON}} (see page 1034)	:SBUS<n>:CXPI:PARity? (see page 1034)	{0 1}
:SBUS<n>:CXPI:SOURce <source> (see page 1035)	:SBUS<n>:CXPI:SOURce? (see page 1035)	<source> ::= {CHANnel<n>} <n> ::= 1 to (# analog channels) in NR1 format
:SBUS<n>:CXPI:TOLeran ce <percent> (see page 1036)	:SBUS<n>:CXPI:TOLeran ce? (see page 1036)	<percent> ::= from 1-30, in NR1 format.
:SBUS<n>:CXPI:TRIGger <mode> (see page 1037)	:SBUS<n>:CXPI:TRIGger ? (see page 1038)	<mode> ::= {SOF EOF PTYPe ID DATA LDATA CRCerror PARityerror IBSError IFSerror FRAMingerror DLENgtherror SAMPleerror ALLerrors SLEEpframe WAKEuppulse}
:SBUS<n>:CXPI:TRIGger :IDFilter {{0 OFF} {1 ON}} (see page 1039)	:SBUS<n>:CXPI:TRIGger :IDFilter? (see page 1039)	{0 1}

Table 35 :SBUS<n>:CXPI Commands Summary (continued)

Command	Query	Options and Query Returns
:SBUS<n>:CXPI:TRIGger :PTYPE {{0 OFF} {1 ON}} (see page 1040)	:SBUS<n>:CXPI:TRIGger :PTYPE? (see page 1040)	{0 1}
:SBUS<n>:CXPI:TRIGger :PATTERN:DATA <string> (see page 1041)	:SBUS<n>:CXPI:TRIGger :PATTERN:DATA? (see page 1041)	<string> ::= "nn...n" where n ::= {0 1 X} <string ::= "0xnn...n" where n ::= {0,...,9 A,...,F X}
:SBUS<n>:CXPI:TRIGger :PATTERN:DATA:LENGth <length> (see page 1042)	:SBUS<n>:CXPI:TRIGger :PATTERN:DATA:LENGth? (see page 1042)	<start> ::= integer between 0 and 12, in NR1 format.
:SBUS<n>:CXPI:TRIGger :PATTERN:DATA:START <start> (see page 1043)	:SBUS<n>:CXPI:TRIGger :PATTERN:DATA:START? (see page 1043)	<start> ::= integer between 0 and 124, in NR1 format.
:SBUS<n>:CXPI:TRIGger :PATTERN:ID <string> (see page 1044)	:SBUS<n>:CXPI:TRIGger :PATTERN:ID? (see page 1044)	<string> ::= "nn...n" where n ::= {0 1 X} <string ::= "0xnn...n" where n ::= {0,...,9 A,...,F X}
:SBUS<n>:CXPI:TRIGger :PATTERN:INFO:CT <string> (see page 1045)	:SBUS<n>:CXPI:TRIGger :PATTERN:INFO:CT? (see page 1045)	<string> ::= "nn" where n ::= {0 1 X}
:SBUS<n>:CXPI:TRIGger :PATTERN:INFO:DLC <dlc> (see page 1046)	:SBUS<n>:CXPI:TRIGger :PATTERN:INFO:DLC? (see page 1046)	<dlc> ::= integer between -1 (don't care) and 15, in NR1 format, when trigger is in DATA mode. <dlc> ::= integer between -1 (don't care) and 255, in NR1 format, when trigger is in LDATA mode.
:SBUS<n>:CXPI:TRIGger :PATTERN:INFO:NM <string> (see page 1047)	:SBUS<n>:CXPI:TRIGger :PATTERN:INFO:NM? (see page 1047)	<string> ::= "nn" where n ::= {0 1 X}

Table 36 :SBUS<n>:FLEXray Commands Summary

Command	Query	Options and Query Returns
:SBUS<n>:FLEXray:AUTO setup (see page 1050)	n/a	n/a
:SBUS<n>:FLEXray:BAUD rate <baudrate> (see page 1051)	:SBUS<n>:FLEXray:BAUD rate? (see page 1051)	<baudrate> ::= {2500000 5000000 10000000}
:SBUS<n>:FLEXray:CHAN nel <channel> (see page 1052)	:SBUS<n>:FLEXray:CHAN nel? (see page 1052)	<channel> ::= {A B}
n/a	:SBUS<n>:FLEXray:COUN t:NULL? (see page 1053)	<frame_count> ::= integer in NR1 format
:SBUS<n>:FLEXray:COUN t:RESet (see page 1054)	n/a	n/a
n/a	:SBUS<n>:FLEXray:COUN t:SYNC? (see page 1055)	<frame_count> ::= integer in NR1 format
n/a	:SBUS<n>:FLEXray:COUN t:TOTal? (see page 1056)	<frame_count> ::= integer in NR1 format
:SBUS<n>:FLEXray:SOUR ce <source> (see page 1057)	:SBUS<n>:FLEXray:SOUR ce? (see page 1057)	<source> ::= {CHANnel<n>} <n> ::= 1-2 or 1-4 in NR1 format
:SBUS<n>:FLEXray:TRIG ger <condition> (see page 1058)	:SBUS<n>:FLEXray:TRIG ger? (see page 1058)	<condition> ::= {FRAME ERRor EVENT}
:SBUS<n>:FLEXray:TRIG ger:ERRor:TYPE <error_type> (see page 1059)	:SBUS<n>:FLEXray:TRIG ger:ERRor:TYPE? (see page 1059)	<error_type> ::= {ALL HCRC FCRC}
:SBUS<n>:FLEXray:TRIG ger:EVENT:AUTOset (see page 1060)	n/a	n/a
:SBUS<n>:FLEXray:TRIG ger:EVENT:BSS:ID <frame_id> (see page 1061)	:SBUS<n>:FLEXray:TRIG ger:EVENT:BSS:ID? (see page 1061)	<frame_id> ::= {ALL <frame #>} <frame #> ::= integer from 1-2047
:SBUS<n>:FLEXray:TRIG ger:EVENT:TYPE <event> (see page 1062)	:SBUS<n>:FLEXray:TRIG ger:EVENT:TYPE? (see page 1062)	<event> ::= {WAKEup TSS {FES DTS} BSS}

Table 36 :SBUS<n>:FLEXray Commands Summary (continued)

Command	Query	Options and Query Returns
:SBUS<n>:FLEXray:TRIGGER:FRAME:CCBase <cycle_count_base> (see page 1063)	:SBUS<n>:FLEXray:TRIGGER:FRAME:CCBase? (see page 1063)	<cycle_count_base> ::= integer from 0-63
:SBUS<n>:FLEXray:TRIGGER:FRAME:CCRepetition <cycle_count_repetition> (see page 1064)	:SBUS<n>:FLEXray:TRIGGER:FRAME:CCRepetition? (see page 1064)	<cycle_count_repetition> ::= {ALL <rep #>} <rep #> ::= integer values 2, 4, 8, 16, 32, or 64
:SBUS<n>:FLEXray:TRIGGER:FRAME:ID <frame_id> (see page 1065)	:SBUS<n>:FLEXray:TRIGGER:FRAME:ID? (see page 1065)	<frame_id> ::= {ALL <frame #>} <frame #> ::= integer from 1-2047
:SBUS<n>:FLEXray:TRIGGER:FRAME:TYPE <frame_type> (see page 1066)	:SBUS<n>:FLEXray:TRIGGER:FRAME:TYPE? (see page 1066)	<frame_type> ::= {NORMAL STARTup NULL SYNC NSTartup NNULL NSYNc ALL}

Table 37 :SBUS<n>:I2S Commands Summary

Command	Query	Options and Query Returns
:SBUS<n>:I2S:ALIGNment <setting> (see page 1070)	:SBUS<n>:I2S:ALIGNment? (see page 1070)	<setting> ::= {I2S LJ RJ}
:SBUS<n>:I2S:BASE <base> (see page 1071)	:SBUS<n>:I2S:BASE? (see page 1071)	<base> ::= {DECimal HEX}
:SBUS<n>:I2S:CLOCK:SLOPe <slope> (see page 1072)	:SBUS<n>:I2S:CLOCK:SLOPe? (see page 1072)	<slope> ::= {NEGative POSitive}
:SBUS<n>:I2S:RWIDth <receiver> (see page 1073)	:SBUS<n>:I2S:RWIDth? (see page 1073)	<receiver> ::= 4-32 in NR1 format
:SBUS<n>:I2S:SOURce:CLOCK <source> (see page 1074)	:SBUS<n>:I2S:SOURce:CLOCK? (see page 1074)	<source> ::= {CHANnel<n> EXTERNAL} for DSO models <source> ::= {CHANnel<n> DIGital<d>} for MSO models <n> ::= 1 to (# analog channels) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format

Table 37 :SBUS<n>:I2S Commands Summary (continued)

Command	Query	Options and Query Returns
:SBUS<n>:I2S:SOURce:D ATA <source> (see page 1075)	:SBUS<n>:I2S:SOURce:D ATA? (see page 1075)	<source> ::= {CHANnel<n> EXTernal} for DSO models <source> ::= {CHANnel<n> DIGital<d> } for MSO models <n> ::= 1 to (# analog channels) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format
:SBUS<n>:I2S:SOURce:W SElect <source> (see page 1076)	:SBUS<n>:I2S:SOURce:W SElect? (see page 1076)	<source> ::= {CHANnel<n> EXTernal} for DSO models <source> ::= {CHANnel<n> DIGital<d> } for MSO models <n> ::= 1 to (# analog channels) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format
:SBUS<n>:I2S:TRIGger <operator> (see page 1077)	:SBUS<n>:I2S:TRIGger? (see page 1077)	<operator> ::= {EQUal NOTequal LESSthan GREATERthan INRange OUTRange INCReasing DECReasing}
:SBUS<n>:I2S:TRIGger: AUDio <audio_ch> (see page 1079)	:SBUS<n>:I2S:TRIGger: AUDio? (see page 1079)	<audio_ch> ::= {RIGHT LEFT EITHer}
:SBUS<n>:I2S:TRIGger: PATtern:DATA <string> (see page 1080)	:SBUS<n>:I2S:TRIGger: PATtern:DATA? (see page 1081)	<string> ::= "n" where n ::= 32-bit integer in signed decimal when <base> = DECimal <string> ::= "nn...n" where n ::= {0 1 X \$} when <base> = BINary <string> ::= "0xnn...n" where n ::= {0,...,9 A,...,F X \$} when <base> = HEX
:SBUS<n>:I2S:TRIGger: PATtern:FORMat <base> (see page 1082)	:SBUS<n>:I2S:TRIGger: PATtern:FORMat? (see page 1082)	<base> ::= {BINary HEX DECimal}

Table 37 :SBUS<n>:I2S Commands Summary (continued)

Command	Query	Options and Query Returns
:SBUS<n>:I2S:TRIGger:RANGe <lower>, <upper> (see page 1083)	:SBUS<n>:I2S:TRIGger:RANGe? (see page 1083)	<p><lower> ::= 32-bit integer in signed decimal, <nondecimal>, or <string></p> <p><upper> ::= 32-bit integer in signed decimal, <nondecimal>, or <string></p> <p><nondecimal> ::= #Hnn...n where n ::= {0,...,9 A,...,F} for hexadecimal</p> <p><nondecimal> ::= #Bnn...n where n ::= {0 1} for binary</p> <p><string> ::= "0xnn...n" where n ::= {0,...,9 A,...,F} for hexadecimal</p>
:SBUS<n>:I2S:TWIDth <word_size> (see page 1084)	:SBUS<n>:I2S:TWIDth? (see page 1084)	<word_size> ::= 4-32 in NR1 format
:SBUS<n>:I2S:WSLow <low_def> (see page 1085)	:SBUS<n>:I2S:WSLow? (see page 1085)	<low_def> ::= {LEFT RIGHT}

Table 38 :SBUS<n>:IIC Commands Summary

Command	Query	Options and Query Returns
:SBUS<n>:IIC:ASIZe <size> (see page 1088)	:SBUS<n>:IIC:ASIZe? (see page 1088)	<size> ::= {BIT7 BIT8}
:SBUS<n>:IIC[:SOURce]:CLOCK <source> (see page 1089)	:SBUS<n>:IIC[:SOURce]:CLOCK? (see page 1089)	<p><source> ::= {CHANnel<n> EXTernal} for DSO models</p> <p><source> ::= {CHANnel<n> DIGital<d>} for MSO models</p> <p><n> ::= 1 to (# analog channels) in NR1 format</p> <p><d> ::= 0 to (# digital channels - 1) in NR1 format</p>

Table 38 :SBUS<n>:IIC Commands Summary (continued)

Command	Query	Options and Query Returns
:SBUS<n>:IIC[:SOURce] :DATA <source> (see page 1090)	:SBUS<n>:IIC[:SOURce] :DATA? (see page 1090)	<source> ::= {CHANnel<n> EXTernal} for DSO models <source> ::= {CHANnel<n> DIGital<d> } for MSO models <n> ::= 1 to (# analog channels) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format
:SBUS<n>:IIC:TRIGger: PATtern:ADDRess <value> (see page 1091)	:SBUS<n>:IIC:TRIGger: PATtern:ADDRess? (see page 1091)	<value> ::= integer or <string> <string> ::= "0xnn" n ::= {0,...,9 A,...,F}
:SBUS<n>:IIC:TRIGger: PATtern:DATA <value> (see page 1092)	:SBUS<n>:IIC:TRIGger: PATtern:DATA? (see page 1092)	<value> ::= integer or <string> <string> ::= "0xnn" n ::= {0,...,9 A,...,F}
:SBUS<n>:IIC:TRIGger: PATtern:DATA2 <value> (see page 1093)	:SBUS<n>:IIC:TRIGger: PATtern:DATA2? (see page 1093)	<value> ::= integer or <string> <string> ::= "0xnn" n ::= {0,...,9 A,...,F}
:SBUS<n>:IIC:TRIGger: QUALifier <value> (see page 1094)	:SBUS<n>:IIC:TRIGger: QUALifier? (see page 1094)	<value> ::= {EQUAL NOTequal LESSthan GREATERthan}
:SBUS<n>:IIC:TRIGger[:TYPE] <type> (see page 1095)	:SBUS<n>:IIC:TRIGger[:TYPE]? (see page 1095)	<type> ::= {START STOP REStart ADDRess ANACK DNACK NACKnowledge READEprom READ7 WRITe7 R7Data2 W7Data2 WRITe10}

Table 39 :SBUS<n>:LIN Commands Summary

Command	Query	Options and Query Returns
:SBUS<n>:LIN:DISPlay <type> (see page 1099)	:SBUS<n>:LIN:DISPlay? (see page 1099)	<type> ::= {HEXadecimal SYMBOLic}
:SBUS<n>:LIN:PARity {{0 OFF} {1 ON}} (see page 1100)	:SBUS<n>:LIN:PARity? (see page 1100)	{0 1}
:SBUS<n>:LIN:SAMplepo int <value> (see page 1101)	:SBUS<n>:LIN:SAMplepo int? (see page 1101)	<value> ::= {60 62.5 68 70 75 80 87.5} in NR3 format

Table 39 :SBUS<n>:LIN Commands Summary (continued)

Command	Query	Options and Query Returns
:SBUS<n>:LIN:SIGNal:BAUDrate <baudrate> (see page 1102)	:SBUS<n>:LIN:SIGNal:BAUDrate? (see page 1102)	<baudrate> ::= integer from 2400 to 625000 in 100 b/s increments
:SBUS<n>:LIN:SOURce <source> (see page 1103)	:SBUS<n>:LIN:SOURce? (see page 1103)	<source> ::= {CHANnel<n> EXTErnal} for DSO models <source> ::= {CHANnel<n> DIGital<d>} for MSO models <n> ::= 1 to (# analog channels) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format
:SBUS<n>:LIN:STANdard <std> (see page 1104)	:SBUS<n>:LIN:STANdard? (see page 1104)	<std> ::= {LIN13 LIN13NLC LIN20}
:SBUS<n>:LIN:SYNCbreaK <value> (see page 1105)	:SBUS<n>:LIN:SYNCbreaK? (see page 1105)	<value> ::= integer = {11 12 13}
:SBUS<n>:LIN:TRIGger <condition> (see page 1106)	:SBUS<n>:LIN:TRIGger? (see page 1106)	<condition> ::= {SYNCbreak ID DATA}
:SBUS<n>:LIN:TRIGger:ID <value> (see page 1108)	:SBUS<n>:LIN:TRIGger:ID? (see page 1108)	<value> ::= 7-bit integer in decimal, <nondecimal>, or <string> from 0-63 or 0x00-0x3f <nondecimal> ::= #Hnn where n ::= {0,...,9 A,...,F} for hexadecimal <nondecimal> ::= #Bnn...n where n ::= {0 1} for binary <string> ::= "0xnn" where n ::= {0,...,9 A,...,F} for hexadecimal
:SBUS<n>:LIN:TRIGger:PATtern:DATA <string> (see page 1109)	:SBUS<n>:LIN:TRIGger:PATtern:DATA? (see page 1109)	<string> ::= "n" where n ::= 32-bit integer in unsigned decimal when <base> = DECimal <string> ::= "nn...n" where n ::= {0 1 X \$} when <base> = BINary <string> ::= "0xnn...n" where n ::= {0,...,9 A,...,F X \$} when <base> = HEX
:SBUS<n>:LIN:TRIGger:PATtern:DATA:LENGth <length> (see page 1111)	:SBUS<n>:LIN:TRIGger:PATtern:DATA:LENGth? (see page 1111)	<length> ::= integer from 1 to 8 in NR1 format

Table 39 :SBUS<n>:LIN Commands Summary (continued)

Command	Query	Options and Query Returns
:SBUS<n>:LIN:TRIGger:PATtern:FORMat <base> (see page 1112)	:SBUS<n>:LIN:TRIGger:PATtern:FORMat? (see page 1112)	<base> ::= {BINary HEX DECimal}
:SBUS<n>:LIN:TRIGger:SYMBolic:FRAMe <name> (see page 1113)	:SBUS<n>:LIN:TRIGger:SYMBolic:FRAMe? (see page 1113)	<name> ::= quoted ASCII string
:SBUS<n>:LIN:TRIGger:SYMBolic:SIGNal <name> (see page 1114)	:SBUS<n>:LIN:TRIGger:SYMBolic:SIGNal? (see page 1114)	<name> ::= quoted ASCII string
:SBUS<n>:LIN:TRIGger:SYMBolic:VALue <data> (see page 1115)	:SBUS<n>:LIN:TRIGger:SYMBolic:VALue? (see page 1115)	<data> ::= value in NR3 format

Table 40 :SBUS<n>:M1553 Commands Summary

Command	Query	Options and Query Returns
:SBUS<n>:M1553:AUTose tup (see page 1117)	n/a	n/a
:SBUS<n>:M1553:BASE <base> (see page 1118)	:SBUS<n>:M1553:BASE? (see page 1118)	<base> ::= {BINary HEX}
:SBUS<n>:M1553:SOURce <source> (see page 1119)	:SBUS<n>:M1553:SOURce ? (see page 1119)	<source> ::= {CHANnel<n>} <n> ::= 1 to (# analog channels) in NR1 format
:SBUS<n>:M1553:TRIGger:PATtern:DATA <string> (see page 1120)	:SBUS<n>:M1553:TRIGger:PATtern:DATA? (see page 1120)	<string> ::= "nn...n" where n ::= {0 1 X}
:SBUS<n>:M1553:TRIGger:RTA <value> (see page 1121)	:SBUS<n>:M1553:TRIGger:RTA? (see page 1121)	<value> ::= 5-bit integer in decimal, <nondecimal>, or <string> from 0-31 <nondecimal> ::= #Hnn where n ::= {0,...,9 A,...,F} <string> ::= "0xnn" where n ::= {0,...,9 A,...,F}
:SBUS<n>:M1553:TRIGger:TYPE <type> (see page 1122)	:SBUS<n>:M1553:TRIGger:TYPE? (see page 1122)	<type> ::= {DStArt DStOp CStArt CStOp RTA PERRor SERRor MERRor RTA11}

Table 41 :SBUS<n>:MANchester Commands Summary

Command	Query	Options and Query Returns
:SBUS<n>:MANchester:BASE <base> (see page 1125)	:SBUS<n>:MANchester:BASE? (see page 1125)	<base> ::= {HEX DECimal ASCii}
:SBUS<n>:MANchester:BAUDrate <baudrate> (see page 1126)	:SBUS<n>:MANchester:BAUDrate? (see page 1126)	<baudrate> ::= integer from 500 to 5000000 in 100 b/s increments
:SBUS<n>:MANchester:BITorder <bitorder> (see page 1127)	:SBUS<n>:MANchester:BITorder? (see page 1127)	<bitorder> ::= {MSBFirst LSBFirst}
:SBUS<n>:MANchester:DISPlay <format> (see page 1128)	:SBUS<n>:MANchester:DISPlay? (see page 1128)	<format> ::= {BIT WORD}
:SBUS<n>:MANchester:DISize {AUTO <#words>} (see page 1129)	:SBUS<n>:MANchester:DISize? (see page 1129)	<#words> ::= from 1-255, in NR1 format
:SBUS<n>:MANchester:HSize <#bits> (see page 1130)	:SBUS<n>:MANchester:HSize? (see page 1130)	<#bits> ::= from 0-32, in NR1 format
:SBUS<n>:MANchester:IDLE:BITS <#bits> (see page 1131)	:SBUS<n>:MANchester:IDLE:BITS? (see page 1131)	<#bits> ::= minimum idle time in terms of bit width, from 1.50 to 32.0, in NR3 format.
:SBUS<n>:MANchester:LOGic <logic> (see page 1132)	:SBUS<n>:MANchester:LOGic? (see page 1132)	<logic> ::= {FALLing RISing}
:SBUS<n>:MANchester:SOURce <source> (see page 1133)	:SBUS<n>:MANchester:SOURce? (see page 1133)	<source> ::= {CHANnel<n> DIGital<d>}
:SBUS<n>:MANchester:SSize <#bits> (see page 1134)	:SBUS<n>:MANchester:SSize? (see page 1134)	<#bits> ::= from 0-255, in NR1 format
:SBUS<n>:MANchester:START <edge#> (see page 1135)	:SBUS<n>:MANchester:START? (see page 1135)	<edge#> ::= from 1-256, in NR1 format
:SBUS<n>:MANchester:TOLerance <percent> (see page 1136)	:SBUS<n>:MANchester:TOLerance? (see page 1136)	<percent> ::= from 1-30, in NR1 format
:SBUS<n>:MANchester:TRIGger <mode> (see page 1137)	:SBUS<n>:MANchester:TRIGger? (see page 1137)	<mode> ::= {SOF VALue MERRor}

Table 41 :SBUS<n>:MANChester Commands Summary (continued)

Command	Query	Options and Query Returns
:SBUS<n>:MANChester:TRIGger:PATtern:VALue:DATA <string> (see page 1138)	:SBUS<n>:MANChester:TRIGger:PATtern:VALue:DATA? (see page 1138)	<string> ::= "nn...n" where n ::= {0 1 X \$} <string ::= "0xnn...n" where n ::= {0,...,9 A,...,F X \$}
:SBUS<n>:MANChester:TRIGger:PATtern:VALue:WIDTh <width> (see page 1139)	:SBUS<n>:MANChester:TRIGger:PATtern:VALue:WIDTh? (see page 1139)	<width> ::= integer from 4 to 128 in NR1 format
:SBUS<n>:MANChester:TRIGger:PATtern:VALue:SIZE <#bits> (see page 1140)	:SBUS<n>:MANChester:TRIGger:PATtern:VALue:SIZE? (see page 1140)	<#bits> ::= from 0-32, in NR1 format
:SBUS<n>:MANChester:WIDTh:SIZE <#bits> (see page 1141)	:SBUS<n>:MANChester:WIDTh:SIZE? (see page 1141)	<#bits> ::= from 2-32, in NR1 format

Table 42 :SBUS<n>:NRZ Commands Summary

Command	Query	Options and Query Returns
:SBUS<n>:NRZ:BASE <base> (see page 1144)	:SBUS<n>:NRZ:BASE? (see page 1144)	<base> ::= {HEX DECimal ASCii}
:SBUS<n>:NRZ:BAUDrate <baudrate> (see page 1145)	:SBUS<n>:NRZ:BAUDrate? (see page 1145)	<baudrate> ::= integer from 5000 to 5000000 in 100 b/s increments
:SBUS<n>:NRZ:BITorder <bitorder> (see page 1146)	:SBUS<n>:NRZ:BITorder? (see page 1146)	<bitorder> ::= {MSBFirst LSBFirst}
:SBUS<n>:NRZ:DISPlay <format> (see page 1147)	:SBUS<n>:NRZ:DISPlay? (see page 1147)	<format> ::= {BIT WORD}
:SBUS<n>:NRZ:DSIZE <#words> (see page 1148)	:SBUS<n>:NRZ:DSIZE? (see page 1148)	<#words> ::= from 1-255, in NR1 format
:SBUS<n>:NRZ:FSIZE <#bits> (see page 1149)	:SBUS<n>:NRZ:FSIZE? (see page 1149)	<#bits> ::= from 2-255, in NR1 format
:SBUS<n>:NRZ:HSIZE <#bits> (see page 1150)	:SBUS<n>:NRZ:HSIZE? (see page 1150)	<#bits> ::= from 0-32, in NR1 format

Table 42 :SBUS<n>:NRZ Commands Summary (continued)

Command	Query	Options and Query Returns
:SBUS<n>:NRZ:IDLE:BIT S <#bits> (see page 1151)	:SBUS<n>:NRZ:IDLE:BIT S? (see page 1151)	<#bits> ::= minimum idle time in terms of bit width, from 1.50 to 32.0, in NR3 format.
:SBUS<n>:NRZ:IDLE:STATE <state> (see page 1152)	:SBUS<n>:NRZ:IDLE:STATE? (see page 1152)	<state> ::= {LOW HIGH}
:SBUS<n>:NRZ:LOGIC <logic> (see page 1153)	:SBUS<n>:NRZ:LOGIC? (see page 1153)	<logic> ::= {HIGH LOW}
:SBUS<n>:NRZ:SOURCE <source> (see page 1154)	:SBUS<n>:NRZ:SOURCE? (see page 1154)	<source> ::= {CHANNEL<n> DIGITAL<d>}
:SBUS<n>:NRZ:START <#bits> (see page 1155)	:SBUS<n>:NRZ:START? (see page 1155)	<#bits> ::= from 0-255, in NR1 format
:SBUS<n>:NRZ:TRIGGER <mode> (see page 1156)	:SBUS<n>:NRZ:TRIGGER? (see page 1156)	<mode> ::= {SOF VALUE}
:SBUS<n>:NRZ:TRIGGER:PATTERN:VALUE:DATA <string> (see page 1157)	:SBUS<n>:NRZ:TRIGGER:PATTERN:VALUE:DATA? (see page 1157)	<string> ::= "nn...n" where n ::= {0 1 X \$} <string> ::= "0xnn...n" where n ::= {0,...,9 A,...,F X \$}
:SBUS<n>:NRZ:TRIGGER:PATTERN:VALUE:WIDTH <width> (see page 1158)	:SBUS<n>:NRZ:TRIGGER:PATTERN:VALUE:WIDTH? (see page 1158)	<width> ::= integer from 4 to 128 in NR1 format
:SBUS<n>:NRZ:TFSIZE <#bits> (see page 1159)	:SBUS<n>:NRZ:TFSIZE? (see page 1159)	<#bits> ::= from 0-32, in NR1 format
:SBUS<n>:NRZ:WSIZE <#bits> (see page 1160)	:SBUS<n>:NRZ:WSIZE? (see page 1160)	<#bits> ::= from 2-32, in NR1 format

Table 43 :SBUS<n>:SENT Commands Summary

Command	Query	Options and Query Returns
:SBUS<n>:SENT:CLOCK <period> (see page 1164)	:SBUS<n>:SENT:CLOCK? (see page 1164)	<period> ::= the nominal clock period (tick), from 500 ns to 300 us, in NR3 format.
:SBUS<n>:SENT:CRC <format> (see page 1165)	:SBUS<n>:SENT:CRC? (see page 1165)	<format> ::= {LEGacy RECommended}
:SBUS<n>:SENT:DISPlay <base> (see page 1166)	:SBUS<n>:SENT:DISPlay ? (see page 1166)	<base> ::= {HEX DECimal SYMBolic}
:SBUS<n>:SENT:FORMat <decode> (see page 1168)	:SBUS<n>:SENT:FORMat? (see page 1168)	<decode> ::= {NIBBles FSIGnal FSSerial FESerial SSERial ESERial}
:SBUS<n>:SENT:IDLE <state> (see page 1170)	:SBUS<n>:SENT:IDLE? (see page 1170)	<state> ::= {LOW HIGH}
:SBUS<n>:SENT:LENGth <#_nibbles> (see page 1171)	:SBUS<n>:SENT:LENGth? (see page 1171)	<#_nibbles> ::= from 1-6, in NR1 format.
:SBUS<n>:SENT:PPULse { {0 OFF} {1 ON} SPC} (see page 1172)	:SBUS<n>:SENT:PPULse? (see page 1172)	{0 1 SPC}
:SBUS<n>:SENT:SIGnal< s>:DISPlay { {0 OFF} {1 ON} } (see page 1174)	:SBUS<n>:SENT:SIGnal< s>:DISPlay? (see page 1174)	<s> ::= 1-6, in NR1 format. {0 1}
:SBUS<n>:SENT:SIGnal< s>:LENGth <length> (see page 1175)	:SBUS<n>:SENT:SIGnal< s>:LENGth? (see page 1175)	<s> ::= 1-6, in NR1 format. <length> ::= from 1-24, in NR1 format.
:SBUS<n>:SENT:SIGnal< s>:MULTiplier <multiplier> (see page 1177)	:SBUS<n>:SENT:SIGnal< s>:MULTiplier? (see page 1177)	<s> ::= 1-6, in NR1 format. <multiplier> ::= from 1-24, in NR3 format.
:SBUS<n>:SENT:SIGnal< s>:OFFSet <offset> (see page 1179)	:SBUS<n>:SENT:SIGnal< s>:OFFSet? (see page 1179)	<s> ::= 1-6, in NR1 format. <offset> ::= from 1-24, in NR3 format.
:SBUS<n>:SENT:SIGnal< s>:ORDer <order> (see page 1181)	:SBUS<n>:SENT:SIGnal< s>:ORDer? (see page 1181)	<s> ::= 1-6, in NR1 format. <order> ::= {MSNFirst LSNFirst}
:SBUS<n>:SENT:SIGnal< s>:START <position> (see page 1183)	:SBUS<n>:SENT:SIGnal< s>:START? (see page 1183)	<s> ::= 1-6, in NR1 format. <position> ::= from 0-23, in NR1 format.

Table 43 :SBUS<n>:SENT Commands Summary (continued)

Command	Query	Options and Query Returns
:SBUS<n>:SENT:SOURce <source> (see page 1185)	:SBUS<n>:SENT:SOURce? (see page 1185)	<source> ::= {CHANnel<n> DIGital<d>} <n> ::= 1 to (# analog channels) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format
:SBUS<n>:SENT:TOLeran ce <percent> (see page 1187)	:SBUS<n>:SENT:TOLeran ce? (see page 1187)	<percent> ::= from 3-30, in NR1 format.
:SBUS<n>:SENT:TRIGger <mode> (see page 1188)	:SBUS<n>:SENT:TRIGger ? (see page 1188)	<mode> ::= {SFCMessage SSCMessage FCData SCMid SCData FCCerror SCCerror CRCerror TOLerror PPErrror SSPErrror}
:SBUS<n>:SENT:TRIGger :FAST:DATA <string> (see page 1190)	:SBUS<n>:SENT:TRIGger :FAST:DATA? (see page 1190)	<string> ::= "nnnn..." where n ::= {0 1 X} <string> ::= "0xn..." where n ::= {0,...,9 A,...,F X \$}
:SBUS<n>:SENT:TRIGger :SLOW:DATA <data> (see page 1191)	:SBUS<n>:SENT:TRIGger :SLOW:DATA? (see page 1191)	<data> ::= when ILENgth = SHORT, from -1 (don't care) to 65535, in NR1 format. <data> ::= when ILENgth = LONG, from -1 (don't care) to 4095, in NR1 format.
:SBUS<n>:SENT:TRIGger :SLOW:ID <id> (see page 1193)	:SBUS<n>:SENT:TRIGger :SLOW:ID? (see page 1193)	<id> ::= when ILENgth = SHORT, from -1 (don't care) to 15, in NR1 format. <id> ::= when ILENgth = LONG, from -1 (don't care) to 255, in NR1 format.
:SBUS<n>:SENT:TRIGger :SLOW:ILENgth <length> (see page 1195)	:SBUS<n>:SENT:TRIGger :SLOW:ILENgth? (see page 1195)	<length> ::= {SHORT LONG}
:SBUS<n>:SENT:TRIGger :TOLerance <percent> (see page 1196)	:SBUS<n>:SENT:TRIGger :TOLerance? (see page 1196)	<percent> ::= from 1-18, in NR1 format.

Table 44 :SBUS<n>:SPI Commands Summary

Command	Query	Options and Query Returns
:SBUS<n>:SPI:BITOrder <order> (see page 1199)	:SBUS<n>:SPI:BITOrder ? (see page 1199)	<order> ::= {LSBFirst MSBFirst}
:SBUS<n>:SPI:CLOCK:SL OPe <slope> (see page 1200)	:SBUS<n>:SPI:CLOCK:SL OPe? (see page 1200)	<slope> ::= {NEGative POSitive}
:SBUS<n>:SPI:CLOCK:TI Meout <time_value> (see page 1201)	:SBUS<n>:SPI:CLOCK:TI Meout? (see page 1201)	<time_value> ::= time in seconds in NR3 format
:SBUS<n>:SPI:DElay <value> (see page 1202)	:SBUS<n>:SPI:DElay? (see page 1202)	<value> ::= {OFF 2-63}
:SBUS<n>:SPI:FRAMing <value> (see page 1203)	:SBUS<n>:SPI:FRAMing? (see page 1203)	<value> ::= {CHIPselect {NCHipselect NOTC} TIMEout}
:SBUS<n>:SPI:SOURce:C LOCK <source> (see page 1204)	:SBUS<n>:SPI:SOURce:C LOCK? (see page 1204)	<value> ::= {CHANnel<n> EXTernal} for the DSO models <value> ::= {CHANnel<n> DIGital<d>} for the MSO models <n> ::= 1 to (# analog channels) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format
:SBUS<n>:SPI:SOURce:F RAME <source> (see page 1205)	:SBUS<n>:SPI:SOURce:F RAME? (see page 1205)	<value> ::= {CHANnel<n> EXTernal} for the DSO models <value> ::= {CHANnel<n> DIGital<d>} for the MSO models <n> ::= 1 to (# analog channels) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format
:SBUS<n>:SPI:SOURce:M ISO <source> (see page 1206)	:SBUS<n>:SPI:SOURce:M ISO? (see page 1206)	<value> ::= {CHANnel<n> EXTernal} for the DSO models <value> ::= {CHANnel<n> DIGital<d>} for the MSO models <n> ::= 1 to (# analog channels) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format

Table 44 :SBUS<n>:SPI Commands Summary (continued)

Command	Query	Options and Query Returns
:SBUS<n>:SPI:SOURce:MOSI <source> (see page 1207)	:SBUS<n>:SPI:SOURce:MOSI? (see page 1207)	<value> ::= {CHANnel<n> EXTernal} for the DSO models <value> ::= {CHANnel<n> DIGital<d>} for the MSO models <n> ::= 1 to (# analog channels) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format
:SBUS<n>:SPI:TRIGger:PATtern:MISO:DATA <string> (see page 1208)	:SBUS<n>:SPI:TRIGger:PATtern:MISO:DATA? (see page 1208)	<string> ::= "nn...n" where n ::= {0 1 X \$} <string> ::= "0xnn...n" where n ::= {0,...,9 A,...,F X \$}
:SBUS<n>:SPI:TRIGger:PATtern:MISO:WIDTh <width> (see page 1209)	:SBUS<n>:SPI:TRIGger:PATtern:MISO:WIDTh? (see page 1209)	<width> ::= integer from 4 to 64 in NR1 format
:SBUS<n>:SPI:TRIGger:PATtern:MOSI:DATA <string> (see page 1210)	:SBUS<n>:SPI:TRIGger:PATtern:MOSI:DATA? (see page 1210)	<string> ::= "nn...n" where n ::= {0 1 X \$} <string> ::= "0xnn...n" where n ::= {0,...,9 A,...,F X \$}
:SBUS<n>:SPI:TRIGger:PATtern:MOSI:WIDTh <width> (see page 1211)	:SBUS<n>:SPI:TRIGger:PATtern:MOSI:WIDTh? (see page 1211)	<width> ::= integer from 4 to 64 in NR1 format
:SBUS<n>:SPI:TRIGger:TYPE <value> (see page 1212)	:SBUS<n>:SPI:TRIGger:TYPE? (see page 1212)	<value> ::= {MOSI MISO}
:SBUS<n>:SPI:WIDTh <word_width> (see page 1213)	:SBUS<n>:SPI:WIDTh? (see page 1213)	<word_width> ::= integer 4-16 in NR1 format

Table 45 :SBUS<n>:UART Commands Summary

Command	Query	Options and Query Returns
:SBUS<n>:UART:BASE <base> (see page 1217)	:SBUS<n>:UART:BASE? (see page 1217)	<base> ::= {ASCii BINary HEX}
:SBUS<n>:UART:BAUDrate <baudrate> (see page 1218)	:SBUS<n>:UART:BAUDrate? (see page 1218)	<baudrate> ::= integer from 100 to 8000000, 10000000, or 12000000

Table 45 :SBUS<n>:UART Commands Summary (continued)

Command	Query	Options and Query Returns
:SBUS<n>:UART:BITOrder <bitorder> (see page 1219)	:SBUS<n>:UART:BITOrder? (see page 1219)	<bitorder> ::= {LSBFirst MSBFirst}
n/a	:SBUS<n>:UART:COUNT:ERRor? (see page 1220)	<frame_count> ::= integer in NR1 format
:SBUS<n>:UART:COUNT:RESEt (see page 1221)	n/a	n/a
n/a	:SBUS<n>:UART:COUNT:RXFRames? (see page 1222)	<frame_count> ::= integer in NR1 format
n/a	:SBUS<n>:UART:COUNT:TXFRames? (see page 1223)	<frame_count> ::= integer in NR1 format
:SBUS<n>:UART:FRAMing <value> (see page 1224)	:SBUS<n>:UART:FRAMing? (see page 1224)	<value> ::= {OFF <decimal> <nondecimal>} <decimal> ::= 8-bit integer from 0-255 (0x00-0xff) <nondecimal> ::= #Hnn where n ::= {0,...,9 A,...,F} for hexadecimal <nondecimal> ::= #Bnn...n where n ::= {0 1} for binary
:SBUS<n>:UART:PARity <parity> (see page 1225)	:SBUS<n>:UART:PARity? (see page 1225)	<parity> ::= {EVEN ODD NONE}
:SBUS<n>:UART:POLarity <polarity> (see page 1226)	:SBUS<n>:UART:POLarity? (see page 1226)	<polarity> ::= {HIGH LOW}
:SBUS<n>:UART:SOURce:RX <source> (see page 1227)	:SBUS<n>:UART:SOURce:RX? (see page 1227)	<source> ::= {CHANnel<n> EXTernal} for DSO models <source> ::= {CHANnel<n> DIGital<d>} for MSO models <n> ::= 1 to (# analog channels) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format

Table 45 :SBUS<n>:UART Commands Summary (continued)

Command	Query	Options and Query Returns
:SBUS<n>:UART:SOURce:TX <source> (see page 1228)	:SBUS<n>:UART:SOURce:TX? (see page 1228)	<source> ::= {CHANnel<n> EXTernal} for DSO models <source> ::= {CHANnel<n> DIGital<d>} for MSO models <n> ::= 1 to (# analog channels) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format
:SBUS<n>:UART:TRIGger:BASE <base> (see page 1229)	:SBUS<n>:UART:TRIGger:BASE? (see page 1229)	<base> ::= {ASCii HEX}
:SBUS<n>:UART:TRIGger:BURSt <value> (see page 1230)	:SBUS<n>:UART:TRIGger:BURSt? (see page 1230)	<value> ::= {OFF 1 to 4096 in NR1 format}
:SBUS<n>:UART:TRIGger:DATA <value> (see page 1231)	:SBUS<n>:UART:TRIGger:DATA? (see page 1231)	<value> ::= 8-bit integer from 0-255 (0x00-0xff) in decimal, <hexadecimal>, <binary>, or <quoted_string> format <hexadecimal> ::= #Hnn where n ::= {0,...,9 A,...,F} for hexadecimal <binary> ::= #Bnn...n where n ::= {0 1} for binary <quoted_string> ::= any of the 128 valid 7-bit ASCII characters (or standard abbreviations)
:SBUS<n>:UART:TRIGger:IDLE <time_value> (see page 1232)	:SBUS<n>:UART:TRIGger:IDLE? (see page 1232)	<time_value> ::= time from 1 us to 10 s in NR3 format
:SBUS<n>:UART:TRIGger:QUALifier <value> (see page 1233)	:SBUS<n>:UART:TRIGger:QUALifier? (see page 1233)	<value> ::= {EQUal NOTequal GREATERthan LESSthan}
:SBUS<n>:UART:TRIGger:TYPE <value> (see page 1234)	:SBUS<n>:UART:TRIGger:TYPE? (see page 1234)	<value> ::= {RSTArt RSTOp RDATA RD1 RD0 RDX PARityerror TSTArt TSTOp TDATA TD1 TD0 TDx}
:SBUS<n>:UART:WIDTh <width> (see page 1235)	:SBUS<n>:UART:WIDTh? (see page 1235)	<width> ::= {5 6 7 8 9}

Table 46 :SBUS<n>:USB Commands Summary

Command	Query	Options and Query Returns
:SBUS<n>:USB:BASE <base> (see page 1239)	:SBUS<n>:USB:BASE? (see page 1239)	<base> ::= {ASCii BINary DECimal HEX}
:SBUS<n>:USB:SOURce:D MINus <source> (see page 1240)	:SBUS<n>:USB:SOURce:D MINus? (see page 1240)	<source> ::= {CHANnel<n>} for DSO models <source> ::= {CHANnel<n> DIGital<d>} for MSO models <n> ::= 1 to (# analog channels) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format
:SBUS<n>:USB:SOURce:D PLus <source> (see page 1241)	:SBUS<n>:USB:SOURce:D PLus? (see page 1241)	<source> ::= {CHANnel<n>} for DSO models <source> ::= {CHANnel<n> DIGital<d>} for MSO models <n> ::= 1 to (# analog channels) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format
:SBUS<n>:USB:SOURce:D IFFerential <source> (see page 1242)	:SBUS<n>:USB:SOURce:D IFFerential? (see page 1242)	<source> ::= {CHANnel<n>} <n> ::= 1 to (# analog channels) in NR1 format
:SBUS<n>:USB:SPEEd <speed> (see page 1243)	:SBUS<n>:USB:SPEEd? (see page 1243)	<speed> ::= {LOW FULL HIGH}
:SBUS<n>:USB:TRIGger <condition> (see page 1244)	:SBUS<n>:USB:TRIGger? (see page 1244)	<condition> ::= {SOP EOP ENTersuspend EXITsuspend RESet TOKen DATA HANDshake SPECial ALLerrors PIDerror CRC5error CRC16error GLITCherror STUFFerror SE1error}
:SBUS<n>:USB:TRIGger: ADDress <string> (see page 1245)	:SBUS<n>:USB:TRIGger: ADDress? (see page 1245)	<string> ::= "nnnnnnn" where n ::= {0 1 X} <string> ::= "0xnn" where n ::= {0,...,9 A,...,F X \$}
:SBUS<n>:USB:TRIGger: CRC <string> (see page 1246)	:SBUS<n>:USB:TRIGger: CRC? (see page 1246)	<string> ::= "nnnnn" where n ::= {0 1 X} <string> ::= "0xnn" where n ::= {0,...,9 A,...,F X \$}

Table 46 :SBUS<n>:USB Commands Summary (continued)

Command	Query	Options and Query Returns
:SBUS<n>:USB:TRIGger:DATA <string> (see page 1247)	:SBUS<n>:USB:TRIGger:DATA? (see page 1247)	<string> ::= "nnnn..." where n ::= {0 1 X} <string> ::= "0xn..." where n ::= {0,...,9 A,...,F X \$}
:SBUS<n>:USB:TRIGger:DATA:LENGth <value> (see page 1248)	:SBUS<n>:USB:TRIGger:DATA:LENGth? (see page 1248)	<length> ::= data length between 1-20
:SBUS<n>:USB:TRIGger:ENDPoint <string> (see page 1249)	:SBUS<n>:USB:TRIGger:ENDPoint? (see page 1249)	<string> ::= "nnnn" where n ::= {0 1 X} <string> ::= "0xn" where n ::= {0,...,9 A,...,F X \$}
:SBUS<n>:USB:TRIGger:ET <string> (see page 1250)	:SBUS<n>:USB:TRIGger:ET? (see page 1250)	<string> ::= "nn" where n ::= {0 1 X} <string> ::= "0xn" where n ::= {0 1 2 3 X \$}
:SBUS<n>:USB:TRIGger:FRAMe <string> (see page 1251)	:SBUS<n>:USB:TRIGger:FRAMe? (see page 1251)	<string> ::= "nnnnnnnnnnnn" where n ::= {0 1 X} <string> ::= "0xn" where n ::= {0,...,9 A,...,F X \$}
:SBUS<n>:USB:TRIGger:HADDRESS <string> (see page 1252)	:SBUS<n>:USB:TRIGger:HADDRESS? (see page 1252)	<string> ::= "nnnnnnnn" where n ::= {0 1 X} <string> ::= "0xn" where n ::= {0,...,9 A,...,F X \$}
:SBUS<n>:USB:TRIGger:PCHECK <string> (see page 1253)	:SBUS<n>:USB:TRIGger:PCHECK? (see page 1253)	<string> ::= "nnnn" where n ::= {0 1 X} <string> ::= "0xn" where n ::= {0,...,9 A,...,F X \$}
:SBUS<n>:USB:TRIGger:PID:DATA <pid> (see page 1254)	:SBUS<n>:USB:TRIGger:PID:DATA? (see page 1254)	<pid> ::= {DATA0 DATA1 DATA2 MDATA}
:SBUS<n>:USB:TRIGger:PID:HANDshake <pid> (see page 1255)	:SBUS<n>:USB:TRIGger:PID:HANDshake? (see page 1255)	<pid> ::= {ACK NAK STALL NYET}
:SBUS<n>:USB:TRIGger:PID:SPECIAL <pid> (see page 1256)	:SBUS<n>:USB:TRIGger:PID:SPECIAL? (see page 1256)	<pid> ::= {PING PRE ERR SPLIT}
:SBUS<n>:USB:TRIGger:PID:TOKEN <pid> (see page 1257)	:SBUS<n>:USB:TRIGger:PID:TOKEN? (see page 1257)	<pid> ::= {OUT IN SETUP SOF}

Table 46 :SBUS<n>:USB Commands Summary (continued)

Command	Query	Options and Query Returns
:SBUS<n>:USB:TRIGger:PORT <string> (see page 1258)	:SBUS<n>:USB:TRIGger:PORT? (see page 1258)	<string> ::= "nnnnnnn" where n ::= {0 1 X} <string> ::= "0xn" where n ::= {0,...,9 A,...,F X \$}
:SBUS<n>:USB:TRIGger:SC <string> (see page 1259)	:SBUS<n>:USB:TRIGger:SC? (see page 1259)	<string> ::= "n" where n ::= {0 1 X} <string> ::= "0xn" where n ::= {0 1 X \$}
:SBUS<n>:USB:TRIGger:SEU <string> (see page 1260)	:SBUS<n>:USB:TRIGger:SEU? (see page 1260)	<string> ::= "nn" where n ::= {0 1 X} <string> ::= "0xn" where n ::= {0 1 2 3 X \$}

Table 47 :SBUS<n>:USBPd Commands Summary

Command	Query	Options and Query Returns
:SBUS<n>:USBPd:SOURce <source> (see page 1262)	:SBUS<n>:USBPd:SOURce ? (see page 1262)	<source> ::= {CHANnel<n>} <n> ::= 1 to (# analog channels) in NR1 format
:SBUS<n>:USBPd:TRIGger <mode> (see page 1263)	:SBUS<n>:USBPd:TRIGger? (see page 1263)	<mode> ::= {PStart EOP SOP SPRime SDPRime SPDebug SDPDebug HRST CRST CRCerror PERRor HEADer}
:SBUS<n>:USBPd:TRIGger:HEADer <type> (see page 1264)	:SBUS<n>:USBPd:TRIGger:HEADer? (see page 1264)	<type> ::= {CMESsage DMESsage EMESsage VALue}
:SBUS<n>:USBPd:TRIGger:HEADer:CMESsage <type> (see page 1266)	:SBUS<n>:USBPd:TRIGger:HEADer:CMESsage? (see page 1266)	<type> ::= {GOODcrc GOTOmin ACcept REJect PING PSRDy GSRCap GSNCap DRSWap PRSWap VCSWap WAIT SRST GSCX GSTatus FRSWap GPSTatus GCCodes}
:SBUS<n>:USBPd:TRIGger:HEADer:DMESsage <type> (see page 1268)	:SBUS<n>:USBPd:TRIGger:HEADer:DMESsage? (see page 1268)	<type> ::= {SRCap REQuest BIST SNCap BSTatus ALERt GCINfo VDEFined}
:SBUS<n>:USBPd:TRIGger:HEADer:EMESsage <type> (see page 1269)	:SBUS<n>:USBPd:TRIGger:HEADer:EMESsage? (see page 1269)	<type> ::= {SCX STATus GBCap GBSTatus BCAP GMINfo MINfo SREQuest SRESponse FREQuest FRESponse PSTatus CINfo CCODEs}

Table 47 :SBUS<n>:USBPd Commands Summary (continued)

Command	Query	Options and Query Returns
:SBUS<n>:USBPd:TRIGger:HEADer:VALue <string> (see page 1271)	:SBUS<n>:USBPd:TRIGger:HEADer:VALue? (see page 1271)	<string> ::= "nn...n" where n ::= {0 1 X} <string ::= "0xnn...n" where n ::= {0,...,9 A,...,F X}
:SBUS<n>:USBPd:TRIGger:HEADer:QUALifier <type> (see page 1272)	:SBUS<n>:USBPd:TRIGger:HEADer:QUALifier? (see page 1272)	<type> ::= {NONE SOP SPrime SDPrime}

Table 48 General :SEARCh Commands Summary

Command	Query	Options and Query Returns
n/a	:SEARCh:COUNT? (see page 1275)	<count> ::= an integer count value
:SEARCh:EVENT <event_number> (see page 1276)	:SEARCh:EVENT? (see page 1276)	<event_number> ::= the integer number of a found search event
:SEARCh:MODE <value> (see page 1277)	:SEARCh:MODE? (see page 1277)	<value> ::= {EDGE GLITCh RUNT TRANSition SERIAL{1 2} PEAK}
:SEARCh:STATe <value> (see page 1278)	:SEARCh:STATe? (see page 1278)	<value> ::= {{0 OFF} {1 ON}}

Table 49 :SEARCh:EDGE Commands Summary

Command	Query	Options and Query Returns
:SEARCh:EDGE:SLOPe <slope> (see page 1280)	:SEARCh:EDGE:SLOPe? (see page 1280)	<slope> ::= {POSitive NEGative EITHER}
:SEARCh:EDGE:SOURce <source> (see page 1281)	:SEARCh:EDGE:SOURce? (see page 1281)	<source> ::= CHANnel<n> <n> ::= 1 to (# analog channels) in NR1 format

Table 50 :SEARCH:GLITCh Commands Summary

Command	Query	Options and Query Returns
:SEARCH:GLITCh:GREate rthan <greater_than_time>[s uffix] (see page 1283)	:SEARCH:GLITCh:GREate rthan? (see page 1283)	<greater_than_time> ::= floating-point number in NR3 format [suffix] ::= {s ms us ns ps}
:SEARCH:GLITCh:LESSt han <less_than_time>[suff ix] (see page 1284)	:SEARCH:GLITCh:LESSt han? (see page 1284)	<less_than_time> ::= floating-point number in NR3 format [suffix] ::= {s ms us ns ps}
:SEARCH:GLITCh:POLari ty <polarity> (see page 1285)	:SEARCH:GLITCh:POLari ty? (see page 1285)	<polarity> ::= {POSitive NEGative}
:SEARCH:GLITCh:QUALif ier <qualifier> (see page 1286)	:SEARCH:GLITCh:QUALif ier? (see page 1286)	<qualifier> ::= {GREaterthan LESSthan RANGE}
:SEARCH:GLITCh:RANGE <less_than_time>[suff ix], <greater_than_time>[s uffix] (see page 1287)	:SEARCH:GLITCh:RANGE? (see page 1287)	<less_than_time> ::= 15 ns to 10 seconds in NR3 format <greater_than_time> ::= 10 ns to 9.99 seconds in NR3 format [suffix] ::= {s ms us ns ps}
:SEARCH:GLITCh:SOURce <source> (see page 1288)	:SEARCH:GLITCh:SOURce ? (see page 1288)	<source> ::= CHANnel<n> <n> ::= 1 to (# analog channels) in NR1 format

Table 51 :SEARCH:PEAK Commands Summary

Command	Query	Options and Query Returns
:SEARCH:PEAK:EXCursio n <delta_level> (see page 1290)	:SEARCH:PEAK:EXCursio n? (see page 1290)	<delta_level> ::= required change in level to be recognized as a peak, in NR3 format.
:SEARCH:PEAK:NPEaks <number> (see page 1291)	:SEARCH:PEAK:NPEaks? (see page 1291)	<number> ::= max number of peaks to find, 1-11 in NR1 format.

Table 51 :SEARCH:PEAK Commands Summary (continued)

Command	Query	Options and Query Returns
:SEARCH:PEAK:SOURce <source> (see page 1292)	:SEARCH:PEAK:SOURce? (see page 1292)	<source> ::= {FUNCTION<m> MATH<m>} (must be an FFT waveform) <m> ::= 1 to 4 in NR1 format
:SEARCH:PEAK:THReshol d <level> (see page 1293)	:SEARCH:PEAK:THReshol d? (see page 1293)	<level> ::= necessary level to be considered a peak, in NR3 format.

Table 52 :SEARCH:RUNT Commands Summary

Command	Query	Options and Query Returns
:SEARCH:RUNT:POLarity <polarity> (see page 1295)	:SEARCH:RUNT:POLarity ? (see page 1295)	<polarity> ::= {POSitive NEGative EITHER}
:SEARCH:RUNT:QUALifie r <qualifier> (see page 1296)	:SEARCH:RUNT:QUALifie r? (see page 1296)	<qualifier> ::= {GREaterthan LESSthan NONE}
:SEARCH:RUNT:SOURce <source> (see page 1297)	:SEARCH:RUNT:SOURce? (see page 1297)	<source> ::= CHANnel<n> <n> ::= 1 to (# analog channels) in NR1 format
:SEARCH:RUNT:TIME <time>[suffix] (see page 1298)	:SEARCH:RUNT:TIME? (see page 1298)	<time> ::= floating-point number in NR3 format [suffix] ::= {s ms us ns ps}

Table 53 :SEARCH:TRANSition Commands Summary

Command	Query	Options and Query Returns
:SEARCH:TRANSition:QU ALifier <qualifier> (see page 1300)	:SEARCH:TRANSition:QU ALifier? (see page 1300)	<qualifier> ::= {GREaterthan LESSthan}
:SEARCH:TRANSition:SL OPe <slope> (see page 1301)	:SEARCH:TRANSition:SL OPe? (see page 1301)	<slope> ::= {NEGative POSitive}

Table 53 :SEARCh:TRANSition Commands Summary (continued)

Command	Query	Options and Query Returns
:SEARCh:TRANSition:SO URce <source> (see page 1302)	:SEARCh:TRANSition:SO URce? (see page 1302)	<source> ::= CHANnel<n> <n> ::= 1 to (# analog channels) in NR1 format
:SEARCh:TRANSition:TI ME <time>[suffix] (see page 1303)	:SEARCh:TRANSition:TI ME? (see page 1303)	<time> ::= floating-point number in NR3 format [suffix] ::= {s ms us ns ps}

Table 54 :SEARCh:SERial:A429 Commands Summary

Command	Query	Options and Query Returns
:SEARCh:SERial:A429:L ABel <value> (see page 1305)	:SEARCh:SERial:A429:L ABel? (see page 1305)	<value> ::= 8-bit integer in decimal, <hex>, <octal>, or <string> from 0-255 <hex> ::= #Hnn where n ::= {0,...,9 A,...,F} <octal> ::= #Qnnn where n ::= {0,...,7} <string> ::= "0xnn" where n ::= {0,...,9 A,...,F}
:SEARCh:SERial:A429:M ODE <condition> (see page 1306)	:SEARCh:SERial:A429:M ODE? (see page 1306)	<condition> ::= {LAbel LBITs PError WError GError WGErrors ALLerrors}
:SEARCh:SERial:A429:P ATTern:DATA <string> (see page 1307)	:SEARCh:SERial:A429:P ATTern:DATA? (see page 1307)	<string> ::= "nn...n" where n ::= {0 1}, length depends on FORMat
:SEARCh:SERial:A429:P ATTern:SDI <string> (see page 1308)	:SEARCh:SERial:A429:P ATTern:SDI? (see page 1308)	<string> ::= "nn" where n ::= {0 1}, length always 2 bits
:SEARCh:SERial:A429:P ATTern:SSM <string> (see page 1309)	:SEARCh:SERial:A429:P ATTern:SSM? (see page 1309)	<string> ::= "nn" where n ::= {0 1}, length always 2 bits

Table 55 :SEARCH:SERIAL:CAN Commands Summary

Command	Query	Options and Query Returns
:SEARCH:SERIAL:CAN:MODE <value> (see page 1311)	:SEARCH:SERIAL:CAN:MODE? (see page 1311)	<value> ::= {IDEither IDData DATA IDRemote ERROR ACKerror FORMerror STUFFerror CRCerror ALLerrors OVERload MESSage MSIGnal}
:SEARCH:SERIAL:CAN:PARTern:DATA <string> (see page 1313)	:SEARCH:SERIAL:CAN:PARTern:DATA? (see page 1313)	<string> ::= "0xnn...n" where n ::= {0,...,9 A,...,F X} for hexadecimal
:SEARCH:SERIAL:CAN:PARTern:DATA:LENGTH <length> (see page 1314)	:SEARCH:SERIAL:CAN:PARTern:DATA:LENGTH? (see page 1314)	<length> ::= integer from 1 to 8 in NR1 format
:SEARCH:SERIAL:CAN:PARTern:ID <string> (see page 1315)	:SEARCH:SERIAL:CAN:PARTern:ID? (see page 1315)	<string> ::= "0xnn...n" where n ::= {0,...,9 A,...,F X} for hexadecimal
:SEARCH:SERIAL:CAN:PARTern:ID:MODE <value> (see page 1316)	:SEARCH:SERIAL:CAN:PARTern:ID:MODE? (see page 1316)	<value> ::= {STANDARD EXTENDED}
:SEARCH:SERIAL:CAN:SYMBOLic:MESSAge <name> (see page 1317)	:SEARCH:SERIAL:CAN:SYMBOLic:MESSAge? (see page 1317)	<name> ::= quoted ASCII string
:SEARCH:SERIAL:CAN:SYMBOLic:SIGNal <name> (see page 1318)	:SEARCH:SERIAL:CAN:SYMBOLic:SIGNal? (see page 1318)	<name> ::= quoted ASCII string
:SEARCH:SERIAL:CAN:SYMBOLic:VALue <data> (see page 1319)	:SEARCH:SERIAL:CAN:SYMBOLic:VALue? (see page 1319)	<data> ::= value in NR3 format

Table 56 :SEARCH:SERIAL:FLEXray Commands Summary

Command	Query	Options and Query Returns
:SEARCH:SERIAL:FLEXray:CYCLE <cycle> (see page 1321)	:SEARCH:SERIAL:FLEXray:CYCLE? (see page 1321)	<cycle> ::= {ALL <cycle #>} <cycle #> ::= integer from 0-63
:SEARCH:SERIAL:FLEXray:DATA <string> (see page 1322)	:SEARCH:SERIAL:FLEXray:DATA? (see page 1322)	<string> ::= "0xnn...n" where n ::= {0,...,9 A,...,F X}
:SEARCH:SERIAL:FLEXray:DATA:LENGTH <length> (see page 1323)	:SEARCH:SERIAL:FLEXray:DATA:LENGTH? (see page 1323)	<length> ::= integer from 1 to 12 in NR1 format

Table 56 :SEARCH:SERIAL:FLEXray Commands Summary (continued)

Command	Query	Options and Query Returns
:SEARCH:SERIAL:FLEXray:FRAME <frame id> (see page 1324)	:SEARCH:SERIAL:FLEXray:FRAME? (see page 1324)	<frame_id> ::= {ALL <frame #>} <frame #> ::= integer from 1-2047
:SEARCH:SERIAL:FLEXray:MODE <value> (see page 1325)	:SEARCH:SERIAL:FLEXray:MODE? (see page 1325)	<value> ::= {FRAME CYCLE DATA HERRor FERRor AERRor}

Table 57 :SEARCH:SERIAL:I2S Commands Summary

Command	Query	Options and Query Returns
:SEARCH:SERIAL:I2S:AUDio <audio_ch> (see page 1327)	:SEARCH:SERIAL:I2S:AUDio? (see page 1327)	<audio_ch> ::= {RIGHT LEFT EITHER}
:SEARCH:SERIAL:I2S:MODE <value> (see page 1328)	:SEARCH:SERIAL:I2S:MODE? (see page 1328)	<value> ::= {EQUAL NOTequal LESSthan GREATERthan INRange OUTRange}
:SEARCH:SERIAL:I2S:PARTtern:DATA <string> (see page 1329)	:SEARCH:SERIAL:I2S:PARTtern:DATA? (see page 1329)	<string> ::= "n" where n ::= 32-bit integer in signed decimal when <base> = DECimal <string> ::= "nn...n" where n ::= {0 1 X} when <base> = BINary <string> ::= "0xnn...n" where n ::= {0,...,9 A,...,F X} when <base> = HEX
:SEARCH:SERIAL:I2S:PARTtern:FORMat <base> (see page 1330)	:SEARCH:SERIAL:I2S:PARTtern:FORMat? (see page 1330)	<base> ::= {BINary HEX DECimal}
:SEARCH:SERIAL:I2S:RANGE <lower>, <upper> (see page 1331)	:SEARCH:SERIAL:I2S:RANGE? (see page 1331)	<lower> ::= 32-bit integer in signed decimal, <nondecimal>, or <string> <upper> ::= 32-bit integer in signed decimal, <nondecimal>, or <string> <nondecimal> ::= #Hnn...n where n ::= {0,...,9 A,...,F} for hexadecimal <nondecimal> ::= #Bnn...n where n ::= {0 1} for binary <string> ::= "0xnn...n" where n ::= {0,...,9 A,...,F} for hexadecimal

Table 58 :SEARCh:SERial:IIC Commands Summary

Command	Query	Options and Query Returns
:SEARCh:SERial:IIC:MODE <value> (see page 1333)	:SEARCh:SERial:IIC:MODE? (see page 1333)	<value> ::= {REStart ADDRESS ANACK NACKnowledge READEprom READ7 WRITE7 R7Data2 W7Data2}
:SEARCh:SERial:IIC:PAATtern:ADDRESS <value> (see page 1335)	:SEARCh:SERial:IIC:PAATtern:ADDRESS? (see page 1335)	<value> ::= integer or <string> <string> ::= "0xnn" n ::= {0,...,9 A,...,F}
:SEARCh:SERial:IIC:PAATtern:DATA <value> (see page 1336)	:SEARCh:SERial:IIC:PAATtern:DATA? (see page 1336)	<value> ::= integer or <string> <string> ::= "0xnn" n ::= {0,...,9 A,...,F}
:SEARCh:SERial:IIC:PAATtern:DATA2 <value> (see page 1337)	:SEARCh:SERial:IIC:PAATtern:DATA2? (see page 1337)	<value> ::= integer or <string> <string> ::= "0xnn" n ::= {0,...,9 A,...,F}
:SEARCh:SERial:IIC:QUALifier <value> (see page 1338)	:SEARCh:SERial:IIC:QUALifier? (see page 1338)	<value> ::= {EQUal NOTequal LESSthan GREaterthan}

Table 59 :SEARCh:SERial:LIN Commands Summary

Command	Query	Options and Query Returns
:SEARCh:SERial:LIN:ID <value> (see page 1340)	:SEARCh:SERial:LIN:ID ? (see page 1340)	<value> ::= 7-bit integer in decimal, <nondecimal>, or <string> from 0-63 or 0x00-0x3f <nondecimal> ::= #Hnn where n ::= {0,...,9 A,...,F} for hexadecimal <nondecimal> ::= #Bnn...n where n ::= {0 1} for binary <string> ::= "0xnn" where n ::= {0,...,9 A,...,F} for hexadecimal
:SEARCh:SERial:LIN:MODE <value> (see page 1341)	:SEARCh:SERial:LIN:MODE? (see page 1341)	<value> ::= {ID DATA ERRor}

Table 59 :SEARCH:SERIAL:LIN Commands Summary (continued)

Command	Query	Options and Query Returns
:SEARCH:SERIAL:LIN:PA TTern:DATA <string> (see page 1342)	:SEARCH:SERIAL:LIN:PA TTern:DATA? (see page 1342)	When :SEARCH:SERIAL:LIN:PATTERN:FORMa t DECimal, <string> ::= "n" where n ::= 32-bit integer in unsigned decimal, returns "\$" if data has any don't cares When :SEARCH:SERIAL:LIN:PATTERN:FORMa t HEX, <string> ::= "0xnn...n" where n ::= {0,...,9 A,...,F X }
:SEARCH:SERIAL:LIN:PA TTern:DATA:LENGth <length> (see page 1343)	:SEARCH:SERIAL:LIN:PA TTern:DATA:LENGth? (see page 1343)	<length> ::= integer from 1 to 8 in NR1 format
:SEARCH:SERIAL:LIN:PA TTern:FORMat <base> (see page 1344)	:SEARCH:SERIAL:LIN:PA TTern:FORMat? (see page 1344)	<base> ::= {HEX DECimal}
:SEARCH:SERIAL:LIN:SY MBolic:FRAMe <name> (see page 1345)	:SEARCH:SERIAL:LIN:SY MBolic:FRAMe? (see page 1345)	<name> ::= quoted ASCII string
:SEARCH:SERIAL:LIN:SY MBolic:SIGNal <name> (see page 1346)	:SEARCH:SERIAL:LIN:SY MBolic:SIGNal? (see page 1346)	<name> ::= quoted ASCII string
:SEARCH:SERIAL:LIN:SY MBolic:VALue <data> (see page 1347)	:SEARCH:SERIAL:LIN:SY MBolic:VALue? (see page 1347)	<data> ::= value in NR3 format

Table 60 :SEARCH:SERIAL:M1553 Commands Summary

Command	Query	Options and Query Returns
:SEARCH:SERIAL:M1553: MODE <value> (see page 1349)	:SEARCH:SERIAL:M1553: MODE? (see page 1349)	<value> ::= {DSTArt CSTArt RTA RTA11 PERRor SERRor MERRor}

Table 60 :SEARCH:SERIAL:M1553 Commands Summary (continued)

Command	Query	Options and Query Returns
:SEARCH:SERIAL:M1553:PATTERN:DATA <string> (see page 1350)	:SEARCH:SERIAL:M1553:PATTERN:DATA? (see page 1350)	<string> ::= "nn...n" where n ::= {0 1}
:SEARCH:SERIAL:M1553:RTA <value> (see page 1351)	:SEARCH:SERIAL:M1553:RTA? (see page 1351)	<value> ::= 5-bit integer in decimal, <hexadecimal>, <binary>, or <string> from 0-31 <hexadecimal> ::= #Hnn where n ::= {0,...,9 A,...,F} <binary> ::= #Bnn...n where n ::= {0 1} for binary <string> ::= "0xnn" where n ::= {0,...,9 A,...,F}

Table 61 :SEARCH:SERIAL:SENT Commands Summary

Command	Query	Options and Query Returns
:SEARCH:SERIAL:SENT:FAST:DATA <string> (see page 1353)	:SEARCH:SERIAL:SENT:FAST:DATA? (see page 1353)	<string> ::= "0xn..." where n ::= {0,...,9 A,...,F X \$}
:SEARCH:SERIAL:SENT:MODE <mode> (see page 1354)	:SEARCH:SERIAL:SENT:MODE? (see page 1354)	<mode> ::= {FCData SCMid SCData CRCError PPERror}
:SEARCH:SERIAL:SENT:SLOW:DATA <data> (see page 1355)	:SEARCH:SERIAL:SENT:SLOW:DATA? (see page 1355)	<data> ::= from -1 (don't care) to 65535, in NR1 format.
:SEARCH:SERIAL:SENT:SLOW:ID <id> (see page 1356)	:SEARCH:SERIAL:SENT:SLOW:ID? (see page 1356)	<id> ::= from -1 (don't care) to 255, in NR1 format.

Table 62 :SEARCH:SERIAL:SPI Commands Summary

Command	Query	Options and Query Returns
:SEARCH:SERIAL:SPI:MODE <value> (see page 1358)	:SEARCH:SERIAL:SPI:MODE? (see page 1358)	<value> ::= {MOSI MISO}

Table 62 :SEARCh:SERial:SPI Commands Summary (continued)

Command	Query	Options and Query Returns
:SEARCh:SERial:SPI:PA TTern:DATA <string> (see page 1359)	:SEARCh:SERial:SPI:PA TTern:DATA? (see page 1359)	<string> ::= "0xnn...n" where n ::= {0,...,9 A,...,F X}
:SEARCh:SERial:SPI:PA TTern:WIDTh <width> (see page 1360)	:SEARCh:SERial:SPI:PA TTern:WIDTh? (see page 1360)	<width> ::= integer from 1 to 10

Table 63 :SEARCh:SERial:UART Commands Summary

Command	Query	Options and Query Returns
:SEARCh:SERial:UART:D ATA <value> (see page 1362)	:SEARCh:SERial:UART:D ATA? (see page 1362)	<value> ::= 8-bit integer from 0-255 (0x00-0xff) in decimal, <hexadecimal>, <binary>, or <quoted_string> format <hexadecimal> ::= #Hnn where n ::= {0,...,9 A,...,F} for hexadecimal <binary> ::= #Bnn...n where n ::= {0 1} for binary <quoted_string> ::= any of the 128 valid 7-bit ASCII characters (or standard abbreviations)
:SEARCh:SERial:UART:M ODE <value> (see page 1363)	:SEARCh:SERial:UART:M ODE? (see page 1363)	<value> ::= {RDATA RD1 RD0 RDX TDATA TD1 TD0 TDX PARityerror AERRor}
:SEARCh:SERial:UART:Q UALifier <value> (see page 1364)	:SEARCh:SERial:UART:Q UALifier? (see page 1364)	<value> ::= {EQUAL NOTequal GREaterthan LESSthan}

Table 64 :SEARCh:SERial:USB Commands Summary

Command	Query	Options and Query Returns
:SEARCh:SERial:USB:MO DE <condition> (see page 1367)	:SEARCh:SERial:USB:MO DE? (see page 1367)	<event> ::= {TOKEN DATA HANDshake SPECial ALLerrors PIDerror CRC5error CRC16error GLITCherror STUFFerror SE1error}
:SEARCh:SERial:USB:AD DRess <string> (see page 1368)	:SEARCh:SERial:USB:AD DRess? (see page 1368)	<string> ::= "0xnn" where n ::= {0,...,9 A,...,F X \$}

Table 64 :SEARCH:SERIAL:USB Commands Summary (continued)

Command	Query	Options and Query Returns
:SEARCH:SERIAL:USB:CR C <string> (see page 1369)	:SEARCH:SERIAL:USB:CR C? (see page 1369)	<string> ::= "0xnn" where n ::= {0,...,9 A,...,F X \$}
:SEARCH:SERIAL:USB:DA TA <string> (see page 1370)	:SEARCH:SERIAL:USB:DA TA? (see page 1370)	<string> ::= "0xn..." where n ::= {0,...,9 A,...,F X \$}
:SEARCH:SERIAL:USB:DA TA:LENGth <value> (see page 1371)	:SEARCH:SERIAL:USB:DA TA:LENGth? (see page 1371)	<length> ::= data length between 1-20
:SEARCH:SERIAL:USB:EN DPoint <string> (see page 1372)	:SEARCH:SERIAL:USB:EN DPoint? (see page 1372)	<string> ::= "0xnn" where n ::= {0,...,9 A,...,F X \$}
:SEARCH:SERIAL:USB:ET <string> (see page 1373)	:SEARCH:SERIAL:USB:ET ? (see page 1373)	<string> ::= "0xnn" where n ::= {0 1 2 3 X \$}
:SEARCH:SERIAL:USB:FR AMe <string> (see page 1374)	:SEARCH:SERIAL:USB:FR AMe? (see page 1374)	<string> ::= "0xn...n" where n ::= {0,...,9 A,...,F X \$}
:SEARCH:SERIAL:USB:HA DDress <string> (see page 1375)	:SEARCH:SERIAL:USB:HA DDress? (see page 1375)	<string> ::= "0xnn" where n ::= {0,...,9 A,...,F X \$}
:SEARCH:SERIAL:USB:PI D:DATA <pid> (see page 1376)	:SEARCH:SERIAL:USB:PI D:DATA? (see page 1376)	<pid> ::= {DATA0 DATA1 DATA2 MDATA}
:SEARCH:SERIAL:USB:PI D:HANDshake <pid> (see page 1377)	:SEARCH:SERIAL:USB:PI D:HANDshake? (see page 1377)	<pid> ::= {ACK NAK STALL NYET}
:SEARCH:SERIAL:USB:PI D:SPECial <pid> (see page 1378)	:SEARCH:SERIAL:USB:PI D:SPECial? (see page 1378)	<pid> ::= {PING PRE ERR SPLIT}
:SEARCH:SERIAL:USB:PI D:TOKEN <pid> (see page 1379)	:SEARCH:SERIAL:USB:PI D:TOKEN? (see page 1379)	<pid> ::= {OUT IN SETUP SOF}
:SEARCH:SERIAL:USB:PO RT <string> (see page 1380)	:SEARCH:SERIAL:USB:PO RT? (see page 1380)	<string> ::= "0xnn" where n ::= {0,...,9 A,...,F X \$}

Table 64 :SEARCH:SERIAL:USB Commands Summary (continued)

Command	Query	Options and Query Returns
:SEARCH:SERIAL:USB:SC <string> (see page 1381)	:SEARCH:SERIAL:USB:SC ? (see page 1381)	<string> ::= "0xn" where n ::= {0 1 X \$}
:SEARCH:SERIAL:USB:SE U <string> (see page 1382)	:SEARCH:SERIAL:USB:SE U? (see page 1382)	<string> ::= "0xn" where n ::= {0 1 2 3 X \$}

Table 65 :SYSTEM Commands Summary

Command	Query	Options and Query Returns
:SYSTEM:DATE <date> (see page 1386)	:SYSTEM:DATE? (see page 1386)	<date> ::= <year>, <month>, <day> <year> ::= 4-digit year in NR1 format <month> ::= {1, ..., 12 JANuary FEBruary MARCH APRil MAY JUNE JULy AUGust SEPTember OCTober NOVember DECember} <day> ::= {1, ..., 31}
n/a	:SYSTEM:DIDENTIFIER? (see page 1387)	n/a
:SYSTEM:DSP <string> (see page 1388)	n/a	<string> ::= up to 75 characters as a quoted ASCII string
n/a	:SYSTEM:ERROR? (see page 1389)	<error> ::= an integer error code <error string> ::= quoted ASCII string. See Error Messages (see page 1669).
:SYSTEM:LOCK {{1 ON} {0 OFF}} (see page 1390)	:SYSTEM:LOCK? (see page 1390)	{1 0}
:SYSTEM:PERSONA[:MANU facturer] <manufacturer_string> (see page 1391)	:SYSTEM:PERSONA[:MANU facturer]? (see page 1391)	<manufacturer_string> ::= quoted ASCII string, up to 63 characters
:SYSTEM:PERSONA[:MANU facturer]:DEFAULT (see page 1392)	n/a	Sets manufacturer string to "KEYSIGHT TECHNOLOGIES"
:SYSTEM:PRECISION {{1 ON} {0 OFF}} (see page 1393)	:SYSTEM:PRECISION? (see page 1393)	{1 0}

Table 65 :SYSTem Commands Summary (continued)

Command	Query	Options and Query Returns
:SYSTem:PRECision:LENGth <length> (see page 1394)	:SYSTem:PRECision:LENGth? (see page 1394)	<length> ::= between 100k and 1M points in NR1 format
:SYSTem:PRESet (see page 1395)	n/a	See :SYSTem:PRESet (see page 1395)
:SYSTem:PROTection:LOCK {{1 ON} {0 OFF}} (see page 1398)	:SYSTem:PROTection:LOCK? (see page 1398)	{1 0}
:SYSTem:RLOGger <setting>[, <file_name>[, <write_mode>]] (see page 1399)	n/a	<setting> ::= {{0 OFF} {1 ON}} <file_name> ::= quoted ASCII string <write_mode> ::= {CREate APPend}
:SYSTem:RLOGger:DESTination <dest> (see page 1400)	:SYSTem:RLOGger:DESTination? (see page 1400)	<dest> ::= {FILE SCReen BOTH}
:SYSTem:RLOGger:DISPlay {{0 OFF} {1 ON}} (see page 1401)	:SYSTem:RLOGger:DISPlay? (see page 1401)	<setting> ::= {0 1}
:SYSTem:RLOGger:FNAME <file_name> (see page 1402)	:SYSTem:RLOGger:FNAME? (see page 1402)	<file_name> ::= quoted ASCII string
:SYSTem:RLOGger:STATe {{0 OFF} {1 ON}} (see page 1403)	:SYSTem:RLOGger:STATe? (see page 1403)	<setting> ::= {0 1}
:SYSTem:RLOGger:TRANSPARENT {{0 OFF} {1 ON}} (see page 1404)	:SYSTem:RLOGger:TRANSPARENT? (see page 1404)	<setting> ::= {0 1}
:SYSTem:RLOGger:WMOde <write_mode> (see page 1405)	:SYSTem:RLOGger:WMOde? (see page 1405)	<write_mode> ::= {CREate APPend}
:SYSTem:SETup <setup_data> (see page 1406)	:SYSTem:SETup? (see page 1406)	<setup_data> ::= data in IEEE 488.2 # format.

Table 65 :SYSTem Commands Summary (continued)

Command	Query	Options and Query Returns
:SYSTem:TIME <time> (see page 1408)	:SYSTem:TIME? (see page 1408)	<time> ::= hours, minutes, seconds in NR1 format
:SYSTem:TOUCh {{1 ON} {0 OFF}} (see page 1409)	:SYSTem:TOUCh? (see page 1409)	{1 0}

Table 66 :TIMEbase Commands Summary

Command	Query	Options and Query Returns
:TIMEbase:MODE <value> (see page 1413)	:TIMEbase:MODE? (see page 1413)	<value> ::= {MAIN WINDow XY ROLL}
:TIMEbase:POSition <pos> (see page 1414)	:TIMEbase:POSition? (see page 1414)	<pos> ::= time from the trigger event to the display reference point in NR3 format
:TIMEbase:RANGe <range_value> (see page 1415)	:TIMEbase:RANGe? (see page 1415)	<range_value> ::= time for 10 div in seconds in NR3 format
:TIMEbase:REFClock {{0 OFF} {1 ON}} (see page 1416)	:TIMEbase:REFClock? (see page 1416)	{0 1}
:TIMEbase:REFerence {LEFT CENTer RIGHT CUSTom} (see page 1417)	:TIMEbase:REFerence? (see page 1417)	<return_value> ::= {LEFT CENTer RIGHT CUSTom}
:TIMEbase:REFerence:L OCation <loc> (see page 1418)	:TIMEbase:REFerence:L OCation? (see page 1418)	<loc> ::= 0.0 to 1.0 in NR3 format
:TIMEbase:SCALe <scale_value> (see page 1419)	:TIMEbase:SCALe? (see page 1419)	<scale_value> ::= time/div in seconds in NR3 format
:TIMEbase:VERNier {{0 OFF} {1 ON}} (see page 1420)	:TIMEbase:VERNier? (see page 1420)	{0 1}
:TIMEbase:WINDow:POSi tion <pos> (see page 1421)	:TIMEbase:WINDow:POSi tion? (see page 1421)	<pos> ::= time from the trigger event to the zoomed view reference point in NR3 format

Table 66 :TIMEbase Commands Summary (continued)

Command	Query	Options and Query Returns
:TIMEbase:WINDow:RANGe <range_value> (see page 1422)	:TIMEbase:WINDow:RANGe? (see page 1422)	<range_value> ::= range value in seconds in NR3 format for the zoomed window
:TIMEbase:WINDow:SCALe <scale_value> (see page 1423)	:TIMEbase:WINDow:SCALe? (see page 1423)	<scale_value> ::= scale value in seconds in NR3 format for the zoomed window

Table 67 General :TRIGger Commands Summary

Command	Query	Options and Query Returns
:TRIGger:FORCe (see page 1429)	n/a	n/a
:TRIGger:HFRejeCt {{0 OFF} {1 ON}} (see page 1430)	:TRIGger:HFRejeCt? (see page 1430)	{0 1}
:TRIGger:HOLDoFF <holdoff_time> (see page 1431)	:TRIGger:HOLDoFF? (see page 1431)	<holdoff_time> ::= 40 ns to 10 s in NR3 format
:TRIGger:HOLDoFF:MAXiMum <max_holdoff> (see page 1432)	:TRIGger:HOLDoFF:MAXiMum? (see page 1432)	<max_holdoff> ::= maximum holdoff time in seconds in NR3 format
:TRIGger:HOLDoFF:MINiMum <min_holdoff> (see page 1433)	:TRIGger:HOLDoFF:MINiMum? (see page 1433)	<min_holdoff> ::= minimum holdoff time in seconds in NR3 format
:TRIGger:HOLDoFF:RANDom {{0 OFF} {1 ON}} (see page 1434)	:TRIGger:HOLDoFF:RANDom? (see page 1434)	<setting> ::= {0 1}
:TRIGger:JFRee {{0 OFF} {1 ON}} (see page 1435)	:TRIGger:JFRee? (see page 1435)	{0 1}
:TRIGger:LEVel:ASeTup (see page 1436)	n/a	n/a
:TRIGger:LEVel:HIGH <level>, <source> (see page 1437)	:TRIGger:LEVel:HIGH? <source> (see page 1437)	<level> ::= .75 x full-scale voltage from center screen in NR3 format. <source> ::= CHANnel<n> <n> ::= 1 to (# analog channels) in NR1 format

Table 67 General :TRIGger Commands Summary (continued)

Command	Query	Options and Query Returns
:TRIGger:LEVel:LOW <level>, <source> (see page 1438)	:TRIGger:LEVel:LOW? <source> (see page 1438)	<level> ::= .75 x full-scale voltage from center screen in NR3 format. <source> ::= CHANnel<n> <n> ::= 1 to (# analog channels) in NR1 format
:TRIGger:MODE <mode> (see page 1439)	:TRIGger:MODE? (see page 1439)	<mode> ::= {EDGE GLITCh PATtern TV DELay EBURst OR RUNT SHOLd TRANSition SBUS{1 2}} <return_value> ::= {<mode> <none>} <none> ::= query returns "NONE" if the :TIMEbase:MODE is ROLL or XY
:TRIGger:NREJect {{0 OFF} {1 ON}} (see page 1440)	:TRIGger:NREJect? (see page 1440)	{0 1}
:TRIGger:SWEep <sweep> (see page 1441)	:TRIGger:SWEep? (see page 1441)	<sweep> ::= {AUTO NORMal}

Table 68 :TRIGger:DELay Commands Summary

Command	Query	Options and Query Returns
:TRIGger:DELay:ARM:SL OPe <slope> (see page 1443)	:TRIGger:DELay:ARM:SL OPe? (see page 1443)	<slope> ::= {NEGative POSitive}
:TRIGger:DELay:ARM:SO URce <source> (see page 1444)	:TRIGger:DELay:ARM:SO URce? (see page 1444)	<source> ::= {CHANnel<n> DIGital<d>} <n> ::= 1 to (# analog channels) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format
:TRIGger:DELay:TDELay :TIME <time_value> (see page 1445)	:TRIGger:DELay:TDELay :TIME? (see page 1445)	<time_value> ::= time in seconds in NR3 format
:TRIGger:DELay:TRIGge r:COUNT <count> (see page 1446)	:TRIGger:DELay:TRIGge r:COUNT? (see page 1446)	<count> ::= integer in NR1 format

Table 68 :TRIGger:DElay Commands Summary (continued)

Command	Query	Options and Query Returns
:TRIGger:DElay:TRIGger:SLOPe <slope> (see page 1447)	:TRIGger:DElay:TRIGger:SLOPe? (see page 1447)	<slope> ::= {NEGative POSitive}
:TRIGger:DElay:TRIGger:SOURce <source> (see page 1448)	:TRIGger:DElay:TRIGger:SOURce? (see page 1448)	<source> ::= {CHANnel<n> DIGital<d>} <n> ::= 1 to (# analog channels) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format

Table 69 :TRIGger:EBURst Commands Summary

Command	Query	Options and Query Returns
:TRIGger:EBURst:COUNT <count> (see page 1450)	:TRIGger:EBURst:COUNT? (see page 1450)	<count> ::= integer in NR1 format
:TRIGger:EBURst:IDLE <time_value> (see page 1451)	:TRIGger:EBURst:IDLE? (see page 1451)	<time_value> ::= time in seconds in NR3 format
:TRIGger:EBURst:SLOPe <slope> (see page 1452)	:TRIGger:EBURst:SLOPe? (see page 1452)	<slope> ::= {NEGative POSitive}
:TRIGger:EBURst:SOURce <source> (see page 1453)	:TRIGger:EBURst:SOURce? (see page 1453)	<source> ::= {CHANnel<n> DIGital<d>} <n> ::= 1 to (# analog channels) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format

Table 70 :TRIGger[:EDGE] Commands Summary

Command	Query	Options and Query Returns
:TRIGger[:EDGE]:COUPling {AC DC LFReject} (see page 1456)	:TRIGger[:EDGE]:COUPling? (see page 1456)	{AC DC LFReject}
:TRIGger[:EDGE]:LEVel <level> [, <source>] (see page 1457)	:TRIGger[:EDGE]:LEVel? [<source>] (see page 1457)	<p>For internal triggers, <level> ::= .75 x full-scale voltage from center screen in NR3 format.</p> <p>For external triggers, <level> ::= ±(external range setting) in NR3 format.</p> <p>For digital channels (MSO models), <level> ::= ±8 V.</p> <p><source> ::= {CHANnel<n> EXTernal} for DSO models</p> <p><source> ::= {CHANnel<n> DIGital<d> EXTernal} for MSO models</p> <p><n> ::= 1 to (# analog channels) in NR1 format</p> <p><d> ::= 0 to (# digital channels - 1) in NR1 format</p>
:TRIGger[:EDGE]:REJect {OFF LFReject HFReject} (see page 1458)	:TRIGger[:EDGE]:REJect? (see page 1458)	{OFF LFReject HFReject}
:TRIGger[:EDGE]:SLOPe <polarity> (see page 1459)	:TRIGger[:EDGE]:SLOPe? (see page 1459)	<polarity> ::= {POSitive NEGative EITHer ALTernate}
:TRIGger[:EDGE]:SOURCe <source> (see page 1460)	:TRIGger[:EDGE]:SOURCe? (see page 1460)	<p><source> ::= {CHANnel<n> EXTernal LINE WGEN} for the DSO models</p> <p><source> ::= {CHANnel<n> DIGital<d> EXTernal LINE WGEN} for the MSO models</p> <p><n> ::= 1 to (# analog channels) in NR1 format</p> <p><d> ::= 0 to (# digital channels - 1) in NR1 format</p>

Table 71 :TRIGger:GLITch Commands Summary

Command	Query	Options and Query Returns
:TRIGger:GLITch:GREAt erthan <greater_than_time>[s uffix] (see page 1463)	:TRIGger:GLITch:GREAt erthan? (see page 1463)	<greater_than_time> ::= floating-point number in NR3 format [suffix] ::= {s ms us ns ps}
:TRIGger:GLITch:LESSt han <less_than_time>[suff ix] (see page 1464)	:TRIGger:GLITch:LESSt han? (see page 1464)	<less_than_time> ::= floating-point number in NR3 format [suffix] ::= {s ms us ns ps}
:TRIGger:GLITch:LEVel <level> [<source>] (see page 1465)	:TRIGger:GLITch:LEVel ? (see page 1465)	For internal triggers, <level> ::= .75 x full-scale voltage from center screen in NR3 format. For external triggers (DSO models), <level> ::= ±(external range setting) in NR3 format. For digital channels (MSO models), <level> ::= ±8 V. <source> ::= {CHANnel<n> EXTernal} for DSO models <source> ::= {CHANnel<n> DIGital<d>} for MSO models <n> ::= 1 to (# analog channels) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format
:TRIGger:GLITch:POLar ity <polarity> (see page 1466)	:TRIGger:GLITch:POLar ity? (see page 1466)	<polarity> ::= {POSitive NEGative}
:TRIGger:GLITch:QUALi fier <qualifier> (see page 1467)	:TRIGger:GLITch:QUALi fier? (see page 1467)	<qualifier> ::= {GREATERthan LESSthan RANGE}

Table 71 :TRIGger:GLITch Commands Summary (continued)

Command	Query	Options and Query Returns
:TRIGger:GLITch:RANGe <less_than_time>[suffix], <greater_than_time>[suffix] (see page 1468)	:TRIGger:GLITch:RANGe? (see page 1468)	<less_than_time> ::= 15 ns to 10 seconds in NR3 format <greater_than_time> ::= 10 ns to 9.99 seconds in NR3 format [suffix] ::= {s ms us ns ps}
:TRIGger:GLITch:SOURce <source> (see page 1469)	:TRIGger:GLITch:SOURce? (see page 1469)	<source> ::= {CHANnel<n> DIGital<d>} <n> ::= 1 to (# analog channels) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format

Table 72 :TRIGger:OR Commands Summary

Command	Query	Options and Query Returns
:TRIGger:OR <string> (see page 1471)	:TRIGger:OR? (see page 1471)	<string> ::= "nn...n" where n ::= {R F E X} R = rising edge, F = falling edge, E = either edge, X = don't care. Each character in the string is for an analog or digital channel as shown on the front panel display.

Table 73 :TRIGger:PATtern Commands Summary

Command	Query	Options and Query Returns
:TRIGger:PATtern <string>[,<edge_source>,<edge>] (see page 1473)	:TRIGger:PATtern? (see page 1474)	<string> ::= "nn...n" where n ::= {0 1 X R F} when <base> = ASCII <string> ::= "0xnn...n" where n ::= {0,...,9 A,...,F X \$} when <base> = HEX <edge_source> ::= {CHANnel<n> NONE} for DSO models <edge_source> ::= {CHANnel<n> DIGital<d> NONE} for MSO models <n> ::= 1 to (# analog channels) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format <edge> ::= {POSitive NEGative}
:TRIGger:PATtern:FORM at <base> (see page 1475)	:TRIGger:PATtern:FORM at? (see page 1475)	<base> ::= {ASCII HEX}
:TRIGger:PATtern:GREa terthan <greater_than_time>[suffix] (see page 1476)	:TRIGger:PATtern:GREa terthan? (see page 1476)	<greater_than_time> ::= floating-point number in NR3 format [suffix] ::= {s ms us ns ps}
:TRIGger:PATtern:LESS than <less_than_time>[suffix] (see page 1477)	:TRIGger:PATtern:LESS than? (see page 1477)	<less_than_time> ::= floating-point number in NR3 format [suffix] ::= {s ms us ns ps}
:TRIGger:PATtern:QUAL ifier <qualifier> (see page 1478)	:TRIGger:PATtern:QUAL ifier? (see page 1478)	<qualifier> ::= {ENTERed GREaterthan LESSthan INRange OUTRange TIMEout}
:TRIGger:PATtern:RANG e <less_than_time>[suffix], <greater_than_time>[suffix] (see page 1479)	:TRIGger:PATtern:RANG e? (see page 1479)	<less_than_time> ::= 15 ns to 10 seconds in NR3 format <greater_than_time> ::= 10 ns to 9.99 seconds in NR3 format [suffix] ::= {s ms us ns ps}

Table 74 :TRIGger:RUNT Commands Summary

Command	Query	Options and Query Returns
:TRIGger:RUNT:POLarity <polarity> (see page 1481)	:TRIGger:RUNT:POLarity? (see page 1481)	<polarity> ::= {POSitive NEGative EITHER}
:TRIGger:RUNT:QUALifier <qualifier> (see page 1482)	:TRIGger:RUNT:QUALifier? (see page 1482)	<qualifier> ::= {GREaterthan LESSthan NONE}
:TRIGger:RUNT:SOURce <source> (see page 1483)	:TRIGger:RUNT:SOURce? (see page 1483)	<source> ::= CHANnel<n> <n> ::= 1 to (# analog channels) in NR1 format
:TRIGger:RUNT:TIME <time>[suffix] (see page 1484)	:TRIGger:RUNT:TIME? (see page 1484)	<time> ::= floating-point number in NR3 format [suffix] ::= {s ms us ns ps}

Table 75 :TRIGger:SHOLd Commands Summary

Command	Query	Options and Query Returns
:TRIGger:SHOLd:SLOPe <slope> (see page 1486)	:TRIGger:SHOLd:SLOPe? (see page 1486)	<slope> ::= {NEGative POSitive}
:TRIGger:SHOLd:SOURce :CLOCK <source> (see page 1487)	:TRIGger:SHOLd:SOURce :CLOCK? (see page 1487)	<source> ::= {CHANnel<n> DIGital<d>} <n> ::= 1 to (# analog channels) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format
:TRIGger:SHOLd:SOURce :DATA <source> (see page 1488)	:TRIGger:SHOLd:SOURce :DATA? (see page 1488)	<source> ::= {CHANnel<n> DIGital<d>} <n> ::= 1 to (# analog channels) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format

Table 75 :TRIGger:SHOLd Commands Summary (continued)

Command	Query	Options and Query Returns
:TRIGger:SHOLd:TIME:HOLD <time>[suffix] (see page 1489)	:TRIGger:SHOLd:TIME:HOLD? (see page 1489)	<time> ::= floating-point number in NR3 format [suffix] ::= {s ms us ns ps}
:TRIGger:SHOLd:TIME:SETup <time>[suffix] (see page 1490)	:TRIGger:SHOLd:TIME:SETup? (see page 1490)	<time> ::= floating-point number in NR3 format [suffix] ::= {s ms us ns ps}

Table 76 :TRIGger:TRANSition Commands Summary

Command	Query	Options and Query Returns
:TRIGger:TRANSition:QUALifier <qualifier> (see page 1492)	:TRIGger:TRANSition:QUALifier? (see page 1492)	<qualifier> ::= {GREaterthan LESSthan}
:TRIGger:TRANSition:SLOPe <slope> (see page 1493)	:TRIGger:TRANSition:SLOPe? (see page 1493)	<slope> ::= {NEGative POSitive}
:TRIGger:TRANSition:SOURce <source> (see page 1494)	:TRIGger:TRANSition:SOURce? (see page 1494)	<source> ::= CHANNEL<n> <n> ::= 1 to (# analog channels) in NR1 format
:TRIGger:TRANSition:TIME <time>[suffix] (see page 1495)	:TRIGger:TRANSition:TIME? (see page 1495)	<time> ::= floating-point number in NR3 format [suffix] ::= {s ms us ns ps}

Table 77 :TRIGger:TV Commands Summary

Command	Query	Options and Query Returns
:TRIGger:TV:LINE <line number> (see page 1497)	:TRIGger:TV:LINE? (see page 1497)	<line number> ::= integer in NR1 format
:TRIGger:TV:MODE <tv mode> (see page 1498)	:TRIGger:TV:MODE? (see page 1498)	<tv mode> ::= {FIELD1 FIELD2 AFIELDS ALINES LINE LFIELD1 LFIELD2 LALternate}
:TRIGger:TV:POLarity <polarity> (see page 1499)	:TRIGger:TV:POLarity? (see page 1499)	<polarity> ::= {POSitive NEGative}

Table 77 :TRIGger:TV Commands Summary (continued)

Command	Query	Options and Query Returns
:TRIGger:TV:SOURce <source> (see page 1500)	:TRIGger:TV:SOURce? (see page 1500)	<source> ::= {CHANnel<n>} <n> ::= 1 to (# analog channels) in NR1 format
:TRIGger:TV:STANdard <standard> (see page 1501)	:TRIGger:TV:STANdard? (see page 1501)	<standard> ::= {NTSC PAL PALM SECam} <standard> ::= {GENeric {P480L60HZ P480} {P720L60HZ P720} {P1080L24HZ P1080} P1080L25HZ P1080L50HZ P1080L60HZ {I1080L50HZ I1080} I1080L60HZ} with extended video triggering license
:TRIGger:TV:UDTV:ENUM ber <count> (see page 1502)	:TRIGger:TV:UDTV:ENUM ber? (see page 1502)	<count> ::= edge number in NR1 format
:TRIGger:TV:UDTV:HSYN c {{0 OFF} {1 ON}} (see page 1503)	:TRIGger:TV:UDTV:HSYN c? (see page 1503)	{0 1}
:TRIGger:TV:UDTV:HTIM e <time> (see page 1504)	:TRIGger:TV:UDTV:HTIM e? (see page 1504)	<time> ::= seconds in NR3 format
:TRIGger:TV:UDTV:PGTH an <min_time> (see page 1505)	:TRIGger:TV:UDTV:PGTH an? (see page 1505)	<min_time> ::= seconds in NR3 format

Table 78 :TRIGger:ZONE Commands Summary

Command	Query	Options and Query Returns
:TRIGger:ZONE:SOURce <source> (see page 1507)	:TRIGger:ZONE:SOURce? (see page 1507)	<source> ::= {CHANnel<n>} <n> ::= 1 to (# analog channels) in NR1 format
:TRIGger:ZONE:STATe {{0 OFF} {1 ON}} (see page 1508)	:TRIGger:ZONE:STATe? (see page 1508)	{0 1}
:TRIGger:ZONE<n>:MODE <mode> (see page 1509)	:TRIGger:ZONE<n>:MODE ? (see page 1509)	<mode> ::= {INTersect NOTintersect} <n> ::= 1-2 in NR1 format

Table 78 :TRIGger:ZONE Commands Summary (continued)

Command	Query	Options and Query Returns
:TRIGger:ZONE<n>:PLAC ement <width>, <height>, <x_center>, <y_center> (see page 1510)	:TRIGger:ZONE<n>:PLAC ement? (see page 1510)	<width> ::= width of zone in seconds <height> ::= height of zone in volts <x_center> ::= center of zone in seconds <y_center> ::= center of zone in volts <n> ::= 1-2 in NR1 format
n/a	:TRIGger:ZONE<n>:VALi dity? (see page 1511)	<value> ::= {VALid INValid OSCRen} <n> ::= 1-2 in NR1 format
:TRIGger:ZONE<n>:STAT e {{0 OFF} {1 ON}} (see page 1512)	:TRIGger:ZONE<n>:STAT e? (see page 1512)	{0 1} <n> ::= 1-2 in NR1 format

Table 79 :WAVEform Commands Summary

Command	Query	Options and Query Returns
:WAVEform:BYTeorder <value> (see page 1521)	:WAVEform:BYTeorder? (see page 1521)	<value> ::= {LSBFirst MSBFirst}
n/a	:WAVEform:COUNT? (see page 1522)	<count> ::= an integer from 1 to 65536 in NR1 format
n/a	:WAVEform:DATA? (see page 1523)	<binary block length bytes>, <binary data> For example, to transmit 1000 bytes of data, the syntax would be: #800001000<1000 bytes of data><NL> 8 is the number of digits that follow 00001000 is the number of bytes to be transmitted <1000 bytes of data> is the actual data
:WAVEform:FORMat <value> (see page 1525)	:WAVEform:FORMat? (see page 1525)	<value> ::= {WORD BYTE ASCII}

Table 79 :WAVeform Commands Summary (continued)

Command	Query	Options and Query Returns
:WAVeform:POINTs <wfm_points> (see page 1526)	:WAVeform:POINTs? (see page 1526)	<wfm_points> ::= {<#_points> <points_mode>} <#_points> ::= an integer between 100 and 10000000 <points_mode> ::= {NORMal MAXimum RAW}
:WAVeform:POINTs:MODE <points_mode> (see page 1528)	:WAVeform:POINTs:MODE ? (see page 1529)	<points_mode> ::= {NORMal MAXimum RAW}
n/a	:WAVeform:PREAmble? (see page 1530)	<preamble_block> ::= <format NR1>, <type NR1>, <points NR1>, <count NR1>, <xincrement NR3>, <xorigin NR3>, <xreference NR1>, <yincrement NR3>, <yorigin NR3>, <yreference NR1> <format> ::= an integer in NR1 format: <ul style="list-style-type: none">• 0 for BYTE format• 1 for WORD format• 2 for ASCii format <type> ::= an integer in NR1 format: <ul style="list-style-type: none">• 0 for NORMal type• 1 for PEAK detect type• 3 for AVERAge type• 4 for HRESolution type <count> ::= Average count, or 1 if PEAK detect type or NORMal; an integer in NR1 format
:WAVeform:SEGmented:A LL {{0 OFF} {1 ON}} (see page 1533)	:WAVeform:SEGmented:A LL? (see page 1533)	<setting> ::= {0 1}
n/a	:WAVeform:SEGmented:C OUNT? (see page 1534)	<count> ::= an integer from 2 to 1000 in NR1 format
n/a	:WAVeform:SEGmented:T TAG? (see page 1535)	<time_tag> ::= in NR3 format
n/a	:WAVeform:SEGmented:X LISt? <xlist_type> (see page 1536)	<xlist_type> ::= {RELXorigin ABSXorigin TTAG} <return_value> ::= X-info for all segments

Table 79 :WAVeform Commands Summary (continued)

Command	Query	Options and Query Returns
:WAVeform:SOURce <source> (see page 1537)	:WAVeform:SOURce? (see page 1537)	<source> ::= {CHANnel<n> FUNction<m> MATH<m> SBUS} for DSO models <source> ::= {CHANnel<n> POD{1 2} BUS{1 2} FUNction<m> MATH<m> SBUS} for MSO models <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format
:WAVeform:SOURce:SUBS ource <subsource> (see page 1541)	:WAVeform:SOURce:SUBS ource? (see page 1541)	<subsource> ::= {{SUB0 RX MOSI} {SUB1 TX MISO}}
n/a	:WAVeform:TYPE? (see page 1542)	<return_mode> ::= {NORM PEAK AVER HRES}
:WAVeform:UNSigned {0 OFF} {1 ON} (see page 1543)	:WAVeform:UNSigned? (see page 1543)	{0 1}
:WAVeform:VIEW <view> (see page 1544)	:WAVeform:VIEW? (see page 1544)	<view> ::= {MAIN}
n/a	:WAVeform:XINCrement? (see page 1545)	<return_value> ::= x-increment in the current preamble in NR3 format
n/a	:WAVeform:XORigin? (see page 1546)	<return_value> ::= x-origin value in the current preamble in NR3 format
n/a	:WAVeform:XREFerence? (see page 1547)	<return_value> ::= 0 (x-reference value in the current preamble in NR1 format)
n/a	:WAVeform:YINCrement? (see page 1548)	<return_value> ::= y-increment value in the current preamble in NR3 format
n/a	:WAVeform:YORigin? (see page 1549)	<return_value> ::= y-origin in the current preamble in NR3 format
n/a	:WAVeform:YREFerence? (see page 1550)	<return_value> ::= y-reference value in the current preamble in NR1 format

Table 80 :WGEN<w> Commands Summary

Command	Query	Options and Query Returns
:WGEN<w>:ARbitrary:BYTeorder <order> (see page 1556)	:WGEN<w>:ARbitrary:BYTeorder? (see page 1556)	<order> ::= {MSBFirst LSBFirst} <w> ::= 1 to (# WaveGen outputs) in NR1 format
:WGEN<w>:ARbitrary:DATA {<binary> <value>, <value> ...} (see page 1557)	n/a	<binary> ::= floating point values between -1.0 to +1.0 in IEEE 488.2 binary block format <value> ::= floating point values between -1.0 to +1.0 in comma-separated format <w> ::= 1 to (# WaveGen outputs) in NR1 format
n/a	:WGEN<w>:ARbitrary:DATA:ATTRibute:POINTs? (see page 1560)	<points> ::= number of points in NR1 format <w> ::= 1 to (# WaveGen outputs) in NR1 format
:WGEN<w>:ARbitrary:DATA:CLear (see page 1561)	n/a	<w> ::= 1 to (# WaveGen outputs) in NR1 format
:WGEN<w>:ARbitrary:DATA:DAC {<binary> <value>, <value> ...} (see page 1562)	n/a	<binary> ::= decimal 16-bit integer values between -512 to +511 in IEEE 488.2 binary block format <value> ::= decimal integer values between -512 to +511 in comma-separated NR1 format <w> ::= 1 to (# WaveGen outputs) in NR1 format
:WGEN<w>:ARbitrary:INTerpolate {{0 OFF} {1 ON}} (see page 1563)	:WGEN<w>:ARbitrary:INTerpolate? (see page 1563)	{0 1} <w> ::= 1 to (# WaveGen outputs) in NR1 format

Table 80 :WGEN<w> Commands Summary (continued)

Command	Query	Options and Query Returns
:WGEN<w>:ARbitrary:STORe <source> (see page 1564)	n/a	<source> ::= {CHANnel<n> WMemory<r> FUNCTION<m> MATH<m>} <n> ::= 1 to (# analog channels) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <w> ::= 1 to (# WaveGen outputs) in NR1 format
:WGEN<w>:FREQuency <frequency> (see page 1565)	:WGEN<w>:FREQuency? (see page 1565)	<frequency> ::= frequency in Hz in NR3 format <w> ::= 1 to (# WaveGen outputs) in NR1 format
:WGEN<w>:FUNCTION <signal> (see page 1566)	:WGEN<w>:FUNCTION? (see page 1569)	<signal> ::= {SINusoid SQUare RAMP PULSe NOISe DC SINC EXPRise EXPFall CARDiac GAUSSian ARBitary} <w> ::= 1 to (# WaveGen outputs) in NR1 format
:WGEN<w>:FUNCTION:PULSe:WIDTh <width> (see page 1570)	:WGEN<w>:FUNCTION:PULSe:WIDTh? (see page 1570)	<width> ::= pulse width in seconds in NR3 format <w> ::= 1 to (# WaveGen outputs) in NR1 format
:WGEN<w>:FUNCTION:RAMP:SYMMetry <percent> (see page 1571)	:WGEN<w>:FUNCTION:RAMP:SYMMetry? (see page 1571)	<percent> ::= symmetry percentage from 0% to 100% in NR1 format <w> ::= 1 to (# WaveGen outputs) in NR1 format
:WGEN<w>:FUNCTION:SQUare:DCYCLE <percent> (see page 1572)	:WGEN<w>:FUNCTION:SQUare:DCYCLE? (see page 1572)	<percent> ::= duty cycle percentage from 20% to 80% in NR1 format <w> ::= 1 to (# WaveGen outputs) in NR1 format
:WGEN<w>:MODulation:AM:DEPTh <percent> (see page 1573)	:WGEN<w>:MODulation:AM:DEPTh? (see page 1573)	<percent> ::= AM depth percentage from 0% to 100% in NR1 format <w> ::= 1 in NR1 format

Table 80 :WGEN<w> Commands Summary (continued)

Command	Query	Options and Query Returns
:WGEN<w>:MODulation:AM:FREQuency <frequency> (see page 1574)	:WGEN<w>:MODulation:AM:FREQuency? (see page 1574)	<frequency> ::= modulating waveform frequency in Hz in NR3 format <w> ::= 1 in NR1 format
:WGEN<w>:MODulation:FM:DEVIation <frequency> (see page 1575)	:WGEN<w>:MODulation:FM:DEVIation? (see page 1575)	<frequency> ::= frequency deviation in Hz in NR3 format <w> ::= 1 in NR1 format
:WGEN<w>:MODulation:FM:FREQuency <frequency> (see page 1576)	:WGEN<w>:MODulation:FM:FREQuency? (see page 1576)	<frequency> ::= modulating waveform frequency in Hz in NR3 format <w> ::= 1 in NR1 format
:WGEN<w>:MODulation:FSKey:FREQuency <percent> (see page 1577)	:WGEN<w>:MODulation:FSKey:FREQuency? (see page 1577)	<frequency> ::= hop frequency in Hz in NR3 format <w> ::= 1 in NR1 format
:WGEN<w>:MODulation:FSKey:RATE <rate> (see page 1578)	:WGEN<w>:MODulation:FSKey:RATE? (see page 1578)	<rate> ::= FSK modulation rate in Hz in NR3 format <w> ::= 1 in NR1 format
:WGEN<w>:MODulation:FUNction <shape> (see page 1579)	:WGEN<w>:MODulation:FUNction? (see page 1579)	<shape> ::= {SINusoid SQUARE RAMP} <w> ::= 1 in NR1 format
:WGEN<w>:MODulation:FUNction:RAMP:SYMMetry <percent> (see page 1580)	:WGEN<w>:MODulation:FUNction:RAMP:SYMMetry? (see page 1580)	<percent> ::= symmetry percentage from 0% to 100% in NR1 format <w> ::= 1 in NR1 format
:WGEN<w>:MODulation:NOISE <percent> (see page 1581)	:WGEN<w>:MODulation:NOISE? (see page 1581)	<percent> ::= 0 to 100 <w> ::= 1 in NR1 format
:WGEN<w>:MODulation:STATe {{0 OFF} {1 ON}} (see page 1582)	:WGEN<w>:MODulation:STATe? (see page 1582)	{0 1} <w> ::= 1 in NR1 format
:WGEN<w>:MODulation:TYPE <type> (see page 1583)	:WGEN<w>:MODulation:TYPE? (see page 1583)	<type> ::= {AM FM FSK} <w> ::= 1 in NR1 format
:WGEN<w>:OUTPut {{0 OFF} {1 ON}} (see page 1585)	:WGEN<w>:OUTPut? (see page 1585)	{0 1} <w> ::= 1 to (# WaveGen outputs) in NR1 format

Table 80 :WGEN<w> Commands Summary (continued)

Command	Query	Options and Query Returns
:WGEN<w>:OUTPut:LOAD <impedance> (see page 1586)	:WGEN<w>:OUTPut:LOAD? (see page 1586)	<impedance> ::= {ONEMeg FIFTy} <w> ::= 1 to (# WaveGen outputs) in NR1 format
:WGEN<w>:OUTPut:MODE <mode> (see page 1587)	:WGEN<w>:OUTPut:MODE? (see page 1587)	<mode> ::= {NORMal SINGLE}
:WGEN<w>:OUTPut:POLar ity <polarity> (see page 1588)	:WGEN<w>:OUTPut:POLar ity? (see page 1588)	<polarity> ::= {NORMal INVerted} <w> ::= 1 to (# WaveGen outputs) in NR1 format
:WGEN<w>:OUTPut:SINGl e (see page 1589)	n/a	n/a
:WGEN<w>:PERiod <period> (see page 1590)	:WGEN<w>:PERiod? (see page 1590)	<period> ::= period in seconds in NR3 format <w> ::= 1 to (# WaveGen outputs) in NR1 format
:WGEN<w>:RST (see page 1591)	n/a	<w> ::= 1 to (# WaveGen outputs) in NR1 format
:WGEN<w>:TRACk {{0 OFF} {1 ON}} (see page 1592)	:WGEN<w>:TRACk? (see page 1592)	{0 1} <w> ::= 1 to (# WaveGen outputs) in NR1 format
:WGEN<w>:TRACk:AMPLit ude {{0 OFF} {1 ON}} (see page 1593)	:WGEN<w>:TRACk:AMPLit ude? (see page 1593)	{0 1} <w> ::= 1 to (# WaveGen outputs) in NR1 format
:WGEN<w>:TRACk:CSIGNa l (see page 1594)	n/a	<w> ::= 1 to (# WaveGen outputs) in NR1 format
:WGEN<w>:TRACk:FREQue ncy {{0 OFF} {1 ON}} (see page 1595)	:WGEN<w>:TRACk:FREQue ncy? (see page 1595)	{0 1} <w> ::= 1 to (# WaveGen outputs) in NR1 format
:WGEN<w>:TRACk:PHASe <phase> (see page 1596)	:WGEN<w>:TRACk:PHASe? (see page 1596)	<w> ::= 1 to (# WaveGen outputs) in NR1 format <phase> ::= -360 to +360 in NR1 format
:WGEN<w>:VOLTag <amplitude> (see page 1597)	:WGEN<w>:VOLTag (see page 1597)	<amplitude> ::= amplitude in volts in NR3 format <w> ::= 1 to (# WaveGen outputs) in NR1 format

Table 80 :WGEN<w> Commands Summary (continued)

Command	Query	Options and Query Returns
:WGEN<w>:VOLTage:HIGH <high> (see page 1598)	:WGEN<w>:VOLTage:HIGH ? (see page 1598)	<high> ::= high-level voltage in volts, in NR3 format <w> ::= 1 to (# WaveGen outputs) in NR1 format
:WGEN<w>:VOLTage:LOW <low> (see page 1599)	:WGEN<w>:VOLTage:LOW? (see page 1599)	<low> ::= low-level voltage in volts, in NR3 format <w> ::= 1 to (# WaveGen outputs) in NR1 format
:WGEN<w>:VOLTage:OFFS et <offset> (see page 1600)	:WGEN<w>:VOLTage:OFFS et? (see page 1600)	<offset> ::= offset in volts in NR3 format <w> ::= 1 to (# WaveGen outputs) in NR1 format

Table 81 :WMEMemory<r> Commands Summary

Command	Query	Options and Query Returns
:WMEMemory<r>:CLEar (see page 1603)	n/a	<r> ::= 1 to (# ref waveforms) in NR1 format
:WMEMemory<r>:DISPlay {{0 OFF} {1 ON}} (see page 1604)	:WMEMemory<r>:DISPlay? (see page 1604)	<r> ::= 1 to (# ref waveforms) in NR1 format {0 1}
:WMEMemory<r>:LABel <string> (see page 1605)	:WMEMemory<r>:LABel? (see page 1605)	<r> ::= 1 to (# ref waveforms) in NR1 format <string> ::= any series of 10 or less ASCII characters enclosed in quotation marks
:WMEMemory<r>:SAVE <source> (see page 1606)	n/a	<r> ::= 1 to (# ref waveforms) in NR1 format <source> ::= {CHANnel<n> FUNCTION<m> MATH<m>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format NOTE: Math functions whose x-axis is not frequency can be saved as reference waveforms.

Table 81 :WMemory<r> Commands Summary (continued)

Command	Query	Options and Query Returns
:WMemory<r>:SKEW <skew> (see page 1607)	:WMemory<r>:SKEW? (see page 1607)	<r> ::= 1 to (# ref waveforms) in NR1 format <skew> ::= time in seconds in NR3 format
:WMemory<r>:YOFFset <offset>[suffix] (see page 1608)	:WMemory<r>:YOFFset? (see page 1608)	<r> ::= 1 to (# ref waveforms) in NR1 format <offset> ::= vertical offset value in NR3 format [suffix] ::= {V mV}
:WMemory<r>:YRANge <range> (see page 1609)	:WMemory<r>:YRANge? (see page 1609)	<r> ::= 1 to (# ref waveforms) in NR1 format <range> ::= vertical full-scale range value in NR3 format
:WMemory<r>:YSCale <scale> (see page 1610)	:WMemory<r>:YSCale? (see page 1610)	<r> ::= 1 to (# ref waveforms) in NR1 format <scale> ::= vertical units per division value in NR3 format

Syntax Elements

- **"Number Format"** on page 225
- **"<NL> (Line Terminator)"** on page 225
- **"[] (Optional Syntax Terms)"** on page 225
- **"{ } (Braces)"** on page 225
- **"::= (Defined As)"** on page 225
- **"< > (Angle Brackets)"** on page 226
- **"... (Ellipsis)"** on page 226
- **"n,...,p (Value Ranges)"** on page 226
- **"d (Digits)"** on page 226
- **"Quoted ASCII String"** on page 226
- **"Definite-Length Block Response Data"** on page 226

Number Format

NR1 specifies integer data.

NR3 specifies exponential data in floating point format (for example, -1.0E-3).

<NL> (Line Terminator)

<NL> = new line or linefeed (ASCII decimal 10).

The line terminator, or a leading colon, will send the parser to the "root" of the command tree.

[] (Optional Syntax Terms)

Items enclosed in square brackets, [], are optional.

{ } (Braces)

When several items are enclosed by braces, { }, only one of these elements may be selected. Vertical line (|) indicates "or". For example, {ON | OFF} indicates that only ON or OFF may be selected, not both.

::= (Defined As)

::= means "defined as".

For example, <A> ::= indicates that <A> can be replaced by in any statement containing <A>.

< > (Angle Brackets)

< > Angle brackets enclose words or characters that symbolize a program code parameter or an interface command.

... (Ellipsis)

... An ellipsis (trailing dots) indicates that the preceding element may be repeated one or more times.

n,...,p (Value Ranges)

n,...,p ::= all integers between n and p inclusive.

d (Digits)

d ::= A single ASCII numeric character 0 - 9.

Quoted ASCII String

A quoted ASCII string is a string delimited by either double quotes (") or single quotes ('). Some command parameters require a quoted ASCII string. For example, when using the Keysight VISA COM library in Visual Basic, the command:

```
myScope.WriteString ":CHANNEL1:LABEL 'One' "
```

has a quoted ASCII string of:

```
'One'
```

In order to read quoted ASCII strings from query return values, some programming languages require special handling or syntax.

Definite-Length Block Response Data

Definite-length block response data allows any type of device-dependent data to be transmitted over the system interface as a series of 8-bit binary data bytes. This is particularly useful for sending large quantities of data or 8-bit extended ASCII codes. This syntax is a pound sign (#) followed by a non-zero digit representing the number of digits in the decimal integer. After the non-zero digit is the decimal integer that states the number of 8-bit data bytes being sent. This is followed by the actual data.

For example, for transmitting 1000 bytes of data, the syntax would be

```
#800001000<1000 bytes of data> <NL>
```

8 is the number of digits that follow

00001000 is the number of bytes to be transmitted

<1000 bytes of data> is the actual data

6 Common (*) Commands

Commands defined by IEEE 488.2 standard that are common to all instruments. See "[Introduction to Common \(*\) Commands](#)" on page 233.

Table 82 Common (*) Commands Summary

Command	Query	Options and Query Returns																																				
*CLS (see page 235)	n/a	n/a																																				
*ESE <mask> (see page 236)	*ESE? (see page 236)	<p><mask> ::= 0 to 255; an integer in NR1 format:</p> <table border="1"> <thead> <tr> <th>Bit</th> <th>Weight</th> <th>Name</th> <th>Enables</th> </tr> </thead> <tbody> <tr> <td>7</td> <td>128</td> <td>PON</td> <td>Power On</td> </tr> <tr> <td>6</td> <td>64</td> <td>URQ</td> <td>User Request</td> </tr> <tr> <td>5</td> <td>32</td> <td>CME</td> <td>Command Error</td> </tr> <tr> <td>4</td> <td>16</td> <td>EXE</td> <td>Execution Error</td> </tr> <tr> <td>3</td> <td>8</td> <td>DDE</td> <td>Dev. Dependent Error</td> </tr> <tr> <td>2</td> <td>4</td> <td>QYE</td> <td>Query Error</td> </tr> <tr> <td>1</td> <td>2</td> <td>RQL</td> <td>Request Control</td> </tr> <tr> <td>0</td> <td>1</td> <td>OPC</td> <td>Operation Complete</td> </tr> </tbody> </table>	Bit	Weight	Name	Enables	7	128	PON	Power On	6	64	URQ	User Request	5	32	CME	Command Error	4	16	EXE	Execution Error	3	8	DDE	Dev. Dependent Error	2	4	QYE	Query Error	1	2	RQL	Request Control	0	1	OPC	Operation Complete
Bit	Weight	Name	Enables																																			
7	128	PON	Power On																																			
6	64	URQ	User Request																																			
5	32	CME	Command Error																																			
4	16	EXE	Execution Error																																			
3	8	DDE	Dev. Dependent Error																																			
2	4	QYE	Query Error																																			
1	2	RQL	Request Control																																			
0	1	OPC	Operation Complete																																			
n/a	*ESR? (see page 238)	<status> ::= 0 to 255; an integer in NR1 format																																				
n/a	*IDN? (see page 238)	<p>AGILENT TECHNOLOGIES,<model>,<serial number>,X.XX.XX</p> <p><model> ::= the model number of the instrument</p> <p><serial number> ::= the serial number of the instrument</p> <p><X.XX.XX> ::= the software revision of the instrument</p>																																				
n/a	*LRN? (see page 241)	<learn_string> ::= current instrument setup as a block of data in IEEE 488.2 # format																																				

Table 82 Common (*) Commands Summary (continued)

Command	Query	Options and Query Returns
*OPC (see page 242)	*OPC? (see page 242)	ASCII "1" is placed in the output queue when all pending device operations have completed.
n/a	*OPT? (see page 243)	<pre> <return_value> ::= 0,0,<license info> <license info> ::= <All field>, <reserved>, <reserved>, <MSO>, <reserved>, <Memory>, <Low Speed Serial>, <Automotive Serial>, <FlexRay Serial>, <Frequency Response Analysis>, <Power Measurements>, <RS-232/UART Serial>, <Segmented Memory>, <Mask Test>, <reserved>, <Bandwidth>, <reserved>, <reserved>, <reserved>, <reserved>, <reserved>, <reserved>, <I2S Serial>, <reserved>, <Educator's Kit>, <Waveform Generator>, <MIL-1553/ARINC 429 Serial>, <Extended Video>, <Advanced Math>, <reserved>, <reserved>, <reserved>, <reserved>, <Digital Voltmeter/Counter>, <reserved>, <reserved>, <USB 2.0 Low/Full Speed>, <USB 2.0 High Speed>, <USB 2.0 Signal Quality Analysis >, <Remote Command Logging>, <reserved>, <SENT Serial>, <CAN FD Serial>, <CXPI Serial>, <reserved>, <Jitter Analysis>, <reserved>, <reserved>, <Manchester/NRZ Serial>, <USB PD Serial>, <reserved>, <Automotive Software>, <General Purpose Software>, <Aerospace Software>, <Power Supply Test Software>, <USB Test Software>, <reserved>, <Software Bundle> </pre>

Table 82 Common (*) Commands Summary (continued)

Command	Query	Options and Query Returns
n/a	*OPT? (see page 243) (cont'd)	<p><All field> ::= {0 All}</p> <p><reserved> ::= 0</p> <p><MSO> ::= {0 MSO}</p> <p><Memory> ::= {0 MEMUP}</p> <p><Low Speed Serial> ::= {0 EMBD}</p> <p><Automotive Serial> ::= {0 AUTO}</p> <p><FlexRay Serial> ::= {0 FLEX}</p> <p><Frequency Response Analysis> ::= {0 FRA}</p> <p><Power Measurements> ::= {0 PWR}</p> <p><RS-232/UART Serial> ::= {0 COMP}</p> <p><Mask Test> ::= {0 MASK}</p> <p><Bandwidth> ::= {0 BW20 BW50}</p> <p><I2S Serial> ::= {0 AUDIO}</p> <p><Educator's Kit> ::= {0 EDK}</p> <p><Waveform Generator> ::= {0 WAVEGEN}</p> <p><MIL-1553/ARINC 429 Serial> ::= {0 AERO}</p> <p><Extended Video> ::= {0 VID}</p> <p><Digital Voltmeter> ::= {0 DVM}</p> <p><USB 2.0 Low/Full Speed> ::= {0 USF}</p> <p><USB 2.0 High Speed> ::= {0 U2H}</p> <p><USB 2.0 Signal Quality Analysis> ::= {0 USBSQ}</p> <p><Remote Command Logging> ::= {0 RML}</p>

Table 82 Common (*) Commands Summary (continued)

Command	Query	Options and Query Returns
n/a	*OPT? (see page 243) (cont'd)	<pre> <SENT Serial> ::= {0 SENSOR} <CAN FD Serial> ::= {0 CANFD} <CXPI Serial> ::= {0 CXPI} <Jitter Analysis> ::= {0 JITTER} <Manchester/NRZ Serial> ::= {0 NRZ} <USB PD Serial> ::= {0 USBPD} <Automotive Software> ::= {0 D6000AUTA} <General Purpose Software> ::= {0 D6000GENA} <Aerospace Software> ::= {0 D6000AERA} <Power Supply Test Software> ::= {0 D6000PWRA} <USB Test Software> ::= {0 D6000USBA} <Software Bundle> ::= {0 D6000BDLA} </pre>
*RCL <value> (see page 245)	n/a	<value> ::= {0 1 4 5 6 7 8 9}
*RST (see page 246)	n/a	See *RST (Reset) (see page 246)
*SAV <value> (see page 249)	n/a	<value> ::= {0 1 4 5 6 7 8 9}
*SRE <mask> (see page 250)	*SRE? (see page 251)	<pre> <mask> ::= sum of all bits that are set, 0 to 255; an integer in NR1 format. <mask> ::= following values: Bit Weight Name Enables ----- 7 128 OPER Operation Status Reg 6 64 ---- (Not used.) 5 32 ESB Event Status Bit 4 16 MAV Message Available 3 8 ---- (Not used.) 2 4 MSG Message 1 2 USR User 0 1 TRG Trigger </pre>

Table 82 Common (*) Commands Summary (continued)

Command	Query	Options and Query Returns
n/a	*STB? (see page 252)	<p><value> ::= 0 to 255; an integer in NR1 format, as shown in the following:</p> <pre> Bit Weight Name "1" Indicates ----- 7 128 OPER Operation status condition occurred. 6 64 RQS/ Instrument is MSS requesting service. 5 32 ESB Enabled event status condition occurred. 4 16 MAV Message available. 3 8 ---- (Not used.) 2 4 MSG Message displayed. 1 2 USR User event condition occurred. 0 1 TRG A trigger occurred. </pre>
*TRG (see page 254)	n/a	n/a
n/a	*TST? (see page 255)	<result> ::= 0 or non-zero value; an integer in NR1 format
*WAI (see page 256)	n/a	n/a

Introduction to Common (*) Commands

The common commands are defined by the IEEE 488.2 standard. They are implemented by all instruments that comply with the IEEE 488.2 standard. They provide some of the basic instrument functions, such as instrument identification and reset, reading the instrument setup, and determining how status is read and cleared.

Common commands can be received and processed by the instrument whether they are sent over the interface as separate program messages or within other program messages. If an instrument subsystem has been selected and a common command is received by the instrument, the instrument remains in the selected subsystem. For example, if the program message ":ACQUIRE:TYPE AVERAGE; *CLS; COUNT 256" is received by the instrument, the instrument sets the acquire type, then clears the status information and sets the average count.

In contrast, if a root level command or some other subsystem command is within the program message, you must re-enter the original subsystem after the command. For example, the program message ":ACQUIRE:TYPE AVERAGE; :AUTOSCALE; :ACQUIRE:COUNT 256" sets the acquire type, completes the autoscale, then sets the acquire count. In this example, :ACQUIRE must be sent again after the :AUTOSCALE command in order to re-enter the ACQUIRE subsystem and set the count.

NOTE

Each of the status registers has an enable (mask) register. By setting the bits in the enable register, you can select the status information you want to use.

*CLS (Clear Status)

C (see [page 1730](#))

Command Syntax

*CLS

The *CLS common command clears the status data structures, the device-defined error queue, and the Request-for-OPC flag.

NOTE

If the *CLS command immediately follows a program message terminator, the output queue and the MAV (message available) bit are cleared.

- See Also
- ["Introduction to Common \(*\) Commands"](#) on page 233
 - ["*STB \(Read Status Byte\)"](#) on page 252
 - ["*ESE \(Standard Event Status Enable\)"](#) on page 236
 - ["*ESR \(Standard Event Status Register\)"](#) on page 238
 - ["*SRE \(Service Request Enable\)"](#) on page 250
 - [":SYSTem:ERRor"](#) on page 1389

*ESE (Standard Event Status Enable)

C (see [page 1730](#))

Command Syntax *ESE <mask_argument>

<mask_argument> ::= integer from 0 to 255

The *ESE common command sets the bits in the Standard Event Status Enable Register. The Standard Event Status Enable Register contains a mask value for the bits to be enabled in the Standard Event Status Register. A "1" in the Standard Event Status Enable Register enables the corresponding bit in the Standard Event Status Register. A zero disables the bit.




Table 83 Standard Event Status Enable (ESE)

Bit	Name	Description	When Set (1 = High = True), Enables:
7	PON	Power On	Event when an OFF to ON transition occurs.
6	URQ	User Request	Event when a front-panel key is pressed.
5	CME	Command Error	Event when a command error is detected.
4	EXE	Execution Error	Event when an execution error is detected.
3	DDE	Device Dependent Error	Event when a device-dependent error is detected.
2	QYE	Query Error	Event when a query error is detected.
1	RQL	Request Control	Event when the device is requesting control. (Not used.)
0	OPC	Operation Complete	Event when an operation is complete.

Query Syntax *ESE?

The *ESE? query returns the current contents of the Standard Event Status Enable Register.

Return Format <mask_argument><NL>

<mask_argument> ::= 0,...,255; an integer in NR1 format.

- See Also**
- ["Introduction to Common \(*\) Commands"](#) on page 233
 - ["*ESR \(Standard Event Status Register\)"](#) on page 238
 - ["*OPC \(Operation Complete\)"](#) on page 242
 - ["*CLS \(Clear Status\)"](#) on page 235

*ESR (Standard Event Status Register)

C (see [page 1730](#))

Query Syntax *ESR?

The *ESR? query returns the contents of the Standard Event Status Register. When you read the Event Status Register, the value returned is the total bit weights of all of the bits that are high at the time you read the byte. Reading the register clears the Event Status Register.

The following table shows bit weight, name, and condition for each bit.




Table 84 Standard Event Status Register (ESR)

Bit	Name	Description	When Set (1 = High = True), Indicates:
7	PON	Power On	An OFF to ON transition has occurred.
6	URQ	User Request	A front-panel key has been pressed.
5	CME	Command Error	A command error has been detected.
4	EXE	Execution Error	An execution error has been detected.
3	DDE	Device Dependent Error	A device-dependent error has been detected.
2	QYE	Query Error	A query error has been detected.
1	RQL	Request Control	The device is requesting control. (Not used.)
0	OPC	Operation Complete	Operation is complete.

Return Format <status><NL>

<status> ::= 0,..,255; an integer in NR1 format.

NOTE

Reading the Standard Event Status Register clears it. High or 1 indicates the bit is true.

- See Also
- ["Introduction to Common \(*\) Commands"](#) on page 233
 - ["*ESE \(Standard Event Status Enable\)"](#) on page 236
 - ["*OPC \(Operation Complete\)"](#) on page 242
 - ["*CLS \(Clear Status\)"](#) on page 235
 - [":SYSTem:ERRor"](#) on page 1389

*IDN (Identification Number)

C (see [page 1730](#))

Query Syntax *IDN?

The *IDN? query identifies the instrument type and software version.

Return Format

```
<manufacturer_string>,<model>,<serial_number>,X.XX.XX <NL>
```

```
<manufacturer_string> ::= KEYSIGHT TECHNOLOGIES
```

```
<model> ::= the model number of the instrument
```

```
<serial_number> ::= the serial number of the instrument
```

```
X.XX.XX ::= the software revision of the instrument
```

- See Also**
- ["Introduction to Common \(*\) Commands"](#) on page 233
 - ["*OPT \(Option Identification\)"](#) on page 243
 - ["::SYSTem:PERSONa\[:MANUFACTURER\]"](#) on page 1391
 - ["::SYSTem:PERSONa\[:MANUFACTURER\]:DEFAULT"](#) on page 1392

*LRN (Learn Device Setup)

C (see [page 1730](#))

Query Syntax

*LRN?

The *LRN? query result contains the current state of the instrument. This query is similar to the :SYSTem:SETup? (see [page 1406](#)) query, except that it contains ":SYST:SET " before the binary block data. The query result is a valid command that can be used to restore instrument settings at a later time.

Return Format

<learn_string><NL>

<learn_string> ::= :SYST:SET <setup_data>

<setup_data> ::= binary block data in IEEE 488.2 # format

<learn string> specifies the current instrument setup. The block size is subject to change with different firmware revisions.

NOTE

The *LRN? query return format has changed from previous Keysight oscilloscopes to match the IEEE 488.2 specification which says that the query result must contain ":SYST:SET " before the binary block data.

- See Also
- ["Introduction to Common \(*\) Commands"](#) on page 233
 - ["*RCL \(Recall\)"](#) on page 245
 - ["*SAV \(Save\)"](#) on page 249
 - [":SYSTem:SETup"](#) on page 1406

*OPC (Operation Complete)

C (see [page 1730](#))

Command Syntax

*OPC

The *OPC command sets the operation complete bit in the Standard Event Status Register when all pending device operations have finished.

You can use the *ESR? query to look at the OPC bit (bit 0) in the Standard Event Status Register to determine when an operation is complete.

NOTE

The front-panel graphical user interface can disable most of the remote interface, including the *OPC syntax, in certain situations. Bit 4 in the Operation Status Condition Register shows whether the remote user interface is enabled or disabled. For more information, see [":OPERRegister:CONDition \(Operation Status Condition Register\)"](#) on page 282.

Query Syntax

*OPC?

The *OPC? query places an ASCII "1" in the output queue when all pending device operations have completed. The interface hangs until this query returns.

The *OPC? query can be used between overlapped commands to make sure one is complete before the next one begins. The *OPC? query can also be used to pause a controller program until an operation is complete.

Return Format

```
<complete><NL>
```

```
<complete> ::= 1
```

See Also

- ["Introduction to Common \(*\) Commands"](#) on page 233
- ["*ESE \(Standard Event Status Enable\)"](#) on page 236
- ["*ESR \(Standard Event Status Register\)"](#) on page 238
- ["*CLS \(Clear Status\)"](#) on page 235
- [":OPERRegister:CONDition \(Operation Status Condition Register\)"](#) on page 282
- [":OPERRegister\[:EVENT\] \(Operation Status Event Register\)"](#) on page 285
- [Chapter 4, "Sequential \(Blocking\) vs. Overlapped Commands,"](#) starting on page 87
- ["Synchronization with an Averaging Acquisition"](#) on page 1716
- ["Set Up the Oscilloscope"](#) on page 1710
- ["Example: Blocking and Polling Synchronization"](#) on page 1718
- ["Example: Waiting for IO Operation Complete"](#) on page 1706

*OPT (Option Identification)

C (see [page 1730](#))

Query Syntax *OPT?

The *OPT? query reports the options installed in the instrument. This query returns a string that identifies the module and its software revision level.

Return Format 0,0,<license info>

```

<license info> ::= <All field>, <reserved>, <reserved>, <MSO>,
  <reserved>, <Memory>, <Low Speed Serial>,
  <Automotive Serial>, <FlexRay Serial>, <Frequency Response Analysis>,
  <Power Measurements>, <RS-232/UART Serial>, <Segmented Memory>,
  <Mask Test>, <reserved>, <Bandwidth>, <reserved>, <reserved>,
  <reserved>, <reserved>, <reserved>, <reserved>, <I2S Serial>,
  <reserved>, <Educator's Kit>, <Waveform Generator>,
  <MIL-1553/ARINC 429 Serial>, <Extended Video>, <Advanced Math>,
  <reserved>, <reserved>, <reserved>, <reserved>,
  <Digital Voltmeter/Counter>, <reserved>, <reserved>,
  <USB 2.0 Low/Full Speed>, <USB 2.0 High Speed>,
  <USB 2.0 Signal Quality Analysis>, <Remote Command Logging>,
  <reserved>, <SENT Serial>, <CAN FD Serial>, <CXPI Serial>,
  <reserved>, <Jitter Analysis>, <reserved>, <reserved>,
  <Manchester/NRZ Serial>, <USB PD Serial>, <reserved>,
  <Automotive Software>, <General Purpose Software>,
  <Aerospace Software>, <Power Supply Test Software>,
  <USB Test Software>, <reserved>,
  <reserved>,
  <Software Bundle>

```

<All field> ::= {0 | All}

<reserved> ::= 0

<MSO> ::= {0 | MSO}

<Memory> ::= {0 | MEMUP}

<Low Speed Serial> ::= {0 | EMBD}

<Automotive Serial> ::= {0 | AUTO}

<FlexRay Serial> ::= {0 | FLEX}

<Frequency Response Analysis> ::= {0 | FRA}

<Power Measurements> ::= {0 | PWR}

<RS-232/UART Serial> ::= {0 | COMP}

<Segmented Memory> ::= {0 | SGM}

<Mask Test> ::= {0 | MASK}

<Bandwidth> ::= {0 | BW50}

<I2S Serial> ::= {0 | AUDIO}

<Educator's Kit> ::= {0 | EDK}

*RCL (Recall)

C (see [page 1730](#))

Command Syntax *RCL <value>

<value> ::= {0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9}

The *RCL command restores the state of the instrument from the specified save/recall register.

- See Also**
- ["Introduction to Common \(*\) Commands"](#) on page 233
 - ["*SAV \(Save\)"](#) on page 249

*RST (Reset)

C (see [page 1730](#))

Command Syntax *RST

The *RST command places the instrument in a known state. This is the same as pressing **[Save/Recall] > Default/Erase > Factory Default** on the front panel.

When you perform a factory default setup, there are no user settings that remain unchanged. To perform the equivalent of the front panel's **[Default Setup]** key, where some user settings (like preferences) remain unchanged, use the :SYSTem:PRESet command.

Reset conditions are:

Acquire Menu	
Mode	Normal
Averaging	Off
# Averages	8

Analog Channel Menu	
Channel 1	On
Channel 2	Off
Volts/division	5.00 V
Offset	0.00
Coupling	DC
Probe attenuation	AutoProbe (if AutoProbe is connected), otherwise 1.0:1
Vernier	Off
Invert	Off
BW limit	Off
Impedance	1 M Ohm
Units	Volts
Skew	0

Cursor Menu	
Source	Channel 1

Digital Channel Menu (MSO models only)	
Channel 0 - 15	Off
Labels	Off
Threshold	TTL (1.4 V)

Display Menu	
Persistence	Off
Grid	20%

Quick Meas Menu	
Source	Channel 1

Run Control	
	Scope is running

Time Base Menu	
Main time/division	100 us
Main time base delay	0.00 s
Delay time/division	500 ns
Delay time base delay	0.00 s
Reference	center
Mode	main
Vernier	Off

Trigger Menu	
Type	Edge
Mode	Auto
Coupling	dc
Source	Channel 1
Level	0.0 V
Slope	Positive

Trigger Menu	
HF Reject and noise reject	Off
Holdoff	40 ns
External probe attenuation	10:1
External Units	Volts
External Impedance	1 M Ohm (cannot be changed)

- See Also
- ["Introduction to Common \(*\) Commands"](#) on page 233
 - [":SYSTem:PRESet"](#) on page 1395

Example Code

```
' RESET - This command puts the oscilloscope into a known state.
' This statement is very important for programs to work as expected.
' Most of the following initialization commands are initialized by
' *RST. It is not necessary to reinitialize them unless the default
' setting is not suitable for your application.
myScope.WriteString "*RST" ' Reset the oscilloscope to the defaults.
```

See complete example programs at: [Chapter 50](#), "Programming Examples," starting on page 1739

*SAV (Save)

C (see [page 1730](#))

Command Syntax *SAV <value>

<value> ::= {0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9}

The *SAV command stores the current state of the instrument in a save register. The data parameter specifies the register where the data will be saved.

- See Also**
- ["Introduction to Common \(*\) Commands"](#) on page 233
 - ["*RCL \(Recall\)"](#) on page 245

*SRE (Service Request Enable)

C (see [page 1730](#))

Command Syntax *SRE <mask>

<mask> ::= integer with values defined in the following table.

The *SRE command sets the bits in the Service Request Enable Register. The Service Request Enable Register contains a mask value for the bits to be enabled in the Status Byte Register. A one in the Service Request Enable Register enables the corresponding bit in the Status Byte Register. A zero disables the bit.




Table 85 Service Request Enable Register (SRE)

Bit	Name	Description	When Set (1 = High = True), Enables:
7	OPER	Operation Status Register	Interrupts when enabled conditions in the Operation Status Register (OPER) occur.
6	---	---	(Not used.)
5	ESB	Event Status Bit	Interrupts when enabled conditions in the Standard Event Status Register (ESR) occur.
4	MAV	Message Available	Interrupts when messages are in the Output Queue.
3	---	---	(Not used.)
2	MSG	Message	Interrupts when an advisory has been displayed on the oscilloscope.
1	USR	User Event	Interrupts when enabled user event conditions occur.
0	TRG	Trigger	Interrupts when a trigger occurs.

Query Syntax *SRE?

The *SRE? query returns the current value of the Service Request Enable Register.

Return Format <mask><NL>

<mask> ::= sum of all bits that are set, 0,...,255;
an integer in NR1 format

- See Also**
- ["Introduction to Common \(*\) Commands"](#) on page 233
 - ["*STB \(Read Status Byte\)"](#) on page 252
 - ["*CLS \(Clear Status\)"](#) on page 235

*STB (Read Status Byte)

C (see [page 1730](#))

Query Syntax *STB?

The *STB? query returns the current value of the instrument's status byte. The MSS (Master Summary Status) bit is reported on bit 6 instead of the RQS (request service) bit. The MSS indicates whether or not the device has at least one reason for requesting service.

Return Format <value><NL>

<value> ::= 0,...,255; an integer in NR1 format




Table 86 Status Byte Register (STB)

Bit	Name	Description	When Set (1 = High = True), Indicates:
7	OPER	Operation Status Register	An enabled condition in the Operation Status Register (OPER) has occurred.
6	RQS	Request Service	When polled, that the device is requesting service.
	MSS	Master Summary Status	When read (by *STB?), whether the device has a reason for requesting service.
5	ESB	Event Status Bit	An enabled condition in the Standard Event Status Register (ESR) has occurred.
4	MAV	Message Available	There are messages in the Output Queue.
3	---	---	(Not used, always 0.)
2	MSG	Message	An advisory has been displayed on the oscilloscope.
1	USR	User Event	An enabled user event condition has occurred.
0	TRG	Trigger	A trigger has occurred.

NOTE

To read the instrument's status byte with RQS reported on bit 6, use the interface Serial Poll.

- See Also
- ["Introduction to Common \(*\) Commands"](#) on page 233
 - ["*SRE \(Service Request Enable\)"](#) on page 250

*TRG (Trigger)

C (see [page 1730](#))

Command Syntax

*TRG

The *TRG command has the same effect as the :DIGitize command with no parameters.

- See Also
- ["Introduction to Common \(*\) Commands"](#) on page 233
 - [":DIGitize"](#) on page 270
 - [":RUN"](#) on page 294
 - [":STOP"](#) on page 298

*TST (Self Test)

C (see [page 1730](#))

Query Syntax *TST?

The *TST? query performs a self-test on the instrument. The result of the test is placed in the output queue. A zero indicates the test passed and a non-zero indicates the test failed. If the test fails, refer to the troubleshooting section of the *Service Guide*.

Return Format <result><NL>

<result> ::= 0 or non-zero value; an integer in NR1 format

See Also • ["Introduction to Common \(*\) Commands"](#) on page 233

*WAI (Wait To Continue)

C (see [page 1730](#))

Command Syntax

*WAI

The *WAI command has no function in the oscilloscope, but is parsed for compatibility with other instruments.

See Also · ["Introduction to Common \(*\) Commands"](#) on page 233

7 Root (:) Commands

Control many of the basic functions of the oscilloscope and reside at the root level of the command tree. See "[Introduction to Root \(:\) Commands](#)" on page 260.

Table 87 Root (:) Commands Summary

Command	Query	Options and Query Returns
:ACTivity (see page 261)	:ACTivity? (see page 261)	<return value> ::= <edges>,<levels> <edges> ::= presence of edges (32-bit integer in NR1 format) <levels> ::= logical highs or lows (32-bit integer in NR1 format)
n/a	:AER? (see page 262)	{0 1}; an integer in NR1 format
:AUToscale [<source>[,...,<source>]] (see page 263)	n/a	<source> ::= CHANNEL<n> for DSO models <source> ::= {CHANNEL<n> DIGital<d> POD1 POD2} for MSO models <source> can be repeated up to 5 times <n> ::= 1 to (# analog channels) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format
:AUToscale:AMODE <value> (see page 265)	:AUToscale:AMODE? (see page 265)	<value> ::= {NORMAL CURRENT}}
:AUToscale:CHANnels <value> (see page 266)	:AUToscale:CHANnels? (see page 266)	<value> ::= {ALL DISPLAYed}}
:AUToscale:FDEBug {{0 OFF} {1 ON}} (see page 267)	:AUToscale:FDEBug? (see page 267)	{0 1}

Table 87 Root (:) Commands Summary (continued)

Command	Query	Options and Query Returns
:BLANK [<source>] (see page 268)	n/a	<p><source> ::= {CHANnel<n> FUNCTION<m> MATH<m> SBUS{1 2} WMemory<r>} for DSO models</p> <p><source> ::= {CHANnel<n> DIGital<d> POD{1 2} BUS{1 2} FUNCTION<m> MATH<m> SBUS{1 2} WMemory<r>} for MSO models</p> <p><n> ::= 1 to (# analog channels) in NR1 format</p> <p><d> ::= 0 to (# digital channels - 1) in NR1 format</p> <p><m> ::= 1 to (# math functions) in NR1 format</p> <p><r> ::= 1 to (# ref waveforms) in NR1 format</p>
:DIGitize [<source>[,...,<source>]] (see page 270)	n/a	<p><source> ::= {CHANnel<n> FUNCTION<m> MATH<m> SBUS{1 2}} for DSO models</p> <p><source> ::= {CHANnel<n> DIGital<d> POD{1 2} BUS{1 2} FUNCTION<m> MATH<m> SBUS{1 2}} for MSO models</p> <p><source> can be repeated up to 5 times</p> <p><n> ::= 1 to (# analog channels) in NR1 format</p> <p><d> ::= 0 to (# digital channels - 1) in NR1 format</p> <p><m> ::= 1 to (# math functions) in NR1 format</p>
:HWEenable <n> (see page 272)	:HWEenable? (see page 272)	<n> ::= 16-bit integer in NR1 format
n/a	:HWERegister:CONDition? (see page 274)	<n> ::= 16-bit integer in NR1 format
n/a	:HWERegister[:EVENT]? (see page 275)	<n> ::= 16-bit integer in NR1 format
:MTEenable <n> (see page 276)	:MTEenable? (see page 276)	<n> ::= 16-bit integer in NR1 format
n/a	:MTERegister[:EVENT]? (see page 278)	<n> ::= 16-bit integer in NR1 format

Table 87 Root (:) Commands Summary (continued)

Command	Query	Options and Query Returns
:OPEE <n> (see page 280)	:OPEE? (see page 281)	<n> ::= 15-bit integer in NR1 format
n/a	:OPERRegister:CONDition? (see page 282)	<n> ::= 15-bit integer in NR1 format
n/a	:OPERRegister[:EVENT]? (see page 285)	<n> ::= 15-bit integer in NR1 format
:OVLenable <mask> (see page 288)	:OVLenable? (see page 289)	<p><mask> ::= 16-bit integer in NR1 format as shown:</p> <pre> Bit Weight Input ----- 10 1024 Ext Trigger Fault 9 512 Channel 4 Fault 8 256 Channel 3 Fault 7 128 Channel 2 Fault 6 64 Channel 1 Fault 4 16 Ext Trigger OVL 3 8 Channel 4 OVL 2 4 Channel 3 OVL 1 2 Channel 2 OVL 0 1 Channel 1 OVL </pre>
n/a	:OVLRegister? (see page 290)	<value> ::= integer in NR1 format. See OVLenable for <value>
:PRINT [<options>] (see page 292)	n/a	<p><options> ::= [<print option>][, ..., <print option>]</p> <p><print option> ::= {COLor GRAYscale PRINter0 BMP8bit BMP PNG NOFactoRs FACToRs}</p> <p><print option> can be repeated up to 5 times.</p>
n/a	:RState? (see page 293)	n/a
:RUN (see page 294)	n/a	n/a
n/a	:SERial (see page 295)	<return value> ::= unquoted string containing serial number
:SINGLE (see page 296)	n/a	n/a

Table 87 Root (:) Commands Summary (continued)

Command	Query	Options and Query Returns
n/a	:STATus? <display> (see page 297)	{0 1} <display> ::= {CHANnel<n> DIGital<d> POD{1 2} BUS{1 2} FUNction<m> MATH<m> SBUS{1 2} WMEMory<r>} <n> ::= 1 to (# analog channels) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format
:STOP (see page 298)	n/a	n/a
n/a	:TER? (see page 299)	{0 1}
:VIEW <source> (see page 300)	n/a	<source> ::= {CHANnel<n> FUNction<m> MATH<m> SBUS{1 2} WMEMory<r>} for DSO models <source> ::= {CHANnel<n> DIGital<d> POD{1 2} BUS{1 2} FUNction<m> MATH<m> SBUS{1 2} WMEMory<r>} for MSO models <n> ::= 1 to (# analog channels) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format

**Introduction to
Root (:)
Commands**

Root level commands control many of the basic operations of the instrument. These commands are always recognized by the parser if they are prefixed with a colon, regardless of current command tree position. After executing a root-level command, the parser is positioned at the root of the command tree.

:ACTivity

N (see [page 1730](#))

Command Syntax :ACTivity

The :ACTivity command clears the cumulative edge variables for the next activity query.

Query Syntax :ACTivity?

The :ACTivity? query returns whether there has been activity (edges) on the digital channels since the last query, and returns the current logic levels.

NOTE

Because the :ACTivity? query returns edge activity since the last :ACTivity? query, you must send this query twice before the edge activity result is valid.

Return Format <edges>,<levels><NL>

<edges> ::= presence of edges (16-bit integer in NR1 format).

<levels> ::= logical highs or lows (16-bit integer in NR1 format).

bit 0 ::= DIGital 0

bit 15 ::= DIGital 15

NOTE

A bit = 0 (zero) in the <edges> result indicates that no edges were detected on that channel (across the specified threshold voltage) since the last query.

A bit = 1 (one) in the <edges> result indicates that edges have been detected on that channel (across the specified threshold voltage) since the last query.

(The threshold voltage must be set appropriately for the logic levels of the signals being probed.)

- See Also**
- ["Introduction to Root \(:\) Commands"](#) on page 260
 - [":POD<n>:THReshold"](#) on page 819
 - [":DIGital<d>:THReshold"](#) on page 427

:AER (Arm Event Register)

C (see [page 1730](#))

Query Syntax :AER?

The AER query reads the Arm Event Register. After the Arm Event Register is read, it is cleared. A "1" indicates the trigger system is in the armed state, ready to accept a trigger.

The Armed Event Register is summarized in the Wait Trig bit of the Operation Status Event Register. A Service Request can be generated when the Wait Trig bit transitions and the appropriate enable bits have been set in the Operation Status Enable Register (OPEE) and the Service Request Enable Register (SRE).

Return Format <value><NL>

<value> ::= {0 | 1}; an integer in NR1 format.

- See Also**
- ["Introduction to Root \(:\) Commands"](#) on page 260
 - [":OPEE \(Operation Status Enable Register\)"](#) on page 280
 - [":OPERRegister:CONDition \(Operation Status Condition Register\)"](#) on page 282
 - [":OPERRegister\[:EVENT\] \(Operation Status Event Register\)"](#) on page 285
 - ["*STB \(Read Status Byte\)"](#) on page 252
 - ["*SRE \(Service Request Enable\)"](#) on page 250

:AUToscale

C (see [page 1730](#))

Command Syntax

```
:AUToscale
:AUToscale [<source>[,...,<source>]]
<source> ::= CHANNEL<n> for the DSO models
<source> ::= {DIGital<d> | POD1 | POD2 | CHANNEL<n>} for the
              MSO models
<n> ::= 1 to (# analog channels) in NR1 format
<d> ::= 0 to (# digital channels - 1) in NR1 format
```

The <source> parameter may be repeated up to 5 times.

The :AUToscale command evaluates all input signals and sets the correct conditions to display the signals. This is the same as pressing the **[Auto Scale]** key on the front panel.

If one or more sources are specified, those specified sources will be enabled and all others blanked. The autoscale channels mode (see **" :AUToscale:CHANNELs "** on page 266) is set to DISPLAYed channels. Then, the autoscale is performed.

When the :AUToscale command is sent, the following conditions are affected and actions are taken:

- Thresholds.
- Channels with activity around the trigger point are turned on, others are turned off.
- Channels are reordered on screen; analog channel 1 first, followed by the remaining analog channels, then the digital channels 0-15.
- Delay is set to 0 seconds.
- Time/Div.

The :AUToscale command does not affect the following conditions:

- Label names.
- Trigger conditioning.

The :AUToscale command turns off the following items:

- Cursors.
- Measurements.
- Math waveforms.
- Reference waveforms.
- Zoomed (delayed) time base mode.

For further information on :AUToscale, see the *User's Guide*.

- See Also**
- ["Introduction to Root \(:\) Commands"](#) on page 260
 - [":AUToscale:CHANnels"](#) on page 266
 - [":AUToscale:AMODE"](#) on page 265

Example Code

```
' AUTOSCALE - This command evaluates all the input signals and sets  
' the correct conditions to display all of the active signals.  
myScope.WriteString ":AUToscale" ' Same as pressing Auto Scale key.
```

See complete example programs at: [Chapter 50](#), "Programming Examples," starting on page 1739

:AUToscale:AMODE

N (see [page 1730](#))

Command Syntax :AUToscale:AMODE <value>
 <value> ::= {NORMal | CURRent}

The :AUToscale:AMODE command specifies the acquisition mode that is set by subsequent :AUToscales.

- When NORMal is selected, an :AUToscale command sets the NORMal acquisition type and the RTIME (real-time) acquisition mode.
- When CURRent is selected, the current acquisition type and mode are kept on subsequent :AUToscales.

Use the :ACquire:TYPE and :ACquire:MODE commands to set the acquisition type and mode.

Query Syntax :AUToscale:AMODE?

The :AUToscale:AMODE? query returns the autoscale acquire mode setting.

Return Format <value><NL>
 <value> ::= {NORM | CURR}

- See Also**
- ["Introduction to Root \(:\) Commands"](#) on page 260
 - [":AUToscale"](#) on page 263
 - [":AUToscale:CHANnels"](#) on page 266
 - [":ACquire:TYPE"](#) on page 318
 - [":ACquire:MODE"](#) on page 308

:AUToscale:CHANnels

N (see [page 1730](#))

Command Syntax :AUToscale:CHANnels <value>
 <value> ::= {ALL | DISplayed}

The :AUToscale:CHANnels command specifies which channels will be displayed on subsequent :AUToscales.

- When ALL is selected, all channels that meet the requirements of :AUToscale will be displayed.
- When DISplayed is selected, only the channels that are turned on are autoscaled.

Use the :VIEW or :BLANK root commands to turn channels on or off.

Query Syntax :AUToscale:CHANnels?

The :AUToscale:CHANnels? query returns the autoscale channels setting.

Return Format <value><NL>
 <value> ::= {ALL | DISP}

- See Also**
- ["Introduction to Root \(:\) Commands"](#) on page 260
 - [":AUToscale"](#) on page 263
 - [":AUToscale:AMODE"](#) on page 265
 - [":VIEW"](#) on page 300
 - [":BLANK"](#) on page 268

:AUToscale:FDEBug

N (see [page 1730](#))

Command Syntax :AUToscale:FDEBug <on_off>
 <on_off> ::= {{1 | ON} | {0 | OFF}}

The :AUToscale:FDEBug command turns fast debug auto scaling on or off.

The Fast Debug option changes the behavior of :AUToscale to let you make quick visual comparisons to determine whether the signal being probed is a DC voltage, ground, or an active AC signal.

Channel coupling is maintained for easy viewing of oscillating signals.

Query Syntax :AUToscale:FDEBug?

The :AUToscale:FDEBug? query returns the current autoscale fast debug setting.

Return Format <on_off><NL>

<on_off> ::= {1 | 0}

- See Also**
- ["Introduction to Root \(:\) Commands"](#) on page 260
 - [":AUToscale"](#) on page 263

:BLANK

N (see [page 1730](#))

Command Syntax

:BLANK [<source>]

```
<source> ::= {CHANnel<n> | FUNction<m> | MATH<m> | SBUS{1 | 2}
             | WMEMory<r> | HISTogram}
             for the DSO models
```

```
<source> ::= {CHANnel<n> | DIGital<d> | POD{1 | 2}
             | BUS{1 | 2} | FUNction<m> | MATH<m> | SBUS{1 | 2}
             | WMEMory<r> | HISTogram}
             for the MSO models
```

<n> ::= 1 to (# analog channels) in NR1 format

<d> ::= 0 to (# digital channels - 1) in NR1 format

<m> ::= 1 to (# math functions) in NR1 format

<r> ::= 1 to (# ref waveforms) in NR1 format

The :BLANK command turns off (stops displaying) the specified channel, digital pod, math function, serial decode bus, or reference waveform location. The :BLANK command with no parameter turns off all sources.

NOTE

To turn on (start displaying) a channel, etc., use the :VIEW command. The DISPlay commands, :CHANnel<n>:DISPlay, :FUNction:DISPlay, :POD<n>:DISPlay, :DIGital<n>:DISPlay, :SBUS<n>:DISPlay, :WMEMory<r>:DISPlay, or :HISTogram:DISPlay, are the preferred method to turn on/off a channel, etc.

NOTE

MATH<m> is an alias for FUNction<m>.

- See Also
- ["Introduction to Root \(:\) Commands"](#) on page 260
 - [":DISPlay:CLEAr"](#) on page 439
 - [":CHANnel<n>:DISPlay"](#) on page 357
 - [":DIGital<d>:DISPlay"](#) on page 423
 - [":FUNction<m>:DISPlay"](#) on page 497
 - [":POD<n>:DISPlay"](#) on page 817
 - [":SBUS<n>:DISPlay"](#) on page 980
 - [":WMEMory<r>:DISPlay"](#) on page 1604
 - [":STATus"](#) on page 297
 - [":VIEW"](#) on page 300

Example Code · ["Example Code"](#) on page 300

:DIGitize

C (see [page 1730](#))

Command Syntax :DIGitize [<source>[,...,<source>]]

<source> ::= {CHANnel<n> | FUNction<m> | MATH<m> | SBUS{1 | 2}}
for the DSO models

<source> ::= {CHANnel<n> | DIGital<d> | POD{1 | 2}
| BUS{1 | 2} | FUNction<m> | MATH<m> | SBUS{1 | 2}}
for the MSO models

<n> ::= 1 to (# analog channels) in NR1 format

<d> ::= 0 to (# digital channels - 1) in NR1 format

<m> ::= 1 to (# math functions) in NR1 format

The <source> parameter may be repeated up to 5 times.

The :DIGitize command is a specialized RUN command. It causes the instrument to acquire waveforms according to the settings of the :ACquire commands subsystem. When the acquisition is complete, the instrument is stopped.

If no argument is given, :DIGitize acquires the channels currently displayed. If no channels are displayed, all channels are acquired.

NOTE

The :DIGitize command is only executed when the :TIMEbase:MODE is MAIN or WINDow.

NOTE

To halt a :DIGitize in progress, use the device clear command.

NOTE

MATH<m> is an alias for FUNction<m>.

- See Also**
- ["Introduction to Root \(:\) Commands"](#) on page 260
 - [":RUN"](#) on page 294
 - [":SINGle"](#) on page 296
 - [":STOP"](#) on page 298
 - [":TIMEbase:MODE"](#) on page 1413
 - [Chapter 8](#), “:ACquire Commands,” starting on page 301
 - [Chapter 42](#), “:WAVEform Commands,” starting on page 1513

- **Chapter 4**, “Sequential (Blocking) vs. Overlapped Commands,” starting on page 87
- **"Example: Checking for Armed Status"** on page 1701

Example Code

```
' Capture an acquisition using :DIGitize.  
' -----  
myScope.WriteString ":DIGitize CHANnel1"
```

See complete example programs at: **Chapter 50**, “Programming Examples,” starting on page 1739

:HWEenable (Hardware Event Enable Register)

N (see [page 1730](#))

Command Syntax :HWEenable <mask>
 <mask> ::= 16-bit integer

The :HWEenable command sets a mask in the Hardware Event Enable register. Set any of the following bits to "1" to enable bit 12 in the Operation Status Condition Register and potentially cause an SRQ (Service Request interrupt) to be generated.




Table 88 Hardware Event Enable Register (HWEenable)

Bit	Name	Description	When Set (1 = High = True), Enables:
15-13	---	---	(Not used.)
12	PLL Locked	PLL Locked	This bit is for internal use and is not intended for general use.
11-0	---	---	(Not used.)

Query Syntax :HWEenable?

The :HWEenable? query returns the current value contained in the Hardware Event Enable register as an integer number.

Return Format <value><NL>
 <value> ::= integer in NR1 format.

- See Also**
- ["Introduction to Root \(:\) Commands"](#) on page 260
 - [":AER \(Arm Event Register\)"](#) on page 262
 - [":CHANnel<n>:PROTection"](#) on page 377

- **":OPERRegister[:EVENT] (Operation Status Event Register)"** on page 285
- **":OVLenable (Overload Event Enable Register)"** on page 288
- **":OVLRegister (Overload Event Register)"** on page 290
- **"*STB (Read Status Byte)"** on page 252
- **"*SRE (Service Request Enable)"** on page 250

:HWERegister:CONDition (Hardware Event Condition Register)

N (see [page 1730](#))

Query Syntax :HWERegister:CONDition?

The :HWERegister:CONDition? query returns the integer value contained in the Hardware Event Condition Register.




Table 89 Hardware Event Condition Register

Bit	Name	Description	When Set (1 = High = True), Indicates:
15-13	---	---	(Not used.)
12	PLL Locked	PLL Locked	This bit is for internal use and is not intended for general use.
11-0	---	---	(Not used.)

Return Format <value><NL>

<value> ::= integer in NR1 format.

- See Also**
- ["Introduction to Root \(: \) Commands"](#) on page 260
 - [":CHANnel<n>:PROTection"](#) on page 377
 - [":OPEE \(Operation Status Enable Register\)"](#) on page 280
 - [":OPERegister\[:EVENT\] \(Operation Status Event Register\)"](#) on page 285
 - [":OVLenable \(Overload Event Enable Register\)"](#) on page 288
 - [":OVLRegister \(Overload Event Register\)"](#) on page 290
 - ["*STB \(Read Status Byte\)"](#) on page 252
 - ["*SRE \(Service Request Enable\)"](#) on page 250

:HWERegister[:EVENT] (Hardware Event Event Register)

N (see [page 1730](#))

Query Syntax :HWERegister[:EVENT]?

The :HWERegister[:EVENT]? query returns the integer value contained in the Hardware Event Event Register.




Table 90 Hardware Event Event Register

Bit	Name	Description	When Set (1 = High = True), Indicates:
15-13	---	---	(Not used.)
12	PLL Locked	PLL Locked	This bit is for internal use and is not intended for general use.
11-0	---	---	(Not used.)

Return Format <value><NL>

<value> ::= integer in NR1 format.

- See Also**
- ["Introduction to Root \(:\) Commands"](#) on page 260
 - [":CHANnel<n>:PROTection"](#) on page 377
 - [":OPEE \(Operation Status Enable Register\)"](#) on page 280
 - [":OPERegister:CONDition \(Operation Status Condition Register\)"](#) on page 282
 - [":OVLenable \(Overload Event Enable Register\)"](#) on page 288
 - [":OVLRegister \(Overload Event Register\)"](#) on page 290
 - ["*STB \(Read Status Byte\)"](#) on page 252
 - ["*SRE \(Service Request Enable\)"](#) on page 250

:MTEenable (Mask Test Event Enable Register)

N (see [page 1730](#))

Command Syntax :MTEenable <mask>

<mask> ::= 16-bit integer

The :MTEenable command sets a mask in the Mask Test Event Enable register. Set any of the following bits to "1" to enable bit 9 in the Operation Status Condition Register and potentially cause an SRQ (Service Request) interrupt to be generated.




Table 91 Mask Test Event Enable Register (MTEenable)

Bit	Name	Description	When Set (1 = High = True), Enables:
15-11	---	---	(Not used.)
10	Auto Mask	Auto Mask Created	Auto mask creation completed.
9	Pass	Mask Test Pass	Mass test passed.
8	Started	Mask Testing Started	Mask testing started.
7-2	---	---	(Not used.)
1	Fail	Mask Test Fail	Mask test failed.
0	Complete	Mask Test Complete	Mask test is complete.

Query Syntax :MTEenable?

The :MTEenable? query returns the current value contained in the Mask Test Event Enable register as an integer number.

Return Format <value><NL>

<value> ::= integer in NR1 format.

- See Also**
- ["Introduction to Root \(:\) Commands"](#) on page 260
 - [":AER \(Arm Event Register\)"](#) on page 262
 - [":CHANnel<n>:PROTection"](#) on page 377
 - [":OPERRegister\[:EVENT\] \(Operation Status Event Register\)"](#) on page 285
 - [":OVLenable \(Overload Event Enable Register\)"](#) on page 288
 - [":OVLRegister \(Overload Event Register\)"](#) on page 290
 - ["*STB \(Read Status Byte\)"](#) on page 252
 - ["*SRE \(Service Request Enable\)"](#) on page 250

:MTERegister[:EVENT] (Mask Test Event Event Register)

N (see [page 1730](#))

Query Syntax :MTERegister[:EVENT]?

The :MTERegister[:EVENT]? query returns the integer value contained in the Mask Test Event Event Register and clears the register.




Table 92 Mask Test Event Event Register

Bit	Name	Description	When Set (1 = High = True), Indicates:
15-11	---	---	(Not used.)
10	Auto Mask	Auto Mask Created	Auto mask creation completed.
9	Pass	Mask Test Pass	The mask test passed.
8	Started	Mask Testing Started	Mask testing started.
7-2	---	---	(Not used.)
1	Fail	Mask Test Fail	The mask test failed.
0	Complete	Mask Test Complete	The mask test is complete.

Return Format <value><NL>
<value> ::= integer in NR1 format.

- See Also**
- "[Introduction to Root \(: \) Commands](#)" on page 260
 - "[:CHANnel<n>:PROTection](#)" on page 377
 - "[:OPEE \(Operation Status Enable Register\)](#)" on page 280
 - "[:OPERRegister:CONDition \(Operation Status Condition Register\)](#)" on page 282

- **":OVLenable (Overload Event Enable Register)"** on page 288
- **":OVLRegister (Overload Event Register)"** on page 290
- **"*STB (Read Status Byte)"** on page 252
- **"*SRE (Service Request Enable)"** on page 250

:OPEE (Operation Status Enable Register)

C (see [page 1730](#))

Command Syntax :OPEE <mask>
 <mask> ::= 15-bit integer

The :OPEE command sets a mask in the Operation Status Enable register. Set any of the following bits to "1" to enable bit 7 in the Status Byte Register and potentially cause an SRQ (Service Request) interrupt to be generated.




Table 93 Operation Status Enable Register (OPEE)

Bit	Name	Description	When Set (1 = High = True), Enables:
14	IOF	IO Operation Failed	Event only when something causes the IO operation to fail, like disconnecting a USB device or interrupting the operation from the oscilloscope's front panel.
13	IOC	IO Operation Complete	Event when any IO operation completes. IO operations are any remote data request using any interface (USB, LAN, or GPIB). For example, if you connect to an oscilloscope using the USB interface and then request waveform data, the IOC bit will be set when the IO operation completes.
12	HWE	Hardware Event	Event when hardware event occurs.
11	OVL	Overload	Event when 50Ω input overload occurs.

Table 93 Operation Status Enable Register (OPEE) (continued)

Bit	Name	Description	When Set (1 = High = True), Enables:
10	---	---	(Not used.)
9	MTE	Mask Test Event	Event when mask test event occurs.
8-6	---	---	(Not used.)
5	Wait Trig	Wait Trig	Event when the trigger is armed.
4	---	---	(Not used.)
3	Run	Running	Event when the oscilloscope is running (not stopped).
2-0	---	---	(Not used.)

Query Syntax :OPEE?

The :OPEE? query returns the current value contained in the Operation Status Enable register as an integer number.

Return Format <value><NL>

<value> ::= integer in NR1 format.

- See Also**
- ["Introduction to Root \(:\) Commands"](#) on page 260
 - [":AER \(Arm Event Register\)"](#) on page 262
 - [":CHANnel<n>:PROTection"](#) on page 377
 - [":OPERegister\[:EVENT\] \(Operation Status Event Register\)"](#) on page 285
 - [":OVLenable \(Overload Event Enable Register\)"](#) on page 288
 - [":OVLRegister \(Overload Event Register\)"](#) on page 290
 - ["*STB \(Read Status Byte\)"](#) on page 252
 - ["*SRE \(Service Request Enable\)"](#) on page 250
 - ["Operation Status Event Register \(:OPERegister\[:EVENT\]\)"](#) on page 1691
 - ["Example: Checking for Armed Status"](#) on page 1701
 - ["Example: Waiting for IO Operation Complete"](#) on page 1706

:OPERRegister:CONDition (Operation Status Condition Register)

C (see [page 1730](#))

Query Syntax :OPERRegister:CONDition?

The :OPERRegister:CONDition? query returns the integer value contained in the Operation Status Condition Register.




Table 94 Operation Status Condition Register

Bit	Name	Description	When Set (1 = High = True), Indicates:
14	IOF	IO Operation Failed	Event only when something causes the IO operation to fail, like disconnecting a USB device or interrupting the operation from the oscilloscope's front panel.
13	IOC	IO Operation Complete	Event when any IO operation completes. IO operations are any remote data request using any interface (USB, LAN, or GPIB). For example, if you connect to an oscilloscope using the USB interface and then request waveform data, the IOC bit will be set when the IO operation completes.
12	HWE	Hardware Event	Event when hardware event occurs.
11	OVLr	Overload	A 50Ω input overload has occurred.
10	---	---	(Not used.)

Table 94 Operation Status Condition Register (continued)

Bit	Name	Description	When Set (1 = High = True), Indicates:
9	MTE	Mask Test Event	A mask test event has occurred.
8-6	---	---	(Not used.)
5	Wait Trig	Wait Trig	The trigger is armed (set by the Trigger Armed Event Register (TER)).
4	RUI Enab	Remote Enabled	Shows whether the remote user interface is enabled. The front-panel graphical user interface can disable most of the remote interface, including the *OPC syntax, for example when: <ul style="list-style-type: none"> ▪ a modal dialog box is open ▪ the user is being prompted ▪ all segments are being analyzed ▪ there is a channel overload ▪ certain compliance applications are running When disabled, commands or queries are accepted, but "settings conflict" errors are returned. The status model is the only part of the remote user interface that is enabled. To determine when the remote interface is re-enabled, you can read this bit or wait for the event that gets generated when its status goes from disabled to enabled.
3	Run	Running	The oscilloscope is running (not stopped).
2-0	---	---	(Not used.)

Return Format <value><NL>

<value> ::= integer in NR1 format.

- See Also**
- [":Introduction to Root \(:\) Commands"](#) on page 260
 - [":CHANnel<n>:PROTection"](#) on page 377
 - [":OPEE \(Operation Status Enable Register\)"](#) on page 280
 - [":OPERegister\[:EVENT\] \(Operation Status Event Register\)"](#) on page 285
 - [":OVLenable \(Overload Event Enable Register\)"](#) on page 288
 - [":OVLRegister \(Overload Event Register\)"](#) on page 290
 - ["*STB \(Read Status Byte\)"](#) on page 252
 - ["*SRE \(Service Request Enable\)"](#) on page 250
 - [":MTERegister\[:EVENT\] \(Mask Test Event Event Register\)"](#) on page 278

- **":MTEenable (Mask Test Event Enable Register)"** on page 276
- **"*OPC (Operation Complete)"** on page 242
- **"Operation Status Condition Register (:OPERregister:CONDition)"** on page 1693
- **"Example: Checking for Armed Status"** on page 1701
- **"Example: Waiting for IO Operation Complete"** on page 1706

:OPERRegister[:EVENT] (Operation Status Event Register)

C (see [page 1730](#))

Query Syntax :OPERRegister[:EVENT]?

The :OPERRegister[:EVENT]? query reads and clears the integer value contained in the Operation Status Event Register.




Table 95 Operation Status Event Register

Bit	Name	Description	When Set (1 = High = True), Indicates:
14	IOF	IO Operation Failed	Event only when something causes the IO operation to fail, like disconnecting a USB device or interrupting the operation from the oscilloscope's front panel.
13	IOC	IO Operation Complete	Event when any IO operation completes. IO operations are any remote data request using any interface (USB, LAN, or GPIB). For example, if you connect to an oscilloscope using the USB interface and then request waveform data, the IOC bit will be set when the IO operation completes.
12	HWE	Hardware Event	Event when hardware event occurs.
11	OVL	Overload	A 50Ω input overload has occurred.
10	---	---	(Not used.)

Table 95 Operation Status Event Register (continued)

Bit	Name	Description	When Set (1 = High = True), Indicates:
9	MTE	Mask Test Event	A mask test event has occurred.
8-6	---	---	(Not used.)
5	Wait Trig	Wait Trig	The trigger is armed (set by the Trigger Armed Event Register (TER)).
4	RUI Enab	Remote Enabled	<p>The remote user interface has gone from a disabled state to an enabled state.</p> <p>The front-panel graphical user interface can disable most of the remote interface, including the *OPC syntax, for example when:</p> <ul style="list-style-type: none"> ▪ a modal dialog box is open ▪ the user is being prompted ▪ all segments are being analyzed ▪ there is a channel overload ▪ certain compliance applications are running <p>When disabled, commands or queries are accepted, but "settings conflict" errors are returned. The status model is the only part of the remote user interface that is enabled.</p> <p>To determine when the remote interface is re-enabled, you can read this bit or wait for the event that gets generated when its status goes from disabled to enabled.</p>
3	Run	Running	The oscilloscope has gone from a stop state to a single or running state.
2-0	---	---	(Not used.)

Return Format <value><NL>

<value> ::= integer in NR1 format.

- See Also**
- ["Introduction to Root \(:\) Commands"](#) on page 260
 - [":CHANnel<n>:PROTection"](#) on page 377
 - [":OPEE \(Operation Status Enable Register\)"](#) on page 280
 - [":OPERegister:CONDition \(Operation Status Condition Register\)"](#) on page 282
 - [":OVLenable \(Overload Event Enable Register\)"](#) on page 288
 - [":OVLRegister \(Overload Event Register\)"](#) on page 290
 - ["*STB \(Read Status Byte\)"](#) on page 252
 - ["*SRE \(Service Request Enable\)"](#) on page 250

- **":MTERegister[:EVENT] (Mask Test Event Register)"** on page 278
- **":MTEenable (Mask Test Event Enable Register)"** on page 276
- **"*OPC (Operation Complete)"** on page 242
- **"Operation Status Event Register (:OPERegister[:EVENT])"** on page 1691
- **"Example: Checking for Armed Status"** on page 1701
- **"Example: Waiting for IO Operation Complete"** on page 1706

:OVLenable (Overload Event Enable Register)

C (see [page 1730](#))

Command Syntax :OVLenable <enable_mask>

<enable_mask> ::= 16-bit integer

The overload enable mask is an integer representing an input as described in the following table.

The :OVLenable command sets the mask in the Overload Event Enable Register and enables the reporting of the Overload Event Register. If an overvoltage is sensed on a 50 Ω input, the input will automatically switch to 1 M Ω input impedance. If enabled, such an event will set bit 11 in the Operation Status Register.




Table 96 Overload Event Enable Register (OVL)

Bit	Description	When Set (1 = High = True), Enables:
15-10	---	(Not used.)
9	Channel 4 Fault	Event when fault occurs on Channel 4 input.
8	Channel 3 Fault	Event when fault occurs on Channel 3 input.
7	Channel 2 Fault	Event when fault occurs on Channel 2 input.
6	Channel 1 Fault	Event when fault occurs on Channel 1 input.
5-4	---	(Not used.)
3	Channel 4 OVL	Event when overload occurs on Channel 4 input.
2	Channel 3 OVL	Event when overload occurs on Channel 3 input.
1	Channel 2 OVL	Event when overload occurs on Channel 2 input.
0	Channel 1 OVL	Event when overload occurs on Channel 1 input.

Query Syntax :OVLenable?

The :OVLenable query returns the current enable mask value contained in the Overload Event Enable Register.

Return Format <enable_mask><NL>

<enable_mask> ::= integer in NR1 format.

- See Also**
- [":Introduction to Root \(:\) Commands"](#) on page 260
 - [":CHANnel<n>:PROTection"](#) on page 377
 - [":OPEE \(Operation Status Enable Register\)"](#) on page 280
 - [":OPERegister:CONDition \(Operation Status Condition Register\)"](#) on page 282
 - [":OPERegister\[:EVENT\] \(Operation Status Event Register\)"](#) on page 285
 - [":OVLRegister \(Overload Event Register\)"](#) on page 290
 - ["*STB \(Read Status Byte\)"](#) on page 252
 - ["*SRE \(Service Request Enable\)"](#) on page 250

:OVLRegister (Overload Event Register)

C (see [page 1730](#))

Query Syntax :OVLRegister?

The :OVLRegister query returns the overload protection value stored in the Overload Event Register (OVL). If an overvoltage is sensed on a 50Ω input, the input will automatically switch to 1 MΩ input impedance. A "1" indicates an overload has occurred.




Table 97 Overload Event Register (OVL)

Bit	Description	When Set (1 = High = True), Indicates:
15-10	---	(Not used.)
9	Channel 4 Fault	Fault has occurred on Channel 4 input.
8	Channel 3 Fault	Fault has occurred on Channel 3 input.
7	Channel 2 Fault	Fault has occurred on Channel 2 input.
6	Channel 1 Fault	Fault has occurred on Channel 1 input.
5-4	---	(Not used.)
3	Channel 4 OVL	Overload has occurred on Channel 4 input.
2	Channel 3 OVL	Overload has occurred on Channel 3 input.
1	Channel 2 OVL	Overload has occurred on Channel 2 input.
0	Channel 1 OVL	Overload has occurred on Channel 1 input.

Return Format <value><NL>

<value> ::= integer in NR1 format.

See Also • ["Introduction to Root \(:\) Commands"](#) on page 260

- **":CHANnel<n>:PROTection"** on page 377
- **":OPEE (Operation Status Enable Register)"** on page 280
- **":OVLenable (Overload Event Enable Register)"** on page 288
- **"*STB (Read Status Byte)"** on page 252
- **"*SRE (Service Request Enable)"** on page 250

:PRINT

C (see [page 1730](#))

Command Syntax :PRINT [<options>]

<options> ::= [<print option>][,...,<print option>]

<print option> ::= {COLor | GRAYscale | PRINter0 | PRINter1 | BMP8bit
| BMP | PNG | NOFactors | FACTors}

The <print option> parameter may be repeated up to 5 times.

The PRINT command formats the output according to the currently selected format (device). If an option is not specified, the value selected in the Print Config menu is used.

- See Also**
- ["Introduction to Root \(:\) Commands"](#) on page 260
 - ["Introduction to :HARDcopy Commands"](#) on page 540
 - [":HARDcopy:FACTors"](#) on page 544
 - [":HARDcopy:GRAYscale"](#) on page 1635
 - [":DISPlay:DATA"](#) on page 440

:RState?

N (see [page 1730](#))

Query Syntax :RState?

The :RState? query returns the run state:

- RUN – The oscilloscope is acquiring and displaying new waveforms.
- STOP – The oscilloscope is no longer acquiring new waveforms.
- SING – A single acquisition has been started and the oscilloscope is waiting for the trigger condition to be met.

These are the same run states displayed on the front panel and in the user interface.

Return Format {RUN | STOP | SING}<NL>

- See Also**
- [":RUN"](#) on page 294
 - [":SINGLE"](#) on page 296
 - [":STOP"](#) on page 298
 - [":OPERRegister\[:EVENT\] \(Operation Status Event Register\)"](#) on page 285

:RUN

C (see [page 1730](#))

Command Syntax :RUN

The :RUN command starts repetitive acquisitions. This is the same as pressing the Run key on the front panel.

- See Also**
- ["Introduction to Root \(:\) Commands"](#) on page 260
 - [":SINGLE"](#) on page 296
 - [":STOP"](#) on page 298

Example Code

```
' RUN_STOP - (not executed in this example)
' - RUN starts the data acquisition for the active waveform display.
' - STOP stops the data acquisition and turns off AUTOSTORE.
' myScope.WriteString ":RUN"      ' Start data acquisition.
' myScope.WriteString ":STOP"    ' Stop the data acquisition.
```

See complete example programs at: [Chapter 50](#), "Programming Examples," starting on page 1739

:SERial

N (see [page 1730](#))

Query Syntax :SERial?

The :SERial? query returns the serial number of the instrument.

Return Format: Unquoted string<NL>

See Also • ["Introduction to Root \(:\) Commands"](#) on page 260

:SINGle

C (see [page 1730](#))

Command Syntax :SINGle

The :SINGle command causes the instrument to acquire a single trigger of data. This is the same as pressing the Single key on the front panel.

- See Also**
- ["Introduction to Root \(:\) Commands"](#) on page 260
 - [":RUN"](#) on page 294
 - [":STOP"](#) on page 298

:STATus

N (see [page 1730](#))

Query Syntax :STATus? <source>

```
<source> ::= {CHANnel<n> | FUNction<m> | MATH<m> | SBUS{1 | 2}
             | WMEMory<r> | HISTogram}
             for the DSO models
```

```
<source> ::= {CHANnel<n> | DIGital<d> | POD{1 | 2}
             | BUS{1 | 2} | FUNction<m> | MATH<m> | SBUS{1 | 2}
             | WMEMory<r> | HISTogram}
             for the MSO models
```

<n> ::= 1 to (# analog channels) in NR1 format

<d> ::= 0 to (# digital channels - 1) in NR1 format

<m> ::= 1 to (# math functions) in NR1 format

<r> ::= 1 to (# ref waveforms) in NR1 format

The :STATus? query reports whether the channel, function, serial decode bus, or reference waveform location specified by <source> is displayed.

NOTE

MATH<m> is an alias for FUNction<m>.

Return Format <value><NL>

```
<value> ::= {1 | 0}
```

- See Also**
- ["Introduction to Root \(: \) Commands"](#) on page 260
 - [":BLANK"](#) on page 268
 - [":CHANnel<n>:DISPlay"](#) on page 357
 - [":DIGital<d>:DISPlay"](#) on page 423
 - [":FUNction<m>:DISPlay"](#) on page 497
 - [":POD<n>:DISPlay"](#) on page 817
 - [":SBUS<n>:DISPlay"](#) on page 980
 - [":WMEMory<r>:DISPlay"](#) on page 1604
 - [":VIEW"](#) on page 300

:STOP

C (see [page 1730](#))

Command Syntax :STOP

The :STOP command stops the acquisition. This is the same as pressing the Stop key on the front panel.

- See Also**
- ["Introduction to Root \(:\) Commands"](#) on page 260
 - [":RUN"](#) on page 294
 - [":SINGle"](#) on page 296

- Example Code**
- ["Example Code"](#) on page 294

:TER (Trigger Event Register)

C (see [page 1730](#))

Query Syntax :TER?

The :TER? query reads the Trigger Event Register. After the Trigger Event Register is read, it is cleared. A one indicates a trigger has occurred. A zero indicates a trigger has not occurred.

The Trigger Event Register is summarized in the TRG bit of the Status Byte Register (STB). A Service Request (SRQ) can be generated when the TRG bit of the Status Byte transitions, and the TRG bit is set in the Service Request Enable register. The Trigger Event Register must be cleared each time you want a new service request to be generated.

Return Format <value><NL>

<value> ::= {1 | 0}; a 16-bit integer in NR1 format.

- See Also**
- ["Introduction to Root \(:\) Commands"](#) on page 260
 - ["*SRE \(Service Request Enable\)"](#) on page 250
 - ["*STB \(Read Status Byte\)"](#) on page 252

:VIEW

N (see [page 1730](#))

Command Syntax

```
:VIEW <source>
```

```
<source> ::= {CHANnel<n> | FUNction<m> | MATH<m> | SBUS{1 | 2}
             | WMEMory<r> | HISTogram}
             for DSO models
```

```
<source> ::= {CHANnel<n> | DIGital<d> | POD{1 | 2}
             | BUS{1 | 2} | FUNction<m> | MATH<m> | SBUS{1 | 2}
             | WMEMory<r> | HISTogram}
             for MSO models
```

```
<n> ::= 1 to (# analog channels) in NR1 format
```

```
<d> ::= 0 to (# digital channels - 1) in NR1 format
```

```
<m> ::= 1 to (# math functions) in NR1 format
```

```
<r> ::= 1 to (# ref waveforms) in NR1 format
```

The :VIEW command turns on the specified channel, function, serial decode bus, or reference waveform location.

NOTE

MATH<m> is an alias for FUNction<m>.

- See Also
- ["Introduction to Root \(:\) Commands"](#) on page 260
 - [":BLANK"](#) on page 268
 - [":CHANnel<n>:DISPlay"](#) on page 357
 - [":DIGital<d>:DISPlay"](#) on page 423
 - [":FUNction<m>:DISPlay"](#) on page 497
 - [":POD<n>:DISPlay"](#) on page 817
 - [":SBUS<n>:DISPlay"](#) on page 980
 - [":WMEMory<r>:DISPlay"](#) on page 1604
 - [":STATus"](#) on page 297

Example Code

```
' VIEW_BLANK - (not executed in this example)
' - VIEW turns on (starts displaying) a channel.
' - BLANK turns off (stops displaying) a channel.
' myScope.WriteString ":BLANK CHANnel1"    ' Turn channel 1 off.
' myScope.WriteString ":VIEW CHANnel1"    ' Turn channel 1 on.
```

See complete example programs at: [Chapter 50](#), "Programming Examples," starting on page 1739

8 :ACQUIRE Commands

Set the parameters for acquiring and storing data. See "[Introduction to :ACQUIRE Commands](#)" on page 302.

Table 98 :ACQUIRE Commands Summary

Command	Query	Options and Query Returns
n/a	:ACQUIRE:AALIAS? (see page 304)	{1 0}
:ACQUIRE:COMPLETE <complete> (see page 305)	:ACQUIRE:COMPLETE? (see page 305)	<complete> ::= 100; an integer in NR1 format
:ACQUIRE:COUNT <count> (see page 306)	:ACQUIRE:COUNT? (see page 306)	<count> ::= an integer from 2 to 65536 in NR1 format
:ACQUIRE:DAALIAS <mode> (see page 307)	:ACQUIRE:DAALIAS? (see page 307)	<mode> ::= {DISABLE AUTO}
:ACQUIRE:MODE <mode> (see page 308)	:ACQUIRE:MODE? (see page 308)	<mode> ::= {RTIME MRTime ETIME SEGMENTED}
n/a	:ACQUIRE:POINTS? (see page 310)	<# points> ::= an integer in NR1 format
:ACQUIRE:RSIGNAL <ref_signal_mode> (see page 311)	:ACQUIRE:RSIGNAL? (see page 311)	<ref_signal_mode> ::= {OFF OUT IN}
:ACQUIRE:SEGMENTED:ANALYZE (see page 312)	n/a	n/a
:ACQUIRE:SEGMENTED:COUNT <count> (see page 313)	:ACQUIRE:SEGMENTED:COUNT? (see page 313)	<count> ::= an integer from 2 to 1000 in NR1 format
:ACQUIRE:SEGMENTED:INDEX <index> (see page 314)	:ACQUIRE:SEGMENTED:INDEX? (see page 314)	<index> ::= an integer from 1 to 1000 in NR1 format

Table 98 :ACquire Commands Summary (continued)

Command	Query	Options and Query Returns
n/a	:ACquire:SRATe? [MAXimum] (see page 317)	<sample_rate> ::= sample rate (samples/s) in NR3 format
:ACquire:TYPE <type> (see page 318)	:ACquire:TYPE? (see page 318)	<type> ::= {NORMAL AVERage HRESolution PEAK}

Introduction to :ACquire Commands The ACquire subsystem controls the way in which waveforms are acquired. These acquisition types are available: normal, averaging, peak detect, and high resolution.

Normal

The :ACquire:TYPE NORMAL command sets the oscilloscope in the normal acquisition mode. For the majority of user models and signals, NORMAL mode yields the best oscilloscope picture of the waveform.

Averaging

The :ACquire:TYPE AVERage command sets the oscilloscope in the averaging mode. You can set the count by sending the :ACquire:COUNt command followed by the number of averages. In this mode, the value for averages is an integer from 2 to 65536. The COUNT value determines the number of averages that must be acquired.

High-Resolution

The :ACquire:TYPE HRESolution command sets the oscilloscope in the high-resolution mode (also known as *smoothing*). This mode is used to reduce noise at slower sweep speeds where the digitizer samples faster than needed to fill memory for the displayed time range. Instead of decimating samples, they are averaged together to provide the value for one display point. The slower the sweep speed, the greater the number of samples that are averaged together for each display point.

Peak Detect

The :ACquire:TYPE PEAK command sets the oscilloscope in the peak detect mode. In this mode, :ACquire:COUNt has no meaning.

Reporting the Setup

Use :ACquire? to query setup information for the ACquire subsystem.

Return Format

The following is a sample response from the :ACquire? query. In this case, the query was issued following a *RST command.

```
:ACQ:MODE RTIM;TYPE NORM;COMP 100;COUNT 8;SEGM:COUN 2
```

:ACquire:AALias

N (see [page 1730](#))

Query Syntax :ACquire:AALias?

The :ACquire:AALias? query returns the current state of the oscilloscope acquisition anti-alias control. This control can be directly disabled or disabled automatically.

Return Format <value><NL>

<value> ::= {1 | 0}

- See Also**
- ["Introduction to :ACquire Commands"](#) on page 302
 - [":ACquire:DAALias"](#) on page 307

:ACQUIRE:COMPLETE

C (see [page 1730](#))

Command Syntax :ACQUIRE:COMPLETE <complete>
 <complete> ::= 100; an integer in NR1 format

The :ACQUIRE:COMPLETE command affects the operation of the :DIGITIZE command. It specifies the minimum completion criteria for an acquisition. The parameter determines the percentage of the time buckets that must be "full" before an acquisition is considered complete. If :ACQUIRE:TYPE is NORMAL, it needs only one sample per time bucket for that time bucket to be considered full.

The only legal value for the :COMPLETE command is 100. All time buckets must contain data for the acquisition to be considered complete.

Query Syntax :ACQUIRE:COMPLETE?

The :ACQUIRE:COMPLETE? query returns the completion criteria (100) for the currently selected mode.

Return Format <completion_criteria><NL>
 <completion_criteria> ::= 100; an integer in NR1 format

- See Also**
- ["Introduction to :ACQUIRE Commands"](#) on page 302
 - [":ACQUIRE:TYPE"](#) on page 318
 - [":DIGITIZE"](#) on page 270
 - [":WAVEFORM:POINTS"](#) on page 1526

Example Code

```
' ACQUIRE_COMPLETE - Specifies the minimum completion criteria for
' an acquisition. The parameter determines the percentage of time
' buckets needed to be "full" before an acquisition is considered
' to be complete.
myScope.WriteString ":ACQUIRE:COMPLETE 100"
```

See complete example programs at: [Chapter 50](#), "Programming Examples," starting on page 1739

:ACquire:COUNT

C (see [page 1730](#))

Command Syntax :ACquire:COUNT <count>
<count> ::= integer in NR1 format

In averaging mode, the :ACquire:COUNT command specifies the number of values to be averaged for each time bucket before the acquisition is considered to be complete for that time bucket. When :ACquire:TYPE is set to AVERage, the count can be set to any value from 2 to 65536.

NOTE

The :ACquire:COUNT 1 command has been deprecated. The AVERage acquisition type with a count of 1 is functionally equivalent to the HRESolution acquisition type; however, you should select the high-resolution acquisition mode with the :ACquire:TYPE HRESolution command instead.

Query Syntax :ACquire:COUNT?

The :ACquire:COUNT? query returns the currently selected count value for averaging mode.

Return Format <count_argument><NL>
<count_argument> ::= an integer from 2 to 65536 in NR1 format

- See Also**
- ["Introduction to :ACquire Commands"](#) on page 302
 - [":ACquire:TYPE"](#) on page 318
 - [":DIGitize"](#) on page 270
 - [":WAVEform:COUNT"](#) on page 1522

:ACQUIRE:DAALias

N (see [page 1730](#))

Command Syntax :ACQUIRE:DAALias <mode>

<mode> ::= {DISable | AUTO}

The :ACQUIRE:DAALias command sets the disable anti-alias mode of the oscilloscope.

When set to DISable, anti-alias is always disabled. This is good for cases where dithered data is not desired.

When set to AUTO, the oscilloscope turns off anti-alias control as needed. Such cases are when the FFT or differentiate math functions are silent. The :DIGitize command always turns off the anti-alias control as well.

Query Syntax :ACQUIRE:DAALias?

The :ACQUIRE:DAALias? query returns the oscilloscope's current disable anti-alias mode setting.

Return Format <mode><NL>

<mode> ::= {DIS | AUTO}

- See Also**
- ["Introduction to :ACQUIRE Commands"](#) on page 302
 - [":ACQUIRE:AALias"](#) on page 304

:ACquire:MODE

C (see [page 1730](#))

Command Syntax :ACquire:MODE <mode>

<mode> ::= {RTIME | MRTime | ETIME | SEGmented}

The :ACquire:MODE command sets the acquisition mode of the oscilloscope.

- **RTIME** – Specifies that the oscilloscope produce the waveform display from samples collected during one trigger event (that is, one acquisition). At fast sweep speeds, when not enough samples can be collected for a waveform, a sophisticated reconstruction filter is used to fill-in sample points and enhance the waveform display.

In RTIME mode, to accurately reproduce a sampled waveform, the sample rate should be at least 2.5 times the highest frequency component of the waveform. If not, it is possible for the reconstructed waveform to be distorted or aliased. Aliasing is most commonly seen as jitter on fast digital edges.

Use RTIME sampling to capture infrequent triggers, unstable triggers, or complex changing waveforms, such as eye diagrams.

NOTE

The obsolete command ACquire:TYPE:REALtime is functionally equivalent to sending ACquire:MODE RTIME; TYPE NORMAl.

- **MRTime** – This is the same as Realtime except that in order to provide maximum update rate (trigger rates), the sample rate drops from 20 GSa/s to 2 GSa/s at a faster time/div setting than normal.

This mode is ideal for finding glitches and infrequent events in waveforms that do not require the full 20 GSa/s sample rate (and associated bandwidth).

This mode is not allowed in single, roll, segmented, mask test, or zone trigger.

- **ETIME** – Available in 6 GHz bandwidth models, this option gives you another way to fill-in sample points at fast sweep speeds – it is used only when sweep speeds are 20 ns/div or faster. In this case, instead of a reconstruction filter, a technique known as random repetitive sampling is used to build-up and draw one waveform using multiple triggers (acquisitions).

At slower sweep speeds, there are enough sample points in a trigger (acquisition, in other words) to render a waveform on the display.

Equivalent time sampling mode requires a repetitive waveform with a stable trigger.

- **SEGmented** – Sets the oscilloscope in segmented memory mode.

Query Syntax :ACquire:MODE?

The :ACquire:MODE? query returns the acquisition mode of the oscilloscope.

Return Format <mode><NL>

<mode> ::= {RTIM | MRT | ETIM | SEGM}

- See Also**
- ["Introduction to :ACquire Commands"](#) on page 302
 - [":ACquire:TYPE"](#) on page 318

:ACquire:POINts

C (see [page 1730](#))

Query Syntax :ACquire:POINts?

The :ACquire:POINts? query returns the number of data points that the hardware will acquire from the input signal. The number of points acquired is not directly controllable. To set the number of points to be transferred from the oscilloscope, use the command :WAVEform:POINts. The :WAVEform:POINts? query will return the number of points available to be transferred from the oscilloscope.

Return Format <points_argument><NL>

<points_argument> ::= an integer in NR1 format

- See Also**
- ["Introduction to :ACquire Commands"](#) on page 302
 - [":DIGitize"](#) on page 270
 - [":WAVEform:POINts"](#) on page 1526

:ACquire:RSIGnal

N (see [page 1730](#))

Command Syntax :ACquire:RSIGnal <ref_signal_mode>
 <ref_signal_mode> ::= {OFF | OUT | IN}

The :ACquire:RSIGnal command selects the 10 MHz reference signal mode.

- The OFF mode disables the oscilloscope's 10 MHz REF BNC connector.
- The OUT mode is used to synchronize the timebase of two or more instruments.
- The IN mode is used to supply a sample clock to the oscilloscope. A 10 MHz square or sine wave signal is input to the BNC connector labeled 10 MHz REF. The amplitude must be from - 5 dBm to 17 dBm (356 mVpp to 4.48 Vpp).

CAUTION

Do not apply more than 20 dBm Max (6.32 Vpp Max) at the 10 MHz REF BNC connector on the rear panel or damage to the instrument may occur.

Query Syntax :ACquire:RSIGnal?

The :ACquire:RSIGnal? query returns the current 10 MHz reference signal mode.

Return Format <ref_signal_mode><NL>
 <ref_signal_mode> ::= {OFF | OUT | IN}

- See Also**
- **":TIMebase:REFClock"** on page 1416
 - The *Keysight InfiniiVision 6000 X Series Oscilloscopes User's Guide* for information on using the 10 MHz reference clock.

:ACquire:SEGmented:ANALyze

N (see [page 1730](#))

Command Syntax :ACquire:SEGmented:ANALyze

This command calculates measurement statistics and/or infinite persistence over all segments that have been acquired. It corresponds to the front panel **Analyze Segments** softkey which appears in both the Measurement Statistics and Segmented Memory Menus.

In order to use this command, the oscilloscope must be stopped and in segmented acquisition mode, with either quick measurements or infinite persistence on.

- See Also**
- [":ACquire:MODE"](#) on page 308
 - [":ACquire:SEGmented:COUNT"](#) on page 313
 - ["Introduction to :ACquire Commands"](#) on page 302

:ACQUIRE:SEGMENTED:COUNT

N (see [page 1730](#))

Command Syntax :ACQUIRE:SEGMENTED:COUNT <count>

<count> ::= an integer from 2 to 1000 (w/4M memory) in NR1 format

The :ACQUIRE:SEGMENTED:COUNT command sets the number of memory segments to acquire.

The segmented memory acquisition mode is enabled with the :ACQUIRE:MODE command, and data is acquired using the :DIGITIZE, :SINGLE, or :RUN commands. The number of memory segments in the current acquisition is returned by the :WAVEFORM:SEGMENTED:COUNT? query.

The maximum number of segments may be limited by the memory depth of your oscilloscope. For example, an oscilloscope with 1M memory allows a maximum of 250 segments.

Query Syntax :ACQUIRE:SEGMENTED:COUNT?

The :ACQUIRE:SEGMENTED:COUNT? query returns the current count setting.

Return Format <count><NL>

<count> ::= an integer from 2 to 1000 (w/4M memory) in NR1 format

- See Also**
- [":ACQUIRE:MODE"](#) on page 308
 - [":DIGITIZE"](#) on page 270
 - [":SINGLE"](#) on page 296
 - [":RUN"](#) on page 294
 - [":WAVEFORM:SEGMENTED:COUNT"](#) on page 1534
 - [":ACQUIRE:SEGMENTED:ANALYZE"](#) on page 312
 - ["Introduction to :ACQUIRE Commands"](#) on page 302

Example Code • ["Example Code"](#) on page 314

:ACquire:SEGmented:INDex

N (see [page 1730](#))

Command Syntax :ACquire:SEGmented:INDex <index>

<index> ::= an integer from 1 to 1000 (w/4M memory) in NR1 format

The :ACquire:SEGmented:INDex command sets the index into the memory segments that have been acquired.

The segmented memory acquisition mode is enabled with the :ACquire:MODE command. The number of segments to acquire is set using the :ACquire:SEGmented:COUNT command, and data is acquired using the :DIGitize, :SINGle, or :RUN commands. The number of memory segments that have been acquired is returned by the :WAVEform:SEGmented:COUNT? query. The time tag of the currently indexed memory segment is returned by the :WAVEform:SEGmented:TTAG? query.

The maximum number of segments may be limited by the memory depth of your oscilloscope. For example, an oscilloscope with 1M memory allows a maximum of 250 segments.

Query Syntax :ACquire:SEGmented:INDex?

The :ACquire:SEGmented:INDex? query returns the current segmented memory index setting.

Return Format <index><NL>

<index> ::= an integer from 1 to 1000 (w/4M memory) in NR1 format

- See Also**
- [":ACquire:MODE"](#) on page 308
 - [":ACquire:SEGmented:COUNT"](#) on page 313
 - [":DIGitize"](#) on page 270
 - [":SINGle"](#) on page 296
 - [":RUN"](#) on page 294
 - [":WAVEform:SEGmented:COUNT"](#) on page 1534
 - [":WAVEform:SEGmented:TTAG"](#) on page 1535
 - [":ACquire:SEGmented:ANALyze"](#) on page 312
 - ["Introduction to :ACquire Commands"](#) on page 302

Example Code ' Segmented memory commands example.

' -----

Option Explicit

```
Public myMgr As VisaComLib.ResourceManager
Public myScope As VisaComLib.FormattedIO488
Public varQueryResult As Variant
```

```

Public strQueryResult As String

Private Declare Sub Sleep Lib "kernel32" (ByVal dwMilliseconds As Long)

Sub Main()

    On Error GoTo VisaComError

    ' Create the VISA COM I/O resource.
    Set myMgr = New VisaComLib.ResourceManager
    Set myScope = New VisaComLib.FormattedIO488
    Set myScope.IO = _
        myMgr.Open("USB0::0x0957::0x17A6::US50210029::0::INSTR")
    myScope.IO.Clear ' Clear the interface.

    ' Turn on segmented memory acquisition mode.
    myScope.WriteString ":ACquire:MODE SEGmented"
    myScope.WriteString ":ACquire:MODE?"
    strQueryResult = myScope.ReadString
    Debug.Print "Acquisition mode: " + strQueryResult

    ' Set the number of segments to 25.
    myScope.WriteString ":ACquire:SEGmented:COUNT 25"
    myScope.WriteString ":ACquire:SEGmented:COUNT?"
    strQueryResult = myScope.ReadString
    Debug.Print "Acquisition memory segments: " + strQueryResult

    ' If data will be acquired within the IO timeout:
    'myScope.IO.Timeout = 10000
    'myScope.WriteString ":DIGitize"
    'Debug.Print ":DIGitize blocks until all segments acquired."
    'myScope.WriteString ":WAVEform:SEGmented:COUNT?"
    'varQueryResult = myScope.ReadNumber

    ' Or, to poll until the desired number of segments acquired:
    myScope.WriteString ":SINGLE"
    Debug.Print ":SINGLE does not block until all segments acquired."
    Do
        Sleep 100 ' Small wait to prevent excessive queries.
        myScope.WriteString ":WAVEform:SEGmented:COUNT?"
        varQueryResult = myScope.ReadNumber
    Loop Until varQueryResult = 25

    Debug.Print "Number of segments in acquired data: " _
        + FormatNumber(varQueryResult)

    ' Allow time for Analyze Segments.
    Sleep 7000

    Dim lngSegments As Long
    lngSegments = varQueryResult

    ' For each segment:
    Dim dblTimeTag As Double
    Dim lngI As Long

    For lngI = lngSegments To 1 Step -1

```

```
' Set the segmented memory index.
myScope.WriteString ":ACquire:SEGmented:INdex " + CStr(lngI)
myScope.WriteString ":ACquire:SEGmented:INdex?"
strQueryResult = myScope.ReadString
Debug.Print "Acquisition memory segment index: " + strQueryResult

' Display the segment time tag.
myScope.WriteString ":WAVEform:SEGmented:TTAG?"
dblTimeTag = myScope.ReadNumber
Debug.Print "Segment " + CStr(lngI) + " time tag: " _
    + FormatNumber(dblTimeTag, 12)

Next lngI

Exit Sub

VisaComError:
    MsgBox "VISA COM Error:" + vbCrLf + Err.Description

End Sub
```

:ACquire:SRATe

N (see [page 1730](#))

Query Syntax :ACquire:SRATe? [MAXimum]

The :ACquire:SRATe? query returns the current oscilloscope acquisition sample rate. The sample rate is not directly controllable.

When the MAXimum parameter is used, the oscilloscope's maximum possible sample rate is returned.

Return Format <sample_rate><NL>

<sample_rate> ::= sample rate in NR3 format

- See Also**
- ["Introduction to :ACquire Commands"](#) on page 302
 - [":ACquire:POINts"](#) on page 310

:ACquire:TYPE

C (see [page 1730](#))

Command Syntax :ACquire:TYPE <type>

<type> ::= {NORMAL | AVERage | HRESolution | PEAK}

The :ACquire:TYPE command selects the type of data acquisition that is to take place. The acquisition types are:

- **NORMAL** – sets the oscilloscope in the normal mode.
- **AVERage** – sets the oscilloscope in the averaging mode. You can set the count by sending the :ACquire:COUNT command followed by the number of averages. In this mode, the value for averages is an integer from 1 to 65536. The COUNT value determines the number of averages that must be acquired.

The AVERage type is not available when in segmented memory mode (:ACquire:MODE SEGmented).

- **HRESolution** – sets the oscilloscope in the high-resolution mode (also known as *smoothing*). This mode is used to reduce noise at slower sweep speeds where the digitizer samples faster than needed to fill memory for the displayed time range.

For example, if the digitizer samples at 200 MSa/s, but the effective sample rate is 1 MSa/s (because of a slower sweep speed), only 1 out of every 200 samples needs to be stored. Instead of storing one sample (and throwing others away), the 200 samples are averaged together to provide the value for one display point. The slower the sweep speed, the greater the number of samples that are averaged together for each display point.

- **PEAK** – sets the oscilloscope in the peak detect mode. In this mode, :ACquire:COUNT has no meaning.

The AVERage and HRESolution types can give you extra bits of vertical resolution. See the *User's Guide* for an explanation. When getting waveform data acquired using the AVERage and HRESolution types, be sure to use the WORD or ASCii waveform data formats to get the extra bits of vertical resolution.

NOTE

The obsolete command ACquire:TYPE:REALtime is functionally equivalent to sending ACquire:MODE RTIME; TYPE NORMAL.

Query Syntax :ACquire:TYPE?

The :ACquire:TYPE? query returns the current acquisition type.

Return Format <acq_type><NL>

<acq_type> ::= {NORM | AVER | HRES | PEAK}

- See Also
- ["Introduction to :ACquire Commands"](#) on page 302
 - [":ACquire:COUNT"](#) on page 306
 - [":ACquire:MODE"](#) on page 308
 - [":DIGitize"](#) on page 270
 - [":WAVEform:FORMat"](#) on page 1525
 - [":WAVEform:TYPE"](#) on page 1542
 - [":WAVEform:PREamble"](#) on page 1530

Example Code

```
' ACQUIRE_TYPE - Sets the acquisition mode, which can be NORMAL,  
' PEAK, or AVERAGE.  
myScope.WriteString ":ACquire:TYPE NORMal"
```

See complete example programs at: [Chapter 50](#), "Programming Examples," starting on page 1739

9 :BUS<n> Commands

Control all oscilloscope functions associated with buses made up of digital channels. See "[Introduction to :BUS<n> Commands](#)" on page 322.

Table 99 :BUS<n> Commands Summary

Command	Query	Options and Query Returns
:BUS<n>:BIT<m> {{0 OFF} {1 ON}} (see page 323)	:BUS<n>:BIT<m>? (see page 323)	{0 1} <n> ::= 1 or 2; an integer in NR1 format <m> ::= 0-15; an integer in NR1 format
:BUS<n>:BITS <channel_list>, {{0 OFF} {1 ON}} (see page 324)	:BUS<n>:BITS? (see page 324)	<channel_list>, {0 1} <channel_list> ::= (@<m>, <m>:<m> ...) where "," is separator and ":" is range <n> ::= 1 or 2; an integer in NR1 format <m> ::= 0-15; an integer in NR1 format
:BUS<n>:CLear (see page 326)	n/a	<n> ::= 1 or 2; an integer in NR1 format
:BUS<n>:DISPlay {{0 OFF} {1 ON}} (see page 327)	:BUS<n>:DISPlay? (see page 327)	{0 1} <n> ::= 1 or 2; an integer in NR1 format

Table 99 :BUS<n> Commands Summary (continued)

Command	Query	Options and Query Returns
:BUS<n>:LABel <string> (see page 328)	:BUS<n>:LABel? (see page 328)	<string> ::= quoted ASCII string up to 10 characters <n> ::= 1 or 2; an integer in NR1 format
:BUS<n>:MASK <mask> (see page 329)	:BUS<n>:MASK? (see page 329)	<mask> ::= 32-bit integer in decimal, <nondecimal>, or <string> <nondecimal> ::= #Hnn...n where n ::= {0,...,9 A,...,F} for hexadecimal <nondecimal> ::= #Bnn...n where n ::= {0 1} for binary <string> ::= "0xnn...n" where n ::= {0,...,9 A,...,F} for hexadecimal <n> ::= 1 or 2; an integer in NR1 format

**Introduction to
:BUS<n>
Commands**

<n> ::= {1 | 2}

The BUS subsystem commands control the viewing, labeling, and digital channel makeup of two possible buses.

NOTE

These commands are only valid for the MSO models.

Reporting the Setup

Use :BUS<n>? to query setup information for the BUS subsystem.

Return Format

The following is a sample response from the :BUS1? query. In this case, the query was issued following a *RST command.

```
:BUS1:DISP 0;LAB "BUS1";MASK +255
```

:BUS<n>:BIT<m>

N (see [page 1730](#))**Command Syntax** :BUS<n>:BIT<m> <display>

<display> ::= {{1 | ON} | {0 | OFF}}

<n> ::= An integer, 1 or 2, is attached as a suffix to BUS and defines the bus that is affected by the command.

<m> ::= An integer, 0,...,15, is attached as a suffix to BIT and defines the digital channel that is affected by the command.

The :BUS<n>:BIT<m> command includes or excludes the selected bit as part of the definition for the selected bus. If the parameter is a 1 (ON), the bit is included in the definition. If the parameter is a 0 (OFF), the bit is excluded from the definition. *Note:* BIT0-15 correspond to DIGital0-15.

NOTE

This command is only valid for the MSO models.

Query Syntax :BUS<n>:BIT<m>?

The :BUS<n>:BIT<m>? query returns the value indicating whether the specified bit is included or excluded from the specified bus definition.

Return Format <display><NL>

<display> ::= {0 | 1}

- See Also**
- ["Introduction to :BUS<n> Commands"](#) on page 322
 - [":BUS<n>:BITS"](#) on page 324
 - [":BUS<n>:CLEar"](#) on page 326
 - [":BUS<n>:DISPlay"](#) on page 327
 - [":BUS<n>:LABel"](#) on page 328
 - [":BUS<n>:MASK"](#) on page 329

Example Code

```
' Include digital channel 1 in bus 1:
myScope.WriteString ":BUS1:BIT1 ON"
```

:BUS<n>:BITS

N (see [page 1730](#))

Command Syntax :BUS<n>:BITS <channel_list>, <display>

<channel_list> ::= (@<m>,<m>:<m>, ...) where commas separate bits and colons define bit ranges.

<m> ::= An integer, 0,...,15, defines a digital channel affected by the command.

<display> ::= {{1 | ON} | {0 | OFF}}

<n> ::= An integer, 1 or 2, is attached as a suffix to BUS and defines the bus that is affected by the command.

The :BUS<n>:BITS command includes or excludes the selected bits in the channel list in the definition of the selected bus. If the parameter is a 1 (ON) then the bits in the channel list are included as part of the selected bus definition. If the parameter is a 0 (OFF) then the bits in the channel list are excluded from the definition of the selected bus.

NOTE

This command is only valid for the MSO models.

Query Syntax :BUS<n>:BITS?

The :BUS<n>:BITS? query returns the definition for the specified bus.

Return Format <channel_list>, <display><NL>

<channel_list> ::= (@<m>,<m>:<m>, ...) where commas separate bits and colons define bit ranges.

<display> ::= {0 | 1}

- See Also**
- ["Introduction to :BUS<n> Commands"](#) on page 322
 - [":BUS<n>:BIT<m>"](#) on page 323
 - [":BUS<n>:CLEar"](#) on page 326
 - [":BUS<n>:DISPlay"](#) on page 327
 - [":BUS<n>:LABel"](#) on page 328
 - [":BUS<n>:MASK"](#) on page 329

Example Code

```
' Include digital channels 1, 2, 4, 5, 6, 7, 8, and 9 in bus 1:
myScope.WriteString ":BUS1:BITS (@1,2,4:9), ON"

' Include digital channels 1, 5, 7, and 9 in bus 1:
myScope.WriteString ":BUS1:BITS (@1,5,7,9), ON"

' Include digital channels 1 through 15 in bus 1:
```

```
myScope.WriteString ":BUS1:BITS (@1:15), ON"  
  
' Include digital channels 1 through 5, 8, and 14 in bus 1:  
myScope.WriteString ":BUS1:BITS (@1:5,8,14), ON"
```

:BUS<n>:CLEAr

N (see [page 1730](#))

Command Syntax :BUS<n>:CLEAr

<n> ::= An integer, 1 or 2, is attached as a suffix to BUS and defines the bus that is affected by the command.

The :BUS<n>:CLEAr command excludes all of the digital channels from the selected bus definition.

NOTE

This command is only valid for the MSO models.

-
- See Also**
- ["Introduction to :BUS<n> Commands"](#) on page 322
 - [":BUS<n>:BIT<m>"](#) on page 323
 - [":BUS<n>:BITS"](#) on page 324
 - [":BUS<n>:DISPlay"](#) on page 327
 - [":BUS<n>:LABel"](#) on page 328
 - [":BUS<n>:MASK"](#) on page 329

:BUS<n>:DISPlay

N (see [page 1730](#))

Command Syntax :BUS<n>:DISplay <value>

<value> ::= {{1 | ON} | {0 | OFF}}

<n> ::= An integer, 1 or 2, is attached as a suffix to BUS and defines the bus that is affected by the command.

The :BUS<n>:DISPlay command enables or disables the view of the selected bus.

NOTE

This command is only valid for the MSO models.

Query Syntax :BUS<n>:DISPlay?

The :BUS<n>:DISPlay? query returns the display value of the selected bus.

Return Format <value><NL>

<value> ::= {0 | 1}

- See Also**
- ["Introduction to :BUS<n> Commands"](#) on page 322
 - [":BUS<n>:BIT<m>"](#) on page 323
 - [":BUS<n>:BITS"](#) on page 324
 - [":BUS<n>:CLEar"](#) on page 326
 - [":BUS<n>:LABel"](#) on page 328
 - [":BUS<n>:MASK"](#) on page 329

:BUS<n>:LABel

N (see [page 1730](#))

Command Syntax :BUS<n>:LABel <quoted_string>

<quoted_string> ::= any series of 10 or less characters as a quoted ASCII string.

<n> ::= An integer, 1 or 2, is attached as a suffix to BUS and defines the bus that is affected by the command.

The :BUS<n>:LABel command sets the bus label to the quoted string. Setting a label for a bus will also result in the name being added to the label list.

NOTE

This command is only valid for the MSO models.

NOTE

Label strings are 10 characters or less, and may contain any commonly used ASCII characters. Labels with more than 10 characters are truncated to 10 characters.

Query Syntax :BUS<n>:LABel?

The :BUS<n>:LABel? query returns the name of the specified bus.

Return Format <quoted_string><NL>

<quoted_string> ::= any series of 10 or less characters as a quoted ASCII string.

- See Also**
- ["Introduction to :BUS<n> Commands"](#) on page 322
 - [":BUS<n>:BIT<m>"](#) on page 323
 - [":BUS<n>:BITS"](#) on page 324
 - [":BUS<n>:CLEar"](#) on page 326
 - [":BUS<n>:DISPlay"](#) on page 327
 - [":BUS<n>:MASK"](#) on page 329
 - [":CHANnel<n>:LABel"](#) on page 360
 - [":DISPlay:LABList"](#) on page 447
 - [":DIGital<d>:LABel"](#) on page 424

Example Code

```
' Set the bus 1 label to "Data":
myScope.WriteString ":BUS1:LABel 'Data'
```


:BUS<n>:MASK

N (see [page 1730](#))

Command Syntax :BUS<n>:MASK <mask>

<mask> ::= 32-bit integer in decimal, <nondecimal>, or <string>

<nondecimal> ::= #Hnn...n where n ::= {0,...,9 | A,...,F} for hexadecimal

<nondecimal> ::= #Bnn...n where n ::= {0 | 1} for binary

<string> ::= "0xnn...n" where n ::= {0,...,9 | A,...,F} for hexadecimal

<n> ::= An integer, 1 or 2, is attached as a suffix to BUS and defines the bus that is affected by the command.

The :BUS<n>:MASK command defines the bits included and excluded in the selected bus according to the mask. Set a mask bit to a "1" to include that bit in the selected bus, and set a mask bit to a "0" to exclude it.

NOTE

This command is only valid for the MSO models.

Query Syntax :BUS<n>:MASK?

The :BUS<n>:MASK? query returns the mask value for the specified bus.

Return Format <mask><NL> in decimal format

- See Also**
- ["Introduction to :BUS<n> Commands"](#) on page 322
 - [":BUS<n>:BIT<m>"](#) on page 323
 - [":BUS<n>:BITS"](#) on page 324
 - [":BUS<n>:CLEar"](#) on page 326
 - [":BUS<n>:DISPlay"](#) on page 327
 - [":BUS<n>:LABel"](#) on page 328

10 :CALibrate Commands

Utility commands for viewing calibration status and for starting the user calibration procedure. See "[Introduction to :CALibrate Commands](#)" on page 332.

Table 100 :CALibrate Commands Summary

Command	Query	Options and Query Returns
n/a	:CALibrate:DATE? (see page 333)	<return value> ::= <year>,<month>,<day>; all in NR1 format
:CALibrate:LABel <string> (see page 334)	:CALibrate:LABel? (see page 334)	<string> ::= quoted ASCII string up to 32 characters
:CALibrate:OUTPut <signal> (see page 335)	:CALibrate:OUTPut? (see page 335)	<signal> ::= {TRIGgers MASK WAVEgen WGEN1 WGEN2} Note: WAVE and WGEN1 are equivalent. Note: WGEN2 only available on models with 2 WaveGen outputs.
n/a	:CALibrate:PROTected? (see page 336)	{"PROTected" "UNPRotected"}
:CALibrate:STARt (see page 337)	n/a	n/a
n/a	:CALibrate:STATus? (see page 338)	<return value> ::= <status_code>,<status_string> <status_code> ::= an integer status code <status_string> ::= an ASCII status string

Table 100 :CALibrate Commands Summary (continued)

Command	Query	Options and Query Returns
n/a	:CALibrate:TEMPerature? (see page 339)	<return value> ::= degrees C delta since last cal in NR3 format
n/a	:CALibrate:TIME? (see page 340)	<return value> ::= <hours>,<minutes>,<seconds>; all in NR1 format

**Introduction to
:CALibrate
Commands**

The CALibrate subsystem provides utility commands for:

- Determining the state of the calibration factor protection switch (CAL PROTECT).
- Saving and querying the calibration label string.
- Reporting the calibration time and date.
- Reporting changes in the temperature since the last calibration.
- Starting the user calibration procedure.

:CALibrate:DATE

N (see [page 1730](#))

Query Syntax :CALibrate:DATE?

The :CALibrate:DATE? query returns the date of the last calibration.

Return Format <date><NL>

<date> ::= year,month,day in NR1 format<NL>

See Also • ["Introduction to :CALibrate Commands"](#) on page 332

:CALibrate:LABel

N (see [page 1730](#))

Command Syntax :CALibrate:LABel <string>

<string> ::= quoted ASCII string of up to 32 characters in length, not including the quotes

The CALibrate:LABel command saves a string that is up to 32 characters in length into the instrument's non-volatile memory. The string may be used to record calibration dates or other information as needed.

Query Syntax :CALibrate:LABel?

The :CALibrate:LABel? query returns the contents of the calibration label string.

Return Format <string><NL>

<string> ::= unquoted ASCII string of up to 32 characters in length

See Also • ["Introduction to :CALibrate Commands"](#) on page 332

:CALibrate:OUTPut

N (see [page 1730](#))

Command Syntax :CALibrate:OUTPut <signal>

<signal> ::= {TRIGgers | MASK | WAVEgen | WGEN1 | WGEN2}

Note: WAVE and WGEN1 are equivalent.

Note: WGEN2 only available on models with 2 WaveGen outputs.

The CALibrate:OUTPut command sets the signal that is available on the rear panel TRIG OUT BNC:

- TRIGgers – pulse when a trigger event occurs. The output level is 0-5 V into an open circuit, and 0-2.5 V into 50 Ω .
- MASK – signal from mask test indicating a failure.
- WAVEgen, WGEN1, WGEN2 – waveform generator sync output signal. This signal depends on the :WGEN<w>:FUNCTION setting:

Waveform Type	Sync Signal Characteristics
SINusoid, SQUare, RAMP, PULSe, SINC, EXPRise, EXPFall, GAUSSian	The Sync signal is a TTL positive pulse that occurs when the waveform rises above zero volts (or the DC offset value).
DC, NOISe, CARDiac	N/A

Query Syntax :CALibrate:OUTPut?

The :CALibrate:OUTPut query returns the current source of the TRIG OUT BNC signal.

Return Format <signal><NL>

<signal> ::= {TRIG | MASK | WAVE | WGEN2}

- See Also**
- ["Introduction to :CALibrate Commands"](#) on page 332
 - [":WGEN<w>:FUNCTION"](#) on page 1566

:CALibrate:PROTECTED

N (see [page 1730](#))

Query Syntax :CALibrate:PROTECTED?

The :CALibrate:PROTECTED? query returns the rear-panel calibration protect (CAL PROTECT) button state. The value PROTECTED indicates calibration is disabled, and UNPROTECTED indicates calibration is enabled.

Return Format <switch><NL>

<switch> ::= {"PROTECTED" | "UNPROTECTED"}

See Also · ["Introduction to :CALibrate Commands"](#) on page 332

:CALibrate:START

N (see [page 1730](#))

Command Syntax :CALibrate:START

The CALibrate:START command starts the user calibration procedure.

NOTE

Before starting the user calibration procedure, you must set the rear panel CALIBRATION switch to UNPROTECTED, and you must connect BNC cables from the TRIG OUT connector to the analog channel inputs. See the *User's Guide* for details.

-
- See Also**
- ["Introduction to :CALibrate Commands"](#) on page 332
 - [":CALibrate:PROTECTED"](#) on page 336

:CALibrate:STATus

N (see [page 1730](#))

Query Syntax :CALibrate:STATus?

The :CALibrate:STATus? query returns the summary results of the last user calibration procedure.

Return Format <return value><NL>

<return value> ::= <status_code>,<status_string>

<status_code> ::= an integer status code

<status_string> ::= an ASCII status string

The status codes and strings can be:

Status Code	Status String
+0	Calibrated
-1	Not Calibrated

See Also · ["Introduction to :CALibrate Commands"](#) on page 332

:CALibrate:TEMPerature

N (see [page 1730](#))

Query Syntax :CALibrate:TEMPerature?

The :CALibrate:TEMPerature? query returns the change in temperature since the last user calibration procedure.

Return Format <return value><NL>

<return value> ::= degrees C delta since last cal in NR3 format

See Also · ["Introduction to :CALibrate Commands"](#) on page 332

:CALibrate:TIME

N (see [page 1730](#))

Query Syntax :CALibrate:TIME?

The :CALibrate:TIME? query returns the time of the last calibration.

Return Format <date><NL>

<date> ::= hour,minutes,seconds in NR1 format

See Also · ["Introduction to :CALibrate Commands"](#) on page 332

11 :CGRade Commands

The :CGRade commands control the color grade waveform analysis feature.

When color grade analysis is enabled, a database is created that has the same number of memory locations as there are pixel locations in the waveform viewing area. Each database memory location is a counter. These counters are incremented when sampled waveform data crosses (or "hits") the associated pixel.

When the oscilloscope is stopped, the counter database remains intact until the acquired data display is modified, usually horizontally or vertically. At that time, the database is reset and the last displayed acquisition is used to start a new database.

Table 101 :CGRade Commands Summary

Command	Query	Options and Query Returns
n/a	:CGRade:LEVels? (see page 343)	<levels> ::= comma-delimited list of color range levels
:CGRade:LEVels:DISPlay {{0 OFF} {1 ON}} (see page 344)	:CGRade:LEVels:DISPlay? (see page 344)	{0 1}
:CGRade:RESet (see page 345)	n/a	n/a
:CGRade:SCHEME <theme> (see page 346)	:CGRade:SCHEME? (see page 346)	<theme> ::= {TEMPerature INTensity}

Table 101 :CGRade Commands Summary (continued)

Command	Query	Options and Query Returns
:CGRade:SOURce <source> (see page 347)	:CGRade:SOURce? (see page 347)	<source> ::= {CHANnel<n> FUNCTION<m> MATH<m> WMEMemory<r>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format
:CGRade:STATe {{0 OFF} {1 ON}} (see page 348)	:CGRade:STATe? (see page 348)	{0 1}

:CGRade:LEVELs

N (see [page 1730](#))

Query Syntax :CGRade:LEVELs?









The :CGRade:LEVELs? query returns a comma-delimited list of the hit ranges for each color bin. For example:

```
"1,20,21,40,41,81,82,163,164,326,327,653,654,1307"
```

The first two values show the hit range for the color bin with fewest number of hits, the next two values show the hit range for the next color bin, and so on.

The color used for the greatest number of hits (white in both themes) represents pixels with the greatest number to about half that number. The next color represents half as many hits, and so on, until the last range (green in the INTensity theme or dark blue in the TEMPerature theme) represents the remaining range of the fewest number of hits.

The following table shows the approximate counter ranges of each color in the INTensity and TEMPerature color grade themes.

:CGRade:SCHEME		Range (MH = most hits)		
INTensity	TEMPerature	Upper Limit	to	Lower Limit (0 if Upper Limit is 0, Else)
		MH	to	MH/2
		MH/2	to	MH/4
		MH/4	to	MH/8
		MH/8	to	MH/16
		MH/16	to	MH/32
		MH/32	to	MH/64
		MH/64	to	1

Return Format <levels><NL>

<levels> ::= comma-delimited list of hit ranges for each color bin

- See Also**
- **":CGRade:STATE"** on page 348
 - **":CGRade:SOURce"** on page 347
 - **":CGRade:SCHEME"** on page 346
 - **":CGRade:RESet"** on page 345
 - **":CGRade:LEVELs:DISPlay"** on page 344

:CGRade:LEVels:DISPlay

N (see [page 1730](#))

Command Syntax :CGRade:LEVels:DISPlay {{0 | OFF} | {1 | ON}}

The :CGRade:LEVels:DISPlay command enables or disables the display of the color grade key and levels.

Query Syntax :CGRade:LEVels:DISPlay?

The :CGRade:LEVels:DISPlay? query returns whether the color grade key and levels display is enabled.

Return Format <off_on><NL>
{0 | 1}

- See Also**
- [":CGRade:STATE"](#) on page 348
 - [":CGRade:LEVels"](#) on page 343
 - [":CGRade:SOURce"](#) on page 347
 - [":CGRade:SCHeme"](#) on page 346
 - [":CGRade:RESet"](#) on page 345

:CGRade:RESet

N (see [page 1730](#))

Command Syntax :CGRade:RESet

The :CGRade:RESet command zeros the color grade counters.

- See Also**
- [":CGRade:STaTe"](#) on page 348
 - [":CGRade:LEVels"](#) on page 343
 - [":CGRade:SOURce"](#) on page 347
 - [":CGRade:SCHeMe"](#) on page 346
 - [":CGRade:LEVels:DISPlay"](#) on page 344

:CGRade:SCHEME

N (see [page 1730](#))

Command Syntax :CGRade:SCHEME <theme>
 <theme> ::= {TEMPerature | INTensity}

The :CGRade:SCHEME command sets the color theme used by color graded waveform display.

The color grade theme specifies seven colors that represent the ranges of counter values (hits) in the database.

Query Syntax :CGRade:SCHEME?

The :CGRade:SCHEME? query returns the currently set color theme.

Return Format <theme><NL>
 <theme> ::= {TEMP | INT}

- See Also**
- [":CGRade:STATE"](#) on page 348
 - [":CGRade:SOURce"](#) on page 347
 - [":CGRade:LEVels"](#) on page 343
 - [":CGRade:RESet"](#) on page 345
 - [":CGRade:LEVels:DISPlay"](#) on page 344

:CGRade:SOURce

N (see [page 1730](#))

Command Syntax :CGRade:SOURce <source>

<source> ::= {CHANnel<n> | FUNCTION<m> | MATH<m> | WMemory<r>}

<n> ::= 1 to (# analog channels) in NR1 format

<m> ::= 1 to (# math functions) in NR1 format

<r> ::= 1 to (# ref waveforms) in NR1 format

The :CGRade:SOURce command specifies the waveform on which to perform the color grade analysis.

Query Syntax :CGRade:SOURce?

The :CGRade:SOURce? query returns the current color grade analysis waveform source.

Return Format <source><NL>

- See Also**
- [":CGRade:STATe"](#) on page 348
 - [":CGRade:SCHeme"](#) on page 346
 - [":CGRade:LEVels"](#) on page 343
 - [":CGRade:RESet"](#) on page 345
 - [":CGRade:LEVels:DISPlay"](#) on page 344

:CGRade:STATE

N (see [page 1730](#))

Command Syntax :CGRade:STATE {{0 | OFF} | {1 | ON}}

The :CGRade:STATE command enables or disables the color grade waveform display.

Query Syntax :CGRade:STATE?

The :CGRade:STATE? query returns whether the color grade display is enabled.

Return Format <off_on><NL>

{0 | 1}

- See Also**
- [":CGRade:SOURce"](#) on page 347
 - [":CGRade:SCHEME"](#) on page 346
 - [":CGRade:LEVELs"](#) on page 343
 - [":CGRade:RESet"](#) on page 345
 - [":CGRade:LEVELs:DISPlay"](#) on page 344

12 :CHANnel<n> Commands

Control all oscilloscope functions associated with individual analog channels or groups of channels. See "[Introduction to :CHANnel<n> Commands](#)" on page 352.

Table 102 :CHANnel<n> Commands Summary

Command	Query	Options and Query Returns
:CHANnel<n>:BANDwidth <limit> (see page 353)	:CHANnel<n>:BANDwidth? ? [MAXimum] (see page 353)	<limit> ::= 20E6, 200E6, 1.5E9, or 3E9 in NR3 format (depending on oscilloscope bandwidth and settings) <n> ::= 1 to (# analog channels) in NR1 format
:CHANnel<n>:BWLimit { {0 OFF} {1 ON} } (see page 355)	:CHANnel<n>:BWLimit? (see page 355)	{0 1} <n> ::= 1 to (# analog channels) in NR1 format
:CHANnel<n>:COUpling <coupling> (see page 356)	:CHANnel<n>:COUpling? (see page 356)	<coupling> ::= {AC DC} <n> ::= 1 to (# analog channels) in NR1 format
:CHANnel<n>:DISPlay { {0 OFF} {1 ON} } (see page 357)	:CHANnel<n>:DISPlay? (see page 357)	{0 1} <n> ::= 1 to (# analog channels) in NR1 format
:CHANnel<n>:IMPedance <impedance> (see page 358)	:CHANnel<n>:IMPedance? ? (see page 358)	<impedance> ::= {ONEMeg FIFTy} <n> ::= 1 to (# analog channels) in NR1 format
:CHANnel<n>:INVert { {0 OFF} {1 ON} } (see page 359)	:CHANnel<n>:INVert? (see page 359)	{0 1} <n> ::= 1 to (# analog channels) in NR1 format
:CHANnel<n>:LABel <string> (see page 360)	:CHANnel<n>:LABel? (see page 360)	<string> ::= any series of 32 or less ASCII characters enclosed in quotation marks <n> ::= 1 to (# analog channels) in NR1 format

Table 102 :CHANnel<n> Commands Summary (continued)

Command	Query	Options and Query Returns
:CHANnel<n>:OFFSet <offset>[suffix] (see page 361)	:CHANnel<n>:OFFSet? (see page 361)	<offset> ::= Vertical offset value in NR3 format [suffix] ::= {V mV} <n> ::= 1-2 or 1-4; in NR1 format
:CHANnel<n>:PROBe <attenuation> (see page 362)	:CHANnel<n>:PROBe? (see page 362)	<attenuation> ::= Probe attenuation ratio in NR3 format <n> ::= 1-2 or 1-4; in NR1 format
:CHANnel<n>:PROBe:BTN <setting> (see page 363)	:CHANnel<n>:PROBe:BTN ? (see page 363)	<n> ::= 1 to (# analog channels) in NR1 format <setting> ::= {HEADlight INFinimode RSTop SINGle CDISplay AUToscale FTRigger QACTion NACTion NONE}
:CHANnel<n>:PROBe:CAL ibration (see page 364)	n/a	n/a
:CHANnel<n>:PROBe:EXT ernal {{0 OFF} {1 ON}} (see page 366)	:CHANnel<n>:PROBe:EXT ernal? (see page 366)	<n> ::= 1 to (# analog channels) in NR1 format <setting> ::= {0 1}
:CHANnel<n>:PROBe:EXT ernal:GAIN <gain_factor> (see page 367)	:CHANnel<n>:PROBe:EXT ernal:GAIN? (see page 367)	<n> ::= 1 to (# analog channels) in NR1 format <gain_factor> ::= a real number from 0.0001 to 1000 in NR3 format
:CHANnel<n>:PROBe:EXT ernal:UNITs <units> (see page 368)	:CHANnel<n>:PROBe:EXT ernal:UNITs? (see page 368)	<n> ::= 1 to (# analog channels) in NR1 format <units> ::= {VOLT AMPere}
:CHANnel<n>:PROBe:HEA D[:TYPE] <head_param> (see page 369)	:CHANnel<n>:PROBe:HEA D[:TYPE]? (see page 369)	<head_param> ::= {SEND0 SEND6 SEND12 SEND20 DIFF0 DIFF6 DIFF12 DIFF20 DSMA DSMA6 NONE} <n> ::= 1 to (# analog channels) in NR1 format
n/a	:CHANnel<n>:PROBe:ID? (see page 370)	<probe id> ::= unquoted ASCII string up to 11 characters <n> ::= 1 to (# analog channels) in NR1 format

Table 102 :CHANnel<n> Commands Summary (continued)

Command	Query	Options and Query Returns
:CHANnel<n>:PROBe:MMO Del <value> (see page 371)	:CHANnel<n>:PROBe:MMO Del? (see page 371)	<value> ::= {P5205 P5210 P6205 P6241 P6243 P6245 P6246 P6247 P6248 P6249 P6250 P6251 P670X P671X TCP202} <n> ::= 1 to (# analog channels) in NR1 format
:CHANnel<n>:PROBe:MODE <setting> (see page 372)	:CHANnel<n>:PROBe:MODE? (see page 372)	<n> ::= 1 to (# analog channels) in NR1 format <setting> ::= {DIFFerential DOFFset SEA SEB CM}
:CHANnel<n>:PROBe:RSE Nse <value> (see page 373)	:CHANnel<n>:PROBe:RSE Nse? (see page 373)	<value> ::= Ohms in NR3 format <n> ::= 1 to (# analog channels) in NR1 format
:CHANnel<n>:PROBe:SKE W <skew_value> (see page 374)	:CHANnel<n>:PROBe:SKE W? (see page 374)	<skew_value> ::= -100 ns to +100 ns in NR3 format <n> ::= 1 to (# analog channels) in NR1 format
:CHANnel<n>:PROBe:STY Pe <signal type> (see page 375)	:CHANnel<n>:PROBe:STY Pe? (see page 375)	<signal type> ::= {DIFFerential SINGLE} <n> ::= 1 to (# analog channels) in NR1 format
:CHANnel<n>:PROBe:ZOOM {{0 OFF} {1 ON}} (see page 376)	:CHANnel<n>:PROBe:ZOOM? (see page 376)	<setting> ::= {0 1} <n> ::= 1 to (# analog channels) in NR1 format
:CHANnel<n>:PROTection (see page 377)	:CHANnel<n>:PROTection? (see page 377)	{NORM TRIP} <n> ::= 1 to (# analog channels) in NR1 format
:CHANnel<n>:RANGe <range>[suffix] (see page 378)	:CHANnel<n>:RANGe? (see page 378)	<range> ::= Vertical full-scale range value in NR3 format [suffix] ::= {V mV} <n> ::= 1 to (# analog channels) in NR1 format
:CHANnel<n>:SCALe <scale>[suffix] (see page 379)	:CHANnel<n>:SCALe? (see page 379)	<scale> ::= Vertical units per division value in NR3 format [suffix] ::= {V mV} <n> ::= 1 to (# analog channels) in NR1 format

Table 102 :CHANnel<n> Commands Summary (continued)

Command	Query	Options and Query Returns
:CHANnel<n>:UNITs <units> (see page 380)	:CHANnel<n>:UNITs? (see page 380)	<units> ::= {VOLT AMPere} <n> ::= 1 to (# analog channels) in NR1 format
:CHANnel<n>:VERNier {0 OFF} {1 ON} (see page 381)	:CHANnel<n>:VERNier? (see page 381)	{0 1} <n> ::= 1 to (# analog channels) in NR1 format

Introduction to :CHANnel<n> Commands

<n> ::= 1 to (# analog channels) in NR1 format

The CHANnel<n> subsystem commands control an analog channel (vertical or Y-axis of the oscilloscope). Channels are independently programmable for all offset, probe, coupling, bandwidth limit, inversion, vernier, and range (scale) functions. The channel number (1, 2, 3, or 4) specified in the command selects the analog channel that is affected by the command.

A label command provides identifying annotations of up to 10 characters.

You can toggle the channel displays on and off with the :CHANnel<n>:DISPlay command as well as with the root level commands :VIEW and :BLANK.

NOTE

The obsolete CHANnel subsystem is supported.

Reporting the Setup

Use :CHANnel1?, :CHANnel2?, :CHANnel3? or :CHANnel4? to query setup information for the CHANnel<n> subsystem.

Return Format

The following are sample responses from the :CHANnel<n>? query. In this case, the query was issued following a *RST command.

```
:CHAN1:RANG +40.0E+00;OFFS +0.00000E+00;COUP DC;IMP ONEM;DISP 1;BWL 0;
INV 0;LAB "1";UNIT VOLT;PROB +10E+00;PROB:SKEW +0.00E+00;STYP SING
```


:CHANnel<n>:BANDwidth

N (see [page 1730](#))

Command Syntax :CHANnel<n>:BANDwidth <limit>

<limit> ::= 20E6, 200E6, 1.5E9, or 3E9 in NR3 format (depending on oscilloscope bandwidth and settings)

<n> ::= 1 to (# analog channels) in NR1 format

The :CHANnel<n>:BANDwidth command sets the bandwidth limit value and turns on bandwidth limiting (see the :CHANnel<n>:BWLlimit command).

For waveforms with frequencies below the bandwidth limit, turning the bandwidth limit on removes unwanted high frequency noise from the waveform.

Bandwidth limit also limits the trigger signal path of the channel.

You can request any limit; the oscilloscope will choose the one that is greater than or equal to the limit requested. The limits available depend on the bandwidth of oscilloscope, the channel's input impedance setting (:CHANnel<n>:IMPedance), and the channel's V/div setting:

Input Impedance	V/div	Oscilloscope Bandwidth	Limits Available
1M Ohm	>2 mV/div	(all)	20 MHz
	<=2 mV/div	(all)	20 MHz or 200 MHz
50 Ohm	(all)	1 GHz	20 MHz or 200 MHz
		2.5 GHz	20 MHz, 200 MHz, or 1.5 GHz
		4 GHz	20 MHz, 200 MHz, 1.5 GHz, or 3 GHz
		6 GHz	20 MHz, 200 MHz, 1.5 GHz, or 3 GHz

Query Syntax :CHANnel<n>:BANDwidth? [MAXimum]

The :CHANnel<n>:BANDwidth? query returns the current setting of the low-pass filter.

If the bandwidth limit is off, the query returns the full bandwidth of the oscilloscope.

When the MAXimum parameter is used, the oscilloscope's maximum possible bandwidth is returned.

Return Format <limit><NL>

```
<limit> ::= 20E6, 200E6, 1.5E9, or 3E9 in NR3 format  
(depending on oscilloscope bandwidth, input impedance, and  
whether the limiting is off)
```

- See Also**
- **":CHANnel<n>:BWLimit"** on page 355
 - **":CHANnel<n>:IMPedance"** on page 358

:CHANnel<n>:BWLimit

C (see [page 1730](#))

Command Syntax :CHANnel<n>:BWLimit <on_off>

<on_off> ::= {{1 | ON} | {0 | OFF}}

<n> ::= 1 to (# analog channels) in NR1 format

The :CHANnel<n>:BWLimit command enables or disables the bandwidth limit.

To specify the bandwidth limit value, see the :CHANnel<n>:BANDwidth command.

If bandwidth limiting is currently OFF, turning it ON will invoke the lowest possible bandwidth limit (20 MHz).

If bandwidth limiting is currently ON, the ":CHANnel<n>:BWLimit ON" command will not change the current setting.

Query Syntax :CHANnel<n>:BWLimit?

The :CHANnel<n>:BWLimit? query returns whether bandwidth limiting is enabled.

Return Format <on_off><NL>

<on_off> ::= {1 | 0}

- See Also**
- [":CHANnel<n>:BANDwidth"](#) on page 353
 - ["Introduction to :CHANnel<n> Commands"](#) on page 352

:CHANnel<n>:COUpling

C (see [page 1730](#))

Command Syntax :CHANnel<n>:COUpling <coupling>

<coupling> ::= {AC | DC}

<n> ::= 1 to (# analog channels) in NR1 format

The :CHANnel<n>:COUpling command selects the input coupling for the specified channel. The coupling for each analog channel can be set to AC or DC.

Query Syntax :CHANnel<n>:COUpling?

The :CHANnel<n>:COUpling? query returns the current coupling for the specified channel.

Return Format <coupling value><NL>

<coupling value> ::= {AC | DC}

See Also • ["Introduction to :CHANnel<n> Commands"](#) on page 352

:CHANnel<n>:DISPlay

C (see [page 1730](#))

Command Syntax :CHANnel<n>:DISPlay <display value>

<display value> ::= {{1 | ON} | {0 | OFF}}

<n> ::= 1 to (# analog channels) in NR1 format

The :CHANnel<n>:DISPlay command turns the display of the specified channel on or off.

Query Syntax :CHANnel<n>:DISPlay?

The :CHANnel<n>:DISPlay? query returns the current display setting for the specified channel.

Return Format <display value><NL>

<display value> ::= {1 | 0}

- See Also**
- ["Introduction to :CHANnel<n> Commands"](#) on page 352
 - [":VIEW"](#) on page 300
 - [":BLANK"](#) on page 268
 - [":STATus"](#) on page 297
 - [":POD<n>:DISPlay"](#) on page 817
 - [":DIGital<d>:DISPlay"](#) on page 423

:CHANnel<n>:IMPedance

C (see [page 1730](#))

Command Syntax :CHANnel<n>:IMPedance <impedance>

<impedance> ::= {ONEMeg | FIFTy}

<n> ::= 1 to (# analog channels) in NR1 format

The :CHANnel<n>:IMPedance command selects the input impedance setting for the specified analog channel. The legal values for this command are ONEMeg (1 M Ω) and FIFTy (50 Ω).

Query Syntax :CHANnel<n>:IMPedance?

The :CHANnel<n>:IMPedance? query returns the current input impedance setting for the specified channel.

Return Format <impedance value><NL>

<impedance value> ::= {ONEM | FIFT}

See Also • ["Introduction to :CHANnel<n> Commands"](#) on page 352

:CHANnel<n>:INVert

N (see [page 1730](#))

Command Syntax :CHANnel<n>:INVert <invert value>

<invert value> ::= {{1 | ON} | {0 | OFF}}

<n> ::= 1 to (# analog channels) in NR1 format

The :CHANnel<n>:INVert command selects whether or not to invert the input signal for the specified channel. The inversion may be 1 (ON/inverted) or 0 (OFF/not inverted).

Query Syntax :CHANnel<n>:INVert?

The :CHANnel<n>:INVert? query returns the current state of the channel inversion.

Return Format <invert value><NL>

<invert value> ::= {0 | 1}

See Also • ["Introduction to :CHANnel<n> Commands"](#) on page 352

:CHANnel<n>:LABel

N (see [page 1730](#))

Command Syntax :CHANnel<n>:LABel <string>
 <string> ::= quoted ASCII string
 <n> ::= 1 to (# analog channels) in NR1 format

NOTE

Label strings are 32 characters or less, and may contain any commonly used ASCII characters. Labels with more than 32 characters are truncated to 32 characters.

The :CHANnel<n>:LABel command sets the analog channel label to the string that follows. Setting a label for a channel also adds the name to the label list in non-volatile memory (replacing the oldest label in the list).

Query Syntax :CHANnel<n>:LABel?

The :CHANnel<n>:LABel? query returns the label associated with a particular analog channel.

Return Format <string><NL>
 <string> ::= quoted ASCII string

- See Also**
- ["Introduction to :CHANnel<n> Commands"](#) on page 352
 - [":DISPlay:LABel"](#) on page 446
 - [":DIGital<d>:LABel"](#) on page 424
 - [":DISPlay:LABList"](#) on page 447
 - [":BUS<n>:LABel"](#) on page 328

Example Code

```
' LABEL - This command allows you to write a name (32 characters
' maximum) next to the channel number. It is not necessary, but
' can be useful for organizing the display.
myScope.WriteString ":CHANnel1:LABel " "CAL 1" " " ' Label ch1 "CAL 1".
myScope.WriteString ":CHANnel12:LABel " "CAL2" " " ' Label ch1 "CAL2".
```

See complete example programs at: [Chapter 50](#), "Programming Examples," starting on page 1739

:CHANnel<n>:OFFSet

C (see [page 1730](#))

Command Syntax :CHANnel<n>:OFFSet <offset> [<suffix>]
 <offset> ::= Vertical offset value in NR3 format
 <suffix> ::= {V | mV}
 <n> ::= 1 to (# analog channels) in NR1 format

The :CHANnel<n>:OFFSet command sets the value that is represented at center screen for the selected channel. The range of legal values varies with the value set by the :CHANnel<n>:RANGe and :CHANnel<n>:SCALe commands. If you set the offset to a value outside of the legal range, the offset value is automatically set to the nearest legal value. Legal values are affected by the probe attenuation setting.

Query Syntax :CHANnel<n>:OFFSet?

The :CHANnel<n>:OFFSet? query returns the current offset value for the selected channel.

Return Format <offset><NL>
 <offset> ::= Vertical offset value in NR3 format

- See Also**
- ["Introduction to :CHANnel<n> Commands"](#) on page 352
 - [":CHANnel<n>:RANGe"](#) on page 378
 - [":CHANnel<n>:SCALe"](#) on page 379
 - [":CHANnel<n>:PROBe"](#) on page 362

:CHANnel<n>:PROBe

C (see [page 1730](#))

Command Syntax :CHANnel<n>:PROBe <attenuation>

<attenuation> ::= probe attenuation ratio in NR3 format

<n> ::= 1 to (# analog channels) in NR1 format

The obsolete attenuation values X1, X10, X20, X100 are also supported.

The :CHANnel<n>:PROBe command specifies the probe attenuation factor for the selected channel.

The probe attenuation factor may be from 0.001 to 10000.

This command does not change the actual input sensitivity of the oscilloscope. It changes the reference constants for scaling the display factors, for making automatic measurements, and for setting trigger levels.

If an AutoProbe probe is connected to the oscilloscope, the attenuation value cannot be changed from the sensed value. Attempting to set the oscilloscope to an attenuation value other than the sensed value produces an error.

Query Syntax :CHANnel<n>:PROBe?

The :CHANnel<n>:PROBe? query returns the current probe attenuation factor for the selected channel.

Return Format <attenuation><NL>

<attenuation> ::= probe attenuation ratio in NR3 format

- See Also**
- ["Introduction to :CHANnel<n> Commands"](#) on page 352
 - [":CHANnel<n>:RANGe"](#) on page 378
 - [":CHANnel<n>:SCALE"](#) on page 379
 - [":CHANnel<n>:OFFSet"](#) on page 361

Example Code

```
' CHANNEL_PROBE - Sets the probe attenuation factor for the
' selected channel. The probe attenuation factor may be set
' from 0.001 to 10000.
myScope.WriteString ":CHANnel1:PROBe 10" ' Set Probe to 10:1.
```

See complete example programs at: [Chapter 50](#), "Programming Examples," starting on page 1739

:CHANnel<n>:PROBe:BTN

N (see [page 1730](#))

Command Syntax :CHANnel<n>:PROBe:BTN <setting>

<setting> ::= {HEADlight | INFiniimode | RSTop | SINGLE | CDISplay
| AUToscale | FTRigger | QACTion | NACTion | NONE}

<n> ::= 1 to (# analog channels) in NR1 format

For N275xA InfiniiMode probes, the :CHANnel<n>:PROBe:BTN command sets the probe's quick-action button mode:

- HEADlight – Pressing the probe's quick-action button toggles the probe headlight on or off. Holding the quick-action button adjusts the intensity of the probe's headlight.
- INFiniimode – Cycles through the InfiniiMode settings (see :CHANnel<n>:PROBe:MODE).
- RSTop (Run/Stop) – Toggles between continuous data acquisition (running) and stopping data acquisitions (same as the oscilloscope's **[Run/Stop]** key).
- SINGLE – Performs a single acquisition on the oscilloscope (same as the oscilloscope's **[Single]** key).
- CDISplay – Clears the oscilloscope display.
- AUToscale – Performs an oscilloscope Autoscale operation.
- FTRigger (Force Trigger) – Performs an oscilloscope "force trigger".
- QACTion (Quick Action) – Performs the quick action configured on the oscilloscope (see the oscilloscope's *user's guide* for more information).
- NACTion (No Action) – Disables the probe's quick-action button.
- NONE – When a probe does not have a quick-action button, this is the only valid setting.

Query Syntax :CHANnel<n>:PROBe:BTN?

The :CHANnel<n>:PROBe:BTN? query returns the N275xA InfiniiMode probe's quick-action button setting.

Return Format <setting><NL>

<setting> ::= {HEAD | INF | RST | SING | CDIS | AUT | FTR | QACT
| NACT | NONE}

See Also • [":CHANnel<n>:PROBe:MODE"](#) on page 372

:CHANnel<n>:PROBe:CALibration

N (see [page 1730](#))

Command Syntax :CHANnel<n>:PROBe:CALibration

The :CHANnel<n>:PROBe:CALibration command begins the probe degauss operation. For the N7026A and N2893A probes only.

:CHANnel<n>:PROBe:BTN

N (see [page 1730](#))

Command Syntax :CHANnel<n>:PROBe:BTN <setting>

<setting> ::= {HEADlight | INFiniimode | RSTop | SINGLE | CDISplay
| AUToscale | FTRigger | QACTion | NACTion | NONE}

<n> ::= 1 to (# analog channels) in NR1 format

For N275xA InfiniiMode probes, the :CHANnel<n>:PROBe:BTN command sets the probe's quick-action button mode:

- HEADlight – Pressing the probe's quick-action button toggles the probe headlight on or off. Holding the quick-action button adjusts the intensity of the probe's headlight.
- INFiniimode – Cycles through the InfiniiMode settings (see :CHANnel<n>:PROBe:MODE).
- RSTop (Run/Stop) – Toggles between continuous data acquisition (running) and stopping data acquisitions (same as the oscilloscope's **[Run/Stop]** key).
- SINGLE – Performs a single acquisition on the oscilloscope (same as the oscilloscope's **[Single]** key).
- CDISplay – Clears the oscilloscope display.
- AUToscale – Performs an oscilloscope Autoscale operation.
- FTRigger (Force Trigger) – Performs an oscilloscope "force trigger".
- QACTion (Quick Action) – Performs the quick action configured on the oscilloscope (see the oscilloscope's *user's guide* for more information).
- NACTion (No Action) – Disables the probe's quick-action button.
- NONE – When a probe does not have a quick-action button, this is the only valid setting.

Query Syntax :CHANnel<n>:PROBe:BTN?

The :CHANnel<n>:PROBe:BTN? query returns the N275xA InfiniiMode probe's quick-action button setting.

Return Format <setting><NL>

<setting> ::= {HEAD | INF | RST | SING | CDIS | AUT | FTR | QACT
| NACT | NONE}

See Also • [":CHANnel<n>:PROBe:MODE"](#) on page 372

:CHANnel<n>:PROBe:EXTeRnal

N (see [page 1730](#))

Command Syntax :CHANnel<n>:PROBe:EXTeRnal {{0 | OFF} | {1 | ON}}

<n> ::= 1 to (# analog channels) in NR1 format

The :CHANnel<n>:PROBe:EXTeRnal command enables or disables External Scaling on the analog input channel. External Scaling can apply additional gain to the input channel to account for additional attenuators, adapters, etc., in the probing system.

Query Syntax :CHANnel<n>:PROBe:EXTeRnal?

The :CHANnel<n>:PROBe:EXTeRnal? query returns whether External Scaling is enabled (1) or disabled (0).

Return Format <setting><NL>

<setting> ::= {0 | 1}

- See Also**
- [":CHANnel<n>:PROBe:EXTeRnal:GAIN"](#) on page 367
 - [":CHANnel<n>:PROBe:EXTeRnal:UNITs"](#) on page 368

:CHANnel<n>:PROBe:EXTeRnal:GAIN

N (see [page 1730](#))

Command Syntax :CHANnel<n>:PROBe:EXTeRnal:GAIN <gain_factor>

<gain_factor> ::= a real number from 0.0001 to 1000 in NR3 format

<n> ::= 1 to (# analog channels) in NR1 format

The :CHANnel<n>:PROBe:EXTeRnal:GAIN command sets the gain associated with External Scaling.

Query Syntax :CHANnel<n>:PROBe:EXTeRnal:GAIN?

The :CHANnel<n>:PROBe:EXTeRnal:GAIN? query returns the External Scaling gain setting.

Return Format <gain_factor><NL>

- See Also**
- [":CHANnel<n>:PROBe:EXTeRnal"](#) on page 366
 - [":CHANnel<n>:PROBe:EXTeRnal:UNITs"](#) on page 368

:CHANnel<n>:PROBe:EXTeRnal:UNITs

N (see [page 1730](#))

Command Syntax :CHANnel<n>:PROBe:EXTeRnal:UNITs <units>

<units> ::= {VOLT | AMPere}

<n> ::= 1 to (# analog channels) in NR1 format

The :CHANnel<n>:PROBe:EXTeRnal:UNITs command sets the measurement units for the connected probe. Select VOLT for a voltage probe and select AMPere for a current probe. Measurement results, channel sensitivity, and trigger level will reflect the measurement units you select.

Query Syntax :CHANnel<n>:PROBe:EXTeRnal:UNITs?

The :CHANnel<n>:PROBe:EXTeRnal:UNITs? query returns the current units setting for the specified channel.

Return Format <units><NL>

<units> ::= {VOLT | AMP}

- See Also**
- [":CHANnel<n>:PROBe:EXTeRnal"](#) on page 366
 - [":CHANnel<n>:PROBe:EXTeRnal:GAIN"](#) on page 367

:CHANnel<n>:PROBe:HEAD[:TYPE]

C (see [page 1730](#))

Command Syntax

NOTE

This command is valid only for the 113xA Series probes.

```
:CHANnel<n>:PROBe:HEAD[:TYPE] <head_param>
<head_param> ::= {SEND0 | SEND6 | SEND12 | SEND20 | DIFF0 | DIFF6
                  | DIFF12 | DIFF20 | DSMA | DSMA6 | NONE}
<n> ::= {1 | 2 | 3 | 4}
```

The :CHANnel<n>:PROBe:HEAD[:TYPE] command sets an analog channel probe head type and dB value. You can choose from:

- SEND0 – Single-ended, 0 dB.
- SEND6 – Single-ended, 6 dB.
- SEND12 – Single-ended, 12 dB.
- SEND20 – Single-ended, 20 dB.
- DIFF0 – Differential, 0 dB.
- DIFF6 – Differential, 6 dB.
- DIFF12 – Differential, 12 dB.
- DIFF20 – Differential, 20 dB.
- DSMA – Differential SMA probe head, 0 dB.
- DSMA6 – Differential SMA probe head, 6 dB.

Query Syntax :CHANnel<n>:PROBe:HEAD[:TYPE] ?

The :CHANnel<n>:PROBe:HEAD[:TYPE]? query returns the current probe head type setting for the selected channel.

Return Format <head_param><NL>

```
<head_param> ::= {SEND0 | SEND6 | SEND12 | SEND20 | DIFF0 | DIFF6
                  | DIFF12 | DIFF20 | DSMA | DSMA6 | NONE}
```

- See Also**
- ["Introduction to :CHANnel<n> Commands"](#) on page 352
 - [":CHANnel<n>:PROBe"](#) on page 362
 - [":CHANnel<n>:PROBe:ID"](#) on page 370
 - [":CHANnel<n>:PROBe:SKEW"](#) on page 374
 - [":CHANnel<n>:PROBe:STYPe"](#) on page 375

:CHANnel<n>:PROBe:ID

C (see [page 1730](#))

Query Syntax :CHANnel<n>:PROBe:ID?

<n> ::= 1 to (# analog channels) in NR1 format

The :CHANnel<n>:PROBe:ID? query returns the type of probe attached to the specified oscilloscope channel.

Return Format <probe id><NL>

<probe id> ::= unquoted ASCII string up to 11 characters

Some of the possible returned values are:

- 1131A
- 1132A
- 1134A
- 1147A
- 1153A
- 1154A
- 1156A
- 1157A
- 1158A
- 1159A
- AutoProbe
- E2621A
- E2622A
- E2695A
- E2697A
- HP1152A
- HP1153A
- NONE
- Probe
- Unknown
- Unsupported

See Also • ["Introduction to :CHANnel<n> Commands"](#) on page 352

:CHANnel<n>:PROBe:MMODEl

N (see [page 1730](#))

Command Syntax :CHANnel<n>:PROBe:MMODEl <value>

<value> ::= {P5205 | P5210 | P6205 | P6241 | P6243 | P6245 | P6246
| P6247 | P6248 | P6249 | P6250 | P6251 | P670X | P671X | TCP202}

<n> ::= 1 to (# analog channels) in NR1 format

The :CHANnel<n>:PROBe:MMODEl command sets the model number of the supported Tektronix probe.

Query Syntax :CHANnel<n>:PROBe:MMODEl?

The :CHANnel<n>:PROBe:MMODEl? query returns the model number setting.

Return Format <value><NL>

<value> ::= {P5205 | P5210 | P6205 | P6241 | P6243 | P6245 | P6246
| P6247 | P6248 | P6249 | P6250 | P6251 | P670X | P671X | TCP202}

See Also • [":CHANnel<n>:PROBe:ID"](#) on page 370

:CHANnel<n>:PROBe:MODE

N (see [page 1730](#))

Command Syntax :CHANnel<n>:PROBe:MODE <setting>

<setting> ::= {DIFFerential | DOFFset | SEA | SEB | CM}

<n> ::= 1 to (# analog channels) in NR1 format

For N275xA InfiniiMode probes, the :CHANnel<n>:PROBe:MODE command sets the probe's mode:

- DIFFerential – Differential.
- DOFFset – Differential with Offset.
- SEA – Single-Ended, side A.
- SEB – Single-Ended, side B.
- CM – Common Mode.

Query Syntax :CHANnel<n>:PROBe:MODE?

The :CHANnel<n>:PROBe:MODE? query returns the N275xA InfiniiMode probe's mode setting.

Return Format <setting><NL>

<setting> ::= {DIFF | DOFF | SEA | SEB | CM}

See Also • [":CHANnel<n>:PROBe:BTN"](#) on page 363

:CHANnel<n>:PROBe:RSENse

N (see [page 1730](#))

Command Syntax :CHANnel<n>:PROBe:RSENse <value>

<value> ::= Ohms in NR3 format

<n> ::= 1 to (# analog channels) in NR1 format

When the N2820A high-sensitivity current probe is used with the N2825A user-defined R-sense head, the :CHANnel<n>:PROBe:RSENse command specifies the value of the R-sense resistor that is being probed in the device under test (DUT). Supported R-sense resistor values are from 1 m Ω to 1M Ω .

Query Syntax :CHANnel<n>:PROBe:RSENse?

The :CHANnel<n>:PROBe:RSENse? query returns the R-sense resistor value setting.

When the N2820A high-sensitivity current probe is not attached, the query returns "INF".

When the N2820A high-sensitivity current probe is attached and a special head is attached to the probe, the query returns the value of the special head. For example, if the head is a "20 m Ω " head, the query returns 0.02.

Return Format {<value> | INF}<NL>

<value> ::= Ohms in NR3 format

- See Also**
- [":CHANnel<n>:PROBe:ZOOM"](#) on page 376
 - [":MEASure:DUAL:CHARge"](#) on page 677
 - [":MEASure:DUAL:VAMplitude"](#) on page 678
 - [":MEASure:DUAL:VAverage"](#) on page 679
 - [":MEASure:DUAL:VBASe"](#) on page 680
 - [":MEASure:DUAL:VPP"](#) on page 681
 - [":MEASure:DUAL:VRMS"](#) on page 682

:CHANnel<n>:PROBe:SKEW

C (see [page 1730](#))

Command Syntax :CHANnel<n>:PROBe:SKEW <skew value>
 <skew value> ::= skew time in NR3 format
 <skew value> ::= -100 ns to +100 ns
 <n> ::= 1 to (# analog channels) in NR1 format

The :CHANnel<n>:PROBe:SKEW command sets the channel-to-channel skew factor for the specified channel. Each analog channel can be adjusted + or -100 ns for a total of 200 ns difference between channels. You can use the oscilloscope's probe skew control to remove cable-delay errors between channels.

Query Syntax :CHANnel<n>:PROBe:SKEW?

The :CHANnel<n>:PROBe:SKEW? query returns the current probe skew setting for the selected channel.

Return Format <skew value><NL>
 <skew value> ::= skew value in NR3 format

See Also • ["Introduction to :CHANnel<n> Commands"](#) on page 352

:CHANnel<n>:PROBe:STYPe

C (see [page 1730](#))

Command Syntax

NOTE

This command is valid only for the 113xA Series probes.

```
:CHANnel<n>:PROBe:STYPe <signal type>
<signal type> ::= {DIFFerential | SINGle}
<n> ::= 1 to (# analog channels) in NR1 format
```

The :CHANnel<n>:PROBe:STYPe command sets the channel probe signal type (STYPe) to differential or single-ended when using the 113xA Series probes and determines how offset is applied.

When single-ended is selected, the :CHANnel<n>:OFFSet command changes the offset value of the probe amplifier. When differential is selected, the :CHANnel<n>:OFFSet command changes the offset value of the channel amplifier.

Query Syntax :CHANnel<n>:PROBe:STYPe?

The :CHANnel<n>:PROBe:STYPe? query returns the current probe signal type setting for the selected channel.

Return Format <signal type><NL>

```
<signal type> ::= {DIFF | SING}
```

- See Also**
- ["Introduction to :CHANnel<n> Commands"](#) on page 352
 - [":CHANnel<n>:OFFSet"](#) on page 361

:CHANnel<n>:PROBe:ZOOM

N (see [page 1730](#))

Command Syntax :CHANnel<n>:PROBe:ZOOM {{0 | OFF} | {1 | ON}}

<n> ::= 1 to (# analog channels) in NR1 format

When the N2820A high-sensitivity current probe is used with both the Primary and Secondary cables, the :CHANnel<n>:PROBe:ZOOM command specifies whether this cable will have the Zoom In waveform (ON) or the Zoom Out waveform (OFF). The other cable will have the opposite waveform.

Query Syntax :CHANnel<n>:PROBe:ZOOM?

The :CHANnel<n>:PROBe:ZOOM? query returns the zoom setting.

Return Format <setting><NL>

<setting> ::= {0 | 1}

- See Also**
- [":CHANnel<n>:PROBe:RSENse"](#) on page 373
 - [":MEASure:DUAL:CHARge"](#) on page 677
 - [":MEASure:DUAL:VAMPlitude"](#) on page 678
 - [":MEASure:DUAL:VAverage"](#) on page 679
 - [":MEASure:DUAL:VBASe"](#) on page 680
 - [":MEASure:DUAL:VPP"](#) on page 681
 - [":MEASure:DUAL:VRMS"](#) on page 682

:CHANnel<n>:PROTection

N (see [page 1730](#))

Command Syntax :CHANnel<n>:PROTection[:CLEar]

<n> ::= 1 to (# analog channels) in NR1 format | 4}

When the analog channel input impedance is set to 50 Ω , the input channels are protected against overvoltage. When an overvoltage condition is sensed, the input impedance for the channel is automatically changed to 1 M Ω .

The :CHANnel<n>:PROTection[:CLEar] command is used to clear (reset) the overload protection. It allows the channel to be used again in 50 Ω mode after the signal that caused the overload has been removed from the channel input.

Reset the analog channel input impedance to 50 Ω (see "[:CHANnel<n>:IMPedance](#)" on page 358) after clearing the overvoltage protection.

Query Syntax :CHANnel<n>:PROTection?

The :CHANnel<n>:PROTection query returns the state of the input protection for CHANnel<n>. If a channel input has experienced an overload, TRIP (tripped) will be returned; otherwise NORM (normal) is returned.

Return Format {NORM | TRIP}<NL>

- See Also**
- "[Introduction to :CHANnel<n> Commands](#)" on page 352
 - "[:CHANnel<n>:COUPling](#)" on page 356
 - "[:CHANnel<n>:IMPedance](#)" on page 358
 - "[:CHANnel<n>:PROBe](#)" on page 362

:CHANnel<n>:RANGe

C (see [page 1730](#))

Command Syntax :CHANnel<n>:RANGe <range>[<suffix>]

<range> ::= vertical full-scale range value in NR3 format

<suffix> ::= {V | mV}

<n> ::= 1 to (# analog channels) in NR1 format

The :CHANnel<n>:RANGe command defines the full-scale vertical axis of the selected channel. When using 1:1 probe attenuation, legal values for the range are from 8 mV to 40 V.

If the probe attenuation is changed, the range value is multiplied by the probe attenuation factor.

Query Syntax :CHANnel<n>:RANGe?

The :CHANnel<n>:RANGe? query returns the current full-scale range setting for the specified channel.

Return Format <range_argument><NL>

<range_argument> ::= vertical full-scale range value in NR3 format

- See Also**
- ["Introduction to :CHANnel<n> Commands"](#) on page 352
 - [":CHANnel<n>:SCALE"](#) on page 379
 - [":CHANnel<n>:PROBE"](#) on page 362

Example Code

```
' CHANNEL_RANGE - Sets the full scale vertical range in volts. The
' range value is 8 times the volts per division.
myScope.WriteString ":CHANnel1:RANGe 8" ' Set the vertical range to
8 volts.
```

See complete example programs at: [Chapter 50](#), "Programming Examples," starting on page 1739

:CHANnel<n>:SCALE

N (see [page 1730](#))

Command Syntax :CHANnel<n>:SCALE <scale>[<suffix>]

<scale> ::= vertical units per division in NR3 format

<suffix> ::= {V | mV}

<n> ::= 1 to (# analog channels) in NR1 format

The :CHANnel<n>:SCALE command sets the vertical scale, or units per division, of the selected channel.

If the probe attenuation is changed, the scale value is multiplied by the probe's attenuation factor.

Query Syntax :CHANnel<n>:SCALE?

The :CHANnel<n>:SCALE? query returns the current scale setting for the specified channel.

Return Format <scale value><NL>

<scale value> ::= vertical units per division in NR3 format

- See Also**
- ["Introduction to :CHANnel<n> Commands"](#) on page 352
 - [":CHANnel<n>:RANGE"](#) on page 378
 - [":CHANnel<n>:PROBE"](#) on page 362

:CHANnel<n>:UNITs

N (see [page 1730](#))

Command Syntax :CHANnel<n>:UNITs <units>

<units> ::= {VOLT | AMPere}

<n> ::= 1 to (# analog channels) in NR1 format

The :CHANnel<n>:UNITs command sets the measurement units for the connected probe. Select VOLT for a voltage probe and select AMPere for a current probe. Measurement results, channel sensitivity, and trigger level will reflect the measurement units you select.

Query Syntax :CHANnel<n>:UNITs?

The :CHANnel<n>:UNITs? query returns the current units setting for the specified channel.

Return Format <units><NL>

<units> ::= {VOLT | AMP}

- See Also**
- ["Introduction to :CHANnel<n> Commands"](#) on page 352
 - [":CHANnel<n>:RANGe"](#) on page 378
 - [":CHANnel<n>:PROBe"](#) on page 362
 - [":EXternal:UNITs"](#) on page 465

:CHANnel<n>:VERNier

N (see [page 1730](#))

Command Syntax :CHANnel<n>:VERNier <vernier value>

<vernier value> ::= {{1 | ON} | {0 | OFF}}

<n> ::= 1 to (# analog channels) in NR1 format

The :CHANnel<n>:VERNier command specifies whether the channel's vernier (fine vertical adjustment) setting is ON (1) or OFF (0).

Query Syntax :CHANnel<n>:VERNier?

The :CHANnel<n>:VERNier? query returns the current state of the channel's vernier setting.

Return Format <vernier value><NL>

<vernier value> ::= {0 | 1}

See Also • ["Introduction to :CHANnel<n> Commands"](#) on page 352

13 :CLOCK Commands

The :CLOCK commands specify the clock recovery options.

Table 103 :CLOCK Commands Summary

Command	Query	Options and Query Returns
:CLOCK {{0 OFF} {1 ON}} (see page 385)	:CLOCK? (see page 385)	{0 1}
:CLOCK:METHOD <method> (see page 386)	:CLOCK:METHOD? (see page 387)	<p><method> ::= {<fixed> <fopll> <sopll> <explicit>}</p> <p><fixed> ::= FIXEd, {AUTO SEMI[, <data_rate>] <data_rate>}</p> <p><fopll> ::= FOPLL, <data_rate>, <loop_bandwidth></p> <p><sopll> ::= SOPLL, <data_rate>, <loop_bandwidth>, <damping_factor></p> <p><explicit> ::= EXPLiCIt, <source>, {RISing FALLing BOTH}[, <multiplier>]</p> <p><data_rate> ::= the data signal's expected bits/second rate in NR3 format</p> <p><loop_bandwidth> ::= the -3 dB bandwidth specification of PLL in NR3 format</p> <p><damping_factor> ::= of the PLL's observed jitter transfer function in NR3 format</p> <p><source> ::= explicit clock source, CHANnel<n></p> <p><n> ::= 1 to (# analog channels) in NR1 format</p> <p><multiplier> ::= explicit clock multiplier from 1 to 1000 in NR1 format</p>

:CLOCK

N (see [page 1730](#))

Command Syntax :CLOCK {{0 | OFF} | {1 | ON}}

The :CLOCK command turns the display of the recovered clock on or off.

Math function 1 is used to display the recovered clock.

Query Syntax :CLOCK?

The :CLOCK? query returns whether the recovered clock is currently displayed.

Return Format <off_on><NL>

{0 | 1}

See Also • [":CLOCK:METHod"](#) on page 386

:CLOCK:METHOD

N (see [page 1730](#))

Command Syntax :CLOCK:METHOD <method>

<method> ::= {<fixed> | <fopll> | <sopll> | <explicit>}

<fixed> ::= FIXed, {AUTO | SEMI[, <data_rate>] | <data_rate>}

<fopll> ::= FOPLl, <data_rate>, <loop_bandwidth>

<sopll> ::= SOPLl, <data_rate>, <loop_bandwidth>, <damping_factor>

<explicit> ::= EXPLicit, <source>, {RISing | FALLing | BOTH}[, <multiplier>]

<data_rate> ::= the data signal's expected bits/second rate in NR3 format

<loop_bandwidth> ::= the -3 dB bandwidth specification of PLL in NR3 format

<damping_factor> ::= of the PLL's observed jitter transfer function in NR3 format

<source> ::= explicit clock source, CHANNEL<n>

<n> ::= 1 to (# analog channels) in NR1 format

<multiplier> ::= explicit clock multiplier from 1 to 1000 in NR1 format

The :CLOCK:METHOD command sets the clock recovery method:

- FIXed – The clock is assumed to be a constant frequency, and the data rate recovery options are:
 - AUTO – The clock is recovered using the signal edge database only. The narrowest pulse is presumed to be an isolated one or zero.
 - SEMI – The clock is recovered using the expected nominal data rate as a "seed" and the signal edge database.
 - <data_rate> – The expected nominal data rate you enter is used. It should be the reciprocal of the signal's unit interval.
- FOPLl – With First Order PLL, the clock is recovered using the DSP-modeled response of an ideal first-order hardware PLL.
- SOPLl – With Second Order PLL, the clock is recovered using the DSP-modeled response of an ideal Type II, second-order hardware PLL.

Typical damping factor values are 1.0, which is critically damped, and 0.707, which is considered ideal or optimal because of its fast settling time (optimally flat) and Butterworth type response. Values less than 1 are underdamped, and values greater than 1 are overdamped.

- EXPLicit – The clock is recovered from a second signal in your device under test, with a multiplier from 1 to 1000 applied.

Query Syntax :CLOCK:METHOD?

The :CLOCK:METHOD? query returns the currently specified clock recovery method.

Return Format <method><NL>

See Also • **":CLOCK"** on page 385

14 :COMPLIance Commands

Control the license-enabled USB 2.0 signal quality analysis feature.

Table 104 :COMPLIance Commands Summary

Command	Query	Options and Query Returns
:COMPLIance:USB:AUTOsetup (see page 390)	n/a	n/a
:COMPLIance:USB:HUBS <number> (see page 391)	:COMPLIance:USB:HUBS? (see page 391)	<number> ::= 0-5 in NR1 format
:COMPLIance:USB:RUN (see page 392)	n/a	n/a
:COMPLIance:USB:SOURce:ADJacent <source> (see page 393)	:COMPLIance:USB:SOURce:ADJacent? (see page 393)	<source> ::= {CHANnel<n>}
:COMPLIance:USB:SOURce:DIFFerential <source> (see page 394)	:COMPLIance:USB:SOURce:DIFFerential? (see page 394)	<source> ::= {CHANnel<n>}
:COMPLIance:USB:SOURce:DMINus <source> (see page 395)	:COMPLIance:USB:SOURce:DMINus? (see page 395)	<source> ::= {CHANnel<n>}
:COMPLIance:USB:SOURce:DPLus <source> (see page 396)	:COMPLIance:USB:SOURce:DPLus? (see page 396)	<source> ::= {CHANnel<n>}
:COMPLIance:USB:TEST <test> (see page 397)	:COMPLIance:USB:TEST? (see page 397)	<test> ::= {DHSS HHSS DLSS HLSS DFSS HFSS}
:COMPLIance:USB:TEST:CONNECTION <connection> (see page 398)	:COMPLIance:USB:TEST:CONNECTION? (see page 398)	<connection> ::= {SINGLEended DIFFerential}
:COMPLIance:USB:TEST:TYPE <type> (see page 399)	:COMPLIance:USB:TEST:TYPE? (see page 399)	<type> ::= {NEARend FARend}

:COMPLIance:USB:AUTOsetup

N (see [page 1730](#))

Command Syntax :COMPLIance:USB:AUTOsetup

The :COMPLIance:USB:AUTOsetup command automatically sets up the oscilloscope for the selected signal quality test and USB compliance test packets. Automatically set are:

- Horizontal scale and delay.
- Analog input channel(s) scale and vertical offset.
- Trigger mode and trigger level.

The :COMPLIance:USB:AUTOsetup command causes the oscilloscope to run (that is, capture acquisitions that meet the trigger condition).

If you are testing the signal quality of real-world packets (instead of USB compliance test packets), you may need to adjust the auto setup.

Note that gating of measurements can only be done via the oscilloscope's horizontal controls. This can be done after the :COMPLIance:USB:AUTOsetup command and before the :COMPLIance:USB:RUN command. The horizontal controls should be adjusted so that only the data to be tested is on screen when the :COMPLIance:USB:RUN command is executed. This is normally one packet of data.

- See Also**
- [":COMPLIance:USB:TEST"](#) on page 397
 - [":COMPLIance:USB:TEST:TYPE"](#) on page 399
 - [":COMPLIance:USB:TEST:CONNECTION"](#) on page 398
 - [":COMPLIance:USB:RUN"](#) on page 392

:COMpliance:USB:HUBS

N (see [page 1730](#))

Command Syntax :COMpliance:USB:HUBS <number>

<number> ::= 0-5 in NR1 format

The :COMpliance:USB:HUBS command specifies the number of internal hubs between the host and the test point.

When the Near-end test type is selected, you can specify 0 to 5 hubs.

When the Far-end test type is selected, the number of hubs is set to 0.

The specified number of hubs affects the test limits for the Sync results and the EOP Width results.

Query Syntax :COMpliance:USB:HUBS?

The :COMpliance:USB:HUBS? query returns the specified the number of internal hubs.

Return Format <number><NL>

<number> ::= 0-5 in NR1 format

- See Also**
- [":COMpliance:USB:TEST"](#) on page 397
 - [":COMpliance:USB:TEST:TYPE"](#) on page 399
 - [":COMpliance:USB:SOURce:DPLus"](#) on page 396
 - [":COMpliance:USB:SOURce:DMINus"](#) on page 395
 - [":COMpliance:USB:SOURce:ADJacent"](#) on page 393
 - [":COMpliance:USB:SOURce:DIFFerential"](#) on page 394

:COMPLIance:USB:RUN

N (see [page 1730](#))

Command Syntax

`:COMPLIance:USB:RUN`

The `:COMPLIance:USB:RUN` command runs the selected signal quality test.

Please be patient as tests can take several minutes to complete.

When tests are run, the oscilloscope stops acquisitions if they are running, analyzes the data on screen, and then displays the results. The analyzed acquisition remains on screen and can be viewed by moving or dismissing the results dialog.

You can run tests when the oscilloscope is already stopped. This is useful in the case of embedded hosts (and other cases) where the device under test (DUT) may not easily be placed in a test mode, and you want to analyze already acquired data.

- See Also**
- [":COMPLIance:USB:TEST"](#) on page 397
 - [":COMPLIance:USB:AUTosetup"](#) on page 390
 - ["*OPC \(Operation Complete\)"](#) on page 242
 - [":SAVE:COMPLIance:USB\[:START\]"](#) on page 948

:COMpliance:USB:SOURce:ADJacent

N (see [page 1730](#))

Command Syntax :COMpliance:USB:SOURce:ADJacent <source>

<source> ::= {CHANnel<n>}

<n> ::= 1 to (# analog channels) in NR1 format

The :COMpliance:USB:SOURce:ADJacent command specifies the analog input channel that is probing the adjacent D+ or D- signal.

When the Device Full Speed Signal Quality test is selected, the specified channel probes the adjacent D+ signal.

When the Device Low Speed Signal Quality test is selected, this specified channel probes the adjacent D- signal.

Query Syntax :COMpliance:USB:SOURce:ADJacent?

The :COMpliance:USB:SOURce:ADJacent? query returns the specified analog input channel.

Return Format <source><NL>

<source> ::= {CHAN<n>}

- See Also**
- [":COMpliance:USB:SOURce:DPLus"](#) on page 396
 - [":COMpliance:USB:SOURce:DMINus"](#) on page 395

:COMPLIance:USB:SOURce:DIFFerential

N (see [page 1730](#))

Command Syntax :COMPLIance:USB:SOURce:DIFFerential <source>

<source> ::= {CHANnel<n>}

<n> ::= 1 to (# analog channels) in NR1 format

The :COMPLIance:USB:SOURce:DIFFerential command specifies the analog input channel whose differential probe is connected to the Hi-Speed signal to be tested.

Query Syntax :COMPLIance:USB:SOURce:DIFFerential?

The :COMPLIance:USB:SOURce:DIFFerential? query returns the specified analog input channel.

Return Format <source><NL>

<source> ::= {CHAN<n>}

- See Also**
- [":COMPLIance:USB:TEST"](#) on page 397
 - [":COMPLIance:USB:TEST:CONNecTion"](#) on page 398

:COMpliance:USB:SOURce:DMINus

N (see [page 1730](#))

Command Syntax :COMpliance:USB:SOURce:DMINus <source>

<source> ::= {CHANnel<n>}

<n> ::= 1 to (# analog channels) in NR1 format

The :COMpliance:USB:SOURce:DMINus command specifies the analog input channel that is probing the D- signal.

On 4-channel oscilloscopes, you are forced to use different channel pairs for the D+ and D- signals. This provides the maximum sample rate. (Channels 1 and 2 are one pair and channels 3 and 4 are the other pair.)

Query Syntax :COMpliance:USB:SOURce:DMINus?

The :COMpliance:USB:SOURce:DMINus? query returns the specified analog input channel.

Return Format <source><NL>

<source> ::= {CHAN<n>}

- See Also**
- [":COMpliance:USB:SOURce:DPLus"](#) on page 396
 - [":COMpliance:USB:SOURce:ADJacent"](#) on page 393

:COMPLIance:USB:SOURce:DPLus

N (see [page 1730](#))

Command Syntax :COMPLIance:USB:SOURce:DPLus <source>

<source> ::= {CHANnel<n>}

<n> ::= 1 to (# analog channels) in NR1 format

The :COMPLIance:USB:SOURce:DPLus command specifies the analog input channel that is probing the D+ signal.

On 4-channel oscilloscopes, you are forced to use different channel pairs for the D+ and D- signals. This provides the maximum sample rate. (Channels 1 and 2 are one pair and channels 3 and 4 are the other pair.)

Query Syntax :COMPLIance:USB:SOURce:DPLus?

The :COMPLIance:USB:SOURce:DPLus? query returns the specified analog input channel.

Return Format <source><NL>

<source> ::= {CHAN<n>}

- See Also**
- [":COMPLIance:USB:SOURce:DMINus"](#) on page 395
 - [":COMPLIance:USB:SOURce:ADJacent"](#) on page 393

:COMpliance:USB:TEST

N (see [page 1730](#))

Command Syntax :COMpliance:USB:TEST <test>

<test> ::= {DHSS | HHSS | DLSS | HLSS | DFSS | HFSS}

The :COMpliance:USB:TEST command selects the type of signal quality test to perform:

- DHSS – Device Hi-Speed Signal Quality.
- HHSS – Host Hi-Speed Signal Quality.
- DLSS – Device Low Speed Signal Quality.
- HLSS – Host Low Speed Signal Quality.
- DFSS – Device Full Speed Signal Quality.
- HFSS – Host Full Speed Signal Quality.

For Hub upstream testing, select the Device tests.

For Hub downstream testing, select the Host tests.

Low and Full Speed tests require two or three single-ended probes.

Hi-Speed tests are available only on 1.5 GHz bandwidth oscilloscopes, and a differential probe or SMA cable connections are required.

Note that the N2750A Series InfiniiMode differential probes cannot be used with the Hi-Speed Signal Quality test fixtures because they have damping resistors and the USB test fixture also has damping resistors specifically designed for the E2678A socketed probe heads.

Query Syntax :COMpliance:USB:TEST?

The :COMpliance:USB:TEST? query returns the selected signal quality test type.

Return Format <test><NL>

<test> ::= {DHSS | HHSS | DLSS | HLSS | DFSS | HFSS}

- See Also**
- [":COMpliance:USB:TEST:TYPE"](#) on page 399
 - [":COMpliance:USB:SOURce:DPLus"](#) on page 396
 - [":COMpliance:USB:SOURce:DMINus"](#) on page 395
 - [":COMpliance:USB:SOURce:ADJacent"](#) on page 393
 - [":COMpliance:USB:SOURce:DIFFerential"](#) on page 394

:COMPLIance:USB:TEST:CONNECTION

N (see [page 1730](#))

Command Syntax :COMPLIance:USB:TEST:CONNECTION <connection>

<connection> ::= {SINGLeended | DIFFerential}

When a Hi-Speed test has been selected, the :COMPLIance:USB:TEST:CONNECTION command specifies the test fixture connection type:

- DIFFerential – specifies that a differential probe is used to probe the signal under test.

In this case, use the :COMPLIance:USB:SOURce:DIFFerential command to specify the analog input channel connected to the differential probe.

- SINGLeended – specifies that two single-ended SMA cables are used to probe the signal under test.

In this case, use the :COMPLIance:USB:SOURce:DPLus command to specify the analog input channel that is probing the D+ signal, and use the :COMPLIance:USB:SOURce:DMINus command to specify the analog input channel that is probing the D- signal.

Query Syntax :COMPLIance:USB:TEST:CONNECTION?

The :COMPLIance:USB:TEST:CONNECTION? query returns the specified the test fixture connection type.

Return Format <connection><NL>

<connection> ::= {SING | DIFF}

- See Also**
- [":COMPLIance:USB:SOURce:DIFFerential"](#) on page 394
 - [":COMPLIance:USB:SOURce:DPLus"](#) on page 396
 - [":COMPLIance:USB:SOURce:DMINus"](#) on page 395

:COMpliance:USB:TEST:TYPE

N (see [page 1730](#))

Command Syntax :COMpliance:USB:TEST:TYPE <type>

<type> ::= {NEARend | FARend}

When a Hi-Speed test has been selected, the :COMpliance:USB:TEST:TYPE command selects whether the test type is near-end or far-end.

Query Syntax :COMpliance:USB:TEST:TYPE?

The :COMpliance:USB:TEST:TYPE? query returns the selected test type.

Return Format <type><NL>

<type> ::= {NEAR | FAR}

See Also • [":COMpliance:USB:TEST"](#) on page 397

15 :COUNter Commands

These commands control the counter feature. See "[Introduction to :COUNTER Commands](#)" on page 402.

Table 105 :COUNter Commands Summary

Command	Query	Options and Query Returns
n/a	:COUNter:CURRent? (see page 403)	<value> ::= current counter value in NR3 format
:COUNter:ENABle {{0 OFF} {1 ON}} (see page 404)	:COUNter:ENABle? (see page 404)	{0 1}
:COUNter:MODE <mode> (see page 405)	:COUNter:MODE (see page 405)	<mode> ::= {FREQuency PERiod TOTAlize}
:COUNter:NDIGits <value> (see page 406)	:COUNter:NDIGits (see page 406)	<value> ::= 3 to 10 in NR1 format
:COUNter:SOURce <source> (see page 407)	:COUNter:SOURce? (see page 407)	<source> ::= {CHANnel<n> TQEVent} <n> ::= 1 to (# analog channels) in NR1 format
:COUNter:TOTAlize:CLEAr (see page 408)	n/a	n/a
:COUNter:TOTAlize:GATE:ENABle {{0 OFF} {1 ON}} (see page 409)	:COUNter:TOTAlize:GATE:ENABle? (see page 409)	{0 1}
:COUNter:TOTAlize:GATE:POLarity <polarity> (see page 410)	:COUNter:TOTAlize:GATE:POLarity? (see page 410)	<polarity> ::= {{NEGative FALLing} {POSitive RISing}}

Table 105 :COUNTER Commands Summary (continued)

Command	Query	Options and Query Returns
:COUNTER:TOTALize:GAT E:SOURce <source> (see page 411)	:COUNTER:TOTALize:GAT E:SOURce? (see page 411)	<source> ::= CHANNEL<n> <n> ::= 1 to (# analog channels) in NR1 format
:COUNTER:TOTALize:SLO Pe <slope> (see page 412)	:COUNTER:TOTALize:SLO Pe? (see page 412)	<slope> ::= {{NEGative FALling} {POSitive RISing}}

Introduction to :COUNTER Commands The :COUNTER subsystem provides commands to control the counter feature.
Reporting the Setup

Use :COUNTER? to query setup information for the COUNTER subsystem.

Return Format

The following is a sample response from the :COUNTER? query. In this case, the query was issued following the *RST command.

```
:COUN:ENAB 0;SOUR CHAN1;MODE FREQ;NDIG 5
```

:COUNter:CURRent

N (see [page 1730](#))

Query Syntax :COUNter:CURRent?

The :COUNter:CURRent? query returns the current counter value.

Return Format <value><NL>

<value> ::= current counter value in NR3 format

- See Also**
- [":COUNter:ENABLE"](#) on page 404
 - [":COUNter:MODE"](#) on page 405
 - [":COUNter:NDIGits"](#) on page 406
 - [":COUNter:SOURce"](#) on page 407

:COUNter:ENABLE

N (see [page 1730](#))

Command Syntax :COUNter:ENABle {{0 | OFF} | {1 | ON}}

The :COUNter:ENABLE command enables or disables the counter feature.

Query Syntax :COUNter:ENABle?

The :COUNter:ENABLE? query returns whether the counter is enabled or disabled.

Return Format <off_on><NL>
{0 | 1}

- See Also**
- [":COUNter:CURRent"](#) on page 403
 - [":COUNter:MODE"](#) on page 405
 - [":COUNter:NDIGits"](#) on page 406
 - [":COUNter:SOURce"](#) on page 407

:COUNter:MODE

N (see [page 1730](#))

Command Syntax :COUNter:MODE <mode>

<mode> ::= {FREQuency | PERiod | TOTalize}

The :COUNter:MODE command sets the counter mode:

- FREQuency – the cycles per second (Hz) of the signal.
- PERiod – the time periods of the signal's cycles.
- TOTalize – the count of edge events on the signal.

Query Syntax :COUNter:MODE?

The :COUNter:MODE? query returns the counter mode setting.

Return Format <mode><NL>

<mode> ::= {FREQ | PER | TOT}

- See Also**
- [":COUNter:CURREnt"](#) on page 403
 - [":COUNter:ENABle"](#) on page 404
 - [":COUNter:NDIGits"](#) on page 406
 - [":COUNter:SOURce"](#) on page 407
 - [":COUNter:TOTalize:CLEar"](#) on page 408
 - [":COUNter:TOTalize:GATE:ENABle"](#) on page 409
 - [":COUNter:TOTalize:GATE:POLarity"](#) on page 410
 - [":COUNter:TOTalize:GATE:SOURce"](#) on page 411
 - [":COUNter:TOTalize:SLOPe"](#) on page 412

:COUNTER:NDIGits

N (see [page 1730](#))

Command Syntax :COUNTER:NDIGits <value>
 <value> ::= 3 to 10 in NR1 format

The :COUNTER:NDIGits command sets the number of digits of resolution used for the frequency or period counter.

Higher resolutions require longer gate times, which cause the measurement times to be longer as well.

Query Syntax :COUNTER:NDIGits?

The :COUNTER:NDIGits? query returns the currently set number of digits of resolution.

Return Format <value><NL>
 <value> ::= 3 to 10 in NR1 format

- See Also**
- [":COUNTER:CURRENT"](#) on page 403
 - [":COUNTER:ENABLE"](#) on page 404
 - [":COUNTER:MODE"](#) on page 405
 - [":COUNTER:SOURCE"](#) on page 407
 - [":COUNTER:TOTALize:CLEAr"](#) on page 408
 - [":COUNTER:TOTALize:GATE:ENABLE"](#) on page 409
 - [":COUNTER:TOTALize:GATE:POLarity"](#) on page 410
 - [":COUNTER:TOTALize:GATE:SOURCE"](#) on page 411
 - [":COUNTER:TOTALize:SLOPe"](#) on page 412

:COUNter:SOURce

N (see [page 1730](#))

Command Syntax :COUNter:SOURce <source>

<source> ::= {CHANnel<n> | TQEvent}

<n> ::= 1 to (# analog channels) in NR1 format

The :COUNter:SOURce command selects the waveform source that the counter measures. You can select one of the analog input channels or the trigger qualified event signal.

With the TQEvent (trigger qualified event) source (available when the trigger mode is not EDGE), you can see how often trigger events are detected. This can be more often than when triggers actually occur, due to the oscilloscope's acquisition time or update rate capabilities. The TRIG OUT signal shows when triggers actually occur. Remember that the oscilloscope's trigger circuitry does not re-arm until the holdoff time occurs (:TRIGger:HOLDoff) and that the minimum holdoff time is 40 ns; therefore, the maximum trigger qualified event frequency that can be counted is 25 MHz.

Query Syntax :COUNter:SOURce?

The :COUNter:SOURce? query returns the currently set counter source channel.

Return Format <source><NL>

- See Also**
- [":COUNter:CURREnt"](#) on page 403
 - [":COUNter:ENABle"](#) on page 404
 - [":COUNter:MODE"](#) on page 405
 - [":COUNter:NDIGits"](#) on page 406

:COUNTER:TOTALize:CLEar

N (see [page 1730](#))

Command Syntax :COUNTER:TOTALize:CLEar

The :COUNTER:TOTALize:CLEar command zeros the edge event counter.

- See Also**
- [":COUNTER:CURRENT"](#) on page 403
 - [":COUNTER:ENABLE"](#) on page 404
 - [":COUNTER:MODE"](#) on page 405
 - [":COUNTER:NDIGits"](#) on page 406
 - [":COUNTER:SOURce"](#) on page 407
 - [":COUNTER:TOTALize:GATE:ENABLE"](#) on page 409
 - [":COUNTER:TOTALize:GATE:POLarity"](#) on page 410
 - [":COUNTER:TOTALize:GATE:SOURce"](#) on page 411
 - [":COUNTER:TOTALize:SLOPe"](#) on page 412

:COUNTER:TOTALize:GATE:ENABLE

N (see [page 1730](#))

Command Syntax :COUNTER:TOTALize:GATE:ENABLE {{0 | OFF} | {1 | ON}}

The :COUNTER:TOTALize:GATE:ENABLE command enables or disables totalizer gating.

When totalizer gating is enabled, the totalizer only counts edges when a second gating signal polarity is true. The second gating signal can be one of the remaining analog channel inputs.

Query Syntax :COUNTER:TOTALize:GATE:ENABLE?

The :COUNTER:TOTALize:GATE:ENABLE? query returns whether totalizer gating is enabled or disabled.

Return Format <off_on><NL>

{0 | 1}

- See Also**
- [":COUNTER:CURRENT"](#) on page 403
 - [":COUNTER:ENABLE"](#) on page 404
 - [":COUNTER:MODE"](#) on page 405
 - [":COUNTER:NDIGITS"](#) on page 406
 - [":COUNTER:SOURCE"](#) on page 407
 - [":COUNTER:TOTALize:CLEAr"](#) on page 408
 - [":COUNTER:TOTALize:GATE:POLarity"](#) on page 410
 - [":COUNTER:TOTALize:GATE:SOURce"](#) on page 411
 - [":COUNTER:TOTALize:SLOPe"](#) on page 412

:COUNTER:TOTALize:GATE:POLarity

N (see [page 1730](#))

Command Syntax :COUNTER:TOTALize:GATE:POLarity <polarity>

<polarity> ::= {{NEGative | FALLing} | {POSitive | RISing}}

The :COUNTER:TOTALize:GATE:POLarity command specifies the gating signal condition under which totalizer edges are counted.

The gating signal is specified with the :COUNTER:TOTALize:GATE:SOURce command.

Query Syntax :COUNTER:TOTALize:GATE:POLarity?

The :COUNTER:TOTALize:GATE:POLarity? query returns the currently specified gating signal condition.

Return Format <polarity><NL>

<polarity> ::= {NEG | POS}

- See Also**
- [":COUNTER:CURRent"](#) on page 403
 - [":COUNTER:ENABle"](#) on page 404
 - [":COUNTER:MODE"](#) on page 405
 - [":COUNTER:NDIGits"](#) on page 406
 - [":COUNTER:SOURce"](#) on page 407
 - [":COUNTER:TOTALize:CLEar"](#) on page 408
 - [":COUNTER:TOTALize:GATE:ENABle"](#) on page 409
 - [":COUNTER:TOTALize:GATE:SOURce"](#) on page 411
 - [":COUNTER:TOTALize:SLOPe"](#) on page 412

:COUNTER:TOTALize:GATE:SOURce

N (see [page 1730](#))

Command Syntax :COUNTER:TOTALize:GATE:SOURce <source>

<source> ::= CHANNEL<n>

<n> ::= 1 to (# analog channels) in NR1 format

The :COUNTER:TOTALize:GATE:SOURce command selects the analog channel that has the totalizer gating signal.

Query Syntax :COUNTER:TOTALize:GATE:SOURce?

The :COUNTER:TOTALize:GATE:SOURce? query returns the current totalizer gating signal source.

Return Format <source><NL>

- See Also**
- [":COUNTER:CURRENT"](#) on page 403
 - [":COUNTER:ENABLE"](#) on page 404
 - [":COUNTER:MODE"](#) on page 405
 - [":COUNTER:NDIGits"](#) on page 406
 - [":COUNTER:SOURce"](#) on page 407
 - [":COUNTER:TOTALize:CLEar"](#) on page 408
 - [":COUNTER:TOTALize:GATE:ENABLE"](#) on page 409
 - [":COUNTER:TOTALize:GATE:POLarity"](#) on page 410
 - [":COUNTER:TOTALize:SLOPe"](#) on page 412

:COUNTER:TOTALize:SLOPe

N (see [page 1730](#))

Command Syntax :COUNTER:TOTALize:SLOPe <slope>

<slope> ::= {{NEGative | FALLing} | {POSitive | RISing}}

The :COUNTER:TOTALize:SLOPe command specifies whether positive or negative edges are counted.

Query Syntax :COUNTER:TOTALize:SLOPe?

The :COUNTER:TOTALize:SLOPe? query returns the currently set slope specification.

Return Format <slope><NL>

<slope> ::= {NEG | POS}

- See Also**
- [":COUNTER:CURRENT"](#) on page 403
 - [":COUNTER:ENABLE"](#) on page 404
 - [":COUNTER:MODE"](#) on page 405
 - [":COUNTER:NDIGits"](#) on page 406
 - [":COUNTER:SOURce"](#) on page 407
 - [":COUNTER:TOTALize:CLEar"](#) on page 408
 - [":COUNTER:TOTALize:GATE:ENABLE"](#) on page 409
 - [":COUNTER:TOTALize:GATE:POLarity"](#) on page 410
 - [":COUNTER:TOTALize:GATE:SOURce"](#) on page 411

16 :DEMO Commands

You can output demonstration signals on the oscilloscope's Demo 1 and Demo 2 terminals. See "[Introduction to :DEMO Commands](#)" on page 413.

Table 106 :DEMO Commands Summary

Command	Query	Options and Query Returns
:DEMO:FUNCTION <signal> (see page 414)	:DEMO:FUNCTION? (see page 418)	<signal> ::= {SINusoid NOISy PHASe RINGing SINGle AM CLK GLITCh BURSt MSO RUNT TRANSition RFBurst SHOLd LFSine FMBurst ETE CAN LIN UART I2C SPI I2S CANLin CXPI ARINc FLEXray MIL MIL2 USB NMONotonic JITTer DCMotor RTEYe SJITter}
:DEMO:FUNCTION:PHASe: PHASe <angle> (see page 419)	:DEMO:FUNCTION:PHASe: PHASe? (see page 419)	<angle> ::= angle in degrees from 0 to 360 in NR3 format
:DEMO:OUTPut {{0 OFF} {1 ON}} (see page 420)	:DEMO:OUTPut? (see page 420)	{0 1}

Introduction to :DEMO Commands The :DEMO subsystem provides commands to output demonstration signals on the oscilloscope's Demo 1 and Demo 2 terminals.

Reporting the Setup

Use :DEMO? to query setup information for the DEMO subsystem.

Return Format

The following is a sample response from the :DEMO? query. In this case, the query was issued following the *RST command.

```
:DEMO:FUNC SIN;OUTP 0
```

:DEMO:FUNCTION

N (see [page 1730](#))

Command Syntax :DEMO:FUNCTION <signal>

```
<signal> ::= {SINusoid | NOISy | PHASe | RINGing | SINGLE | AM | CLK
| GLITCh | BURSt | MSO | RUNT | TRANsition | RFBurst | SHOLd
| LFSine | FMBurst | ETE | CAN | LIN | UART | I2C | SPI | I2S
| CANLin | CXPI | ARINc | FLEXray | MANChester | MIL | MIL2 | USB
| NMONotonic | JITTer | DCMotor | RTEYe | SJITter | HARMonics
| COUPLing | CFD | SENT | USBPd | KEYSight}
```

The :DEMO:FUNCTION command selects the type of demo signal:

Demo Signal Function	Demo 1 Terminal	Demo 2 Terminal
SINusoid	5 MHz sine wave @ ~ 6 Vpp, 0 V offset	Off
NOISy	1 kHz sine wave @ ~ 2.4 Vpp, 0.0 V offset, with ~ 0.5 Vpp of random noise added	Off
PHASe	1 kHz sine wave @ 2.4 Vpp, 0.0 V offset	1 kHz sine wave @ 2.4 Vpp, 0.0 V offset , phase shifted by the amount entered using the ":DEMO:FUNCTION:PHASe:PHASe" on page 419 command
RINGing	500 kHz digital pulse @ ~ 2.4 Vpp, 1.2 V offset, and ~500 ns pulse width with ringing	Off
SINGLE	~500 ns wide digital pulse with ringing @ ~ 3 Vpp, 1.5 V offset Press the front panel Set Off Single-Shot softkey to cause the selected single-shot signal to be output.	Off
AM	26 kHz sine wave, ~ 5 Vpp, 0 V offset	Amplitude modulated signal, ~ 2 Vpp, 0 V offset, with ~13 MHz carrier and sine envelope
CLK	3.6 MHz clock @ ~2 Vpp, 1 V offset, with infrequent glitch (1 glitch per 1,000,000 clocks)	Off
GLITCh	Burst of 6 digital pulses (plus infrequent glitch) that occurs once every 80 μ s @ ~2.5 Vpp, ~1.25 V offset	Off

Demo Signal Function	Demo 1 Terminal	Demo 2 Terminal
BURSt	Burst of digital pulses that occur every 50 μ s @ \sim 2.5 Vpp, \sim 1.25 V offset	Off
MSO	3.1 kHz stair-step sine wave output of DAC @ \sim 1.5 Vpp, 0.75 V offset DAC input signals are internally routed to digital channels D0 through D7	\sim 3.1 kHz sine wave filtered from DAC output @ \sim 600 mVpp, 300 mV offset
RUNT	Digital pulse train with positive and negative runt pulses @ \sim 2.9 Vpp, 1.5 V offset	Off
TRANSition	Digital pulse train with two different edge speeds @ \sim 2.5 Vpp, 1.25 V offset	Off
RFBurst	5-cycle burst of a 10 MHz amplitude modulated sine wave @ \sim 2.0 Vpp, 0 V offset occurring once every 4 ms	Off
SHOLd	6.25 MHz digital clock @ \sim 3.5 Vpp, 1.75 V offset	Data signal @ \sim 3.5 Vpp, 1.75 V offset
LFSine	30 Hz sine wave @ \sim 2.7 Vpp, 0 V offset, with very narrow glitch near each positive peak	Off
FMBurst	FM burst, modulated from \sim 100 kHz to \sim 1 MHz, \sim 5.0 Vpp, \sim 600 mV offset.	Off
ETE	100 kHz pulse, 400 ns wide @ \sim 3.3 Vpp, 1.65 V offset	600 ns analog burst (@ \sim 3.3 Vpp, 0.7 V offset) followed by 3.6 μ s digital burst @ \sim 3.3 Vpp, 1.65 V offset) at a 100 kHz repetitive rate
CAN	CAN_L, 125 kbps dominant-low, \sim 2.8 Vpp, \sim 1.4 V offset	Off
LIN	LIN, 19.2 kbs, \sim 2.8 Vpp, \sim 1.4 V offset	Off
UART	Receive data (RX) with odd parity, 19.2 kbps, 8-bit words, LSB out 1st, low idle @ \sim 2.8 Vpp, 1.4 V offset	Transmit data (TX) with odd parity, 19.2 kbps, 8-bit words, LSB out 1st, low idle @ \sim 2.8 Vpp, 1.4 V offset
I2C	I2C serial clock signal (SCL) @ \sim 2.8 Vpp, 1.4 V offset	I2C serial data signal (SDA) @ \sim 2.8 Vpp, 1.4 V offset

Demo Signal Function	Demo 1 Terminal	Demo 2 Terminal
SPI	<p>Off</p> <p>Signals are internally routed to digital channels D6 through D9:</p> <ul style="list-style-type: none"> ▪ D9 – MOSI, TTL level, with MSB out 1st (internally routed to digital input). ▪ D8 – MISO, TTL level, with MSB out 1st (internally routed to digital input). ▪ D7 – CLK, TTL level (internally routed to digital input). ▪ D6 – ~CS, low-enable, TTL level (internally routed to digital input). 	Off
I2S	<p>Off</p> <p>Signals are internally routed to digital channels D7 through D9:</p> <ul style="list-style-type: none"> ▪ D9 – SDATA, TTL level, with "standard" alignment (internally routed to digital input). ▪ D8 – SCLK, TTL level, (internally routed to digital input). ▪ D7 – WS, TTL level, low for left channel, high for right channel (internally routed to digital input) 	Off
CANLin	CAN_L, 250 kbps dominant-low, ~2.8 Vpp, ~1.4 V offset	LIN, 19.2 kbps, ~2.8 Vpp, ~1.4 V offset
CXPI	CXPI, ~2.5 Vpp, ~1.25 V offset, frame IDs: 20, 21, and 29 (with a frame error).	Off
ARINc	ARINC 429, 100 kbps, ~5 Vpp, ~0 V offset.	Off
FLEXray	FlexRay @ 10 Mbps, ~2.8 Vpp, ~0 V offset	Off
MANchester	Manchester/NRZ @ 125 kbps, ~2.5 Vpp, 1.25 V offset, a 125 kb/s 10-bit PS15-like signal	Off
MIL	MIL-STD-1553 RT to RT transfer, received ~1.3 Vpp, transmitted ~4.8 Vpp, 0 V offset	Off

Demo Signal Function	Demo 1 Terminal	Demo 2 Terminal
MIL2	MIL-STD-1553 RT to RT transfer, received ~1.3 Vpp, transmitted ~4.8 Vpp, 0 V offset	MIL-STD-1553 RT to BC transfer, received ~1.3 Vpp, transmitted ~4.8 Vpp, 0 V offset
USB	USB Low Speed D+ signal, ~2.8 Vpp, 1.4 V offset	USB Low Speed D- signal, ~2.8 Vpp, 1.4 V offset
NMONotonic	Digital pulse train with infrequent non-monotonic rising edges @ ~2.85 Vpp, 1.42 V offset	Off
JITTer	5 MHz square wave @ ~2.7 Vpp, 0.0 V offset, with a frequency modulation of 100 kHz.	Off
DCMotor	Output of DAC controlling a DC motor: 800 mV pulse, 1 μ s wide, every 10 μ s, runt pulse every 100 ms. DAC input signals are internally routed to digital channels D0 through D7	Off
RTEYe	10 Mb/s max rate digital signal @ ~5 Vpp, 0.0 V offset.	Off
SJITter	6.25 Mb/s serial data signal @ ~1.5 Vpp, 750 mV offset, with sine wave frequency modulation of 20 kHz and an infrequent shifted data edge.	Off
HARMonics	1 kHz sine wave @ ~3.5 Vpp, 0.0 V offset, with a ~2 kHz sine wave coupled in	Off
COUPling	1 kHz square wave @ ~1 Vpp, 0.0 V offset, with a ~90 kHz sine wave with ~180 mVpp riding on top	Off
CFD	CAN FD, ~2.4 Vpp, ~-1.2 V offset, 500 kb/s standard baud rate (sample point at 80%), 10 Mb/s FD baud rate (sample point at 50%)	Off
SENT	SENT, ~2.7 Vpp, ~1.35 V offset, 3 μ s clock period, 6 nibbles in a Fast Channel Message, Slow Channel Messages in enhanced format, idle state high, with pause pulse	Off

Demo Signal Function	Demo 1 Terminal	Demo 2 Terminal
USBPd	USB PD, ~2.5 Vpp, ~1.25 V offset, with vendor-defined data message packet and Good CRC control message packet	Off
KEYSight	Series of positive and negative pulses, 125 μ s wide, amplitude modulated, ~2.6 Vpp, ~0 V offset	Off

Query Syntax :DEMO:FUNCTION?

The :DEMO:FUNCTION? query returns the currently selected demo signal type.

Return Format <signal><NL>

```
<signal> ::= {SIN | NOIS | PHAS | RING | SING | AM | CLK | GLIT
| BURS | MSO | RUNT | TRAN | RFB | SHOL | LFS | FMB | ETE | CAN
| LIN | UART | I2C | SPI | I2S | CANL | CXPI | ARIN | FLEX | MANC
| MIL | MIL2 | USB | NMON | JITT | DCM | RTEY | SJIT | HARM | COUP
| CFD | SENT | USBP | KEYS}
```

See Also • ["Introduction to :DEMO Commands"](#) on page 413

:DEMO:FUNCTION:PHASe:PHASe

N (see [page 1730](#))

Command Syntax :DEMO:FUNCTION:PHASe:PHASe <angle>

<angle> ::= angle in degrees from 0 to 360 in NR3 format

For the phase shifted sine demo signals, the :DEMO:FUNCTION:PHASe:PHASe command specifies the phase shift in the second sine waveform.

Query Syntax :DEMO:FUNCTION:PHASe:PHASe?

The :DEMO:FUNCTION:PHASe:PHASe? query returns the currently set phase shift.

Return Format <angle><NL>

<angle> ::= angle in degrees from 0 to 360 in NR3 format

- See Also**
- ["Introduction to :DEMO Commands"](#) on page 413
 - [":DEMO:FUNCTION"](#) on page 414

:DEMO:OUTPut

N (see [page 1730](#))

Command Syntax :DEMO:OUTPut <on_off>

<on_off> ::= {{1 | ON} | {0 | OFF}}

The :DEMO:OUTPut command specifies whether the demo signal output is ON (1) or OFF (0).

Query Syntax :DEMO:OUTPut?

The :DEMO:OUTPut? query returns the current state of the demo signal output setting.

Return Format <on_off><NL>

<on_off> ::= {1 | 0}

- See Also**
- ["Introduction to :DEMO Commands"](#) on page 413
 - [":DEMO:FUNCTION"](#) on page 414

17 :DIGital<d> Commands

Control all oscilloscope functions associated with individual digital channels. See "[Introduction to :DIGital<d> Commands](#)" on page 422.

Table 107 :DIGital<d> Commands Summary

Command	Query	Options and Query Returns
:DIGital<d>:DISPlay { {0 OFF} {1 ON} } (see page 423)	:DIGital<d>:DISPlay? (see page 423)	<d> ::= 0 to (# digital channels - 1) in NR1 format {0 1}
:DIGital<d>:LABel <string> (see page 424)	:DIGital<d>:LABel? (see page 424)	<d> ::= 0 to (# digital channels - 1) in NR1 format <string> ::= any series of 10 or less ASCII characters enclosed in quotation marks
:DIGital<d>:POSition <position> (see page 425)	:DIGital<d>:POSition? (see page 425)	<d> ::= 0 to (# digital channels - 1) in NR1 format <position> ::= 0-7 if display size = large, 0-15 if size = medium, 0-31 if size = small Returns -1 when there is no space to display the digital waveform.
:DIGital<d>:SIZE <value> (see page 426)	:DIGital<d>:SIZE? (see page 426)	<d> ::= 0 to (# digital channels - 1) in NR1 format <value> ::= {SMALl MEDium LARGe}
:DIGital<d>:THReshold <value>[suffix] (see page 427)	:DIGital<d>:THReshold? (see page 427)	<d> ::= 0 to (# digital channels - 1) in NR1 format <value> ::= {CMOS ECL TTL <user defined value>} <user defined value> ::= value in NR3 format from -8.00 to +8.00 [suffix] ::= {V mV uV}

**Introduction to
:DIGital<d>
Commands**

<d> ::= 0 to (# digital channels - 1) in NR1 format

The DIGital subsystem commands control the viewing, labeling, and positioning of digital channels. They also control threshold settings for groups of digital channels, or *Pods*.

NOTE

These commands are only valid for the MSO models.

Reporting the Setup

Use :DIGital<d>? to query setup information for the DIGital subsystem.

Return Format

The following is a sample response from the :DIGital0? query. In this case, the query was issued following a *RST command.

```
:DIG0:DISP 0;THR +1.40E+00;LAB 'D0';POS +0
```

:DIGital<d>:DISPlay

N (see [page 1730](#))

Command Syntax :DIGital<d>:DISPlay <display>

<d> ::= 0 to (# digital channels - 1) in NR1 format

<display> ::= {{1 | ON} | {0 | OFF}}

The :DIGital<d>:DISPlay command turns digital display on or off for the specified channel.

NOTE

This command is only valid for the MSO models.

Query Syntax :DIGital<d>:DISPlay?

The :DIGital<d>:DISPlay? query returns the current digital display setting for the specified channel.

Return Format <display><NL>

<display> ::= {0 | 1}

- See Also**
- ["Introduction to :DIGital<d> Commands"](#) on page 422
 - [":POD<n>:DISPlay"](#) on page 817
 - [":CHANnel<n>:DISPlay"](#) on page 357
 - [":VIEW"](#) on page 300
 - [":BLANK"](#) on page 268
 - [":STATus"](#) on page 297

:DIGital<d>:LABel

N (see [page 1730](#))

Command Syntax :DIGital<d>:LABel <string>

<d> ::= 0 to (# digital channels - 1) in NR1 format

<string> ::= any series of 10 or less characters as quoted ASCII string.

The :DIGital<d>:LABel command sets the channel label to the string that follows. Setting a label for a channel also adds the name to the label list in non-volatile memory (replacing the oldest label in the list).

NOTE

This command is only valid for the MSO models.

NOTE

Label strings are 10 characters or less, and may contain any commonly used ASCII characters. Labels with more than 10 characters are truncated to 10 characters.

Query Syntax :DIGital<d>:LABel?

The :DIGital<d>:LABel? query returns the name of the specified channel.

Return Format <label string><NL>

<label string> ::= any series of 10 or less characters as a quoted ASCII string.

- See Also**
- ["Introduction to :DIGital<d> Commands"](#) on page 422
 - [":CHANnel<n>:LABel"](#) on page 360
 - [":DISPlay:LABList"](#) on page 447
 - [":BUS<n>:LABel"](#) on page 328

:DIGital<d>:POSition

N (see [page 1730](#))

Command Syntax :DIGital<d>:POSition <position>
 <d> ::= 0 to (# digital channels - 1) in NR1 format
 <position> ::= integer in NR1 format.

Channel Size	Position	Top	Bottom
Large	0-7	7	0
Medium	0-15	15	0
Small	0-31	31	0

The :DIGital<d>:POSition command sets the position of the specified channel. Note that bottom positions might not be valid depending on whether digital buses, serial decode waveforms, or the zoomed time base are displayed.

NOTE

This command is only valid for the MSO models.

Query Syntax :DIGital<d>:POSition?

The :DIGital<d>:POSition? query returns the position of the specified channel.

If the returned value is "-1", this indicates there is no space to display the digital waveform (for example, when all serial lanes, digital buses, and the zoomed time base are displayed).

Return Format <position><NL>
 <position> ::= integer in NR1 format.

See Also • ["Introduction to :DIGital<d> Commands"](#) on page 422

:DIGital<d>:SIZE

N (see [page 1730](#))

Command Syntax :DIGital<d>:SIZE <value>

<d> ::= 0 to (# digital channels - 1) in NR1 format

<value> ::= {SMALl | MEDium | LARGe}

The :DIGital<d>:SIZE command specifies the size of digital channels on the display. Sizes are set for all digital channels. Therefore, if you set the size on digital channel 0 (for example), the same size is set on all other as well.

NOTE

This command is only valid for the MSO models.

Query Syntax :DIGital<d>:SIZE?

The :DIGital<d>:SIZE? query returns the size setting for the specified digital channels.

Return Format <size_value><NL>

<size_value> ::= {SMAL | MED | LARG}

- See Also**
- ["Introduction to :DIGital<d> Commands"](#) on page 422
 - [":POD<n>:SIZE"](#) on page 818
 - [":DIGital<d>:POSition"](#) on page 425

:DIGital<d>:THReshold

N (see [page 1730](#))

Command Syntax :DIGital<d>:THReshold <value>

<d> ::= 0 to (# digital channels - 1) in NR1 format

<value> ::= {CMOS | ECL | TTL | <user defined value>[<suffix>]}

<user defined value> ::= -8.00 to +8.00 in NR3 format

<suffix> ::= {V | mV | uV}

- TTL = 1.4V
- CMOS = 2.5V
- ECL = -1.3V

The :DIGital<d>:THReshold command sets the logic threshold value for all channels in the same *pod* as the specified channel. The threshold is used for triggering purposes and for displaying the digital data as high (above the threshold) or low (below the threshold).

NOTE

This command is only valid for the MSO models.

Query Syntax :DIGital<d>:THReshold?

The :DIGital<d>:THReshold? query returns the threshold value for the specified channel.

Return Format <value><NL>

<value> ::= threshold value in NR3 format

- See Also**
- ["Introduction to :DIGital<d> Commands"](#) on page 422
 - [":POD<n>:THReshold"](#) on page 819
 - [":TRIGger\[:EDGE\]:LEVel"](#) on page 1457

18 :DISPlay Commands

Control how waveforms, graticule, and text are displayed and written on the screen. See "[Introduction to :DISPlay Commands](#)" on page 431.

Table 108 :DISPlay Commands Summary

Command	Query	Options and Query Returns
:DISPlay:ANNotation<n> > {{0 OFF} {1 ON}} (see page 432)	:DISPlay:ANNotation<n> >? (see page 432)	{0 1} <n> ::= an integer from 1 to 4 in NR1 format.
:DISPlay:ANNotation<n> >:BACKground <mode> (see page 433)	:DISPlay:ANNotation<n> >:BACKground? (see page 433)	<mode> ::= {OPAQue INVerted TRANSPARENT} <n> ::= an integer from 1 to 4 in NR1 format.
:DISPlay:ANNotation<n> >:COLor <color> (see page 434)	:DISPlay:ANNotation<n> >:COLor? (see page 434)	<color> ::= {CH1 CH2 CH3 CH4 DIG MATH REF MARKer WHITE RED} <n> ::= an integer from 1 to 4 in NR1 format.
:DISPlay:ANNotation<n> >:TEXT <string> (see page 435)	:DISPlay:ANNotation<n> >:TEXT? (see page 435)	<string> ::= quoted ASCII string (up to 254 characters) <n> ::= an integer from 1 to 4 in NR1 format.
:DISPlay:ANNotation<n> >:X1Position <value> (see page 436)	:DISPlay:ANNotation<n> >:X1Position? (see page 436)	<value> ::= an integer from 0 to (800 - width of annotation) in NR1 format. <n> ::= an integer from 1 to 4 in NR1 format.
:DISPlay:ANNotation<n> >:Y1Position <value> (see page 437)	:DISPlay:ANNotation<n> >:Y1Position? (see page 437)	<value> ::= an integer from 0 to (480 - height of annotation) in NR1 format. <n> ::= an integer from 1 to 4 in NR1 format.

Table 108 :DISPlay Commands Summary (continued)

Command	Query	Options and Query Returns
:DISPlay:BACKlight { {0 OFF} {1 ON} } (see page 438)	n/a	n/a
:DISPlay:CLear (see page 439)	n/a	n/a
n/a	:DISPlay:DATA? [<format>] [,] [<palette>] (see page 440)	<format> ::= {BMP BMP8bit PNG} <palette> ::= {COLor GRAYscale} <display data> ::= data in IEEE 488.2 # format
:DISPlay:GRATICule:ALABels { {0 OFF} {1 ON} } (see page 442)	:DISPlay:GRATICule:ALABels? (see page 442)	<setting> ::= {0 1}
:DISPlay:GRATICule:INTensity <value> (see page 443)	:DISPlay:GRATICule:INTensity? (see page 443)	<value> ::= an integer from 0 to 100 in NR1 format.
:DISPlay:GRATICule:TYPE <type> (see page 444)	:DISPlay:GRATICule:TYPE? (see page 444)	<type> ::= {FULL MVOLT IRE}
:DISPlay:INTensity:WAVEform <value> (see page 445)	:DISPlay:INTensity:WAVEform? (see page 445)	<value> ::= an integer from 0 to 100 in NR1 format.
:DISPlay:LABEL { {0 OFF} {1 ON} } (see page 446)	:DISPlay:LABEL? (see page 446)	{0 1}
:DISPlay:LABList <binary block> (see page 447)	:DISPlay:LABList? (see page 447)	<binary block> ::= an ordered list of up to 75 labels, each 32 characters maximum, separated by newline characters
:DISPlay:MENU <menu> (see page 448)	n/a	<menu> ::= {MASK MEASure SEGmented LISTer POWER}
:DISPlay:MESSAge:CLear (see page 449)	n/a	n/a
:DISPlay:PERSistence <value> (see page 450)	:DISPlay:PERSistence? (see page 450)	<value> ::= {MINimum INFinite <time>} <time> ::= seconds in in NR3 format from 100E-3 to 60E0
:DISPlay:PERSistence:CLear (see page 451)	n/a	n/a

Table 108 :DISPlay Commands Summary (continued)

Command	Query	Options and Query Returns
:DISPlay:SIDebar <sidebar> (see page 452)	n/a	<sidebar> ::= {SUMMary CURSors MEASurements DVM NAVigate CONTrols}
:DISPlay:TRANSPARENT {OFF ON} (see page 453)	:DISPlay:TRANSPARENT? (see page 453)	{OFF ON}
:DISPlay:VECTors {{0 OFF} {1 ON}} (see page 454)	:DISPlay:VECTors? (see page 454)	{0 1} OFF or 0 can only be selected with the 1 GHz or 1.5 GHz bandwidth models

Introduction to :DISPlay Commands

The DISPlay subsystem is used to control the display storage and retrieval of waveform data, labels, and text. This subsystem allows the following actions:

- Clear the waveform area on the display.
- Turn vectors on or off.
- Set waveform persistence.
- Specify labels.
- Save and Recall display data.

Reporting the Setup

Use :DISPlay? to query the setup information for the DISPlay subsystem.

Return Format

The following is a sample response from the :DISPlay? query. In this case, the query was issued following a *RST command.

```
:DISP:LAB 0;VECT 1;PERS MIN
```

:DISPlay:ANNotation<n>

N (see [page 1730](#))

Command Syntax :DISPlay:ANNotation<n> <setting>

<setting> ::= {{1 | ON} | {0 | OFF}}

<n> ::= an integer from 1 to 10 in NR1 format.

The :DISPlay:ANNotation<n> command turns the annotation on and off. When on, the annotation appears in the upper left corner of the oscilloscope's display.

The annotation is useful for documentation purposes, to add notes before capturing screens.

Query Syntax :DISPlay:ANNotation<n>?

The :DISPlay:ANNotation<n>? query returns the annotation setting.

Return Format <value><NL>

<value> ::= {0 | 1}

- See Also**
- [":DISPlay:ANNotation<n>:TEXT"](#) on page 435
 - [":DISPlay:ANNotation<n>:COLor"](#) on page 434
 - [":DISPlay:ANNotation<n>:BACKground"](#) on page 433
 - [":DISPlay:ANNotation<n>:X1Position"](#) on page 436
 - [":DISPlay:ANNotation<n>:Y1Position"](#) on page 437
 - ["Introduction to :DISPlay Commands"](#) on page 431

:DISPlay:ANNotation<n>:BACKground

N (see [page 1730](#))

Command Syntax :DISPlay:ANNotation<n>:BACKground <mode>

<mode> ::= {OPAQue | INVerted | TRANSPARENT}

<n> ::= an integer from 1 to 10 in NR1 format.

The :DISPlay:ANNotation<n>:BACKground command specifies the background of the annotation:

- OPAQue – the annotation has a solid background.
- INVerted – the annotation's foreground and background colors are switched.
- TRANSPARENT – the annotation has a transparent background.

Query Syntax :DISPlay:ANNotation<n>:BACKground?

The :DISPlay:ANNotation<n>:BACKground? query returns the specified annotation background mode.

Return Format <mode><NL>

<mode> ::= {OPAQ | INV | TRAN}

- See Also**
- [":DISPlay:ANNotation<n>"](#) on page 432
 - [":DISPlay:ANNotation<n>:TEXT"](#) on page 435
 - [":DISPlay:ANNotation<n>:COLor"](#) on page 434
 - [":DISPlay:ANNotation<n>:X1 Position"](#) on page 436
 - [":DISPlay:ANNotation<n>:Y1 Position"](#) on page 437
 - ["Introduction to :DISPlay Commands"](#) on page 431

:DISPlay:ANNotation<n>:COLor

N (see [page 1730](#))

Command Syntax :DISPlay:ANNotation<n>:COLor <color>

<color> ::= {CH1 | CH2 | CH3 | CH4 | DIG | MATH | REF | MARKer | WHITE
| RED}

<n> ::= an integer from 1 to 10 in NR1 format.

The :DISPlay:ANNotation<n>:COLor command specifies the annotation color. You can choose white, red, or colors that match analog channels, digital channels, math waveforms, reference waveforms, or markers.

Query Syntax :DISPlay:ANNotation<n>:COLor?

The :DISPlay:ANNotation<n>:COLor? query returns the specified annotation color.

Return Format <color><NL>

<color> ::= {CH1 | CH2 | CH3 | CH4 | DIG | MATH | REF | MARK | WHIT
| RED}

- See Also**
- [":DISPlay:ANNotation<n>"](#) on page 432
 - [":DISPlay:ANNotation<n>:TEXT"](#) on page 435
 - [":DISPlay:ANNotation<n>:BACKground"](#) on page 433
 - [":DISPlay:ANNotation<n>:X1 Position"](#) on page 436
 - [":DISPlay:ANNotation<n>:Y1 Position"](#) on page 437
 - ["Introduction to :DISPlay Commands"](#) on page 431

:DISPlay:ANNotation<n>:TEXT

N (see [page 1730](#))

Command Syntax :DISPlay:ANNotation<n>:TEXT <string>

<string> ::= quoted ASCII string (up to 254 characters)

<n> ::= an integer from 1 to 10 in NR1 format.

The :DISPlay:ANNotation<n>:TEXT command specifies the annotation string. The annotation string can contain as many characters as will fit in the Edit Annotation box on the oscilloscope's screen, up to 254 characters.

You can include a carriage return in the annotation string using the characters "\n". Note that this is not a new line character but the actual "\" (backslash) and "n" characters in the string. Carriage returns lessen the number of characters available for the annotation string.

Use :DISPlay:ANNotation<n>:TEXT "" to remotely clear the annotation text. (Two sets of quote marks without a space between them creates a NULL string.)

Query Syntax :DISPlay:ANNotation<n>:TEXT?

The :DISPlay:ANNotation<n>:TEXT? query returns the specified annotation text.

When carriage returns are present in the annotation text, they are returned as the actual carriage return character (ASCII 0x0D).

Return Format <string><NL>

<string> ::= quoted ASCII string

- See Also**
- [":DISPlay:ANNotation<n>"](#) on page 432
 - [":DISPlay:ANNotation<n>:COLor"](#) on page 434
 - [":DISPlay:ANNotation<n>:BACKground"](#) on page 433
 - [":DISPlay:ANNotation<n>:X1Position"](#) on page 436
 - [":DISPlay:ANNotation<n>:Y1Position"](#) on page 437
 - ["Introduction to :DISPlay Commands"](#) on page 431

:DISPlay:ANNotation<n>:X1Position

N (see [page 1730](#))

Command Syntax :DISPlay:ANNotation<n>:X1Position <value>

<value> ::= an integer from 0 to (800 - width of annotation) in NR1 format.

<n> ::= an integer from 1 to 10 in NR1 format.

The :DISPlay:ANNotation<n>:X1Position command sets the annotation's horizontal X1 position.

Query Syntax :DISPlay:ANNotation<n>:X1Position?

The :DISPlay:ANNotation<n>:X1Position? query returns the annotation's horizontal X1 position.

Return Format <value><NL>

<value> ::= an integer from 0 to (800 - width of annotation) in NR1 format.

- See Also**
- [":DISPlay:ANNotation<n>:Y1Position"](#) on page 437
 - [":DISPlay:ANNotation<n>"](#) on page 432
 - [":DISPlay:ANNotation<n>:COLor"](#) on page 434
 - [":DISPlay:ANNotation<n>:BACKground"](#) on page 433
 - [":DISPlay:ANNotation<n>:TEXT"](#) on page 435

:DISPlay:ANNotation<n>:Y1Position

N (see [page 1730](#))

Command Syntax :DISPlay:ANNotation<n>:Y1Position <value>

<value> ::= an integer from 0 to (480 - height of annotation) in NR1 format.

<n> ::= an integer from 1 to 10 in NR1 format.

The :DISPlay:ANNotation<n>:Y1Position command sets the annotation's vertical Y1 position.

Query Syntax :DISPlay:ANNotation<n>:Y1Position?

The :DISPlay:ANNotation<n>:Y1Position? query returns the annotation's vertical Y1 position.

Return Format <value><NL>

<value> ::= an integer from 0 to (480 - height of annotation) in NR1 format.

- See Also**
- [":DISPlay:ANNotation<n>:X1Position"](#) on page 436
 - [":DISPlay:ANNotation<n>"](#) on page 432
 - [":DISPlay:ANNotation<n>:COLor"](#) on page 434
 - [":DISPlay:ANNotation<n>:BACKground"](#) on page 433
 - [":DISPlay:ANNotation<n>:TEXT"](#) on page 435

:DISPlay:BACKlight

N (see [page 1730](#))

Command Syntax :DISPlay:BACKlight {{0 | OFF} | {1 | ON}}

The :DISPlay:BACKlight command turns the display's backlight off or on.

:DISPlay:CLEar

N (see [page 1730](#))

Command Syntax :DISPlay:CLEar

The :DISPlay:CLEar command clears the display and resets all associated measurements. If the oscilloscope is stopped, all currently displayed data is erased. If the oscilloscope is running, all of the data for active channels and functions is erased; however, new data is displayed on the next acquisition.

See Also • ["Introduction to :DISPlay Commands"](#) on page 431

:DISPlay:DATA

N (see [page 1730](#))

Query Syntax :DISPlay:DATA? [<format>] [, <palette>]

<format> ::= {BMP | BMP8bit | PNG}

<palette> ::= {COLor | GRAYscale}

The :DISPlay:DATA? query reads screen image data. You can choose 24-bit BMP, 8-bit BMP8bit, or 24-bit PNG formats in color or grayscale.

Note that the returned image is also affected by the :HARDcopy:INKSaver command, which is ON by default and returns an inverted image. To get a non-inverted image, send the ":HARDcopy:INKSaver OFF" command before the DATA? query.

If no format or palette option is specified, the screen image is returned in whatever image format is selected by the front panel's **[Save/Recall] > Save > Format** softkey. If the **Format** softkey does not select an image format (in other words, it selects a setup or data format), the BMP, COLor format is used.

Screen image data is returned in the IEEE-488.2 # binary block data format.

Return Format <display data><NL>

<display data> ::= binary block data in IEEE-488.2 # format.

- See Also**
- ["Introduction to :DISPlay Commands"](#) on page 431
 - [":HARDcopy:INKSaver"](#) on page 546
 - [":HCOPY:SDUMp:DATA"](#) on page 557
 - [":HCOPY:SDUMp:FORMat"](#) on page 558
 - [":PRINT"](#) on page 292
 - ["*RCL \(Recall\)"](#) on page 245
 - ["*SAV \(Save\)"](#) on page 249
 - [":VIEW"](#) on page 300

Example Code

```
' IMAGE_TRANSFER - In this example, we will query for the image data
' with ":DISPlay:DATA?", read the data, and then save it to a file.
Dim byteData() As Byte
myScope.IO.Timeout = 15000
myScope.WriteString ":DISPlay:DATA? BMP, COLOR"
byteData = myScope.ReadIEEEBlock(BinaryType_UI1)
' Output display data to a file:
strPath = "c:\scope\data\screen.bmp"
' Remove file if it exists.
If Len(Dir(strPath)) Then
    Kill strPath
End If
Close #1 ' If #1 is open, close it.
```



```
Open strPath For Binary Access Write Lock Write As #1 ' Open file f
or output.
Put #1, , byteData ' Write data.
Close #1 ' Close file.
myScope.IO.Timeout = 5000
```

See complete example programs at: [Chapter 50](#), “Programming Examples,” starting on page 1739

:DISPlay:GRATicule:ALABels

N (see [page 1730](#))

Command Syntax :DISPlay:GRATicule:ALABels {{0 | OFF} | {1 | ON}}

The :DISPlay:GRATicule:ALABels command turns graticule (grid) axis labels on or off.

Query Syntax :DISPlay:GRATicule:ALABels?

The :DISPlay:GRATicule:ALABels? query returns the graticule (grid) axis labels setting

Return Format <setting><NL>

<setting> ::= {0 | 1}

- See Also**
- [":DISPlay:GRATicule:INTensity"](#) on page 443
 - [":DISPlay:GRATicule:TYPE"](#) on page 444

:DISPlay:GRATicule:INTensity

N (see [page 1730](#))

Command Syntax :DISPlay:GRATicule:INTensity <value>

<value> ::= an integer from 0 to 100 in NR1 format.

The :DISPlay:GRATicule:INTensity command sets the graticule (grid) intensity.

Query Syntax :DISPlay:GRATicule:INTensity?

The :DISPlay:GRATicule:INTensity? query returns the graticule (grid) intensity setting.

Return Format <value><NL>

- See Also**
- [":DISPlay:GRATicule:ALABels"](#) on page 442
 - [":DISPlay:GRATicule:TYPE"](#) on page 444

:DISPlay:GRATicule:TYPE

N (see [page 1730](#))

Command Syntax :DISPlay:GRATicule:TYPE <type>

<type> ::= {FULL | MVOLt | IRE}

The :DISPlay:GRATicule:TYPE command sets the graticule (grid) type.

When the TV trigger type is selected (see **":TRIGger:MODE"** on page 1439), and the vertical scaling of at least one displayed channel is 140 mV/div, the :DISPlay:GRATicule:TYPE command lets you select from these grid types:

- FULL – the normal oscilloscope grid.
- MVOLt – shows vertical grids, labeled on the left, from -0.3 V to 0.8 V.
- IRE – (Institute of Radio Engineers) shows vertical grids in IRE units, labeled on the left, from -40 to 100 IRE. The 0.35 V and 0.7 V levels from the MVOLt grid are also shown and labeled at the right. When the IRE grid is selected, cursor values on the display are also shown in IRE units. However, cursor values via the remote interface are not in IRE units.

The MVOLt and IRE grid values are accurate when the vertical scaling is 140 mV/division and the vertical offset is 245 mV.

Query Syntax :DISPlay:GRATicule:TYPE?

The :DISPlay:GRATicule:TYPE? query returns the graticule (grid) type setting.

Return Format <type><NL>

<type> ::= {FULL | MVOL | IRE}

- See Also**
- **":TRIGger:MODE"** on page 1439
 - **":CHANnel<n>:SCALE"** on page 379
 - **":CHANnel<n>:OFFSet"** on page 361
 - **":DISPlay:GRATicule:ALABels"** on page 442
 - **":DISPlay:GRATicule:INTensity"** on page 443

:DISPlay:INTensity:WAVeform

N (see [page 1730](#))

Command Syntax :DISPlay:INTensity:WAVeform <value>

<value> ::= an integer from 0 to 100 in NR1 format.

The :DISPlay:INTensity:WAVeform command sets the waveform intensity.

This is the same as adjusting the front panel **[Intensity]** knob.

Query Syntax :DISPlay:INTensity:WAVeform?

The :DISPlay:INTensity:WAVeform? query returns the waveform intensity setting.

Return Format <value><NL>

<value> ::= an integer from 0 to 100 in NR1 format.

See Also • ["Introduction to :DISPlay Commands"](#) on page 431

:DISPlay:LABel

N (see [page 1730](#))

Command Syntax :DISPlay:LABel <value>

<value> ::= {{1 | ON} | {0 | OFF}}

The :DISPlay:LABel command turns the analog and digital channel labels on and off.

Query Syntax :DISPlay:LABel?

The :DISPlay:LABel? query returns the display mode of the analog and digital labels.

Return Format <value><NL>

<value> ::= {0 | 1}

- See Also**
- ["Introduction to :DISPlay Commands"](#) on page 431
 - [":CHANnel<n>:LABel"](#) on page 360

Example Code

```
' DISP_LABEL
' - Turns label names ON or OFF on the analyzer display.
myScope.WriteString ":DISPlay:LABel ON" ' Turn on labels.
```

See complete example programs at: [Chapter 50](#), "Programming Examples," starting on page 1739

:DISPlay:LABList

N (see [page 1730](#))

Command Syntax :DISPlay:LABList <binary block data>

<binary block> ::= an ordered list of up to 75 labels, a maximum of 32 characters each, separated by newline characters.

The :DISPlay:LABList command adds labels to the label list. Labels are added in alphabetical order.

NOTE

Labels that begin with the same alphabetic base string followed by decimal digits are considered duplicate labels. Duplicate labels are not added to the label list. For example, if label "A0" is in the list and you try to add a new label called "A1234567890123456789012345678901", the new label is not added.

Query Syntax :DISPlay:LABList?

The :DISPlay:LABList? query returns the label list.

Return Format <binary block><NL>

<binary block> ::= an ordered list of up to 75 labels, a maximum of 32 characters each, separated by newline characters.

- See Also**
- ["Introduction to :DISPlay Commands"](#) on page 431
 - [":DISPlay:LABel"](#) on page 446
 - [":CHANnel<n>:LABel"](#) on page 360
 - [":DIGital<d>:LABel"](#) on page 424
 - [":BUS<n>:LABel"](#) on page 328

:DISPlay:MENU

N (see [page 1730](#))

Command Syntax :DISPlay:MENU <menu>

<menu> ::= {MASK | MEASure | SEGmented | LISTer | POWer | OFF}

The :DISPlay:MENU command changes the front panel softkey menu or turns it off. When off, channel setup information is displayed instead.

:DISPlay:MESSage:CLEar

N (see [page 1730](#))

Command Syntax :DISPlay:MESSage:CLEar

The :DISPlay:MESSage:CLEar command removes all user messages that are currently on screen.

See Also • [":SYSTem:DSP"](#) on page 1388

:DISPlay:PERStence

N (see [page 1730](#))

Command Syntax :DISPlay:PERStence <value>

<value> ::= {MINimum | INFinite | <time>}

<time> ::= seconds in in NR3 format from 100E-3 to 60E0

The :DISPlay:PERStence command specifies the persistence setting:

- MINimum – indicates zero persistence.
- INFinite – indicates infinite persistence.
- <time> – for variable persistence, that is, you can specify how long acquisitions remain on the screen.

Use the :DISPlay:PERStence:CLEar command to erase points stored by persistence.

Query Syntax :DISPlay:PERStence?

The :DISPlay:PERStence? query returns the specified persistence setting.

Return Format <value><NL>

<value> ::= {MIN | INF | <time>}

- See Also**
- ["Introduction to :DISPlay Commands"](#) on page 431
 - [":DISPlay:PERStence:CLEar"](#) on page 451

:DISPlay:PERStence:CLEar

N (see [page 1730](#))

Command Syntax :DISPlay:PERStence:CLEar

The :DISPlay:PERStence:CLEar command erases all persistence data from the display, leaving the data from the last acquisition.

If the oscilloscope is running, the display will begin to accumulate waveform and persistence data again.

The :DISPlay:CLEar command clears all waveform data from the display, including the data from the last acquisition.

- See Also**
- [":DISPlay:PERStence"](#) on page 450
 - [":DISPlay:CLEar"](#) on page 439

:DISPlay:SIDebar

N (see [page 1730](#))

Command Syntax :DISPlay:SIDebar <sidebar>

```
<sidebar> ::= {SUMMary | CURSors | MEASurements | DVM | NAVigate  
              | CONTROLS | EVENTs | COUNter | HISTogram}
```

The :DISPlay:SIDebar command specifies the sidebar dialog to display on the screen.

:DISPlay:TRANSPARENT

N (see [page 1730](#))

Command Syntax :DISPlay:TRANSPARENT <setting>

<setting> ::= {OFF | ON}

The :DISPlay:TRANSPARENT command enables or disables transparent mode for dialog box backgrounds in the front panel graphical user interface.

This command maps to the **Transparent** softkey that appears in the front panel user interface under **[Utility] > Options > Preferences**.

Query Syntax :DISPlay:TRANSPARENT?

The :DISPlay:TRANSPARENT? query returns the transparent setting.

Return Format <setting><NL>

<setting> ::= {OFF | ON}

See Also • ["Introduction to :DISPlay Commands"](#) on page 431

:DISPlay:VECTors

N (see [page 1730](#))

Command Syntax :DISPlay:VECTors <vectors>
 <vectors> ::= {{1 | ON} | {0 | OFF}}

The :DISPlay:VECTors command turns vector display on or off.

When vectors are turned on, the oscilloscope displays lines connecting sampled data points.

On the 1 GHz and 1.5 GHz bandwidth models, you can turn off vectors to view just waveform data points.

Query Syntax :DISPlay:VECTors?

The :DISPlay:VECTors? query returns the vectors setting.

Return Format <vectors><NL>
 <vectors> ::= {1 | 0}

See Also • ["Introduction to :DISPlay Commands"](#) on page 431

19 :DVM Commands

These commands control the digital voltmeter (DVM) feature.

Table 109 :DVM Commands Summary

Command	Query	Options and Query Returns
:DVM:ARANge {{0 OFF} {1 ON}} (see page 456)	:DVM:ARANge? (see page 456)	{0 1}
n/a	:DVM:CURRent? (see page 457)	<dvm_value> ::= floating-point number in NR3 format
:DVM:ENABle {{0 OFF} {1 ON}} (see page 458)	:DVM:ENABle? (see page 458)	{0 1}
:DVM:MODE <mode> (see page 459)	:DVM:MODE? (see page 459)	<dvm_mode> ::= {ACRMs DC DCRMs}
:DVM:SOURce <source> (see page 460)	:DVM:SOURce? (see page 460)	<source> ::= {CHANnel<n>} <n> ::= 1-2 or 1-4 in NR1 format

:DVM:ARANge

N (see [page 1730](#))

Command Syntax :DVM:ARANge <setting>
 <setting> ::= {{OFF | 0} | {ON | 1}}

If the selected digital voltmeter (DVM) source channel is not used in oscilloscope triggering, the :DVM:ARANge command turns the digital voltmeter's Auto Range capability on or off.

- When on, the DVM channel's vertical scale, vertical (ground level) position, and trigger (threshold voltage) level (used for the counter frequency measurement) are automatically adjusted.

The Auto Range capability overrides attempted adjustments of the channel's vertical scale and position.

- When off, you can adjust the channel's vertical scale and position normally.

Query Syntax :DVM:ARANge?

The :DVM:ARANge? query returns a flag indicating whether the digital voltmeter's Auto Range capability is on or off.

Return Format <setting><NL>
 <setting> ::= {0 | 1}

- See Also**
- [":DVM:SOURce"](#) on page 460
 - [":DVM:ENABLE"](#) on page 458
 - [":DVM:MODE"](#) on page 459

:DVM:CURRent

N (see [page 1730](#))

Query Syntax :DVM:CURRent?

The :DVM:CURRent? query returns the displayed 3-digit DVM value based on the current mode.

NOTE

It can take up to a few seconds after DVM analysis is enabled before this query starts to produce good results, that is, results other than +9.9E+37. To wait for good values after DVM analysis is enabled, programs should loop until a value less than +9.9E+37 is returned.

Return Format <dvm_value><NL>

<dvm_value> ::= floating-point number in NR3 format

- See Also**
- [":DVM:SOURce"](#) on page 460
 - [":DVM:ENABle"](#) on page 458
 - [":DVM:MODE"](#) on page 459

:DVM:ENABLE

N (see [page 1730](#))

Command Syntax :DVM:ENABle <setting>

<setting> ::= {{OFF | 0} | {ON | 1}}

The :DVM:ENABLE command turns the digital voltmeter (DVM) analysis feature on or off.

Query Syntax :DVM:ENABle?

The :DVM:ENABLE? query returns a flag indicating whether the digital voltmeter (DVM) analysis feature is on or off.

Return Format <setting><NL>

<setting> ::= {0 | 1}

- See Also**
- [":DVM:SOURce"](#) on page 460
 - [":DVM:MODE"](#) on page 459
 - [":DVM:ARANge"](#) on page 456

:DVM:MODE

N (see [page 1730](#))

Command Syntax :DVM:MODE <dvm_mode>
 <dvm_mode> ::= {ACRMs | DC | DCRMs}

The :DVM:MODE command sets the digital voltmeter (DVM) mode:

- ACRMs – displays the root-mean-square value of the acquired data, with the DC component removed.
- DC – displays the DC value of the acquired data.
- DCRMs – displays the root-mean-square value of the acquired data.

Query Syntax :DVM:MODE?

The :DVM:MODE? query returns the selected DVM mode.

Return Format <dvm_mode><NL>
 <dvm_mode> ::= {ACRM | DC | DCRM}

- See Also**
- [":DVM:ENABLE"](#) on page 458
 - [":DVM:SOURce"](#) on page 460
 - [":DVM:ARANge"](#) on page 456
 - [":DVM:CURRent"](#) on page 457

:DVM:SOURce

N (see [page 1730](#))

Command Syntax :DVM:SOURce <source>

<source> ::= {CHANnel<n>}

<n> ::= 1-2 or 1-4 in NR1 format

The :DVM:SOURce command sets the select the analog channel on which digital voltmeter (DVM) measurements are made.

The selected channel does not have to be on (displaying a waveform) in order for DVM measurements to be made.

Query Syntax :DVM:SOURce?

The :DVM:SOURce? query returns the selected DVM input source.

Return Format <source><NL>

<source> ::= {CHAN<n>}

<n> ::= 1-2 or 1-4 in NR1 format

- See Also**
- [":DVM:ENABLE"](#) on page 458
 - [":DVM:MODE"](#) on page 459
 - [":DVM:ARANge"](#) on page 456
 - [":DVM:CURRent"](#) on page 457

20 :EXternal Trigger Commands

Control the input characteristics of the external trigger input. See "[Introduction to :EXternal Trigger Commands](#)" on page 461.

Table 110 :EXternal Trigger Commands Summary

Command	Query	Options and Query Returns
:EXternal:BWLimit <bwlimit> (see page 462)	:EXternal:BWLimit? (see page 462)	<bwlimit> ::= {0 OFF}
:EXternal:PROBe <attenuation> (see page 463)	:EXternal:PROBe? (see page 463)	<attenuation> ::= probe attenuation ratio in NR3 format
:EXternal:RANGe <range> [<suffix>] (see page 464)	:EXternal:RANGe? (see page 464)	<range> ::= vertical full-scale range value in NR3 format <suffix> ::= {V mV}
:EXternal:UNITs <units> (see page 465)	:EXternal:UNITs? (see page 465)	<units> ::= {VOLT AMPere}

Introduction to :EXternal Trigger Commands

The EXternal trigger subsystem commands control the input characteristics of the external trigger input. The probe factor, impedance, input range, input protection state, units, and bandwidth limit settings may all be queried. Depending on the instrument type, some settings may be changeable.

Reporting the Setup

Use :EXternal? to query setup information for the EXternal subsystem.

Return Format

The following is a sample response from the :EXternal query. In this case, the query was issued following a *RST command.

```
:EXT: BWL 0; RANG +8.0E+00; UNIT VOLT; PROB +1.000E+00
```

:EXternal:BWLimit

C (see [page 1730](#))

Command Syntax :EXternal:BWLimit <bwlimit>

<bwlimit> ::= {0 | OFF}

The :EXternal:BWLimit command is provided for product compatibility. The only legal value is 0 or OFF. Use the :TRIGger:HFReject command to limit bandwidth on the external trigger input.

Query Syntax :EXternal:BWLimit?

The :EXternal:BWLimit? query returns the current setting of the low-pass filter (always 0).

Return Format <bwlimit><NL>

<bwlimit> ::= 0

- See Also**
- ["Introduction to :EXternal Trigger Commands"](#) on page 461
 - ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:HFReject"](#) on page 1430

:EXternal:PROBe

C (see [page 1730](#))

Command Syntax :EXternal:PROBe <attenuation>

<attenuation> ::= probe attenuation ratio in NR3 format

The :EXternal:PROBe command specifies the probe attenuation factor for the external trigger. The probe attenuation factor may be 0.1 to 1000. This command does not change the actual input sensitivity of the oscilloscope. It changes the reference constants for scaling the display factors and for setting trigger levels.

If an AutoProbe probe is connected to the oscilloscope, the attenuation value cannot be changed from the sensed value. Attempting to set the oscilloscope to an attenuation value other than the sensed value produces an error.

Query Syntax :EXternal:PROBe?

The :EXternal:PROBe? query returns the current probe attenuation factor for the external trigger.

Return Format <attenuation><NL>

<attenuation> ::= probe attenuation ratio in NR3 format

- See Also**
- ["Introduction to :EXternal Trigger Commands"](#) on page 461
 - [":EXternal:RANGe"](#) on page 464
 - ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":CHANnel<n>:PROBe"](#) on page 362

:EXternal:RANGe

C (see [page 1730](#))

Command Syntax :EXternal:RANGe <range>[<suffix>]

<range> ::= vertical full-scale range value in NR3 format

<suffix> ::= {V | mV}

The :EXternal:RANGe command is provided for product compatibility. When using 1:1 probe attenuation, the range is either 1.6 V or 8 V.

The range is automatically recalculated when the external trigger probe attenuation factor is changed.

Query Syntax :EXternal:RANGe?

The :EXternal:RANGe? query returns the current full-scale range setting for the external trigger.

Return Format <range_argument><NL>

<range_argument> ::= external trigger range value in NR3 format

- See Also**
- ["Introduction to :EXternal Trigger Commands"](#) on page 461
 - [":EXternal:PROBe"](#) on page 463
 - ["Introduction to :TRIGger Commands"](#) on page 1425

:EXternal:UNITs

N (see [page 1730](#))

Command Syntax :EXternal:UNITs <units>

<units> ::= {VOLT | AMPere}

The :EXternal:UNITs command sets the measurement units for the probe connected to the external trigger input. Select VOLT for a voltage probe and select AMPere for a current probe. Measurement results, channel sensitivity, and trigger level will reflect the measurement units you select.

Query Syntax :EXternal:UNITs?

The :CHANnel<n>:UNITs? query returns the current units setting for the external trigger.

Return Format <units><NL>

<units> ::= {VOLT | AMP}

- See Also**
- ["Introduction to :EXternal Trigger Commands"](#) on page 461
 - ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":EXternal:RANGe"](#) on page 464
 - [":EXternal:PROBe"](#) on page 463
 - [":CHANnel<n>:UNITs"](#) on page 380

21 :FRANalysis Commands

Control oscilloscope functions associated with the Frequency Response Analysis (FRA) feature, which is available in oscilloscope models that have a license-enabled built-in waveform generator. See "[Introduction to :FRANalysis Commands](#)" on page 468.

Table 111 :FRANalysis Commands Summary

Command	Query	Options and Query Returns
n/a	:FRANalysis:DATA? [SWEep SINGLE] (see page 469)	<binary_block> ::= comma-separated data with newlines at the end of each row
:FRANalysis:ENABle {{0 OFF} {1 ON}} (see page 470)	:FRANalysis:ENABle? (see page 470)	{0 1}
:FRANalysis:FREQuency:MODE <setting> (see page 471)	:FRANalysis:FREQuency:MODE? (see page 471)	<setting> ::= {SWEep SINGLE}
:FRANalysis:FREQuency:SINGLE <value>[suffix] (see page 472)	:FRANalysis:FREQuency:SINGLE? (see page 472)	<value> ::= {20 100 1000 10000 100000 1000000 10000000 20000000} [suffix] ::= {Hz kHz MHz}
:FRANalysis:FREQuency:START <value>[suffix] (see page 473)	:FRANalysis:FREQuency:START? (see page 473)	<value> ::= {20 100 1000 10000 100000 1000000 10000000} [suffix] ::= {Hz kHz MHz}
:FRANalysis:FREQuency:STOP <value>[suffix] (see page 474)	:FRANalysis:FREQuency:STOP? (see page 474)	<value> ::= {100 1000 10000 100000 1000000 10000000 20000000} [suffix] ::= {Hz kHz MHz}
:FRANalysis:PPDecade <value> (see page 475)	:FRANalysis:PPDecade? (see page 475)	<value> ::= {10 20 30 40 50 60 70 80 90 100}
:FRANalysis:RUN (see page 476)	n/a	n/a

Table 111 :FRANalysis Commands Summary (continued)

Command	Query	Options and Query Returns
:FRANalysis:SOURce:INPut <source> (see page 477)	:FRANalysis:SOURce:INPut? (see page 477)	<source> ::= CHANnel<n> <n> ::= 1 to (# analog channels) in NR1 format
:FRANalysis:SOURce:OUTPut <source> (see page 478)	:FRANalysis:SOURce:OUTPut? (see page 478)	<source> ::= CHANnel<n> <n> ::= 1 to (# analog channels) in NR1 format
:FRANalysis:TRACe <selection> (see page 479)	:FRANalysis:TRACe? (see page 479)	<selection> ::= {NONE ALL GAIN PHASe}[, {GAIN PHASe}]
:FRANalysis:WGEN:LOAD <impedance> (see page 480)	:FRANalysis:WGEN:LOAD? (see page 480)	<impedance> ::= {ONEMeg FIFTy}
:FRANalysis:WGEN:VOLTage <amplitude>, [<range>] (see page 481)	:FRANalysis:WGEN:VOLTage? [<range>] (see page 481)	<amplitude> ::= amplitude in volts in NR3 format <range> ::= {F20HZ F100HZ F1KHZ F10KHZ F100KHZ F1MHZ F10MHZ F20MHZ}
:FRANalysis:WGEN:VOLTage:PROFile {{0 OFF} {1 ON}} (see page 482)	:FRANalysis:WGEN:VOLTage:PROFile? (see page 482)	{0 1}

Introduction to :FRANalysis Commands

The FRANalysis subsystem controls the Frequency Response Analysis feature in the oscilloscope.

The Frequency Response Analysis (FRA) feature controls the built-in waveform generator to sweep a sine wave across a range of frequencies while measuring the input to and output from a device under test (DUT). At each frequency, gain (A) and phase are measured and plotted on a frequency response chart.

Reporting the Setup

Use :FRANalysis? to query setup information for the FRANalysis subsystem.

Return Format

The following is a sample response from the :FRANalysis? query. In this case, the query was issued following a *RST command.

```
:FRAN:SOUR:INP CHAN1;OUTP CHAN2;;FRAN:FREQ:STAR +100E+00;
STOP +20.000000E+06;;FRAN:WGEN:VOLT +200.0E-03;LOAD FIFT
```

:FRANalysis:DATA

N (see [page 1730](#))

Query Syntax :FRANalysis:DATA? [SWEep | SINGle]

The :FRANalysis:DATA? query returns the frequency response analysis data.

The data is returned in four comma-separated columns of data for each step in the sweep: Frequency (Hz), Amplitude (Vpp), Gain (dB), and Phase (°).

You can use the :FRANalysis:TRACe command to specify whether to include gain, phase, both gain and phase, or neither in the frequency response analysis results.

The SWEep or SINGle option specifies whether to get the data from a sweep or single-frequency analysis (see :FRANalysis:FREQuency:MODE). If this option is not specified, the data from the sweep analysis is returned by default.

Return Format <binary_block><NL>

<binary_block> ::= comma-separated data with newlines at the end of each row

- See Also**
- [":FRANalysis:ENABle"](#) on page 470
 - [":FRANalysis:FREQuency:MODE"](#) on page 471
 - [":FRANalysis:FREQuency:SINGle"](#) on page 472
 - [":FRANalysis:FREQuency:START"](#) on page 473
 - [":FRANalysis:FREQuency:STOP"](#) on page 474
 - [":FRANalysis:RUN"](#) on page 476
 - [":FRANalysis:SOURce:INPut"](#) on page 477
 - [":FRANalysis:SOURce:OUTPut"](#) on page 478
 - [":FRANalysis:TRACe"](#) on page 479
 - [":FRANalysis:WGEN:LOAD"](#) on page 480
 - [":FRANalysis:WGEN:VOLTage"](#) on page 481

:FRANalysis:ENABLE

N (see [page 1730](#))

Command Syntax :FRANalysis:ENABLE <setting>

<setting> ::= {{0 | OFF} | {1 | ON}}

The :FRANalysis:ENABLE command turns the Frequency Response Analysis (FRA) feature on or off.

Query Syntax :FRANalysis:ENABLE?

The :FRANalysis:ENABLE? query returns a flag indicating whether the Frequency Response Analysis (FRA) feature is on or off.

Return Format <setting><NL>

<setting> ::= {0 | 1}

- See Also**
- [":FRANalysis:DATA"](#) on page 469
 - [":FRANalysis:FREQuency:START"](#) on page 473
 - [":FRANalysis:FREQuency:STOP"](#) on page 474
 - [":FRANalysis:RUN"](#) on page 476
 - [":FRANalysis:SOURce:INPut"](#) on page 477
 - [":FRANalysis:SOURce:OUTPut"](#) on page 478
 - [":FRANalysis:WGEN:LOAD"](#) on page 480
 - [":FRANalysis:WGEN:VOLTage"](#) on page 481

:FRANalysis:FREQuency:MODE

N (see [page 1730](#))

Command Syntax :FRANalysis:FREQuency:MODE <setting>

<setting> ::= {SWEep | SINGle}

The :FRANalysis:FREQuency:MODE command lets you select between the normal swept frequency response analysis or analysis at a single frequency, which can be useful when debugging.

Query Syntax :FRANalysis:FREQuency:MODE?

The :FRANalysis:FREQuency:MODE? query returns the frequency mode setting.

Return Format <setting><NL>

<setting> ::= {SWEep | SINGle}

- See Also**
- [":FRANalysis:RUN"](#) on page 476
 - [":FRANalysis:FREQuency:SINGle"](#) on page 472
 - [":FRANalysis:FREQuency:START"](#) on page 473
 - [":FRANalysis:FREQuency:STOP"](#) on page 474
 - [":FRANalysis:PPDecade"](#) on page 475
 - [":FRANalysis:WGEN:VOLTage:PROFile"](#) on page 482

:FRANalysis:FREQuency:SINGle

N (see [page 1730](#))

Command Syntax :FRANalysis:FREQuency:SINGle <value>[suffix]

<value> ::= {20 | 100 | 1000 | 10000 | 100000 | 1000000 | 10000000
| 2000000}

[suffix] ::= {Hz | kHz | MHz}

The :FRANalysis:FREQuency:SINGle command sets the single frequency value. The frequency response analysis is displayed on a log scale Bode plot, so you can select from decade values in addition to the minimum frequency of 20 Hz.

Query Syntax :FRANalysis:FREQuency:SINGle?

The :FRANalysis:FREQuency:SINGle? query returns the single frequency setting.

Return Format <value><NL>

<value> ::= {20 | 100 | 1000 | 10000 | 100000 | 1000000 | 10000000
| 2000000}

- See Also**
- [":FRANalysis:DATA"](#) on page 469
 - [":FRANalysis:ENABLE"](#) on page 470
 - [":FRANalysis:PPDecade"](#) on page 475
 - [":FRANalysis:FREQuency:MODE"](#) on page 471
 - [":FRANalysis:RUN"](#) on page 476
 - [":FRANalysis:SOURce:INPut"](#) on page 477
 - [":FRANalysis:SOURce:OUTPut"](#) on page 478
 - [":FRANalysis:WGEN:LOAD"](#) on page 480
 - [":FRANalysis:WGEN:VOLTage"](#) on page 481
 - [":FRANalysis:WGEN:VOLTage:PROFile"](#) on page 482

:FRANalysis:FREQuency:STARt

N (see [page 1730](#))

Command Syntax :FRANalysis:FREQuency:STARt <value>[suffix]
 <value> ::= {20 | 100 | 1000 | 10000 | 100000 | 1000000 | 10000000}
 [suffix] ::= {Hz | kHz | MHz}

The :FRANalysis:FREQuency:STARt command sets the frequency sweep start value. The frequency response analysis is displayed on a log scale Bode plot, so you can select from decade values in addition to the minimum frequency of 20 Hz.

Query Syntax :FRANalysis:FREQuency:STARt?

The :FRANalysis:FREQuency:STARt? query returns the frequency sweep start setting.

Return Format <value><NL>
 <value> ::= {20 | 100 | 1000 | 10000 | 100000 | 1000000 | 10000000}

- See Also**
- [":FRANalysis:DATA"](#) on page 469
 - [":FRANalysis:ENABle"](#) on page 470
 - [":FRANalysis:FREQuency:STOP"](#) on page 474
 - [":FRANalysis:PPDecade"](#) on page 475
 - [":FRANalysis:FREQuency:MODE"](#) on page 471
 - [":FRANalysis:RUN"](#) on page 476
 - [":FRANalysis:SOURce:INPut"](#) on page 477
 - [":FRANalysis:SOURce:OUTPut"](#) on page 478
 - [":FRANalysis:WGEN:LOAD"](#) on page 480
 - [":FRANalysis:WGEN:VOLTage"](#) on page 481
 - [":FRANalysis:WGEN:VOLTage:PROFile"](#) on page 482

:FRANalysis:FREQuency:STOP

N (see [page 1730](#))

Command Syntax :FRANalysis:FREQuency:STOP <value>[suffix]

<value> ::= {100 | 1000 | 10000 | 100000 | 1000000 | 10000000 | 20000000
}

[suffix] ::= {Hz | kHz | MHz}

The :FRANalysis:FREQuency:STOP command sets the frequency sweep stop value. The frequency response analysis is displayed on a log scale Bode plot, so you can select from decade values in addition to the maximum frequency of 20 MHz.

Query Syntax :FRANalysis:FREQuency:STOP?

The :FRANalysis:FREQuency:STOP? query returns the frequency sweep stop setting.

Return Format <value><NL>

<value> ::= {100 | 1000 | 10000 | 100000 | 1000000 | 10000000 | 20000000
}

- See Also**
- [":FRANalysis:DATA"](#) on page 469
 - [":FRANalysis:ENABLE"](#) on page 470
 - [":FRANalysis:FREQuency:START"](#) on page 473
 - [":FRANalysis:PPDecade"](#) on page 475
 - [":FRANalysis:FREQuency:MODE"](#) on page 471
 - [":FRANalysis:RUN"](#) on page 476
 - [":FRANalysis:SOURce:INPut"](#) on page 477
 - [":FRANalysis:SOURce:OUTPut"](#) on page 478
 - [":FRANalysis:WGEN:LOAD"](#) on page 480
 - [":FRANalysis:WGEN:VOLTage"](#) on page 481
 - [":FRANalysis:WGEN:VOLTage:PROFile"](#) on page 482

:FRANalysis:PPDecade

N (see [page 1730](#))

Command Syntax :FRANalysis:PPDecade <value>

<value> ::= {10 | 20 | 30 | 40 | 50 | 60 | 70 | 80 | 90 | 100}

The :FRANalysis:PPDecade command specifies the number of points per decade in the frequency response analysis.

Query Syntax :FRANalysis:PPDecade?

The :FRANalysis:PPDecade? query returns the points per decade setting.

Return Format <value><NL>

- See Also**
- [":FRANalysis:FREQuency:START"](#) on page 473
 - [":FRANalysis:FREQuency:STOP"](#) on page 474
 - [":FRANalysis:WGEN:VOLTage:PROFile"](#) on page 482

:FRANalysis:RUN

N (see [page 1730](#))

Command Syntax

`:FRANalysis:RUN`

The :FRANalysis:RUN command performs the Frequency Response Analysis. This analysis controls the built-in waveform generator to sweep a sine wave across a range of frequencies while measuring the input to and output from a device under test (DUT). At each frequency, gain (A) and phase are measured and plotted on a Bode frequency response chart.

The :FRANalysis:APPLY command is a valid compatible alias for the :FRANalysis:RUN command.

When the frequency response analysis completes, you can use the :FRANalysis:DATA? query to get four comma-separated columns of data for each step in the sweep: Frequency (Hz), Amplitude (Vpp), Gain (dB), and Phase (°).

You can use the :FRANalysis:TRACe command to specify whether to include gain, phase, both gain and phase, or neither in the frequency response analysis results.

It takes some time for the frequency sweep analysis to complete. You can query bit 0 of the Standard Event Status Register (*ESR?) to find out when the analysis is complete.

- See Also
- [":FRANalysis:DATA"](#) on page 469
 - [":FRANalysis:ENABle"](#) on page 470
 - [":FRANalysis:FREQuency:MODE"](#) on page 471
 - [":FRANalysis:FREQuency:SINGle"](#) on page 472
 - [":FRANalysis:FREQuency:STARt"](#) on page 473
 - [":FRANalysis:FREQuency:STOP"](#) on page 474
 - [":FRANalysis:SOURce:INPut"](#) on page 477
 - [":FRANalysis:SOURce:OUTPut"](#) on page 478
 - [":FRANalysis:TRACe"](#) on page 479
 - [":FRANalysis:WGEN:LOAD"](#) on page 480
 - [":FRANalysis:WGEN:VOLTage"](#) on page 481
 - ["*ESR \(Standard Event Status Register\)"](#) on page 238

:FRANalysis:SOURce:INPut

N (see [page 1730](#))

Command Syntax :FRANalysis:SOURce:INPut <source>

<source> ::= CHANnel<n>

<n> ::= 1 to (# analog channels) in NR1 format

The :FRANalysis:SOURce:INPut command specifies the analog input channel that is probing the input voltage to the device under test (DUT) in the frequency response analysis.

Query Syntax :FRANalysis:SOURce:INPut?

The :FRANalysis:SOURce:INPut? query returns the currently selected channel probing the input voltage.

Return Format <source><NL>

<source> ::= CHAN<n>

- See Also**
- [":FRANalysis:DATA"](#) on page 469
 - [":FRANalysis:ENABLE"](#) on page 470
 - [":FRANalysis:FREQuency:START"](#) on page 473
 - [":FRANalysis:FREQuency:STOP"](#) on page 474
 - [":FRANalysis:RUN"](#) on page 476
 - [":FRANalysis:SOURce:OUTPut"](#) on page 478
 - [":FRANalysis:WGEN:LOAD"](#) on page 480
 - [":FRANalysis:WGEN:VOLTage"](#) on page 481

:FRANalysis:SOURce:OUTPut

N (see [page 1730](#))

Command Syntax :FRANalysis:SOURce:OUTPut <source>

<source> ::= CHANnel<n>

<n> ::= 1 to (# analog channels) in NR1 format

The :FRANalysis:SOURce:OUTPut command specifies the analog input channel that is probing the output voltage from the device under test (DUT) in the frequency response analysis.

Query Syntax :FRANalysis:SOURce:OUTPut?

The :FRANalysis:SOURce:OUTPut? query returns the currently selected channel probing the output voltage.

Return Format <source><NL>

<source> ::= CHAN<n>

- See Also**
- [":FRANalysis:DATA"](#) on page 469
 - [":FRANalysis:ENABLE"](#) on page 470
 - [":FRANalysis:FREQuency:START"](#) on page 473
 - [":FRANalysis:FREQuency:STOP"](#) on page 474
 - [":FRANalysis:RUN"](#) on page 476
 - [":FRANalysis:SOURce:INPut"](#) on page 477
 - [":FRANalysis:WGEN:LOAD"](#) on page 480
 - [":FRANalysis:WGEN:VOLTage"](#) on page 481

:FRANalysis:TRACe

N (see [page 1730](#))

Command Syntax :FRANalysis:TRACe <selection>

<selection> ::= {NONE | ALL | GAIN | PHASe}[, {GAIN | PHASe}]

The :FRANalysis:TRACe command specifies whether to include gain, phase, both gain and phase, or neither in the frequency response analysis results.

NOTE

This command affects the oscilloscope's front panel graphical user interface (plot and table) as well as when saving analysis data.

Query Syntax :FRANalysis:TRACe?

The :FRANalysis:TRACe? query returns a comma-separated list of the types of data that are currently included in the frequency response analysis results, or "NONE" if neither gain nor phase data is included.

Return Format <selection_list><NL>

<selection_list> ::= {"NONE" | "GAIN" | "PHASe" | "GAIN, PHASe"}

- See Also**
- [":FRANalysis:RUN"](#) on page 476
 - [":FRANalysis:DATA"](#) on page 469

:FRANalysis:WGEN:LOAD

N (see [page 1730](#))

Command Syntax :FRANalysis:WGEN:LOAD <impedance>

<impedance> ::= {ONEMeg | FIFTy}

The :FRANalysis:WGEN:LOAD command selects the expected output load impedance.

The output impedance of the Gen Out BNC is fixed at 50 ohms. However, the output load selection lets the waveform generator display the correct amplitude and offset levels for the expected output load.

If the actual load impedance is different than the selected value, the displayed amplitude and offset levels will be incorrect.

Query Syntax :FRANalysis:WGEN:LOAD?

The :FRANalysis:WGEN:LOAD? query returns the current expected output load impedance.

Return Format <impedance><NL>

<impedance> ::= {ONEM | FIFT}

- See Also**
- [":FRANalysis:DATA"](#) on page 469
 - [":FRANalysis:ENABLE"](#) on page 470
 - [":FRANalysis:FREQuency:START"](#) on page 473
 - [":FRANalysis:FREQuency:STOP"](#) on page 474
 - [":FRANalysis:RUN"](#) on page 476
 - [":FRANalysis:SOURce:INPut"](#) on page 477
 - [":FRANalysis:SOURce:OUTPut"](#) on page 478
 - [":FRANalysis:WGEN:VOLTage"](#) on page 481

:FRANalysis:WGEN:VOLTage

N (see [page 1730](#))

Command Syntax :FRANalysis:WGEN:VOLTage <amplitude>, [<range>]

<amplitude> ::= amplitude in volts in NR3 format

<range> ::= {F20HZ | F100HZ | F1KHZ | F10KHZ | F100KHZ | F1MHZ
| F10MHZ | F20MHZ}

The :FRANalysis:WGEN:VOLTage command specifies the waveform generator's output sine wave amplitude.

Use the :WGEN:VOLTage:OFFSet command to specify the offset voltage or DC level.

You can also specify the amplitude and offset indirectly using the :WGEN:VOLTage:HIGH and :WGEN:VOLTage:LOW commands. For example, an amplitude of 5 V and an offset of 1 V is the same as a high-level voltage of 4 V and a low-level voltage of -1 V.

When the amplitude profile setting is on (:FRANalysis:WGEN:VOLTage:PROFile ON), the <range> option specifies the initial ramp amplitude at the frequency setting. Amplitudes ramp between the settings specified for individual frequencies.

Query Syntax :FRANalysis:WGEN:VOLTage? [<range>]

The :FRANalysis:WGEN:VOLTage? query returns the currently specified waveform generator amplitude.

When the amplitude profile setting is on (:FRANalysis:WGEN:VOLTage:PROFile ON), the <range> option specifies the frequency whose initial ramp amplitude is returned.

Return Format <amplitude><NL>

<amplitude> ::= amplitude in volts in NR3 format

- See Also**
- [":FRANalysis:WGEN:VOLTage:PROFile"](#) on page 482
 - [":FRANalysis:DATA"](#) on page 469
 - [":FRANalysis:ENABLE"](#) on page 470
 - [":FRANalysis:FREQuency:START"](#) on page 473
 - [":FRANalysis:FREQuency:STOP"](#) on page 474
 - [":FRANalysis:PPDecade"](#) on page 475
 - [":FRANalysis:RUN"](#) on page 476
 - [":FRANalysis:SOURce:INPut"](#) on page 477
 - [":FRANalysis:SOURce:OUTPut"](#) on page 478
 - [":FRANalysis:WGEN:LOAD"](#) on page 480

:FRANalysis:WGEN:VOLTage:PROFile

N (see [page 1730](#))

Command Syntax :FRANalysis:WGEN:VOLTage:PROFile {{0 | OFF} | {1 | ON}}

The :FRANalysis:WGEN:VOLTage:PROFile command enables or disables the ability to specify amplitude ramping within different decades.

Query Syntax :FRANalysis:WGEN:VOLTage:PROFile?

The :FRANalysis:WGEN:VOLTage:PROFile? query returns the voltage profile setting.

Return Format <setting><NL>
<setting> ::= {0 | 1}

- See Also**
- [":FRANalysis:WGEN:VOLTage"](#) on page 481
 - [":FRANalysis:PPDecade"](#) on page 475
 - [":FRANalysis:FREQuency:START"](#) on page 473
 - [":FRANalysis:FREQuency:STOP"](#) on page 474

22 :FUNction<m> Commands

Control math functions in the oscilloscope. See "[Introduction to :FUNction<m> Commands](#)" on page 489.

Table 112 :FUNction<m> Commands Summary

Command	Query	Options and Query Returns
:FUNction<m>:AVERage:COUNT <count> (see page 490)	:FUNction<m>:AVERage:COUNT? (see page 490)	<count> ::= an integer from 2 to 65536 in NR1 format <m> ::= 1 to (# math functions) in NR1 format
:FUNction<m>:BUS:CLOCK <source> (see page 491)	:FUNction<m>:BUS:CLOCK? (see page 491)	<source> ::= {CHANnel<n> DIGital<d>} <n> ::= 1 to (# analog channels) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format <m> ::= 1 to (# math functions) in NR1 format
:FUNction<m>:BUS:SLOPE <slope> (see page 492)	:FUNction<m>:BUS:SLOPE? (see page 492)	<slope> ::= {NEGative POSitive EITHer} <m> ::= 1 to (# math functions) in NR1 format
:FUNction<m>:BUS:YINCREMENT <value> (see page 493)	:FUNction<m>:BUS:YINCREMENT? (see page 493)	<value> ::= value per bus code, in NR3 format <m> ::= 1 to (# math functions) in NR1 format
:FUNction<m>:BUS:YORIGIN <value> (see page 494)	:FUNction<m>:BUS:YORIGIN? (see page 494)	<value> ::= value at bus code = 0, in NR3 format <m> ::= 1 to (# math functions) in NR1 format

Table 112 :FUNCTION<m> Commands Summary (continued)

Command	Query	Options and Query Returns
:FUNCTION<m>:BUS:YUNits <units> (see page 495)	:FUNCTION<m>:BUS:YUNits? (see page 495)	<units> ::= {VOLT AMPere NONE} <m> ::= 1 to (# math functions) in NR1 format
:FUNCTION<m>:CLEar (see page 496)	n/a	n/a
:FUNCTION<m>:DISPlay {{0 OFF} {1 ON}} (see page 497)	:FUNCTION<m>:DISPlay? (see page 497)	{0 1} <m> ::= 1 to (# math functions) in NR1 format
n/a	:FUNCTION<m>[:FFT]:BSIZE? (see page 498)	<bin_size> ::= Hz in NR3 format <m> ::= 1 to (# math functions) in NR1 format
:FUNCTION<m>[:FFT]:CENTer <frequency> (see page 499)	:FUNCTION<m>[:FFT]:CENTer? (see page 499)	<frequency> ::= the current center frequency in NR3 format. The range of legal values is from -25 GHz to 25 GHz. <m> ::= 1 to (# math functions) in NR1 format
:FUNCTION<m>[:FFT]:DETECTION:POINTS <number_of_buckets> (see page 500)	:FUNCTION<m>[:FFT]:DETECTION:POINTS? (see page 500)	<number_of_buckets> ::= an integer in NR1 format <m> ::= 1 to (# math functions) in NR1 format
:FUNCTION<m>[:FFT]:DETECTION:TYPE <type> (see page 501)	:FUNCTION<m>[:FFT]:DETECTION:TYPE? (see page 501)	<type> ::= {OFF SAMPLE PPositive PNEGative NORMal AVERage} <m> ::= 1 to (# math functions) in NR1 format
:FUNCTION<m>[:FFT]:FREQUENCY:START <frequency> (see page 502)	:FUNCTION<m>[:FFT]:FREQUENCY:START? (see page 502)	<frequency> ::= the start frequency in NR3 format. <m> ::= 1 to (# math functions) in NR1 format
:FUNCTION<m>[:FFT]:FREQUENCY:STOP <frequency> (see page 503)	:FUNCTION<m>[:FFT]:FREQUENCY:STOP? (see page 503)	<frequency> ::= the stop frequency in NR3 format. <m> ::= 1 to (# math functions) in NR1 format
:FUNCTION<m>[:FFT]:GATE <gating> (see page 504)	:FUNCTION<m>[:FFT]:GATE? (see page 504)	<gating> ::= {NONE ZOOM} <m> ::= 1-4 in NR1 format

Table 112 :FUNCTION<m> Commands Summary (continued)

Command	Query	Options and Query Returns
:FUNCTION<m>[:FFT]:PHASE:REFERENCE<ref_point> (see page 505)	:FUNCTION<m>[:FFT]:PHASE:REFERENCE? (see page 505)	<ref_point> ::= {TRIGGER DISPLAY} <m> ::= 1-4 in NR1 format
n/a	:FUNCTION<m>[:FFT]:RBWIDTH? (see page 506)	<resolution_bw> ::= Hz in NR3 format <m> ::= 1 to (# math functions) in NR1 format
:FUNCTION<m>[:FFT]:READOUT<n><readout_type> (see page 507)	:FUNCTION<m>[:FFT]:READOUT<n>? (see page 507)	<readout_type> ::= {SRATE BSIZE RBWIDTH} <m> ::= 1 to (# math functions) in NR1 format <n> ::= 1-2 in NR1 format, 2 is for dedicated FFT function
:FUNCTION<m>[:FFT]:SPAN (see page 508)	:FUNCTION<m>[:FFT]:SPAN? (see page 508)	 ::= the current frequency span in NR3 format. Legal values are 1 Hz to 100 GHz. <m> ::= 1 to (# math functions) in NR1 format
n/a	:FUNCTION<m>[:FFT]:SRATE? (see page 509)	<sample_rate> ::= Hz in NR3 format <m> ::= 1 to (# math functions) in NR1 format
:FUNCTION<m>[:FFT]:VTYPE<units> (see page 510)	:FUNCTION<m>[:FFT]:VTYPE? (see page 510)	<units> ::= {DECIBEL VRMS} for the FFT (magnitude) operation <units> ::= {DEGREES RADIANS} for the FFTPhase operation <m> ::= 1 to (# math functions) in NR1 format
:FUNCTION<m>[:FFT]:WINDOW<window> (see page 511)	:FUNCTION<m>[:FFT]:WINDOW? (see page 511)	<window> ::= {RECTANGULAR HANNING FLATTOP BHARRIS BARTLETT} <m> ::= 1 to (# math functions) in NR1 format
:FUNCTION<m>:FREQUENCY:BANDPASS:CENTER<center_freq> (see page 512)	:FUNCTION<m>:FREQUENCY:BANDPASS:CENTER? (see page 512)	<center_freq> ::= center frequency of band-pass filter in NR3 format

Table 112 :FUNCTION<m> Commands Summary (continued)

Command	Query	Options and Query Returns
:FUNCTION<m>:FREQuency:BANDpass:WIDTh <freq_width> (see page 513)	:FUNCTION<m>:FREQuency:BANDpass:WIDTh? (see page 513)	<freq_width> ::= frequency width of band-pass filter in NR3 format
:FUNCTION<m>:FREQuency:HIGHPass <3dB_freq> (see page 514)	:FUNCTION<m>:FREQuency:HIGHPass? (see page 514)	<3dB_freq> ::= 3dB cutoff frequency value in NR3 format <m> ::= 1 to (# math functions) in NR1 format
:FUNCTION<m>:FREQuency:LOWPass <3dB_freq> (see page 515)	:FUNCTION<m>:FREQuency:LOWPass? (see page 515)	<3dB_freq> ::= 3dB cutoff frequency value in NR3 format <m> ::= 1 to (# math functions) in NR1 format
:FUNCTION<m>:INTEgrate:IICondition {{0 OFF} {1 ON}} (see page 516)	:FUNCTION<m>:INTEgrate:IICondition? (see page 516)	{0 1} <m> ::= 1 to (# math functions) in NR1 format
:FUNCTION<m>:INTEgrate:IOFFset <input_offset> (see page 517)	:FUNCTION<m>:INTEgrate:IOFFset? (see page 517)	<input_offset> ::= DC offset correction in NR3 format. <m> ::= 1 to (# math functions) in NR1 format
:FUNCTION<m>:LINear:GAIN <value> (see page 518)	:FUNCTION<m>:LINear:GAIN? (see page 518)	<value> ::= 'A' in Ax + B, value in NR3 format <m> ::= 1 to (# math functions) in NR1 format
:FUNCTION<m>:LINear:OFFSet <value> (see page 519)	:FUNCTION<m>:LINear:OFFSet? (see page 519)	<value> ::= 'B' in Ax + B, value in NR3 format <m> ::= 1 to (# math functions) in NR1 format
:FUNCTION<m>:OFFSet <offset> (see page 520)	:FUNCTION<m>:OFFSet? (see page 520)	<offset> ::= the value at center screen in NR3 format. The range of legal values is +/-10 times the current sensitivity of the selected function. <m> ::= 1 to (# math functions) in NR1 format

Table 112 :FUNCTION<m> Commands Summary (continued)

Command	Query	Options and Query Returns
:FUNCTION<m>:OPERATION <operation> (see page 521)	:FUNCTION<m>:OPERATION? (see page 524)	<p><operation> ::= {ADD SUBTRACT MULTIPLY DIVIDE INTEGRATE DIFF FFT FFTPHASE SQRT MAGNIFY ABSOLUTE SQUARE LN LOG EXP TEN LOWPASS HIGHPASS BANDPASS AVERAGE LINEAR MAXIMUM MINIMUM PEAK MAXHOLD MINHOLD TREND BTIMING BSTATE SERCHART CLOCK}</p> <p><m> ::= 1 to (# math functions) in NR1 format</p>
:FUNCTION<m>:RANGE <range> (see page 526)	:FUNCTION<m>:RANGE? (see page 526)	<p><range> ::= the full-scale vertical axis value in NR3 format.</p> <p>The range for ADD, SUBT, MULT is 8E-6 to 800E+3. The range for the INTEGRATE function is 8E-9 to 400E+3.</p> <p>The range for the DIFF function is 80E-3 to 8.0E12 (depends on current sweep speed).</p> <p>The range for the FFT function is 8 to 800 dBV.</p> <p><m> ::= 1 to (# math functions) in NR1 format</p>
:FUNCTION<m>:REFERENCE <level> (see page 527)	:FUNCTION<m>:REFERENCE? (see page 527)	<p><level> ::= the value at center screen in NR3 format.</p> <p>The range of legal values is +/-10 times the current sensitivity of the selected function.</p> <p><m> ::= 1 to (# math functions) in NR1 format</p>
:FUNCTION<m>:SCALE <scale value> [<suffix>] (see page 528)	:FUNCTION<m>:SCALE? (see page 528)	<p><scale value> ::= integer in NR1 format</p> <p><suffix> ::= {V dB}</p> <p><m> ::= 1 to (# math functions) in NR1 format</p>

Table 112 :FUNCTION<m> Commands Summary (continued)

Command	Query	Options and Query Returns
:FUNCTION<m>:SERChart :SOURCE <serialbus> (see page 529)	:FUNCTION<m>:SERChart :SOURCE? (see page 529)	<m> ::= 1 to (# math functions) in NR1 format <serialbus> ::= {SBUS<n>} <n> ::= 1 to (# of serial bus) in NR1 format
:FUNCTION<m>:SERChart :TIME:MODE <value> (see page 530)	:FUNCTION<m>:SERChart :TIME:MODE? (see page 530)	<m> ::= 1 to (# math functions) in NR1 format <value> ::= {MAIN ROLL}
:FUNCTION<m>:SERChart :TIME:RANGE <range_value> (see page 532)	:FUNCTION<m>:SERChart :TIME:RANGE? (see page 532)	<m> ::= 1 to (# math functions) in NR1 format <range_value> ::= time value in NR3 format
:FUNCTION<m>:SERChart :TIME:OFFSet <offset> (see page 533)	:FUNCTION<m>:SERChart :TIME:OFFSet? (see page 533)	<m> ::= 1 to (# math functions) in NR1 format <offset> ::= vertical offset value in NR3 format
:FUNCTION<m>:SMOoth:POINTs <points> (see page 534)	:FUNCTION<m>:SMOoth:POINTs? (see page 534)	<points> ::= odd integer in NR1 format
:FUNCTION<m>:SOURCE1 <source> (see page 535)	:FUNCTION<m>:SOURCE1? (see page 535)	<source> ::= {CHANNEL<n> FUNCTION<c> MATH<c> WMEMORY<r> BUS} <n> ::= 1 to (# analog channels) in NR1 format <c> ::= {1 2 3}, must be lower than <m> <r> ::= 1 to (# ref waveforms) in NR1 format ::= {1 2} <m> ::= 1 to (# math functions) in NR1 format

Table 112 :FUNCTION<m> Commands Summary (continued)

Command	Query	Options and Query Returns
:FUNCTION<m>:SOURCE2 <source> (see page 537)	:FUNCTION<m>:SOURCE2? (see page 537)	<source> ::= {CHANNEL<n> WMEMORY<r> NONE} <n> ::= 1 to (# analog channels) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <m> ::= 1 to (# math functions) in NR1 format
:FUNCTION<m>:TRENd:NM Easurement MEAS<n> (see page 538)	:FUNCTION<m>:TRENd:NM Easurement? (see page 538)	<n> ::= # of installed measurement, from 1 to 10 <m> ::= 1 to (# math functions) in NR1 format

Introduction to :FUNCTION<m> Commands

The FUNCTION subsystem controls the math functions in the oscilloscope. Four math functions are available – the <m> in :FUNCTION<m> can be from 1 to 4.

The math function operator, transform, filter, or visualization is selected using the :FUNCTION<m>:OPERation command. Depending on the selected operation, there may be other commands for specifying options for that operation. See "[:FUNCTION<m>:OPERation](#)" on page 521.

The SOURCE1, DISPLAY, RANGE, and OFFSET (or REFERENCE) commands apply to any function.

Reporting the Setup

Use :FUNCTION<m>? to query setup information for the FUNCTION subsystem.

Return Format

The following is a sample response from the :FUNCTION1? query. In this case, the query was issued following a *RST command.

```
:FUNC1:OPER ADD;DISP 0;SOUR1 CHAN1;SOUR2 CHAN2;RANG +8.00E+00;OFFS  
+0.0E+00
```

:FUNCTION<m>:AVERAge:COUNT

N (see [page 1730](#))

Command Syntax :FUNCTION<m>:AVERAge:COUNT <count>

<count> ::= an integer from 2 to 65536 in NR1 format

<m> ::= 1 to (# math functions) in NR1 format

The :FUNCTION<m>:AVERAge:COUNT command sets the number of waveforms to be averaged together.

The number of averages can be set from 2 to 65536 in increments of powers of 2.

Increasing the number of averages will increase resolution and reduce noise.

Query Syntax :FUNCTION<m>:AVERAge:COUNT?

The :FUNCTION<m>:AVERAge:COUNT? query returns the number of waveforms to be averaged together.

Return Format <count><NL>

<count> ::= an integer from 2 to 65536 in NR1 format

See Also • [":FUNCTION<m>:OPERation"](#) on page 521

:FUNCTION<m>:BUS:CLOCK

N (see [page 1730](#))

Command Syntax :FUNCTION<m>:BUS:CLOCK <source>

<m> ::= 1 to (# math functions) in NR1 format

<source> ::= {DIGital<d>}

<d> ::= 0 to (# digital channels - 1) in NR1 format

The :FUNCTION<m>:BUS:CLOCK command selects the clock signal source for the Chart Logic Bus State operation.

Query Syntax :FUNCTION<m>:BUS:CLOCK?

The :FUNCTION<m>:BUS:CLOCK query returns the source selected for the clock signal.

Return Format <source><NL>

<source> ::= {DIGital<d>}

<d> ::= 0 to (# digital channels - 1) in NR1 format

See Also • [":FUNCTION<m>:OPERation"](#) on page 521

:FUNCTION<m>:BUS:SLOPe

N (see [page 1730](#))

Command Syntax :FUNCTION<m>:BUS:SLOPe <slope>

<m> ::= 1 to (# math functions) in NR1 format

<slope> ::= {NEGative | POSitive | EITHER}

The :FUNCTION<m>:BUS:SLOPe command specifies the clock signal edge for the Chart Logic Bus State operation.

Query Syntax :FUNCTION<m>:BUS:SLOPe?

The :FUNCTION<m>:BUS:SLOPe query returns the clock edge setting.

Return Format <slope><NL>

<slope> ::= {NEGative | POSitive | EITHER}

See Also • [":FUNCTION<m>:OPERation"](#) on page 521

:FUNCTION<m>:BUS:YINCrement

N (see [page 1730](#))

Command Syntax :FUNCTION<m>:BUS:YINCrement <value>

<m> ::= 1 to (# math functions) in NR1 format

<value> ::= value per bus code, in NR3 format

The :FUNCTION<m>:BUS:YINCrement command specifies the value associated with each increment in Chart Logic Bus data.

Query Syntax :FUNCTION<m>:BUS:YINCrement?

The :FUNCTION<m>:BUS:YINCrement query returns the value associated with each increment in Chart Logic Bus data.

Return Format <value><NL>

<value> ::= value per bus code, in NR3 format

See Also • [":FUNCTION<m>:OPERation"](#) on page 521

:FUNCTION<m>:BUS:YORigin

N (see [page 1730](#))

Command Syntax :FUNCTION<m>:BUS:YORigin <value>

<m> ::= 1 to (# math functions) in NR1 format

<value> ::= value at bus code = 0, in NR3 format

The :FUNCTION<m>:BUS:YORigin command specifies the value associated with Chart Logic Bus data equal to zero.

Query Syntax :FUNCTION<m>:BUS:YORigin?

The :FUNCTION<m>:BUS:YORigin query returns the value for associated with data equal to zero.

Return Format <value><NL>

<value> ::= value at bus code = 0, in NR3 format

See Also • [":FUNCTION<m>:OPERation"](#) on page 521

:FUNCTION<m>:BUS:YUNits

N (see [page 1730](#))

Command Syntax :FUNCTION<m>:BUS:YUNits <units>

<m> ::= 1 to (# math functions) in NR1 format

<units> ::= {VOLT | AMPere | NONE}

The :FUNCTION<m>:BUS:YUNits command specifies the vertical units for the Chart Logic Bus operations.

Query Syntax :FUNCTION<m>:BUS:YUNits?

The :FUNCTION<m>:BUS:YUNits query returns the Chart Logic Bus vertical units.

Return Format <units><NL>

<units> ::= {VOLT | AMP | NONE}

See Also • [":FUNCTION<m>:OPERation"](#) on page 521

:FUNCTION<m>:CLEar

N (see [page 1730](#))

Command Syntax :FUNCTION<m>:CLEar

When the :FUNCTION<m>:OPERation is AVERage, MAXHold, or MINHold, the :FUNCTION<m>:CLEar command clears the number of evaluated waveforms.

See Also • [":FUNCTION<m>:AVERage:COUNT"](#) on page 490

:FUNCTION<m>:DISPlay

N (see [page 1730](#))

Command Syntax :FUNCTION<m>:DISPlay <display>

<m> ::= 1 to (# math functions) in NR1 format

<display> ::= {{1 | ON} | {0 | OFF}}

The :FUNCTION<m>:DISPlay command turns the display of the function on or off. When ON is selected, the function operates as specified by the other :FUNCTION<m> commands.

NOTE

Automatic vertical scaling of the math function waveform occurs when the function display is turned from off to on. If you wait for the operation to complete (with an *OPC? query for example), then query the math function's scale, you can see the vertical scaling that was automatically determined.

All math functions can be displayed at the same time.

When math functions are off, they are still calculated so that they can be cascaded, that is, used as a source for a higher math function.

Query Syntax :FUNCTION<m>:DISPlay?

The :FUNCTION<m>:DISPlay? query returns whether the function display is on or off.

Return Format <display><NL>

<display> ::= {1 | 0}

- See Also**
- ["Introduction to :FUNCTION<m> Commands"](#) on page 489
 - ["*OPC \(Operation Complete\)"](#) on page 242
 - [":FUNCTION<m>:SCALE"](#) on page 528
 - [":VIEW"](#) on page 300
 - [":BLANK"](#) on page 268
 - [":STATus"](#) on page 297

:FUNCTION<m>[:FFT]:BSIZE

N (see [page 1730](#))

Query Syntax :FUNCTION<m>[:FFT]:BSIZE?

<m> ::= 1-4 in NR1 format

The :FUNCTION<m>[:FFT]:BSIZE? query returns the Bin Size setting for the FFT.

Return Format <bin_size><NL>

<bin_size> ::= Hz in NR3 format

See Also · [":FUNCTION<m>\[:FFT\]:READout<n>"](#) on page 507

:FUNction<m>[:FFT]:CENTer

N (see [page 1730](#))

Command Syntax :FUNction<m>[:FFT]:CENTer <frequency>
 <m> ::= 1 to (# math functions) in NR1 format
 <frequency> ::= the current center frequency in NR3 format. The range of legal values is from -25 GHz to 25 GHz.

The :FUNction<m>[:FFT]:CENTer command sets the center frequency when FFT (Fast Fourier Transform) is selected.

Query Syntax :FUNction<m>[:FFT]:CENTer?

The :FUNction<m>[:FFT]:CENTer? query returns the current center frequency in Hertz.

Return Format <frequency><NL>

<frequency> ::= the current center frequency in NR3 format. The range of legal values is from -25 GHz to 25 GHz.

NOTE

After a *RST (Reset) or :AUToscale command, the values returned by the :FUNction<m>[:FFT]:CENTer? and :FUNction<m>:SPAN? queries depend on the current :TIMEbase:RANGe value. Once you change either the :FUNction<m>[:FFT]:CENTer or :FUNction<m>:SPAN value, they no longer track the :TIMEbase:RANGe value.

- See Also**
- ["Introduction to :FUNction<m> Commands"](#) on page 489
 - [":FUNction<m>\[:FFT\]:SPAN"](#) on page 508
 - [":TIMEbase:RANGe"](#) on page 1415
 - [":TIMEbase:SCALE"](#) on page 1419

:FUNCTION<m>[:FFT]:DETECTION:POINTS

N (see [page 1730](#))

Command Syntax :FUNCTION<m>[:FFT]:DETECTION:POINTS <number_of_buckets>

<number_of_buckets> ::= an integer in NR1 format

<m> ::= 1-4 in NR1 format

The :FUNCTION<m>[:FFT]:DETECTION:POINTS command specifies the maximum number of points that the FFT detector should decimate to. This is also the number of buckets that sampled FFT points are grouped into before the selected detection type reduction (decimation) is applied.

The minimum number of points is 640.

When precision analysis is off, the maximum number of points is the measurement record limit of 64K.

When precision analysis is on (see [":SYSTEM:PRECISION"](#) on page 1393), the maximum number of points is 1/2 the power-of-two value needed to hold the precision analysis record length.

Query Syntax :FUNCTION<m>[:FFT]:DETECTION:POINTS?

The :FUNCTION<m>[:FFT]:DETECTION:POINTS? query returns the FFT detector points setting.

Return Format <number_of_buckets><NL>

<number_of_buckets> ::= an integer in NR1 format

- See Also**
- [":SYSTEM:PRECISION"](#) on page 1393
 - [":FUNCTION<m>\[:FFT\]:DETECTION:TYPE"](#) on page 501

:FUNCTION<m>[:FFT]:DETECTION:TYPE

N (see [page 1730](#))

Command Syntax :FUNCTION<m>[:FFT]:DETECTION:TYPE <type>

<type> ::= {OFF | SAMPLE | PPOSITIVE | PNEGATIVE | NORMAL | AVERAGE}

<m> ::= 1-4 in NR1 format

The :FUNCTION<m>[:FFT]:DETECTION:TYPE command sets the FFT detector decimation type.

Detectors give you a way of manipulating the acquired data to emphasize different features of the data. Detectors reduce (decimate) the number of FFT points to at most the number of specified detector points. In this reduction, sampled FFT points are bucketized, that is, split into a number of groups that equals the specified number of detector points. Then, the points in each bucket are reduced to a single point according to the selected detection type. The detector types are:

- OFF – No detector is used.
- SAMPLE – Takes the point nearest to the center of every bucket.
- PPOSITIVE (+ Peak) – Takes the most positive point in every bucket.
- PNEGATIVE (- Peak) – Takes the most negative point in every bucket.
- AVERAGE – Takes the average of all points in every bucket.
- NORMAL – Implements a rosenfell algorithm. This method to picks either the minimum or maximum sample in every bucket depending on whether the data is monotonically increasing, decreasing, or varying. For details, see the [Spectrum Analysis Basics application note](#) at www.keysight.com.

When detectors are used, the FFT's output is decimated, and any analysis is performed on the reduced or detected data set.

Query Syntax :FUNCTION<m>[:FFT]:DETECTION:TYPE?

The :FUNCTION<m>[:FFT]:DETECTION:TYPE? query returns the FFT detector type setting

Return Format <type><NL>

<type> ::= {OFF | SAMPLE | PPOSITIVE | PNEGATIVE | NORMAL | AVERAGE}

See Also • [":FUNCTION<m>\[:FFT\]:DETECTION:POINTS"](#) on page 500

:FUNCTION<m>[:FFT]:FREQUENCY:START

N (see [page 1730](#))

Command Syntax :FUNCTION<m>[:FFT]:FREQUENCY:START <frequency>

<m> ::= 1 to (# math functions) in NR1 format

<frequency> ::= the start frequency in NR3 format.

The :FUNCTION<m>[:FFT]:FREQUENCY:START command sets the start frequency in the FFT (Fast Fourier Transform) math function's displayed range.

The FFT (Fast Fourier Transform) math function's displayed range can also be set with the :FUNCTION<m>[:FFT]:CENTER and :FUNCTION<m>[:FFT]:SPAN commands.

Query Syntax :FUNCTION<m>[:FFT]:FREQUENCY:START?

The :FUNCTION<m>[:FFT]:FREQUENCY:START? query returns the current start frequency in Hertz.

Return Format <frequency><NL>

<frequency> ::= the start frequency in NR3 format.

- See Also**
- [":FUNCTION<m>\[:FFT\]:FREQUENCY:STOP"](#) on page 503
 - [":FUNCTION<m>\[:FFT\]:CENTER"](#) on page 499
 - [":FUNCTION<m>\[:FFT\]:SPAN"](#) on page 508

:FUNCTION<m>[:FFT]:FREQUENCY:STOP

N (see [page 1730](#))

Command Syntax :FUNCTION<m>[:FFT]:FREQUENCY:STOP <frequency>

<m> ::= 1 to (# math functions) in NR1 format

<frequency> ::= the stop frequency in NR3 format.

The :FUNCTION<m>[:FFT]:FREQUENCY:STOP command sets the stop frequency in the FFT (Fast Fourier Transform) math function's displayed range.

The FFT (Fast Fourier Transform) math function's displayed range can also be set with the :FUNCTION<m>[:FFT]:CENTER and :FUNCTION<m>[:FFT]:SPAN commands.

Query Syntax :FUNCTION<m>[:FFT]:FREQUENCY:STOP?

The :FUNCTION<m>[:FFT]:FREQUENCY:STOP? query returns returns the current stop frequency in Hertz.

Return Format <frequency><NL>

<frequency> ::= the stop frequency in NR3 format.

- See Also**
- [":FUNCTION<m>\[:FFT\]:FREQUENCY:START"](#) on page 502
 - [":FUNCTION<m>\[:FFT\]:CENTER"](#) on page 499
 - [":FUNCTION<m>\[:FFT\]:SPAN"](#) on page 508

:FUNCTION<m>[:FFT]:GATE

N (see [page 1730](#))

Command Syntax :FUNCTION<m>[:FFT]:GATE <gating>

<m> ::= 1-4 in NR1 format

<gating> ::= {NONE | ZOOM}

The :FUNCTION<m>[:FFT]:GATE command specifies whether the FFT is performed on the Main time base window (NONE) or the ZOOM window when the zoomed time base is displayed.

Query Syntax :FUNCTION<m>[:FFT]:GATE?

The :FUNCTION<m>[:FFT]:GATE? query returns the gate setting.

Return Format <gating><NL>

<gating> ::= {NONE | ZOOM}

- See Also**
- [":FUNCTION<m>\[:FFT\]:VTYPE"](#) on page 510
 - [":FUNCTION<m>\[:FFT\]:WINDOW"](#) on page 511
 - ["Introduction to :FUNCTION<m> Commands"](#) on page 489
 - [":FUNCTION<m>:OPERATION"](#) on page 521

:FUNCTION<m>[:FFT]:PHASe:REFerence

N (see [page 1730](#))

Command Syntax :FUNCTION<m>[:FFT]:PHASe:REFerence <ref_point>

<ref_point> ::= {TRIGger | DISPlay}

<m> ::= 1-4 in NR1 format

The :FUNCTION<m>[:FFT]:PHASe:REFerence command sets the reference point for calculating the FFT Phase function to either the trigger point or beginning of the displayed waveform.

Query Syntax :FUNCTION<m>[:FFT]:PHASe:REFerence?

The :FUNCTION<m>[:FFT]:PHASe:REFerence? query returns the selected reference point.

Return Format <ref_point><NL>

<ref_point> ::= {TRIGger | DISPlay}

- See Also**
- [":FUNCTION<m>:OPERation"](#) on page 521
 - ["Introduction to :FUNCTION<m> Commands"](#) on page 489

:FUNCTION<m>[:FFT]:RBWidth

N (see [page 1730](#))

Query Syntax :FUNCTION<m>[:FFT]:RBWidth?

<m> ::= 1-4 in NR1 format

The :FUNCTION<m>[:FFT]:RBWidth? query returns the Resolution Bandwidth setting for the FFT.

Return Format <resolution_bw><NL>

<resolution_bw> ::= Hz in NR3 format

See Also · [":FUNCTION<m>\[:FFT\]:READOut<n>"](#) on page 507

:FUNCTION<m>[:FFT]:READout<n>

N (see [page 1730](#))

Command Syntax :FUNCTION<m>[:FFT]:READout<n> <readout_type>
 <readout_type> ::= {SRATe | BSIZe | RBWidth}
 <m> ::= 1-4 in NR1 format
 <n> ::= 1-2 in NR1 format, 2 is valid only on oscilloscopes that have
 the dedicated FFT function

The :FUNCTION<m>[:FFT]:READout<n> command selects from these types of readouts for the FFT:

- SRATe – Sample Rate
- BSIZe – Bin Size
- RBWidth – Resolution Bandwidth

Note that READout1 is used for both the dedicated FFT and the general-purpose math FFT function and READout2 is used only for oscilloscopes that have a dedicated FFT function (like the 3000T X-Series).

Query Syntax :FUNCTION<m>[:FFT]:READout<n>?

The :FUNCTION<m>[:FFT]:READout<n>? query returns the readout selection.

Return Format <readout_type><NL>
 <readout_type> ::= {SRAT | BSIZ | RBW}

- See Also**
- [":FUNCTION<m>\[:FFT\]:BSIZe"](#) on page 498
 - [":FUNCTION<m>\[:FFT\]:RBWidth"](#) on page 506
 - [":FUNCTION<m>\[:FFT\]:SRATe"](#) on page 509

:FUNCTION<m>[:FFT]:SPAN

N (see [page 1730](#))

Command Syntax :FUNCTION<m>[:FFT]:SPAN

<m> ::= 1 to (# math functions) in NR1 format

 ::= the current frequency span in NR3 format. Legal values are 1 Hz to 100 GHz.

If you set the frequency span to a value outside of the legal range, the step size is automatically set to the nearest legal value.

The :FUNCTION<m>[:FFT]:SPAN command sets the frequency span of the display (left graticule to right graticule) when FFT (Fast Fourier Transform) is selected.

Query Syntax :FUNCTION<m>[:FFT]:SPAN?

The :FUNCTION<m>[:FFT]:SPAN? query returns the current frequency span in Hertz.

NOTE

After a *RST (Reset) or :AUToscale command, the values returned by the :FUNCTION<m>[:FFT]:CENTER? and :FUNCTION<m>:SPAN? queries depend on the current :TIMEbase:RANGe value. Once you change either the :FUNCTION<m>[:FFT]:CENTER or :FUNCTION<m>:SPAN value, they no longer track the :TIMEbase:RANGe value.

Return Format <NL>

 ::= the current frequency span in NR3 format. Legal values are 1 Hz to 100 GHz.

- See Also**
- ["Introduction to :FUNCTION<m> Commands"](#) on page 489
 - [":FUNCTION<m>\[:FFT\]:CENTER"](#) on page 499
 - [":TIMEbase:RANGe"](#) on page 1415
 - [":TIMEbase:SCALE"](#) on page 1419

:FUNCTION<m>[:FFT]:SRATE

N (see [page 1730](#))

Query Syntax :FUNCTION<m>[:FFT]:SRATE?

<m> ::= 1-4 in NR1 format

The :FUNCTION<m>[:FFT]:SRATE? query returns the Sample Rate setting for the FFT.

Return Format <sample_rate><NL>

<sample_rate> ::= Hz in NR3 format

See Also • [":FUNCTION<m>\[:FFT\]:READout<n>"](#) on page 507

:FUNCTION<m>[:FFT]:VTYPE

N (see [page 1730](#))

Command Syntax :FUNCTION<m>[:FFT]:VTYPE <units>

<m> ::= 1 to (# math functions) in NR1 format

<units> ::= {DECibel | VRMS} for the FFT (magnitude) operation

<units> ::= {DEGREes | RADians} for the FFTPhase operation

The :FUNCTION<m>[:FFT]:VTYPE command specifies FFT vertical units.

For the FFT (Magnitude) operation units, DECibel equates to the user interface's Logarithmic selection, and VRMS equates to the user interface's Linear selection.

Query Syntax :FUNCTION<m>[:FFT]:VTYPE?

The :FUNCTION<m>[:FFT]:VTYPE? query returns the current FFT vertical units.

Return Format <units><NL>

<units> ::= {DEC | VRMS} for the FFT (magnitude) operation

<units> ::= {DEGR | RAD} for the FFTPhase operation

- See Also**
- [":FUNCTION<m>\[:FFT\]:GATE"](#) on page 504
 - ["Introduction to :FUNCTION<m> Commands"](#) on page 489
 - [":FUNCTION<m>:OPERation"](#) on page 521

:FUNCTION<m>[:FFT]:WINDow

N (see [page 1730](#))

Command Syntax :FUNCTION<m>[:FFT]:WINDow <window>

<m> ::= 1 to (# math functions) in NR1 format

<window> ::= {RECTangular | HANNing | FLATtop | BHARris | BARTlett}

The :FUNCTION<m>[:FFT]:WINDow command allows the selection of different windowing transforms or operations for the FFT (Fast Fourier Transform) function.

The FFT operation assumes that the time record repeats. Unless an integral number of sampled waveform cycles exist in the record, a discontinuity is created between the end of one record and the beginning of the next. This discontinuity introduces additional frequency components about the peaks into the spectrum. This is referred to as leakage. To minimize leakage, windows that approach zero smoothly at the start and end of the record are employed as filters to the FFTs. Each window is useful for certain classes of input signals.

- RECTangular – useful for transient signals, and signals where there are an integral number of cycles in the time record.
- HANNing – useful for frequency resolution and general purpose use. It is good for resolving two frequencies that are close together, or for making frequency measurements. This is the default window.
- FLATtop – best for making accurate amplitude measurements of frequency peaks.
- BHARris (Blackman-Harris) – reduces time resolution compared to the rectangular window, but it improves the capacity to detect smaller impulses due to lower secondary lobes (provides minimal spectral leakage).
- BARTlett – (triangular, with end points at zero) window is similar to the Hanning window in that it is good for making accurate frequency measurements, but its higher and wider secondary lobes make it not quite as good for resolving frequencies that are close together.

Query Syntax :FUNCTION<m>[:FFT]:WINDow?

The :FUNCTION<m>[:FFT]:WINDow? query returns the value of the window selected for the FFT function.

Return Format <window><NL>

<window> ::= {RECT | HANN | FLAT | BHAR | BART}

- See Also**
- [":FUNCTION<m>\[:FFT\]:GATE"](#) on page 504
 - ["Introduction to :FUNCTION<m> Commands"](#) on page 489

:FUNction<m>:FREQuency:BANdpass:CENTer

N (see [page 1730](#))

Command Syntax :FUNction<m>:FREQuency:BANdpass:CENTer <center_freq>
<center_freq> ::= center frequency of band-pass filter in NR3 format

The :FUNction<m>:FREQuency:BANdpass:CENTer command sets the center frequency of the band-pass filter.

Query Syntax :FUNction<m>:FREQuency:BANdpass:CENTer?

The :FUNction<m>:FREQuency:BANdpass:CENTer? query returns the band-pass filter's center frequency setting.

Return Format <center_freq><NL>

- See Also**
- [":FUNction<m>:FREQuency:BANdpass:WIDTh"](#) on page 513
 - [":FUNction<m>:OPERation"](#) on page 521

:FUNCTION<m>:FREQUENCY:BANDpass:WIDTH

N (see [page 1730](#))

Command Syntax :FUNCTION<m>:FREQUENCY:BANDpass:WIDTH <freq_width>

<freq_width> ::= frequency width of band-pass filter in NR3 format

The :FUNCTION<m>:FREQUENCY:BANDpass:WIDTH command sets the frequency width of the band-pass filter. The width specifies the filter's -3 dB cutoff frequencies (center frequency minus half the width and center frequency plus half the width).

Query Syntax :FUNCTION<m>:FREQUENCY:BANDpass:WIDTH?

The :FUNCTION<m>:FREQUENCY:BANDpass:WIDTH? query returns the band-pass filter's frequency width setting.

Return Format <freq_width><NL>

- See Also**
- [":FUNCTION<m>:FREQUENCY:BANDpass:CENTer"](#) on page 512
 - [":FUNCTION<m>:OPERation"](#) on page 521

:FUNCTION<m>:FREQUENCY:HIGHpass

N (see [page 1730](#))

Command Syntax :FUNCTION<m>:FREQUENCY:HIGHpass <3dB_freq>

<m> ::= 1 to (# math functions) in NR1 format

<3dB_freq> ::= -3dB cutoff frequency value in NR3 format

The :FUNCTION<m>:FREQUENCY:HIGHpass command sets the high-pass filter's -3 dB cutoff frequency.

The high-pass filter is a single-pole high pass filter.

Query Syntax :FUNCTION<m>:FREQUENCY:HIGHpass?

The :FUNCTION<m>:FREQUENCY:HIGHpass query returns the high-pass filter's cutoff frequency.

Return Format <3dB_freq><NL>

<3dB_freq> ::= -3dB cutoff frequency value in NR3 format

See Also • [":FUNCTION<m>:OPERation"](#) on page 521

:FUNCTION<m>:FREQUENCY:LOWPass

N (see [page 1730](#))

Command Syntax :FUNCTION<m>:FREQUENCY:LOWPass <3dB_freq>

<m> ::= 1 to (# math functions) in NR1 format

<3dB_freq> ::= -3dB cutoff frequency value in NR3 format

The :FUNCTION<m>:FREQUENCY:LOWPass command sets the low-pass filter's -3 dB cutoff frequency.

The low-pass filter is a 4th order Bessel-Thompson filter.

Query Syntax :FUNCTION<m>:FREQUENCY:LOWPass?

The :FUNCTION<m>:FREQUENCY:LOWPass query returns the low-pass filter's cutoff frequency.

Return Format <3dB_freq><NL>

<3dB_freq> ::= -3dB cutoff frequency value in NR3 format

See Also • [":FUNCTION<m>:OPERation"](#) on page 521

:FUNCTION<m>:INTEgrate:IICondition

N (see [page 1730](#))

Command Syntax :FUNCTION<m>:INTEgrate:IICondition {{0 | OFF} | {1 | ON}}

<m> ::= 1 to (# math functions) in NR1 format

The :FUNCTION<m>:INTEgrate:IICondition command sets the Initial Condition of the Integrate math function waveform:

- ON – the integrate math waveform is vertically centered in the screen. In other words, the top and bottom of the math waveform are equal distances from the top and bottom of the screen.
- OFF – the integrate math waveform starts at the zero-level reference on the left side of the screen.

Query Syntax :FUNCTION<m>:INTEgrate:IICondition?

The :FUNCTION<m>:INTEgrate:IICondition? query returns Initial Condition setting for the Integrate math function.

Return Format <setting><NL>

<setting> ::= {0 | 1}

- See Also**
- [":FUNCTION<m>:OPERation"](#) on page 521
 - [":FUNCTION<m>:INTEgrate:IOFFset"](#) on page 517

:FUNCTION<m>:INTEgrate:IOFFset

N (see [page 1730](#))

Command Syntax :FUNCTION<m>:INTEgrate:IOFFset <input_offset>

<m> ::= 1 to (# math functions) in NR1 format

<input_offset> ::= DC offset correction in NR3 format.

The :FUNCTION<m>:INTEgrate:IOFFset command lets you enter a DC offset correction factor for the integrate math waveform input signal. This DC offset correction lets you level a "ramp"ed waveform.

Query Syntax :FUNCTION<m>:INTEgrate:IOFFset?

The :FUNCTION<m>:INTEgrate:IOFFset? query returns the current input offset value.

Return Format <input_offset><NL>

<input_offset> ::= DC offset correction in NR3 format.

- See Also**
- ["Introduction to :FUNCTION<m> Commands"](#) on page 489
 - [":FUNCTION<m>:OPERation"](#) on page 521
 - [":FUNCTION<m>:INTEgrate:IICondition"](#) on page 516

:FUNCTION<m>:LINear:GAIN

N (see [page 1730](#))

Command Syntax :FUNCTION<m>:LINear:GAIN <value>

<m> ::= 1 to (# math functions) in NR1 format

<value> ::= 'A' in Ax + B, value in NR3 format

The :FUNCTION<m>:LINear:GAIN command specifies the 'A' value in the Ax + B operation.

Query Syntax :FUNCTION<m>:LINear:GAIN?

The :FUNCTION<m>:LINear:GAIN query returns the gain value.

Return Format <value><NL>

<value> ::= 'A' in Ax + B, value in NR3 format

See Also • [":FUNCTION<m>:OPERation"](#) on page 521

:FUNCTION<m>:LINear:OFFSet

N (see [page 1730](#))

Command Syntax :FUNCTION<m>:LINear:OFFSet <value>

<m> ::= 1 to (# math functions) in NR1 format

<value> ::= 'B' in Ax + B, value in NR3 format

The :FUNCTION<m>:LINear:OFFSet command specifies the 'B' value in the Ax + B operation.

Query Syntax :FUNCTION<m>:LINear:OFFSet?

The :FUNCTION<m>:LINear:OFFSet query returns the offset value.

Return Format <value><NL>

<value> ::= 'B' in Ax + B, value in NR3 format

See Also • [":FUNCTION<m>:OPERation"](#) on page 521

:FUNCTION<m>:OFFSet

N (see [page 1730](#))

Command Syntax :FUNCTION<m>:OFFSet <offset>

<m> ::= 1 to (# math functions) in NR1 format

<offset> ::= the value at center screen in NR3 format.

The :FUNCTION<m>:OFFSet command sets the voltage or vertical value represented at center screen for the selected function. The range of legal values is generally +/-10 times the current scale of the selected function, but will vary by function. If you set the offset to a value outside of the legal range, the offset value is automatically set to the nearest legal value.

NOTE

The :FUNCTION<m>:OFFSet command is equivalent to the :FUNCTION<m>:REFerence command.

Query Syntax :FUNCTION<m>:OFFSet?

The :FUNCTION<m>:OFFSet? query outputs the current offset value for the selected function.

Return Format <offset><NL>

<offset> ::= the value at center screen in NR3 format.

- See Also**
- "[Introduction to :FUNCTION<m> Commands](#)" on page 489
 - "[:FUNCTION<m>:RANGe](#)" on page 526
 - "[:FUNCTION<m>:REFerence](#)" on page 527
 - "[:FUNCTION<m>:SCALE](#)" on page 528

:FUNCTION<m>:OPERation

N (see [page 1730](#))

Command Syntax :FUNCTION<m>:OPERation <operation>

<m> ::= 1 to (# math functions) in NR1 format

<operation> ::= {ADD | SUBTract | MULTiPLY | DIVide | DIFF | INTegrate
| FFT | FFTPhase | Sqrt | MAGNify | ABSolute | SQUare | LN | LOG
| EXP | TEN | LOWPass | HIGHpass | BANDpass | AVERage | SMOoth
| ENVELOpe | LINear | MAXimum | MINimum | PEAK | MAXHold | MINHold
| TREND | BTIMing | BState | SERChart | CLOCK}

The :FUNCTION<m>:OPERation command sets the desired waveform math operator, transform, filter or visualization:

- Operators:
 - ADD – Source1 + source2.
 - SUBTract – Source1 - source2.
 - MULTiPLY – Source1 * source2.
 - DIVide – Source1 / source2.
- Operators perform their function on two analog channel sources.
- Transforms:
 - DIFF – Differentiate
 - INTegrate – The INTegrate:IOFFset command lets you specify a DC offset correction factor.
 - FFT (magnitude) – Using the Fast Fourier Transform (FFT), this operation displays the magnitudes of the frequency content that makes up the source waveform. The FFT takes the digitized time record of the specified source and transforms it to the frequency domain.

The SPAN, CENTER, VTYPe, and WINDow commands are used for FFT functions. When FFT is selected, the horizontal cursors change from time to frequency (Hz), and the vertical cursors change from volts to decibels or V RMS.

- FFTPhase – Using the Fast Fourier Transform (FFT), this operation shows the phase relationships of the frequency content that makes up the source waveform. The FFT takes the digitized time record of the specified source and transforms it to the frequency domain.

The SPAN, CENTER, VTYPe, and WINDow commands are used for FFT functions. When FFTPhase is selected, the horizontal cursors change from time to frequency (Hz), and the vertical cursors change from volts to degrees or radians.

- LINear – $Ax + B$ – The LINear commands set the gain (A) and offset (B) values for this function.
- SQUare
- SQRT – Square root
- ABSolute – Absolute Value
- LOG – Common Logarithm
- LN – Natural Logarithm
- EXP – Exponential (e^x)
- TEN – Base 10 exponential (10^x)

Transforms operate on a single analog channel source or on lower math functions.

- Filters:
 - LOWPass – Low pass filter – The FREQuency:LOWPass command sets the -3 dB cutoff frequency.
 - HIGHpass – High pass filter – The FREQuency:HIGHPass command sets the -3 dB cutoff frequency.
 - BANDpass – Band pass filter – The FREQuency:BANDpass:CENTer and FREQuency:BANDpass:WIDTh commands set the center frequency and width of the filter.
 - AVERage – Averaged value – The AVERage:COUNT command specifies the number of averages.

Unlike acquisition averaging, the math averaging operator can be used to average the data on a single analog input channel or math function.

If acquisition averaging is also used, the analog input channel data is averaged and the math function averages it again. You can use both types of averaging to get a certain number of averages on all waveforms and an increased number of averages on a particular waveform.

Averages are calculated using a "decaying average" approximation, where:

$$\text{next_average} = \text{current_average} + (\text{new_data} - \text{current_average})/N$$

Where N starts at 1 for the first acquisition and increments for each following acquisition until it reaches the selected number of averages, where it holds.

- SMOoth – Smoothing – The resulting math waveform is the selected source with a normalized rectangular (boxcar) FIR filter applied.

The boxcar filter is a moving average of adjacent waveform points, where the number of adjacent points is specified by the SMOoth:POINts command. You can choose an odd number of points, from 3 to 999.

The smoothing operator limits the bandwidth of the source waveform. The smoothing operator can be used, for example, to smooth measurement trend waveforms.

- ENvelope – Envelope – The resulting math waveform is the amplitude envelope for an amplitude modulated (AM) input signal.

This function uses a Hilbert transform to get the real (in-phase, I) and imaginary (quadrature, Q) parts of the input signal and then performs a square root of the sum of the real and imaginary parts to get the demodulated amplitude envelope waveform.

Filters operate on a single analog channel source or on a lower math function.

- Visualizations:
 - MAGNify – Operates on a single analog channel source or on a lower math function.
 - MAXimum – This operator is like the MAXHold operator without the hold. The maximum vertical values found at each horizontal bucket are used to build a waveform.
 - MINimum – This operator is like the MINHold operator without the hold. The minimum vertical values found at each horizontal bucket are used to build a waveform.
 - PEAK – The PEAK operator is like the MAXimum operator minus the MINimum operator. At each horizontal bucket, the minimum vertical values found are subtracted from the maximum vertical values found to build a waveform.
 - MAXHold – Operates on a single analog channel source or on a lower math function. The Max Hold (or Max Envelope) operator records the maximum vertical values found at each horizontal bucket across multiple analysis cycles and uses those values to build a waveform.
 - MINHold – Operates on a single analog channel source or on a lower math function. The Min Hold (or Min Envelope) operator records the minimum vertical values found at each horizontal bucket across multiple analysis cycles and uses those values to build a waveform.
 - TREND – Measurement trend – Operates on a single analog channel source. The TREND:NMEasurement command selects the measurement whose trend you want to measure.
 - BTIMing – Chart logic bus timing – Operates on a bus made up of digital channels. The BUS:YINcrement, BUS:YORigin, and BUS:YUNits commands specify function values.
 - BState – Chart logic bus state – Operates on a bus made up of digital channels. The BUS:YINcrement, BUS:YORigin, and BUS:YUNit commands specify function values. The BUS:CLOCK and BUS:SLOPe commands specify the clock source and edge.

- SERChart – Chart serial signal – Operates on a serial decode that is displaying symbolic data values. For example, CAN or LIN symbolic display or the SENT transfer function display allow charting of serial data values.
- CLOCK – Clock recovery – You can display recovered clocks from different sources using multiple math function waveforms; however, the same clock recovery method applies to all recovered clocks. See **":CLOCK:METHOD"** on page 386.

NOTE

If a math function is on (see :FUNCTION<m>:DISPLAY), changing the operator will cause an automatic vertical scaling of the new math function waveform. If you wait for the operation to complete (with an *OPC? query for example), then query the math function's scale, you can see the vertical scaling that was automatically determined.

Query Syntax :FUNCTION<m>:OPERATION?

The :FUNCTION<m>:OPERATION? query returns the current operation for the selected function.

Return Format <operation><NL>

```
<operation> ::= {ADD | SUBT | MULT | DIV | INT | DIFF | FFT | FFTP
| Sqrt | MAGN | ABS | SQU | LN | LOG | EXP | TEN | LOWP | HIGH
| BAND | AVER | SMO | ENV | LIN | MAX | MIN | PEAK | MAXH | MINH
| TREN | BTIM | BST | SERC | CLOC}
```

- See Also**
- **"Introduction to :FUNCTION<m> Commands"** on page 489
 - **":FUNCTION<m>:DISPLAY"** on page 497
 - **"*OPC (Operation Complete)"** on page 242
 - **":FUNCTION<m>:SOURCE1"** on page 535
 - **":FUNCTION<m>:SOURCE2"** on page 537
 - **":FUNCTION<m>:INTEGRATE:OFFSET"** on page 517
 - **":FUNCTION<m>[:FFT]:SPAN"** on page 508
 - **":FUNCTION<m>[:FFT]:CENTER"** on page 499
 - **":FUNCTION<m>[:FFT]:PHASE:REFERENCE"** on page 505
 - **":FUNCTION<m>[:FFT]:VTYPE"** on page 510
 - **":FUNCTION<m>[:FFT]:WINDOW"** on page 511
 - **":FUNCTION<m>:LINEAR:GAIN"** on page 518
 - **":FUNCTION<m>:LINEAR:OFFSET"** on page 519
 - **":FUNCTION<m>:FREQUENCY:BANDPASS:CENTER"** on page 512
 - **":FUNCTION<m>:FREQUENCY:BANDPASS:WIDTH"** on page 513
 - **":FUNCTION<m>:FREQUENCY:LOWPASS"** on page 515
 - **":FUNCTION<m>:FREQUENCY:HIGHPASS"** on page 514

- **":FUNction<m>:AVERAge:COUNT"** on page 490
- **":FUNction<m>:SMOoth:POINTs"** on page 534
- **":FUNction<m>:TRENd:NMEasurement"** on page 538
- **":FUNction<m>:SERChart:SOURce"** on page 529
- **":FUNction<m>:SERChart:TIME:MODE"** on page 530
- **":FUNction<m>:SERChart:TIME:RANGe"** on page 532
- **":FUNction<m>:SERChart:TIME:OFFSet"** on page 533
- **":FUNction<m>:BUS:YINCrement"** on page 493
- **":FUNction<m>:BUS:YORigin"** on page 494
- **":FUNction<m>:BUS:YUNits"** on page 495
- **":FUNction<m>:BUS:CLOCK"** on page 491
- **":FUNction<m>:BUS:SLOPe"** on page 492

:FUNCTION<m>:RANGe

N (see [page 1730](#))

Command Syntax :FUNCTION<m>:RANGe <range>

<m> ::= 1 to (# math functions) in NR1 format

<range> ::= the full-scale vertical axis value in NR3 format.

The :FUNCTION<m>:RANGe command defines the full-scale vertical axis for the selected function.

Query Syntax :FUNCTION<m>:RANGe?

The :FUNCTION<m>:RANGe? query returns the current full-scale range value for the selected function.

Return Format <range><NL>

<range> ::= the full-scale vertical axis value in NR3 format.

- See Also**
- ["Introduction to :FUNCTION<m> Commands"](#) on page 489
 - [":FUNCTION<m>:SCALE"](#) on page 528

:FUNCTION<m>:REFerence

N (see [page 1730](#))

Command Syntax :FUNCTION<m>:REFerence <level>

<m> ::= 1 to (# math functions) in NR1 format

<level> ::= the current reference level in NR3 format.

The :FUNCTION<m>:REFerence command sets the voltage or vertical value represented at center screen for the selected function. The range of legal values is generally +/-10 times the current scale of the selected function, but will vary by function. If you set the reference level to a value outside of the legal range, the level is automatically set to the nearest legal value.

NOTE

The FUNCTION:REFerence command is equivalent to the :FUNCTION<m>:OFFSet command.

Query Syntax :FUNCTION<m>:REFerence?

The :FUNCTION<m>:REFerence? query outputs the current reference level value for the selected function.

Return Format <level><NL>

<level> ::= the current reference level in NR3 format.

- See Also**
- ["Introduction to :FUNCTION<m> Commands"](#) on page 489
 - [":FUNCTION<m>:OFFSet"](#) on page 520
 - [":FUNCTION<m>:RANGe"](#) on page 526
 - [":FUNCTION<m>:SCALE"](#) on page 528

:FUNCTION<m>:SCALE

N (see [page 1730](#))

Command Syntax `:FUNCTION<m>:SCALE <scale value>[<suffix>]`
 `<m> ::= 1 to (# math functions) in NR1 format`
 `<scale value> ::= vertical units/div value in NR3 format`
 `<suffix> ::= {V | dB}`

The :FUNCTION<m>:SCALE command sets the vertical scale, or units per division, of the selected function. Legal values for the scale depend on the selected function.

NOTE

Automatic vertical scaling of the math function waveform occurs when the function display is turned from off to on (see :FUNCTION<m>:DISPLAY) or, if the function is already on, when the operation is changed (see :FUNCTION<m>:OPERATION). If you want to change the math function's vertical scaling, you should do it after the math function display is turned on or after the operation is changed.

Query Syntax `:FUNCTION<m>:SCALE?`

The :FUNCTION<m>:SCALE? query returns the current scale value for the selected function.

Return Format `<scale value><NL>`
 `<scale value> ::= vertical units/div value in NR3 format`

- See Also**
- ["Introduction to :FUNCTION<m> Commands"](#) on page 489
 - [":FUNCTION<m>:DISPLAY"](#) on page 497
 - [":FUNCTION<m>:OPERATION"](#) on page 521
 - [":FUNCTION<m>:RANGE"](#) on page 526

:FUNCTION<m>:SERChart:SOURce

N (see [page 1730](#))

Command Syntax :FUNCTION<m>:SERChart:SOURce <serialbus>
 <m> ::= 1 to (# math functions) in NR1 format
 <serialbus> ::= {SBUS<n>}
 <n> :: 1 to (# of serial bus) in NR1 format

The :FUNCTION<m>:SERChart:SOURce command sets the serial bus source for the Chart Serial Signal math function.

Query Syntax :FUNCTION<m>:SERChart:SOURce?

The :FUNCTION<m>:SERChart:SOURce? query returns the serial bus source.

Return Format <serialbus><NL>
 <serialbus> ::= {SBUS<n>}

- See Also**
- [":FUNCTION<m>:OPERation"](#) on page 521
 - [":FUNCTION<m>:SERChart:TIME:MODE"](#) on page 530
 - [":FUNCTION<m>:SERChart:TIME:RANGe"](#) on page 532
 - [":FUNCTION<m>:SERChart:TIME:OFFSet"](#) on page 533

:FUNCTION<m>:SERChart:TIME:MODE

N (see [page 1730](#))

Command Syntax :FUNCTION<m>:SERChart:TIME:MODE <value>

<m> ::= 1 to (# math functions) in NR1 format

<value> ::= {MAIN | ROLL}

The :FUNCTION<m>:SERChart:TIME:MODE command sets the time mode for the Chart Serial Signal math function:

- **MAIN** – The signal data values are plotted per acquisition, in the same horizontal time scale as the other waveforms, and all waveform data is time-correlated.

In this mode, the oscilloscope's timebase (time/div) is typically set for a long acquisition time to capture multiple occurrences of the message/frame/packet that contains the signal to be charted.

If the timebase is set to longer than 200 ms/div for high-speed CAN or SENT, undersampling may occur due to limited acquisition memory and reduced sample rate. Timebase settings for LIN can usually be much longer.

- **ROLL** – The signal data values are plotted at the right side of the display and roll across the display for a specified amount of time. This resulting math function waveform is not time-correlated with other waveforms on the display.

Roll mode establishes a second and typically much slower timebase and is useful for charting very slow changing signals (up to 1 hour), such as temperature or pressure.

Signal values are typically under-sampled (not every occurrence of a signal will be plotted). Signal values roll across the display as new signal values are received and plotted.

If charting a CAN or LIN signal in this mode, you should set up the oscilloscope to trigger on the message/frame that contains the signal.

If charting SENT, the oscilloscope should be set up to trigger on the start of any Fast Channel Message (":SBUS<n>:SENT:TRIGger SFCMessage").

In Roll mode, the oscilloscope's main timebase setting is typically set to capture just a few messages.

Query Syntax :FUNCTION<m>:SERChart:TIME:MODE?

The :FUNCTION<m>:SERChart:TIME:MODE? query returns the time mode setting.

Return Format <value><NL>

<value> ::= {MAIN | ROLL}

See Also • [":FUNCTION<m>:OPERation"](#) on page 521

- **":FUNction<m>:SERChart:SOURce"** on page 529
- **":FUNction<m>:SERChart:TIME:RANGe"** on page 532
- **":FUNction<m>:SERChart:TIME:OFFSet"** on page 533
- **":SBUS<n>:SENT:TRIGger"** on page 1188

:FUNCTION<m>:SERChart:TIME:RANGe

N (see [page 1730](#))

Command Syntax :FUNCTION<m>:SERChart:TIME:RANGe <range_value>
 <m> ::= 1 to (# math functions) in NR1 format
 <range_value> ::= time value in NR3 format

When the ROLL serial chart time mode is selected (see :FUNCTION<m>:SERChart:TIME:MODE), the :FUNCTION<m>:SERChart:TIME:RANGe command sets the full-scale time range value for the Chart Serial Signal math function.

The time range defines the width across the display for the charted serial signal waveform.

When oscilloscope acquisitions are stopped, you can adjust the time offset and time range to scroll and zoom the plotted signal values.

Query Syntax :FUNCTION<m>:SERChart:TIME:RANGe?

The :FUNCTION<m>:SERChart:TIME:RANGe? query returns the time range setting.

Return Format <range_value><NL>
 <range_value> ::= time value in NR3 format

- See Also**
- [":FUNCTION<m>:OPERation"](#) on page 521
 - [":FUNCTION<m>:SERChart:SOURce"](#) on page 529
 - [":FUNCTION<m>:SERChart:TIME:MODE"](#) on page 530
 - [":FUNCTION<m>:SERChart:TIME:OFFSet"](#) on page 533

:FUNCTION<m>:SERChart:TIME:OFFSet

N (see [page 1730](#))

Command Syntax :FUNCTION<m>:SERChart:TIME:OFFSet <offset>

<m> ::= 1 to (# math functions) in NR1 format

<offset> ::= time offset value in NR3 format

When the ROLL serial chart time mode is selected (see :FUNCTION<m>:SERChart:TIME:MODE), the :FUNCTION<m>:SERChart:TIME:OFFSet command sets the time offset for the Chart Serial Signal math function.

The time offset shows the time value of the center of the display. When oscilloscope acquisitions are running, the time offset is automatically set to the middle of the time range.

When oscilloscope acquisitions are stopped, you can adjust the time offset and time range to scroll and zoom the plotted signal values.

Query Syntax :FUNCTION<m>:SERChart:TIME:OFFSet?

The :FUNCTION<m>:SERChart:TIME:OFFSet? query returns the time offset setting.

Return Format <offset><NL>

<offset> ::= time offset value in NR3 format

- See Also**
- [":FUNCTION<m>:OPERation"](#) on page 521
 - [":FUNCTION<m>:SERChart:SOURce"](#) on page 529
 - [":FUNCTION<m>:SERChart:TIME:MODE"](#) on page 530
 - [":FUNCTION<m>:SERChart:TIME:RANGe"](#) on page 532

:FUNCTION<m>:SMOoth:POINts

N (see [page 1730](#))

Command Syntax :FUNCTION<m>:SMOoth:POINts <points>

<points> ::= odd integer in NR1 format

When the :FUNCTION<m>:OPERation is SMOoth, the :FUNCTION<m>:SMOoth:POINts command sets the number of smoothing points to use.

You can choose an odd number of points, from 3 up to half of the measurement record or precision analysis record.

Query Syntax :FUNCTION<m>:SMOoth:POINts?

The :FUNCTION<m>:SMOoth:POINts? query returns the number of smoothing points specified.

Return Format <points><NL>

See Also • [":FUNCTION<m>:OPERation"](#) on page 521

:FUNCTION<m>:SOURCE1

N (see [page 1730](#))

Command Syntax :FUNCTION<m>:SOURCE1 <value>

<m> ::= 1 to (# math functions) in NR1 format

<value> ::= {CHANnel<n> | FUNCTION<c> | MATH<c> | WMemory<r> | BUS}

<n> ::= 1 to (# analog channels) in NR1 format

<c> ::= {1 | 2 | 3}, must be lower than <m>

<r> ::= 1 to (# ref waveforms) in NR1 format

 ::= {1 | 2}

The :FUNCTION<m>:SOURCE1 command is used for any :FUNCTION<m>:OPERation selection. This command selects the first source for the operator math functions or the single source for the transform functions, filter functions, or visualization functions.

The FUNCTION<c> or MATH<c> parameters are available for the transform functions, filter functions, and the magnify visualization function (see ["Introduction to :FUNCTION<m> Commands"](#) on page 489) when <c> is lower than <m>.

In other words, higher math functions can operate on lower math functions when using operators other than the simple arithmetic operations (+, -, *, /). For example, if :FUNCTION1:OPERation is a SUBtract of CHANnel1 and CHANnel2, the :FUNCTION2:OPERation could be set up as a FFT operation on the FUNCTION1 source. These are called cascaded math functions.

To cascade math functions, select the lower math function using the :FUNCTION<m>:SOURCE1 command.

When cascading math functions, to get the most accurate results, be sure to vertically scale lower math functions so that their waveforms take up the full screen without being clipped.

The BUS<m> parameter is available for the bus charting visualization functions.

NOTE

Another shorthand notation for SOURCE1 in this command/query (besides SOUR1) is SOUR.

When :FUNCTION<m>:OPERation is TRENd, the :FUNCTION<m>:SOURCE1 command reports error -221, "Settings conflict" because the TRENd function operates on a measurement and not a source waveform.

Query Syntax :FUNCTION<m>:SOURCE1?

The :FUNCTION<m>:SOURCE1? query returns the current source1 for function operations.

When :FUNCTION<m>:OPERATION is TRENd, the :FUNCTION<m>:SOURCE1? query returns the source of the measurement.

Return Format <value><NL>

<value> ::= {CHAN<n> | FUNC<c> | MATH<c> | WMEM<r> | BUS}

- See Also**
- ["Introduction to :FUNCTION<m> Commands"](#) on page 489
 - [":FUNCTION<m>:OPERATION"](#) on page 521

:FUNCTION<m>:SOURCE2

N (see [page 1730](#))

Command Syntax :FUNCTION<m>:SOURCE2 <value>

<m> ::= 1 to (# math functions) in NR1 format

<value> ::= {CHANnel<n> | WMEMory<r> | NONE}

<n> ::= 1 to (# analog channels) in NR1 format

<r> ::= 1 to (# ref waveforms) in NR1 format

The :FUNCTION<m>:SOURCE2 command specifies the second source for math operator functions that have two sources. (The :FUNCTION<m>:SOURCE1 command specifies the first source.)

The :FUNCTION<m>:SOURCE2 setting is not used for the transform functions, filter functions, or visualization functions (except when the measurement trend visualization's measurement requires two sources).

When :FUNCTION<m>:OPERation is TRENd, the :FUNCTION<m>:SOURCE2 command reports error -221, "Settings conflict" because the TRENd function operates on a measurement and not a source waveform.

Query Syntax :FUNCTION<m>:SOURCE2?

The :FUNCTION<m>:SOURCE2? query returns the currently specified second source for math operations.

When :FUNCTION<m>:OPERation is TRENd, the :FUNCTION<m>:SOURCE2? query returns the source of the measurement.

Return Format <value><NL>

<value> ::= {CHAN<n> | WMEM<r> | NONE}

- See Also**
- ["Introduction to :FUNCTION<m> Commands"](#) on page 489
 - [":FUNCTION<m>:OPERation"](#) on page 521
 - [":FUNCTION<m>:SOURCE1"](#) on page 535

:FUNCTION<m>:TREND:NMEasurement

N (see [page 1730](#))

Command Syntax :FUNCTION<m>:TREND:NMEasurement MEAS<n>

<n> ::= # of installed measurement, from 1 to 10

<m> ::= 1 to (# math functions) in NR1 format

The :FUNCTION<m>:TREND:NMEasurement command selects the measurement whose trend is shown in the math waveform.

There are 10 locations (or slots) that installed measurements can occupy. The MEAS<n> parameter specifies the location of the measurement whose trend you want to analyze.

You can view the trend math function waveform for these installed measurements:

- :MEASure:VAverage, <interval> ::= CYCLE
- :MEASure:VRMS, <type> ::= AC (AC RMS)
- :MEASure:VRATio, <interval> ::= CYCLE
- :MEASure:PERiod
- :MEASure:FREQuency
- :MEASure:PWIDth
- :MEASure:NWIDth
- :MEASure:DUTYcycle
- :MEASure:NDUTy
- :MEASure:RISetime
- :MEASure:FALLtime

Query Syntax :FUNCTION<m>:TREND:NMEasurement?

The :FUNCTION<m>:TREND:NMEasurement? query returns the selected measurement.

If no measurements are installed, the :FUNCTION<m>:TREND:NMEasurement? query will return NONE.

Return Format MEAS<n><NL>

<n> ::= # of installed measurement, from 1 to 10

See Also • [":FUNCTION<m>:OPERation"](#) on page 521

23 :HARDcopy/:HCOPY Commands

Set and query the selection of hardcopy device and formatting options. See "[Introduction to :HARDcopy Commands](#)" on page 540.

Table 113 :HARDcopy/:HCOPY Commands Summary

Command	Query	Options and Query Returns
:HARDcopy:AREA <area> (see page 542)	:HARDcopy:AREA? (see page 542)	<area> ::= SCReen
:HARDcopy:APRinter <active_printer> (see page 543)	:HARDcopy:APRinter? (see page 543)	<active_printer> ::= {<index> <name>} <index> ::= integer index of printer in list <name> ::= name of printer in list
:HARDcopy:FACTors {{0 OFF} {1 ON}} (see page 544)	:HARDcopy:FACTors? (see page 544)	{0 1}
:HARDcopy:FFEed {{0 OFF} {1 ON}} (see page 545)	:HARDcopy:FFEed? (see page 545)	{0 1}
:HARDcopy:INKSaver {{0 OFF} {1 ON}} (see page 546)	:HARDcopy:INKSaver? (see page 546)	{0 1}
:HARDcopy:LAYout <layout> (see page 547)	:HARDcopy:LAYout? (see page 547)	<layout> ::= {LANDscape PORTRait}
:HARDcopy:NETWork:ADD Ress <address> (see page 548)	:HARDcopy:NETWork:ADD Ress? (see page 548)	<address> ::= quoted ASCII string
:HARDcopy:NETWork:APP Ly (see page 549)	n/a	n/a

Table 113 :HARDcopy/:HCOPY Commands Summary (continued)

Command	Query	Options and Query Returns
:HARDcopy:NETWork:DOM ain <domain> (see page 550)	:HARDcopy:NETWork:DOM ain? (see page 550)	<domain> ::= quoted ASCII string
:HARDcopy:NETWork:PAS Sword <password> (see page 551)	n/a	<password> ::= quoted ASCII string
:HARDcopy:NETWork:SLO T <slot> (see page 552)	:HARDcopy:NETWork:SLO T? (see page 552)	<slot> ::= {NET0 NET1}
:HARDcopy:NETWork:USE Rname <username> (see page 553)	:HARDcopy:NETWork:USE Rname? (see page 553)	<username> ::= quoted ASCII string
:HARDcopy:PALette <palette> (see page 554)	:HARDcopy:PALette? (see page 554)	<palette> ::= {COLor GRAYscale NONE}
n/a	:HARDcopy:PRINter:LIS T? (see page 555)	<list> ::= [<printer_spec>] ... [printer_spec] <printer_spec> ::= "<index>,<active>,<name>," <index> ::= integer index of printer <active> ::= {Y N} <name> ::= name of printer
:HARDcopy:START (see page 556)	n/a	n/a
n/a	:HCOPY:SDump:DATA? (see page 557)	<display_data> ::= binary block data in IEEE-488.2 # format.
:HCOPY:SDUMP:FORMat <format> (see page 558)	:HCOPY:SDUMP:FORMat? (see page 558)	<format> ::= {BMP BMP8bit PNG}

Introduction to :HARDcopy Commands

The HARDcopy subsystem provides commands to set and query the selection of hardcopy device and formatting options such as inclusion of instrument settings (FACTors) and generation of formfeed (FFEed).

:HARDC or :HCOPY are acceptable short forms for :HARDcopy.

Reporting the Setup

Use :HARDcopy? to query setup information for the HARDcopy subsystem.

Return Format

The following is a sample response from the :HARDcopy? query. In this case, the query was issued following the *RST command.

```
:HARD:APR " ";AREA SCR;FACT 0;FFE 0;INKS 1;PAL NONE;LAY PORT
```

:HARDcopy:AREA

N (see [page 1730](#))

Command Syntax :HARDcopy:AREA <area>

<area> ::= SCReen

The :HARDcopy:AREA command controls what part of the display area is printed. Currently, the only legal choice is SCReen.

Query Syntax :HARDcopy:AREA?

The :HARDcopy:AREA? query returns the selected display area.

Return Format <area><NL>

<area> ::= SCR

- See Also**
- ["Introduction to :HARDcopy Commands"](#) on page 540
 - [":HARDcopy:STArT"](#) on page 556
 - [":HARDcopy:APRinter"](#) on page 543
 - [":HARDcopy:PRINter:LIST"](#) on page 555
 - [":HARDcopy:FACTors"](#) on page 544
 - [":HARDcopy:FFEed"](#) on page 545
 - [":HARDcopy:INKSaver"](#) on page 546
 - [":HARDcopy:LAYout"](#) on page 547
 - [":HARDcopy:PALette"](#) on page 554

:HARDcopy:APRinter

N (see [page 1730](#))

Command Syntax :HARDcopy:APRinter <active_printer>
 <active_printer> ::= {<index> | <name>}
 <index> ::= integer index of printer in list
 <name> ::= name of printer in list

The :HARDcopy:APRinter command sets the active printer.

Query Syntax :HARDcopy:APRinter?

The :HARDcopy:APRinter? query returns the name of the active printer.

Return Format <name><NL>
 <name> ::= name of printer in list

- See Also**
- ["Introduction to :HARDcopy Commands"](#) on page 540
 - [":HARDcopy:PRINter:LIST"](#) on page 555
 - [":HARDcopy:START"](#) on page 556

:HARDcopy:FACTors

N (see [page 1730](#))

Command Syntax :HARDcopy:FACTors <factors>
 <factors> ::= {{OFF | 0} | {ON | 1}}

The :HARDcopy:FACTors command controls whether the scale factors are output on the hardcopy dump.

Query Syntax :HARDcopy:FACTors?

The :HARDcopy:FACTors? query returns a flag indicating whether oscilloscope instrument settings are output on the hardcopy.

Return Format <factors><NL>
 <factors> ::= {0 | 1}

- See Also**
- ["Introduction to :HARDcopy Commands"](#) on page 540
 - [":HARDcopy:START"](#) on page 556
 - [":HARDcopy:FFEed"](#) on page 545
 - [":HARDcopy:INKSaver"](#) on page 546
 - [":HARDcopy:LAYout"](#) on page 547
 - [":HARDcopy:PALette"](#) on page 554

:HARDcopy:FFEed

N (see [page 1730](#))

Command Syntax :HARDcopy:FFEed <ffeed>

<ffeed> ::= {{OFF | 0} | {ON | 1}}

The :HARDcopy:FFEed command controls whether a formfeed is output between the screen image and factors of a hardcopy dump.

Query Syntax :HARDcopy:FFEed?

The :HARDcopy:FFEed? query returns a flag indicating whether a formfeed is output at the end of the hardcopy dump.

Return Format <ffeed><NL>

<ffeed> ::= {0 | 1}

- See Also**
- ["Introduction to :HARDcopy Commands"](#) on page 540
 - [":HARDcopy:START"](#) on page 556
 - [":HARDcopy:FACTors"](#) on page 544
 - [":HARDcopy:INKSaver"](#) on page 546
 - [":HARDcopy:LAYout"](#) on page 547
 - [":HARDcopy:PALette"](#) on page 554

:HARDcopy:INKSaver

N (see [page 1730](#))

Command Syntax :HARDcopy:INKSaver <value>
 <value> ::= {{OFF | 0} | {ON | 1}}

The :HARDcopy:INKSaver command controls whether the graticule colors are inverted or not.

Query Syntax :HARDcopy:INKSaver?

The :HARDcopy:INKSaver? query returns a flag indicating whether graticule colors are inverted or not.

Return Format <value><NL>
 <value> ::= {0 | 1}

- See Also**
- ["Introduction to :HARDcopy Commands"](#) on page 540
 - [":HARDcopy:START"](#) on page 556
 - [":HARDcopy:FACTors"](#) on page 544
 - [":HARDcopy:FFEed"](#) on page 545
 - [":HARDcopy:LAYout"](#) on page 547
 - [":HARDcopy:PALette"](#) on page 554

:HARDcopy:LAYout

N (see [page 1730](#))

Command Syntax :HARDcopy:LAYout <layout>

<layout> ::= {LANDscape | PORTrait}

The :HARDcopy:LAYout command sets the hardcopy layout mode.

Query Syntax :HARDcopy:LAYout?

The :HARDcopy:LAYout? query returns the selected hardcopy layout mode.

Return Format <layout><NL>

<layout> ::= {LAND | PORT}

- See Also**
- ["Introduction to :HARDcopy Commands"](#) on page 540
 - [":HARDcopy:START"](#) on page 556
 - [":HARDcopy:FACTors"](#) on page 544
 - [":HARDcopy:PALette"](#) on page 554
 - [":HARDcopy:FFEed"](#) on page 545
 - [":HARDcopy:INKSaver"](#) on page 546

:HARDcopy:NETWork:ADDRes

N (see [page 1730](#))

Command Syntax :HARDcopy:NETWork:ADDRes <address>

<address> ::= quoted ASCII string

The :HARDcopy:NETWork:ADDRes command sets the address for a network printer slot. The address is the server/computer name and the printer's share name in the \\server\share format.

The network printer slot is selected by the :HARDcopy:NETWork:SLOT command.

To apply the entered address, use the :HARDcopy:NETWork:APPLY command.

Query Syntax :HARDcopy:NETWork:ADDRes?

The :HARDcopy:NETWork:ADDRes? query returns the specified address for the currently selected network printer slot.

Return Format <address><NL>

<address> ::= quoted ASCII string

- See Also**
- ["Introduction to :HARDcopy Commands"](#) on page 540
 - [":HARDcopy:NETWork:SLOT"](#) on page 552
 - [":HARDcopy:NETWork:APPLY"](#) on page 549
 - [":HARDcopy:NETWork:DOMain"](#) on page 550
 - [":HARDcopy:NETWork:USERname"](#) on page 553
 - [":HARDcopy:NETWork:PASSword"](#) on page 551

:HARDcopy:NETWork:APPLy

N (see [page 1730](#))

Command Syntax :HARDcopy:NETWork:APPLy

The :HARDcopy:NETWork:APPLy command applies the network printer settings and makes the printer connection.

- See Also**
- ["Introduction to :HARDcopy Commands"](#) on page 540
 - [":HARDcopy:NETWork:SLOT"](#) on page 552
 - [":HARDcopy:NETWork:ADDRes"](#) on page 548
 - [":HARDcopy:NETWork:DOMain"](#) on page 550
 - [":HARDcopy:NETWork:USERname"](#) on page 553
 - [":HARDcopy:NETWork:PASSword"](#) on page 551

:HARDcopy:NETWork:DOMain

N (see [page 1730](#))

Command Syntax :HARDcopy:NETWork:DOMain <domain>

<domain> ::= quoted ASCII string

The :HARDcopy:NETWork:DOMain command sets the Windows network domain name.

The domain name setting is a common setting for both network printer slots.

Query Syntax :HARDcopy:NETWork:DOMain?

The :HARDcopy:NETWork:DOMain? query returns the current Windows network domain name.

Return Format <domain><NL>

<domain> ::= quoted ASCII string

- See Also**
- ["Introduction to :HARDcopy Commands"](#) on page 540
 - [":HARDcopy:NETWork:SLOT"](#) on page 552
 - [":HARDcopy:NETWork:APPLY"](#) on page 549
 - [":HARDcopy:NETWork:ADDRESS"](#) on page 548
 - [":HARDcopy:NETWork:USERNAME"](#) on page 553
 - [":HARDcopy:NETWork:PASSWORD"](#) on page 551

:HARDcopy:NETWork:PASSword

N (see [page 1730](#))

Command Syntax :HARDcopy:NETWork:PASSword <password>

<password> ::= quoted ASCII string

The :HARDcopy:NETWork:PASSword command sets the password for the specified Windows network domain and user name.

The password setting is a common setting for both network printer slots.

- See Also**
- ["Introduction to :HARDcopy Commands"](#) on page 540
 - [":HARDcopy:NETWork:USERname"](#) on page 553
 - [":HARDcopy:NETWork:DOMain"](#) on page 550
 - [":HARDcopy:NETWork:SLOT"](#) on page 552
 - [":HARDcopy:NETWork:APPLY"](#) on page 549
 - [":HARDcopy:NETWork:ADDRESS"](#) on page 548

:HARDcopy:NETWork:SLOT

N (see [page 1730](#))

Command Syntax :HARDcopy:NETWork:SLOT <slot>

<slot> ::= {NET0 | NET1}

The :HARDcopy:NETWork:SLOT command selects the network printer slot used for the address and apply commands. There are two network printer slots to choose from.

Query Syntax :HARDcopy:NETWork:SLOT?

The :HARDcopy:NETWork:SLOT? query returns the currently selected network printer slot.

Return Format <slot><NL>

<slot> ::= {NET0 | NET1}

- See Also**
- ["Introduction to :HARDcopy Commands"](#) on page 540
 - [":HARDcopy:NETWork:APPLY"](#) on page 549
 - [":HARDcopy:NETWork:ADDRESS"](#) on page 548
 - [":HARDcopy:NETWork:DOMAIN"](#) on page 550
 - [":HARDcopy:NETWork:USERNAME"](#) on page 553
 - [":HARDcopy:NETWork:PASSWORD"](#) on page 551

:HARDcopy:NETWork:USERname

N (see [page 1730](#))

Command Syntax :HARDcopy:NETWork:USERname <username>

<username> ::= quoted ASCII string

The :HARDcopy:NETWork:USERname command sets the user name to use when connecting to the Windows network domain.

The user name setting is a common setting for both network printer slots.

Query Syntax :HARDcopy:NETWork:USERname?

The :HARDcopy:NETWork:USERname? query returns the currently set user name.

Return Format <username><NL>

<username> ::= quoted ASCII string

- See Also**
- ["Introduction to :HARDcopy Commands"](#) on page 540
 - [":HARDcopy:NETWork:DOMain"](#) on page 550
 - [":HARDcopy:NETWork:PASSword"](#) on page 551
 - [":HARDcopy:NETWork:SLOT"](#) on page 552
 - [":HARDcopy:NETWork:APPLY"](#) on page 549
 - [":HARDcopy:NETWork:ADDRes"](#) on page 548

:HARDcopy:PALETTE

N (see [page 1730](#))

Command Syntax :HARDcopy:PALETTE <palette>
<palette> ::= {COLOR | GRAYscale | NONE}

The :HARDcopy:PALETTE command sets the hardcopy palette color.

The oscilloscope's print driver cannot print color images to color laser printers, so the COLOR option is not available when connected to laser printers.

Query Syntax :HARDcopy:PALETTE?

The :HARDcopy:PALETTE? query returns the selected hardcopy palette color.

Return Format <palette><NL>
<palette> ::= {COL | GRAY | NONE}

- See Also**
- ["Introduction to :HARDcopy Commands"](#) on page 540
 - [":HARDcopy:START"](#) on page 556
 - [":HARDcopy:FACTors"](#) on page 544
 - [":HARDcopy:LAYout"](#) on page 547
 - [":HARDcopy:FFEed"](#) on page 545
 - [":HARDcopy:INKSaver"](#) on page 546

:HARDcopy:PRINter:LIST

N (see [page 1730](#))

Query Syntax :HARDcopy:PRINter:LIST?

The :HARDcopy:PRINter:LIST? query returns a list of available printers. The list can be empty.

Return Format <list><NL>

```
<list> ::= [<printer_spec>] ... [<printer_spec>]
<printer_spec> ::= "<index>,<active>,<name>;"
<index> ::= integer index of printer
<active> ::= {Y | N}
<name> ::= name of printer (for example "DESKJET 950C")
```

- See Also**
- ["Introduction to :HARDcopy Commands"](#) on page 540
 - [":HARDcopy:APRinter"](#) on page 543
 - [":HARDcopy:START"](#) on page 556

:HARDcopy:START

N (see [page 1730](#))

Command Syntax :HARDcopy:START

The :HARDcopy:START command starts a print job.

- See Also**
- ["Introduction to :HARDcopy Commands"](#) on page 540
 - [":HARDcopy:APRinter"](#) on page 543
 - [":HARDcopy:PRINter:LIST"](#) on page 555
 - [":HARDcopy:FACTors"](#) on page 544
 - [":HARDcopy:FFEed"](#) on page 545
 - [":HARDcopy:INKSaver"](#) on page 546
 - [":HARDcopy:LAYout"](#) on page 547
 - [":HARDcopy:PALette"](#) on page 554

:HCOPY:SDUMp:DATA

N (see [page 1730](#))

Query Syntax :HCOPY:SDUMp:DATA? [<format>]

<format> ::= {PNG | BMP | BMP8bit}

The :HCOPY:SDUMp:DATA? query reads and returns screen image data. You can choose 24-bit BMP, 8-bit BMP8bit, or 24-bit PNG formats.

Note that the returned image is also affected by the :HARDcopy:INKSaver command, which is ON by default and returns an inverted image. To get a non-inverted image, send the ":HARDcopy:INKSaver OFF" command before the DATA? query.

In addition to the <format> option of this query, the screen image data format can also be set by the :HCOPY:SDUMp:FORMat command or the front panel's **[Save/Recall] > Save > Format** softkey, when an image format (instead of a setup or data format) is selected.

If no <format> option is specified with this query, the screen image data is returned in the currently selected format. After a *RST (factory default) command, the PNG format is selected by default.

If the <format> option is specified with this query, the format setting will affect the front panel's **[Save/Recall] > Save > Format** softkey setting if the **Format** softkey currently selects an image format (instead of a setup or data format).

Screen image data is returned in the IEEE-488.2 # binary block data format.

Return Format <display_data><NL>

<display_data> ::= binary block data in IEEE-488.2 # format.

- See Also**
- **":HCOPY:SDUMp:FORMat"** on page 558
 - **":DISPlay:DATA"** on page 440
 - **":HARDcopy:INKSaver"** on page 546

:HCOPY:SDUMp:FORMat

N (see [page 1730](#))

Command Syntax :HCOPY:SDUMp:FORMat <format>

<format> ::= {PNG | BMP | BMP8bit}

The :HCOPY:SDUMp:FORMat command specifies the format for screen image data: 24-bit PNG, 24-bit BMP, or 8-bit BMP8bit.

Note that the screen image data is also affected by the :HARDcopy:INKSaver command, which is ON by default and results in an inverted image. To get a non-inverted image, send the ":HARDcopy:INKSaver OFF" command before querying the screen image data.

The :HCOPY:SDUMp:FORMat setting will persist when cycling power but will be reset to PNG after a *RST (factory default) command.

The :HCOPY:SDUMp:FORMat setting will affect the front panel's **[Save/Recall] > Save > Format** softkey setting if the **Format** softkey currently selects an image format (instead of a setup or data format).

Query Syntax :HCOPY:SDUMp:FORMat?

The :HCOPY:SDUMp:FORMat? query returns the specified screen image data format.

The screen image data format can be set by the :HCOPY:SDUMp:FORMat command or the front panel's **[Save/Recall] > Save > Format** softkey, when it selects an image format (instead of a setup or data format).

Return Format <format><NL>

<format> ::= {PNG | BMP | BMP8}

- See Also**
- [":HCOPY:SDUMp:DATA"](#) on page 557
 - [":DISPlay:DATA"](#) on page 440
 - [":HARDcopy:INKSaver"](#) on page 546
 - ["*RST \(Reset\)"](#) on page 246

24 :HISTogram Commands

These commands control the histogram analysis feature.

The histogram analysis feature provides a statistical view of a waveform or a measurement's results.

Waveform histograms show the number of times a waveform crosses into (or hits) a row or column of a user-defined window. For vertical histograms, the window is divided into rows. For horizontal histograms, the window is divided into columns.

Measurement histograms show the distribution of a measurement's results similar to ordinary measurement statistics.

As waveforms are acquired and displayed, or as measurements are made, a counter database accumulates the total number of hits (or measurements), and the histogram data is displayed as a bar graph on the graticule.

When the oscilloscope is stopped, that counter database remains intact until the acquired data display is modified, usually horizontally or vertically. At that time, the database is reset and the last displayed acquisition is used to start a new database.

Table 114 :HISTogram Commands Summary

Command	Query	Options and Query Returns
:HISTogram:AXIS <axis> (see page 562)	:HISTogram:AXIS? (see page 562)	<axis> ::= {VERTical HORizontal}
:HISTogram:DISPlay { {0 OFF} {1 ON} } (see page 563)	:HISTogram:DISPlay? (see page 563)	{0 1}
:HISTogram:MEASurement MEAS<n> (see page 564)	:HISTogram:MEASurement? (see page 564)	<n> ::= # of installed measurement, from 1 to 10
:HISTogram:MODE <mode> (see page 565)	:HISTogram:MODE? (see page 565)	<mode> ::= {OFF WAVEform MEASurement}
:HISTogram:RESet (see page 566)	n/a	n/a

Table 114 :HISTogram Commands Summary (continued)

Command	Query	Options and Query Returns
:HISTogram:SIZE <size> (see page 567)	:HISTogram:SIZE? (see page 567)	<size> ::= 1.0 to 5.0 for vertical histograms, 1.0 to 4.0 for horizontal histograms, in NR3 format
:HISTogram:TYPE <type> (see page 568)	:HISTogram:TYPE? (see page 568)	<type> ::= {VERTical HORizontal MEASurement}
:HISTogram:WINDow:BLI Mit <limit> (see page 569)	:HISTogram:WINDow:BLI Mit? (see page 569)	<limit> ::= bottom value in NR3 format
:HISTogram:WINDow:LLI Mit <limit> (see page 570)	:HISTogram:WINDow:LLI Mit? (see page 570)	<limit> ::= left value in NR3 format
:HISTogram:WINDow:RLI Mit <limit> (see page 571)	:HISTogram:WINDow:RLI Mit? (see page 571)	<limit> ::= right value in NR3 format
:HISTogram:WINDow:SOU Rce <source> (see page 572)	:HISTogram:WINDow:SOU Rce? (see page 572)	<source> ::= {CHANnel<n> FUNction<m> MATH<m> WMEmory<r> CGRade} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format
:HISTogram:WINDow:TLI Mit <limit> (see page 573)	:HISTogram:WINDow:TLI Mit? (see page 573)	<limit> ::= top value in NR3 format

Histogram results statistics can be queried with these commands:

- **":MEASure:HISTogram:HITS"** on page 691 – The sum of all hits in all bins (buckets) in the histogram.
- **":MEASure:HISTogram:PEAK"** on page 700 – Maximum number of hits in any single bin.
- **":MEASure:HISTogram:MAXimum"** on page 695 – The value corresponding to the maximum bin that has any hits.
- **":MEASure:HISTogram:MINimum"** on page 698 – The value corresponding to the minimum bin that has any hits.
- **":MEASure:HISTogram:PPEak"** on page 701 – Delta between the Max and Min values.

- **":MEASure:HISTogram:MEAN"** on page 696 – Mean value of the histogram.
- **":MEASure:HISTogram:MEDian"** on page 697 – Median value of the histogram.
- **":MEASure:HISTogram:MODE"** on page 699 – Mode value of the histogram.
- **":MEASure:HISTogram:BWIDth"** on page 690 – The width of each bin (bucket) in the histogram.
- **":MEASure:HISTogram:SDEVIation"** on page 702 – Standard deviation of the histogram values.
- **":MEASure:HISTogram:M1S"** on page 692 – Percentage of histogram hits that lie within ± 1 Std Dev of the mean.
- **":MEASure:HISTogram:M2S"** on page 693 – Percentage of histogram hits that lie within ± 2 Std Dev of the mean.
- **":MEASure:HISTogram:M3S"** on page 694 – Percentage of histogram hits that lie within ± 3 Std Dev of the mean.

Histogram Interaction With Other Oscilloscope Features

When you enable a histogram, horizontal zoom, XY time mode, or roll time mode are automatically disabled.

When using segmented memory acquisitions, histograms perform similarly to math waveforms and measurements. The histogram is reset at the start of a segmented acquisition and all segments are histogrammed at the end of the acquisition.

Because it is not possible to histogram every waveform, be aware that persistence can show a peak or glitch that does not show up in the histogram data.

Histograms do not wait for the specified number of averaged acquisitions to be acquired before starting analysis, so intermediate results could be erratic.

:HISTogram:AXIS

N (see [page 1730](#))

Command Syntax :HISTogram:AXIS <axis>
<axis> ::= {VERTical | HORizontal}

When the :HISTogram:MODE is WAVEform, the :HISTogram:AXIS command specifies the orientation of the histogram:

- **HORizontal** – the limits window is divided into columns, and the number of hits in each column is displayed in a histogram bar graph at the bottom of the graticule.
- **VERTical** – the limits window is divided into rows, and the number of hits in each row is displayed in a histogram bar graph at the left of the graticule.

(When the :HISTogram:MODE is MEASurement, histograms are always displayed horizontally at the bottom of the graticule.)

Query Syntax :HISTogram:AXIS?

The :HISTogram:AXIS? query returns the currently specified type of waveform histogram.

Return Format <axis><NL>
<axis> ::= {VERT | HOR}

- See Also**
- [":HISTogram:DISPlay"](#) on page 563
 - [":HISTogram:TYPE"](#) on page 568
 - [":HISTogram:MODE"](#) on page 565
 - [":HISTogram:RESet"](#) on page 566
 - [":HISTogram:SIZE"](#) on page 567
 - [":HISTogram:WINDow:BLIMit"](#) on page 569
 - [":HISTogram:WINDow:LLIMit"](#) on page 570
 - [":HISTogram:WINDow:RLIMit"](#) on page 571
 - [":HISTogram:WINDow:SOURce"](#) on page 572
 - [":HISTogram:WINDow:TLIMit"](#) on page 573

:HISTogram:DISPlay

N (see [page 1730](#))

Command Syntax :HISTogram:DISPlay {{0 | OFF} | {1 | ON}}

The :HISTogram:DISPlay command turns the histogram display on or off.

Query Syntax :HISTogram:DISPlay?

The :HISTogram:DISPlay? query returns the current display setting for the histogram.

Return Format <off_on><NL>

{0 | 1}

- See Also**
- [":HISTogram:TYPE"](#) on page 568
 - [":HISTogram:RESet"](#) on page 566
 - [":HISTogram:AXIS"](#) on page 562
 - [":HISTogram:MEASurement"](#) on page 564
 - [":HISTogram:MODE"](#) on page 565
 - [":HISTogram:SIZE"](#) on page 567
 - [":HISTogram:WINDow:BLIMit"](#) on page 569
 - [":HISTogram:WINDow:LLIMit"](#) on page 570
 - [":HISTogram:WINDow:RLIMit"](#) on page 571
 - [":HISTogram:WINDow:SOURce"](#) on page 572
 - [":HISTogram:WINDow:TLIMit"](#) on page 573

:HISTogram:MEASurement

N (see [page 1730](#))

Command Syntax :HISTogram:MEASurement MEAS<n>

<n> ::= # of installed measurement, from 1 to 10

When the :HISTogram:MODE is MEASurement, the :HISTogram:MEASurement command selects the measurement to analyze.

There are 10 locations (or slots) that installed measurements can occupy. The MEAS<n> parameter specifies the location of the measurement you want to analyze.

Query Syntax :HISTogram:MEASurement?

The :HISTogram:MEASurement? query returns the location of the measurement currently selected for histogram analysis.

Return Format MEAS<n><NL>

<n> ::= # of installed measurement, from 1 to 10

- See Also**
- [":HISTogram:DISPlay"](#) on page 563
 - [":HISTogram:TYPE"](#) on page 568
 - [":HISTogram:MODE"](#) on page 565
 - [":HISTogram:RESet"](#) on page 566
 - [":HISTogram:SIZE"](#) on page 567

:HISTogram:MODE

N (see [page 1730](#))

Command Syntax :HISTogram:MODE <mode>
 <mode> ::= {OFF | WAVeform | MEASurement}

The :HISTogram:MODE command selects the type of histogram or disables the histogram analysis feature:

- OFF – disables the histogram analysis feature.
- WAVeform – shows the number of times a waveform crosses into (or hits) a row or column of a user-defined window. For vertical histograms, the window is divided into rows. For horizontal histograms, the window is divided into columns. Use the :HISTogram:AXIS command to specify a vertical or horizontal histogram.
- MEASurement – shows the distribution of a measurement's results just like ordinary measurement statistics.

Query Syntax :HISTogram:MODE?

The :HISTogram:MODE? query returns the currently set histogram mode.

Return Format <mode><NL>
 <mode> ::= {OFF | WAV | MEAS}

- See Also**
- [":HISTogram:DISPlay"](#) on page 563
 - [":HISTogram:TYPE"](#) on page 568
 - [":HISTogram:AXIS"](#) on page 562
 - [":HISTogram:MEASurement"](#) on page 564
 - [":HISTogram:RESet"](#) on page 566
 - [":HISTogram:SIZE"](#) on page 567
 - [":HISTogram:WINDow:BLIMit"](#) on page 569
 - [":HISTogram:WINDow:LLIMit"](#) on page 570
 - [":HISTogram:WINDow:RLIMit"](#) on page 571
 - [":HISTogram:WINDow:SOURce"](#) on page 572
 - [":HISTogram:WINDow:TLIMit"](#) on page 573

:HISTogram:RESet

N (see [page 1730](#))

Command Syntax :HISTogram:RESet

The :HISTogram:RESet command zeros the histogram counters.

- See Also**
- [":HISTogram:DISPlay"](#) on page 563
 - [":HISTogram:TYPE"](#) on page 568
 - [":HISTogram:AXIS"](#) on page 562
 - [":HISTogram:MEASurement"](#) on page 564
 - [":HISTogram:MODE"](#) on page 565
 - [":HISTogram:SIZE"](#) on page 567
 - [":HISTogram:WINDow:BLIMit"](#) on page 569
 - [":HISTogram:WINDow:LLIMit"](#) on page 570
 - [":HISTogram:WINDow:RLIMit"](#) on page 571
 - [":HISTogram:WINDow:SOURce"](#) on page 572
 - [":HISTogram:WINDow:TLIMit"](#) on page 573

:HISTogram:SIZE

N (see [page 1730](#))

Command Syntax :HISTogram:SIZE <size>

<size> ::= 1.0 to 5.0 for vertical histograms, 1.0 to 4.0 for horizontal histograms, in NR3 format

The :HISTogram:SIZE command specifies the number of divisions the histogram bar graph should use:

- For horizontal histograms, you can choose whole and half divisions from 1 to 4.
- For vertical histograms, you can choose whole and half divisions from 1 to 5.

Query Syntax :HISTogram:SIZE?

The :HISTogram:SIZE? query returns the number of divisions currently used for the histogram bar graph.

Return Format <size><NL>

<size> ::= 1.0 to 5.0 for vertical histograms, 1.0 to 4.0 for horizontal histograms, in NR3 format

- See Also**
- [":HISTogram:DISPlay"](#) on page 563
 - [":HISTogram:TYPE"](#) on page 568
 - [":HISTogram:AXIS"](#) on page 562
 - [":HISTogram:MEASurement"](#) on page 564
 - [":HISTogram:MODE"](#) on page 565
 - [":HISTogram:RESet"](#) on page 566
 - [":HISTogram:WINDow:BLIMit"](#) on page 569
 - [":HISTogram:WINDow:LLIMit"](#) on page 570
 - [":HISTogram:WINDow:RLIMit"](#) on page 571
 - [":HISTogram:WINDow:SOURce"](#) on page 572
 - [":HISTogram:WINDow:TLIMit"](#) on page 573

:HISTogram:TYPE

N (see [page 1730](#))

Command Syntax :HISTogram:TYPE <type>
 <type> ::= {VERTical | HORizontal | MEASurement}

The :HISTogram:TYPE command selects either a waveform histogram (horizontal or vertical) or a measurement histogram:

- **HORizontal** – the limits window is divided into columns, and the number of hits in each column is displayed in a histogram bar graph at the bottom of the graticule.
- **VERTical** – the limits window is divided into rows, and the number of hits in each row is displayed in a histogram bar graph at the left of the graticule.
- **MEASurement** – shows the distribution of a measurement's results similar to ordinary measurement statistics.

Query Syntax :HISTogram:TYPE?

The :HISTogram:TYPE? query returns the currently selected histogram type.

Return Format <type><NL>
 <type> ::= {VERT | HOR | MEAS}

- See Also**
- [":HISTogram:DISPlay"](#) on page 563
 - [":HISTogram:RESet"](#) on page 566
 - [":HISTogram:AXIS"](#) on page 562
 - [":HISTogram:MEASurement"](#) on page 564
 - [":HISTogram:MODE"](#) on page 565
 - [":HISTogram:SIZE"](#) on page 567
 - [":HISTogram:WINDow:BLIMit"](#) on page 569
 - [":HISTogram:WINDow:LLIMit"](#) on page 570
 - [":HISTogram:WINDow:RLIMit"](#) on page 571
 - [":HISTogram:WINDow:SOURce"](#) on page 572
 - [":HISTogram:WINDow:TLIMit"](#) on page 573

:HISTogram:WINDow:BLIMit

N (see [page 1730](#))

Command Syntax :HISTogram:WINDow:BLIMit <limit>

<limit> ::= bottom value in NR3 format

When the :HISTogram:MODE is WAVEform, the :HISTogram:WINDow:BLIMit command specifies the histogram limits window's bottom boundary.

The units are the same as the input waveform's vertical units. The input waveform is specified using the :HISTogram:WINDow:SOURce command.

Query Syntax :HISTogram:WINDow:BLIMit?

The :HISTogram:WINDow:BLIMit? query returns the histogram limits window's bottom boundary.

Return Format <limit><NL>

<limit> ::= bottom value in NR3 format

- See Also**
- [":HISTogram:DISPlay"](#) on page 563
 - [":HISTogram:TYPE"](#) on page 568
 - [":HISTogram:AXIS"](#) on page 562
 - [":HISTogram:MODE"](#) on page 565
 - [":HISTogram:RESet"](#) on page 566
 - [":HISTogram:SIZE"](#) on page 567
 - [":HISTogram:WINDow:LLIMit"](#) on page 570
 - [":HISTogram:WINDow:RLIMit"](#) on page 571
 - [":HISTogram:WINDow:SOURce"](#) on page 572
 - [":HISTogram:WINDow:TLIMit"](#) on page 573

:HISTogram:WINDow:LLIMit

N (see [page 1730](#))

Command Syntax :HISTogram:WINDow:LLIMit <limit>

<limit> ::= left value in NR3 format

When the :HISTogram:MODE is WAVEform, the :HISTogram:WINDow:LLIMit command specifies the histogram limits window's left boundary.

The units are the same as the input waveform's horizontal units. The input waveform is specified using the :HISTogram:WINDow:SOURce command.

Query Syntax :HISTogram:WINDow:LLIMit?

The :HISTogram:WINDow:LLIMit? query returns the histogram limits window's left boundary.

Return Format <limit><NL>

<limit> ::= left value in NR3 format

- See Also**
- [":HISTogram:DISPlay"](#) on page 563
 - [":HISTogram:TYPE"](#) on page 568
 - [":HISTogram:AXIS"](#) on page 562
 - [":HISTogram:MODE"](#) on page 565
 - [":HISTogram:RESet"](#) on page 566
 - [":HISTogram:SIZE"](#) on page 567
 - [":HISTogram:WINDow:BLIMit"](#) on page 569
 - [":HISTogram:WINDow:RLIMit"](#) on page 571
 - [":HISTogram:WINDow:SOURce"](#) on page 572
 - [":HISTogram:WINDow:TLIMit"](#) on page 573

:HISTogram:WINDow:RLIMit

N (see [page 1730](#))

Command Syntax :HISTogram:WINDow:RLIMit <limit>

<limit> ::= right value in NR3 format

When the :HISTogram:MODE is WAVEform, the :HISTogram:WINDow:RLIMit command specifies the histogram limits window's right boundary.

The units are the same as the input waveform's horizontal units. The input waveform is specified using the :HISTogram:WINDow:SOURce command.

Query Syntax :HISTogram:WINDow:RLIMit?

The :HISTogram:WINDow:RLIMit? query returns the histogram limits window's right boundary.

Return Format <limit><NL>

<limit> ::= right value in NR3 format

- See Also**
- [":HISTogram:DISPlay"](#) on page 563
 - [":HISTogram:TYPE"](#) on page 568
 - [":HISTogram:AXIS"](#) on page 562
 - [":HISTogram:MODE"](#) on page 565
 - [":HISTogram:RESet"](#) on page 566
 - [":HISTogram:SIZE"](#) on page 567
 - [":HISTogram:WINDow:BLIMit"](#) on page 569
 - [":HISTogram:WINDow:LLIMit"](#) on page 570
 - [":HISTogram:WINDow:SOURce"](#) on page 572
 - [":HISTogram:WINDow:TLIMit"](#) on page 573

:HISTogram:WINDow:SOURce

N (see [page 1730](#))

Command Syntax :HISTogram:WINDow:SOURce <source>
 <source> ::= {CHANnel<n> | FUNCTION<m> | MATH<m> | WMEMory<r> | CGRade}
 <n> ::= 1 to (# analog channels) in NR1 format
 <m> ::= 1 to (# math functions) in NR1 format
 <r> ::= 1 to (# ref waveforms) in NR1 format

When the :HISTogram:MODE is WAVEform, the :HISTogram:WINDow:SOURce command specifies the waveform that is used as the histogram source.

Query Syntax :HISTogram:WINDow:SOURce?

The :HISTogram:WINDow:SOURce? query returns the currently specified waveform histogram source.

Return Format <source><NL>

- See Also**
- [":HISTogram:DISPlay"](#) on page 563
 - [":HISTogram:TYPE"](#) on page 568
 - [":HISTogram:AXIS"](#) on page 562
 - [":HISTogram:MODE"](#) on page 565
 - [":HISTogram:RESet"](#) on page 566
 - [":HISTogram:SIZE"](#) on page 567
 - [":HISTogram:WINDow:BLIMit"](#) on page 569
 - [":HISTogram:WINDow:LLIMit"](#) on page 570
 - [":HISTogram:WINDow:RLIMit"](#) on page 571
 - [":HISTogram:WINDow:TLIMit"](#) on page 573

:HISTogram:WINDow:TLIMit

N (see [page 1730](#))

Command Syntax :HISTogram:WINDow:TLIMit <limit>

<limit> ::= top value in NR3 format

When the :HISTogram:MODE is WAVEform, the :HISTogram:WINDow:TLIMit command specifies the histogram limits window's top boundary.

The units are the same as the input waveform's vertical units. The input waveform is specified using the :HISTogram:WINDow:SOURce command.

Query Syntax :HISTogram:WINDow:TLIMit?

The :HISTogram:WINDow:TLIMit? query returns the histogram limits window's top boundary.

Return Format <limit><NL>

<limit> ::= top value in NR3 format

- See Also**
- [":HISTogram:DISPlay"](#) on page 563
 - [":HISTogram:TYPE"](#) on page 568
 - [":HISTogram:AXIS"](#) on page 562
 - [":HISTogram:MODE"](#) on page 565
 - [":HISTogram:RESet"](#) on page 566
 - [":HISTogram:SIZE"](#) on page 567
 - [":HISTogram:WINDow:BLIMit"](#) on page 569
 - [":HISTogram:WINDow:LLIMit"](#) on page 570
 - [":HISTogram:WINDow:RLIMit"](#) on page 571
 - [":HISTogram:WINDow:SOURce"](#) on page 572

25 :JITTer Commands

When the jitter analysis feature is licensed, these commands control jitter analysis.

Jitter analysis measures the variance of a measurement over time. The principal measurement used with jitter analysis is time interval error (TIE), but several other measurements can be analyzed as well.

The TIE measurement recovers an ideal clock frequency from the source waveform and compares it against measured transitions to generate error statistics. Several different clock recovery methods are available.

Jitter statistics can be visualized in four ways: measurement statistics, histogram, trend, and spectrum.

NOTE

It is important to set up absolute thresholds for the integrity of jitter measurements from acquisition to acquisition. See **":MEASure:DEFine"** on page 671.

Table 115 :JITTer Commands Summary

Command	Query	Options and Query Returns
:JITTer:HISTogram:APPLy (see page 577)	n/a	n/a
:JITTer:MEASurement MEAS<n> (see page 578)	:JITTer:MEASurement? (see page 578)	<n> ::= # of installed measurement, from 1 to 10
:JITTer:SPECTrum:APPLy (see page 580)	n/a	n/a
:JITTer:SPECTrum:HORizontal:POSition <value> (see page 581)	:JITTer:SPECTrum:HORizontal:POSition? (see page 581)	<value> ::= X position (center), in NR3 format
:JITTer:SPECTrum:HORizontal:RANGE <value> (see page 582)	:JITTer:SPECTrum:HORizontal:RANGE? (see page 582)	<value> ::= X scaling (span), in NR3 format

Table 115 :JITter Commands Summary (continued)

Command	Query	Options and Query Returns
:JITter:SPECTrum:VERTical:OFFSet <value> (see page 583)	:JITter:SPECTrum:VERTical:OFFSet? (see page 583)	<value> ::= Y offset, in NR3 format
:JITter:SPECTrum:VERTical:RANGe <value> (see page 584)	:JITter:SPECTrum:VERTical:RANGe? (see page 584)	<value> ::= Y scaling, in NR3 format
:JITter:SPECTrum:VERTical:TYPE <type> (see page 585)	:JITter:SPECTrum:VERTical:TYPE? (see page 585)	<type> ::= {DECibel VRMS}
:JITter:SPECTrum:WINDow <window> (see page 586)	:JITter:SPECTrum:WINDow? (see page 586)	<window> ::= {RECTangular HANNing FLATtop BHARRis BARTlett}
:JITter:STATe {{0 OFF} {1 ON}} (see page 588)	:JITter:STATe? (see page 588)	{0 1}
:JITter:TREND:APPLy (see page 590)	n/a	n/a
:JITter:TREND:SMOoth:APPLy (see page 591)	n/a	n/a
:JITter:TREND:SMOoth:POINTs <points> (see page 592)	:JITter:TREND:SMOoth:POINTs? (see page 592)	<points> ::= odd integer in NR1 format
:JITter:TREND:VERTical:OFFSet <value> (see page 593)	:JITter:TREND:VERTical:OFFSet? (see page 593)	<value> ::= Y offset, in NR3 format
:JITter:TREND:VERTical:RANGe <value> (see page 594)	:JITter:TREND:VERTical:RANGe? (see page 594)	<value> ::= Y scaling, in NR3 format

:JITTer:HISTogram:APPLy

N (see [page 1730](#))

Command Syntax :JITTer:HISTogram:APPLy

The :JITTer:HISTogram:APPLy command auto-configures and turns on the jitter measurement histogram for the selected measurement.

- See Also**
- [":JITTer:MEASurement"](#) on page 578
 - [":JITTer:STATe"](#) on page 588

:JITter:MEASurement

N (see [page 1730](#))

Command Syntax :JITter:MEASurement MEAS<n>

<n> ::= # of installed measurement, from 1 to 10

The :JITter:MEASurement command selects the measurement to analyze.

There are 10 locations (or slots) that installed measurements can occupy. The MEAS<n> parameter specifies the location of the measurement you want to analyze.

The measurement location you specify must have one of these measurements installed:

- Data TIE (time interval error) – see [":MEASure:TIEData"](#) on page 738.
Time interval error measurements use clock recovery. To change the clock recovery method, see [":CLOCK:METHod"](#) on page 386.
- Clock TIE (time interval error) – see [":MEASure:TIEClock"](#) on page 740.
Time interval error measurements use clock recovery. To change the clock recovery method, see [":CLOCK:METHod"](#) on page 386.
- N-Period – see [":MEASure:NPERiod"](#) on page 707.
- N-Period to N-Period – see [":MEASure:NCJitter"](#) on page 703.
- +Width to +Width – see [":MEASure:CTCPwidth"](#) on page 669.
- -Width to -Width – see [":MEASure:CTCNwidth"](#) on page 667.
- +Duty Cycle – see [":MEASure:DUTYcycle"](#) on page 683.

Query Syntax :JITter:MEASurement?

The :JITter:MEASurement? query returns the location of the measurement currently selected for histogram analysis.

Return Format MEAS<n><NL>

<n> ::= # of installed measurement, from 1 to 10

- See Also**
- [":JITter:HISTogram:APPLY"](#) on page 577
 - [":JITter:SPECTrum:APPLY"](#) on page 580
 - [":JITter:SPECTrum:HORIZontal:POSition"](#) on page 581
 - [":JITter:SPECTrum:HORIZontal:RANGe"](#) on page 582
 - [":JITter:SPECTrum:VERTical:OFFSet"](#) on page 583
 - [":JITter:SPECTrum:VERTical:RANGe"](#) on page 584
 - [":JITter:SPECTrum:VERTical:TYPE"](#) on page 585
 - [":JITter:SPECTrum:WINDow"](#) on page 586

- **":JITTer:STATe"** on page 588
- **":JITTer:TREND:APPLY"** on page 590
- **":JITTer:TREND:SMOoth:APPLY"** on page 591
- **":JITTer:TREND:SMOoth:POINTs"** on page 592
- **":JITTer:TREND:VERTical:OFFSet"** on page 593
- **":JITTer:TREND:VERTical:RANGe"** on page 594

:JITTer:SPECTrum:APPLy

N (see [page 1730](#))

Command Syntax :JITTer:SPECTrum:APPLy

The :JITTer:SPECTrum:APPLy command auto-configures and turns on the jitter spectrum for the selected measurement.

- See Also**
- [":JITTer:MEASurement"](#) on page 578
 - [":JITTer:SPECTrum:HORizontal:POSition"](#) on page 581
 - [":JITTer:SPECTrum:HORizontal:RANGe"](#) on page 582
 - [":JITTer:SPECTrum:VERTical:OFFSet"](#) on page 583
 - [":JITTer:SPECTrum:VERTical:RANGe"](#) on page 584
 - [":JITTer:SPECTrum:VERTical:TYPE"](#) on page 585
 - [":JITTer:SPECTrum:WINDow"](#) on page 586
 - [":JITTer:STATe"](#) on page 588

:JITter:SPECTrum:HORizontal:POSition

N (see [page 1730](#))

Command Syntax :JITter:SPECTrum:HORizontal:POSition <value>

<value> ::= X position (center), in NR3 format

The :JITter:SPECTrum:HORizontal:POSition command sets the center frequency for the jitter measurement spectrum.

After the :JITter:SPECTrum:APPLY command, this command is an alias for :FUNCTION4[:FFT]:CENTER.

Query Syntax :JITter:SPECTrum:HORizontal:POSition?

The :JITter:SPECTrum:HORizontal:POSition? query returns the current center frequency in Hertz.

Return Format <value><NL>

<value> ::= X position (center), in NR3 format

- See Also**
- [":JITter:MEASurement"](#) on page 578
 - [":JITter:SPECTrum:APPLY"](#) on page 580
 - [":JITter:SPECTrum:HORizontal:RANGe"](#) on page 582
 - [":JITter:SPECTrum:VERTical:OFFSet"](#) on page 583
 - [":JITter:SPECTrum:VERTical:RANGe"](#) on page 584
 - [":JITter:SPECTrum:VERTical:TYPE"](#) on page 585
 - [":JITter:SPECTrum:WINDow"](#) on page 586
 - [":JITter:STATe"](#) on page 588

:JITter:SPECTrum:HORizontal:RANGe

N (see [page 1730](#))

Command Syntax :JITter:SPECTrum:HORizontal:RANGe <value>

<value> ::= X scaling (span), in NR3 format

The :JITter:SPECTrum:HORizontal:RANGe command sets the frequency span of the display (left graticule to right graticule) for the jitter measurement spectrum.

After the :JITter:SPECTrum:APPLY command, this command is an alias for :FUNCTION4[:FFT]:SPAN.

Query Syntax :JITter:SPECTrum:HORizontal:RANGe?

The :JITter:SPECTrum:HORizontal:RANGe? query returns the current frequency span in Hertz.

Return Format <value><NL>

<value> ::= X scaling (span), in NR3 format

- See Also**
- [":JITter:MEASurement"](#) on page 578
 - [":JITter:SPECTrum:APPLY"](#) on page 580
 - [":JITter:SPECTrum:HORizontal:POSition"](#) on page 581
 - [":JITter:SPECTrum:VERTical:OFFSet"](#) on page 583
 - [":JITter:SPECTrum:VERTical:RANGe"](#) on page 584
 - [":JITter:SPECTrum:VERTical:TYPE"](#) on page 585
 - [":JITter:SPECTrum:WINDow"](#) on page 586
 - [":JITter:STATE"](#) on page 588

:JITter:SPECTrum:VERTical:OFFSet

N (see [page 1730](#))

Command Syntax :JITter:SPECTrum:VERTical:OFFSet <value>

<value> ::= Y offset, in NR3 format

The :JITter:SPECTrum:VERTical:OFFSet command sets the vertical value represented at center screen for the jitter measurement spectrum.

After the :JITter:SPECTrum:APPLy command, this command is an alias for :FUNCTION4:OFFSet.

Query Syntax :JITter:SPECTrum:VERTical:OFFSet?

The :JITter:SPECTrum:VERTical:OFFSet? query returns the current offset value for the jitter measurement spectrum.

Return Format <value><NL>

<value> ::= Y offset, in NR3 format

- See Also**
- [":JITter:MEASurement"](#) on page 578
 - [":JITter:SPECTrum:APPLy"](#) on page 580
 - [":JITter:SPECTrum:HORizontal:POSition"](#) on page 581
 - [":JITter:SPECTrum:HORizontal:RANGe"](#) on page 582
 - [":JITter:SPECTrum:VERTical:RANGe"](#) on page 584
 - [":JITter:SPECTrum:VERTical:TYPE"](#) on page 585
 - [":JITter:SPECTrum:WINDow"](#) on page 586
 - [":JITter:STATe"](#) on page 588

:JITter:SPECTrum:VERTical:RANGe

N (see [page 1730](#))

Command Syntax `:JITter:SPECTrum:VERTical:RANGe <value>`

`<value>` ::= Y scaling, in NR3 format

The `:JITter:SPECTrum:VERTical:RANGe` command defines the full-scale vertical range for the jitter measurement spectrum.

After the `:JITter:SPECTrum:APPLy` command, this command is an alias for `:FUNCTION4:RANGe`.

Query Syntax `:JITter:SPECTrum:VERTical:RANGe?`

The `:JITter:SPECTrum:VERTical:RANGe?` query returns the current full-scale vertical range for the jitter measurement spectrum.

Return Format `<value><NL>`

`<value>` ::= Y scaling, in NR3 format

- See Also**
- [":JITter:MEASurement"](#) on page 578
 - [":JITter:SPECTrum:APPLy"](#) on page 580
 - [":JITter:SPECTrum:HORizontal:POSition"](#) on page 581
 - [":JITter:SPECTrum:HORizontal:RANGe"](#) on page 582
 - [":JITter:SPECTrum:VERTical:OFFSet"](#) on page 583
 - [":JITter:SPECTrum:VERTical:TYPE"](#) on page 585
 - [":JITter:SPECTrum:WINDow"](#) on page 586
 - [":JITter:STATe"](#) on page 588

:JITTer:SPECtrum:VERTical:TYPE

N (see [page 1730](#))

Command Syntax :JITTer:SPECtrum:VERTical:TYPE <type>

<type> ::= {DECibel | VRMS}

The :JITTer:SPECtrum:VERTical:TYPE command sets the vertical units for the jitter spectrum.

After the :JITTer:SPECtrum:APPLY command, this command is an alias for :FUNCTION4[:FFT]:VTYPE.

Query Syntax :JITTer:SPECtrum:VERTical:TYPE?

The :JITTer:SPECtrum:VERTical:TYPE? query returns the vertical units setting.

Return Format <type><NL>

<type> ::= {DEC | VRMS}

- See Also**
- [":JITTer:MEASurement"](#) on page 578
 - [":JITTer:SPECtrum:APPLY"](#) on page 580
 - [":JITTer:SPECtrum:HORizontal:POSition"](#) on page 581
 - [":JITTer:SPECtrum:HORizontal:RANGe"](#) on page 582
 - [":JITTer:SPECtrum:VERTical:OFFSet"](#) on page 583
 - [":JITTer:SPECtrum:VERTical:RANGe"](#) on page 584
 - [":JITTer:SPECtrum:WINDow"](#) on page 586
 - [":JITTer:STATe"](#) on page 588

:JITter:SPECTrum:WINDow

N (see [page 1730](#))

Command Syntax :JITter:SPECTrum:WINDow <window>

<window> ::= {RECTangular | HANNing | FLATtop | BHARris | BARTlett}

The :JITter:SPECTrum:WINDow command allows the selection of different windowing transforms or operations for the jitter spectrum FFT (Fast Fourier Transform).

The jitter spectrum operation assumes that the time record repeats. Unless an integral number of sampled waveform cycles exist in the record, a discontinuity is created between the end of one record and the beginning of the next. This discontinuity introduces additional frequency components about the peaks into the spectrum. This is referred to as leakage. To minimize leakage, windows that approach zero smoothly at the start and end of the record are employed as filters to the FFTs. Each window is useful for certain classes of input signals.

- RECTangular – useful for transient signals, and signals where there are an integral number of cycles in the time record.
- HANNing – useful for frequency resolution and general purpose use. It is good for resolving two frequencies that are close together, or for making frequency measurements. This is the default window.
- FLATtop – best for making accurate amplitude measurements of frequency peaks.
- BHARris (Blackman-Harris) – reduces time resolution compared to the rectangular window, but it improves the capacity to detect smaller impulses due to lower secondary lobes (provides minimal spectral leakage).
- BARTlett – (triangular, with end points at zero) window is similar to the Hanning window in that it is good for making accurate frequency measurements, but its higher and wider secondary lobes make it not quite as good for resolving frequencies that are close together.

After the :JITter:SPECTrum:APPLY command, this command is an alias for :FUNCTION4[:FFT]:WINDow.

Query Syntax :JITter:SPECTrum:WINDow?

The :JITter:SPECTrum:WINDow? query returns the value of the window selected for the jitter spectrum function.

Return Format <window><NL>

<window> ::= {RECT | HANN | FLAT | BHAR | BART}

- See Also**
- [":JITter:MEASurement"](#) on page 578
 - [":JITter:SPECTrum:APPLY"](#) on page 580
 - [":JITter:SPECTrum:HORizontal:POSition"](#) on page 581

- `":JITTer:SPECTrum:HORizontal:RANGe"` on page 582
- `":JITTer:SPECTrum:VERTical:OFFSet"` on page 583
- `":JITTer:SPECTrum:VERTical:RANGe"` on page 584
- `":JITTer:SPECTrum:VERTical:TYPE"` on page 585
- `":JITTer:STATe"` on page 588

:JITTer:STATe

N (see [page 1730](#))

Command Syntax :JITTer:STATe {{0 | OFF} | {1 | ON}}

The :JITTer:STATe command enables or disables the jitter analysis feature.

When jitter analysis is enabled, the **[Jitter]** front panel key is lit, and these oscilloscope settings are forced on:

- Precision measurements with a 1M precision analysis record length (see [":SYSTem:PRECision"](#) on page 1393), which gives better accuracy.
- All edges in each acquisition are measured (instead of a single edge per acquisition, as is normally the case). For each acquisition, the measurement count increases by the number of edges in the acquisition. This applies to all measurements that look at edges, not just jitter analysis measurements.

When jitter analysis is disabled:

- The light behind the **[Jitter]** key is turned off.
- The "precision measurements" and 1M precision analysis record length settings are returned to the settings present when jitter analysis was enabled.
- The oscilloscope returns to measuring a specific edge in each acquisition (generally around the horizontal time reference) and ignoring all other edges in the acquisition, as is normally the case. For each acquisition, the measurement count increases by one.

Query Syntax :JITTer:STATe?

The :JITTer:STATe? query returns whether the jitter analysis feature is enabled.

Return Format <off_on><NL>
{0 | 1}

- See Also**
- [":JITTer:HISTogram:APPLY"](#) on page 577
 - [":JITTer:MEASurement"](#) on page 578
 - [":JITTer:SPECTrum:APPLY"](#) on page 580
 - [":JITTer:SPECTrum:HORizontal:POSition"](#) on page 581
 - [":JITTer:SPECTrum:HORizontal:RANGe"](#) on page 582
 - [":JITTer:SPECTrum:VERTical:OFFSet"](#) on page 583
 - [":JITTer:SPECTrum:VERTical:RANGe"](#) on page 584
 - [":JITTer:SPECTrum:VERTical:TYPE"](#) on page 585
 - [":JITTer:SPECTrum:WINDow"](#) on page 586
 - [":JITTer:TREND:APPLY"](#) on page 590
 - [":JITTer:TREND:SMOoth:APPLY"](#) on page 591

- `":JITTer:TREND:SMOoth:POINts"` on page 592
- `":JITTer:TREND:VERTical:OFFSet"` on page 593
- `":JITTer:TREND:VERTical:RANGe"` on page 594

:JITTer:TREND:APPLY

N (see [page 1730](#))

Command Syntax :JITTer:TREND:APPLY

The :JITTer:TREND:APPLY command auto-configures and turns on the jitter measurement trend for the selected measurement.

- See Also**
- [":JITTer:MEASurement"](#) on page 578
 - [":JITTer:STAtE"](#) on page 588
 - [":JITTer:TREND:SMOoth:APPLY"](#) on page 591
 - [":JITTer:TREND:SMOoth:POINts"](#) on page 592
 - [":JITTer:TREND:VERTical:OFFSet"](#) on page 593
 - [":JITTer:TREND:VERTical:RANGe"](#) on page 594

:JITTer:TREND:SMOoth:APPLy

N (see [page 1730](#))

Command Syntax :JITTer:TREND:SMOoth:APPLy

The :JITTer:TREND:SMOoth:APPLy command auto-configures and turns on smoothing for the jitter measurement trend.

- See Also**
- [":JITTer:MEASurement"](#) on page 578
 - [":JITTer:STATe"](#) on page 588
 - [":JITTer:TREND:APPLy"](#) on page 590
 - [":JITTer:TREND:SMOoth:POINts"](#) on page 592
 - [":JITTer:TREND:VERTical:OFFSet"](#) on page 593
 - [":JITTer:TREND:VERTical:RANGe"](#) on page 594

:JITTer:TREND:SMOoth:POINTs

N (see [page 1730](#))

Command Syntax :JITTer:TREND:SMOoth:POINTs <points>

<points> ::= odd integer in NR1 format

When jitter trend smoothing is turned on (by :JITTer:TREND:SMOoth:APPLY), the :JITTer:TREND:SMOoth:POINTs command sets the number of smoothing points to use.

You can choose an odd number of points, from 3 up to half of the measurement record or precision analysis record.

After the :JITTer:TREND:SMOoth:APPLY command, this command is an alias for :FUNCTION3:SMOoth:POINTs.

Query Syntax :JITTer:TREND:SMOoth:POINTs?

The :JITTer:TREND:SMOoth:POINTs? query returns the number of jitter trend smoothing points specified.

Return Format <points><NL>

- See Also**
- [":JITTer:MEASurement"](#) on page 578
 - [":JITTer:STATe"](#) on page 588
 - [":JITTer:TREND:APPLY"](#) on page 590
 - [":JITTer:TREND:SMOoth:APPLY"](#) on page 591
 - [":JITTer:TREND:VERTical:OFFSet"](#) on page 593
 - [":JITTer:TREND:VERTical:RANGe"](#) on page 594

:JITTer:TREND:VERTical:OFFSet

N (see [page 1730](#))

Command Syntax :JITTer:TREND:VERTical:OFFSet <value>

<value> ::= Y offset, in NR3 format

The :JITTer:TREND:VERTical:OFFSet command sets the vertical value represented at center screen for the jitter measurement trend.

After the :JITTer:TREND:APPLy command, this command is an alias for :FUNctIon2:OFFSet.

Query Syntax :JITTer:TREND:VERTical:OFFSet?

The :JITTer:TREND:VERTical:OFFSet? query returns the current offset value for the jitter measurement trend.

Return Format <value><NL>

<value> ::= Y offset, in NR3 format

- See Also**
- [":JITTer:MEASurement"](#) on page 578
 - [":JITTer:STATe"](#) on page 588
 - [":JITTer:TREND:APPLy"](#) on page 590
 - [":JITTer:TREND:SMOoth:APPLy"](#) on page 591
 - [":JITTer:TREND:SMOoth:POINts"](#) on page 592
 - [":JITTer:TREND:VERTical:RANGe"](#) on page 594

:JITter:TREND:VERTical:RANGe

N (see [page 1730](#))

Command Syntax :JITter:TREND:VERTical:RANGe <value>

<value> ::= Y scaling, in NR3 format

The :JITter:TREND:VERTical:RANGe command defines the full-scale vertical range for the jitter measurement trend.

After the :JITter:TREND:APPLy command, this command is an alias for :FUNctIon2:RANGe.

Query Syntax :JITter:TREND:VERTical:RANGe?

The :JITter:TREND:VERTical:RANGe? query returns the current full-scale vertical range for the jitter measurement trend.

Return Format <value><NL>

<value> ::= Y scaling, in NR3 format

- See Also**
- [":JITter:MEASurement"](#) on page 578
 - [":JITter:STATe"](#) on page 588
 - [":JITter:TREND:APPLy"](#) on page 590
 - [":JITter:TREND:SMOoth:APPLy"](#) on page 591
 - [":JITter:TREND:SMOoth:POINts"](#) on page 592
 - [":JITter:TREND:VERTical:OFFSet"](#) on page 593

26 :LISTer Commands

Table 116 :LISTer Commands Summary

Command	Query	Options and Query Returns
n/a	:LISTer:DATA? (see page 596)	<binary_block> ::= comma-separated data with newlines at the end of each row
:LISTer:DISPlay { {OFF 0} {SBUS1 ON 1} {SBUS2 2} ALL} (see page 597)	:LISTer:DISPlay? (see page 597)	{OFF SBUS1 SBUS2 ALL}
:LISTer:REference <time_ref> (see page 598)	:LISTer:REference? (see page 598)	<time_ref> ::= {TRIGger PREVIOUS}

Introduction to :LISTer Commands The LISTer subsystem is used to turn on/off the serial decode Lister display and return data from the Lister display.

:LISTer:DATA

N (see [page 1730](#))

Query Syntax :LISTer:DATA?

The :LISTer:DATA? query returns the lister data.

Return Format <binary_block><NL>

<binary_block> ::= comma-separated data with newlines at the end of each row

- See Also**
- ["Introduction to :LISTer Commands"](#) on page 595
 - [":LISTer:DISPlay"](#) on page 597
 - ["Definite-Length Block Response Data"](#) on page 226

:LISTer:DISPlay

N (see [page 1730](#))

Command Syntax :LISTer:DISPlay <value>

<value> ::= {{OFF | 0} | {SBUS1 | ON | 1} | {SBUS2 | 2} | ALL}

The :LISTer:DISPlay command configures which of the serial buses to display in the Lister, or whether the Lister is off. "ON" or "1" is the same as "SBUS1".

When set to "ALL", the decode information for different buses is interleaved in time.

Serial bus decode must be on before it can be displayed in the Lister.

Query Syntax :LISTer:DISPlay?

The :LISTer:DISPlay? query returns the Lister display setting.

Return Format <value><NL>

<value> ::= {OFF | SBUS1 | SBUS2 | ALL}

- See Also**
- ["Introduction to :LISTer Commands"](#) on page 595
 - [":SBUS<n>:DISPlay"](#) on page 980
 - [":LISTer:DATA"](#) on page 596

:LISTer:REFErence

N (see [page 1730](#))

Command Syntax :LISTer:REFErence <time_ref>

<time_ref> ::= {TRIGger | PREVIOUS}

The :LISTer:REFErence command selects whether the time value for a Lister row is relative to the trigger or the previous Lister row.

Query Syntax :LISTer:REFErence?

The :LISTer:REFErence? query returns the Lister time reference setting.

Return Format <time_ref><NL>

<time_ref> ::= {TRIGger | PREVIOUS}

- See Also**
- ["Introduction to :LISTer Commands"](#) on page 595
 - [":SBUS<n>:DISPlay"](#) on page 980
 - [":LISTer:DATA"](#) on page 596
 - [":LISTer:DISPlay"](#) on page 597

27 :LTEST Commands

Table 117 :LTEST Commands Summary

Command	Query	Options and Query Returns
:LTEST:COPY (see page 601)	n/a	n/a
:LTEST:COPY:ALL (see page 602)	n/a	n/a
:LTEST:COPY:MARGin <percent> (see page 603)	:LTEST:COPY:MARGin? (see page 603)	<percent> ::= copy margin percent in NR1 format
:LTEST:ENABle {{0 OFF} {1 ON}} (see page 604)	:LTEST:ENABle? (see page 604)	<setting> ::= {0 1}
:LTEST:FAIL <condition> (see page 605)	:LTEST:FAIL? (see page 605)	<condition> ::= {INSide OUTSide}
:LTEST:LLIMit <lower_value> (see page 606)	:LTEST:LLIMit? (see page 606)	<lower_value> ::= a real number in NR3 format
:LTEST:MEASurement {MEAS<n>} (see page 607)	:LTEST:MEASurement? (see page 607)	<n> ::= # of installed measurement, from 1 to 10
n/a	:LTEST:RESults? [{MEAS<n>}] (see page 608)	<n> ::= # of installed measurement, from 1 to 10
:LTEST:RUMode:SOFailu re {{0 OFF} {1 ON}} (see page 609)	:LTEST:RUMode:SOFailu re? (see page 609)	<setting> ::= {0 1}

Table 117 :LTEST Commands Summary (continued)

Command	Query	Options and Query Returns
:LTEST:TEST {{0 OFF} {1 ON}} (see page 610)	:LTEST:TEST? (see page 610)	<setting> ::= {0 1}
:LTEST:ULIMit <upper_value> (see page 611)	:LTEST:ULIMit? (see page 611)	<upper_value> ::= a real number in NR3 format

Introduction to :LTEST Commands The LTEST subsystem is used for the Measurement Limit Test feature.

:LTEST:COPY

N (see [page 1730](#))

Command Syntax :LTEST:COPY

For the measurement selected by :LTEST:MEASUREMENT, the :LTEST:COPY command sets upper and lower limits to the last measurement result plus or minus a percent margin (see :LTEST:COPY:MARGIN).

- See Also**
- [":LTEST:COPY:ALL"](#) on page 602
 - [":LTEST:COPY:MARGIN"](#) on page 603
 - [":LTEST:ENABLE"](#) on page 604
 - [":LTEST:FAIL"](#) on page 605
 - [":LTEST:LLIMIT"](#) on page 606
 - [":LTEST:MEASUREMENT"](#) on page 607
 - [":LTEST:RESULTS"](#) on page 608
 - [":LTEST:RUMODE:SOFAILURE"](#) on page 609
 - [":LTEST:TEST"](#) on page 610
 - [":LTEST:ULIMIT"](#) on page 611

:LTEST:COPY:ALL

N (see [page 1730](#))

Command Syntax :LTEST:COPY:ALL

For all measurements whose limits are being tested, the :LTEST:COPY:ALL command sets upper and lower limits to the last measurement result plus or minus a percent margin (see :LTEST:COPY:MARGIN).

In essence, this command performs the :LTEST:COPY operation on all measurements whose limits are being tested.

- See Also**
- [":LTEST:COPY"](#) on page 601
 - [":LTEST:COPY:MARGIN"](#) on page 603
 - [":LTEST:ENABLE"](#) on page 604
 - [":LTEST:FAIL"](#) on page 605
 - [":LTEST:LLIMIT"](#) on page 606
 - [":LTEST:MEASUREMENT"](#) on page 607
 - [":LTEST:RESULTS"](#) on page 608
 - [":LTEST:RUMODE:SOFAILURE"](#) on page 609
 - [":LTEST:TEST"](#) on page 610
 - [":LTEST:ULIMIT"](#) on page 611

:LTEST:COPY:MARGIN

N (see [page 1730](#))

Command Syntax :LTEST:COPY:MARGIN <percent>

<percent> ::= copy margin percent in NR1 format

For the measurement selected by :LTEST:MEASUREMENT, the :LTEST:COPY:MARGIN command specifies the percent margin used when setting upper and lower limits by copying from measurement results.

Query Syntax :LTEST:COPY:MARGIN?

The :LTEST:COPY:MARGIN? query returns the percent margin setting for the measurement selected by :LTEST:MEASUREMENT.

Return Format <percent><NL>

<percent> ::= copy margin percent in NR1 format

- See Also**
- [":LTEST:COPY"](#) on page 601
 - [":LTEST:COPY:ALL"](#) on page 602
 - [":LTEST:ENABLE"](#) on page 604
 - [":LTEST:FAIL"](#) on page 605
 - [":LTEST:LLIMIT"](#) on page 606
 - [":LTEST:MEASUREMENT"](#) on page 607
 - [":LTEST:RESULTS"](#) on page 608
 - [":LTEST:RUMODE:SOFailure"](#) on page 609
 - [":LTEST:TEST"](#) on page 610
 - [":LTEST:ULIMIT"](#) on page 611

:LTEST:ENABLE

N (see [page 1730](#))

Command Syntax :LTEST:ENABLE {{0 | OFF} | {1 | ON}}

The :LTEST:ENABLE command turns the measurement limit test feature on or off.

Query Syntax :LTEST:ENABLE?

The :LTEST:ENABLE? query returns whether the measurement limit test feature is on or off.

Return Format <setting><NL>

<setting> ::= {0 | 1}

- See Also**
- [":LTEST:COPY"](#) on page 601
 - [":LTEST:COPY:ALL"](#) on page 602
 - [":LTEST:COPY:MARGIN"](#) on page 603
 - [":LTEST:FAIL"](#) on page 605
 - [":LTEST:LLIMIT"](#) on page 606
 - [":LTEST:MEASUREMENT"](#) on page 607
 - [":LTEST:RESULTS"](#) on page 608
 - [":LTEST:RUMODE:SOFAILURE"](#) on page 609
 - [":LTEST:TEST"](#) on page 610
 - [":LTEST:ULIMIT"](#) on page 611

:LTEST:FAIL

N (see [page 1730](#))

Command Syntax :LTEST:FAIL <condition>

<condition> ::= {INSide | OUTSide}

For the active measurement currently selected by the :LTEST:MEASurement command, the :LTEST:FAIL command sets the fail condition for the measurement.

When a measurement failure is detected by the limit test, the fail action conditions are executed, and there is the potential to generate an SRQ.

- **INSide** – causes the oscilloscope to fail a test when the measurement results are within the parameters set by the :LTEST:LIMit and :LTEST:ULIMit commands.
- **OUTSide** – causes the oscilloscope to fail a test when the measurement results exceed the parameters set by :LTEST:LLIMit and :LTEST:ULIMit commands.

Query Syntax :LTEST:FAIL?

The :LTEST:FAIL? query returns the currently set fail condition.

Return Format <condition><NL>

<condition> ::= {INS | OUTS}

- See Also**
- [":LTEST:COPY"](#) on page 601
 - [":LTEST:COPY:ALL"](#) on page 602
 - [":LTEST:COPY:MARGIN"](#) on page 603
 - [":LTEST:ENABLE"](#) on page 604
 - [":LTEST:LLIMit"](#) on page 606
 - [":LTEST:MEASurement"](#) on page 607
 - [":LTEST:RESults"](#) on page 608
 - [":LTEST:RUMode:SOFailure"](#) on page 609
 - [":LTEST:TEST"](#) on page 610
 - [":LTEST:ULIMit"](#) on page 611

:LTEST:LLIMit

N (see [page 1730](#))

Command Syntax :LTEST:LLIMit <lower_value>
 <lower_value> ::= a real number in NR3 format

For the active measurement currently selected by the :LTEST:MEASurement command, the :LTEST:LLIMit (Lower LIMit) command sets the lower test limit.

Query Syntax :LTEST:LLIMit?

The :LTEST:LLIMit? query returns the current lower limit setting.

Return Format <lower_value><NL>

- See Also**
- [":LTEST:COPY"](#) on page 601
 - [":LTEST:COPY:ALL"](#) on page 602
 - [":LTEST:COPY:MARGin"](#) on page 603
 - [":LTEST:ENABle"](#) on page 604
 - [":LTEST:FAIL"](#) on page 605
 - [":LTEST:MEASurement"](#) on page 607
 - [":LTEST:RESults"](#) on page 608
 - [":LTEST:RUMode:SOFailure"](#) on page 609
 - [":LTEST:TEST"](#) on page 610
 - [":LTEST:ULIMit"](#) on page 611

:LTEST:MEASurement

N (see [page 1730](#))

Command Syntax :LTEST:MEASurement {MEAS<n>}

<n> ::= # of installed measurement, from 1 to 10

The :LTEST:MEASurement command selects the measurement source for the :LTEST:FAIL, :LTEST:LLIMit, :LTEST:ULIMit, and :LTEST:TEST commands. It selects one of the active measurements by its number, where MEAS1 is the first added measurement. When you add more than 10 measurements, measurement numbering starts again from MEAS1.

Query Syntax :LTEST:MEASurement?

The :LTEST:MEASurement? query returns the currently selected measurement source.

Return Format MEAS<n><NL>

- See Also**
- [":LTEST:COPY"](#) on page 601
 - [":LTEST:COPY:ALL"](#) on page 602
 - [":LTEST:COPY:MARGin"](#) on page 603
 - [":LTEST:ENABle"](#) on page 604
 - [":LTEST:FAIL"](#) on page 605
 - [":LTEST:LLIMit"](#) on page 606
 - [":LTEST:RESults"](#) on page 608
 - [":LTEST:RUMode:SOFailure"](#) on page 609
 - [":LTEST:TEST"](#) on page 610
 - [":LTEST:ULIMit"](#) on page 611

:LTEST:RESults

N (see [page 1730](#))

Query Syntax :LTEST:RESults? [{MEAS<n>}]

<n> ::= # of installed measurement, from 1 to 10

The :LTEST:RESults? query returns the measurement results for selected measurement.

When :LTEST:TEST is ON, the :LTEST:RESults? query returns the failed minimum value (Fail Min), the failed maximum value (Fail Max), and the total number of measurements made (# of Meas).

When :LTEST:TEST is OFF, the :LTEST:RESults? query returns nothing.

Return Format <fail_min>,<fail_max>,<num_meas><NL>

- <fail_min> – A real number representing the total number of measurements that have failed the minimum limit.
- <fail_max> – A real number representing the total number of measurements that have failed the maximum limit.
- <num_meas> – A real number representing the total number of measurements that have been made.

- See Also**
- [":LTEST:COPIY"](#) on page 601
 - [":LTEST:COPIY:ALL"](#) on page 602
 - [":LTEST:COPIY:MARGIn"](#) on page 603
 - [":LTEST:ENABle"](#) on page 604
 - [":LTEST:FAIL"](#) on page 605
 - [":LTEST:LLIMit"](#) on page 606
 - [":LTEST:MEASurement"](#) on page 607
 - [":LTEST:RUMode:SOFailure"](#) on page 609
 - [":LTEST:TEST"](#) on page 610
 - [":LTEST:ULIMit"](#) on page 611

:LTEST:RUMode:SOFailure

N (see [page 1730](#))

Command Syntax :LTEST:RUMode:SOFailure {{0 | OFF} | {1 | ON}}

The :LTEST:RUMode:SOFailure command enables or disables the limit test "stop on failure" option.

When ON, the oscilloscope acquisition system stops once a limit failure is detected. If more than one measurement limit test is enabled, a failure of any of the measurements stops the oscilloscope from acquiring new waveforms.

Query Syntax :LTEST:RUMode:SOFailure?

The :LTEST:RUMode:SOFailure? query returns the "stop on failure" setting.

Return Format <setting><NL>

<setting> ::= {0 | 1}

- See Also**
- [":LTEST:COPY"](#) on page 601
 - [":LTEST:COPY:ALL"](#) on page 602
 - [":LTEST:COPY:MARGIN"](#) on page 603
 - [":LTEST:ENABLE"](#) on page 604
 - [":LTEST:FAIL"](#) on page 605
 - [":LTEST:LLIMIT"](#) on page 606
 - [":LTEST:MEASUREMENT"](#) on page 607
 - [":LTEST:RESULTS"](#) on page 608
 - [":LTEST:TEST"](#) on page 610
 - [":LTEST:ULIMIT"](#) on page 611

:LTEST:TEST

N (see [page 1730](#))

Command Syntax :LTEST:TEST {{0 | OFF} | {1 | ON}}

For the active measurement currently selected by the :LTEST:MEASUREMENT command, the :LTEST:TEST command enables or disables the limit test function on that measurement.

When any measurement has its limit test function enabled, the overall Limit Test feature is enabled.

The :LTEST:RESULTS? query returns nothing when :LTEST:TEST is OFF.

Query Syntax :LTEST:TEST?

The :LTEST:TEST? query returns the state of the TEST control for the active measurement currently selected by the :LTEST:MEASUREMENT command.

Return Format <setting><NL>

<setting> ::= {0 | 1}

- See Also**
- [":LTEST:COPY"](#) on page 601
 - [":LTEST:COPY:ALL"](#) on page 602
 - [":LTEST:COPY:MARGIN"](#) on page 603
 - [":LTEST:ENABLE"](#) on page 604
 - [":LTEST:FAIL"](#) on page 605
 - [":LTEST:LLIMIT"](#) on page 606
 - [":LTEST:MEASUREMENT"](#) on page 607
 - [":LTEST:RESULTS"](#) on page 608
 - [":LTEST:RUMODE:SOFAILURE"](#) on page 609
 - [":LTEST:ULIMIT"](#) on page 611

:LTEST:ULIMit

N (see [page 1730](#))

Command Syntax :LTEST:ULIMit <upper_value>
 <upper_value> ::= a real number in NR3 format

For the active measurement currently selected by the :LTEST:MEASurement command, the :LTEST:ULIMit (Upper LIMit) command sets the upper test limit.

Query Syntax :LTEST:ULIMit?

The :LTEST:ULIMit? query returns the current upper limit setting.

Return Format <upper_value><NL>

- See Also**
- [":LTEST:COPY"](#) on page 601
 - [":LTEST:COPY:ALL"](#) on page 602
 - [":LTEST:COPY:MARGin"](#) on page 603
 - [":LTEST:ENABLE"](#) on page 604
 - [":LTEST:FAIL"](#) on page 605
 - [":LTEST:LLIMit"](#) on page 606
 - [":LTEST:MEASurement"](#) on page 607
 - [":LTEST:RESults"](#) on page 608
 - [":LTEST:RUMode:SOFailure"](#) on page 609
 - [":LTEST:TEST"](#) on page 610

28 :MARKer Commands

Set and query the settings of X-axis markers (X1 and X2 cursors) and the Y-axis markers (Y1 and Y2 cursors). See "[Introduction to :MARKer Commands](#)" on page 615.

Table 118 :MARKer Commands Summary

Command	Query	Options and Query Returns
n/a	:MARKer:DYDX? (see page 616)	<return_value> ::= •Y/•X value in NR3 format
:MARKer:MODE <mode> (see page 617)	:MARKer:MODE? (see page 617)	<mode> ::= {OFF MEASurement MANual WAVeform BINary HEX}
:MARKer:X1:DISPlay {{0 OFF} {1 ON}} (see page 618)	:MARKer:X1:DISPlay? (see page 618)	<setting> ::= {0 1}
:MARKer:X1Position <position>[suffix] (see page 619)	:MARKer:X1Position? (see page 619)	<position> ::= X1 cursor position value in NR3 format [suffix] ::= {s ms us ns ps Hz kHz MHz} <return_value> ::= X1 cursor position value in NR3 format
:MARKer:X1Y1source <source> (see page 620)	:MARKer:X1Y1source? (see page 620)	<source> ::= {CHANnel<n> FUNCTION<m> MATH<m> WMEMory<r> HISTogram CGRade} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <return_value> ::= <source>
:MARKer:X2:DISPlay {{0 OFF} {1 ON}} (see page 621)	:MARKer:X2:DISPlay? (see page 621)	<setting> ::= {0 1}

Table 118 :MARKer Commands Summary (continued)

Command	Query	Options and Query Returns
:MARKer:X2Position <position>[suffix] (see page 622)	:MARKer:X2Position? (see page 622)	<position> ::= X2 cursor position value in NR3 format [suffix] ::= {s ms us ns ps Hz kHz MHz} <return_value> ::= X2 cursor position value in NR3 format
:MARKer:X2Y2source <source> (see page 623)	:MARKer:X2Y2source? (see page 623)	<source> ::= {CHANnel<n> FUNCTION<m> MATH<m> WMemory<r> HISTogram CGRade} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <return_value> ::= <source>
n/a	:MARKer:XDELta? (see page 624)	<return_value> ::= X cursors delta value in NR3 format
:MARKer:XUNits <mode> (see page 625)	:MARKer:XUNits? (see page 625)	<units> ::= {SEcOnDs HERTz DEGRees PERCent}
:MARKer:XUNits:USE (see page 626)	n/a	n/a
:MARKer:Y1:DISPlay {{0 OFF} {1 ON}} (see page 627)	:MARKer:Y1:DISPlay? (see page 627)	<setting> ::= {0 1}
:MARKer:Y1Position <position>[suffix] (see page 628)	:MARKer:Y1Position? (see page 628)	<position> ::= Y1 cursor position value in NR3 format [suffix] ::= {V mV dB} <return_value> ::= Y1 cursor position value in NR3 format
:MARKer:Y2:DISPlay {{0 OFF} {1 ON}} (see page 629)	:MARKer:Y2:DISPlay? (see page 629)	<setting> ::= {0 1}
:MARKer:Y2Position <position>[suffix] (see page 630)	:MARKer:Y2Position? (see page 630)	<position> ::= Y2 cursor position value in NR3 format [suffix] ::= {V mV dB} <return_value> ::= Y2 cursor position value in NR3 format

Table 118 :MARKer Commands Summary (continued)

Command	Query	Options and Query Returns
n/a	:MARKer:YDELta? (see page 631)	<return_value> ::= Y cursors delta value in NR3 format
:MARKer:YUNits <mode> (see page 632)	:MARKer:YUNits? (see page 632)	<units> ::= {BASE PERCent}
:MARKer:YUNits:USE (see page 633)	n/a	n/a

Introduction to :MARKer Commands The MARKer subsystem commands set and query the settings of X-axis markers (X1 and X2 cursors) and the Y-axis markers (Y1 and Y2 cursors). You can set and query the marker mode and source, the position of the X and Y cursors, and query delta X and delta Y cursor values.

Reporting the Setup

Use :MARKer? to query setup information for the MARKer subsystem.

Return Format

The following is a sample response from the :MARKer? query. In this case, the query was issued following a *RST and ":MARKer:MODE MANual" command.

```
:MARK:X1Y1 CHAN1;X2Y2 CHAN1;MODE MAN
```

:MARKer:DYDX

N (see [page 1730](#))

Query Syntax :MARKer:DYDX?

The MARKer:DYDX? query returns the cursor $\Delta Y/\Delta X$ value.

X cursor units are set by the :MARKer:XUNits command.

NOTE

If the front-panel cursors are off, the marker position values are not defined. Make sure to set :MARKer:MODE to MANual or WAVEform to put the cursors in the front-panel Normal mode.

Return Format <value><NL>

<value> ::= •Y/•X value in NR3 format.

- See Also**
- ["Introduction to :MARKer Commands"](#) on page 615
 - [":MARKer:MODE"](#) on page 617
 - [":MARKer:X1Position"](#) on page 619
 - [":MARKer:X2Position"](#) on page 622
 - [":MARKer:X1Y1source"](#) on page 620
 - [":MARKer:X2Y2source"](#) on page 623
 - [":MARKer:XUNits"](#) on page 625

:MARKer:MODE

N (see [page 1730](#))

Command Syntax :MARKer:MODE <mode>

<mode> ::= {OFF | MEASurement | MANual | WAVeform | BINary | HEX}

The :MARKer:MODE command sets the cursors mode:

- OFF – removes the cursor information from the display.
- MANual – enables manual placement of the X and Y cursors.

If the front-panel cursors are off, or are set to the front-panel Hex or Binary mode, setting :MARKer:MODE MANual will put the cursors in the front-panel Normal mode.

- MEASurement – cursors track the most recent measurement.

Setting the mode to MEASurement sets the marker sources (:MARKer:X1Y1source and :MARKer:X2Y2source) to the measurement source (:MEASure:SOURce). Setting the measurement source remotely always sets the marker sources.

- WAVeform – the Y1 cursor tracks the voltage value at the X1 cursor of the waveform specified by the X1Y1source, and the Y2 cursor does the same for the X2 cursor and its X2Y2source.
- BINary – logic levels of displayed waveforms at the current X1 and X2 cursor positions are displayed in the Cursor sidebar dialog in binary.
- HEX – logic levels of displayed waveforms at the current X1 and X2 cursor positions are displayed in the Cursor sidebar dialog in hexadecimal.

Query Syntax :MARKer:MODE?

The :MARKer:MODE? query returns the current cursors mode.

Return Format <mode><NL>

<mode> ::= {OFF | MEAS | MAN | WAV | BIN | HEX}

See Also • ["Introduction to :MARKer Commands"](#) on page 615

- [":MARKer:X1Y1source"](#) on page 620
- [":MARKer:X2Y2source"](#) on page 623
- [":MEASure:SOURce"](#) on page 727
- [":MARKer:X1Position"](#) on page 619
- [":MARKer:X2Position"](#) on page 622
- [":MARKer:Y1Position"](#) on page 628
- [":MARKer:Y2Position"](#) on page 630

:MARKer:X1:DISPlay

N (see [page 1730](#))

Command Syntax :MARKer:X1:DISPlay {{0 | OFF} | {1 | ON}}

The :MARKer:X1:DISPlay command specifies whether the X1 cursor is displayed.

Query Syntax :MARKer:X1:DISPlay?

The :MARKer:X1:DISPlay? query returns the X1 cursor display setting.

Return Format <setting><NL>

<setting> ::= {0 | 1}

See Also • [":MARKer:X1:DISPlay"](#) on page 618

:MARKer:X1Position

N (see [page 1730](#))

Command Syntax :MARKer:X1Position <position> [suffix]
 <position> ::= X1 cursor position in NR3 format
 <suffix> ::= {s | ms | us | ns | ps | Hz | kHz | MHz}

The :MARKer:X1Position command:

- Sets :MARKer:MODE to MANual if it is not currently set to WAVEform (see [":MARKer:MODE"](#) on page 617).
- Sets the X1 cursor position to the specified value.

X cursor units are set by the :MARKer:XUNits command.

Query Syntax :MARKer:X1Position?

The :MARKer:X1Position? query returns the current X1 cursor position. This is functionally equivalent to the obsolete :MEASure:TSTArt command/query.

NOTE

If the front-panel cursors are off, the marker position values are not defined and an error is generated. Make sure to set :MARKer:MODE to MANual or WAVEform to put the cursors in the front-panel Normal mode.

Return Format <position><NL>
 <position> ::= X1 cursor position in NR3 format

- See Also**
- ["Introduction to :MARKer Commands"](#) on page 615
 - [":MARKer:MODE"](#) on page 617
 - [":MARKer:X2Position"](#) on page 622
 - [":MARKer:X1Y1source"](#) on page 620
 - [":MARKer:X2Y2source"](#) on page 623
 - [":MARKer:XUNits"](#) on page 625
 - [":MEASure:TSTArt"](#) on page 1644

:MARKer:X1Y1source

N (see [page 1730](#))

Command Syntax :MARKer:X1Y1source <source>

```
<source> ::= {CHANnel<n> | FUNction<m> | MATH<m> | WMEMory<r>
             | HISTogram | CGRade}
```

```
<n> ::= 1 to (# analog channels) in NR1 format
```

```
<m> ::= 1 to (# math functions) in NR1 format
```

```
<r> ::= 1 to (# ref waveforms) in NR1 format
```

The :MARKer:X1Y1source command sets the source for the cursors. The channel you specify must be enabled for cursors to be displayed. If the channel or function is not on, an error message is issued.

If the marker mode is not currently WAVEform (see [":MARKer:MODE"](#) on page 617):

- Sending a :MARKer:X1Y1source command will put the cursors in the MANual mode.
- Setting the source for one pair of markers (for example, X1Y1) sets the source for the other (for example, X2Y2).

If the marker mode is currently WAVEform, the X1Y1 source can be set separate from the X2Y2 source.

If :MARKer:MODE is set to OFF or MANual, setting :MEASure:SOURce to CHANnel<n>, FUNction, MATH, or WMEMory<r> will also set :MARKer:X1Y1source and :MARKer:X2Y2source to this value.

NOTE

MATH is an alias for FUNction. The query will return FUNC if the source is FUNction or MATH.

Query Syntax :MARKer:X1Y1source?

The :MARKer:X1Y1source? query returns the current source for the cursors. If all channels are off, the query returns NONE.

Return Format <source><NL>

```
<source> ::= {CHAN<n> | FUNC | WMEM<r> | HIST | CGR | NONE}
```

- See Also**
- ["Introduction to :MARKer Commands"](#) on page 615
 - [":MARKer:MODE"](#) on page 617
 - [":MARKer:X2Y2source"](#) on page 623
 - [":MEASure:SOURce"](#) on page 727

:MARKer:X2:DISPlay

N (see [page 1730](#))

Command Syntax :MARKer:X2:DISPlay {{0 | OFF} | {1 | ON}}

The :MARKer:X2:DISPlay command specifies whether the X2 cursor is displayed.

Query Syntax :MARKer:X2:DISPlay?

The :MARKer:X2:DISPlay? query returns the X2 cursor display setting.

Return Format <setting><NL>

<setting> ::= {0 | 1}

See Also • [":MARKer:X2:DISPlay"](#) on page 621

:MARKer:X2Position

N (see [page 1730](#))

Command Syntax :MARKer:X2Position <position> [suffix]
 <position> ::= X2 cursor position in NR3 format
 <suffix> ::= {s | ms | us | ns | ps | Hz | kHz | MHz}

The :MARKer:X2Position command:

- Sets :MARKer:MODE to MANual if it is not currently set to WAVEform (see [":MARKer:MODE"](#) on page 617).
- Sets the X2 cursor position to the specified value.

X cursor units are set by the :MARKer:XUNits command.

Query Syntax :MARKer:X2Position?

The :MARKer:X2Position? query returns current X2 cursor position. This is functionally equivalent to the obsolete :MEASure:TSTOp command/query.

NOTE

If the front-panel cursors are off, the marker position values are not defined and an error is generated. Make sure to set :MARKer:MODE to MANual or WAVEform to put the cursors in the front-panel Normal mode.

Return Format <position><NL>
 <position> ::= X2 cursor position in NR3 format

- See Also**
- ["Introduction to :MARKer Commands"](#) on page 615
 - [":MARKer:MODE"](#) on page 617
 - [":MARKer:X1Position"](#) on page 619
 - [":MARKer:X2Y2source"](#) on page 623
 - [":MARKer:XUNits"](#) on page 625
 - [":MEASure:TSTOp"](#) on page 1645

:MARKer:X2Y2source

N (see [page 1730](#))

Command Syntax :MARKer:X2Y2source <source>

```
<source> ::= {CHANnel<n> | FUNction<m> | MATH<m> | WMEMory<r>
              | HISTogram | CGRade}
```

<n> ::= 1 to (# analog channels) in NR1 format

<m> ::= 1 to (# math functions) in NR1 format

<r> ::= 1 to (# ref waveforms) in NR1 format

The :MARKer:X2Y2source command sets the source for the cursors. The channel you specify must be enabled for cursors to be displayed. If the channel or function is not on, an error message is issued.

If the marker mode is not currently WAVEform (see [":MARKer:MODE"](#) on page 617):

- Sending a :MARKer:X2Y2source command will put the cursors in the MANual mode.
- Setting the source for one pair of markers (for example, X2Y2) sets the source for the other (for example, X1Y1).

If the marker mode is currently WAVEform, the X2Y2 source can be set separate from the X1Y1 source.

If :MARKer:MODE is set to OFF or MANual, setting :MEASure:SOURce to CHANnel<n>, FUNction, MATH, or WMEMory<r> will also set :MARKer:X1Y1source and :MARKer:X2Y2source to this value.

NOTE

MATH is an alias for FUNction. The query will return FUNC if the source is FUNction or MATH.

Query Syntax :MARKer:X2Y2source?

The :MARKer:X2Y2source? query returns the current source for the cursors. If all channels are off, the query returns NONE.

Return Format <source><NL>

```
<source> ::= {CHAN<n> | FUNC | WMEM<r> | HIST | CGR | NONE}
```

- See Also**
- ["Introduction to :MARKer Commands"](#) on page 615
 - [":MARKer:MODE"](#) on page 617
 - [":MARKer:X1Y1source"](#) on page 620
 - [":MEASure:SOURce"](#) on page 727

:MARKer:XDELta

N (see [page 1730](#))

Query Syntax :MARKer:XDELta?

The MARKer:XDELta? query returns the value difference between the current X1 and X2 cursor positions.

$Xdelta = (Value\ at\ X2\ cursor) - (Value\ at\ X1\ cursor)$

X cursor units are set by the :MARKer:XUNits command.

NOTE

If the front-panel cursors are off, the marker position values are not defined. Make sure to set :MARKer:MODE to MANual or WAVEform to put the cursors in the front-panel Normal mode.

Return Format <value><NL>

<value> ::= difference value in NR3 format.

- See Also**
- ["Introduction to :MARKer Commands"](#) on page 615
 - [":MARKer:MODE"](#) on page 617
 - [":MARKer:X1Position"](#) on page 619
 - [":MARKer:X2Position"](#) on page 622
 - [":MARKer:X1Y1source"](#) on page 620
 - [":MARKer:X2Y2source"](#) on page 623
 - [":MARKer:XUNits"](#) on page 625

:MARKer:XUNits

N (see [page 1730](#))

Command Syntax :MARKer:XUNits <units>

<units> ::= {SEConds | HERTz | DEGRees | PERCent}

The :MARKer:XUNits command sets the X cursors units:

- SEConds – for making time measurements.
- HERTz – for making frequency measurements.
- DEGRees – for making phase measurements. Use the :MARKer:XUNits:USE command to set the current X1 location as 0 degrees and the current X2 location as 360 degrees.
- PERCent – for making ratio measurements. Use the :MARKer:XUNits:USE command to set the current X1 location as 0 percent and the current X2 location as 100 percent.

Changing X units affects the input and output values of the :MARKer:X1Position, :MARKer:X2Position, and :MARKer:XDELta commands/queries.

Query Syntax :MARKer:XUNits?

The :MARKer:XUNits? query returns the current X cursors units.

Return Format <units><NL>

<units> ::= {SEC | HERT | DEGR | PERC}

- See Also**
- ["Introduction to :MARKer Commands"](#) on page 615
 - [":MARKer:XUNits:USE"](#) on page 626
 - [":MARKer:X1Y1source"](#) on page 620
 - [":MARKer:X2Y2source"](#) on page 623
 - [":MEASure:SOURce"](#) on page 727
 - [":MARKer:X1Position"](#) on page 619
 - [":MARKer:X2Position"](#) on page 622

:MARKer:XUNits:USE

N (see [page 1730](#))

Command Syntax `:MARKer:XUNits:USE`

When DEGRees is selected for :MARKer:XUNits, the :MARKer:XUNits:USE command sets the current X1 location as 0 degrees and the current X2 location as 360 degrees.

When PERCent is selected for :MARKer:XUNits, the :MARKer:XUNits:USE command sets the current X1 location as 0 percent and the current X2 location as 100 percent.

Once the 0 and 360 degree or 0 and 100 percent locations are set, inputs to and outputs from the :MARKer:X1Position, :MARKer:X2Position, and :MARKer:XDELta commands/queries are relative to the set locations.

- See Also**
- ["Introduction to :MARKer Commands"](#) on page 615
 - [":MARKer:XUNits"](#) on page 625
 - [":MARKer:X1Y1source"](#) on page 620
 - [":MARKer:X2Y2source"](#) on page 623
 - [":MEASure:SOURce"](#) on page 727
 - [":MARKer:X1Position"](#) on page 619
 - [":MARKer:X2Position"](#) on page 622
 - [":MARKer:XDELta"](#) on page 624

:MARKer:Y1:DISPlay

N (see [page 1730](#))

Command Syntax :MARKer:Y1:DISPlay {{0 | OFF} | {1 | ON}}

The :MARKer:Y1:DISPlay command specifies whether the Y1 cursor is displayed.

Query Syntax :MARKer:Y1:DISPlay?

The :MARKer:Y1:DISPlay? query returns the Y1 cursor display setting.

Return Format <setting><NL>

<setting> ::= {0 | 1}

See Also • [":MARKer:Y1:DISPlay"](#) on page 627

:MARKer:Y1Position

N (see [page 1730](#))

Command Syntax :MARKer:Y1Position <position> [suffix]

<position> ::= Y1 cursor position in NR3 format

<suffix> ::= {mV | V | dB}

If the :MARKer:MODE is not currently set to WAVEform (see [":MARKer:MODE"](#) on page 617), the :MARKer:Y1Position command:

- Sets :MARKer:MODE to MANual.
- Sets the Y1 cursor position to the specified value.

Y cursor units are set by the :MARKer:YUNits command.

When the :MARKer:MODE is set to WAVEform, Y positions cannot be set.

Query Syntax :MARKer:Y1Position?

The :MARKer:Y1Position? query returns current Y1 cursor position. This is functionally equivalent to the obsolete :MEASure:VStArt command/query.

NOTE

If the front-panel cursors are off or are set to Binary or Hex Mode, the marker position values are not defined and an error is generated. Make sure to set :MARKer:MODE to MANual or WAVEform to put the cursors in the front-panel Normal mode.

Return Format <position><NL>

<position> ::= Y1 cursor position in NR3 format

- See Also**
- ["Introduction to :MARKer Commands"](#) on page 615
 - [":MARKer:MODE"](#) on page 617
 - [":MARKer:X1Y1source"](#) on page 620
 - [":MARKer:X2Y2source"](#) on page 623
 - [":MARKer:Y2Position"](#) on page 630
 - [":MARKer:YUNits"](#) on page 632
 - [":MEASure:VStArt"](#) on page 1649

:MARKer:Y2:DISPlay

N (see [page 1730](#))

Command Syntax :MARKer:Y2:DISPlay {{0 | OFF} | {1 | ON}}

The :MARKer:Y2:DISPlay command specifies whether the Y2 cursor is displayed.

Query Syntax :MARKer:Y2:DISPlay?

The :MARKer:Y2:DISPlay? query returns the Y2 cursor display setting.

Return Format <setting><NL>

<setting> ::= {0 | 1}

See Also • [":MARKer:Y2:DISPlay"](#) on page 629

:MARKer:Y2Position

N (see [page 1730](#))

Command Syntax :MARKer:Y2Position <position> [suffix]

<position> ::= Y2 cursor position in NR3 format

<suffix> ::= {mV | V | dB}

If the :MARKer:MODE is not currently set to WAVEform (see [":MARKer:MODE"](#) on page 617), the :MARKer:Y2Position command:

- Sets :MARKer:MODE to MANual.
- Sets the Y2 cursor position to the specified value.

Y cursor units are set by the :MARKer:YUNits command.

When the :MARKer:MODE is set to WAVEform, Y positions cannot be set.

Query Syntax :MARKer:Y2Position?

The :MARKer:Y2Position? query returns current Y2 cursor position. This is functionally equivalent to the obsolete :MEASure:VSTop command/query.

NOTE

If the front-panel cursors are off or are set to Binary or Hex Mode, the marker position values are not defined and an error is generated. Make sure to set :MARKer:MODE to MANual or WAVEform to put the cursors in the front-panel Normal mode.

Return Format <position><NL>

<position> ::= Y2 cursor position in NR3 format

- See Also**
- ["Introduction to :MARKer Commands"](#) on page 615
 - [":MARKer:MODE"](#) on page 617
 - [":MARKer:X1Y1source"](#) on page 620
 - [":MARKer:X2Y2source"](#) on page 623
 - [":MARKer:Y1Position"](#) on page 628
 - [":MARKer:YUNits"](#) on page 632
 - [":MEASure:VSTop"](#) on page 1650

:MARKer:YDELta

N (see [page 1730](#))

Query Syntax :MARKer:YDELta?

The :MARKer:YDELta? query returns the value difference between the current Y1 and Y2 cursor positions.

Ydelta = (Value at Y2 cursor) - (Value at Y1 cursor)

NOTE

If the front-panel cursors are off or are set to Binary or Hex Mode, the marker position values are not defined. Make sure to set :MARKer:MODE to MANual or WAVEform to put the cursors in the front-panel Normal mode.

Y cursor units are set by the :MARKer:YUNits command.

Return Format <value><NL>

<value> ::= difference value in NR3 format

- See Also**
- ["Introduction to :MARKer Commands"](#) on page 615
 - [":MARKer:MODE"](#) on page 617
 - [":MARKer:X1Y1source"](#) on page 620
 - [":MARKer:X2Y2source"](#) on page 623
 - [":MARKer:Y1Position"](#) on page 628
 - [":MARKer:Y2Position"](#) on page 630
 - [":MARKer:YUNits"](#) on page 632

:MARKer:YUNits

N (see [page 1730](#))

Command Syntax :MARKer:YUNits <units>
 <units> ::= {BASE | PERCent}

The :MARKer:YUNits command sets the Y cursors units:

- BASE – for making measurements in the units associated with the cursors source.
- PERCent – for making ratio measurements. Use the :MARKer:YUNits:USE command to set the current Y1 location as 0 percent and the current Y2 location as 100 percent.

Changing Y units affects the input and output values of the :MARKer:Y1Position, :MARKer:Y2Position, and :MARKer:YDELta commands/queries.

Query Syntax :MARKer:YUNits?

The :MARKer:YUNits? query returns the current Y cursors units.

Return Format <units><NL>
 <units> ::= {BASE | PERC}

- See Also**
- ["Introduction to :MARKer Commands"](#) on page 615
 - [":MARKer:YUNits:USE"](#) on page 633
 - [":MARKer:X1Y1source"](#) on page 620
 - [":MARKer:X2Y2source"](#) on page 623
 - [":MEASure:SOURce"](#) on page 727
 - [":MARKer:Y1Position"](#) on page 628
 - [":MARKer:Y2Position"](#) on page 630
 - [":MARKer:YDELta"](#) on page 631

:MARKer:YUNits:USE

N (see [page 1730](#))

Command Syntax :MARKer:YUNits:USE

When PERCent is selected for :MARKer:YUNits, the :MARKer:YUNits:USE command sets the current Y1 location as 0 percent and the current Y2 location as 100 percent.

Once the 0 and 100 percent locations are set, inputs to and outputs from the :MARKer:Y1Position, :MARKer:Y2Position, and :MARKer:YDELta commands/queries are relative to the set locations.

- See Also**
- ["Introduction to :MARKer Commands"](#) on page 615
 - [":MARKer:YUNits"](#) on page 632
 - [":MARKer:X1Y1source"](#) on page 620
 - [":MARKer:X2Y2source"](#) on page 623
 - [":MEASure:SOURce"](#) on page 727
 - [":MARKer:Y1Position"](#) on page 628
 - [":MARKer:Y2Position"](#) on page 630
 - [":MARKer:YDELta"](#) on page 631

29 :MEASure Commands

Select automatic measurements to be made and control time markers. See "[Introduction to :MEASure Commands](#)" on page 658.

Table 119 :MEASure Commands Summary

Command	Query	Options and Query Returns
:MEASure:ALL (see page 660)	n/a	n/a
:MEASure:AREa [<interval>] [, <source>] >] (see page 661)	:MEASure:AREa? [<interval>] [, <source>] >] (see page 661)	<interval> ::= {CYCLe DISPlay} <source> ::= {CHANnel<n> FUNCTION<m> MATH<m> WMEMory<r>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <return_value> ::= area in volt-seconds, NR3 format

Table 119 :MEASure Commands Summary (continued)

Command	Query	Options and Query Returns
:MEASure:BRATe [<source>] (see page 662)	:MEASure:BRATe? [<source>] (see page 662)	<source> ::= {<digital channels> CHANnel<n> FUNCTion<m> MATH<m> WMEMory<r>} <digital channels> ::= DIGital<d> for the MSO models <d> ::= 0 to (# digital channels - 1) in NR1 format <n> ::= 1 to (# of analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <return_value> ::= bit rate in Hz, NR3 format
:MEASure:BWIDth [<source>] (see page 663)	:MEASure:BWIDth? [<source>] (see page 663)	<source> ::= {CHANnel<n> FUNCTion<m> MATH<m> WMEMory<r>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <return_value> ::= burst width in seconds, NR3 format
:MEASure:CLEar (see page 664)	n/a	n/a
:MEASure:COUNter [<source>] (see page 665)	:MEASure:COUNter? [<source>] (see page 665)	<source> ::= {CHANnel<n> EXTernal} for DSO models <source> ::= {CHANnel<n> DIGital<d> EXTernal} for MSO models <n> ::= 1 to (# analog channels) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format <return_value> ::= counter frequency in Hertz in NR3 format

Table 119 :MEASure Commands Summary (continued)

Command	Query	Options and Query Returns
:MEASure:CTCnwidth [<source>] (see page 667)	:MEASure:CTCnwidth? [<source>] (see page 667)	<source> ::= CHANnel<n> <n> ::= 1 to (# analog channels) in NR1 format <return_value> ::= -Width to -Width jitter in NR3 format
:MEASure:CTCPwidth [<source>] (see page 669)	:MEASure:CTCPwidth? [<source>] (see page 669)	<source> ::= CHANnel<n> <n> ::= 1 to (# analog channels) in NR1 format <return_value> ::= +Width to +Width jitter in NR3 format
:MEASure:DEFine DELay, <delay spec> (see page 671)	:MEASure:DEFine? DELay (see page 673)	<delay spec> ::= <edge_spec1>, <edge_spec2> edge_spec1 ::= [<slope>]<occurrence> edge_spec2 ::= [<slope>]<occurrence> <slope> ::= {+ -} <occurrence> ::= integer
:MEASure:DEFine THResholds, <threshold spec> (see page 671)	:MEASure:DEFine? THResholds (see page 673)	<threshold spec> ::= {STANdard} {<threshold mode>, <upper>, <middle>, <lower>} <threshold mode> ::= {PERCent ABSolute}
:MEASure:DELay [<source1> [, <source2>] (see page 674)	:MEASure:DELay? [<source1> [, <source2>] (see page 674)	<source1,2> ::= {CHANnel<n> FUNctIon<m> MATH<m> WMEMory<r> <digital channels>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <digital channels> ::= DIGital<d> for the MSO models <d> ::= 0 to (# digital channels - 1) in NR1 format <return_value> ::= floating-point number delay time in seconds in NR3 format

Table 119 :MEASure Commands Summary (continued)

Command	Query	Options and Query Returns
:MEASure:DElay:DEFine <source1_edge_slope>, <source1_edge_number> , <source1_edge_thresho ld>, <source2_edge_slope>, <source2_edge_number> , <source2_edge_thresho ld> (see page 676)	:MEASure:DElay:DEFine ? (see page 676)	<source1_edge_slope>, <source2_edge_slope> ::= {RISing FALLing} <source1_edge_number>, <source2_edge_number> ::= 0 to 1000 in NR1 format <source1_edge_threshold>, <source2_edge_threshold> ::= {LOWer MIDDle UPPer}
:MEASure:DUAL:CHARGE [<interval>] [,<source1>] [,<source 2>] (see page 677)	:MEASure:DUAL:CHARGE? [<interval>] [,<source1>] [,<source 2>] (see page 677)	<interval> ::= {CYCLE DISPLAY} <source1>,<source2> ::= CHANnel<n> with N2820A probe connected <n> ::= 1 to (# analog channels) in NR1 format <return_value> ::= area in Amp-hours, NR3 format
:MEASure:DUAL:VAMplit ude [<source1>] [,<source2 >] (see page 678)	:MEASure:DUAL:VAMplit ude? [<source1>] [,<source2 >] (see page 678)	<source1>,<source2> ::= CHANnel<n> with N2820A probe connected <n> ::= 1 to (# analog channels) in NR1 format <return_value> ::= the amplitude of the selected waveform in volts in NR3 format
:MEASure:DUAL:VAverage [<interval>] [,<source1>] [,<source 2>] (see page 679)	:MEASure:DUAL:VAverage ? [<interval>] [,<source1>] [,<source 2>] (see page 679)	<interval> ::= {CYCLE DISPLAY} <source1>,<source2> ::= CHANnel<n> with N2820A probe connected <n> ::= 1 to (# analog channels) in NR1 format <return_value> ::= calculated average voltage in NR3 format

Table 119 :MEASure Commands Summary (continued)

Command	Query	Options and Query Returns
:MEASure:DUAL:VBASE [<source1>] [, <source2 >] (see page 680)	:MEASure:DUAL:VBASE? [<source1>] [, <source2 >] (see page 680)	<source1>, <source2> ::= CHANnel<n> with N2820A probe connected <n> ::= 1 to (# analog channels) in NR1 format <base_voltage> ::= voltage at the base of the selected waveform in NR3 format
:MEASure:DUAL:VPP [<source1>] [, <source2 >] (see page 681)	:MEASure:DUAL:VPP? [<source1>] [, <source2 >] (see page 681)	<source1>, <source2> ::= CHANnel<n> with N2820A probe connected <n> ::= 1 to (# analog channels) in NR1 format <return_value> ::= voltage peak-to-peak of the selected waveform in NR3 format
:MEASure:DUAL:VRMS [<interval>] [, <type>] [, <source1>] [, <source 2>] (see page 682)	:MEASure:DUAL:VRMS? [<interval>] [, <type>] [, <source1>] [, <source 2>] (see page 682)	<interval> ::= {CYCLE DISPLAY} <type> ::= {AC DC} <source1>, <source2> ::= CHANnel<n> with N2820A probe connected <n> ::= 1 to (# analog channels) in NR1 format <return_value> ::= calculated RMS voltage in NR3 format

Table 119 :MEASure Commands Summary (continued)

Command	Query	Options and Query Returns
:MEASure:DUTYcycle [<source>] (see page 683)	:MEASure:DUTYcycle? [<source>] (see page 683)	<p><source> ::= {CHANnel<n> FUNCTION<m> MATH<m> WMemory<r>} for DSO models</p> <p><source> ::= {CHANnel<n> DIGital<d> FUNCTION<m> MATH<m> WMemory<r>} for MSO models</p> <p><n> ::= 1 to (# analog channels) in NR1 format</p> <p><m> ::= 1 to (# math functions) in NR1 format</p> <p><r> ::= 1 to (# ref waveforms) in NR1 format</p> <p><d> ::= 0 to (# digital channels - 1) in NR1 format</p> <p><return_value> ::= ratio of positive pulse width to period in NR3 format</p>
:MEASure:FALLtime [<source>] (see page 684)	:MEASure:FALLtime? [<source>] (see page 684)	<p><source> ::= {CHANnel<n> FUNCTION<m> MATH<m> WMemory<r>} for DSO models</p> <p><source> ::= {CHANnel<n> DIGital<d> FUNCTION<m> MATH<m> WMemory<r>} for MSO models</p> <p><n> ::= 1 to (# analog channels) in NR1 format</p> <p><m> ::= 1 to (# math functions) in NR1 format</p> <p><r> ::= 1 to (# ref waveforms) in NR1 format</p> <p><d> ::= 0 to (# digital channels - 1) in NR1 format</p> <p><return_value> ::= time in seconds between the lower and upper thresholds in NR3 format</p>

Table 119 :MEASure Commands Summary (continued)

Command	Query	Options and Query Returns
:MEASure:FFT:ACPR <chan_width>, <chan_spacing>, <chan>[,<source>] (see page 685)	:MEASure:FFT:ACPR? <chan_width>, <chan_spacing>, <chan>[,<source>] (see page 685)	<chan_width> ::= width of main range and sideband channels, Hz in NR3 format <chan_spacing> ::= spacing between main range and sideband channels, Hz in NR3 format <chan> ::= {CENTer HIGH<sb> LOW<sb>} <sb> ::= sideband 1 to 5 <source> ::= {FUNCTION<m> MATH<m> FFT} (source must be an FFT waveform) <m> ::= 1 to (# math functions) in NR1 format <return_value> ::= adjacent channel power ratio, dBV in NR3 format
:MEASure:FFT:CPOWER [<source>] (see page 686)	:MEASure:FFT:CPOWER? [<source>] (see page 686)	<source> ::= {FUNCTION<m> MATH<m> FFT} (source must be an FFT waveform) <m> ::= 1 to (# math functions) in NR1 format <return_value> ::= spectral channel power, dBV in NR3 format
:MEASure:FFT:OBW <percentage>[,<source>] >] (see page 687)	:MEASure:FFT:OBW? <percentage>[,<source>] >] (see page 687)	<percentage> ::= percent of spectral power occupied bandwidth is measured for in NR3 format <source> ::= {FUNCTION<m> MATH<m> FFT} (source must be an FFT waveform) <m> ::= 1 to (# math functions) in NR1 format <return_value> ::= occupied bandwidth, Hz in NR3 format

Table 119 :MEASure Commands Summary (continued)

Command	Query	Options and Query Returns
:MEASure:FFT:THD [<source>] (see page 688)	:MEASure:FFT:THD? [<source>] (see page 688)	<source> ::= {FUNCTION<m> MATH<m> FFT} (source must be an FFT waveform) <m> ::= 1 to (# math functions) in NR1 format <return_value> ::= total harmonic distortion ratio percent in NR3 format
:MEASure:FREQuency [<source>] (see page 689)	:MEASure:FREQuency? [<source>] (see page 689)	<source> ::= {CHANnel<n> FUNCTION<m> MATH<m> WMEMory<r>} for DSO models <source> ::= {CHANnel<n> DIGital<d> FUNCTION<m> MATH<m> WMEMory<r>} for MSO models <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format <return_value> ::= frequency in Hertz in NR3 format
n/a	:MEASure:HISTogram:BW IDth? (see page 690)	<value> ::= bin width in NR3 format
n/a	:MEASure:HISTogram:HI TS? (see page 691)	<value> ::= # of total hits in NR3 format
n/a	:MEASure:HISTogram:M1 S? (see page 692)	<value> ::= % of hits within +/-1 std dev in NR3 format
n/a	:MEASure:HISTogram:M2 S? (see page 693)	<value> ::= % of hits within +/-2 std devs in NR3 format
n/a	:MEASure:HISTogram:M3 S? (see page 694)	<value> ::= % of hits within +/-3 std devs in NR3 format
n/a	:MEASure:HISTogram:MA Ximum? (see page 695)	<value> ::= value of max bin in NR3 format
n/a	:MEASure:HISTogram:ME AN? (see page 696)	<value> ::= mean of histogram in NR3 format

Table 119 :MEASure Commands Summary (continued)

Command	Query	Options and Query Returns
n/a	:MEASure:HISTogram:ME Dian? (see page 697)	<value> ::= median of histogram in NR3 format
n/a	:MEASure:HISTogram:MI Nimum? (see page 698)	<value> ::= value of min bin in NR3 format
n/a	:MEASure:HISTogram:MO DE? (see page 699)	<value> ::= mode of histogram in NR3 format
n/a	:MEASure:HISTogram:PE AK? (see page 700)	<value> ::= # of hits in max bin in NR3 format
n/a	:MEASure:HISTogram:PP Eak? (see page 701)	<value> ::= delta value between max bin and min bin in NR3 format
n/a	:MEASure:HISTogram:SD EVIation? (see page 702)	<value> ::= standard deviation of histogram in NR3 format
:MEASure:NCJitter <config> (see page 703)	:MEASure:NCJitter? <config> (see page 704)	<config> ::= <source>, <direction>, <num_periods> <source> ::= {CHANnel<n> FUNctIon<m> MATH<m> WMEMemory<r>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <direction> ::= {RISing FALLing} <num_periods> ::= 1 to 10000 in NR1 format <return_value> ::= N-Period to N-Period jitter in NR3 format

Table 119 :MEASure Commands Summary (continued)

Command	Query	Options and Query Returns
:MEASure:NDUTy [<source>] (see page 705)	:MEASure:NDUTy? [<source>] (see page 705)	<source> ::= {CHANnel<n> FUNctIon<m> MATH<m> WMEMory<r>} for DSO models <source> ::= {CHANnel<n> DIGital<d> FUNctIon<m> MATH<m> WMEMory<r>} for MSO models <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format <return_value> ::= ratio of negative pulse width to period in NR3 format
:MEASure:NEDGes [<source>] (see page 706)	:MEASure:NEDGes? [<source>] (see page 706)	<source> ::= {CHANnel<n> FUNctIon<m> MATH<m> WMEMory<r>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <return_value> ::= the falling edge count in NR3 format

Table 119 :MEASure Commands Summary (continued)

Command	Query	Options and Query Returns
:MEASure:NPERiod <config> (see page 707)	:MEASure:NPERiod? <config> (see page 707)	<config> ::= <source>, <slope>, <num_periods> <source> ::= {CHANnel<n> FUNction<m> MATH<m> WMEMory<r>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <slope> ::= {RISing FALLing} <num_periods> ::= 1 to 10000 in NR1 format <return_value> ::= N-Period jitter in NR3 format
:MEASure:NPULses [<source>] (see page 708)	:MEASure:NPULses? [<source>] (see page 708)	<source> ::= {CHANnel<n> FUNction<m> MATH<m> WMEMory<r> <digital channels>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <digital channels> ::= DIGital<d> for the MSO models <d> ::= 0 to (# digital channels - 1) in NR1 format <return_value> ::= the falling pulse count in NR3 format

Table 119 :MEASure Commands Summary (continued)

Command	Query	Options and Query Returns
:MEASure:NWIDth [<source>] (see page 709)	:MEASure:NWIDth? [<source>] (see page 709)	<p><source> ::= {CHANnel<n> FUNCTION<m> MATH<m> WMEMory<r>} for DSO models</p> <p><source> ::= {CHANnel<n> DIGital<d> FUNCTION<m> MATH<m> WMEMory<r>} for MSO models</p> <p><n> ::= 1 to (# analog channels) in NR1 format</p> <p><m> ::= 1 to (# math functions) in NR1 format</p> <p><r> ::= 1 to (# ref waveforms) in NR1 format</p> <p><d> ::= 0 to (# digital channels - 1) in NR1 format</p> <p><return_value> ::= negative pulse width in seconds-NR3 format</p>
:MEASure:OVERshoot [<source>] (see page 710)	:MEASure:OVERshoot? [<source>] (see page 710)	<p><source> ::= {CHANnel<n> FUNCTION<m> MATH<m> WMEMory<r>} </p> <p><n> ::= 1 to (# analog channels) in NR1 format</p> <p><m> ::= 1 to (# math functions) in NR1 format</p> <p><r> ::= 1 to (# ref waveforms) in NR1 format</p> <p><return_value> ::= the percent of the overshoot of the selected waveform in NR3 format</p>
:MEASure:PEDGes [<source>] (see page 712)	:MEASure:PEDGes? [<source>] (see page 712)	<p><source> ::= {CHANnel<n> FUNCTION<m> MATH<m> WMEMory<r>} </p> <p><n> ::= 1 to (# analog channels) in NR1 format</p> <p><m> ::= 1 to (# math functions) in NR1 format</p> <p><r> ::= 1 to (# ref waveforms) in NR1 format</p> <p><return_value> ::= the rising edge count in NR3 format</p>

Table 119 :MEASure Commands Summary (continued)

Command	Query	Options and Query Returns
:MEASure:PERiod [<source>] (see page 713)	:MEASure:PERiod? [<source>] (see page 713)	<p><source> ::= {CHANnel<n> FUNCTION<m> MATH<m> WMEMory<r>} for DSO models</p> <p><source> ::= {CHANnel<n> DIGital<d> FUNCTION<m> MATH<m> WMEMory<r>} for MSO models</p> <p><n> ::= 1 to (# analog channels) in NR1 format</p> <p><m> ::= 1 to (# math functions) in NR1 format</p> <p><r> ::= 1 to (# ref waveforms) in NR1 format</p> <p><d> ::= 0 to (# digital channels - 1) in NR1 format</p> <p><return_value> ::= waveform period in seconds in NR3 format</p>
:MEASure:PHASe [<source1> [,<source2>] (see page 714)	:MEASure:PHASe? [<source1> [,<source2>] (see page 714)	<p><source1,2> ::= {CHANnel<n> FUNCTION<m> MATH<m> WMEMory<r>} </p> <p><n> ::= 1 to (# analog channels) in NR1 format</p> <p><m> ::= 1 to (# math functions) in NR1 format</p> <p><r> ::= 1 to (# ref waveforms) in NR1 format</p> <p><return_value> ::= the phase angle value in degrees in NR3 format</p>

Table 119 :MEASure Commands Summary (continued)

Command	Query	Options and Query Returns
:MEASure:PPULses [<source>] (see page 715)	:MEASure:PPULses? [<source>] (see page 715)	<source> ::= {CHANnel<n> FUNCTION<m> MATH<m> WMEMory<r> <digital channels>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <digital channels> ::= DIGital<d> for the MSO models <d> ::= 0 to (# digital channels - 1) in NR1 format <return_value> ::= the rising pulse count in NR3 format
:MEASure:PREShoot [<source>] (see page 716)	:MEASure:PREShoot? [<source>] (see page 716)	<source> ::= {CHANnel<n> FUNCTION<m> MATH<m> WMEMory<r>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <return_value> ::= the percent of preshoot of the selected waveform in NR3 format

Table 119 :MEASure Commands Summary (continued)

Command	Query	Options and Query Returns
:MEASure:PWIDth [<source>] (see page 717)	:MEASure:PWIDth? [<source>] (see page 717)	<source> ::= {CHANnel<n> FUNctIon<m> MATH<m> WMEMory<r>} for DSO models <source> ::= {CHANnel<n> DIGital<d> FUNctIon<m> MATH<m> WMEMory<r>} for MSO models <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format <return_value> ::= width of positive pulse in seconds in NR3 format
n/a	:MEASure:RESults? <result_list> (see page 718)	<result_list> ::= comma-separated list of measurement results
:MEASure:RISetime [<source>] (see page 721)	:MEASure:RISetime? [<source>] (see page 721)	<source> ::= {CHANnel<n> FUNctIon<m> MATH<m> WMEMory<r>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <return_value> ::= rise time in seconds in NR3 format
:MEASure:RTEYe:EHEigh t (see page 722)	:MEASure:RTEYe:EHEigh t? (see page 722)	<return_value> ::= eye opening height in NR3 format
:MEASure:RTEYe:EWIDth (see page 723)	:MEASure:RTEYe:EWIDth ? (see page 723)	<return_value> ::= eye opening width in NR3 format

Table 119 :MEASure Commands Summary (continued)

Command	Query	Options and Query Returns
:MEASure:SDEVIation [<source>] (see page 724)	:MEASure:SDEVIation? [<source>] (see page 724)	<source> ::= {CHANnel<n> FUNctIon<m> MATH<m> WMEMory<r>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <return_value> ::= calculated std deviation in NR3 format
:MEASure:SHOW {{0 OFF} {1 ON}} (see page 725)	:MEASure:SHOW? (see page 725)	{0 1}
:MEASure:SLEWrate [<source>[,<slope>]] (see page 726)	:MEASure:SLEWrate? [<source>[,<slope>]] (see page 726)	<source> ::= {CHANnel<n> FUNctIon<m> MATH<m> WMEMory<r>} <n> ::= 1 to (# of analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format
:MEASure:SOURce <source1> [,<source2>] (see page 727)	:MEASure:SOURce? (see page 727)	<source1,2> ::= {CHANnel<n> FUNctIon<m> MATH<m> WMEMory<r> EXTernal} for DSO models <source1,2> ::= {CHANnel<n> DIGital<d> FUNctIon<m> MATH<m> WMEMory<r> EXTernal} for MSO models <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format <return_value> ::= {<source> NONE}

Table 119 :MEASure Commands Summary (continued)

Command	Query	Options and Query Returns
:MEASure:STATistics <type> (see page 729)	:MEASure:STATistics? (see page 729)	<type> ::= {{ON 1} CURRENT MEAN MINimum MAXimum STDDev COUNT} ON ::= all statistics returned
:MEASure:STATistics:DISPlay {{0 OFF} {1 ON}} (see page 730)	:MEASure:STATistics:DISPlay? (see page 730)	{0 1}
:MEASure:STATistics:INCRement (see page 731)	n/a	n/a
:MEASure:STATistics:MCOUNT <setting> (see page 732)	:MEASure:STATistics:MCOUNT? (see page 732)	<setting> ::= {INFinite <count>} <count> ::= 2 to 2000 in NR1 format
:MEASure:STATistics:RESET (see page 733)	n/a	n/a
:MEASure:STATistics:RSDDeviation {{0 OFF} {1 ON}} (see page 734)	:MEASure:STATistics:RSDDeviation? (see page 734)	{0 1}

Table 119 :MEASure Commands Summary (continued)

Command	Query	Options and Query Returns
:MEASure:TEDGe [<slope>,<occurrence>[,<source>] (see page 735)	:MEASure:TEDGe? [<slope>,<occurrence>[,<source>] (see page 736)	<slope> ::= {RISing FALLing EITHER} <occurrence> ::= [+ -]<number> <number> ::= the edge number in NR1 format <source> ::= {<digital channels> CHANnel<n> FUNction<m> MATH<m> WMEMory<r>} <digital channels> ::= DIGital<d> for the MSO models <n> ::= 1 to (# of analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format <return_value> ::= time in seconds of the specified transition
:MEASure:TIEData <config> (see page 738)	:MEASure:TIEData? <config> (see page 738)	<config> ::= <source>, {SECond UNITinterval} <source> ::= {CHANnel<n> FUNction<m> MATH<m> WMEMory<r>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <return_value> ::= Clock TIE jitter in NR3 format

Table 119 :MEASure Commands Summary (continued)

Command	Query	Options and Query Returns
:MEASure:TIEClock <config> (see page 740)	:MEASure:TIEClock? <config> (see page 740)	<p><config> ::= <source>, {SECond UNITinterval}, <direction></p> <p><source> ::= {CHANnel<n> FUNction<m> MATH<m> WMEMory<r>}</p> <p><n> ::= 1 to (# analog channels) in NR1 format</p> <p><m> ::= 1 to (# math functions) in NR1 format</p> <p><r> ::= 1 to (# ref waveforms) in NR1 format</p> <p><direction> ::= {RISing FALLing BOTH}</p> <p><return_value> ::= Clock TIE jitter in NR3 format</p>
n/a	:MEASure:TVALue? <value>, [<slope>]<occurrence> [,<source>] (see page 742)	<p><value> ::= voltage level that the waveform must cross.</p> <p><slope> ::= direction of the waveform when <value> is crossed.</p> <p><occurrence> ::= transitions reported.</p> <p><source> ::= {CHANnel<n> FUNction<m> MATH<m> WMEMory<r>} for DSO models</p> <p><source> ::= {CHANnel<n> DIGital<d> FUNction<m> MATH<m> WMEMory<r>} for MSO models</p> <p><n> ::= 1 to (# analog channels) in NR1 format</p> <p><m> ::= 1 to (# math functions) in NR1 format</p> <p><r> ::= 1 to (# ref waveforms) in NR1 format</p> <p><d> ::= 0 to (# digital channels - 1) in NR1 format</p> <p><return_value> ::= time in seconds of specified voltage crossing in NR3 format</p>

Table 119 :MEASure Commands Summary (continued)

Command	Query	Options and Query Returns
:MEASure:VAMplitude [<source>] (see page 744)	:MEASure:VAMplitude? [<source>] (see page 744)	<source> ::= {CHANnel<n> FUNctIon<m> MATH<m> WMEMory<r>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <return_value> ::= the amplitude of the selected waveform in volts in NR3 format
:MEASure:VAverage [<interval>] [, <source >] (see page 745)	:MEASure:VAverage? [<interval>] [, <source >] (see page 745)	<interval> ::= {CYCLe DISPlay} <source> ::= {CHANnel<n> FUNctIon<m> MATH<m> WMEMory<r>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <return_value> ::= calculated average voltage in NR3 format
:MEASure:VBASe [<source>] (see page 746)	:MEASure:VBASe? [<source>] (see page 746)	<source> ::= {CHANnel<n> FUNctIon<m> MATH<m> WMEMory<r>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <base_voltage> ::= voltage at the base of the selected waveform in NR3 format

Table 119 :MEASure Commands Summary (continued)

Command	Query	Options and Query Returns
:MEASure:VMAX [<source>] (see page 747)	:MEASure:VMAX? [<source>] (see page 747)	<source> ::= {CHANnel<n> FUNction<m> MATH<m> WMEMory<r>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <return_value> ::= maximum voltage of the selected waveform in NR3 format
:MEASure:VMIN [<source>] (see page 748)	:MEASure:VMIN? [<source>] (see page 748)	<source> ::= {CHANnel<n> FUNction<m> MATH<m> WMEMory<r>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <return_value> ::= minimum voltage of the selected waveform in NR3 format
:MEASure:VPP [<source>] (see page 749)	:MEASure:VPP? [<source>] (see page 749)	<source> ::= {CHANnel<n> FUNction<m> MATH<m> WMEMory<r>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <return_value> ::= voltage peak-to-peak of the selected waveform in NR3 format

Table 119 :MEASure Commands Summary (continued)

Command	Query	Options and Query Returns
:MEASure:VRATio [<interval>] [, <source 1>] [, <source2>] (see page 750)	:MEASure:VRATio? [<interval>] [, <source 1>] [, <source2>] (see page 750)	<interval> ::= {CYCLe DISPlay} <source1,2> ::= {CHANnel<n> FUNctIon<m> MATH<m> WMEMory<r>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <return_value> ::= the ratio value in dB in NR3 format
:MEASure:VRMS [<interval>] [, <type>] [, <source>] (see page 751)	:MEASure:VRMS? [<interval>] [, <type>] [, <source>] (see page 751)	<interval> ::= {CYCLe DISPlay} <type> ::= {AC DC} <source> ::= {CHANnel<n> FUNctIon<m> MATH<m> WMEMory<r>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <return_value> ::= calculated dc RMS voltage in NR3 format
:MEASure:VTOP [<source>] (see page 752)	:MEASure:VTOP? [<source>] (see page 752)	<source> ::= {CHANnel<n> FUNctIon<m> MATH<m> WMEMory<r>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <return_value> ::= voltage at the top of the waveform in NR3 format
:MEASure:WINDow <type> (see page 753)	:MEASure:WINDow? (see page 753)	<type> ::= {MAIN ZOOM AUTO GATE}

Table 119 :MEASure Commands Summary (continued)

Command	Query	Options and Query Returns
:MEASure:XMAX [<source>] (see page 754)	:MEASure:XMAX? [<source>] (see page 754)	<source> ::= {CHANnel<n> FUNction<m> MATH<m> WMEMory<r>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <return_value> ::= horizontal value of the maximum in NR3 format

Table 119 :MEASure Commands Summary (continued)

Command	Query	Options and Query Returns
:MEASure:XMIN [<source>] (see page 755)	:MEASure:XMIN? [<source>] (see page 755)	<source> ::= {CHANnel<n> FUNction<m> MATH<m> WMEMemory<r>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <return_value> ::= horizontal value of the minimum in NR3 format
:MEASure:YATX <horiz_location>[,<so urce>] (see page 756)	:MEASure:YATX? <horiz_location>[,<so urce>] (see page 756)	<horiz_location> ::= displayed time from trigger in seconds in NR3 format <source> ::= {CHANnel<n> FUNction<m> MATH<m> WMEMemory<r>} for DSO models <source> ::= {CHANnel<n> DIGital<d> FUNction<m> MATH<m> WMEMemory<r>} for MSO models <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format <return_value> ::= voltage at the specified time in NR3 format

**Introduction to
:MEASure
Commands**

The commands in the MEASure subsystem are used to make parametric measurements on displayed waveforms.

Measurement Setup

To make a measurement, the portion of the waveform required for that measurement must be displayed on the oscilloscope screen.

Measurement Type	Portion of waveform that must be displayed
period, duty cycle, or frequency	at least one complete cycle
pulse width	the entire pulse
rise time	rising edge, top and bottom of pulse
fall time	falling edge, top and bottom of pulse

Measurement Error

If a measurement cannot be made (typically because the proper portion of the waveform is not displayed), the value +9.9E+37 is returned for that measurement.

Making Measurements

If more than one waveform, edge, or pulse is displayed, time measurements are made on the portion of the displayed waveform closest to the trigger reference (left, center, or right).

When making measurements in the zoomed (delayed) time base mode (:TIMebase:MODE WINDow), the oscilloscope will attempt to make the measurement inside the zoomed sweep window. If the measurement is an average and there are not three edges, the oscilloscope will revert to the mode of making the measurement at the start of the main sweep.

When the command form is used, the measurement result is displayed on the instrument. When the query form of these measurements is used, the measurement is made one time, and the measurement result is returned over the bus.

Measurements are made on the displayed waveforms specified by the :MEASure:SOURce command. The MATH source is an alias for the FUNCtion source.

Not all measurements are available on the digital channels or FFT (Fast Fourier Transform).

Reporting the Setup

Use the :MEASure? query to obtain setup information for the MEASure subsystem. (Currently, this is only :MEASure:SOURce.)

Return Format

The following is a sample response from the :MEASure? query. In this case, the query was issued following a *RST command.

```
:MEAS:SOUR CHAN1,CHAN2;STAT ON
```

:MEASure:ALL

N (see [page 1730](#))

Command Syntax :MEASure:ALL

This command installs a Snapshot All measurement on the screen.

See Also • ["Introduction to :MEASure Commands"](#) on page 658

:MEASure:AREa

N (see [page 1730](#))

Command Syntax :MEASure:AREa [<interval>][,<source>]
 <interval> ::= {CYCLe | DISPlay}
 <source> ::= {CHANnel<n> | FUNctIon<m> | MATH<m> | WMEMory<r>}
 <n> ::= 1 to (# analog channels) in NR1 format
 <m> ::= 1 to (# math functions) in NR1 format
 <r> ::= 1 to (# ref waveforms) in NR1 format

The :MEASure:AREa command installs an area measurement on screen. Area measurements show the area between the waveform and the ground level.

The <interval> option lets you specify the measurement interval: either an integral number of cycles, or the full screen. If <interval> is not specified, DISPlay is implied.

NOTE

This command is not available if the source is FFT (Fast Fourier Transform).

Query Syntax :MEASure:AREa? [<interval>][,<source>]

The :MEASure:AREa? query measures and returns the area value.

Return Format <value><NL>
 <value> ::= the area value in volt-seconds in NR3 format

See Also

- ["Introduction to :MEASure Commands"](#) on page 658
- [":MEASure:SOURce"](#) on page 727

:MEASure:BRATe

N (see [page 1730](#))

Command Syntax :MEASure:BRATe [<source>]

<source> ::= {<digital channels> | CHANnel<n> | FUNction<m> | MATH<m>
| WMEMory<r>}

<digital channels> ::= DIGital<d> for the MSO models

<d> ::= 0 to (# digital channels - 1) in NR1 format

<n> ::= 1 to (# of analog channels) in NR1 format

<m> ::= 1 to (# math functions) in NR1 format

<r> ::= 1 to (# ref waveforms) in NR1 format

The :MEASure:BRATe command installs a screen measurement and starts the bit rate measurement. If the optional source parameter is specified, the currently specified source is modified.

NOTE

This command is not available if the source is FFT (Fast Fourier Transform).

Query Syntax :MEASure:BRATe? [<source>]

The :MEASure:BRATe? query measures all positive and negative pulse widths on the waveform, takes the minimum value found of either width type and inverts that minimum width to give a value in Hertz.

Return Format <value><NL>

<value> ::= the bit rate value in Hertz

- See Also**
- ["Introduction to :MEASure Commands"](#) on page 658
 - [":MEASure:SOURce"](#) on page 727
 - [":MEASure:FREQuency"](#) on page 689
 - [":MEASure:PERiod"](#) on page 713

:MEASure:BWIDth

N (see [page 1730](#))

Command Syntax :MEASure:BWIDth [<source>]
 <source> ::= {CHANnel<n> | FUNction<m> | MATH<m> | WMEMory<r>}
 <n> ::= 1 to (# analog channels) in NR1 format
 <m> ::= 1 to (# math functions) in NR1 format
 <r> ::= 1 to (# ref waveforms) in NR1 format

The :MEASure:BWIDth command installs a burst width measurement on screen. If the optional source parameter is not specified, the current measurement source is used.

NOTE

This command is not available if the source is FFT (Fast Fourier Transform).

Query Syntax :MEASure:BWIDth? [<source>]

The :MEASure:BWIDth? query measures and returns the width of the burst on the screen.

The burst width is calculated as follows:

$$\text{burst width} = (\text{last edge on screen} - \text{first edge on screen})$$

Return Format <value><NL>
 <value> ::= burst width in seconds in NR3 format

- See Also**
- ["Introduction to :MEASure Commands"](#) on page 658
 - [":MEASure:SOURce"](#) on page 727

:MEASure:CLEar

N (see [page 1730](#))

Command Syntax :MEASure:CLEar

This command clears all selected measurements and markers from the screen.

See Also · ["Introduction to :MEASure Commands"](#) on page 658

:MEASure:COUNter

N (see [page 1730](#))

Command Syntax :MEASure:COUNter [<source>]
 <source> ::= {<digital channels> | CHANnel<n> | EXTeRnal}
 <digital channels> ::= DIGital<d> for the MSO models
 <n> ::= 1 to (# analog channels) in NR1 format
 <d> ::= 0 to (# digital channels - 1) in NR1 format

The :MEASure:COUNter command installs a screen measurement and starts a counter measurement. If the optional source parameter is specified, the current source is modified. Any channel except Math or Reference Waveforms may be selected for the source.

The counter measurement counts trigger level crossings within a certain amount of time (gate time) and displays the results in Hz.

The gate time is the horizontal range of the oscilloscope but is limited to ≥ 0.1 s and ≤ 10 s. Unlike other measurements, the Zoom horizontal timebase window does not gate the Counter measurement.

The Counter measurement can measure frequencies up to the bandwidth of the oscilloscope. The minimum frequency supported is $2.0 / \text{gateTime}$.

Only one counter measurement may be displayed at a time.

NOTE

This command is not available if the source is MATH.

Query Syntax :MEASure:COUNter? [<source>]

The :MEASure:COUNter? query measures and outputs the counter frequency of the specified source.

NOTE

The :MEASure:COUNter? query times out if the counter measurement is installed on the front panel. Use :MEASure:CLEar to remove the front-panel measurement before executing the :MEASure:COUNter? query.

Return Format <source><NL>
 <source> ::= count in Hertz in NR3 format

- See Also**
- ["Introduction to :MEASure Commands"](#) on page 658
 - [":MEASure:SOURce"](#) on page 727

- **":MEASure:FREQuency"** on page 689
- **":MEASure:CLEar"** on page 664

:MEASure:CTCNwidth

N (see [page 1730](#))

Command Syntax

NOTE

This measurement is available when the optional jitter analysis feature is licensed


```
:MEASure:CTCNwidth [<source>]
```

```
<source> ::= CHANnel<n>
```

```
<n> ::= 1 to (# analog channels) in NR1 format
```

The :MEASure:CTCNwidth command installs a -Width to -Width (cycle-to-cycle negative width) jitter measurement on screen.

The -Width to -Width jitter measurement subtracts the first cycle's negative pulse width from the second cycle's negative pulse width for the first measurement result. Then, the second cycle's negative pulse width is subtracted from the third cycle's negative pulse width for the second measurement result, and so on, until all of the cycles of the waveform have been measured. The following figure shows the first two -Width to -Width measurements.



All of the measurement results are used to compute the statistics. The statistics are the values accumulated over all of the trigger cycles that have occurred.

The measurement is made on all the cycles of the waveform. Even in Zoom mode, all the cycles of the waveform in the Main window will be measured.

Query Syntax :MEASure:CTCNwidth? [<source>]

The :MEASure:CTCNwidth? query measures and returns the -Width to -Width jitter value.

Return Format <value><NL>

`<value> ::= -Width to -Width jitter in NR3 format`

- See Also**
- [":MEASure:CTCPwidth"](#) on page 669
 - [Chapter 25](#), “:JITTer Commands,” starting on page 575

:MEASure:CTCPwidth

N (see [page 1730](#))

Command Syntax

NOTE

This measurement is available when the optional jitter analysis feature is licensed


```
:MEASure:CTCPwidth [<source>]
```

```
<source> ::= CHANnel<n>
```

```
<n> ::= 1 to (# analog channels) in NR1 format
```


The :MEASure:CTCPwidth command installs a +Width to +Width (cycle-to-cycle positive width) jitter measurement on screen.

The +Width to +Width jitter measurement subtracts the first cycle's positive pulse width from the second cycle's positive pulse width for the first measurement result. Then, the second cycle's positive pulse width is subtracted from the third cycle's positive pulse width for the second measurement result, and so on, until all of the cycles of the waveform have been measured. The following figure shows the first two +Width to +Width measurements.



+Width1 +Width2

1st Measurement = +Width2 - +Width1



+Width2 +Width3

2nd Measurement = +Width3 - +Width2

All of the measurement results are used to compute the statistics. The statistics are the values accumulated over all of the trigger cycles that have occurred.

The measurement is made on all the cycles of the waveform. Even in Zoom mode, all the cycles of the waveform in the Main window will be measured.

Query Syntax :MEASure:CTCPwidth? [<source>]

The :MEASure:CTCPwidth? query measures and returns the +Width to +Width jitter value.

Return Format <value><NL>

`<value> ::= +Width to +Width jitter in NR3 format`

- See Also**
- [":MEASure:CTCNwidth"](#) on page 667
 - [Chapter 25](#), “:JITTer Commands,” starting on page 575

:MEASure:DEFine

N (see [page 1730](#))

Command Syntax :MEASure:DEFine <meas_spec>[,<source>]

<meas_spec> ::= {DElay | THResholds}, for remaining syntax, see:

- [":MEASure:DEFine DELay Command Syntax"](#) on page 671
- [":MEASure:DEFine THResholds Command Syntax"](#) on page 672

The :MEASure:DEFine command sets up the definition for measurements by specifying the delta time or threshold values. Changing these values may affect the results of other measure commands. The table below identifies which measurement results that can be affected by redefining the DELay specification or the THResholds values. For example, changing the THResholds definition from the default 10%, 50%, and 90% values may change the returned measurement result.

MEASure Command	DElay	THResholds
DUTYcycle		x
DElay	x	x
FALLtime		x
FREQuency		x
NWIDth		x
OVERshoot		x
PERiod		x
PHASe		x
PREShoot		x
PWIDth		x
RISetime		x
VAVerage		x
VRMS		x

:MEASure:DEFine
DElay Command
Syntax

NOTE

The DELay portion of the MEASure:DEFine command has been deprecated, and you should instead use the :MEASure:DElay:DEFine command to specify delay measurement parameters. The delay measurement now allows an edge occurrence of zero (0) to specify automatic edge selection. The limitation of this command is that you cannot specify a negative slope with an occurrence count of zero (0).

```

:MEASure:DEFine DELay,<delay spec>[,<source>]
<delay spec> ::= <edge_spec1>,<edge_spec2>
<edge_spec1> ::= [<slope>]<occurrence>
<edge_spec2> ::= [<slope>]<occurrence>
<slope> ::= {+ | -}
<occurrence> ::= integer
<source> ::= {CHANnel<n> | FUNCTION<m> | MATH<m> | WMEMory<r>}
<n> ::= 1 to (# analog channels) in NR1 format
<m> ::= 1 to (# math functions) in NR1 format
<r> ::= 1 to (# ref waveforms) in NR1 format

```

This command defines the behavior of the :MEASure:DELay command/query by specifying the start and stop edge to be used. <edge_spec1> specifies the slope and edge number on source1. <edge_spec2> specifies the slope and edge number on source2. The measurement is taken as:

$$\text{delay} = t(\text{<edge_spec2>}) - t(\text{<edge_spec1>})$$

:MEASure:DEFine THResholds Command Syntax

```

:MEASure:DEFine THResholds,<threshold spec>[,<source>]
<threshold spec> ::= {STANdard
                    | {<threshold mode>,<upper>,<middle>,<lower>}}
<threshold mode> ::= {PERCent | ABSolute}

```

for <threshold mode> = PERCent:

```

<upper>,<middle>,<lower> ::= A number specifying the upper, middle,
                           and lower threshold percentage values
                           between Vbase and Vtop in NR3 format.

```

for <threshold mode> = ABSolute:

```

<upper>,<middle>,<lower> ::= A number specifying the upper, middle,
                           and lower threshold absolute values in
                           NR3 format.

```

```

<source> ::= {CHANnel<n> | FUNCTION<m> | MATH<m> | WMEMory<r>}
<n> ::= 1 to (# analog channels) in NR1 format
<m> ::= 1 to (# math functions) in NR1 format
<r> ::= 1 to (# ref waveforms) in NR1 format

```

- STANdard threshold specification sets the lower, middle, and upper measurement thresholds to 10%, 50%, and 90% values between Vbase and Vtop.
- Threshold mode PERCent sets the measurement thresholds to any user-defined percentages between 5% and 95% of values between Vbase and Vtop.

- Threshold mode ABSolute sets the measurement thresholds to absolute values. ABSolute thresholds are dependent on channel scaling (:CHANnel<n>:RANGe or :CHANnel<n>:SCALE), probe attenuation (:CHANnel<n>:PROBe), and probe units (:CHANnel<n>:UNITs). Always set these values first before setting ABSolute thresholds.

Query Syntax :MEASure:DEFine? <meas_spec>[,<source>]

<meas_spec> ::= {DELay | THResholds}

The :MEASure:DEFine? query returns the current edge specification for the delay measurements setup or the current specification for the thresholds setup.

Return Format for <meas_spec> = DELay:

{ <edge_spec1> | <edge_spec2> | <edge_spec1>,<edge_spec2>} <NL>

for <meas_spec> = THResholds and <threshold mode> = PERCent:

THR, PERC, <upper>, <middle>, <lower><NL>

<upper>, <middle>, <lower> ::= A number specifying the upper, middle, and lower threshold percentage values between Vbase and Vtop in NR3 format.

for <meas_spec> = THResholds and <threshold mode> = ABSolute:

THR, ABS, <upper>, <middle>, <lower><NL>

<upper>, <middle>, <lower> ::= A number specifying the upper, middle, and lower threshold voltages in NR3 format.

for <threshold spec> = STANdard:

THR, PERC, +90.0, +50.0, +10.0

- See Also**
- ["Introduction to :MEASure Commands"](#) on page 658
 - [":MEASure:DELay"](#) on page 674
 - [":MEASure:DELay:DEFine"](#) on page 676
 - [":MEASure:SOURce"](#) on page 727
 - [":CHANnel<n>:RANGe"](#) on page 378
 - [":CHANnel<n>:SCALE"](#) on page 379
 - [":CHANnel<n>:PROBe"](#) on page 362
 - [":CHANnel<n>:UNITs"](#) on page 380

:MEASure:DELAy

N (see [page 1730](#))

Command Syntax :MEASure:DELAy [<edge_select_mode>] [,] [<source1>] [, <source2>]

```
<edge_select_mode> ::= {MANual | AUTO}
<source1>, <source2> ::= {CHANnel<n> | FUNction<m> | MATH<m>
    | WMEMory<r> | <digital channels>}
<n> ::= 1 to (# analog channels) in NR1 format
<m> ::= 1 to (# math functions) in NR1 format
<r> ::= 1 to (# ref waveforms) in NR1 format
<digital channels> ::= DIGital<d> for the MSO models
<d> ::= 0 to (# digital channels - 1) in NR1 format
```

The :MEASure:DELAy command places the instrument in the continuous measurement mode and starts a delay measurement.

The measurement is taken as:

$$\text{delay} = t(\text{<edge_spec_2>}) - t(\text{<edge_spec_1>})$$

where the <edge_spec> definitions are determined by the <edge_select_mode> and the :MEASure:DELAy:DEFine command.

When the <edge_select_mode> is:

- AUTO – edges are automatically selected: the source1 edge closest to the timebase reference point is used, and the source2 edge closest to the source1 edge is used.
- MANual – edge numbers are determined by the :MEASure:DELAy:DEFine settings.

Edge numbers greater than zero (0) are counted from the left side of the display for both sources.

Edge thresholds and slopes are always determined by the :MEASure:DELAy:DEFine settings.

If the <edge_select_mode> is not included with the command, AUTO is the default.

Query Syntax :MEASure:DELAy? [<edge_select_mode>] [,] [<source1>] [, <source2>]

The :MEASure:DELAy? query measures and returns the delay between source1 and source2. Delay measurement threshold, slope, and edge count parameters are determined by the <edge_select_mode> and the :MEASure:DELAy:DEFine command.

The <edge_select_mode> definitions are the same as with the command syntax.

However, if the `<edge_select_mode>` is not included with the query, `MANual` is the default.

In the `:MEASure:DEFine` command, you can set upper, middle, and lower threshold values. The standard upper, middle, and lower measurement thresholds are 90%, 50%, and 10% values between `Vbase` and `Vtop`.

Return Format

`<value><NL>`

`<value> ::= floating-point number delay time in seconds in NR3 format`

- See Also**
- ["Introduction to :MEASure Commands"](#) on page 658
 - [":MEASure:DElay:DEFine"](#) on page 676
 - [":MEASure:DEFine"](#) on page 671
 - [":MEASure:PHASe"](#) on page 714

:MEASure:DELAy:DEFine

N (see [page 1730](#))

Command Syntax :MEASure:DELAy:DEFine <source1_edge_slope>, <source1_edge_number>,
<source1_edge_threshold>, <source2_edge_slope>,
<source2_edge_number>, <source2_edge_threshold>

```
<source1_edge_slope>,  
<source2_edge_slope> ::= {RISing | FALLing}  
  
<source1_edge_number>,  
<source2_edge_number> ::= 0 to 1000 in NR1 format  
  
<source1_edge_threshold>,  
<source2_edge_threshold> ::= {LOWer | MIDDle | UPPer}
```

The :MEASure:DELAy:DEFine command defines slope directions and edge numbers for the delay measurement started or returned by the :MEASure:DELAy command. The :MEASure:DELAy:DEFine command also defines edge position parameters.

A <source1_edge_number> setting of zero (0) specifies that the edge closest to the timebase reference point automatically be selected. In this case, the <source2_edge_number> setting must also be zero (0), and the source2 edge closest to the selected source1 edge is used.

When edge numbers greater than zero (0) are specified, edges are counted from the left side of the display for both sources.

The selection of the source1 and source2 waveforms is made in the :MEASure:DELAy or :MEASure:SOURce commands.

Query Syntax :MEASure:DELAy:DEFine?

The :MEASure:DELAy:DEFine? query returns the specified delay measurement parameter definitions.

Return Format <source1_edge_slope>, <source1_edge_number>,
<source1_edge_threshold>, <source2_edge_slope>,
<source2_edge_number>,<source2_edge_threshold><NL>

<source1_edge_slope>,
<source2_edge_slope> ::= {RIS | FALL}

<source1_edge_number>,
<source2_edge_number> ::= 0 to 1000 in NR1 format

<source1_edge_threshold>,
<source2_edge_threshold> ::= {LOW | MIDD | UPP}

- See Also**
- [":MEASure:DELAy"](#) on page 674
 - [":MEASure:SOURce"](#) on page 727
 - [":MEASure:DEFine"](#) on page 671

:MEASure:DUAL:CHARge

N (see [page 1730](#))

Overview This measurement is available with the N2820A high sensitivity current probe when both the Primary and Secondary probe cables are used. This measurement joins the Zoom In waveform data below the probe's clamp level with Zoom Out waveform data above the probe's clamp level to create the waveform on which the measurement is made.

Command Syntax :MEASure:DUAL:CHARge [<interval>] [, <source1>] [, <source2>]
 <interval> ::= {CYCLe | DISPlay}
 <source1>, <source2> ::= CHANnel<n> with N2820A probe connected
 <n> ::= 1 to (# analog channels) in NR1 format

The :MEASure:DUAL:CHARge command installs a charge measurement on screen. Charge measurements show the area between the waveform and the ground level.

The <interval> option lets you specify the measurement interval: either an integral number of cycles, or the full screen. If <interval> is not specified, DISPlay is implied.

If the optional source parameter(s) are specified, the currently specified source(s) are modified.

Query Syntax :MEASure:DUAL:CHARge? [<interval>] [, <source1>] [, <source2>]

The :MEASure:DUAL:CHARge? query measures and returns the charge measurement value.

Return Format <value><NL>
 <value> ::= the charge value in Amp-hours in NR3 format

- See Also**
- [":MEASure:DUAL:VAMPLitude"](#) on page 678
 - [":MEASure:DUAL:VAverage"](#) on page 679
 - [":MEASure:DUAL:VBASe"](#) on page 680
 - [":MEASure:DUAL:VPP"](#) on page 681
 - [":MEASure:DUAL:VRMS"](#) on page 682
 - ["Introduction to :MEASure Commands"](#) on page 658
 - [":MEASure:SOURce"](#) on page 727

:MEASure:DUAL:VAMplitude

N (see [page 1730](#))

Overview This measurement is available with the N2820A high sensitivity current probe when both the Primary and Secondary probe cables are used. This measurement joins the Zoom In waveform data below the probe's clamp level with Zoom Out waveform data above the probe's clamp level to create the waveform on which the measurement is made.

Command Syntax :MEASure:DUAL:VAMplitude [<source1>] [,<source2>]
 <source1>,<source2> ::= CHANnel<n> with N2820A probe connected
 <n> ::= 1 to (# analog channels) in NR1 format

The :MEASure:DUAL:VAMplitude command installs a screen measurement and starts a vertical amplitude measurement.

If the optional source parameter(s) are specified, the currently specified source(s) are modified.

Query Syntax :MEASure:DUAL:VAMplitude? [<source1>] [,<source2>]

The :MEASure:DUAL:VAMplitude? query measures and returns the vertical amplitude of the waveform. To determine the amplitude, the instrument measures Vtop and Vbase, then calculates the amplitude as follows:

$$\text{vertical amplitude} = V_{\text{top}} - V_{\text{base}}$$

Return Format <value><NL>
 <value> ::= the amplitude of the selected waveform in NR3 format

- See Also**
- [":MEASure:DUAL:CHARge"](#) on page 677
 - [":MEASure:DUAL:VAverage"](#) on page 679
 - [":MEASure:DUAL:VBASe"](#) on page 680
 - [":MEASure:DUAL:VPP"](#) on page 681
 - [":MEASure:DUAL:VRMS"](#) on page 682
 - ["Introduction to :MEASure Commands"](#) on page 658
 - [":MEASure:SOURce"](#) on page 727
 - [":MEASure:VTOP"](#) on page 752

:MEASure:DUAL:VAverage

N (see [page 1730](#))

Overview This measurement is available with the N2820A high sensitivity current probe when both the Primary and Secondary probe cables are used. This measurement joins the Zoom In waveform data below the probe's clamp level with Zoom Out waveform data above the probe's clamp level to create the waveform on which the measurement is made.

Command Syntax :MEASure:DUAL:VAverage [<interval>] [,<source1>] [,<source2>]
 <interval> ::= {CYCLe | DISPlay}
 <source1>,<source2> ::= CHANnel<n> with N2820A probe connected
 <n> ::= 1 to (# analog channels) in NR1 format

The :MEASure:DUAL:VAverage command installs a screen measurement and starts an average value measurement.

The <interval> option lets you specify the measurement interval: either an integral number of cycles, or the full screen. If <interval> is not specified, DISPlay is implied.

If the optional source parameter(s) are specified, the currently specified source(s) are modified.

Query Syntax :MEASure:DUAL:VAverage? [<interval>] [,<source1>] [,<source2>]

The :MEASure:DUAL:VAverage? query returns the average value measurement.

Return Format <value><NL>
 <value> ::= calculated average value in NR3 format

- See Also**
- [":MEASure:DUAL:CHARge"](#) on page 677
 - [":MEASure:DUAL:VAMPLitude"](#) on page 678
 - [":MEASure:DUAL:VBASe"](#) on page 680
 - [":MEASure:DUAL:VPP"](#) on page 681
 - [":MEASure:DUAL:VRMS"](#) on page 682
 - ["Introduction to :MEASure Commands"](#) on page 658
 - [":MEASure:SOURce"](#) on page 727

:MEASure:DUAL:VBASe

N (see [page 1730](#))

Overview This measurement is available with the N2820A high sensitivity current probe when both the Primary and Secondary probe cables are used. This measurement joins the Zoom In waveform data below the probe's clamp level with Zoom Out waveform data above the probe's clamp level to create the waveform on which the measurement is made.

Command Syntax :MEASure:DUAL:VBASe [<source1>] [, <source2>]

<source1>, <source2> ::= CHANnel<n> with N2820A probe connected

<n> ::= 1 to (# analog channels) in NR1 format

The :MEASure:DUAL:VBASe command installs a screen measurement and starts a waveform base value measurement.

If the optional source parameter(s) are specified, the currently specified source(s) are modified.

Query Syntax :MEASure:DUAL:VBASe? [<source1>] [, <source2>]

The :MEASure:DUAL:VBASe? query returns the vertical value at the base of the waveform. The base value of a pulse is normally not the same as the minimum value.

Return Format <base_voltage><NL>

<base_voltage> ::= value at the base of the selected waveform in NR3 format

- See Also**
- [":MEASure:DUAL:CHARge"](#) on page 677
 - [":MEASure:DUAL:VAMPLitude"](#) on page 678
 - [":MEASure:DUAL:VAverage"](#) on page 679
 - [":MEASure:DUAL:VPP"](#) on page 681
 - [":MEASure:DUAL:VRMS"](#) on page 682
 - ["Introduction to :MEASure Commands"](#) on page 658
 - [":MEASure:SOURce"](#) on page 727
 - [":MEASure:VTOP"](#) on page 752
 - [":MEASure:VMIN"](#) on page 748

:MEASure:DUAL:VPP

N (see [page 1730](#))

Overview This measurement is available with the N2820A high sensitivity current probe when both the Primary and Secondary probe cables are used. This measurement joins the Zoom In waveform data below the probe's clamp level with Zoom Out waveform data above the probe's clamp level to create the waveform on which the measurement is made.

Command Syntax :MEASure:DUAL:VPP [<source1>] [,<source2>]
 <source1>,<source2> ::= CHANnel<n> with N2820A probe connected
 <n> ::= 1 to (# analog channels) in NR1 format

The :MEASure:DUAL:VPP command installs a screen measurement and starts a vertical peak-to-peak measurement.

If the optional source parameter(s) are specified, the currently specified source(s) are modified.

Query Syntax :MEASure:DUAL:VPP? [<source1>] [,<source2>]

The :MEASure:DUAL:VPP? query measures the maximum and minimum vertical value for the selected source, then calculates the vertical peak-to-peak value and returns that value. The peak-to-peak value (Vpp) is calculated with the following formula:

$$V_{pp} = V_{max} - V_{min}$$

Vmax and Vmin are the vertical maximum and minimum values present on the selected source.

Return Format <value><NL>
 <value> ::= vertical peak to peak value in NR3 format

- See Also**
- [":MEASure:DUAL:CHARge"](#) on page 677
 - [":MEASure:DUAL:VAMplitude"](#) on page 678
 - [":MEASure:DUAL:VAverage"](#) on page 679
 - [":MEASure:DUAL:VBASe"](#) on page 680
 - [":MEASure:DUAL:VRMS"](#) on page 682
 - ["Introduction to :MEASure Commands"](#) on page 658
 - [":MEASure:SOURce"](#) on page 727
 - [":MEASure:VMAX"](#) on page 747
 - [":MEASure:VMIN"](#) on page 748

:MEASure:DUAL:VRMS

N (see [page 1730](#))

Overview This measurement is available with the N2820A high sensitivity current probe when both the Primary and Secondary probe cables are used. This measurement joins the Zoom In waveform data below the probe's clamp level with Zoom Out waveform data above the probe's clamp level to create the waveform on which the measurement is made.

Command Syntax :MEASure:DUAL:VRMS [<interval>] [, <type>] [, <source1>] [, <source2>]

<interval> ::= {CYCLe | DISPlay}

<type> ::= {AC | DC}

<source1>, <source2> ::= CHANnel<n> with N2820A probe connected

<n> ::= 1 to (# analog channels) in NR1 format

The :MEASure:DUAL:VRMS command installs a screen measurement and starts an RMS value measurement.

The <interval> option lets you specify the measurement interval: either an integral number of cycles, or the full screen. If <interval> is not specified, DISPlay is implied.

The <type> option lets you choose between a DC RMS measurement and an AC RMS measurement. If <type> is not specified, DC is implied.

If the optional source parameter(s) are specified, the currently specified source(s) are modified.

Query Syntax :MEASure:DUAL:VRMS? [<interval>] [, <type>] [, <source1>] [, <source2>]

The :MEASure:DUAL:VRMS? query measures and outputs the RMS value measurement.

Return Format <value><NL>

<value> ::= calculated dc RMS value in NR3 format

- See Also**
- [":MEASure:DUAL:CHARge"](#) on page 677
 - [":MEASure:DUAL:VAMPLitude"](#) on page 678
 - [":MEASure:DUAL:VAverage"](#) on page 679
 - [":MEASure:DUAL:VBASe"](#) on page 680
 - [":MEASure:DUAL:VPP"](#) on page 681
 - ["Introduction to :MEASure Commands"](#) on page 658
 - [":MEASure:SOURce"](#) on page 727

:MEASure:DUTYcycle

C (see [page 1730](#))

Command Syntax :MEASure:DUTYcycle [<source>]

<source> ::= {<digital channels> | CHANnel<n> | FUNction<m> | MATH<m>
| WMEMory<r>}

<digital channels> ::= DIGital<d> for the MSO models

<d> ::= 0 to (# digital channels - 1) in NR1 format

<n> ::= 1 to (# of analog channels) in NR1 format

<m> ::= 1 to (# math functions) in NR1 format

<r> ::= 1 to (# ref waveforms) in NR1 format

The :MEASure:DUTYcycle command installs a screen measurement and starts a positive duty cycle measurement on the current :MEASure:SOURce. If the optional source parameter is specified, the current source is modified.

NOTE

The signal must be displayed to make the measurement. This command is not available if the source is FFT (Fast Fourier Transform).

Query Syntax :MEASure:DUTYcycle? [<source>]

The :MEASure:DUTYcycle? query measures and outputs the positive duty cycle of the signal specified by the :MEASure:SOURce command. The value returned for the duty cycle is the ratio of the positive pulse width to the period. The positive pulse width and the period of the specified signal are measured, then the duty cycle is calculated with the following formula:

$$+duty\ cycle = (+pulse\ width/period)*100$$

Return Format <value><NL>

<value> ::= ratio of positive pulse width to period in NR3 format

- See Also**
- ["Introduction to :MEASure Commands"](#) on page 658
 - [":MEASure:PERiod"](#) on page 713
 - [":MEASure:PWIDth"](#) on page 717
 - [":MEASure:SOURce"](#) on page 727
 - [":MEASure:NDUTy"](#) on page 705

Example Code

- ["Example Code"](#) on page 728

:MEASure:FALLtime

C (see [page 1730](#))

Command Syntax :MEASure:FALLtime [<source>]
 <source> ::= {CHANnel<n> | FUNCTION<m> | MATH<m> | WMEMory<r>}
 <n> ::= 1 to (# analog channels) in NR1 format
 <m> ::= 1 to (# math functions) in NR1 format
 <r> ::= 1 to (# ref waveforms) in NR1 format

The :MEASure:FALLtime command installs a screen measurement and starts a fall-time measurement. For highest measurement accuracy, set the sweep speed as fast as possible, while leaving the falling edge of the waveform on the display. If the optional source parameter is specified, the current source is modified.

NOTE

This command is not available if the source is FFT (Fast Fourier Transform).

Query Syntax :MEASure:FALLtime? [<source>]

The :MEASure:FALLtime? query measures and outputs the fall time of the displayed falling (negative-going) edge closest to the timebase reference. The fall time is determined by measuring the time at the upper threshold of the falling edge, then measuring the time at the lower threshold of the falling edge, and calculating the fall time with the following formula:

$$\text{fall time} = \text{time at lower threshold} - \text{time at upper threshold}$$

Return Format <value><NL>
 <value> ::= time in seconds between the lower threshold and upper threshold in NR3 format

- See Also**
- ["Introduction to :MEASure Commands"](#) on page 658
 - [":MEASure:RISetime"](#) on page 721
 - [":MEASure:SOURce"](#) on page 727
 - [":MEASure:SLEWrate"](#) on page 726

:MEASure:FFT:ACPR

N (see [page 1730](#))

Command Syntax :MEASure:FFT:ACPR <chan_width>,<chan_spacing>,<chan>[,<source>]
 <chan_width> ::= of main range and sideband channels, Hz in NR3 format
 <chan_spacing> ::= spacing between main range and sideband channels,
 Hz in NR3 format
 <chan> ::= {CENTer | HIGH<sb> | LOW<sb>}
 <sb> ::= sideband 1 to 5
 <source> ::= {FUNction<m> | MATH<m> | FFT} (must be an FFT waveform)
 <m> ::= 1 to (# math functions) in NR1 format

The :MEASure:FFT:ACPR command installs an FFT analysis Adjacent Channel Power Ratio (ACPR) measurement on screen.

Adjacent Channel Power Ratio (or channel leakage ratio) measures the ratio of the power in the main frequency range to the power contained in one or more sidebands.

The main range is specified by a channel width and a center frequency. The center frequency used in the measurement is the one defined for the FFT function.

Sidebands (with the same width as the main range) exist above and below the main range separated by the channel spacing width.

The sideband used for the measurement is selected with the <chan> parameter. You can select the first through fifth sidebands above or below the main range (HIGH1 through HIGH5 above and LOW1 through LOW5 below). The full sideband must be in the graticule (on screen) to be measured. Otherwise, the measurement results will be "Incomplete".

When this measurement is tracked with cursors, the cursors show the sideband being measured.

Query Syntax :MEASure:FFT:ACPR? <chan_width>,<chan_spacing>,<chan>[,<source>]

The :MEASure:FFT:ACPR? query returns the measured Adjacent Channel Power Ratio (ACPR) value.

Return Format <return_value><NL>
 <return_value> ::= adjacent channel power ratio, dBV in NR3 format

- See Also**
- [":MEASure:FFT:CPOWer"](#) on page 686
 - [":MEASure:FFT:OBW"](#) on page 687
 - [":MEASure:FFT:THD"](#) on page 688

:MEASure:FFT:CPOWer

N (see [page 1730](#))

Command Syntax :MEASure:FFT:CPOWer [<source>]
 <source> ::= {FUNCTION<m> | MATH<m> | FFT} (must be an FFT waveform)
 <m> ::= 1 to (# math functions) in NR1 format

The :MEASure:FFT:CPOWer command installs an FFT analysis Channel Power measurement on screen.

Channel Power measures the spectral power across a frequency range.

The center frequency used in the measurement is the one defined for the FFT function, and the FFT span specifies the frequency range.

When this measurement is tracked with cursors, the cursors are at the left and right edges of the frequency span.

Query Syntax :MEASure:FFT:CPOWer? [<source>]

The :MEASure:FFT:CPOWer? query returns the measured Channel Power value.

Return Format <return_value><NL>
 <return_value> ::= spectral channel power, dBV in NR3 format

- See Also**
- [":MEASure:FFT:ACPR"](#) on page 685
 - [":MEASure:FFT:OBW"](#) on page 687
 - [":MEASure:FFT:THD"](#) on page 688

:MEASure:FFT:OBW

N (see [page 1730](#))

Command Syntax :MEASure:FFT:OBW <percentage> [, <source>]

<percentage> ::= percent of spectral power occupied bandwidth is measured for (in NR3 format)

<source> ::= {FUNCTION<m> | MATH<m> | FFT} (must be an FFT waveform)

<m> ::= 1 to (# math functions) in NR1 format

The :MEASure:FFT:OBW command installs an FFT analysis Occupied Bandwidth measurement on screen.

Occupied Bandwidth measures the bandwidth (frequency range) containing some percent (usually 99%) of the total spectral power. While 99% is the industry norm, you can specify the percent you want to use in the measurement.

The center frequency used in the measurement is the one defined for the FFT function, and the FFT span represents the total spectral power.

When this measurement is tracked with cursors, the cursors show the measured bandwidth (frequency range).

Query Syntax :MEASure:FFT:OBW? <percentage> [, <source>]

The :MEASure:FFT:OBW? query returns the measured Occupied Bandwidth value.

Return Format <return_value><NL>

<return_value> ::= occupied bandwidth, Hz in NR3 format

- See Also**
- [":MEASure:FFT:ACPR"](#) on page 685
 - [":MEASure:FFT:CPOWer"](#) on page 686
 - [":MEASure:FFT:THD"](#) on page 688

:MEASure:FFT:THD

N (see [page 1730](#))

Command Syntax :MEASure:FFT:THD <tracking>[,<fundamental_freq>] [,<source>]
 <tracking> ::= {AUTO | MANual}
 <fundamental_freq> ::= in NR3 format, required if <tracking> is MANual
 <source> ::= {FUNction<m> | MATH<m> | FFT} (must be an FFT waveform)
 <m> ::= 1 to (# math functions) in NR1 format

The :MEASure:FFT:THD command installs an FFT analysis Total Harmonic Distortion measurement on screen.

Total Harmonic Distortion (THD) is the ratio of power in the fundamental frequency to the power contained in the rest of the harmonics and noise. THD is a measure of signal purity.

Total Harmonic Distortion (THD) measures the power contained in the bands surrounding each harmonic and compares it to the power in the band surrounding the fundamental frequency. The width of the bands measured is the same for the fundamental frequency and each harmonic. That width is 1/2 of the fundamental frequency.

You can either enter the fundamental frequency as a measurement parameter and have the fundamental frequency and harmonics be tracked manually, or you can allow the fundamental frequency and harmonics to be tracked automatically, where the highest peak is assumed to be the fundamental frequency.

When this measurement is tracked with cursors, the cursors show the band surrounding the fundamental frequency that is being measured (at $\pm 1/4$ of the fundamental frequency).

Query Syntax :MEASure:FFT:THD? <tracking>[,<fundamental_freq>] [,<source>]

The :MEASure:FFT:THD? query returns the measured Total Harmonic Distortion value.

Return Format <return_value><NL>
 <return_value> ::= total harmonic distortion ratio percent in NR3 format

- See Also**
- [":MEASure:FFT:ACPR"](#) on page 685
 - [":MEASure:FFT:CPOWer"](#) on page 686
 - [":MEASure:FFT:OBW"](#) on page 687

:MEASure:FREQuency

C (see [page 1730](#))

Command Syntax :MEASure:FREQuency [<source>]

```
<source> ::= {<digital channels> | CHANnel<n> | FUNction<m> | MATH<m>
             | WMEMory<r>}
```

<digital channels> ::= DIGital<d> for the MSO models

<d> ::= 0 to (# digital channels - 1) in NR1 format

<n> ::= 1 to (# of analog channels) in NR1 format

<m> ::= 1 to (# math functions) in NR1 format

<r> ::= 1 to (# ref waveforms) in NR1 format

The :MEASure:FREQuency command installs a screen measurement and starts a frequency measurement. If the optional source parameter is specified, the current source is modified.

IF the edge on the screen closest to the trigger reference is rising:

THEN frequency = 1/(time at trailing rising edge - time at leading rising edge)

ELSE frequency = 1/(time at trailing falling edge - time at leading falling edge)

NOTE

This command is not available if the source is FFT (Fast Fourier Transform).

Query Syntax :MEASure:FREQuency? [<source>]

The :MEASure:FREQuency? query measures and outputs the frequency of the cycle on the screen closest to the trigger reference.

Return Format <source><NL>

```
<source> ::= frequency in Hertz in NR3 format
```

See Also • ["Introduction to :MEASure Commands"](#) on page 658

• [":MEASure:SOURce"](#) on page 727

• [":MEASure:PERiod"](#) on page 713

Example Code • ["Example Code"](#) on page 728

:MEASure:HISTogram:BWIDth

N (see [page 1730](#))

Query Syntax :MEASure:HISTogram:BWIDth?

The :MEASure:HISTogram:BWIDth? query returns the width of each bin (bucket) in the histogram.

Return Format <value><NL>

<value> ::= bin width in NR3 format

- See Also**
- [Chapter 24](#), “:HISTogram Commands,” starting on page 559
 - [":MEASure:HISTogram:HITS"](#) on page 691
 - [":MEASure:HISTogram:M1S"](#) on page 692
 - [":MEASure:HISTogram:M2S"](#) on page 693
 - [":MEASure:HISTogram:M3S"](#) on page 694
 - [":MEASure:HISTogram:MAXimum"](#) on page 695
 - [":MEASure:HISTogram:MEAN"](#) on page 696
 - [":MEASure:HISTogram:MEDian"](#) on page 697
 - [":MEASure:HISTogram:MINimum"](#) on page 698
 - [":MEASure:HISTogram:MODE"](#) on page 699
 - [":MEASure:HISTogram:PEAK"](#) on page 700
 - [":MEASure:HISTogram:PPEak"](#) on page 701
 - [":MEASure:HISTogram:SDEViation"](#) on page 702

:MEASure:HISTogram:HITS

N (see [page 1730](#))

Query Syntax :MEASure:HISTogram:HITS?

The :MEASure:HISTogram:HITS? query returns the sum of all hits in all bins (buckets) in the histogram.

Return Format <value><NL>

<value> ::= # of total hits in NR1 format

- See Also**
- [Chapter 24](#), “:HISTogram Commands,” starting on page 559
 - [":MEASure:HISTogram:BWIDth"](#) on page 690
 - [":MEASure:HISTogram:M1S"](#) on page 692
 - [":MEASure:HISTogram:M2S"](#) on page 693
 - [":MEASure:HISTogram:M3S"](#) on page 694
 - [":MEASure:HISTogram:MAXimum"](#) on page 695
 - [":MEASure:HISTogram:MEAN"](#) on page 696
 - [":MEASure:HISTogram:MEDian"](#) on page 697
 - [":MEASure:HISTogram:MINimum"](#) on page 698
 - [":MEASure:HISTogram:MODE"](#) on page 699
 - [":MEASure:HISTogram:PEAK"](#) on page 700
 - [":MEASure:HISTogram:PPEak"](#) on page 701
 - [":MEASure:HISTogram:SDEViation"](#) on page 702

:MEASure:HISTogram:M1S

N (see [page 1730](#))

Query Syntax :MEASure:HISTogram:M1S?

The :MEASure:HISTogram:M1S? query returns the percentage of histogram hits that lie within ± 1 Std Dev of the mean.

Return Format <value><NL>

<value> ::= % of hits within +/-1 std dev in NR3 format

- See Also**
- [Chapter 24](#), “:HISTogram Commands,” starting on page 559
 - [":MEASure:HISTogram:BWIDth"](#) on page 690
 - [":MEASure:HISTogram:HITS"](#) on page 691
 - [":MEASure:HISTogram:M2S"](#) on page 693
 - [":MEASure:HISTogram:M3S"](#) on page 694
 - [":MEASure:HISTogram:MAXimum"](#) on page 695
 - [":MEASure:HISTogram:MEAN"](#) on page 696
 - [":MEASure:HISTogram:MEDian"](#) on page 697
 - [":MEASure:HISTogram:MINimum"](#) on page 698
 - [":MEASure:HISTogram:MODE"](#) on page 699
 - [":MEASure:HISTogram:PEAK"](#) on page 700
 - [":MEASure:HISTogram:PPEak"](#) on page 701
 - [":MEASure:HISTogram:SDEViation"](#) on page 702

:MEASure:HISTogram:M2S

N (see [page 1730](#))

Query Syntax :MEASure:HISTogram:M2S?

The :MEASure:HISTogram:M2S? query returns the percentage of histogram hits that lie within ± 2 Std Dev of the mean.

Return Format <value><NL>

<value> ::= % of hits within +/-2 std devs in NR3 format

- See Also**
- [Chapter 24](#), “:HISTogram Commands,” starting on page 559
 - [":MEASure:HISTogram:BWIDth"](#) on page 690
 - [":MEASure:HISTogram:HITS"](#) on page 691
 - [":MEASure:HISTogram:M1S"](#) on page 692
 - [":MEASure:HISTogram:M3S"](#) on page 694
 - [":MEASure:HISTogram:MAXimum"](#) on page 695
 - [":MEASure:HISTogram:MEAN"](#) on page 696
 - [":MEASure:HISTogram:MEDian"](#) on page 697
 - [":MEASure:HISTogram:MINimum"](#) on page 698
 - [":MEASure:HISTogram:MODE"](#) on page 699
 - [":MEASure:HISTogram:PEAK"](#) on page 700
 - [":MEASure:HISTogram:PPEak"](#) on page 701
 - [":MEASure:HISTogram:SDEViation"](#) on page 702

:MEASure:HISTogram:M3S

N (see [page 1730](#))

Query Syntax :MEASure:HISTogram:M3S?

The :MEASure:HISTogram:M3S? query returns the percentage of histogram hits that lie within ± 3 Std Dev of the mean.

Return Format <value><NL>

<value> ::= % of hits within +/-3 std devs in NR3 format

- See Also**
- [Chapter 24](#), “:HISTogram Commands,” starting on page 559
 - [":MEASure:HISTogram:BWIDth"](#) on page 690
 - [":MEASure:HISTogram:HITS"](#) on page 691
 - [":MEASure:HISTogram:M1S"](#) on page 692
 - [":MEASure:HISTogram:M2S"](#) on page 693
 - [":MEASure:HISTogram:MAXimum"](#) on page 695
 - [":MEASure:HISTogram:MEAN"](#) on page 696
 - [":MEASure:HISTogram:MEDian"](#) on page 697
 - [":MEASure:HISTogram:MINimum"](#) on page 698
 - [":MEASure:HISTogram:MODE"](#) on page 699
 - [":MEASure:HISTogram:PEAK"](#) on page 700
 - [":MEASure:HISTogram:PPEak"](#) on page 701
 - [":MEASure:HISTogram:SDEViation"](#) on page 702

:MEASure:HISTogram:MAXimum

N (see [page 1730](#))

Query Syntax :MEASure:HISTogram:MAXimum?

The :MEASure:HISTogram:MAXimum? query returns the value corresponding to the maximum bin that has any hits.

Return Format <value><NL>

<value> ::= value of max bin in NR3 format

- See Also**
- [Chapter 24](#), “:HISTogram Commands,” starting on page 559
 - [":MEASure:HISTogram:BWIDth"](#) on page 690
 - [":MEASure:HISTogram:HITS"](#) on page 691
 - [":MEASure:HISTogram:M1S"](#) on page 692
 - [":MEASure:HISTogram:M2S"](#) on page 693
 - [":MEASure:HISTogram:M3S"](#) on page 694
 - [":MEASure:HISTogram:MEAN"](#) on page 696
 - [":MEASure:HISTogram:MEDian"](#) on page 697
 - [":MEASure:HISTogram:MINimum"](#) on page 698
 - [":MEASure:HISTogram:MODE"](#) on page 699
 - [":MEASure:HISTogram:PEAK"](#) on page 700
 - [":MEASure:HISTogram:PPEak"](#) on page 701
 - [":MEASure:HISTogram:SDEViation"](#) on page 702

:MEASure:HISTogram:MEAN

N (see [page 1730](#))

Query Syntax :MEASure:HISTogram:MEAN?

The :MEASure:HISTogram:MEAN? query returns the mean value of the histogram.

Return Format <value><NL>

<value> ::= mean of histogram in NR3 format

- See Also**
- [Chapter 24](#), “:HISTogram Commands,” starting on page 559
 - [":MEASure:HISTogram:BWIDth"](#) on page 690
 - [":MEASure:HISTogram:HITS"](#) on page 691
 - [":MEASure:HISTogram:M1S"](#) on page 692
 - [":MEASure:HISTogram:M2S"](#) on page 693
 - [":MEASure:HISTogram:M3S"](#) on page 694
 - [":MEASure:HISTogram:MAXimum"](#) on page 695
 - [":MEASure:HISTogram:MEDian"](#) on page 697
 - [":MEASure:HISTogram:MINimum"](#) on page 698
 - [":MEASure:HISTogram:MODE"](#) on page 699
 - [":MEASure:HISTogram:PEAK"](#) on page 700
 - [":MEASure:HISTogram:PPEak"](#) on page 701
 - [":MEASure:HISTogram:SDEVIation"](#) on page 702

:MEASure:HISTogram:MEDian

N (see [page 1730](#))

Query Syntax :MEASure:HISTogram:MEDian?

The :MEASure:HISTogram:MEDian? query returns the median value of the histogram.

Return Format <value><NL>

<value> ::= median of histogram in NR3 format

- See Also**
- [Chapter 24](#), “:HISTogram Commands,” starting on page 559
 - [":MEASure:HISTogram:BWIDth"](#) on page 690
 - [":MEASure:HISTogram:HITS"](#) on page 691
 - [":MEASure:HISTogram:M1S"](#) on page 692
 - [":MEASure:HISTogram:M2S"](#) on page 693
 - [":MEASure:HISTogram:M3S"](#) on page 694
 - [":MEASure:HISTogram:MAXimum"](#) on page 695
 - [":MEASure:HISTogram:MEAN"](#) on page 696
 - [":MEASure:HISTogram:MINimum"](#) on page 698
 - [":MEASure:HISTogram:MODE"](#) on page 699
 - [":MEASure:HISTogram:PEAK"](#) on page 700
 - [":MEASure:HISTogram:PPEak"](#) on page 701
 - [":MEASure:HISTogram:SDEVIation"](#) on page 702

:MEASure:HISTogram:MINimum

N (see [page 1730](#))

Query Syntax :MEASure:HISTogram:MINimum?

The :MEASure:HISTogram:MINimum? query returns the value corresponding to the minimum bin that has any hits.

Return Format <value><NL>

<value> ::= value of min bin in NR3 format

- See Also**
- [Chapter 24](#), “:HISTogram Commands,” starting on page 559
 - [":MEASure:HISTogram:BWIDth"](#) on page 690
 - [":MEASure:HISTogram:HITS"](#) on page 691
 - [":MEASure:HISTogram:M1S"](#) on page 692
 - [":MEASure:HISTogram:M2S"](#) on page 693
 - [":MEASure:HISTogram:M3S"](#) on page 694
 - [":MEASure:HISTogram:MAXimum"](#) on page 695
 - [":MEASure:HISTogram:MEAN"](#) on page 696
 - [":MEASure:HISTogram:MEDian"](#) on page 697
 - [":MEASure:HISTogram:MODE"](#) on page 699
 - [":MEASure:HISTogram:PEAK"](#) on page 700
 - [":MEASure:HISTogram:PPEak"](#) on page 701
 - [":MEASure:HISTogram:SDEViation"](#) on page 702

:MEASure:HISTogram:MODE

N (see [page 1730](#))

Query Syntax :MEASure:HISTogram:MODE?

The :MEASure:HISTogram:MODE? query returns the mode value of the histogram.

Return Format <value><NL>

<value> ::= mode of histogram in NR3 format

- See Also**
- [Chapter 24](#), “:HISTogram Commands,” starting on page 559
 - [":MEASure:HISTogram:BWIDth"](#) on page 690
 - [":MEASure:HISTogram:HITS"](#) on page 691
 - [":MEASure:HISTogram:M1S"](#) on page 692
 - [":MEASure:HISTogram:M2S"](#) on page 693
 - [":MEASure:HISTogram:M3S"](#) on page 694
 - [":MEASure:HISTogram:MAXimum"](#) on page 695
 - [":MEASure:HISTogram:MEAN"](#) on page 696
 - [":MEASure:HISTogram:MEDian"](#) on page 697
 - [":MEASure:HISTogram:MINimum"](#) on page 698
 - [":MEASure:HISTogram:PEAK"](#) on page 700
 - [":MEASure:HISTogram:PPEak"](#) on page 701
 - [":MEASure:HISTogram:SDEViation"](#) on page 702

:MEASure:HISTogram:PEAK

N (see [page 1730](#))

Query Syntax :MEASure:HISTogram:PEAK?

The :MEASure:HISTogram:PEAK? query returns the maximum number of hits in any single bin.

Return Format <value><NL>

<value> ::= # of hits in max bin in NR1 format

- See Also**
- [Chapter 24](#), “:HISTogram Commands,” starting on page 559
 - [":MEASure:HISTogram:BWIDth"](#) on page 690
 - [":MEASure:HISTogram:HITS"](#) on page 691
 - [":MEASure:HISTogram:M1S"](#) on page 692
 - [":MEASure:HISTogram:M2S"](#) on page 693
 - [":MEASure:HISTogram:M3S"](#) on page 694
 - [":MEASure:HISTogram:MAXimum"](#) on page 695
 - [":MEASure:HISTogram:MEAN"](#) on page 696
 - [":MEASure:HISTogram:MEDian"](#) on page 697
 - [":MEASure:HISTogram:MINimum"](#) on page 698
 - [":MEASure:HISTogram:MODE"](#) on page 699
 - [":MEASure:HISTogram:PPEak"](#) on page 701
 - [":MEASure:HISTogram:SDEViation"](#) on page 702

:MEASure:HISTogram:PPEak

N (see [page 1730](#))

Query Syntax :MEASure:HISTogram:PPEak?

The :MEASure:HISTogram:PPEak? query returns the delta between the Max and Min values.

Return Format <value><NL>

<value> ::= delta value between max bin and min bin in NR3 format

- See Also**
- [Chapter 24](#), “:HISTogram Commands,” starting on page 559
 - [":MEASure:HISTogram:BWIDth"](#) on page 690
 - [":MEASure:HISTogram:HITS"](#) on page 691
 - [":MEASure:HISTogram:M1S"](#) on page 692
 - [":MEASure:HISTogram:M2S"](#) on page 693
 - [":MEASure:HISTogram:M3S"](#) on page 694
 - [":MEASure:HISTogram:MAXimum"](#) on page 695
 - [":MEASure:HISTogram:MEAN"](#) on page 696
 - [":MEASure:HISTogram:MEDian"](#) on page 697
 - [":MEASure:HISTogram:MINimum"](#) on page 698
 - [":MEASure:HISTogram:MODE"](#) on page 699
 - [":MEASure:HISTogram:PEAK"](#) on page 700
 - [":MEASure:HISTogram:SDEViation"](#) on page 702

:MEASure:HISTogram:SDEVIation

N (see [page 1730](#))

Query Syntax :MEASure:HISTogram:SDEVIation?

The :MEASure:HISTogram:SDEVIation? query returns the standard deviation of the histogram values.

Return Format <value><NL>

<value> ::= standard deviation of histogram in NR3 format

- See Also**
- [Chapter 24](#), “:HISTogram Commands,” starting on page 559
 - [":MEASure:HISTogram:BWIDth"](#) on page 690
 - [":MEASure:HISTogram:HITS"](#) on page 691
 - [":MEASure:HISTogram:M1S"](#) on page 692
 - [":MEASure:HISTogram:M2S"](#) on page 693
 - [":MEASure:HISTogram:M3S"](#) on page 694
 - [":MEASure:HISTogram:MAXimum"](#) on page 695
 - [":MEASure:HISTogram:MEAN"](#) on page 696
 - [":MEASure:HISTogram:MEDian"](#) on page 697
 - [":MEASure:HISTogram:MINimum"](#) on page 698
 - [":MEASure:HISTogram:MODE"](#) on page 699
 - [":MEASure:HISTogram:PEAK"](#) on page 700
 - [":MEASure:HISTogram:PPEak"](#) on page 701

:MEASure:NCJitter

N (see [page 1730](#))

Command Syntax


NOTE

This measurement is available when the optional jitter analysis feature is licensed

```
:MEASure:NCJitter <config>
<config> ::= <source>, <direction>, <num_periods>
<source> ::= {CHANnel<n> | FUNction<m> | MATH<m> | WMEMory<r>}
<n> ::= 1 to (# analog channels) in NR1 format
<m> ::= 1 to (# math functions) in NR1 format
<r> ::= 1 to (# ref waveforms) in NR1 format
<direction> ::= {RISing | FALLing}
<num_periods> ::= 1 to 10000 in NR1 format
```

The :MEASure:NCJitter command install a period-period (N-cycle) jitter measurement on screen.

The Period-Period jitter measurement takes a group of cycles and measures the period from the first edge of the first cycle of the group to the final edge of the last cycle of the group. The N-period of the first group is measured and subtracted from the N-period of the second group. After shifting ahead one cycle the next measurement is made. The following figure shows how an N-cycle jitter measurement is made for N=3.



Once all of the groups of cycles of the waveform are measured, the statistics are calculated. The statistics are the values accumulated over all of the trigger cycles that have occurred.

To perform a cycle-cycle jitter measurement, use Period-Period and set N=1.

The measurement is made on all the cycles of the waveform. Even in Zoom mode, all the cycles of the waveform in the Main window will be measured.

Query Syntax :MEASure:NCJitter? <config>

The :MEASure:NCJitter? query measures and returns the N-Period to N-Period jitter value.

Return Format

<value><NL>

<value> ::= N-Period to N-Period jitter in NR3 format

- See Also**
- [":MEASure:NPERiod"](#) on page 707
 - [Chapter 25](#), “:JITTer Commands,” starting on page 575

:MEASure:NDUTy

N (see [page 1730](#))

Command Syntax :MEASure:NDUTy [<source>]

```
<source> ::= {<digital channels> | CHANnel<n> | FUNction<m> | MATH<m>
              | WMEMory<r>}
```

<digital channels> ::= DIGital<d> for the MSO models

<d> ::= 0 to (# digital channels - 1) in NR1 format

<n> ::= 1 to (# of analog channels) in NR1 format

<m> ::= 1 to (# math functions) in NR1 format

<r> ::= 1 to (# ref waveforms) in NR1 format

The :MEASure:NDUTy command installs a screen measurement and starts a negative duty cycle measurement on the current :MEASure:SOURce. If the optional source parameter is specified, the current source is modified.

NOTE

The signal must be displayed to make the measurement. This command is not available if the source is FFT (Fast Fourier Transform).

Query Syntax :MEASure:NDUTy? [<source>]

The :MEASure:NDUTy? query measures and outputs the negative duty cycle of the signal specified by the :MEASure:SOURce command. The value returned for the duty cycle is the ratio of the negative pulse width to the period. The negative pulse width and the period of the specified signal are measured, then the duty cycle is calculated with the following formula:

$$-\text{duty cycle} = (-\text{pulse width}/\text{period}) * 100$$

Return Format <value><NL>

<value> ::= ratio of negative pulse width to period in NR3 format

- See Also**
- ["Introduction to :MEASure Commands"](#) on page 658
 - [":MEASure:PERiod"](#) on page 713
 - [":MEASure:NWIDth"](#) on page 709
 - [":MEASure:SOURce"](#) on page 727
 - [":MEASure:DUTYcycle"](#) on page 683

:MEASure:NEDGes

N (see [page 1730](#))

Command Syntax :MEASure:NEDGes [<source>]
 <source> ::= {CHANnel<n> | FUNction<m> | MATH<m> | WMEMory<r>}
 <n> ::= 1 to (# analog channels) in NR1 format
 <m> ::= 1 to (# math functions) in NR1 format
 <r> ::= 1 to (# ref waveforms) in NR1 format

The :MEASure:NEDGes command installs a falling edge count measurement on screen. If the optional source parameter is not specified, the current source is measured.

NOTE

This command is not available if the source is FFT (Fast Fourier Transform).

Query Syntax :MEASure:NEDGes? [<source>]

The :MEASure:NEDGes? query measures and returns the on-screen falling edge count.

Return Format <value><NL>
 <value> ::= the falling edge count in NR3 format

- See Also**
- ["Introduction to :MEASure Commands"](#) on page 658
 - [":MEASure:SOURce"](#) on page 727

:MEASure:NPERiod

N (see [page 1730](#))

Command Syntax


NOTE

This measurement is available when the optional jitter analysis feature is licensed

```
:MEASure:NPERiod <config>
<config> ::= <source>, <slope>, <num_periods>
<source> ::= {CHANnel<n> | FUNction<m> | MATH<m> | WMEMory<r>}
<n> ::= 1 to (# analog channels) in NR1 format
<m> ::= 1 to (# math functions) in NR1 format
<r> ::= 1 to (# ref waveforms) in NR1 format
<slope> ::= {RISing | FALLing}
<num_periods> ::= 1 to 10000 in NR1 format
```

The :MEASure:NPERiod command installs an N-period jitter measurement on screen.

The N-Period jitter measurement measures the time span of N consecutive periods. Then, it shifts ahead one period and measures the time span of the next N consecutive periods, and so on.



Query Syntax :MEASure:NPERiod? <config>

The :MEASure:NPERiod? query measures and returns the N-Period jitter value.

Return Format

```
<value><NL>
<value> ::= N-Period jitter in NR3 format
```

- See Also**
- [":MEASure:NCJitter"](#) on page 703
 - [Chapter 25](#), ":JITTer Commands," starting on page 575

:MEASure:NPULses

N (see [page 1730](#))

Command Syntax :MEASure:NPULses [<source>]

<source> ::= {CHANnel<n> | FUNction<m> | MATH<m> | WMEMory<r>
| <digital channels>}

<n> ::= 1 to (# analog channels) in NR1 format

<m> ::= 1 to (# math functions) in NR1 format

<r> ::= 1 to (# ref waveforms) in NR1 format

<digital channels> ::= DIGital<d> for the MSO models

<d> ::= 0 to (# digital channels - 1) in NR1 format

The :MEASure:NPULses command installs a falling pulse count measurement on screen. If the optional source parameter is not specified, the current source is measured.

NOTE

This command is not available if the source is FFT (Fast Fourier Transform).

Query Syntax :MEASure:NPULses? [<source>]

The :MEASure:NPULses? query measures and returns the on-screen falling pulse count.

Return Format <value><NL>

<value> ::= the falling pulse count in NR3 format

- See Also**
- ["Introduction to :MEASure Commands"](#) on page 658
 - [":MEASure:SOURce"](#) on page 727

:MEASure:NWIDth

C (see [page 1730](#))

Command Syntax :MEASure:NWIDth [<source>]

<source> ::= {<digital channels> | CHANnel<n> | FUNction<m> | MATH<m>
| WMEMory<r>}

<digital channels> ::= DIGital<d> for the MSO models

<d> ::= 0 to (# digital channels - 1) in NR1 format

<n> ::= 1 to (# of analog channels) in NR1 format

<m> ::= 1 to (# math functions) in NR1 format

<r> ::= 1 to (# ref waveforms) in NR1 format

The :MEASure:NWIDth command installs a screen measurement and starts a negative pulse width measurement. If the optional source parameter is not specified, the current source is modified.

NOTE

This command is not available if the source is FFT (Fast Fourier Transform).

Query Syntax :MEASure:NWIDth? [<source>]

The :MEASure:NWIDth? query measures and outputs the width of the negative pulse on the screen closest to the trigger reference using the midpoint between the upper and lower thresholds.

FOR the negative pulse closest to the trigger point:

$$\text{width} = (\text{time at trailing rising edge} - \text{time at leading falling edge})$$

Return Format <value><NL>

<value> ::= negative pulse width in seconds in NR3 format

- See Also**
- ["Introduction to :MEASure Commands"](#) on page 658
 - [":MEASure:SOURce"](#) on page 727
 - [":MEASure:PWIDth"](#) on page 717
 - [":MEASure:PERiod"](#) on page 713

:MEASure:OVERshoot

C (see [page 1730](#))

Command Syntax :MEASure:OVERshoot [<source>]
 <source> ::= {CHANnel<n> | FUNCTION<m> | MATH<m> | WMEMory<r>}
 <n> ::= 1 to (# analog channels) in NR1 format
 <m> ::= 1 to (# math functions) in NR1 format
 <r> ::= 1 to (# ref waveforms) in NR1 format

The :MEASure:OVERshoot command installs a screen measurement and starts an overshoot measurement. If the optional source parameter is specified, the current source is modified.

NOTE

This command is not available if the source is FFT (Fast Fourier Transform).

Query Syntax :MEASure:OVERshoot? [<source>]

The :MEASure:OVERshoot? query measures and returns the overshoot of the edge closest to the trigger reference, displayed on the screen. The method used to determine overshoot is to make three different vertical value measurements: Vtop, Vbase, and either Vmax or Vmin, depending on whether the edge is rising or falling.

For a rising edge:

$$\text{overshoot} = ((V_{\text{max}} - V_{\text{top}}) / (V_{\text{top}} - V_{\text{base}})) \times 100$$

For a falling edge:

$$\text{overshoot} = ((V_{\text{base}} - V_{\text{min}}) / (V_{\text{top}} - V_{\text{base}})) \times 100$$

Vtop and Vbase are taken from the normal histogram of all waveform vertical values. The extremum of Vmax or Vmin is taken from the waveform interval right after the chosen edge, halfway to the next edge. This more restricted definition is used instead of the normal one, because it is conceivable that a signal may have more preshoot than overshoot, and the normal extremum would then be dominated by the preshoot of the following edge.

Return Format <overshoot><NL>
 <overshoot> ::= the percent of the overshoot of the selected waveform in NR3 format

- See Also**
- ["Introduction to :MEASure Commands"](#) on page 658
 - [":MEASure:PREShoot"](#) on page 716
 - [":MEASure:SOURce"](#) on page 727

- **":MEASure:VMAX"** on page 747
- **":MEASure:VTOP"** on page 752
- **":MEASure:VBASe"** on page 746
- **":MEASure:VMIN"** on page 748

:MEASure:PEDGes

N (see [page 1730](#))

Command Syntax :MEASure:PEDGes [<source>]
 <source> ::= {CHANnel<n> | FUNction<m> | MATH<m> | WMEMory<r>}
 <n> ::= 1 to (# analog channels) in NR1 format
 <m> ::= 1 to (# math functions) in NR1 format
 <r> ::= 1 to (# ref waveforms) in NR1 format

The :MEASure:PEDGes command installs a rising edge count measurement on screen. If the optional source parameter is not specified, the current source is measured.

NOTE

This command is not available if the source is FFT (Fast Fourier Transform).

Query Syntax :MEASure:PEDGes? [<source>]

The :MEASure:PEDGes? query measures and returns the on-screen rising edge count.

Return Format <value><NL>
 <value> ::= the rising edge count in NR3 format

- See Also**
- ["Introduction to :MEASure Commands"](#) on page 658
 - [":MEASure:SOURce"](#) on page 727

:MEASure:PERiod

C (see [page 1730](#))

Command Syntax :MEASure:PERiod [<source>]

<source> ::= {<digital channels> | CHANnel<n> | FUNction<m> | MATH<m>
| WMEMory<r>}

<digital channels> ::= DIGital<d> for the MSO models

<d> ::= 0 to (# digital channels - 1) in NR1 format

<n> ::= 1 to (# of analog channels) in NR1 format

<m> ::= 1 to (# math functions) in NR1 format

<r> ::= 1 to (# ref waveforms) in NR1 format

The :MEASure:PERiod command installs a screen measurement and starts the period measurement. If the optional source parameter is specified, the current source is modified.

NOTE

This command is not available if the source is FFT (Fast Fourier Transform).

Query Syntax :MEASure:PERiod? [<source>]

The :MEASure:PERiod? query measures and outputs the period of the cycle closest to the trigger reference on the screen. The period is measured at the midpoint of the upper and lower thresholds.

IF the edge closest to the trigger reference on screen is rising:

THEN period = (time at trailing rising edge - time at leading rising edge)

ELSE period = (time at trailing falling edge - time at leading falling edge)

Return Format <value><NL>

<value> ::= waveform period in seconds in NR3 format

- See Also**
- ["Introduction to :MEASure Commands"](#) on page 658
 - [":MEASure:SOURce"](#) on page 727
 - [":MEASure:NWIDth"](#) on page 709
 - [":MEASure:PWIDth"](#) on page 717
 - [":MEASure:FREQuency"](#) on page 689

Example Code • ["Example Code"](#) on page 728

:MEASure:PHASe

N (see [page 1730](#))

Command Syntax :MEASure:PHASe [<source1>] [,<source2>]

<source1>, <source2> ::= {CHANnel<n> | FUNction<m> | MATH<m> | WMEMory<r>}

<n> ::= 1 to (# analog channels) in NR1 format

<m> ::= 1 to (# math functions) in NR1 format

<r> ::= 1 to (# ref waveforms) in NR1 format

The :MEASure:PHASe command places the instrument in the continuous measurement mode and starts a phase measurement.

Query Syntax :MEASure:PHASe? [<source1>] [,<source2>]

The :MEASure:PHASe? query measures and returns the phase between the specified sources.

A phase measurement is a combination of the period and delay measurements. First, the period is measured on source1. Then the delay is measured between source1 and source2. The edges used for delay are the source1 rising edge used for the period measurement closest to the horizontal reference and the rising edge on source 2. See :MEASure:DELAy for more detail on selecting the 2nd edge.

The phase is calculated as follows:

$$\text{phase} = (\text{delay} / \text{period of input 1}) \times 360$$

Return Format <value><NL>

<value> ::= the phase angle value in degrees in NR3 format

- See Also**
- ["Introduction to :MEASure Commands"](#) on page 658
 - [":MEASure:DELAy"](#) on page 674
 - [":MEASure:PERiod"](#) on page 713
 - [":MEASure:SOURce"](#) on page 727

:MEASure:PPULses

N (see [page 1730](#))

Command Syntax :MEASure:PPULses [<source>]

<source> ::= {CHANnel<n> | FUNction<m> | MATH<m> | WMEMory<r>
| <digital channels>}

<n> ::= 1 to (# analog channels) in NR1 format

<m> ::= 1 to (# math functions) in NR1 format

<r> ::= 1 to (# ref waveforms) in NR1 format

<digital channels> ::= DIGital<d> for the MSO models

<d> ::= 0 to (# digital channels - 1) in NR1 format

The :MEASure:PPULses command installs a rising pulse count measurement on screen. If the optional source parameter is not specified, the current source is measured.

NOTE

This command is not available if the source is FFT (Fast Fourier Transform).

Query Syntax :MEASure:PPULses? [<source>]

The :MEASure:PPULses? query measures and returns the on-screen rising pulse count.

Return Format <value><NL>

<value> ::= the rising pulse count in NR3 format

- See Also**
- ["Introduction to :MEASure Commands"](#) on page 658
 - [":MEASure:SOURce"](#) on page 727

:MEASure:PREShoot

C (see [page 1730](#))

Command Syntax :MEASure:PREShoot [<source>]

<source> ::= {CHANnel<n> | FUNction<m> | MATH<m> | WMEMory<r>}

<n> ::= 1 to (# analog channels) in NR1 format

<r> ::= 1 to (# ref waveforms) in NR1 format

The :MEASure:PREShoot command installs a screen measurement and starts a preshoot measurement. If the optional source parameter is specified, the current source is modified.

Query Syntax :MEASure:PREShoot? [<source>]

The :MEASure:PREShoot? query measures and returns the preshoot of the edge closest to the trigger, displayed on the screen. The method used to determine preshoot is to make three different vertical value measurements: Vtop, Vbase, and either Vmin or Vmax, depending on whether the edge is rising or falling.

For a rising edge:

$$\text{preshoot} = ((V_{\text{min}} - V_{\text{base}}) / (V_{\text{top}} - V_{\text{base}})) \times 100$$

For a falling edge:

$$\text{preshoot} = ((V_{\text{max}} - V_{\text{top}}) / (V_{\text{top}} - V_{\text{base}})) \times 100$$

Vtop and Vbase are taken from the normal histogram of all waveform vertical values. The extremum of Vmax or Vmin is taken from the waveform interval right before the chosen edge, halfway back to the previous edge. This more restricted definition is used instead of the normal one, because it is likely that a signal may have more overshoot than preshoot, and the normal extremum would then be dominated by the overshoot of the preceding edge.

Return Format <value><NL>

<value> ::= the percent of preshoot of the selected waveform
in NR3 format

- See Also**
- ["Introduction to :MEASure Commands"](#) on page 658
 - [":MEASure:SOURce"](#) on page 727
 - [":MEASure:VMIN"](#) on page 748
 - [":MEASure:VMAX"](#) on page 747
 - [":MEASure:VTOP"](#) on page 752
 - [":MEASure:VBASe"](#) on page 746

:MEASure:PWIDth

C (see [page 1730](#))

Command Syntax :MEASure:PWIDth [<source>]

```
<source> ::= {<digital channels> | CHANnel<n> | FUNction<m> | MATH<m>
             | WMEMory<r>}
```

<digital channels> ::= DIGital<d> for the MSO models

<d> ::= 0 to (# digital channels - 1) in NR1 format

<n> ::= 1 to (# of analog channels) in NR1 format

<m> ::= 1 to (# math functions) in NR1 format

<r> ::= 1 to (# ref waveforms) in NR1 format

The :MEASure:PWIDth command installs a screen measurement and starts the positive pulse width measurement. If the optional source parameter is specified, the current source is modified.

NOTE

This command is not available if the source is FFT (Fast Fourier Transform).

Query Syntax :MEASure:PWIDth? [<source>]

The :MEASure:PWIDth? query measures and outputs the width of the displayed positive pulse closest to the trigger reference. Pulse width is measured at the midpoint of the upper and lower thresholds.

IF the edge on the screen closest to the trigger is falling:

THEN width = (time at trailing falling edge - time at leading rising edge)

ELSE width = (time at leading falling edge - time at leading rising edge)

Return Format <value><NL>

```
<value> ::= width of positive pulse in seconds in NR3 format
```

- See Also**
- ["Introduction to :MEASure Commands"](#) on page 658
 - [":MEASure:SOURce"](#) on page 727
 - [":MEASure:NWIDth"](#) on page 709
 - [":MEASure:PERiod"](#) on page 713

:MEASure:RESults

N (see [page 1730](#))

Query Syntax

`:MEASure:RESults?`

The `:MEASure:RESults?` query returns the results of the continuously displayed measurements. The response to the `MEASure:RESults?` query is a list of comma-separated values.

If more than one measurement is running continuously, the `:MEASure:RESults` return values are duplicated for each continuous measurement from the first to last (top to bottom) result displayed. Each result returned is separated from the previous result by a comma. There is a maximum of 10 continuous measurements that can be continuously displayed at a time.

When no quick measurements are installed, the `:MEASure:RESults?` query returns nothing (empty string). When the count for any of the measurements is 0, the value of infinity ($9.9E+37$) is returned for the min, max, mean, and standard deviation.

Return Format

`<result_list><NL>`

`<result_list> ::= comma-separated list of measurement results`

The following shows the order of values received for a single measurement if `:MEASure:STATistics` is set to ON.

Measureme nt label	current	min	max	mean	std dev	count
-----------------------	---------	-----	-----	------	---------	-------

Measurement label, current, min, max, mean, std dev, and count are only returned if `:MEASure:STATistics` is ON.

If `:MEASure:STATistics` is set to `CURRent`, `MIN`, `MAX`, `MEAN`, `STDDev`, or `COUNT` only that particular statistic value is returned for each measurement that is on.

- See Also
- ["Introduction to :MEASure Commands"](#) on page 658
 - [":MEASure:STATistics"](#) on page 729

Example Code

```
' This program shows the InfiniiVision oscilloscopes' measurement
' statistics commands.
```

Option Explicit

```
Public myMgr As VisaComLib.ResourceManager
Public myScope As VisaComLib.FormattedIO488
Public varQueryResult As Variant
Public strQueryResult As String
```

```

Private Declare Sub Sleep Lib "kernel32" (ByVal dwMilliseconds As Long)

Sub Main()

    On Error GoTo VisaComError

    ' Create the VISA COM I/O resource.
    Set myMgr = New VisaComLib.ResourceManager
    Set myScope = New VisaComLib.FormattedIO488
    Set myScope.IO = myMgr.Open("TCPIP0::130.29.70.228::inst0::INSTR")

    ' Initialize.
    myScope.IO.Clear ' Clear the interface.
    myScope.WriteString "*RST" ' Reset to the defaults.
    myScope.WriteString "*CLS" ' Clear the status data structures.
    myScope.WriteString ":AUToscale"

    ' Wait for auto scale.
    Sleep 7000

    ' Install some measurements.
    myScope.WriteString ":MEASure:SOURce CHANnel1" ' Input source.

    Dim MeasurementArray(3) As String
    MeasurementArray(0) = "FREQuency"
    MeasurementArray(1) = "DUTYcycle"
    MeasurementArray(2) = "VAMPLitude"
    MeasurementArray(3) = "VPP"
    Dim Measurement As Variant

    For Each Measurement In MeasurementArray
        myScope.WriteString ":MEASure:" + Measurement
        myScope.WriteString ":MEASure:" + Measurement + "?"
        varQueryResult = myScope.ReadNumber ' Read measurement value.
        Debug.Print Measurement + ": " + FormatNumber(varQueryResult, 4)
    Next

    myScope.WriteString ":MEASure:STATistics:RESet" ' Reset stats.
    Sleep 5000 ' Wait for 5 seconds.

    ' Select the statistics results type.
    Dim ResultsTypeArray(6) As String
    ResultsTypeArray(0) = "CURRent"
    ResultsTypeArray(1) = "MINimum"
    ResultsTypeArray(2) = "MAXimum"
    ResultsTypeArray(3) = "MEAN"
    ResultsTypeArray(4) = "STDDev"
    ResultsTypeArray(5) = "COUNT"
    ResultsTypeArray(6) = "ON" ' All results.
    Dim ResultType As Variant

    Dim ResultsList()

    Dim ValueColumnArray(6) As String
    ValueColumnArray(0) = "Meas_Lbl"
    ValueColumnArray(1) = "Current"
    ValueColumnArray(2) = "Min"

```

```

ValueColumnArray(3) = "Max"
ValueColumnArray(4) = "Mean"
ValueColumnArray(5) = "Std_Dev"
ValueColumnArray(6) = "Count"
Dim ValueColumn As Variant

For Each ResultType In ResultsTypeArray
    myScope.WriteString ":MEASure:STATistics " + ResultType

    ' Get the statistics results.
    Dim intCounter As Integer
    intCounter = 0
    myScope.WriteString ":MEASure:RESults?"
    ResultsList() = myScope.ReadList

    For Each Measurement In MeasurementArray

        If ResultType = "ON" Then ' All statistics.

            For Each ValueColumn In ValueColumnArray
                If VarType(ResultsList(intCounter)) <> vbString Then
                    Debug.Print "Measure statistics result CH1, " + _
                        Measurement + ", "; ValueColumn + ": " + _
                        FormatNumber(ResultsList(intCounter), 4)

                Else ' Result is a string (e.g., measurement label).
                    Debug.Print "Measure statistics result CH1, " + _
                        Measurement + ", "; ValueColumn + ": " + _
                        ResultsList(intCounter)

                End If

                intCounter = intCounter + 1
            Next

            Else ' Specific statistic (e.g., Current, Max, Min, etc.).

                Debug.Print "Measure statistics result CH1, " + _
                    Measurement + ", "; ResultType + ": " + _
                    FormatNumber(ResultsList(intCounter), 4)

                intCounter = intCounter + 1

            End If

        Next

    Next

Exit Sub

VisaComError:
    MsgBox "VISA COM Error:" + vbCrLf + Err.Description

End Sub

```


:MEASure:RISetime

C (see [page 1730](#))

Command Syntax :MEASure:RISetime [<source>]
 <source> ::= {CHANnel<n> | FUNCTION<m> | MATH<m> | WMEMory<r>}
 <n> ::= 1 to (# analog channels) in NR1 format
 <m> ::= 1 to (# math functions) in NR1 format
 <r> ::= 1 to (# ref waveforms) in NR1 format

The :MEASure:RISetime command installs a screen measurement and starts a rise-time measurement. If the optional source parameter is specified, the current source is modified.

NOTE

This command is not available if the source is FFT (Fast Fourier Transform).

Query Syntax :MEASure:RISetime? [<source>]

The :MEASure:RISetime? query measures and outputs the rise time of the displayed rising (positive-going) edge closest to the timebase reference. For maximum measurement accuracy, set the sweep speed as fast as possible while leaving the leading edge of the waveform on the display. The rise time is determined by measuring the time at the lower threshold of the rising edge and the time at the upper threshold of the rising edge, then calculating the rise time with the following formula:

$$\text{rise time} = \text{time at upper threshold} - \text{time at lower threshold}$$

Return Format <value><NL>
 <value> ::= rise time in seconds in NR3 format

- See Also**
- ["Introduction to :MEASure Commands"](#) on page 658
 - [":MEASure:SOURce"](#) on page 727
 - [":MEASure:FALLtime"](#) on page 684
 - [":MEASure:SLEWrate"](#) on page 726

:MEASure:RTEYe:EHEight

N (see [page 1730](#))

Command Syntax :MEASure:RTEYe:EHEight

When real-time eye analysis is enabled, the :MEASure:RTEYe:EHEight command installs the real-time eye height measurement on screen.

Because the measurement is made using the color grade database, it is the only valid source, and the :MEASure:SOURce is automatically set to CGRade.

Query Syntax :MEASure:RTEYe:EHEight?

The :MEASure:RTEYe:EHEight? query returns the vertical opening of an eye diagram. The opening at the center time reference is reported.

Return Format <return_value><NL>

<return_value> ::= eye opening height in NR3 format

- See Also**
- [":MEASure:SOURce"](#) on page 727
 - [":MEASure:RTEYe:EWIDth"](#) on page 723
 - [":RTEYe:STATe"](#) on page 940
 - [":RTEYe:TUINtervals"](#) on page 941

:MEASure:RTEYe:EWIDth

N (see [page 1730](#))

Command Syntax :MEASure:RTEYe:EWIDth

When real-time eye analysis is enabled, the :MEASure:RTEYe:EWIDth command installs the real-time eye width measurement on screen.

Because the measurement is made using the color grade database, it is the only valid source, and the :MEASure:SOURce is automatically set to CGRade.

Query Syntax :MEASure:RTEYe:EWIDth?

The :MEASure:RTEYe:EWIDth? query returns the horizontal opening of an eye diagram. The largest opening within the crossings is returned.

Return Format <return_value><NL>

<return_value> ::= eye opening width in NR3 format

- See Also**
- [":MEASure:SOURce"](#) on page 727
 - [":MEASure:RTEYe:EHEight"](#) on page 722
 - [":RTEYe:STATe"](#) on page 940
 - [":RTEYe:TUINtervals"](#) on page 941

:MEASure:SDEVIation

N (see [page 1730](#))

Command Syntax :MEASure:SDEVIation [<source>]
 <source> ::= {CHANnel<n> | FUNction<m> | MATH<m> | WMEMory<r>}
 <n> ::= 1-2 or 1-4 (# of analog channels) in NR1 format
 <m> ::= 1 to (# math functions) in NR1 format
 <r> ::= 1 to (# ref waveforms) in NR1 format

NOTE

This ":MEASure:VRMS DISPlay, AC" command is the preferred syntax for making standard deviation measurements.

The :MEASure:SDEVIation command installs a screen measurement and starts std deviation measurement. If the optional source parameter is specified, the current source is modified.

NOTE

This command is not available if the source is FFT (Fast Fourier Transform).

Query Syntax :MEASure:SDEVIation? [<source>]

The :MEASure:SDEVIation? query measures and outputs the std deviation of the selected waveform. The oscilloscope computes the std deviation on all displayed data points.

Return Format <value><NL>
 <value> ::= calculated std deviation value in NR3 format

- See Also**
- ["Introduction to :MEASure Commands"](#) on page 658
 - [":MEASure:VRMS"](#) on page 751
 - [":MEASure:SOURce"](#) on page 727

:MEASure:SHOW

N (see [page 1730](#))

Command Syntax :MEASure:SHOW <on_off>
 <on_off> ::= {{0 | OFF} | {1 | ON}}

The :MEASure:SHOW command enables markers for tracking measurements on the display.

Query Syntax :MEASure:SHOW?

The :MEASure:SHOW? query returns the current state of the markers.

This can return OFF when :MARKer:MODE selects a mode other than MEASurement.

Return Format <on_off><NL>
 <on_off> ::= {1 | 0}

- See Also**
- ["Introduction to :MEASure Commands"](#) on page 658
 - [":MARKer:MODE"](#) on page 617

:MEASure:SLEWrate

N (see [page 1730](#))

Command Syntax :MEASure:SLEWrate [<source>[,<slope>]]

<source> ::= {CHANnel<n> | FUNCTION<m> | MATH<m> | WMEMory<r>}

<n> ::= 1 to (# of analog channels) in NR1 format

<m> ::= 1 to (# math functions) in NR1 format

<r> ::= 1 to (# ref waveforms) in NR1 format

<slope> ::= {RISing | FALLing | EITHer}

The :MEASure:SLEWrate command installs a slew rate measurement on the oscilloscope's front-panel screen.

The slew rate of an edge is the change in vertical value between the lower and upper thresholds of a waveform source (typically volts) divided by the change in time between where the waveform threshold crossings take place.

The lower and upper thresholds for the measurement are specified by the measurement threshold settings for the source waveform (see :MEASure:DEFine). If the <source> parameter is not specified, the current :MEASure:SOURce setting is used

The on-screen edge closest to the timebase reference is measured.

You can specify that a RISing edge be measured, a FALLing edge be measured, or either a rising or a falling edge be measured (EITHer). If the <slope> is not specified, a rising edge is measured.

NOTE

This command is not available if the source is a FFT (Fast Fourier Transform) waveform.

Query Syntax :MEASure:SLEWrate? [<source>[,<slope>]]

The :MEASure:SLEWrate? query returns the measured slew rate of the specified edge closest to the timebase reference.

Return Format <value><NL>

<value> ::= slew rate in vertical units/second in NR3 format

- See Also**
- [":MEASure:DEFine"](#) on page 671
 - [":MEASure:SOURce"](#) on page 727
 - [":MEASure:RISetime"](#) on page 721
 - [":MEASure:FALLtime"](#) on page 684
 - ["Introduction to :MEASure Commands"](#) on page 658

:MEASure:SOURce

C (see [page 1730](#))

Command Syntax :MEASure:SOURce <source1>[,<source2>]

<source1>,<source2> ::= {<digital channels> | CHANnel<n> | FUNcTion<m>
| MATH<m> | WMEMory<r>}

<digital channels> ::= DIGital<d> for the MSO models

<n> ::= 1 to (# of analog channels) in NR1 format

<m> ::= 1 to (# math functions) in NR1 format

<r> ::= 1-2 in NR1 format

<d> ::= 0 to (# digital channels - 1) in NR1 format

The :MEASure:SOURce command sets the default sources for measurements. The specified sources are used as the sources for the MEASure subsystem commands if the sources are not explicitly set with the command.

If a source is specified for any measurement, the current source is changed to this new value.

If :MARKer:MODE is set to OFF or MANual, setting :MEASure:SOURce to CHANnel<n>, FUNcTion<m>, or MATH<m> will also set :MARKer:X1Y1source to source1 and :MARKer:X2Y2source to source2.

Query Syntax :MEASure:SOURce?

The :MEASure:SOURce? query returns the current source selections. If source2 is not specified, the query returns "NONE" for source2. If all channels are off, the query returns "NONE,NONE". Source2 applies only to :MEASure:DElay and :MEASure:PHASe measurements.

NOTE

MATH<m> is an alias for FUNcTion<m>. The query will return FUNC<m> if the source is FUNcTion<m> or MATH<m>.

NOTE

FUNcTion or MATH (without the "<m>" math function number) is an alias for FUNcTion2 or MATH2. The query will return FUNC2 if the source is FUNcTion or MATH.

Return Format <source1>,<source2><NL>

<source1>,<source2> ::= {<digital channels> | CHAN<n> | FUNc<m>
| WMEM<r> | NONE}

- See Also:**
- ["Introduction to :MEASure Commands"](#) on page 658
 - [":MARKer:MODE"](#) on page 617

- **":MARKer:X1Y1source"** on page 620
- **":MARKer:X2Y2source"** on page 623
- **":MEASure:DElay"** on page 674
- **":MEASure:PHASe"** on page 714

Example Code

```
' MEASURE - The commands in the MEASure subsystem are used to make
' measurements on displayed waveforms.
myScope.WriteString ":MEASure:SOURce CHANnel1" ' Source to measure.
myScope.WriteString ":MEASure:FREQuency?" ' Query for frequency.
varQueryResult = myScope.ReadNumber ' Read frequency.
MsgBox "Frequency:" + vbCrLf _
    + FormatNumber(varQueryResult / 1000, 4) + " kHz"
myScope.WriteString ":MEASure:DUTYcycle?" ' Query for duty cycle.
varQueryResult = myScope.ReadNumber ' Read duty cycle.
MsgBox "Duty cycle:" + vbCrLf _
    + FormatNumber(varQueryResult, 3) + "%"
myScope.WriteString ":MEASure:RISetime?" ' Query for risetime.
varQueryResult = myScope.ReadNumber ' Read risetime.
MsgBox "Risetime:" + vbCrLf _
    + FormatNumber(varQueryResult * 1000000, 4) + " us"
myScope.WriteString ":MEASure:VPP?" ' Query for Pk to Pk voltage.
varQueryResult = myScope.ReadNumber ' Read VPP.
MsgBox "Peak to peak voltage:" + vbCrLf _
    + FormatNumber(varQueryResult, 4) + " V"
myScope.WriteString ":MEASure:VMAX?" ' Query for Vmax.
varQueryResult = myScope.ReadNumber ' Read Vmax.
MsgBox "Maximum voltage:" + vbCrLf _
    + FormatNumber(varQueryResult, 4) + " V"
```

See complete example programs at: [Chapter 50](#), "Programming Examples," starting on page 1739

:MEASure:STATistics

N (see [page 1730](#))

Command Syntax :MEASure:STATistics <type>

```
<type> ::= {{ON | 1} | CURRent | MINimum | MAXimum | MEAN | STDDev
           | COUNT}
```

The :MEASure:STATistics command determines the type of information returned by the :MEASure:RESults? query. ON means all the statistics are on.

Query Syntax :MEASure:STATistics?

The :MEASure:STATistics? query returns the current statistics mode.

Return Format <type><NL>

```
<type> ::= {ON | CURR | MIN | MAX | MEAN | STDD | COUN}
```

- See Also**
- ["Introduction to :MEASure Commands"](#) on page 658
 - [":MEASure:RESults"](#) on page 718
 - [":MEASure:STATistics:DISPlay"](#) on page 730
 - [":MEASure:STATistics:RESet"](#) on page 733
 - [":MEASure:STATistics:INCRement"](#) on page 731

Example Code • ["Example Code"](#) on page 718

:MEASure:STATistics:DISPlay

N (see [page 1730](#))

Command Syntax :MEASure:STATistics:DISPlay {{0 | OFF} | {1 | ON}}

The :MEASure:STATistics:DISPlay command disables or enables the display of the measurement statistics.

Query Syntax :MEASure:STATistics:DISPlay?

The :MEASure:STATistics:DISPlay? query returns the state of the measurement statistics display.

Return Format {0 | 1}<NL>

- See Also**
- ["Introduction to :MEASure Commands"](#) on page 658
 - [":MEASure:RESults"](#) on page 718
 - [":MEASure:STATistics"](#) on page 729
 - [":MEASure:STATistics:MCOunt"](#) on page 732
 - [":MEASure:STATistics:RESet"](#) on page 733
 - [":MEASure:STATistics:INCRement"](#) on page 731
 - [":MEASure:STATistics:RSDeviation"](#) on page 734

:MEASure:STATistics:INCRement

N (see [page 1730](#))

Command Syntax :MEASure:STATistics:INCRement

This command updates the statistics once (incrementing the count by one) using the current measurement values. It corresponds to the front panel **Increment Statistics** softkey in the Measurement Statistics Menu. This command lets you, for example, gather statistics over multiple pulses captured in a single acquisition. To do this, change the horizontal position and enter the command for each new pulse that is measured.

This command is only allowed when the oscilloscope is stopped and quick measurements are on.

The command is allowed in segmented acquisition mode even though the corresponding front panel softkey is not available.

- See Also**
- ["Introduction to :MEASure Commands"](#) on page 658
 - [":MEASure:STATistics"](#) on page 729
 - [":MEASure:STATistics:DISPlay"](#) on page 730
 - [":MEASure:STATistics:RESet"](#) on page 733
 - [":MEASure:RESults"](#) on page 718

:MEASure:STATistics:MCOunt

N (see [page 1730](#))

Command Syntax :MEASure:STATistics:MCOunt <setting>

<setting> ::= {INFinite | <count>}

<count> ::= 2 to 2000 in NR1 format

The :MEASure:STATistics:MCOunt command specifies the maximum number of values used when calculating measurement statistics.

Query Syntax :MEASure:STATistics:MCOunt?

The :MEASure:STATistics:MCOunt? query returns the current measurement statistics max count setting.

Return Format <setting><NL>

<setting> ::= {INF | <count>}

<count> ::= 2 to 2000

- See Also**
- ["Introduction to :MEASure Commands"](#) on page 658
 - [":MEASure:RESults"](#) on page 718
 - [":MEASure:STATistics"](#) on page 729
 - [":MEASure:STATistics:DISPlay"](#) on page 730
 - [":MEASure:STATistics:RSDeviation"](#) on page 734
 - [":MEASure:STATistics:RESet"](#) on page 733
 - [":MEASure:STATistics:INCRement"](#) on page 731

:MEASure:STATistics:RESet

N (see [page 1730](#))

Command Syntax :MEASure:STATistics:RESet

This command resets the measurement statistics, zeroing the counts.

Note that the measurement (statistics) configuration is not deleted.

- See Also**
- ["Introduction to :MEASure Commands"](#) on page 658
 - [":MEASure:STATistics"](#) on page 729
 - [":MEASure:STATistics:DISPlay"](#) on page 730
 - [":MEASure:RESults"](#) on page 718
 - [":MEASure:STATistics:INCRement"](#) on page 731

- Example Code**
- ["Example Code"](#) on page 718

:MEASure:STATistics:RSDeviation

N (see [page 1730](#))

Command Syntax :MEASure:STATistics:RSDeviation {{0 | OFF} | {1 | ON}}

The :MEASure:STATistics:RSDeviation command disables or enables relative standard deviations, that is, standard deviation/mean, in the measurement statistics.

Query Syntax :MEASure:STATistics:RSDeviation?

The :MEASure:STATistics:RSDeviation? query returns the current relative standard deviation setting.

Return Format {0 | 1}<NL>

- See Also**
- ["Introduction to :MEASure Commands"](#) on page 658
 - [":MEASure:RESults"](#) on page 718
 - [":MEASure:STATistics"](#) on page 729
 - [":MEASure:STATistics:DISPlay"](#) on page 730
 - [":MEASure:STATistics:MCOunt"](#) on page 732
 - [":MEASure:STATistics:RESet"](#) on page 733
 - [":MEASure:STATistics:INCRement"](#) on page 731

:MEASure:TEDGE

N (see [page 1730](#))

Command Syntax :MEASure:TEDGE [<slope>,<occurrence>[,<source>]
 <slope> ::= {RISing | FALLing | EITHER}
 <occurrence> ::= [+ | -]<number>
 <number> ::= the edge number in NR1 format
 <source> ::= {<digital channels> | CHANnel<n> | FUNction<m> | MATH<m>
 | WMEMory<r>}
 <digital channels> ::= DIGital<d> for the MSO models
 <n> ::= 1 to (# of analog channels) in NR1 format
 <m> ::= 1 to (# math functions) in NR1 format
 <r> ::= 1 to (# ref waveforms) in NR1 format
 <d> ::= 0 to (# digital channels - 1) in NR1 format

The :MEASure:TEDGE command installs a screen measurement whose result is the time of the specified edge transition relative to the trigger edge (time=zero).

The threshold voltage used for this measurement is at the 50% point with a small amount of hysteresis added. You cannot change the threshold voltage used for this measurement with the :MEASure:DEFine command.

The optional <slope> parameter specifies whether to look for RISing edges or FALLing edges. If not otherwise specified, rising edges are assumed.

The <occurrence> parameter specifies the Nth edge to identify.

An <occurrence> value of zero (0) means the edge closest to the timebase reference; it is equivalent to the **Auto** selection for the **Edge #** in the front panel user interface. The EITHER (either edge) <slope> option can be used only when the <occurrence> count is zero (0).

Any other <occurrence> value means the Nth edge from the left side of the display.

The <occurrence> parameter can optionally have a plus sign (+) or a minus sign (-) to specify a rising or falling slope. Plus or minus signs cannot be used when the <slope> parameter is used.

If the optional <source> parameter is not specified, the current :MEASure:SOURce setting is used.

NOTE

This command is not available if the source is a FFT (Fast Fourier Transform) waveform.

Query Syntax :MEASure:TEDGE? [<slope>,<occurrence>[,<source>]

When the :MEASure:TEDGE query is sent, the displayed signal is searched for the specified transition.

The time interval between the trigger event and the edge occurrence is returned.

If the specified crossing cannot be found, the oscilloscope returns +9.9E+37. This value is returned if the waveform does not cross the specified vertical value, or if the waveform does not cross the specified vertical value for the specific number of times in the direction specified.

Return Format <value><NL>

<value> ::= time in seconds of the specified transition in NR3 format

:MEASure:TEDGE Code You can use multiple :MEASure:TEDGE? measurements to form delay and phase measurements:

Delay = time at the Nth rising or falling edge of the channel - time at the same edge of another channel

Phase = (delay between channels / period of channel) x 360

For example:

```
' Make a delay measurement between channel 1 and 2.
Dim dblChan1Edge1 As Double
Dim dblChan2Edge1 As Double
Dim dblChan1Edge2 As Double
Dim dblDelay As Double
Dim dblPeriod As Double
Dim dblPhase As Double

' Query time at 1st rising edge on ch1.
myScope.WriteString ":MEASURE:TEDGE? +1, CHAN1"

' Read time at edge 1 on ch 1.
dblChan1Edge1 = myScope.ReadNumber

' Query time at 1st rising edge on ch2.
myScope.WriteString ":MEASURE:TEDGE? +1, CHAN2"

' Read time at edge 1 on ch 2.
dblChan2Edge1 = myScope.ReadNumber

' Calculate delay time between ch1 and ch2.
dblDelay = dblChan2Edge1 - dblChan1Edge1

' Write calculated delay time to screen.
MsgBox "Delay = " + vbCrLf + CStr(dblDelay)

' Make a phase difference measurement between channel 1 and 2.
' Query time at 1st rising edge on ch1.
myScope.WriteString ":MEASURE:TEDGE? +2, CHAN1"

' Read time at edge 2 on ch 1.
```



```
dblChan1Edge2 = myScope.ReadNumber

' Calculate period of ch 1.
dblPeriod = dblChan1Edge2 - dblChan1Edge1

' Calculate phase difference between ch1 and ch2.
dblPhase = (dblDelay / dblPeriod) * 360
MsgBox "Phase = " + vbCrLf + CStr(dblPhase)
```

See complete example programs at: [Chapter 50](#), “Programming Examples,” starting on page 1739

- See Also**
- ["Introduction to :MEASure Commands"](#) on page 658
 - [":MEASure:TVALue"](#) on page 742
 - [":MEASure:VTIME"](#) on page 1651

:MEASure:TIEData

N (see [page 1730](#))

Command Syntax

NOTE


This measurement is available when the optional jitter analysis feature is licensed

```
:MEASure:TIEData <config>
<config> ::= <source>, {SECond | UNITinterval}
<source> ::= {CHANnel<n> | FUNCTion<m> | MATH<m> | WMEMory<r>}
<n> ::= 1 to (# analog channels) in NR1 format
<m> ::= 1 to (# math functions) in NR1 format
<r> ::= 1 to (# ref waveforms) in NR1 format
```

The :MEASure:TIEData command installs a data TIE jitter measurement on screen.

The Data TIE (Time Interval Error) jitter measurement compares edges in a data signal with the edges in an ideal data signal determined by the clock recovery feature. To change the clock recovery method, see **":CLOCK:METHOD"** on page 386.

Once the ideal data rate is determined, all of the data intervals are measured with respect to the ideal data rate and the error statistics are computed. The following figure shows how the Data TIE is measured on rising edges of the data.



The measurement is made on all the cycles of the waveform. Even in Zoom mode, all the cycles of the waveform in the Main window will be measured.

Query Syntax :MEASure:TIEData? <config>

The :MEASure:TIEData? query measures and returns the Data TIE jitter value.

Return Format

```
<value><NL>
<value> ::= Clock TIE jitter in NR3 format
```

- See Also
- [":MEASure:TIEClock"](#) on page 740
 - [Chapter 25](#), "JITTer Commands," starting on page 575

:MEASure:TIEClock

N (see [page 1730](#))

Command Syntax

NOTE


This measurement is available when the optional jitter analysis feature is licensed

```
:MEASure:TIEClock <config>
<config> ::= <source>, {SECond | UNITinterval}, <direction>
<source> ::= {CHANnel<n> | FUNction<m> | MATH<m> | WMEMory<r>}
<n> ::= 1 to (# analog channels) in NR1 format
<m> ::= 1 to (# math functions) in NR1 format
<r> ::= 1 to (# ref waveforms) in NR1 format
<direction> ::= {RISing | FALLing | BOTH}
```

The :MEASure:TIEClock command installs a clock TIE jitter measurement on screen.

The Clock TIE (Time Interval Error) jitter measurement compares edges in a clock signal with the edges in an ideal clock signal determined by the clock recovery feature. To change the clock recovery method, see **":CLOCK:METHOD"** on page 386.

Once the ideal clock frequency is determined, all of the cycles of your waveform are compared to the ideal clock frequency and the error statistics are computed. The following figure shows how the Clock TIE is measured on rising edges of the clock.



The measurement is made on all the cycles of the waveform. Even in Zoom mode, all the cycles of the waveform in the Main window will be measured.

Query Syntax :MEASure:TIEClock? <config>

The :MEASure:TIEClock? query measures and returns the Clock TIE jitter value.

Return Format

```
<value><NL>
```

```
<value> ::= Clock TIE jitter in NR3 format
```

- See Also
- [":MEASure:TIEData"](#) on page 738
 - [Chapter 25](#), "JITTer Commands," starting on page 575

:MEASure:TVALue

C (see [page 1730](#))

Query Syntax :MEASure:TVALue? <value>, [<slope>]<occurrence>[,<source>]

<value> ::= the vertical value that the waveform must cross. The value can be volts or a math function value such as dB, Vs, or V/s.

<slope> ::= direction of the waveform. A rising slope is indicated by a plus sign (+). A falling edge is indicated by a minus sign (-).

<occurrence> ::= the transition to be reported. If the occurrence number is one, the first crossing is reported. If the number is two, the second crossing is reported, etc.

<source> ::= {CHANnel<n> | FUNCTION<m> | MATH<m> | WMEMory<r>}

<n> ::= 1 to (# analog channels) in NR1 format

<m> ::= 1 to (# math functions) in NR1 format

<r> ::= 1 to (# ref waveforms) in NR1 format

When the :MEASure:TVALue? query is sent, the displayed signal is searched for the specified value level and transition. The time interval between the trigger event and this defined occurrence is returned as the response to the query.

The specified value can be negative or positive. To specify a negative value, use a minus sign (-). The sign of the slope selects a rising (+) or falling (-) edge. If no sign is specified for the slope, it is assumed to be the rising edge.

The magnitude of the occurrence defines the occurrence to be reported. For example, +3 returns the time for the third time the waveform crosses the specified value level in the positive direction. Once this value crossing is found, the oscilloscope reports the time at that crossing in seconds, with the trigger point (time zero) as the reference.

If the specified crossing cannot be found, the oscilloscope reports +9.9E+37. This value is returned if the waveform does not cross the specified value, or if the waveform does not cross the specified value for the specified number of times in the direction specified.

If the optional source parameter is specified, the current source is modified.

NOTE

This query is not available if the source is FFT (Fast Fourier Transform).

Return Format <value><NL>

<value> ::= time in seconds of the specified value crossing in
NR3 format

- See Also
- ["Introduction to :MEASure Commands"](#) on page 658
 - [":MEASure:TEDGe"](#) on page 735
 - [":MEASure:VTIMe"](#) on page 1651

:MEASure:VAMPlitude

C (see [page 1730](#))

Command Syntax :MEASure:VAMPlitude [<source>]
 <source> ::= {CHANnel<n> | FUNction<m> | MATH<m> | WMEMory<r>}
 <n> ::= 1 to (# analog channels) in NR1 format
 <m> ::= 1 to (# math functions) in NR1 format
 <r> ::= 1 to (# ref waveforms) in NR1 format

The :MEASure:VAMPlitude command installs a screen measurement and starts a vertical amplitude measurement. If the optional source parameter is specified, the current source is modified.

Query Syntax :MEASure:VAMPlitude? [<source>]

The :MEASure:VAMPlitude? query measures and returns the vertical amplitude of the waveform. To determine the amplitude, the instrument measures Vtop and Vbase, then calculates the amplitude as follows:

$$\text{vertical amplitude} = V_{\text{top}} - V_{\text{base}}$$

Return Format <value><NL>
 <value> ::= the amplitude of the selected waveform in NR3 format

- See Also**
- ["Introduction to :MEASure Commands"](#) on page 658
 - [":MEASure:SOURce"](#) on page 727
 - [":MEASure:VBASe"](#) on page 746
 - [":MEASure:VTOP"](#) on page 752
 - [":MEASure:VPP"](#) on page 749

:MEASure:VAverage

C (see [page 1730](#))

Command Syntax :MEASure:VAverage [<interval>][,<source>]
 <interval> ::= {CYCLe | DISPlay}
 <source> ::= {CHANnel<n> | FUNCTION<m> | MATH<m> | WMEMory<r>}
 <n> ::= 1-2 or 1-4 (# of analog channels) in NR1 format
 <m> ::= 1 to (# math functions) in NR1 format
 <r> ::= 1 to (# ref waveforms) in NR1 format

The :MEASure:VAverage command installs a screen measurement and starts an average value measurement.

The <interval> option lets you specify the measurement interval: either an integral number of cycles, or the full screen. If <interval> is not specified, DISPlay is implied.

If the optional source parameter is specified, the current source is modified.

Query Syntax :MEASure:VAverage? [<interval>][,<source>]

The :MEASure:VAverage? query returns the average value of an integral number of periods of the signal.

Return Format <value><NL>
 <value> ::= calculated average value in NR3 format

- See Also**
- ["Introduction to :MEASure Commands"](#) on page 658
 - [":MEASure:SOURce"](#) on page 727

:MEASure:VBASe

C (see [page 1730](#))

Command Syntax :MEASure:VBASe [<source>]
 <source> ::= {CHANnel<n> | FUNCTION<m> | MATH<m> | WMEMory<r>}
 <n> ::= 1 to (# analog channels) in NR1 format
 <m> ::= 1 to (# math functions) in NR1 format
 <r> ::= 1 to (# ref waveforms) in NR1 format

The :MEASure:VBASe command installs a screen measurement and starts a waveform base value measurement. If the optional source parameter is specified, the current source is modified.

NOTE

This command is not available if the source is FFT (Fast Fourier Transform).

Query Syntax :MEASure:VBASe? [<source>]

The :MEASure:VBASe? query returns the vertical value at the base of the waveform. The base value of a pulse is normally not the same as the minimum value.

Return Format <base_voltage><NL>
 <base_voltage> ::= value at the base of the selected waveform in NR3 format

- See Also**
- ["Introduction to :MEASure Commands"](#) on page 658
 - [":MEASure:SOURce"](#) on page 727
 - [":MEASure:VTOP"](#) on page 752
 - [":MEASure:VAMPLitude"](#) on page 744
 - [":MEASure:VMIN"](#) on page 748

:MEASure:VMAX

C (see [page 1730](#))

Command Syntax :MEASure:VMAX [<source>]

<source> ::= {CHANnel<n> | FUNction<m> | MATH<m> | WMEMory<r>}

<n> ::= 1-2 or 1-4 (# of analog channels) in NR1 format

<m> ::= 1 to (# math functions) in NR1 format

<r> ::= 1 to (# ref waveforms) in NR1 format

The :MEASure:VMAX command installs a screen measurement and starts a maximum vertical value measurement. If the optional source parameter is specified, the current source is modified.

Query Syntax :MEASure:VMAX? [<source>]

The :MEASure:VMAX? query measures and outputs the maximum vertical value present on the selected waveform.

Return Format <value><NL>

<value> ::= maximum vertical value of the selected waveform in NR3 format

- See Also**
- ["Introduction to :MEASure Commands"](#) on page 658
 - [":MEASure:SOURce"](#) on page 727
 - [":MEASure:VMIN"](#) on page 748
 - [":MEASure:VPP"](#) on page 749
 - [":MEASure:VTOP"](#) on page 752

:MEASure:VMIN

C (see [page 1730](#))

Command Syntax :MEASure:VMIN [<source>]

<source> ::= {CHANnel<n> | FUNction<m> | MATH<m> | WMEMory<r>}

<n> ::= 1 to (# analog channels) in NR1 format

<m> ::= 1 to (# math functions) in NR1 format

<r> ::= 1 to (# ref waveforms) in NR1 format

The :MEASure:VMIN command installs a screen measurement and starts a minimum vertical value measurement. If the optional source parameter is specified, the current source is modified.

Query Syntax :MEASure:VMIN? [<source>]

The :MEASure:VMIN? query measures and outputs the minimum vertical value present on the selected waveform.

Return Format <value><NL>

<value> ::= minimum vertical value of the selected waveform in NR3 format

- See Also**
- ["Introduction to :MEASure Commands"](#) on page 658
 - [":MEASure:SOURce"](#) on page 727
 - [":MEASure:VBASe"](#) on page 746
 - [":MEASure:VMAX"](#) on page 747
 - [":MEASure:VPP"](#) on page 749

:MEASure:VPP

C (see [page 1730](#))

Command Syntax :MEASure:VPP [<source>]

<source> ::= {CHANnel<n> | FUNCTION<m> | MATH<m> | WMemory<r>}

<n> ::= 1 to (# analog channels) in NR1 format

<m> ::= 1 to (# math functions) in NR1 format

<r> ::= 1 to (# ref waveforms) in NR1 format

The :MEASure:VPP command installs a screen measurement and starts a vertical peak-to-peak measurement. If the optional source parameter is specified, the current source is modified.

Query Syntax :MEASure:VPP? [<source>]

The :MEASure:VPP? query measures the maximum and minimum vertical value for the selected source, then calculates the vertical peak-to-peak value and returns that value. The peak-to-peak value (Vpp) is calculated with the following formula:

$$V_{pp} = V_{max} - V_{min}$$

Vmax and Vmin are the vertical maximum and minimum values present on the selected source.

Return Format <value><NL>

<value> ::= vertical peak to peak value in NR3 format

- See Also**
- ["Introduction to :MEASure Commands"](#) on page 658
 - [":MEASure:SOURce"](#) on page 727
 - [":MEASure:VMAX"](#) on page 747
 - [":MEASure:VMIN"](#) on page 748
 - [":MEASure:VAMPLitude"](#) on page 744

:MEASure:VRATio

N (see [page 1730](#))

Command Syntax :MEASure:VRATio [<interval>] [,<source1>] [,<source2>]
 <interval> ::= {CYCLe | DISPlay}
 <source1,2> ::= {CHANnel<n> | FUNCTion<m> | MATH<m> | WMEMory<r>}
 <n> ::= 1 to (# analog channels) in NR1 format
 <m> ::= 1 to (# math functions) in NR1 format
 <r> ::= 1 to (# ref waveforms) in NR1 format

The :MEASure:VRATio command installs a ratio measurement on screen. Ratio measurements show the ratio of the ACRMS value of source1 to that of source2, expressed in dB.

The <interval> option lets you specify the measurement interval: either an integral number of cycles, or the full screen. If <interval> is not specified, DISPlay is implied.

NOTE

This command is not available if the source is FFT (Fast Fourier Transform).

Query Syntax :MEASure:VRATio? [<interval>] [<source1>] [,<source2>]

The :MEASure:VRATio? query measures and returns the ratio of AC RMS values of the specified sources expressed as dB.

Return Format <value><NL>
 <value> ::= the ratio value in dB in NR3 format

- See Also**
- ["Introduction to :MEASure Commands"](#) on page 658
 - [":MEASure:VRMS"](#) on page 751
 - [":MEASure:SOURce"](#) on page 727

:MEASure:VRMS

C (see [page 1730](#))

Command Syntax :MEASure:VRMS [<interval>] [,<type>] [,<source>]
 <interval> ::= {CYCLe | DISPlay}
 <type> ::= {AC | DC}
 <source> ::= {CHANnel<n> | FUNCTION<m> | MATH<m> | WMEMory<r>}
 <n> ::= 1-2 or 1-4 (# of analog channels) in NR1 format
 <m> ::= 1 to (# math functions) in NR1 format
 <r> ::= 1 to (# ref waveforms) in NR1 format

The :MEASure:VRMS command installs a screen measurement and starts an RMS value measurement.

The <interval> option lets you specify the measurement interval: either an integral number of cycles, or the full screen. If <interval> is not specified, DISPlay is implied.

The <type> option lets you choose between a DC RMS measurement and an AC RMS measurement. If <type> is not specified, DC is implied.

If the optional source parameter is specified, the current source is modified.

NOTE

This command is not available if the source is FFT (Fast Fourier Transform).

Query Syntax :MEASure:VRMS? [<interval>] [,<type>] [,<source>]

The :MEASure:VRMS? query measures and outputs the RMS measurement value.

Return Format <value><NL>

<value> ::= calculated dc RMS value in NR3 format

- See Also**
- ["Introduction to :MEASure Commands"](#) on page 658
 - [":MEASure:SOURce"](#) on page 727

:MEASure:VTOP

C (see [page 1730](#))

Command Syntax :MEASure:VTOP [<source>]

<source> ::= {CHANnel<n> | FUNction<m> | MATH<m>}

<n> ::= 1-2 or 1-4 (# of analog channels) in NR1 format

<m> ::= 1 to (# math functions) in NR1 format

<r> ::= 1 to (# ref waveforms) in NR1 format

The :MEASure:VTOP command installs a screen measurement and starts a waveform top value measurement.

NOTE

This query is not available if the source is FFT (Fast Fourier Transform).

Query Syntax :MEASure:VTOP? [<source>]

The :MEASure:VTOP? query returns the vertical value at the top of the waveform. The top value of the pulse is normally not the same as the maximum value.

Return Format <value><NL>

<value> ::= vertical value at the top of the waveform in NR3 format

- See Also**
- ["Introduction to :MEASure Commands"](#) on page 658
 - [":MEASure:SOURce"](#) on page 727
 - [":MEASure:VMAX"](#) on page 747
 - [":MEASure:VAMPLitude"](#) on page 744
 - [":MEASure:VBASe"](#) on page 746

:MEASure:WINDow

N (see [page 1730](#))

Command Syntax :MEASure:WINDow <type>

<type> ::= {MAIN | ZOOM | AUTO | GATE}

The :MEASure:WINDow command lets you choose whether measurements are made in the Main window portion of the display, the Zoom window portion of the display (when the zoomed time base is displayed), or gated by the X1 and X2 cursors.

- MAIN – the measurement window is the Main window.
- ZOOM – the measurement window is the lower, Zoom window.
- AUTO – when the zoomed time base is displayed, the measurement is attempted in the lower, Zoom window; if it cannot be made there, or if the zoomed time base is not displayed, the Main window is used.
- GATE – the measurement window is between the X1 and X2 cursors. When the zoomed time base is displayed, the X1 and X2 cursors in the Zoom window portion of the display are used.

Query Syntax :MEASure:WINDow?

The :MEASure:WINDow? query returns the current measurement window setting.

Return Format <type><NL>

<type> ::= {MAIN | ZOOM | AUTO | GATE}

- See Also**
- ["Introduction to :MEASure Commands"](#) on page 658
 - [":MEASure:SOURce"](#) on page 727

:MEASure:XMAX

N (see [page 1730](#))

Command Syntax :MEASure:XMAX [<source>]
 <source> ::= {CHANnel<n> | FUNction<m> | MATH<m> | WMEMory<r>}
 <n> ::= 1-2 or 1-4 (# of analog channels) in NR1 format
 <m> ::= 1 to (# math functions) in NR1 format
 <r> ::= 1 to (# ref waveforms) in NR1 format

The :MEASure:XMAX command installs a screen measurement and starts an X-at-Max-Y measurement on the selected window. If the optional source parameter is specified, the current source is modified.

NOTE

:MEASure:XMAX is an alias for :MEASure:TMAX.

Query Syntax :MEASure:XMAX? [<source>]

The :MEASure:XMAX? query measures and returns the horizontal axis value at which the maximum vertical value occurs. If the optional source is specified, the current source is modified.

Return Format <value><NL>
 <value> ::= horizontal value of the maximum in NR3 format

- See Also**
- ["Introduction to :MEASure Commands"](#) on page 658
 - [":MEASure:XMIN"](#) on page 755
 - [":MEASure:TMAX"](#) on page 1642

:MEASure:XMIN

N (see [page 1730](#))

Command Syntax :MEASure:XMIN [<source>]
 <source> ::= {CHANnel<n> | FUNCTION<m> | MATH<m> | WMEMory<r>}
 <n> ::= 1-2 or 1-4 (# of analog channels) in NR1 format
 <m> ::= 1 to (# math functions) in NR1 format
 <r> ::= 1 to (# ref waveforms) in NR1 format

The :MEASure:XMIN command installs a screen measurement and starts an X-at-Min-Y measurement on the selected window. If the optional source parameter is specified, the current source is modified.

NOTE

:MEASure:XMIN is an alias for :MEASure:TMIN.

Query Syntax :MEASure:XMIN? [<source>]

The :MEASure:XMIN? query measures and returns the horizontal axis value at which the minimum vertical value occurs. If the optional source is specified, the current source is modified.

Return Format <value><NL>
 <value> ::= horizontal value of the minimum in NR3 format

- See Also**
- ["Introduction to :MEASure Commands"](#) on page 658
 - [":MEASure:XMAX"](#) on page 754
 - [":MEASure:TMIN"](#) on page 1643

:MEASure:YATX

N (see [page 1730](#))

Query Syntax :MEASure:YATX <horiz_location>[,<source>]

<horiz_location> ::= time from trigger in seconds

<source> ::= {<digital channels> | CHANnel<n> | FUNction<m> | MATH<m>
| WMEMory<r>}

<digital channels> ::= DIGital<d> for the MSO models

<d> ::= 0 to (# digital channels - 1) in NR1 format

<n> ::= 1 to (# of analog channels) in NR1 format

<m> ::= 1 to (# math functions) in NR1 format

<r> ::= 1 to (# ref waveforms) in NR1 format

The :MEASure:YATX command installs a screen measurement of the vertical value at a specified horizontal value on the source specified (see also :MEASure:SOURce).

The specified horizontal value must be on the screen; when it is a time value, it is referenced to the trigger event. If the optional source parameter is specified, the measurement source is modified.

NOTE

When the source is an FFT (Fast Fourier Transform) waveform, the <horiz_location> is a frequency value instead of a time value.

Query Syntax :MEASure:YATX? <horiz_location>[,<source>]

The :MEASure:YATX? query returns the vertical value at a specified horizontal value on the source specified (see also :MEASure:SOURce).

Return Format <value><NL>

<value> ::= vertical value at the specified horizontal location
in NR3 format

- See Also**
- ["Introduction to :MEASure Commands"](#) on page 658
 - [":MEASure:SOURce"](#) on page 727
 - [":MEASure:TEDGe"](#) on page 735
 - [":MEASure:TVALue"](#) on page 742

30 :MEASure Power Commands

These :MEASure commands are available when the power measurements and analysis application is licensed and enabled.

Table 120 :MEASure Power Commands Summary

Command	Query	Options and Query Returns
:MEASure:ANGLE [<source1>] [, <source2 >] (see page 762)	:MEASure:ANGLE? [<source1>] [, <source2 >] (see page 762)	<source1>, <source2> ::= {CHANnel<n>} <n> ::= 1 to (# analog channels) in NR1 format <return_value> ::= the power phase angle in degrees in NR3 format
:MEASure:APParent [<source1>] [, <source2 >] (see page 763)	:MEASure:APParent? [<source1>] [, <source2 >] (see page 763)	<source1>, <source2> ::= {CHANnel<n>} <n> ::= 1 to (# analog channels) in NR1 format <return_value> ::= the apparent power value in NR3 format
:MEASure:CPLoss [<source1>] [, <source2 >] (see page 764)	:MEASure:CPLoss? [<source1>] [, <source2 >] (see page 764)	<source1>, <source2> <source1> ::= {FUNCTION<m> MATH<m>} <source2> ::= {CHANnel<n>} <m> ::= 1 to (# math functions) in NR1 format <n> ::= 1 to (# analog channels) in NR1 format <return_value> ::= the switching loss per cycle watts value in NR3 format

Table 120 :MEASure Power Commands Summary (continued)

Command	Query	Options and Query Returns
:MEASure:CRESt [<source>] (see page 765)	:MEASure:CRESt? [<source>] (see page 765)	<source> ::= {CHANnel<n> FUNction<m> MATH<m>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <return_value> ::= the crest factor value in NR3 format
:MEASure:EFFiciency (see page 766)	:MEASure:EFFiciency? (see page 766)	<return_value> ::= percent value in NR3 format
:MEASure:ELOSs [<source>] (see page 767)	:MEASure:ELOSs? [<source>] (see page 767)	<source> ::= {CHANnel<n> FUNction<m> MATH<m> WMEMOry<r>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <return_value> ::= the energy loss value in NR3 format
:MEASure:FACTOR [<source1>] [,<source2 >] (see page 768)	:MEASure:FACTOR? [<source1>] [,<source2 >] (see page 768)	<source1>, <source2> ::= {CHANnel<n>} <n> ::= 1 to (# analog channels) in NR1 format <return_value> ::= the power factor value in NR3 format
:MEASure:IPower (see page 769)	:MEASure:IPower? (see page 769)	<return_value> ::= the input power value in NR3 format
:MEASure:OFFTime [<source1>] [,<source2 >] (see page 770)	:MEASure:OFFTime? [<source1>] [,<source2 >] (see page 770)	<source1>, <source2> ::= {CHANnel<n>} <n> ::= 1 to (# analog channels) in NR1 format <return_value> ::= the time in seconds in NR3 format

Table 120 :MEASure Power Commands Summary (continued)

Command	Query	Options and Query Returns
:MEASure:ONTime [<source1>] [, <source2>] >] (see page 771)	:MEASure:ONTime? [<source1>] [, <source2>] >] (see page 771)	<source1>, <source2> ::= {CHANnel<n>} <n> ::= 1 to (# analog channels) in NR1 format <return_value> ::= the time in seconds in NR3 format
:MEASure:OPower (see page 772)	:MEASure:OPower? (see page 772)	<return_value> ::= the output power value in NR3 format
:MEASure:PCURrent [<source>] (see page 773)	:MEASure:PCURrent? [<source>] (see page 773)	<source> ::= {CHANnel<n> FUNCTION<m> MATH<m> WMemory<r>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <return_value> ::= the peak current value in NR3 format
:MEASure:PLOSS [<source>] (see page 774)	:MEASure:PLOSS? [<source>] (see page 774)	<source> ::= {CHANnel<n> FUNCTION<m> MATH<m> WMemory<r>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <return_value> ::= the power loss value in NR3 format

Table 120 :MEASure Power Commands Summary (continued)

Command	Query	Options and Query Returns
:MEASure:RDson [<source1>] [, <source2>] >] (see page 775)	:MEASure:RDson? [<source1>] [, <source2>] >] (see page 775)	<source1>, <source2> ::= {CHANnel<n> FUNCTION<m> MATH<m> WMemory<r>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <return_value> ::= the Rds(on) value in NR3 format
:MEASure:REACTIVE [<source1>] [, <source2>] >] (see page 776)	:MEASure:REACTIVE? [<source1>] [, <source2>] >] (see page 776)	<source1>, <source2> ::= {CHANnel<n>} <n> ::= 1 to (# analog channels) in NR1 format <return_value> ::= the reactive power value in NR3 format
:MEASure:REAL [<source>] (see page 777)	:MEASure:REAL? [<source>] (see page 777)	<source> ::= {CHANnel<n> FUNCTION<m> MATH<m>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <return_value> ::= the real power value in NR3 format
:MEASure:RIPple [<source>] (see page 778)	:MEASure:RIPple? [<source>] (see page 778)	<source> ::= {CHANnel<n> FUNCTION<m> MATH<m> WMemory<r>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <return_value> ::= the output ripple value in NR3 format

Table 120 :MEASure Power Commands Summary (continued)

Command	Query	Options and Query Returns
:MEASure:TRESponse [<source>] (see page 779)	:MEASure:TRESponse? [<source>] (see page 779)	<source> ::= {CHANnel<n> FUNction<m> MATH<m> WMEMory<r>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <return_value> ::= time in seconds for the overshoot to settle back into the band in NR3 format
:MEASure:VCESat [<source>] (see page 780)	:MEASure:VCESat? [<source>] (see page 780)	<source> ::= {CHANnel<n> FUNction<m> MATH<m> WMEMory<r>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <return_value> ::= the Vce(sat) value in NR3 format

:MEASure:ANGLE

N (see [page 1730](#))

Command Syntax :MEASure:ANGLE [<source1>] [,<source2>]

<source1>, <source2> ::= {CHANnel<n>}

<n> ::= 1 to (# analog channels) in NR1 format

The :MEASure:ANGLE command installs a power phase angle measurement on screen.

The <source1> parameter is the channel probing voltage and the <source2> parameter is the channel probing current. These sources can also be specified by the :MEASure:SOURce command.

Phase angle is a measure of power quality. In the *power triangle* (the right triangle where $\text{apparent_power}^2 = \text{real_power}^2 + \text{reactive_power}^2$), phase angle is the angle between the apparent power and the real power, indicating the amount of reactive power. Small phase angles equate to less reactive power.

Query Syntax :MEASure:ANGLE? [<source1>] [,<source2>]

The :MEASure:ANGLE query returns the measured power phase angle in degrees.

Return Format <return_value><NL>

<return_value> ::= the power phase angle in degrees in NR3 format

- See Also**
- [":MEASure:SOURce"](#) on page 727
 - [":POWer:QUALity:APPLY"](#) on page 890

:MEASure:APParent

N (see [page 1730](#))

Command Syntax :MEASure:APParent [<source1>][,<source2>]

<source1>, <source2> ::= {CHANnel<n>}

<n> ::= 1 to (# analog channels) in NR1 format

The :MEASure:APParent command installs an apparent power measurement on screen.

The <source1> parameter is the channel probing voltage and the <source2> parameter is the channel probing current. These sources can also be specified by the :MEASure:SOURce command.

Apparent power is a measure of power quality. It is the portion of AC line power flow due to stored energy which returns to the source in each cycle.

$IRMS * VRMS$

Query Syntax :MEASure:APParent? [<source1>][,<source2>]

The :MEASure:APParent query returns the measured apparent power.

Return Format <return_value><NL>

<return_value> ::= the apparent power value in NR3 format

- See Also**
- [":MEASure:SOURce"](#) on page 727
 - [":POWer:QUALity:APPLY"](#) on page 890

:MEASure:CPLoss

N (see [page 1730](#))

Command Syntax :MEASure:CPLoss [<source1>] [,<source2>]

<source1> ::= {FUNCTION<m> | MATH<m>}

<source2> ::= {CHANnel<n>}

<m> ::= 1 to (# math functions) in NR1 format

<n> ::= 1 to (# analog channels) in NR1 format

The :MEASure:CPLoss command installs a power loss per cycle measurement on screen.

The <source1> parameter is typically a math multiply waveform or other waveform that represents power (voltage * current). This source can also be specified by the :MEASure:SOURce command.

Power loss per cycle is $P_n = (V_{dsn} * I_{dn}) * (\text{Time range of zoom window}) * (\text{Counter measurement of the voltage of the switching signal})$, where n is each sample.

This measurement operates when in zoom mode and the counter measurement is installed on the voltage of the switching signal.

Query Syntax :MEASure:CPLoss? [<source1>] [,<source2>]

The :MEASure:CPLoss query returns the switching loss per cycle in watts.

Return Format <return_value><NL>

<return_value> ::= the switching loss per cycle value in NR3 format

- See Also**
- [":MEASure:SOURce"](#) on page 727
 - [":POWer:SWITCh:APPLY"](#) on page 913

:MEASure:CRESt

N (see [page 1730](#))

Command Syntax :MEASure:CRESt [<source>]
 <source> ::= {CHANnel<n> | FUNction<m> | MATH<m>}
 <n> ::= 1 to (# analog channels) in NR1 format
 <m> ::= 1 to (# math functions) in NR1 format

The :MEASure:CRESt command installs a crest factor measurement on screen.

The <source> parameter is the channel probing current or voltage. This source can also be specified by the :MEASure:SOURce command.

Crest factor is a measure of power quality. It is the ratio between the instantaneous peak AC line current (or voltage) required by the load and the RMS current (or voltage). For example: I_{peak} / I_{RMS} or V_{peak} / V_{RMS} .

Query Syntax :MEASure:CRESt? [<source>]

The :MEASure:CRESt query returns the measured crest factor.

Return Format <return_value><NL>
 <return_value> ::= the crest factor value in NR3 format

- See Also**
- [":MEASure:SOURce"](#) on page 727
 - [":POWer:QUALity:APPLY"](#) on page 890

:MEASure:EFFiciency

N (see [page 1730](#))

Command Syntax :MEASure:EFFiciency

The :MEASure:EFFiciency command installs an efficiency (output power / input power) measurement on screen.

Before sending this command or query, you must specify the channels probing the input voltage, input current, output voltage, and output current (using the :POWer:SIGNals:SOURce:VOLTage<i> and :POWer:SIGNals:SOURce:CURRent<i> commands) and you must perform the automated signals setup (using the :POWer:SIGNals:AUTosetup EFFiciency command).

Query Syntax :MEASure:EFFiciency?

The :MEASure:EFFiciency query returns the measured efficiency as a percent value.

Return Format <return_value><NL>

<return_value> ::= percent value in NR3 format

- See Also**
- [":POWer:SIGNals:SOURce:VOLTage<i>"](#) on page 910
 - [":POWer:SIGNals:SOURce:CURRent<i>"](#) on page 909
 - [":POWer:SIGNals:AUTosetup"](#) on page 892
 - [":POWer:EFFiciency:APPLY"](#) on page 848

:MEASure:ELOSs

N (see [page 1730](#))

Command Syntax :MEASure:ELOSs [<source>]

<source> ::= {CHANnel<n> | FUNCTION<m> | MATH<m> | WMemory<r>}

<n> ::= 1 to (# analog channels) in NR1 format

<m> ::= 1 to (# math functions) in NR1 format

<r> ::= 1 to (# ref waveforms) in NR1 format

The :MEASure:ELOSs command installs an energy loss measurement on screen.

The <source> parameter is typically a math multiply waveform or other waveform that represents power (voltage * current). This source can also be specified by the :MEASure:SOURce command.

Energy loss = $\sum (Vds_n * Id_n) * \text{sample size}$, where n is each sample.

Query Syntax :MEASure:ELOSs? [<source>]

The :MEASure:ELOSs query returns the switching loss in joules.

Return Format <return_value><NL>

<return_value> ::= the energy loss value in NR3 format

- See Also**
- [":MEASure:SOURce"](#) on page 727
 - [":POWer:SWITCh:APPLY"](#) on page 913

:MEASure:FACTor

N (see [page 1730](#))

Command Syntax :MEASure:FACTor [<source1>] [,<source2>]

<source1>, <source2> ::= {CHANnel<n>}

<n> ::= 1 to (# analog channels) in NR1 format

The :MEASure:FACTor command installs a power factor measurement on screen.

The <source1> parameter is the channel probing voltage and the <source2> parameter is the channel probing current. These sources can also be specified by the :MEASure:SOURce command.

Power factor is a measure of power quality. It is the ratio of the actual AC line power to the apparent power:

Real Power / Apparent Power

Query Syntax :MEASure:FACTor? [<source1>] [,<source2>]

The :MEASure:FACTor query returns the measured power factor.

Return Format <return_value><NL>

<return_value> ::= the power factor value in NR3 format

- See Also**
- [":MEASure:SOURce"](#) on page 727
 - [":POWer:QUALity:APPLY"](#) on page 890

:MEASure:IPower

N (see [page 1730](#))

Command Syntax :MEASure:IPower

The :MEASure:IPower command installs an input power measurement on screen.

Before sending this command or query, you must specify the channels probing the input voltage, input current, output voltage, and output current (using the :POWer:SIGNals:SOURce:VOLTage<i> and :POWer:SIGNals:SOURce:CURREnt<i> commands) and you must perform the automated signals setup (using the :POWer:SIGNals:AUTosetup EFFiciency command).

Query Syntax :MEASure:IPower?

The :MEASure:IPower query returns the measured input power.

Return Format <return_value><NL>

<return_value> ::= the input power value in NR3 format

- See Also**
- [":POWer:SIGNals:SOURce:VOLTage<i>"](#) on page 910
 - [":POWer:SIGNals:SOURce:CURREnt<i>"](#) on page 909
 - [":POWer:SIGNals:AUTosetup"](#) on page 892
 - [":POWer:EFFiciency:APPLY"](#) on page 848

:MEASure:OFFTime

N (see [page 1730](#))

Command Syntax :MEASure:OFFTime [<source1>] [,<source2>]

<source1>, <source2> ::= {CHANnel<n>}

<n> ::= 1 to (# analog channels) in NR1 format

The :MEASure:OFFTime command installs an "off time" measurement on screen.

Turn off time measures the difference of time between when the input AC Voltage last falls to 10% of its maximum amplitude to the time when the output DC Voltage last falls to 10% of its maximum amplitude.

The <source1> parameter is the AC Voltage and the <source2> parameter is the DC Voltage. These sources can also be specified by the :MEASure:SOURce command.

Query Syntax :MEASure:OFFTime? [<source1>] [,<source2>]

The :MEASure:OFFTime query returns the measured turn off time.

Return Format <return_value><NL>

<return_value> ::= the time in seconds in NR3 format

- See Also**
- [":MEASure:SOURce"](#) on page 727
 - [":POWer:ONOff:TEST"](#) on page 873
 - [":POWer:ONOff:APPLY"](#) on page 870

:MEASure:ONTime

N (see [page 1730](#))

Command Syntax :MEASure:ONTime [<source1>] [,<source2>]

<source1>, <source2> ::= {CHANnel<n>}

<n> ::= 1 to (# analog channels) in NR1 format

The :MEASure:ONTime command installs an "on time" measurement on screen.

Turn on time measures the difference of time between when the input AC Voltage first rises to 10% of its maximum amplitude to the time when the output DC Voltage rises to 90% of its maximum amplitude.

The <source1> parameter is the AC Voltage and the <source2> parameter is the DC Voltage. These sources can also be specified by the :MEASure:SOURce command.

Query Syntax :MEASure:ONTime? [<source1>] [,<source2>]

The :MEASure:ONTime query returns the measured turn off time.

Return Format <return_value><NL>

<return_value> ::= the time in seconds in NR3 format

- See Also**
- [":MEASure:SOURce"](#) on page 727
 - [":POWer:ONOff:TEST"](#) on page 873
 - [":POWer:ONOff:APPLY"](#) on page 870

:MEASure:OPOWer

N (see [page 1730](#))

Command Syntax :MEASure:OPOWer

The :MEASure:OPOWer command installs an output power measurement on screen.

Before sending this command or query, you must specify the channels probing the input voltage, input current, output voltage, and output current (using the :POWer:SIGNals:SOURce:VOLTage<i> and :POWer:SIGNals:SOURce:CURRent<i> commands) and you must perform the automated signals setup (using the :POWer:SIGNals:AUTosetup EFFiciency command).

Query Syntax :MEASure:OPOWer?

The :MEASure:OPOWer query returns the measured output power.

Return Format <return_value><NL>

<return_value> ::= the output power value in NR3 format

- See Also**
- [":POWer:SIGNals:SOURce:VOLTage<i>"](#) on page 910
 - [":POWer:SIGNals:SOURce:CURRent<i>"](#) on page 909
 - [":POWer:SIGNals:AUTosetup"](#) on page 892
 - [":POWer:EFFiciency:APPLY"](#) on page 848

:MEASure:PCURrent

N (see [page 1730](#))

Command Syntax :MEASure:PCURrent [<source>]

<source> ::= {CHANnel<n> | FUNCTION<m> | MATH<m> | WMemory<r>}

<n> ::= 1 to (# analog channels) in NR1 format

<m> ::= 1 to (# math functions) in NR1 format

<r> ::= 1 to (# ref waveforms) in NR1 format

The :MEASure:PCURrent command installs a peak current measurement on screen.

The <source> parameter is the channel probing the current. This source can also be specified by the :MEASure:SOURce command.

This command measures the peak current when the power supply first turned on.

Query Syntax :MEASure:PCURrent? [<source>]

The :MEASure:PCURrent query returns the measured peak current.

Return Format <return_value><NL>

<return_value> ::= the peak current value in NR3 format

- See Also**
- [":MEASure:SOURce"](#) on page 727
 - [":POWer:INRush:APPLY"](#) on page 863

:MEASure:PLOSs

N (see [page 1730](#))

Command Syntax :MEASure:PLOSs [<source>]

<source> ::= {CHANnel<n> | FUNCTION<m> | MATH<m> | WMemory<r>}

<n> ::= 1 to (# analog channels) in NR1 format

<m> ::= 1 to (# math functions) in NR1 format

<r> ::= 1 to (# ref waveforms) in NR1 format

The :MEASure:PLOSs command installs a power loss measurement on screen.

The <source> parameter is typically a math multiply waveform or other waveform that represents power (voltage * current). This source can also be specified by the :MEASure:SOURce command.

Power loss is $P_n = V_{ds_n} * I_{d_n}$, where n is each sample.

Query Syntax :MEASure:PLOSs? [<source>]

The :MEASure:PLOSs query returns the switching loss in watts.

Return Format <return_value><NL>

<return_value> ::= the power loss value in NR3 format

- See Also**
- [":MEASure:SOURce"](#) on page 727
 - [":POWER:SWITCh:APPLY"](#) on page 913

:MEASure:RDson

N (see [page 1730](#))

Command Syntax :MEASure:RDson [<source1>] [,<source2>]

<source1>, <source2> ::= {CHANnel<n>| FUNction<m> | MATH<m>
| WMEMory<r>}

<n> ::= 1 to (# analog channels) in NR1 format

<m> ::= 1 to (# math functions) in NR1 format

<r> ::= 1 to (# ref waveforms) in NR1 format

The :MEASure:RDson command installs a power Rds(on) measurement on screen.

Rds(on) is the ON resistance between the drain and source of MOSFET. The Rds(on) characteristic is also published in the switching device data sheet.

Query Syntax :MEASure:RDson? [<source1>] [,<source2>]

The :MEASure:RDson? query returns the measured Rds(on) value.

Return Format <return_value><NL>

<return_value> ::= the Rds(on) value in NR3 format

See Also • [":MEASure:VCESat"](#) on page 780

:MEASure:REACTIVE

N (see [page 1730](#))

Command Syntax :MEASure:REACTIVE [<source1>][,<source2>]

<source1>, <source2> ::= {CHANnel<n>}

<n> ::= 1 to (# analog channels) in NR1 format

The :MEASure:REACTIVE command installs a reactive power measurement on screen.

The <source1> parameter is the channel probing voltage and the <source2> parameter is the channel probing current. These sources can also be specified by the :MEASure:SOURce command.

Reactive power is a measure of power quality. It is the difference between apparent power and real power due to reactance. Using the *power triangle* (the right triangle where $\text{apparent_power}^2 = \text{real_power}^2 + \text{reactive_power}^2$):

$$\text{Reactive Power} = \sqrt{\text{Apparent Power}^2 - \text{Real Power}^2}$$

Reactive power is measured in VAR (Volts-Amps-Reactive).

Query Syntax :MEASure:REACTIVE? [<source1>][,<source2>]

The :MEASure:REACTIVE query returns the measured reactive power.

Return Format <return_value><NL>

<return_value> ::= the reactive power value in NR3 format

- See Also**
- [":MEASure:SOURce"](#) on page 727
 - [":POWER:QUALity:APPLY"](#) on page 890

:MEASure:REAL

N (see [page 1730](#))

Command Syntax :MEASure:REAL [<source>]
 <source> ::= {CHANnel<n> | FUNction<m> | MATH<m>}
 <n> ::= 1 to (# analog channels) in NR1 format
 <m> ::= 1 to (# math functions) in NR1 format

The :MEASure:REAL command installs a real power measurement on screen.

The <source> parameter is typically a math multiply waveform or other waveform that represents power (voltage * current). This source can also be specified by the :MEASure:SOURce command.

Real power is a measure of power quality. It is the portion of power flow that, averaged over a complete cycle of the AC waveform, results in net transfer of energy in one direction.

$$\text{Real Power} = \sqrt{\frac{1}{N} \sum_{n=0}^{N-1} V_n I_n}$$

Query Syntax :MEASure:REAL? [<source>]

The :MEASure:REAL query returns the measured real power.

Return Format <return_value><NL>
 <return_value> ::= the real power value in NR3 format

See Also

- [":MEASure:SOURce"](#) on page 727
- [":POWER:QUALity:APPLY"](#) on page 890

:MEASure:RIPple

N (see [page 1730](#))

Command Syntax :MEASure:RIPple [<source>]

<source> ::= {CHANnel<n> | FUNCTION<m> | MATH<m> | WMemory<r>}

<n> ::= 1 to (# analog channels) in NR1 format

<m> ::= 1 to (# math functions) in NR1 format

<r> ::= 1 to (# ref waveforms) in NR1 format

The :MEASure:RIPple command installs an output ripple measurement on screen.

The <source> parameter is the channel probing the output voltage. This source can also be specified by the :MEASure:SOURce command.

Output ripple is: Vmax - Vmin.

Query Syntax :MEASure:RIPple? [<source>]

The :MEASure:RIPple query returns the measured output ripple.

Return Format <return_value><NL>

<return_value> ::= the output ripple value in NR3 format

- See Also**
- [":MEASure:SOURce"](#) on page 727
 - [":POWer:RIPple:APPLY"](#) on page 891

:MEASure:TRESponse

N (see [page 1730](#))

Command Syntax :MEASure:TRESponse [<source>]

<source> ::= {CHANnel<n> | FUNCTION<m> | MATH<m> | WMemory<r>}

<n> ::= 1 to (# analog channels) in NR1 format

<m> ::= 1 to (# math functions) in NR1 format

<r> ::= 1 to (# ref waveforms) in NR1 format

The :MEASure:TRESponse command installs a transient response time measurement on screen.

The <source> parameter is the channel probing the output voltage. This source can also be specified by the :MEASure:SOURce command.

Transient response time = $t_2 - t_1$, where:

- t_1 = The first time a voltage waveform exits the settling band.
- t_2 = The last time it enters into the settling band.
- Settling band = +/-overshoot % of the steady state output voltage.

Query Syntax :MEASure:TRESponse? [<source>]

The :MEASure:TRESponse query returns the measured transient response time.

Return Format <return_value><NL>

<return_value> ::= time in seconds for the overshoot to settle back into the band in NR3 format

- See Also**
- [":MEASure:SOURce"](#) on page 727
 - [":POWER:TRANSient:APPLY"](#) on page 919

:MEASure:VCESat

N (see [page 1730](#))

Command Syntax :MEASure:VCESat [<source>]

<source> ::= {CHANnel<n> | FUNCTION<m> | MATH<m> | WMemory<r>}

<n> ::= 1 to (# analog channels) in NR1 format

<m> ::= 1 to (# math functions) in NR1 format

<r> ::= 1 to (# ref waveforms) in NR1 format

The :MEASure:VCESat command installs a power Vce(sat) measurement on screen.

Vce(sat) is the saturation voltage between the collector and emitter of a BJT. The Vce(sat) characteristic is also published in the switching device data sheet.

Query Syntax :MEASure:VCESat? [<source>]

The :MEASure:VCESat? query returns the measured Vce(sat) value.

Return Format <return_value><NL>

<return_value> ::= the VCE(sat) value in NR3 format

See Also • [":MEASure:RDSon"](#) on page 775

31 :MTEST Commands

The MTEST subsystem commands and queries control the mask test features. See "[Introduction to :MTEST Commands](#)" on page 783.

Table 121 :MTEST Commands Summary

Command	Query	Options and Query Returns
:MTEST:ALL {{0 OFF} {1 ON}} (see page 786)	:MTEST:ALL? (see page 786)	{0 1}
:MTEST:AMASK:CREate (see page 787)	n/a	n/a
:MTEST:AMASK:SOURce <source> (see page 788)	:MTEST:AMASK:SOURce? (see page 788)	<source> ::= CHANNEL<n> <n> ::= {1 2 3 4} for 4ch models <n> ::= {1 2} for 2ch models
:MTEST:AMASK:UNITs <units> (see page 789)	:MTEST:AMASK:UNITs? (see page 789)	<units> ::= {CURRENT DIVISIONS}
:MTEST:AMASK:XDELta <value> (see page 790)	:MTEST:AMASK:XDELta? (see page 790)	<value> ::= X delta value in NR3 format
:MTEST:AMASK:YDELta <value> (see page 791)	:MTEST:AMASK:YDELta? (see page 791)	<value> ::= Y delta value in NR3 format
n/a	:MTEST:COUNT:FWAVEforMs? [CHANNEL<n>] (see page 792)	<failed> ::= number of failed waveforms in NR1 format
:MTEST:COUNT:RESet (see page 793)	n/a	n/a
n/a	:MTEST:COUNT:TIME? (see page 794)	<time> ::= elapsed seconds in NR3 format
n/a	:MTEST:COUNT:WAVEformS? (see page 795)	<count> ::= number of waveforms in NR1 format
:MTEST:DATA <mask> (see page 796)	:MTEST:DATA? (see page 796)	<mask> ::= data in IEEE 488.2 # format.

Table 121 :MTESt Commands Summary (continued)

Command	Query	Options and Query Returns
:MTESt:DELeTe (see page 797)	n/a	n/a
:MTESt:ENABLe {{0 OFF} {1 ON}} (see page 798)	:MTESt:ENABLe? (see page 798)	{0 1}
:MTESt:LOCK {{0 OFF} {1 ON}} (see page 799)	:MTESt:LOCK? (see page 799)	{0 1}
:MTESt:RMODe <rmode> (see page 800)	:MTESt:RMODe? (see page 800)	<rmode> ::= {FORever TIME SIGMa WAVeforms}
:MTESt:RMODe:FACTion:MEASure {{0 OFF} {1 ON}} (see page 801)	:MTESt:RMODe:FACTion:MEASure? (see page 801)	{0 1}
:MTESt:RMODe:FACTion:PRINt {{0 OFF} {1 ON}} (see page 802)	:MTESt:RMODe:FACTion:PRINt? (see page 802)	{0 1}
:MTESt:RMODe:FACTion:SAVE {{0 OFF} {1 ON}} (see page 803)	:MTESt:RMODe:FACTion:SAVE? (see page 803)	{0 1}
:MTESt:RMODe:FACTion:STOP {{0 OFF} {1 ON}} (see page 804)	:MTESt:RMODe:FACTion:STOP? (see page 804)	{0 1}
:MTESt:RMODe:SIGMa <level> (see page 805)	:MTESt:RMODe:SIGMa? (see page 805)	<level> ::= from 0.1 to 9.3 in NR3 format
:MTESt:RMODe:TIME <seconds> (see page 806)	:MTESt:RMODe:TIME? (see page 806)	<seconds> ::= from 1 to 86400 in NR3 format
:MTESt:RMODe:WAVeform s <count> (see page 807)	:MTESt:RMODe:WAVeform s? (see page 807)	<count> ::= number of waveforms in NR1 format
:MTESt:SCALE:BINd {{0 OFF} {1 ON}} (see page 808)	:MTESt:SCALE:BINd? (see page 808)	{0 1}
:MTESt:SCALE:X1 <x1_value> (see page 809)	:MTESt:SCALE:X1? (see page 809)	<x1_value> ::= X1 value in NR3 format
:MTESt:SCALE:XDELta <xdelta_value> (see page 810)	:MTESt:SCALE:XDELta? (see page 810)	<xdelta_value> ::= X delta value in NR3 format

Table 121 :MTESt Commands Summary (continued)

Command	Query	Options and Query Returns
:MTESt:SCALe:Y1 <y1_value> (see page 811)	:MTESt:SCALe:Y1? (see page 811)	<y1_value> ::= Y1 value in NR3 format
:MTESt:SCALe:Y2 <y2_value> (see page 812)	:MTESt:SCALe:Y2? (see page 812)	<y2_value> ::= Y2 value in NR3 format
:MTESt:SOURce <source> (see page 813)	:MTESt:SOURce? (see page 813)	<source> ::= {CHANnel<n> NONE} <n> ::= {1 2 3 4} for 4ch models <n> ::= {1 2} for 2ch models
n/a	:MTESt:TITLe? (see page 814)	<title> ::= a string of up to 128 ASCII characters

Introduction to :MTESt Commands

Mask testing automatically compares the current displayed waveform with the boundaries of a set of polygons that you define. Any waveform or sample that falls within the boundaries of one or more polygons is recorded as a failure.

Reporting the Setup

Use :MTESt? to query setup information for the MTESt subsystem.

Return Format

The following is a sample response from the :MTESt? query. In this case, the query was issued following a *RST command.

```
:MTES:SOUR CHAN1;ENAB 0;LOCK 1;:MTES:AMAS:SOUR CHAN1;UNIT DIV;XDEL
+2.50000000E-001;YDEL +2.50000000E-001;:MTES:SCAL:X1 +200.000E-06;XDEL
+400.000E-06;Y1 -3.00000E+00;Y2 +3.00000E+00;BIND 0;:MTES:RMOD
FOR;RMOD:TIME +1E+00;WAV 1000;SIGM +6.0E+00;:MTES:RMOD:FACT:STOP
0;PRIN 0;SAVE 0
```

Example Code

```
' Mask testing commands example.
' -----

Option Explicit

Public myMgr As VisaComLib.ResourceManager
Public myScope As VisaComLib.FormattedIO488
Public varQueryResult As Variant
Public strQueryResult As String

Private Declare Sub Sleep Lib "kernel32" (ByVal dwMilliseconds As Long)

Sub Main()
```

```

On Error GoTo VisaComError

' Create the VISA COM I/O resource.
Set myMgr = New VisaComLib.ResourceManager
Set myScope = New VisaComLib.FormattedIO488
Set myScope.IO = _
    myMgr.Open("USB0::0x0957::0x17A6::US50210029::0::INSTR")
myScope.IO.Clear ' Clear the interface.

' Make sure oscilloscope is running.
myScope.WriteString ":RUN"

' Set mask test termination conditions.
myScope.WriteString ":MTESt:RMODe SIGMa"
myScope.WriteString ":MTESt:RMODe?"
strQueryResult = myScope.ReadString
Debug.Print "Mask test termination mode: " + strQueryResult

myScope.WriteString ":MTESt:RMODe:SIGMa 4.2"
myScope.WriteString ":MTESt:RMODe:SIGMa?"
varQueryResult = myScope.ReadNumber
Debug.Print "Mask test termination 'test sigma': " + _
    FormatNumber(varQueryResult)

' Use auto-mask to create mask.
myScope.WriteString ":MTESt:AMASk:SOURce CHANnel1"
myScope.WriteString ":MTESt:AMASk:SOURce?"
strQueryResult = myScope.ReadString
Debug.Print "Mask test auto-mask source: " + strQueryResult

myScope.WriteString ":MTESt:AMASk:UNITs DIVisions"
myScope.WriteString ":MTESt:AMASk:UNITs?"
strQueryResult = myScope.ReadString
Debug.Print "Mask test auto-mask units: " + strQueryResult

myScope.WriteString ":MTESt:AMASk:XDELta 0.1"
myScope.WriteString ":MTESt:AMASk:XDELta?"
varQueryResult = myScope.ReadNumber
Debug.Print "Mask test auto-mask X delta: " + _
    FormatNumber(varQueryResult)

myScope.WriteString ":MTESt:AMASk:YDELta 0.1"
myScope.WriteString ":MTESt:AMASk:YDELta?"
varQueryResult = myScope.ReadNumber
Debug.Print "Mask test auto-mask Y delta: " + _
    FormatNumber(varQueryResult)

' Enable "Auto Mask Created" event (bit 10, &H400)
myScope.WriteString "*CLS"
myScope.WriteString ":MTEEnable " + CStr(CInt("&H400"))

' Create mask.
myScope.WriteString ":MTESt:AMASk:CREate"
Debug.Print "Auto-mask created, mask test automatically enabled."

' Set up timeout variables.

```



```

Dim lngTimeout As Long    ' Max millisecs to wait.
Dim lngElapsed As Long
lngTimeout = 60000    ' 60 seconds.

' Wait until mask is created.
lngElapsed = 0
Do While lngElapsed <= lngTimeout
    myScope.WriteString ":OPERRegister:CONditiOn?"
    varQueryResult = myScope.ReadNumber
    ' Operation Status Condition Register MTE bit (bit 9, &H200).
    If (varQueryResult And &H200) <> 0 Then
        Exit Do
    Else
        Sleep 100    ' Small wait to prevent excessive queries.
        lngElapsed = lngElapsed + 100
    End If
Loop

' Look for RUN bit = stopped (mask test termination).
lngElapsed = 0
Do While lngElapsed <= lngTimeout
    myScope.WriteString ":OPERRegister:CONditiOn?"
    varQueryResult = myScope.ReadNumber
    ' Operation Status Condition Register RUN bit (bit 3, &H8).
    If (varQueryResult And &H8) = 0 Then
        Exit Do
    Else
        Sleep 100    ' Small wait to prevent excessive queries.
        lngElapsed = lngElapsed + 100
    End If
Loop

' Get total waveforms, failed waveforms, and test time.
myScope.WriteString ":MTESt:COUNT:WAVEforms?"
strQueryResult = myScope.ReadString
Debug.Print "Mask test total waveforms: " + strQueryResult

myScope.WriteString ":MTESt:COUNT:FWAVEforms?"
strQueryResult = myScope.ReadString
Debug.Print "Mask test failed waveforms: " + strQueryResult

myScope.WriteString ":MTESt:COUNT:TIME?"
strQueryResult = myScope.ReadString
Debug.Print "Mask test elapsed seconds: " + strQueryResult

Exit Sub

VisaComError:
    MsgBox "VISA COM Error:" + vbCrLf + Err.Description

End Sub

```

:MTESt:ALL

N (see [page 1730](#))

Command Syntax :MTESt:ALL <on_off>
 <on_off> ::= {{1 | ON} | {0 | OFF}}

The :MTESt:ALL command specifies the channel(s) that are included in the mask test:

- ON – All displayed analog channels are included in the mask test.
- OFF – Just the selected source channel is included in the test.

Query Syntax :MTESt:ALL?

The :MTESt:ALL? query returns the current setting.

Return Format <on_off><NL>
 <on_off> ::= {1 | 0}

See Also • ["Introduction to :MTESt Commands"](#) on page 783

:MTESt:AMASk:CREate

N (see [page 1730](#))

Command Syntax :MTESt:AMASk:CREate

The :MTESt:AMASk:CREate command automatically constructs a mask around the current selected channel, using the tolerance parameters defined by the :MTESt:AMASk:XDELta, :MTESt:AMASk:YDELta, and :MTESt:AMASk:UNITs commands. The mask only encompasses the portion of the waveform visible on the display, so you must ensure that the waveform is acquired and displayed consistently to obtain repeatable results.

The :MTESt:SOURce command selects the channel and should be set before using this command.

- See Also**
- ["Introduction to :MTESt Commands"](#) on page 783
 - [":MTESt:AMASk:XDELta"](#) on page 790
 - [":MTESt:AMASk:YDELta"](#) on page 791
 - [":MTESt:AMASk:UNITs"](#) on page 789
 - [":MTESt:AMASk:SOURce"](#) on page 788
 - [":MTESt:SOURce"](#) on page 813

- Example Code**
- ["Example Code"](#) on page 783

:MTESt:AMASk:SOURce

N (see [page 1730](#))

Command Syntax :MTESt:AMASk:SOURce <source>

<source> ::= CHANnel<n>

<n> ::= 1 to (# analog channels) in NR1 format

The :MTESt:AMASk:SOURce command selects the source for the interpretation of the :MTESt:AMASk:XDELta and :MTESt:AMASk:YDELta parameters when :MTESt:AMASk:UNITs is set to CURRent.

When UNITs are CURRent, the XDELta and YDELta parameters are defined in terms of the channel units, as set by the :CHANnel<n>:UNITs command, of the selected source.

Suppose that UNITs are CURRent and that you set SOURce to CHANNEL1, which is using units of volts. Then you can define AMASk:XDELta in terms of volts and AMASk:YDELta in terms of seconds.

This command is the same as the :MTESt:SOURce command.

Query Syntax :MTESt:AMASk:SOURce?

The :MTESt:AMASk:SOURce? query returns the currently set source.

Return Format <source> ::= CHAN<n>

<n> ::= 1 to (# analog channels) in NR1 format

- See Also**
- ["Introduction to :MTESt Commands"](#) on page 783
 - [":MTESt:AMASk:XDELta"](#) on page 790
 - [":MTESt:AMASk:YDELta"](#) on page 791
 - [":MTESt:AMASk:UNITs"](#) on page 789
 - [":MTESt:SOURce"](#) on page 813

Example Code • ["Example Code"](#) on page 783

:MTESt:AMASk:UNITs

N (see [page 1730](#))

Command Syntax :MTESt:AMASk:UNITs <units>
 <units> ::= {CURRent | DIVisions}

The :MTESt:AMASk:UNITs command alters the way the mask test subsystem interprets the tolerance parameters for automasking as defined by :MTESt:AMASk:XDELta and :MTESt:AMASk:YDELta commands.

- CURRent – the mask test subsystem uses the units as set by the :CHANnel<n>:UNITs command, usually time for ΔX and voltage for ΔY .
- DIVisions – the mask test subsystem uses the graticule as the measurement system, so tolerance settings are specified as parts of a screen division. The mask test subsystem maintains separate XDELta and YDELta settings for CURRent and DIVisions. Thus, XDELta and YDELta are not converted to new values when the UNITs setting is changed.

Query Syntax :MTESt:AMASk:UNITs?

The :MTESt:AMASk:UNITs query returns the current measurement units setting for the mask test automask feature.

Return Format <units><NL>
 <units> ::= {CURR | DIV}

- See Also**
- ["Introduction to :MTESt Commands"](#) on page 783
 - [":MTESt:AMASk:XDELta"](#) on page 790
 - [":MTESt:AMASk:YDELta"](#) on page 791
 - [":CHANnel<n>:UNITs"](#) on page 380
 - [":MTESt:AMASk:SOURce"](#) on page 788
 - [":MTESt:SOURce"](#) on page 813

Example Code • ["Example Code"](#) on page 783

:MTESt:AMASk:XDELta

N (see [page 1730](#))

Command Syntax `:MTESt:AMASk:XDELta <value>`
`<value> ::= X delta value in NR3 format`

The `:MTESt:AMASk:XDELta` command sets the tolerance in the X direction around the waveform for the automasking feature. The absolute value of the tolerance will be added and subtracted to horizontal values of the waveform to determine the boundaries of the mask.

The horizontal tolerance value is interpreted based on the setting specified by the `:MTESt:AMASk:UNITs` command; thus, if you specify `250-E3`, the setting for `:MTESt:AMASk:UNITs` is `CURRent`, and the current setting specifies time in the horizontal direction, the tolerance will be ± 250 ms. If the setting for `:MTESt:AMASk:UNITs` is `DIVisions`, the same X delta value will set the tolerance to ± 250 millidivisions, or 1/4 of a division.

Query Syntax `:MTESt:AMASk:XDELta?`

The `:MTESt:AMASk:XDELta?` query returns the current setting of the ΔX tolerance for automasking. If your computer program will interpret this value, it should also request the current measurement system using the `:MTESt:AMASk:UNITs` query.

Return Format `<value><NL>`
`<value> ::= X delta value in NR3 format`

- See Also**
- ["Introduction to :MTESt Commands"](#) on page 783
 - [":MTESt:AMASk:UNITs"](#) on page 789
 - [":MTESt:AMASk:YDELta"](#) on page 791
 - [":MTESt:AMASk:SOURce"](#) on page 788
 - [":MTESt:SOURce"](#) on page 813

Example Code • ["Example Code"](#) on page 783

:MTESt:AMASK:YDELta

N (see [page 1730](#))

Command Syntax :MTESt:AMASK:YDELta <value>
 <value> ::= Y delta value in NR3 format

The :MTESt:AMASK:YDELta command sets the vertical tolerance around the waveform for the automasking feature. The absolute value of the tolerance will be added and subtracted to vertical values of the waveform to determine the boundaries of the mask.

The vertical tolerance value is interpreted based on the setting specified by the :MTESt:AMASK:UNITs command; thus, if you specify 250-E3, the setting for :MTESt:AMASK:UNITs is CURRent, and the current setting specifies voltage in the vertical direction, the tolerance will be ± 250 mV. If the setting for :MTESt:AMASK:UNITs is DIVisions, the same Y delta value will set the tolerance to ± 250 millidivisions, or 1/4 of a division.

Query Syntax :MTESt:AMASK:YDELta?

The :MTESt:AMASK:YDELta? query returns the current setting of the ΔY tolerance for automasking. If your computer program will interpret this value, it should also request the current measurement system using the :MTESt:AMASK:UNITs query.

Return Format <value><NL>
 <value> ::= Y delta value in NR3 format

- See Also**
- ["Introduction to :MTESt Commands"](#) on page 783
 - [":MTESt:AMASK:UNITs"](#) on page 789
 - [":MTESt:AMASK:XDELta"](#) on page 790
 - [":MTESt:AMASK:SOURce"](#) on page 788
 - [":MTESt:SOURce"](#) on page 813

Example Code • ["Example Code"](#) on page 783

:MTESt:COUNT:FWAVEforms

N (see [page 1730](#))

Query Syntax :MTESt:COUNT:FWAVEforms? [CHANnel<n>]

<n> ::= 1 to (# analog channels) in NR1 format

The :MTESt:COUNT:FWAVEforms? query returns the total number of failed waveforms in the current mask test run. This count is for all regions and all waveforms collected on the channel specified by the optional parameter or collected on the currently specified source channel (:MTESt:SOURce) if there is no parameter.

Return Format <failed><NL>

<failed> ::= number of failed waveforms in NR1 format.

- See Also**
- ["Introduction to :MTESt Commands"](#) on page 783
 - [":MTESt:COUNT:WAVEforms"](#) on page 795
 - [":MTESt:COUNT:TIME"](#) on page 794
 - [":MTESt:COUNT:RESet"](#) on page 793
 - [":MTESt:SOURce"](#) on page 813

Example Code • ["Example Code"](#) on page 783

:MTESt:COUNT:RESet

N (see [page 1730](#))

Command Syntax :MTESt:COUNT:RESet

The :MTESt:COUNT:RESet command resets the mask statistics.

- See Also**
- ["Introduction to :MTESt Commands"](#) on page 783
 - [":MTESt:COUNT:WAVEforms"](#) on page 795
 - [":MTESt:COUNT:FWAVEforms"](#) on page 792
 - [":MTESt:COUNT:TIME"](#) on page 794

:MTESt:COUNT:TIME

N (see [page 1730](#))

Query Syntax :MTESt:COUNT:TIME?

The :MTESt:COUNT:TIME? query returns the elapsed time in the current mask test run.

Return Format <time><NL>

<time> ::= elapsed seconds in NR3 format.

- See Also**
- ["Introduction to :MTESt Commands"](#) on page 783
 - [":MTESt:COUNT:WAVEforms"](#) on page 795
 - [":MTESt:COUNT:FWAVEforms"](#) on page 792
 - [":MTESt:COUNT:RESet"](#) on page 793

Example Code • ["Example Code"](#) on page 783

:MTESt:COUNT:WAVEforms

N (see [page 1730](#))

Query Syntax :MTESt:COUNT:WAVEforms?

The :MTESt:COUNT:WAVEforms? query returns the total number of waveforms acquired in the current mask test run.

Return Format <count><NL>

<count> ::= number of waveforms in NR1 format.

- See Also**
- ["Introduction to :MTESt Commands"](#) on page 783
 - [":MTESt:COUNT:FWAVEforms"](#) on page 792
 - [":MTESt:COUNT:TIME"](#) on page 794
 - [":MTESt:COUNT:RESet"](#) on page 793

Example Code • ["Example Code"](#) on page 783

:MTEST:DATA

N (see [page 1730](#))

Command Syntax :MTEST:DATA <mask>

<mask> ::= binary block data in IEEE 488.2 # format.

The :MTEST:DATA command loads a mask from binary block data.

Query Syntax :MTEST:DATA?

The :MTEST:DATA? query returns a mask in binary block data format. The format for the data transmission is the # format defined in the IEEE 488.2 specification.

Return Format <mask><NL>

<mask> ::= binary block data in IEEE 488.2 # format

- See Also**
- [":SAVE:MASK\[:START\]"](#) on page 956
 - [":RECall:MASK\[:START\]"](#) on page 932

:MTESt:DELeTe

N (see [page 1730](#))

Command Syntax :MTESt:DELeTe

The :MTESt:DELeTe command clears the currently loaded mask.

- See Also**
- ["Introduction to :MTESt Commands"](#) on page 783
 - [":MTESt:AMASk:CREate"](#) on page 787

:MTESt:ENABle

N (see [page 1730](#))

Command Syntax :MTESt:ENABle <on_off>
 <on_off> ::= {{1 | ON} | {0 | OFF}}

The :MTESt:ENABle command enables or disables the mask test features.

- ON – Enables the mask test features.
- OFF – Disables the mask test features.

Query Syntax :MTESt:ENABle?

The :MTESt:ENABle? query returns the current state of mask test features.

Return Format <on_off><NL>
 <on_off> ::= {1 | 0}

See Also • ["Introduction to :MTESt Commands"](#) on page 783

:MTESt:LOCK

N (see [page 1730](#))

Command Syntax :MTESt:LOCK <on_off>
 <on_off> ::= {{1 | ON} | {0 | OFF}}

The :MTESt:LOCK command enables or disables the mask lock feature:

- ON – Locks a mask to the SOURce. As the vertical or horizontal scaling or position of the SOURce changes, the mask is redrawn accordingly.
- OFF – The mask is static and does not move.

Query Syntax :MTESt:LOCK?

The :MTESt:LOCK? query returns the current mask lock setting.

Return Format <on_off><NL>
 <on_off> ::= {1 | 0}

- See Also**
- ["Introduction to :MTESt Commands"](#) on page 783
 - [":MTESt:SOURce"](#) on page 813

:MTESt:RMODe

N (see [page 1730](#))

Command Syntax :MTESt:RMODe <rmode>
<rmode> ::= {FORever | SIGMa | TIME | WAVeforms}

The :MTESt:RMODe command specifies the termination conditions for the mask test:

- FORever – the mask test runs until it is turned off.
- SIGMa – the mask test runs until the Sigma level is reached. This level is set by the [":MTESt:RMODe:SIGMa"](#) on page 805 command.
- TIME – the mask test runs for a fixed amount of time. The amount of time is set by the [":MTESt:RMODe:TIME"](#) on page 806 command.
- WAVeforms – the mask test runs until a fixed number of waveforms are acquired. The number of waveforms is set by the [":MTESt:RMODe:WAVeforms"](#) on page 807 command.

Query Syntax :MTESt:RMODe?

The :MTESt:RMODe? query returns the currently set termination condition.

Return Format <rmode><NL>
<rmode> ::= {FOR | SIGM | TIME | WAV}

- See Also**
- ["Introduction to :MTESt Commands"](#) on page 783
 - [":MTESt:RMODe:SIGMa"](#) on page 805
 - [":MTESt:RMODe:TIME"](#) on page 806
 - [":MTESt:RMODe:WAVeforms"](#) on page 807

Example Code • ["Example Code"](#) on page 783

:MTESt:RMODe:FACTion:MEASure

N (see [page 1730](#))

Command Syntax :MTESt:RMODe:FACTion:MEASure <on_off>

<on_off> ::= {{1 | ON} | {0 | OFF}}

The :MTESt:RMODe:FACTion:MEASure command sets measuring only mask failures on or off.

When ON, measurements and measurement statistics run only on waveforms that contain a mask violation; passing waveforms do not affect measurements and measurement statistics.

This mode is not available when the acquisition mode is set to Averaging.

Query Syntax :MTESt:RMODe:FACTion:MEASure?

The :MTESt:RMODe:FACTion:MEASure? query returns the current mask failure measure setting.

Return Format <on_off><NL>

<on_off> ::= {1 | 0}

- See Also**
- ["Introduction to :MTESt Commands"](#) on page 783
 - [":MTESt:RMODe:FACTion:PRINT"](#) on page 802
 - [":MTESt:RMODe:FACTion:SAVE"](#) on page 803
 - [":MTESt:RMODe:FACTion:STOP"](#) on page 804

:MTESt:RMODe:FACTion:PRINt

N (see [page 1730](#))

Command Syntax :MTESt:RMODe:FACTion:PRINt <on_off>

<on_off> ::= {{1 | ON} | {0 | OFF}}

The :MTESt:RMODe:FACTion:PRINt command sets printing on mask failures on or off.

NOTE

Setting :MTESt:RMODe:FACTion:PRINt ON automatically sets :MTESt:RMODe:FACTion:SAVE OFF.

See [Chapter 23](#), “:HARDcopy/:HCOPY Commands,” starting on page 539 for more information on setting the hardcopy device and formatting options.

Query Syntax :MTESt:RMODe:FACTion:PRINt?

The :MTESt:RMODe:FACTion:PRINt? query returns the current mask failure print setting.

Return Format <on_off><NL>

<on_off> ::= {1 | 0}

- See Also**
- ["Introduction to :MTESt Commands"](#) on page 783
 - [":MTESt:RMODe:FACTion:MEASure"](#) on page 801
 - [":MTESt:RMODe:FACTion:SAVE"](#) on page 803
 - [":MTESt:RMODe:FACTion:STOP"](#) on page 804

:MTESt:RMODe:FACTion:SAVE

N (see [page 1730](#))

Command Syntax :MTESt:RMODe:FACTion:SAVE <on_off>
 <on_off> ::= {{1 | ON} | {0 | OFF}}

The :MTESt:RMODe:FACTion:SAVE command sets saving on mask failures on or off.

NOTE

Setting :MTESt:RMODe:FACTion:SAVE ON automatically sets :MTESt:RMODe:FACTion:PRINT OFF.

See [Chapter 36](#), “:SAVE Commands,” starting on page 943 for more information on save options.

Query Syntax :MTESt:RMODe:FACTion:SAVE?

The :MTESt:RMODe:FACTion:SAVE? query returns the current mask failure save setting.

Return Format <on_off><NL>
 <on_off> ::= {1 | 0}

- See Also**
- ["Introduction to :MTESt Commands"](#) on page 783
 - [":MTESt:RMODe:FACTion:MEASure"](#) on page 801
 - [":MTESt:RMODe:FACTion:PRINT"](#) on page 802
 - [":MTESt:RMODe:FACTion:STOP"](#) on page 804

:MTESt:RMODe:FACTion:STOP

N (see [page 1730](#))

Command Syntax :MTESt:RMODe:FACTion:STOP <on_off>

<on_off> ::= {{1 | ON} | {0 | OFF}}

The :MTESt:RMODe:FACTion:STOP command sets stopping on a mask failure on or off. When this setting is ON and a mask violation is detected, the mask test is stopped and the acquisition system is stopped.

Query Syntax :MTESt:RMODe:FACTion:STOP?

The :MTESt:RMODe:FACTion:STOP? query returns the current mask failure stop setting.

Return Format <on_off><NL>

<on_off> ::= {1 | 0}

- See Also**
- ["Introduction to :MTESt Commands"](#) on page 783
 - [":MTESt:RMODe:FACTion:MEASure"](#) on page 801
 - [":MTESt:RMODe:FACTion:PRINT"](#) on page 802
 - [":MTESt:RMODe:FACTion:SAVE"](#) on page 803

:MTESt:RMODE:SIGMa

N (see [page 1730](#))

Command Syntax :MTESt:RMODE:SIGMa <level>

<level> ::= from 0.1 to 9.3 in NR3 format

When the :MTESt:RMODE command is set to SIGMa, the :MTESt:RMODE:SIGMa command sets the *test sigma* level to which a mask test runs. *Test sigma* is the best achievable process sigma, assuming no failures. (*Process sigma* is calculated using the number of failures per test.) The *test sigma* level indirectly specifies the number of waveforms that must be tested (in order to reach the sigma level).

Query Syntax :MTESt:RMODE:SIGMa?

The :MTESt:RMODE:SIGMa? query returns the current Sigma level setting.

Return Format <level><NL>

<level> ::= from 0.1 to 9.3 in NR3 format

See Also • ["Introduction to :MTESt Commands"](#) on page 783

• [":MTESt:RMODE"](#) on page 800

Example Code • ["Example Code"](#) on page 783

:MTESt:RMODE:TIME

N (see [page 1730](#))

Command Syntax :MTESt:RMODE:TIME <seconds>

<seconds> ::= from 1 to 86400 in NR3 format

When the :MTESt:RMODE command is set to TIME, the :MTESt:RMODE:TIME command sets the number of seconds for a mask test to run.

Query Syntax :MTESt:RMODE:TIME?

The :MTESt:RMODE:TIME? query returns the number of seconds currently set.

Return Format <seconds><NL>

<seconds> ::= from 1 to 86400 in NR3 format

- See Also**
- ["Introduction to :MTESt Commands"](#) on page 783
 - [":MTESt:RMODE"](#) on page 800

:MTESt:RMODE:WAVEforms

N (see [page 1730](#))

Command Syntax :MTESt:RMODE:WAVEforms <count>

<count> ::= number of waveforms in NR1 format
from 1 to 2,000,000,000

When the :MTESt:RMODE command is set to WAVEforms, the :MTESt:RMODE:WAVEforms command sets the number of waveform acquisitions that are mask tested.

Query Syntax :MTESt:RMODE:WAVEforms?

The :MTESt:RMODE:WAVEforms? query returns the number of waveforms currently set.

Return Format <count><NL>

<count> ::= number of waveforms in NR1 format
from 1 to 2,000,000,000

- See Also**
- ["Introduction to :MTESt Commands"](#) on page 783
 - [":MTESt:RMODE"](#) on page 800

:MTESt:SCALe:BIND

N (see [page 1730](#))

Command Syntax :MTESt:SCALe:BIND <on_off>

<on_off> ::= {{1 | ON} | {0 | OFF}}

The :MTESt:SCALe:BIND command enables or disables Bind 1 & 0 Levels (Bind -1 & 0 Levels for inverted masks) control:

- ON –

If the Bind 1 & 0 Levels control is enabled, the 1 Level and the 0 Level controls track each other. Adjusting either the 1 Level or the 0 Level control shifts the position of the mask up or down without changing its size.

If the Bind -1 & 0 Levels control is enabled, the -1 Level and the 0 Level controls track each other. Adjusting either the -1 Level or the 0 Level control shifts the position of the mask up or down without changing its size.

- OFF –

If the Bind 1 & 0 Levels control is disabled, adjusting either the 1 Level or the 0 Level control changes the vertical height of the mask.

If the Bind -1 & 0 Levels control is disabled, adjusting either the -1 Level or the 0 Level control changes the vertical height of the mask.

Query Syntax :MTESt:SCALe:BIND?

The :MTESt:SCALe:BIND? query returns the value of the Bind 1&0 control (Bind -1&0 for inverted masks).

Return Format <on_off><NL>

<on_off> ::= {1 | 0}

- See Also**
- ["Introduction to :MTESt Commands"](#) on page 783
 - [":MTESt:SCALe:X1"](#) on page 809
 - [":MTESt:SCALe:XDELta"](#) on page 810
 - [":MTESt:SCALe:Y1"](#) on page 811
 - [":MTESt:SCALe:Y2"](#) on page 812

:MTESt:SCALE:X1

N (see [page 1730](#))

Command Syntax :MTESt:SCALE:X1 <x1_value>
 <x1_value> ::= X1 value in NR3 format

The :MTESt:SCALE:X1 command defines where X=0 in the base coordinate system used for mask testing. The other X-coordinate is defined by the :MTESt:SCALE:XDELta command. Once the X1 and XDELta coordinates are set, all X values of vertices in the mask regions are defined with respect to this value, according to the equation:

$$x = (X * \Delta X) + X1$$

Thus, if you set X1 to 100 ms, and XDELta to 100 ms, an X value of 0.100 is a vertex at 110 ms.

The oscilloscope uses this equation to normalize vertices. This simplifies reprogramming to handle different data rates. For example, if you halve the period of the waveform of interest, you need only to adjust the XDELta value to set up the mask for the new waveform.

The X1 value is a time value specifying the location of the X1 coordinate, which will then be treated as X=0 for mask regions coordinates.

Query Syntax :MTESt:SCALE:X1?

The :MTESt:SCALE:X1? query returns the current X1 coordinate setting.

Return Format <x1_value><NL>
 <x1_value> ::= X1 value in NR3 format

- See Also**
- ["Introduction to :MTESt Commands"](#) on page 783
 - [":MTESt:SCALE:BIND"](#) on page 808
 - [":MTESt:SCALE:XDELta"](#) on page 810
 - [":MTESt:SCALE:Y1"](#) on page 811
 - [":MTESt:SCALE:Y2"](#) on page 812

:MTESt:SCALE:XDELta

N (see [page 1730](#))

Command Syntax `:MTESt:SCALE:XDELta <xdelta_value>`

`<xdelta_value> ::= X delta value in NR3 format`

The `:MTESt:SCALE:XDELta` command defines the position of the X2 marker with respect to the X1 marker. In the mask test coordinate system, the X1 marker defines where $X=0$; thus, the X2 marker defines where $X=1$.

Because all X vertices of the regions defined for mask testing are normalized with respect to X1 and ΔX , redefining ΔX also moves those vertices to stay in the same locations with respect to X1 and ΔX . Thus, in many applications, it is best if you define XDELta as a pulse width or bit period. Then, a change in data rate without corresponding changes in the waveform can easily be handled by changing ΔX .

The X-coordinate of polygon vertices is normalized using this equation:

$$x = (X * \Delta X) + X1$$

The X delta value is a time value specifying the distance of the X2 marker with respect to the X1 marker.

For example, if the period of the waveform you wish to test is 1 ms, setting ΔX to 1 ms ensures that the waveform's period is between the X1 and X2 markers.

Query Syntax `:MTESt:SCALE:XDELta?`

The `:MTESt:SCALE:XDELta?` query returns the current value of ΔX .

Return Format `<xdelta_value><NL>`

`<xdelta_value> ::= X delta value in NR3 format`

- See Also**
- ["Introduction to :MTESt Commands"](#) on page 783
 - [":MTESt:SCALE:BIND"](#) on page 808
 - [":MTESt:SCALE:X1"](#) on page 809
 - [":MTESt:SCALE:Y1"](#) on page 811
 - [":MTESt:SCALE:Y2"](#) on page 812

:MTESt:SCALe:Y1

N (see [page 1730](#))

Command Syntax :MTESt:SCALe:Y1 <y1_value>
 <y1_value> ::= Y1 value in NR3 format

The :MTESt:SCALe:Y1 command defines where Y=0 in the coordinate system for mask testing. All Y values of vertices in the coordinate system are defined with respect to the boundaries set by SCALe:Y1 and SCALe:Y2 according to the equation:

$$Y = (Y * (Y2 - Y1)) + Y1$$

Thus, if you set Y1 to 100 mV, and Y2 to 1 V, a Y value of 0.100 in a vertex is at 190 mV.

The Y1 value is a voltage value specifying the point at which Y=0.

Query Syntax :MTESt:SCALe:Y1?

The :MTESt:SCALe:Y1? query returns the current setting of the Y1 marker.

Return Format <y1_value><NL>
 <y1_value> ::= Y1 value in NR3 format

- See Also**
- ["Introduction to :MTESt Commands"](#) on page 783
 - [":MTESt:SCALe:BIND"](#) on page 808
 - [":MTESt:SCALe:X1"](#) on page 809
 - [":MTESt:SCALe:XDELta"](#) on page 810
 - [":MTESt:SCALe:Y2"](#) on page 812

:MTESt:SCALe:Y2

N (see [page 1730](#))

Command Syntax `:MTESt:SCALe:Y2 <y2_value>`

`<y2_value> ::= Y2 value in NR3 format`

The `:MTESt:SCALe:Y2` command defines the Y2 marker in the coordinate system for mask testing. All Y values of vertices in the coordinate system are defined with respect to the boundaries defined by `SCALe:Y1` and `SCALe:Y2` according to the following equation:

$$Y = (Y * (Y2 - Y1)) + Y1$$

Thus, if you set Y1 to 100 mV, and Y2 to 1 V, a Y value of 0.100 in a vertex is at 190 mV.

The Y2 value is a voltage value specifying the location of the Y2 marker.

Query Syntax `:MTESt:SCALe:Y2?`

The `:MTESt:SCALe:Y2?` query returns the current setting of the Y2 marker.

Return Format `<y2_value><NL>`

`<y2_value> ::= Y2 value in NR3 format`

- See Also**
- ["Introduction to :MTESt Commands"](#) on page 783
 - [":MTESt:SCALe:BIND"](#) on page 808
 - [":MTESt:SCALe:X1"](#) on page 809
 - [":MTESt:SCALe:XDELta"](#) on page 810
 - [":MTESt:SCALe:Y1"](#) on page 811

:MTESt:SOURce

N (see [page 1730](#))

Command Syntax :MTESt:SOURce <source>

<source> ::= CHANnel<n>

<n> ::= 1 to (# analog channels) in NR1 format

The :MTESt:SOURce command selects the channel which is configured by the commands contained in a mask file when it is loaded.

Query Syntax :MTESt:SOURce?

The :MTESt:SOURce? query returns the channel which is configured by the commands contained in the current mask file.

Return Format <source><NL>

<source> ::= {CHAN<n> | NONE}

<n> ::= 1 to (# analog channels) in NR1 format

- See Also**
- ["Introduction to :MTESt Commands"](#) on page 783
 - [":MTESt:AMASK:SOURce"](#) on page 788

:MTESt:TITLe

N (see [page 1730](#))

Query Syntax :MTESt:TITLe?

The :MTESt:TITLe? query returns the mask title which is a string of up to 128 characters. The title is displayed in the mask test dialog box and mask test tab when a mask file is loaded.

Return Format <title><NL>

<title> ::= a string of up to 128 ASCII characters.

See Also · ["Introduction to :MTESt Commands"](#) on page 783

32 :POD Commands

Control all oscilloscope functions associated with groups of digital channels. See "[Introduction to :POD<n> Commands](#)" on page 815.

Table 122 :POD<n> Commands Summary

Command	Query	Options and Query Returns
:POD<n>:DISPlay {{0 OFF} {1 ON}} (see page 817)	:POD<n>:DISPlay? (see page 817)	{0 1} <n> ::= 1-2 in NR1 format
:POD<n>:SIZE <value> (see page 818)	:POD<n>:SIZE? (see page 818)	<value> ::= {SMALl MEDiUm LARGe}
:POD<n>:THReshold <type>[suffix] (see page 819)	:POD<n>:THReshold? (see page 819)	<n> ::= 1-2 in NR1 format <type> ::= {CMOS ECL TTL <user defined value>} <user defined value> ::= value in NR3 format [suffix] ::= {V mV uV }

Introduction to :POD<n> Commands <n> ::= {1 | 2}

The POD subsystem commands control the viewing and threshold of groups of digital channels.

POD1 ::= D0-D7

POD2 ::= D8-D15

NOTE

These commands are only valid for the MSO models.

Reporting the Setup

Use :POD1? or :POD2? to query setup information for the POD subsystem.

Return Format

The following is a sample response from the :POD1? query. In this case, the query was issued following a *RST command.

```
:POD1:DISP 0;THR +1.40E+00
```


:POD<n>:DISPlay

N (see [page 1730](#))

Command Syntax :POD<n>:DISPlay <display>

<display> ::= {{1 | ON} | {0 | OFF}}

<n> ::= An integer, 1 or 2, is attached as a suffix to the command and defines the group of channels that are affected by the command.

POD1 ::= D0-D7

POD2 ::= D8-D15

The :POD<n>:DISPlay command turns displaying of the specified group of channels on or off.

NOTE

This command is only valid for the MSO models.

Query Syntax :POD<n>:DISPlay?

The :POD<n>:DISPlay? query returns the current display setting of the specified group of channels.

Return Format <display><NL>

<display> ::= {0 | 1}

- See Also**
- ["Introduction to :POD<n> Commands"](#) on page 815
 - [":DIGital<d>:DISPlay"](#) on page 423
 - [":CHANnel<n>:DISPlay"](#) on page 357
 - [":VIEW"](#) on page 300
 - [":BLANK"](#) on page 268
 - [":STATus"](#) on page 297

:POD<n>:SIZE

N (see [page 1730](#))

Command Syntax :POD<n>:SIZE <value>

<n> ::= An integer, 1 or 2, is attached as a suffix to the command and defines the group of channels that are affected by the command.

POD1 ::= D0-D7

POD2 ::= D8-D15

<value> ::= {SMALl | MEDiUm | LARGe}

The :POD<n>:SIZE command specifies the size of digital channels on the display. Sizes are set for all pods. Therefore, if you set the size on pod 1 (for example), the same size is set on pod 2 as well.

NOTE

This command is only valid for the MSO models.

Query Syntax :POD<n>:SIZE?

The :POD<n>:SIZE? query returns the digital channels size setting.

Return Format <size_value><NL>

<size_value> ::= {SMAL | MED | LARG}

- See Also**
- ["Introduction to :POD<n> Commands"](#) on page 815
 - [":DIGital<d>:SIZE"](#) on page 426
 - [":DIGital<d>:POSition"](#) on page 425

:POD<n>:THReshold

N (see [page 1730](#))

Command Syntax :POD<n>:THReshold <type>[<suffix>]

<n> ::= An integer, 1 or 2, is attached as a suffix to the command and defines the group of channels that are affected by the command.

<type> ::= {CMOS | ECL | TTL | <user defined value>}

<user defined value> ::= -8.00 to +8.00 in NR3 format

<suffix> ::= {V | mV | uV}

POD1 ::= D0-D7

POD2 ::= D8-D15

TTL ::= 1.4V

CMOS ::= 2.5V

ECL ::= -1.3V

The :POD<n>:THReshold command sets the threshold for the specified group of channels. The threshold is used for triggering purposes and for displaying the digital data as high (above the threshold) or low (below the threshold).

NOTE

This command is only valid for the MSO models.

Query Syntax :POD<n>:THReshold?

The :POD<n>:THReshold? query returns the threshold value for the specified group of channels.

Return Format <threshold><NL>

<threshold> ::= Floating point number in NR3 format

- See Also**
- ["Introduction to :POD<n> Commands"](#) on page 815
 - [":DIGital<d>:THReshold"](#) on page 427
 - [":TRIGger\[:EDGE\]:LEVel"](#) on page 1457

Example Code

```
' THRESHOLD - This command is used to set the voltage threshold for
' the waveforms. There are three preset values (TTL, CMOS, and ECL)
' and you can also set a user-defined threshold value between
' -8.0 volts and +8.0 volts.
'
' In this example, we set channels 0-7 to CMOS, then set channels
' 8-15 to a user-defined 2.0 volts, and then set the external trigger
' to TTL. Of course, you only need to set the thresholds for the
' channels you will be using in your program.
```

```
' Set channels 0-7 to CMOS threshold.  
myScope.WriteString ":POD1:THRESHOLD CMOS"  
  
' Set channels 8-15 to 2.0 volts.  
myScope.WriteString ":POD2:THRESHOLD 2.0"  
  
' Set external channel to TTL threshold (short form).  
myScope.WriteString ":TRIG:LEV TTL,EXT"
```

See complete example programs at: [Chapter 50](#), "Programming Examples," starting on page 1739

33 :POWer Commands

These :POWer commands are available when the power measurements and analysis application is licensed and enabled.

Table 123 :POWer Commands Summary

Command	Query	Options and Query Returns
n/a	:POWer:CLResponse? (see page 829)	n/a
:POWer:CLResponse:APP Ly (see page 830)	n/a	n/a
n/a	:POWer:CLResponse:DATA? [SWEep SINGLE] (see page 831)	<binary_block> ::= comma-separated data with newlines at the end of each row
n/a	:POWer:CLResponse:DATA:GMARgin? (see page 832)	<gain_margin> ::= gain margin in dB in NR3 format.
n/a	:POWer:CLResponse:DATA:GMARgin:FREQuency? (see page 833)	<frequency> ::= 0 degrees phase crossover frequency in Hz in NR3 format
n/a	:POWer:CLResponse:DATA:PMARgin? (see page 834)	<phase_margin> ::= phase margin in degrees in NR3 format.
n/a	:POWer:CLResponse:DATA:PMARgin:FREQuency? (see page 835)	<frequency> ::= 0dB gain crossover frequency in Hz in NR3 format.
:POWer:CLResponse:FREQuency:MODE <mode> (see page 836)	:POWer:CLResponse:FREQuency:MODE? (see page 836)	<mode> ::= {SWEep SINGLE}
:POWer:CLResponse:FREQuency:SINGLE <value>[suffix] (see page 837)	:POWer:CLResponse:FREQuency:SINGLE? (see page 837)	<value> ::= {20 100 1000 10000 100000 1000000 10000000 20000000} [suffix] ::= {Hz kHz MHz}

Table 123 :POWer Commands Summary (continued)

Command	Query	Options and Query Returns
:POWer:CLResponse:FREQuency:START <value>[suffix] (see page 838)	:POWer:CLResponse:FREQuency:START? (see page 838)	<value> ::= {20 100 1000 10000 100000 1000000 10000000} [suffix] ::= {Hz kHz MHz}
:POWer:CLResponse:FREQuency:STOP <value>[suffix] (see page 839)	:POWer:CLResponse:FREQuency:STOP? (see page 839)	<value> ::= {100 1000 10000 100000 1000000 10000000 20000000} [suffix] ::= {Hz kHz MHz}
:POWer:CLResponse:PPDecade <pts> (see page 840)	:POWer:CLResponse:PPDecade? (see page 840)	<pts> ::= {10 20 30 40 50 60 70 80 90 100}
:POWer:CLResponse:SOURce:INPut <source> (see page 841)	:POWer:CLResponse:SOURce:INPut? (see page 841)	<source> ::= CHANNEL<n> <n> ::= 1 to (# analog channels) in NR1 format
:POWer:CLResponse:SOURce:OUTPut <source> (see page 842)	:POWer:CLResponse:SOURce:OUTPut? (see page 842)	<source> ::= CHANNEL<n> <n> ::= 1 to (# analog channels) in NR1 format
:POWer:CLResponse:TRACe <selection> (see page 843)	:POWer:CLResponse:TRACe? (see page 843)	<selection> ::= {NONE ALL GAIN PHASE}[, {GAIN PHASE}]
:POWer:CLResponse:WGEN:LOAD <impedance> (see page 844)	:POWer:CLResponse:WGEN:LOAD? (see page 844)	<impedance> ::= {ONEMeg FIFTy}
:POWer:CLResponse:WGEN:VOLTage <amplitude>[, <range>] (see page 845)	:POWer:CLResponse:WGEN:VOLTage? [<range>] (see page 845)	<amplitude> ::= amplitude in volts in NR3 format <range> ::= {F20HZ F100HZ F1KHZ F10KHZ F100KHZ F1MHZ F10MHZ F20MHZ}
:POWer:CLResponse:WGEN:VOLTage:PROFile {0 OFF} {1 ON} (see page 846)	:POWer:CLResponse:WGEN:VOLTage:PROFile? (see page 846)	{0 1}
:POWer:DESKew (see page 847)	n/a	n/a
:POWer:EFFiciency:APPLy (see page 848)	n/a	n/a
:POWer:EFFiciency:TYPE <type> (see page 849)	:POWer:EFFiciency:TYPE? (see page 849)	<type> ::= {DCDC DCAC ACDC ACAC}

Table 123 :POWer Commands Summary (continued)

Command	Query	Options and Query Returns
:POWer:ENABle {{0 OFF} {1 ON}} (see page 850)	:POWer:ENABle? (see page 850)	{0 1}
:POWer:HARMonics:APPLy (see page 851)	n/a	n/a
n/a	:POWer:HARMonics:DATA? (see page 852)	<binary_block> ::= comma-separated data with newlines at the end of each row
:POWer:HARMonics:DISP lay <display> (see page 853)	:POWer:HARMonics:DISP lay? (see page 853)	<display> ::= {TABLE BAR OFF}
n/a	:POWer:HARMonics:FAIL count? (see page 854)	<count> ::= integer in NR1 format
:POWer:HARMonics:LINE <frequency> (see page 855)	:POWer:HARMonics:LINE ? (see page 855)	<frequency> ::= {F50 F60 F400 AUTO}
n/a	:POWer:HARMonics:POWe rfactor? (see page 856)	<value> ::= Class C power factor in NR3 format
:POWer:HARMonics:RPOW er <source> (see page 857)	:POWer:HARMonics:RPOW er? (see page 857)	<source> ::= {MEASured USER}
:POWer:HARMonics:RPOW er:USER <value> (see page 858)	:POWer:HARMonics:RPOW er:USER? (see page 858)	<value> ::= Watts from 1.0 to 600.0 in NR3 format
n/a	:POWer:HARMonics:RUNC ount? (see page 859)	<count> ::= integer in NR1 format
:POWer:HARMonics:STAN dard <class> (see page 860)	:POWer:HARMonics:STAN dard? (see page 860)	<class> ::= {A B C D}
n/a	:POWer:HARMonics:STAT us? (see page 861)	<status> ::= {PASS FAIL UNTested}
n/a	:POWer:HARMonics:THD? (see page 862)	<value> ::= Total Harmonics Distortion in NR3 format
:POWer:INRush:APPLy (see page 863)	n/a	n/a
:POWer:INRush:EXIT (see page 864)	n/a	n/a

Table 123 :POWer Commands Summary (continued)

Command	Query	Options and Query Returns
:POWer:INRush:NEXT (see page 865)	n/a	n/a
:POWer:ITYPE <type> (see page 866)	:POWer:ITYPE? (see page 866)	<type> ::= {DC AC}
:POWer:MODulation:APPLY (see page 867)	n/a	n/a
:POWer:MODulation:SOURCe <source> (see page 868)	:POWer:MODulation:SOURCe? (see page 868)	<source> ::= {V I}
:POWer:MODulation:TYPE <modulation> (see page 869)	:POWer:MODulation:TYPE? (see page 869)	<modulation> ::= {VAverage ACRMs VRATio PERiod FREQuency PWIDith NWIDth DUTYcycle RISetime FALLtime}
:POWer:ONOFF:APPLY (see page 870)	n/a	n/a
:POWer:ONOFF:EXIT (see page 871)	n/a	n/a
:POWer:ONOFF:NEXT (see page 872)	n/a	n/a
:POWer:ONOFF:TEST {{0 OFF} {1 ON}} (see page 873)	:POWer:ONOFF:TEST? (see page 873)	{0 1}
:POWer:ONOFF:THRESHolDs <type>, <input_thr>, <output_thr> (see page 874)	:POWer:ONOFF:THRESHolDs? <type> (see page 874)	<type> ::= {0 1} <input_thr> ::= percent from 0-100 in NR1 format <output_thr> ::= percent from 0-100 in NR1 format
n/a	:POWer:PSRR? (see page 876)	n/a
:POWer:PSRR:APPLY (see page 877)	n/a	n/a
n/a	:POWer:PSRR:DATA? [SWEep SINGLE] (see page 878)	<binary_block> ::= comma-separated data with newlines at the end of each row
:POWer:PSRR:FREQuency:MAXimum <value>[suffix] (see page 879)	:POWer:PSRR:FREQuency:MAXimum? (see page 879)	<value> ::= {10 100 1000 10000 100000 1000000 10000000 20000000} [suffix] ::= {Hz kHz MHz}

Table 123 :POWer Commands Summary (continued)

Command	Query	Options and Query Returns
:POWer:PSRR:FREQuency :MINimum <value>[suffix] (see page 880)	:POWer:PSRR:FREQuency :MINimum? (see page 880)	<value> ::= {1 10 100 1000 10000 100000 1000000 10000000} [suffix] ::= {Hz kHz MHz}
:POWer:PSRR:FREQuency :MODE <mode> (see page 881)	:POWer:PSRR:FREQuency :MODE? (see page 881)	<mode> ::= {SWEep SINGLE}
:POWer:PSRR:FREQuency :SINGLE <value>[suffix] (see page 882)	:POWer:PSRR:FREQuency :SINGLE? (see page 882)	<value> ::= {1 10 100 1000 10000 100000 1000000 10000000 20000000} [suffix] ::= {Hz kHz MHz}
:POWer:PSRR:PPDecade <pts> (see page 883)	:POWer:PSRR:PPDecade? (see page 883)	<pts> ::= {10 20 30 40 50 60 70 80 90 100}
:POWer:PSRR:SOURce:IN Put <source> (see page 884)	:POWer:PSRR:SOURce:IN Put? (see page 884)	<source> ::= CHANNEL<n> <n> ::= 1 to (# analog channels) in NR1 format
:POWer:PSRR:SOURce:OU TPut <source> (see page 885)	:POWer:PSRR:SOURce:OU TPut? (see page 885)	<source> ::= CHANNEL<n> <n> ::= 1 to (# analog channels) in NR1 format
:POWer:PSRR:TRACe <selection> (see page 886)	:POWer:PSRR:TRACe? (see page 886)	<selection> ::= {NONE GAIN}
:POWer:PSRR:WGEN:LOAD <impedance> (see page 887)	:POWer:PSRR:WGEN:LOAD ? (see page 887)	<impedance> ::= {ONEMeg FIFTy}
:POWer:PSRR:WGEN:VOLT age <amplitude>[,<range>] (see page 888)	:POWer:PSRR:WGEN:VOLT age? [<range>] (see page 888)	<amplitude> ::= amplitude in volts in NR3 format <range> ::= {F20HZ F100HZ F1KHZ F10KHZ F100KHZ F1MHZ F10MHZ F20MHZ}
:POWer:PSRR:WGEN:VOLT age:PROFile {{0 OFF} {1 ON}} (see page 889)	:POWer:PSRR:WGEN:VOLT age:PROFile? (see page 889)	{0 1}
:POWer:QUALity:APPLY (see page 890)	n/a	n/a
:POWer:RIPPlE:APPLY (see page 891)	n/a	n/a

Table 123 :POWer Commands Summary (continued)

Command	Query	Options and Query Returns
:POWer:SIGNals:AUTOse tup <analysis> (see page 892)	n/a	<analysis> ::= {HARMONics EFFiciency RIPPLE MODulation QUALity SLEW SWITCh RDSVce}
:POWer:SIGNals:CYCLes :HARMONics <count> (see page 893)	:POWer:SIGNals:CYCLes :HARMONics? (see page 893)	<count> ::= integer in NR1 format Legal values are 1 to 100.
:POWer:SIGNals:CYCLes :QUALity <count> (see page 894)	:POWer:SIGNals:CYCLes :QUALity? (see page 894)	<count> ::= integer in NR1 format Legal values are 1 to 100.
:POWer:SIGNals:DURati on:EFFiciency <value>[suffix] (see page 895)	:POWer:SIGNals:DURati on:EFFiciency? (see page 895)	<value> ::= value in NR3 format [suffix] ::= {s ms us ns}
:POWer:SIGNals:DURati on:MODulation <value>[suffix] (see page 896)	:POWer:SIGNals:DURati on:MODulation? (see page 896)	<value> ::= value in NR3 format [suffix] ::= {s ms us ns}
:POWer:SIGNals:DURati on:ONOFF:OFF <value>[suffix] (see page 897)	:POWer:SIGNals:DURati on:ONOFF:OFF? (see page 897)	<value> ::= value in NR3 format [suffix] ::= {s ms us ns}
:POWer:SIGNals:DURati on:ONOFF:ON <value>[suffix] (see page 898)	:POWer:SIGNals:DURati on:ONOFF:ON? (see page 898)	<value> ::= value in NR3 format [suffix] ::= {s ms us ns}
:POWer:SIGNals:DURati on:RIPPLE <value>[suffix] (see page 899)	:POWer:SIGNals:DURati on:RIPPLE? (see page 899)	<value> ::= value in NR3 format [suffix] ::= {s ms us ns}
:POWer:SIGNals:DURati on:TRANSient <value>[suffix] (see page 900)	:POWer:SIGNals:DURati on:TRANSient? (see page 900)	<value> ::= value in NR3 format [suffix] ::= {s ms us ns}
:POWer:SIGNals:IEXPe cted <value>[suffix] (see page 901)	:POWer:SIGNals:IEXPe cted? (see page 901)	<value> ::= Expected current value in NR3 format [suffix] ::= {A mA}
:POWer:SIGNals:OVERsh oot <percent> (see page 902)	:POWer:SIGNals:OVERsh oot? (see page 902)	<percent> ::= percent of overshoot value in NR1 format [suffix] ::= {V mV}}

Table 123 :POWer Commands Summary (continued)

Command	Query	Options and Query Returns
:POWer:SIGNals:VMAXimum:INRush <value>[suffix] (see page 903)	:POWer:SIGNals:VMAXimum:INRush? (see page 903)	<value> ::= Maximum expected input Voltage in NR3 format [suffix] ::= {V mV}
:POWer:SIGNals:VMAXimum:ONOff:OFF <value>[suffix] (see page 904)	:POWer:SIGNals:VMAXimum:ONOff:OFF? (see page 904)	<value> ::= Maximum expected input Voltage in NR3 format [suffix] ::= {V mV}
:POWer:SIGNals:VMAXimum:ONOff:ON <value>[suffix] (see page 905)	:POWer:SIGNals:VMAXimum:ONOff:ON? (see page 905)	<value> ::= Maximum expected input Voltage in NR3 format [suffix] ::= {V mV}
:POWer:SIGNals:VSTeady:ONOff:OFF <value>[suffix] (see page 906)	:POWer:SIGNals:VSTeady:ONOff:OFF? (see page 906)	<value> ::= Expected steady stage output Voltage value in NR3 format [suffix] ::= {V mV}
:POWer:SIGNals:VSTeady:ONOff:ON <value>[suffix] (see page 907)	:POWer:SIGNals:VSTeady:ONOff:ON? (see page 907)	<value> ::= Expected steady stage output Voltage value in NR3 format [suffix] ::= {V mV}
:POWer:SIGNals:VSTeady:TRANSient <value>[suffix] (see page 908)	:POWer:SIGNals:VSTeady:TRANSient? (see page 908)	<value> ::= Expected steady stage output Voltage value in NR3 format [suffix] ::= {V mV}
:POWer:SIGNals:SOURce:CURRENT<i> <source> (see page 909)	:POWer:SIGNals:SOURce:CURRENT<i>? (see page 909)	<i> ::= 1, 2 in NR1 format <source> ::= CHANnel<n> <n> ::= 1 to (# analog channels) in NR1 format
:POWer:SIGNals:SOURce:VOLTage<i> <source> (see page 910)	:POWer:SIGNals:SOURce:VOLTage<i>? (see page 910)	<i> ::= 1, 2 in NR1 format <source> ::= CHANnel<n> <n> ::= 1 to (# analog channels) in NR1 format
:POWer:SLEW:APPLy (see page 911)	n/a	n/a
:POWer:SLEW:SOURce <source> (see page 912)	:POWer:SLEW:SOURce? (see page 912)	<source> ::= {V I}
:POWer:SWITCh:APPLy (see page 913)	n/a	n/a

Table 123 :POWer Commands Summary (continued)

Command	Query	Options and Query Returns
:POWer:SWITCh:CONDUCTion <conduction> (see page 914)	:POWer:SWITCh:CONDUCTion? (see page 914)	<conduction> ::= {WAVEform RDS VCE}
:POWer:SWITCh:IREFereNce <percent> (see page 915)	:POWer:SWITCh:IREFereNce? (see page 915)	<percent> ::= percent in NR1 format
:POWer:SWITCh:RDS <value>[suffix] (see page 916)	:POWer:SWITCh:RDS? (see page 916)	<value> ::= Rds(on) value in NR3 format [suffix] ::= {OHM mOHM}
:POWer:SWITCh:VCE <value>[suffix] (see page 917)	:POWer:SWITCh:VCE? (see page 917)	<value> ::= Vce(sat) value in NR3 format [suffix] ::= {V mV}
:POWer:SWITCh:VREFereNce <percent> (see page 918)	:POWer:SWITCh:VREFereNce? (see page 918)	<percent> ::= percent in NR1 format
:POWer:TRANsient:APPLy (see page 919)	n/a	n/a
:POWer:TRANsient:EXIT (see page 920)	n/a	n/a
:POWer:TRANsient:IINiitial <value>[suffix] (see page 921)	:POWer:TRANsient:IINiitial? (see page 921)	<value> ::= Initial current value in NR3 format [suffix] ::= {A mA}
:POWer:TRANsient:INEW <value>[suffix] (see page 922)	:POWer:TRANsient:INEW? (see page 922)	<value> ::= New current value in NR3 format [suffix] ::= {A mA}
:POWer:TRANsient:NEXT (see page 923)	n/a	n/a

:POWer:CLResponse

N (see [page 1730](#))

Query Syntax :POWer:CLResponse?

The :POWer:CLResponse? query returns the Control Loop Response (Bode) power analysis settings.

Return Format <settings_string><NL>

For example, the query returns the following string when issued after the *RST command.

```
:POW:CLR:SOUR:INP CHAN1;OUTP CHAN2;:POW:CLR:FREQ:STAR +100E+00;
STOP +20.000000E+06;:POW:CLR:WGEN:VOLT +200.0E-03;LOAD FIFT
```

- See Also**
- [":POWer:CLResponse:APPLY"](#) on page 830
 - [":POWer:CLResponse:DATA"](#) on page 831
 - [":POWer:CLResponse:FREQuency:MODE"](#) on page 836
 - [":POWer:CLResponse:FREQuency:START"](#) on page 838
 - [":POWer:CLResponse:FREQuency:STOP"](#) on page 839
 - [":POWer:CLResponse:PPDecade"](#) on page 840
 - [":POWer:CLResponse:SOURce:INPut"](#) on page 841
 - [":POWer:CLResponse:SOURce:OUTPut"](#) on page 842
 - [":POWer:CLResponse:WGEN:LOAD"](#) on page 844
 - [":POWer:CLResponse:WGEN:VOLTage"](#) on page 845
 - [":POWer:CLResponse:WGEN:VOLTage:PROFile"](#) on page 846

:POWer:CLResponse:APPLy

N (see [page 1730](#))

Command Syntax

`:POWer:CLResponse:APPLy`

The `:POWer:CLResponse:APPLy` command performs the control loop response (Bode) analysis to help you determine the margin of a control loop.

A Bode plot measurement plots gain and/or phase as a function of frequency.

You can use the `:POWer:CLResponse:TRACe` command to specify whether to include gain, phase, both gain and phase, or neither in the frequency response analysis results.

This control loop response analysis requires an input sine wave (from the oscilloscope's waveform generator, V_i) be swept from a low to a high frequency while measuring V_i and V_o RMS voltages at each step frequency, using two channels of the oscilloscope.

For a gain plot, gain (A, in dB units) at each step frequency is computed as $20\text{Log}(V_o/V_i)$ and plotted using a math function waveform.

For a phase plot, the phase difference between the channels is measured at each step frequency. Phase measurements and plots are only possible if the input and output waveforms exceed 1 division peak-to-peak (>1 mVpp).

It takes some time for the frequency sweep analysis to complete. You can query bit 0 of the Standard Event Status Register (`*ESR?`) to find out when the analysis is complete.

- See Also
- ["*ESR \(Standard Event Status Register\)"](#) on page 238
 - [":POWer:CLResponse"](#) on page 829
 - [":POWer:CLResponse:DATA"](#) on page 831
 - [":POWer:CLResponse:FREQuency:MODE"](#) on page 836
 - [":POWer:CLResponse:FREQuency:SINGLE"](#) on page 837
 - [":POWer:CLResponse:FREQuency:START"](#) on page 838
 - [":POWer:CLResponse:FREQuency:STOP"](#) on page 839
 - [":POWer:CLResponse:PPDecade"](#) on page 840
 - [":POWer:CLResponse:SOURce:INPut"](#) on page 841
 - [":POWer:CLResponse:SOURce:OUTPut"](#) on page 842
 - [":POWer:CLResponse:TRACe"](#) on page 843
 - [":POWer:CLResponse:WGEN:LOAD"](#) on page 844
 - [":POWer:CLResponse:WGEN:VOLTage"](#) on page 845
 - [":POWer:CLResponse:WGEN:VOLTage:PROFile"](#) on page 846

:POWer:CLResponse:DATA

N (see [page 1730](#))

Query Syntax :POWer:CLResponse:DATA? [SWEep | SINGle]

The :POWer:CLResponse:DATA? query returns data from the Control Loop Response (Bode) power analysis.

The comma-separated value format is suitable for spreadsheet analysis.

You can use the :POWer:CLResponse:TRACe command to specify whether to include gain, phase, both gain and phase, or neither in the frequency response analysis results.

The SWEep or SINGle option specifies whether to get the data from a sweep or single-frequency analysis (see :POWer:CLResponse:FREQuency:MODE). If this option is not specified, the data from the sweep analysis is returned by default.

Return Format <binary_block><NL>

<binary_block> ::= comma-separated data with newlines at the end of each row

- See Also**
- [":POWer:CLResponse"](#) on page 829
 - [":POWer:CLResponse:APPLy"](#) on page 830
 - [":POWer:CLResponse:DATA:GMARgin"](#) on page 832
 - [":POWer:CLResponse:DATA:GMARgin:FREQuency"](#) on page 833
 - [":POWer:CLResponse:DATA:PMARgin"](#) on page 834
 - [":POWer:CLResponse:DATA:PMARgin:FREQuency"](#) on page 835
 - [":POWer:CLResponse:FREQuency:MODE"](#) on page 836
 - [":POWer:CLResponse:FREQuency:SINGle"](#) on page 837
 - [":POWer:CLResponse:FREQuency:START"](#) on page 838
 - [":POWer:CLResponse:FREQuency:STOP"](#) on page 839
 - [":POWer:CLResponse:PPDecade"](#) on page 840
 - [":POWer:CLResponse:SOURce:INPut"](#) on page 841
 - [":POWer:CLResponse:SOURce:OUTPut"](#) on page 842
 - [":POWer:CLResponse:TRACe"](#) on page 843
 - [":POWer:CLResponse:WGEN:LOAD"](#) on page 844
 - [":POWer:CLResponse:WGEN:VOLTage"](#) on page 845
 - [":POWer:CLResponse:WGEN:VOLTage:PROFile"](#) on page 846

:POWer:CLResponse:DATA:GMARgin

N (see [page 1730](#))

Query Syntax :POWer:CLResponse:DATA:GMARgin?

After the Control Loop Response (Bode) power analysis has been performed (see :POWer:CLResponse:APPLY), the :POWer:CLResponse:DATA:GMARgin? query returns the gain margin in dB.

Return Format <gain_margin><NL>

<gain_margin> ::= gain margin in dB in NR3 format.

The query returns +9.9E+37 if the value cannot be calculated from the last sweep (that is, if there are no crossover points).

- See Also**
- [":POWer:CLResponse:APPLY"](#) on page 830
 - [":POWer:CLResponse:DATA"](#) on page 831
 - [":POWer:CLResponse:DATA:GMARgin:FREQuency"](#) on page 833
 - [":POWer:CLResponse:DATA:PMARgin"](#) on page 834
 - [":POWer:CLResponse:DATA:PMARgin:FREQuency"](#) on page 835

:POWer:CLResponse:DATA:GMARgin:FREQuency

N (see [page 1730](#))

Query Syntax :POWer:CLResponse:DATA:GMARgin:FREQuency?

After the Control Loop Response (Bode) power analysis has been performed (see :POWer:CLResponse:APPLY), the :POWer:CLResponse:DATA:GMARgin:FREQuency? query returns the 0° phase crossover frequency in Hz.

Return Format <frequency><NL>

<frequency> ::= 0 degrees phase crossover frequency in Hz in NR3 format

The query returns +9.9E+37 if the value cannot be calculated from the last sweep (that is, if there are no crossover points).

- See Also**
- [":POWer:CLResponse:APPLY"](#) on page 830
 - [":POWer:CLResponse:DATA"](#) on page 831
 - [":POWer:CLResponse:DATA:GMARgin"](#) on page 832
 - [":POWer:CLResponse:DATA:PMARgin"](#) on page 834
 - [":POWer:CLResponse:DATA:PMARgin:FREQuency"](#) on page 835

:POWer:CLResponse:DATA:PMARgin

N (see [page 1730](#))

Query Syntax :POWer:CLResponse:DATA:PMARgin?

After the Control Loop Response (Bode) power analysis has been performed (see :POWer:CLResponse:APPLY), the :POWer:CLResponse:DATA:PMARgin? query returns the phase margin in degrees.

Return Format <phase_margin><NL>

<phase_margin> ::= phase margin in degrees in NR3 format.

The query returns +9.9E+37 if the value cannot be calculated from the last sweep (that is, if there are no crossover points).

- See Also**
- [":POWer:CLResponse:APPLY"](#) on page 830
 - [":POWer:CLResponse:DATA"](#) on page 831
 - [":POWer:CLResponse:DATA:GMARgin"](#) on page 832
 - [":POWer:CLResponse:DATA:GMARgin:FREQuency"](#) on page 833
 - [":POWer:CLResponse:DATA:PMARgin:FREQuency"](#) on page 835

:POWer:CLResponse:DATA:PMARgin:FREQuency

N (see [page 1730](#))

Query Syntax :POWer:CLResponse:DATA:PMARgin:FREQuency?

After the Control Loop Response (Bode) power analysis has been performed (see :POWer:CLResponse:APPLy), the :POWer:CLResponse:DATA:PMARgin:FREQuency? query returns the 0 dB gain crossover frequency in Hz.

Return Format <frequency><NL>

<frequency> ::= 0dB gain crossover frequency in Hz in NR3 format.

The query returns +9.9E+37 if the value cannot be calculated from the last sweep (that is, if there are no crossover points).

- See Also**
- [":POWer:CLResponse:APPLy"](#) on page 830
 - [":POWer:CLResponse:DATA"](#) on page 831
 - [":POWer:CLResponse:DATA:GMARgin"](#) on page 832
 - [":POWer:CLResponse:DATA:GMARgin:FREQuency"](#) on page 833
 - [":POWer:CLResponse:DATA:PMARgin"](#) on page 834

:POWer:CLResponse:FREQuency:MODE

N (see [page 1730](#))

Command Syntax :POWer:CLResponse:FREQuency:MODE <mode>

<mode> ::= {SWEep | SINGle}

The :POWer:CLResponse:FREQuency:MODE command specifies whether the analysis should be performed by sweeping through a range of frequencies (SWEep) or at a single frequency (SINGle).

The SINGle mode is useful for evaluating amplitudes at a single frequency, for example, near the expected 0 dB cross-over frequency. After running the test at a single frequency, you can manually adjust (increase) the waveform generator's amplitude until you begin to observe distortion in the waveforms on the oscilloscope's display. You can then use that amplitude at all frequencies in SWEep mode, or you can evaluate amplitudes at other frequencies in order to determine an optimized amplitude profile (see :POWer:CLResponse:WGEN:VOLTage:PROFile).

Query Syntax :POWer:CLResponse:FREQuency:MODE?

The :POWer:CLResponse:FREQuency:MODE? query returns the frequency mode setting.

Return Format <mode><NL>

<mode> ::= {SWE | SING}

- See Also**
- [":POWer:CLResponse"](#) on page 829
 - [":POWer:CLResponse:APPLY"](#) on page 830
 - [":POWer:CLResponse:DATA"](#) on page 831
 - [":POWer:CLResponse:FREQuency:SINGle"](#) on page 837
 - [":POWer:CLResponse:FREQuency:START"](#) on page 838
 - [":POWer:CLResponse:FREQuency:STOP"](#) on page 839
 - [":POWer:CLResponse:PPDecade"](#) on page 840
 - [":POWer:CLResponse:SOURce:INPut"](#) on page 841
 - [":POWer:CLResponse:SOURce:OUTPut"](#) on page 842
 - [":POWer:CLResponse:WGEN:LOAD"](#) on page 844
 - [":POWer:CLResponse:WGEN:VOLTage"](#) on page 845
 - [":POWer:CLResponse:WGEN:VOLTage:PROFile"](#) on page 846

:POWer:CLResponse:FREQuency:SINGle

N (see [page 1730](#))

Command Syntax :POWer:CLResponse:FREQuency:SINGle <value>[suffix]
 <value> ::= {20 | 100 | 1000 | 10000 | 100000 | 1000000 | 10000000
 | 20000000}
 [suffix] ::= {Hz | kHz | MHz}

The :POWer:CLResponse:FREQuency:SINGle command sets the single frequency value. The control loop response analysis is displayed on a log scale Bode plot, so you can select from decade values in addition to the minimum frequency of 20 Hz.

Query Syntax :POWer:CLResponse:FREQuency:SINGle?

The :POWer:CLResponse:FREQuency:SINGle? query returns the single frequency setting.

Return Format <value><NL>
 <value> ::= {20 | 100 | 1000 | 10000 | 100000 | 1000000 | 10000000
 | 20000000}

- See Also**
- [":POWer:CLResponse"](#) on page 829
 - [":POWer:CLResponse:APPLY"](#) on page 830
 - [":POWer:CLResponse:DATA"](#) on page 831
 - [":POWer:CLResponse:FREQuency:MODE"](#) on page 836
 - [":POWer:CLResponse:PPDecade"](#) on page 840
 - [":POWer:CLResponse:SOURce:INPut"](#) on page 841
 - [":POWer:CLResponse:SOURce:OUTPut"](#) on page 842
 - [":POWer:CLResponse:WGEN:LOAD"](#) on page 844
 - [":POWer:CLResponse:WGEN:VOLTage"](#) on page 845
 - [":POWer:CLResponse:WGEN:VOLTage:PROFile"](#) on page 846

:POWer:CLResponse:FREQuency:START

N (see [page 1730](#))

Command Syntax :POWer:CLResponse:FREQuency:START <value>[suffix]
 <value> ::= {20 | 100 | 1000 | 10000 | 100000 | 1000000 | 10000000}
 [suffix] ::= {Hz | kHz | MHz}

The :POWer:CLResponse:FREQuency:START command sets the frequency sweep start value. The control loop response analysis is displayed on a log scale Bode plot, so you can select from decade values in addition to the minimum frequency of 20 Hz.

Query Syntax :POWer:CLResponse:FREQuency:START?

The :POWer:CLResponse:FREQuency:START? query returns the frequency sweep start setting.

Return Format <value><NL>
 <value> ::= {20 | 100 | 1000 | 10000 | 100000 | 1000000 | 10000000}

- See Also**
- [":POWer:CLResponse"](#) on page 829
 - [":POWer:CLResponse:APPLY"](#) on page 830
 - [":POWer:CLResponse:DATA"](#) on page 831
 - [":POWer:CLResponse:FREQuency:MODE"](#) on page 836
 - [":POWer:CLResponse:FREQuency:STOP"](#) on page 839
 - [":POWer:CLResponse:PPDecade"](#) on page 840
 - [":POWer:CLResponse:SOURce:INPut"](#) on page 841
 - [":POWer:CLResponse:SOURce:OUTPut"](#) on page 842
 - [":POWer:CLResponse:WGEN:LOAD"](#) on page 844
 - [":POWer:CLResponse:WGEN:VOLTage"](#) on page 845
 - [":POWer:CLResponse:WGEN:VOLTage:PROFile"](#) on page 846

:POWer:CLResponse:FREQuency:STOP

N (see [page 1730](#))

Command Syntax :POWer:CLResponse:FREQuency:STOP <value>[suffix]

<value> ::= {100 | 1000 | 10000 | 100000 | 1000000 | 10000000 | 20000000
}

[suffix] ::= {Hz | kHz | MHz}

The :POWer:CLResponse:FREQuency:STOP command sets the frequency sweep stop value. The control loop response analysis is displayed on a log scale Bode plot, so you can select from decade values in addition to the maximum frequency of 20 MHz.

Query Syntax :POWer:CLResponse:FREQuency:STOP?

The :POWer:CLResponse:FREQuency:STOP? query returns the frequency sweep stop setting.

Return Format <value><NL>

<value> ::= {100 | 1000 | 10000 | 100000 | 1000000 | 10000000 | 20000000
}

- See Also**
- [":POWer:CLResponse"](#) on page 829
 - [":POWer:CLResponse:APPLY"](#) on page 830
 - [":POWer:CLResponse:DATA"](#) on page 831
 - [":POWer:CLResponse:FREQuency:MODE"](#) on page 836
 - [":POWer:CLResponse:FREQuency:START"](#) on page 838
 - [":POWer:CLResponse:PPDecade"](#) on page 840
 - [":POWer:CLResponse:SOURce:INPut"](#) on page 841
 - [":POWer:CLResponse:SOURce:OUTPut"](#) on page 842
 - [":POWer:CLResponse:WGEN:LOAD"](#) on page 844
 - [":POWer:CLResponse:WGEN:VOLTage"](#) on page 845
 - [":POWer:CLResponse:WGEN:VOLTage:PROFile"](#) on page 846

:POWer:CLResponse:PPDecade

N (see [page 1730](#))

Command Syntax :POWer:CLResponse:PPDecade <pts>

<pts> ::= {10 | 20 | 30 | 40 | 50 | 60 | 70 | 80 | 90 | 100}

The :POWer:CLResponse:PPDecade command selects the number of frequency test points per decade (in the log scale).

Query Syntax :POWer:CLResponse:PPDecade?

The :POWer:CLResponse:PPDecade? query returns the points per decade setting.

Return Format <pts><NL>

<pts> ::= {10 | 20 | 30 | 40 | 50 | 60 | 70 | 80 | 90 | 100}

- See Also**
- [":POWer:CLResponse"](#) on page 829
 - [":POWer:CLResponse:APPLY"](#) on page 830
 - [":POWer:CLResponse:DATA"](#) on page 831
 - [":POWer:CLResponse:FREQuency:MODE"](#) on page 836
 - [":POWer:CLResponse:FREQuency:START"](#) on page 838
 - [":POWer:CLResponse:FREQuency:STOP"](#) on page 839
 - [":POWer:CLResponse:SOURce:INPut"](#) on page 841
 - [":POWer:CLResponse:SOURce:OUTPut"](#) on page 842
 - [":POWer:CLResponse:WGEN:LOAD"](#) on page 844
 - [":POWer:CLResponse:WGEN:VOLTage"](#) on page 845
 - [":POWer:CLResponse:WGEN:VOLTage:PROFile"](#) on page 846

:POWer:CLResponse:SOURce:INPut

N (see [page 1730](#))

Command Syntax :POWer:CLResponse:SOURce:INPut <source>

<source> ::= CHANnel<n>

<n> ::= 1 to (# analog channels) in NR1 format

The :POWer:CLResponse:SOURce:INPut command selects the oscilloscope channel that is probing the power supply input.

Query Syntax :POWer:CLResponse:SOURce:INPut?

The :POWer:CLResponse:SOURce:INPut? query returns the channel selection.

Return Format <source><NL>

<source> ::= CHAN<n>

- See Also**
- [":POWer:CLResponse"](#) on page 829
 - [":POWer:CLResponse:APPLY"](#) on page 830
 - [":POWer:CLResponse:DATA"](#) on page 831
 - [":POWer:CLResponse:FREQuency:MODE"](#) on page 836
 - [":POWer:CLResponse:FREQuency:START"](#) on page 838
 - [":POWer:CLResponse:FREQuency:STOP"](#) on page 839
 - [":POWer:CLResponse:PPDecade"](#) on page 840
 - [":POWer:CLResponse:SOURce:OUTPut"](#) on page 842
 - [":POWer:CLResponse:WGEN:LOAD"](#) on page 844
 - [":POWer:CLResponse:WGEN:VOLTage"](#) on page 845
 - [":POWer:CLResponse:WGEN:VOLTage:PROFile"](#) on page 846

:POWer:CLResponse:SOURce:OUTPut

N (see [page 1730](#))

Command Syntax :POWer:CLResponse:SOURce:OUTPut <source>

<source> ::= CHANnel<n>

<n> ::= 1 to (# analog channels) in NR1 format

The :POWer:CLResponse:SOURce:OUTPut command selects the oscilloscope channel that is probing the power supply output.

Query Syntax :POWer:CLResponse:SOURce:OUTPut?

The :POWer:CLResponse:SOURce:OUTPut? query returns the channel selection.

Return Format <source><NL>

<source> ::= CHAN<n>

- See Also**
- [":POWer:CLResponse"](#) on page 829
 - [":POWer:CLResponse:APPLY"](#) on page 830
 - [":POWer:CLResponse:DATA"](#) on page 831
 - [":POWer:CLResponse:FREQuency:MODE"](#) on page 836
 - [":POWer:CLResponse:FREQuency:START"](#) on page 838
 - [":POWer:CLResponse:FREQuency:STOP"](#) on page 839
 - [":POWer:CLResponse:PPDecade"](#) on page 840
 - [":POWer:CLResponse:SOURce:INPut"](#) on page 841
 - [":POWer:CLResponse:WGEN:LOAD"](#) on page 844
 - [":POWer:CLResponse:WGEN:VOLTage"](#) on page 845
 - [":POWer:CLResponse:WGEN:VOLTage:PROFile"](#) on page 846

:POWer:CLResponse:TRACe

N (see [page 1730](#))

Command Syntax :POWer:CLResponse:TRACe <selection>

<selection> ::= {NONE | ALL | GAIN | PHASe}[, {GAIN | PHASe}]

The :POWer:CLResponse:TRACe command specifies whether to include gain, phase, both gain and phase, or neither in the control loop response analysis results.

NOTE

This command affects the oscilloscope's front panel graphical user interface (plot and table) as well as when saving analysis data.

Query Syntax :POWer:CLResponse:TRACe?

The :POWer:CLResponse:TRACe? query returns a comma-separated list of the types of data that are currently included in the control loop response analysis results, or "NONE" if neither gain nor phase data is included.

Return Format <selection_list><NL>

<selection_list> ::= {"NONE" | "GAIN" | "PHASe" | "GAIN,PHASe"}

- See Also**
- [":POWer:CLResponse:APPLy"](#) on page 830
 - [":POWer:CLResponse:DATA"](#) on page 831

:POWer:CLResponse:WGEN:LOAD

N (see [page 1730](#))

Command Syntax :POWer:CLResponse:WGEN:LOAD <impedance>

<impedance> ::= {ONEMeg | FIFTy}

The :POWer:CLResponse:WGEN:LOAD command sets the waveform generator expected output load impedance.

The output impedance of the Gen Out signal is fixed at 50 ohms. However, the output load selection lets the waveform generator display the correct amplitude and offset levels for the expected output load. If the actual load impedance is different than the selected value, the displayed amplitude and offset levels will be incorrect.

Query Syntax :POWer:CLResponse:WGEN:LOAD?

The :POWer:CLResponse:WGEN:LOAD? query returns the waveform generator expected output load impedance setting.

Return Format <impedance><NL>

<impedance> ::= {ONEM | FIFT}

- See Also**
- [":POWer:CLResponse"](#) on page 829
 - [":POWer:CLResponse:APPLY"](#) on page 830
 - [":POWer:CLResponse:DATA"](#) on page 831
 - [":POWer:CLResponse:FREQuency:MODE"](#) on page 836
 - [":POWer:CLResponse:FREQuency:START"](#) on page 838
 - [":POWer:CLResponse:FREQuency:STOP"](#) on page 839
 - [":POWer:CLResponse:PPDecade"](#) on page 840
 - [":POWer:CLResponse:SOURce:INPut"](#) on page 841
 - [":POWer:CLResponse:SOURce:OUTPut"](#) on page 842
 - [":POWer:CLResponse:WGEN:VOLTage"](#) on page 845
 - [":POWer:CLResponse:WGEN:VOLTage:PROFile"](#) on page 846

:POWer:CLResponse:WGEN:VOLTage

N (see [page 1730](#))

Command Syntax :POWer:CLResponse:WGEN:VOLTage <amplitude>[,<range>]

<amplitude> ::= amplitude in volts in NR3 format

<range> ::= {F20HZ | F100HZ | F1KHZ | F10KHZ | F100KHZ | F1MHZ
| F10MHZ | F20MHZ}

The :POWer:CLResponse:WGEN:VOLTage command sets the waveform generator output amplitude(s).

When the waveform generator amplitude profile is enabled (with the :POWer:CLResponse:WGEN:VOLTage:PROFile command), you can set an initial ramp amplitude for each frequency range.

Without the <range> parameter, this command sets the waveform generator output amplitude used when the amplitude profile is disabled.

Query Syntax :POWer:PSRR:WGEN:VOLTage? [<range>]

The :POWer:CLResponse:WGEN:VOLTage? query returns the waveform generator output amplitude setting(s).

Return Format <amplitude><NL>

<amplitude> ::= amplitude in volts in NR3 format

- See Also**
- [":POWer:CLResponse"](#) on page 829
 - [":POWer:CLResponse:APPLY"](#) on page 830
 - [":POWer:CLResponse:DATA"](#) on page 831
 - [":POWer:CLResponse:FREQuency:MODE"](#) on page 836
 - [":POWer:CLResponse:FREQuency:STARt"](#) on page 838
 - [":POWer:CLResponse:FREQuency:STOP"](#) on page 839
 - [":POWer:CLResponse:PPDecade"](#) on page 840
 - [":POWer:CLResponse:SOURce:INPut"](#) on page 841
 - [":POWer:CLResponse:SOURce:OUTPut"](#) on page 842
 - [":POWer:CLResponse:WGEN:LOAD"](#) on page 844
 - [":POWer:CLResponse:WGEN:VOLTage:PROFile"](#) on page 846

:POWer:CLResponse:WGEN:VOLTage:PROFile

N (see [page 1730](#))

Command Syntax :POWer:CLResponse:WGEN:VOLTage:PROFile {{0 | OFF} | {1 | ON}}

The :POWer:CLResponse:WGEN:VOLTage:PROFile command enables or disables the ability to set initial waveform generator ramp amplitudes for each frequency range.

With amplitude profiling, you can use lower amplitudes at frequencies where the device under test (DUT) is sensitive to distortion and use higher amplitudes where the DUT is less sensitive to distortion. Power supply feedback networks are typically most sensitive near the 0 dB cross-over frequency.

You can often observe distortions during the test. If the input test sine wave begins to look lopsided, clipped, or somewhat triangular in shape (nonsinusoidal), you are probably encountering distortion due to overdriving your DUT. Optimizing test amplitudes to achieve the best dynamic range measurements is often an iterative process of running your frequency response measurements multiple times.

Query Syntax :POWer:CLResponse:WGEN:VOLTage:PROFile?

The :POWer:CLResponse:WGEN:VOLTage:PROFile? query returns the voltage profile setting.

Return Format <setting><NL>
<setting> ::= {0 | 1}

- See Also**
- [":POWer:CLResponse"](#) on page 829
 - [":POWer:CLResponse:APPLY"](#) on page 830
 - [":POWer:CLResponse:DATA"](#) on page 831
 - [":POWer:CLResponse:FREQuency:MODE"](#) on page 836
 - [":POWer:CLResponse:FREQuency:START"](#) on page 838
 - [":POWer:CLResponse:FREQuency:STOP"](#) on page 839
 - [":POWer:CLResponse:PPDecade"](#) on page 840
 - [":POWer:CLResponse:SOURce:INPut"](#) on page 841
 - [":POWer:CLResponse:SOURce:OUTPut"](#) on page 842
 - [":POWer:CLResponse:WGEN:LOAD"](#) on page 844
 - [":POWer:CLResponse:WGEN:VOLTage"](#) on page 845

:POWer:DESKew

N (see [page 1730](#))

Command Syntax :POWer:DESKew

The :POWer:DESKew command launches the auto deskew process on the oscilloscope.

Before sending this command:

- 1 Demagnetize and zero-adjust the current probe.
Refer to the current probe's documentation for instructions on how to do this.
- 2 Make connections to the U1880A deskew fixture as described in the oscilloscope's connection dialog or in the *Power Measurement Application User's Guide*.
- 3 Make sure the voltage probe and current probe channels are specified appropriately using the :POWer:SIGNals:SOURce:VOLTage1 and :POWer:SIGNals:SOURce:CURRent1 commands.

NOTE

Use the lowest attenuation setting on the high voltage differential probes whenever possible because the voltage levels on the deskew fixture are very small. Using a higher attenuation setting may yield inaccurate skew values (and affect the measurements made) because the noise level is magnified as well.

The deskew values are saved in the oscilloscope until a factory default or secure erase is performed. The next time you run the Power Application, you can use the saved deskew values or perform the deskew again.

Generally, you need to perform the deskew again when part of the test setup changes (for example, a different probe, different oscilloscope channel, etc.) or when the ambient temperature has changed.

- See Also**
- **":POWer:SIGNals:SOURce:VOLTage<i>"** on page 910
 - **":POWer:SIGNals:SOURce:CURRent<i>"** on page 909

:POWer:EFFiciency:APPLy

N (see [page 1730](#))

Command Syntax :POWer:EFFiciency:APPLy

The :POWer:EFFiciency:APPLy command applies the efficiency power analysis. Efficiency analysis tests the overall efficiency of the power supply by measuring the output power over the input power.

NOTE

Efficiency analysis requires a 4-channel oscilloscope because input voltage, input current, output voltage, and output current are measured.

- See Also**
- [":POWer:EFFiciency:TYPE"](#) on page 849
 - [":MEASure:EFFiciency"](#) on page 766
 - [":MEASure:IPOWer"](#) on page 769
 - [":MEASure:OPOWer"](#) on page 772

:POWer:EFFiciency:TYPE

N (see [page 1730](#))

Command Syntax :POWer:EFFiciency:TYPE <type>

<type> ::= {DCDC | DCAC | ACDC | ACAC}

The :POWer:EFFiciency:TYPE command specifies the type of power that is being converted from the input to the output. This selection affects how the efficiency is measured.

Query Syntax :POWer:EFFiciency:TYPE?

The :POWer:EFFiciency:TYPE? query returns the currently specified type setting.

Return Format <type><NL>

<type> ::= {DCDC | DCAC | ACDC | ACAC}

- See Also**
- [":POWer:EFFiciency:APPLY"](#) on page 848
 - [":MEASure:EFFiciency"](#) on page 766
 - [":MEASure:IPOWer"](#) on page 769
 - [":MEASure:OPOWer"](#) on page 772

:POWer:ENABle

N (see [page 1730](#))

Command Syntax :POWer:ENABle {{0 | OFF} | {1 | ON}}

The :POWer:ENABle command enables or disables power analysis.

Query Syntax :POWer:ENABle?

The :POWer:ENABle query returns a 1 or a 0 showing whether power analysis is enabled or disabled, respectively.

Return Format {0 | 1}

See Also • [Chapter 30](#), “:MEASure Power Commands,” starting on page 757

:POWer:HARMonics:APPLy

N (see [page 1730](#))

Command Syntax

`:POWer:HARMonics:APPLy`

The `:POWer:HARMonics:APPLy` command applies the current harmonics analysis.

Switching power supplies draw a range of harmonics from the AC mains.

Standard limits are set for these harmonics because these harmonics can travel back to the supply grid and cause problems with other devices on the grid.

Use the Current Harmonics analysis to test a switching power supply's current harmonics to pre-compliance standard of IEC61000-3-2 (Class A, B, C, or D). The analysis presents up to 40 harmonics.

- See Also**
- [":POWer:HARMonics:DATA"](#) on page 852
 - [":POWer:HARMonics:DISPlay"](#) on page 853
 - [":POWer:HARMonics:FAILcount"](#) on page 854
 - [":POWer:HARMonics:LINE"](#) on page 855
 - [":POWer:HARMonics:POWerfactor"](#) on page 856
 - [":POWer:HARMonics:STANdard"](#) on page 860
 - [":POWer:HARMonics:STATus"](#) on page 861
 - [":POWer:HARMonics:RUNCount"](#) on page 859
 - [":POWer:HARMonics:THD"](#) on page 862

:POWer:HARMonics:DATA

N (see [page 1730](#))

Query Syntax :POWer:HARMonics:DATA?

The :POWer:HARMonics:DATA query returns the power harmonics results table data.

Return Format <binary_block> ::= comma-separated data with newlines at the end of each row

- See Also**
- [":POWer:HARMonics:APPLy"](#) on page 851
 - [":POWer:HARMonics:DISPlay"](#) on page 853
 - [":POWer:HARMonics:FAILcount"](#) on page 854
 - [":POWer:HARMonics:LINE"](#) on page 855
 - [":POWer:HARMonics:POWerfactor"](#) on page 856
 - [":POWer:HARMonics:RUNCount"](#) on page 859
 - [":POWer:HARMonics:STANdard"](#) on page 860
 - [":POWer:HARMonics:STATus"](#) on page 861
 - [":POWer:HARMonics:THD"](#) on page 862

:POWer:HARMonics:DISPlay

N (see [page 1730](#))

Command Syntax :POWer:HARMonics:DISPlay <display>

<display> ::= {TABLe | BAR | OFF}

The :POWer:HARMonics:DISPlay command specifies how to display the current harmonics analysis results:

- TABLE
- BAR – Bar chart.
- OFF – Harmonics measurement results are not displayed.

Query Syntax :POWer:HARMonics:DISPlay?

The :POWer:HARMonics:DISPlay query returns the display setting.

Return Format <display><NL>

<display> ::= {TABL | BAR | OFF}

- See Also**
- [":POWer:HARMonics:APPLy"](#) on page 851
 - [":POWer:HARMonics:DATA"](#) on page 852
 - [":POWer:HARMonics:FAILcount"](#) on page 854
 - [":POWer:HARMonics:LINE"](#) on page 855
 - [":POWer:HARMonics:POWerfactor"](#) on page 856
 - [":POWer:HARMonics:RUNCount"](#) on page 859
 - [":POWer:HARMonics:STANdard"](#) on page 860
 - [":POWer:HARMonics:STATus"](#) on page 861
 - [":POWer:HARMonics:THD"](#) on page 862

:POWer:HARMonics:FAILcount

N (see [page 1730](#))

Query Syntax :POWer:HARMonics:FAILcount?

Returns the current harmonics analysis' fail count. Non Spec values (that is, harmonics values not specified by the selected standard) are not counted.

Return Format <count><NL>

<count> ::= integer in NR1 format

- See Also**
- [":POWer:HARMonics:RUNCount"](#) on page 859
 - [":POWer:HARMonics:APPLy"](#) on page 851
 - [":POWer:HARMonics:DATA"](#) on page 852
 - [":POWer:HARMonics:DISPlay"](#) on page 853
 - [":POWer:HARMonics:LINE"](#) on page 855
 - [":POWer:HARMonics:POWerfactor"](#) on page 856
 - [":POWer:HARMonics:STANdard"](#) on page 860
 - [":POWer:HARMonics:STATus"](#) on page 861
 - [":POWer:HARMonics:THD"](#) on page 862

:POWer:HARMonics:LINE

N (see [page 1730](#))

Command Syntax :POWer:HARMonics:LINE <frequency>

<frequency> ::= {F50 | F60 | F400 | AUTO}

The :POWer:HARMonics:LINE command specifies the line frequency setting for the current harmonics analysis:

- F50 – 50 Hz.
- F60 – 60 Hz.
- F400 – 400 Hz.
- AUTO – Automatically determines the frequency of the Current waveform.

Query Syntax :POWer:HARMonics:LINE?

The :POWer:HARMonics:LINE query returns the line frequency setting.

Return Format <frequency><NL>

<frequency> ::= {F50 | F60 | F400 | AUTO}

- See Also**
- [":POWer:HARMonics:APPLy"](#) on page 851
 - [":POWer:HARMonics:DATA"](#) on page 852
 - [":POWer:HARMonics:DISPlay"](#) on page 853
 - [":POWer:HARMonics:FAILcount"](#) on page 854
 - [":POWer:HARMonics:POWerfactor"](#) on page 856
 - [":POWer:HARMonics:RUNCount"](#) on page 859
 - [":POWer:HARMonics:STANdard"](#) on page 860
 - [":POWer:HARMonics:STATus"](#) on page 861
 - [":POWer:HARMonics:THD"](#) on page 862

:POWer:HARMonics:POWerfactor

N (see [page 1730](#))

Query Syntax :POWer:HARMonics:POWerfactor?

The :POWer:HARMonics:POWerfactor query returns the power factor for IEC 61000-3-2 Standard Class C power factor value.

Return Format <value> ::= Class C power factor in NR3 format

- See Also**
- [":POWer:HARMonics:APPLy"](#) on page 851
 - [":POWer:HARMonics:DATA"](#) on page 852
 - [":POWer:HARMonics:DISPlay"](#) on page 853
 - [":POWer:HARMonics:FAILcount"](#) on page 854
 - [":POWer:HARMonics:LINE"](#) on page 855
 - [":POWer:HARMonics:RUNCount"](#) on page 859
 - [":POWer:HARMonics:STANdard"](#) on page 860
 - [":POWer:HARMonics:STATus"](#) on page 861
 - [":POWer:HARMonics:THD"](#) on page 862

:POWer:HARMonics:RPOWer

N (see [page 1730](#))

Command Syntax :POWer:HARMonics:RPOWer <source>

<source> ::= {MEASured | USER}

When Class D is selected as the current harmonics analysis standard, the :POWer:HARMonics:RPOWer command specifies whether the Real Power value used for the current-per-watt measurement is measured by the oscilloscope or is defined by the user.

When USER is selected, use the :POWer:HARMonics:RPOWer:USER command to enter the user-defined value.

Query Syntax :POWer:HARMonics:RPOWer?

The :POWer:HARMonics:RPOWer? query returns the Real Power source setting.

Return Format <source><NL>

<source> ::= {MEAS | USER}

- See Also**
- [":POWer:HARMonics:STANdard"](#) on page 860
 - [":POWer:HARMonics:RPOWer:USER"](#) on page 858

:POWer:HARMonics:RPOWer:USER

N (see [page 1730](#))

Command Syntax :POWer:HARMonics:RPOWer:USER <value>

<value> ::= Watts from 1.0 to 600.0 in NR3 format

When Class D is selected as the current harmonics analysis standard and you have chosen to use a user-defined Real Power value (see :POWer:HARMonics:RPOWer), the :POWer:HARMonics:RPOWer:USER command specifies the Real Power value used in the current-per-watt measurement.

Query Syntax :POWer:HARMonics:RPOWer:USER?

The :POWer:HARMonics:RPOWer:USER? query returns the user-defined Real Power value.

Return Format <value><NL>

<value> ::= Watts from 1.0 to 600.0 in NR3 format

- See Also**
- [":POWer:HARMonics:STANdard"](#) on page 860
 - [":POWer:HARMonics:RPOWer"](#) on page 857

:POWer:HARMonics:RUNCount

N (see [page 1730](#))

Query Syntax :POWer:HARMonics:RUNCount?

Returns the current harmonics analysis' run iteration count. Non Spec values (that is, harmonics values not specified by the selected standard) are not counted.

Return Format <count><NL>

<count> ::= integer in NR1 format

- See Also**
- [":POWer:HARMonics:FAILcount"](#) on page 854
 - [":POWer:HARMonics:APPLy"](#) on page 851
 - [":POWer:HARMonics:DATA"](#) on page 852
 - [":POWer:HARMonics:DISPlay"](#) on page 853
 - [":POWer:HARMonics:LINE"](#) on page 855
 - [":POWer:HARMonics:POWerfactor"](#) on page 856
 - [":POWer:HARMonics:STANdard"](#) on page 860
 - [":POWer:HARMonics:STATus"](#) on page 861
 - [":POWer:HARMonics:THD"](#) on page 862

:POWer:HARMonics:STANdard

N (see [page 1730](#))

Command Syntax :POWer:HARMonics:STANdard <class>

<class> ::= {A | B | C | D}

The :POWer:HARMonics:STANdard command selects the standard to perform current harmonics compliance testing on.

- A – IEC 61000-3-2 Class A – for balanced three-phase equipment, household appliances (except equipment identified as Class D), tools excluding portable tools, dimmers for incandescent lamps, and audio equipment.
- B – IEC 61000-3-2 Class B – for portable tools.
- C – IEC 61000-3-2 Class C – for lighting equipment.
- D – IEC 61000-3-2 Class D – for equipment having a specified power according less than or equal to 600 W, of the following types: personal computers and personal computer monitors, television receivers.

Query Syntax :POWer:HARMonics:STANdard?

The :POWer:HARMonics:STANdard query returns the currently set IEC 61000-3-2 standard.

Return Format <class><NL>

<class> ::= {A | B | C | D}

- See Also**
- [":POWer:HARMonics:APPLy"](#) on page 851
 - [":POWer:HARMonics:DATA"](#) on page 852
 - [":POWer:HARMonics:DISPlay"](#) on page 853
 - [":POWer:HARMonics:FAILcount"](#) on page 854
 - [":POWer:HARMonics:LINE"](#) on page 855
 - [":POWer:HARMonics:POWerfactor"](#) on page 856
 - [":POWer:HARMonics:RUNCount"](#) on page 859
 - [":POWer:HARMonics:STATus"](#) on page 861
 - [":POWer:HARMonics:THD"](#) on page 862

:POWer:HARMonics:STATus

N (see [page 1730](#))

Query Syntax :POWer:HARMonics:STATus?

The :POWer:HARMonics:STATus query returns the overall pass/fail status of the current harmonics analysis.

Return Format <status> ::= {PASS | FAIL | UNTested}

- See Also**
- [":POWer:HARMonics:RUNCount"](#) on page 859
 - [":POWer:HARMonics:FAILcount"](#) on page 854
 - [":POWer:HARMonics:APPLY"](#) on page 851
 - [":POWer:HARMonics:DATA"](#) on page 852
 - [":POWer:HARMonics:DISPlay"](#) on page 853
 - [":POWer:HARMonics:LINE"](#) on page 855
 - [":POWer:HARMonics:POWerfactor"](#) on page 856
 - [":POWer:HARMonics:STANdard"](#) on page 860
 - [":POWer:HARMonics:THD"](#) on page 862

:POWer:HARMonics:THD

N (see [page 1730](#))

Query Syntax :POWer:HARMonics:THD?

The :POWer:HARMonics:THD query returns the Total Harmonics Distortion (THD) results of the current harmonics analysis.

Return Format <value> ::= Total Harmonics Distortion in NR3 format

- See Also**
- [":POWer:HARMonics:APPLy"](#) on page 851
 - [":POWer:HARMonics:DATA"](#) on page 852
 - [":POWer:HARMonics:DISPlay"](#) on page 853
 - [":POWer:HARMonics:FAILcount"](#) on page 854
 - [":POWer:HARMonics:LINE"](#) on page 855
 - [":POWer:HARMonics:POWerfactor"](#) on page 856
 - [":POWer:HARMonics:RUNCount"](#) on page 859
 - [":POWer:HARMonics:STANdard"](#) on page 860
 - [":POWer:HARMonics:STATus"](#) on page 861

:POWer:INRush:APPLy

N (see [page 1730](#))

Command Syntax :POWer:INRush:APPLy

The :POWer:INRush:APPLy command applies the inrush current analysis.

The Inrush current analysis measures the peak inrush current of the power supply when the power supply is first turned on.

- See Also**
- [":POWer:ITYPE"](#) on page 866
 - [":POWer:INRush:EXIT"](#) on page 864
 - [":POWer:INRush:NEXT"](#) on page 865
 - [":MEASure:PCURrent"](#) on page 773

:POWer:INRush:EXIT

N (see [page 1730](#))

Command Syntax :POWer:INRush:EXIT

The :POWer:INRush:EXIT command exits (stops) the inrush current power analysis.

This command is equivalent to pressing the **Exit** softkey on the oscilloscope front panel during the analysis.

- See Also**
- [":POWer:INRush:APPLY"](#) on page 863
 - [":POWer:INRush:NEXT"](#) on page 865
 - [":POWer:ITYPE"](#) on page 866

:POWer:INRush:NEXT

N (see [page 1730](#))

Command Syntax :POWer:INRush:NEXT

The :POWer:INRush:NEXT command goes to the next step of the inrush current analysis.

This command is equivalent to pressing the **Next** softkey on the oscilloscope front panel when prompted during the analysis.

- See Also**
- [":POWer:INRush:APPLY"](#) on page 863
 - [":POWer:INRush:EXIT"](#) on page 864
 - [":POWer:ITYPE"](#) on page 866

:POWer:ITYPE

N (see [page 1730](#))

Command Syntax :POWer:ITYPE <type>

<type> ::= {DC | AC}

The :POWer:ITYPE command specifies the type of power that is being converted from the input (DC or AC). Your selection affects how the measurements are made.

This setting is used in the Inrush Current and Turn On/Turn Off tests.

Query Syntax :POWer:ITYPE?

The :POWer:ITYPE? query returns the input power type setting.

Return Format <type><NL>

<type> ::= {DC | AC}

- See Also**
- [":POWer:INRush:APPLY"](#) on page 863
 - [":POWer:ONOFF:APPLY"](#) on page 870

:POWer:MODulation:APPLY

N (see [page 1730](#))

Command Syntax :POWer:MODulation:APPLY

The :POWer:MODulation:APPLY command applies the selected modulation analysis type (:POWer:MODulation:TYPE).

The Modulation analysis measures the control pulse signal to a switching device (MOSFET) and observes the trending of the pulse width, duty cycle, period, frequency, etc. of the control pulse signal.

- See Also**
- [":POWer:MODulation:SOURce"](#) on page 868
 - [":POWer:MODulation:TYPE"](#) on page 869
 - [":MEASure:VAverage"](#) on page 745
 - [":MEASure:VRMS"](#) on page 751
 - [":MEASure:VRATio"](#) on page 750
 - [":MEASure:PERiod"](#) on page 713
 - [":MEASure:FREQuency"](#) on page 689
 - [":MEASure:PWIDth"](#) on page 717
 - [":MEASure:NWIDth"](#) on page 709
 - [":MEASure:DUTYcycle"](#) on page 683
 - [":MEASure:RISetime"](#) on page 721
 - [":MEASure:FALLtime"](#) on page 684

:POWer:MODulation:SOURce

N (see [page 1730](#))

Command Syntax :POWer:MODulation:SOURce <source>

<source> ::= {V | I}

The :POWer:MODulation:SOURce command selects either the voltage source or the current source as the source for the modulation analysis.

Query Syntax :POWer:MODulation:SOURce?

The :POWer:MODulation:SOURce query returns the selected source for the modulation analysis.

Return Format <source><NL>

<source> ::= {V | I}

- See Also**
- [":POWer:MODulation:APPLY"](#) on page 867
 - [":POWer:MODulation:TYPE"](#) on page 869

:POWer:MODulation:TYPE

N (see [page 1730](#))

Command Syntax :POWer:MODulation:TYPE <modulation>

```
<modulation> ::= {VAVerage | ACRMs | VRATio | PERiod | FREQuency
                  | PWIDith | NWIDth | DUTYcycle | RISetime | FALLtime}
```

The :POWer:MODulation:TYPE command selects the type of measurement to make in the modulation analysis:

- VAVerage
- ACRMs
- VRATio
- PERiod
- FREQuency
- PWIDth (positive pulse width)
- NWIDth (negative pulse width)
- DUTYcycle
- RISetime
- FALLtime

Query Syntax :POWer:MODulation:TYPE?

The :POWer:MODulation:TYPE query returns the modulation type setting.

Return Format <modulation><NL>

```
<modulation> ::= {VAV | ACRM | VRAT | PER | FREQ | PWID | NWID | DUTY
                  | RIS | FALL}
```

- See Also**
- [":POWer:MODulation:SOURce"](#) on page 868
 - [":POWer:MODulation:APPLY"](#) on page 867
 - [":MEASure:VAVerage"](#) on page 745
 - [":MEASure:VRMS"](#) on page 751
 - [":MEASure:VRATio"](#) on page 750
 - [":MEASure:PERiod"](#) on page 713
 - [":MEASure:FREQuency"](#) on page 689
 - [":MEASure:PWIDth"](#) on page 717
 - [":MEASure:NWIDth"](#) on page 709
 - [":MEASure:DUTYcycle"](#) on page 683
 - [":MEASure:RISetime"](#) on page 721
 - [":MEASure:FALLtime"](#) on page 684

:POWer:ONOFF:APPLy

N (see [page 1730](#))

Command Syntax :POWer:ONOFF:APPLy

The :POWer:ONOFF:APPLy command applies the selected turn on/off analysis test (:POWer:ONOFF:TEST).

- See Also**
- [":POWer:SIGNals:VSTeady:ONOFF:OFF"](#) on page 906
 - [":POWer:SIGNals:VSTeady:ONOFF:ON"](#) on page 907
 - [":POWer:ITYPE"](#) on page 866
 - [":POWer:ONOFF:THResholds"](#) on page 874
 - [":POWer:ONOFF:TEST"](#) on page 873
 - [":POWer:ONOFF:EXIT"](#) on page 871
 - [":POWer:ONOFF:NEXT"](#) on page 872
 - [":MEASure:ONTime"](#) on page 771
 - [":MEASure:OFFTime"](#) on page 770

:POWer:ONOFF:EXIT

N (see [page 1730](#))

Command Syntax :POWer:ONOFF:EXIT

The :POWer:ONOFF:EXIT command exits (stops) the turn on time/turn off time analysis.

This command is equivalent to pressing the **Exit** softkey on the oscilloscope front panel during the analysis.

- See Also**
- [":POWer:ONOFF:THResholds"](#) on page 874
 - [":POWer:ITYPE"](#) on page 866
 - [":POWer:ONOFF:APPLY"](#) on page 870
 - [":POWer:ONOFF:NEXT"](#) on page 872
 - [":POWer:ONOFF:TEST"](#) on page 873

:POWer:ONOFF:NEXT

N (see [page 1730](#))

Command Syntax :POWer:ONOFF:NEXT

The :POWer:ONOFF:NEXT command goes to the next step of the turn on/turn off analysis.

This command is equivalent to pressing the **Next** softkey on the oscilloscope front panel when prompted during the analysis.

- See Also**
- [":POWer:ONOFF:THResholds"](#) on page 874
 - [":POWer:ITYPE"](#) on page 866
 - [":POWer:ONOFF:APPLY"](#) on page 870
 - [":POWer:ONOFF:EXIT"](#) on page 871
 - [":POWer:ONOFF:TEST"](#) on page 873

:POWer:ONOFF:TEST

N (see [page 1730](#))

Command Syntax :POWer:ONOFF:TEST {{0 | OFF} | {1 | ON}}

The :POWer:ONOFF:TEST command selects whether turn on or turn off analysis is performed:

- ON – Turn On – measures the time taken to get the output voltage of the power supply after the input voltage is applied.
- OFF – Turn Off – measures the time taken for the output voltage of the power supply to turn off after the input voltage is removed.

Query Syntax :POWer:ONOFF:TEST?

The :POWer:ONOFF:TEST query returns the selected test type.

Return Format {0 | 1}

- See Also**
- [":POWer:ONOFF:THResholds"](#) on page 874
 - [":POWer:ITYPE"](#) on page 866
 - [":POWer:ONOFF:APPLY"](#) on page 870
 - [":POWer:ONOFF:EXIT"](#) on page 871
 - [":POWer:ONOFF:NEXT"](#) on page 872

:POWer:ONOFF:THResholds

N (see [page 1730](#))

Command Syntax :POWer:ONOFF:THResholds <type>,<input_thr>,<output_thr>

<type> ::= {ON | OFF}

<input_thr> ::= percent from 0-100 in NR1 format

<output_thr> ::= percent from 0-100 in NR1 format

The :POWer:ONOFF:THResholds command specifies the input and output thresholds used in the Turn On/Turn Off analysis.

Turn On analysis determines how fast a turned on power supply takes to reach some percent of its steady state output. Turn on time is the time between T2 and T1 where:

- T1 = when the input voltage first rises to some percent (typically the 10% threshold) of its maximum amplitude.
- T2 = when the output DC voltage rises to some percent (typically the 90% threshold) of its maximum amplitude.

Turn Off analysis determines how fast a turned off power supply takes to reduce its output voltage to some percent of maximum. Turn off time is the time between T2 and T1 where:

- T1 = when the input voltage last falls to some percent (typically the 10% threshold) of its maximum amplitude.
- T2 = when the output DC voltage last falls to some percent (typically the 10% threshold) of its maximum amplitude.

Query Syntax :POWer:ONOFF:THResholds? <type>

The :POWer:ONOFF:THResholds? query returns the input and output threshold settings for the turn on/turn off analysis type.

Return Format <input_thr>,<output_thr><NL>

<input_thr> ::= percent from 0-100 in NR1 format

<output_thr> ::= percent from 0-100 in NR1 format

- See Also**
- [":POWer:SIGNals:VSTeady:ONOFF:OFF"](#) on page 906
 - [":POWer:SIGNals:VSTeady:ONOFF:ON"](#) on page 907
 - [":POWer:ITYPE"](#) on page 866
 - [":POWer:ONOFF:APPLY"](#) on page 870
 - [":POWer:ONOFF:TEST"](#) on page 873
 - [":POWer:ONOFF:EXIT"](#) on page 871
 - [":POWer:ONOFF:NEXT"](#) on page 872

- **":MEASure:ONTime"** on page 771
- **":MEASure:OFFTime"** on page 770

:POWer:PSRR

N (see [page 1730](#))

Query Syntax :POWer:PSRR?

The :POWer:PSRR? query returns the Power Supply Rejection Ratio (PSRR) power analysis settings.

Return Format <settings_string><NL>

For example, the query returns the following string when issued after the *RST command.

```
:POW:PSRR:SOUR:INP CHAN1;OUTP CHAN2;:POW:PSRR:FREQ:STAR +100E+00;
STOP +20.000000E+06;:POW:PSRR:WGEN:VOLT +200.0E-03;LOAD FIFT
```

- See Also**
- [":POWer:PSRR:APPLY"](#) on page 877
 - [":POWer:PSRR:DATA"](#) on page 878
 - [":POWer:PSRR:FREQuency:MAXimum"](#) on page 879
 - [":POWer:PSRR:FREQuency:MINimum"](#) on page 880
 - [":POWer:PSRR:FREQuency:MODE"](#) on page 881
 - [":POWer:PSRR:PPDecade"](#) on page 883
 - [":POWer:PSRR:SOURce:INPut"](#) on page 884
 - [":POWer:PSRR:SOURce:OUTPut"](#) on page 885
 - [":POWer:PSRR:WGEN:LOAD"](#) on page 887
 - [":POWer:PSRR:WGEN:VOLTage"](#) on page 888
 - [":POWer:PSRR:WGEN:VOLTage:PROFile"](#) on page 889

:POWer:PSRR:APPLy

N (see [page 1730](#))

Command Syntax :POWer:PSRR:APPLy

The :POWer:PSRR:APPLy command applies the power supply rejection ratio (PSRR) analysis.

The Power Supply Rejection Ratio (PSRR) test is used to determine how well a voltage regulator rejects ripple noise over different frequency range.

This analysis provides a signal from the oscilloscope's waveform generator that sweeps its frequency. This signal is used to inject ripple to the DC voltage that feeds the voltage regulator.

The AC RMS ratio of the input over the output is measured and is plotted over the range of frequencies.

It takes some time for the frequency sweep analysis to complete. You can query bit 0 of the Standard Event Status Register (*ESR?) to find out when the analysis is complete.

You can use the :POWer:PSRR:TRACe command to specify whether to include gain data in the PSRR analysis results.

- See Also**
- ["*ESR \(Standard Event Status Register\)"](#) on page 238
 - [":POWer:PSRR"](#) on page 876
 - [":POWer:PSRR:DATA"](#) on page 878
 - [":POWer:PSRR:FREQuency:MAXimum"](#) on page 879
 - [":POWer:PSRR:FREQuency:MINimum"](#) on page 880
 - [":POWer:PSRR:FREQuency:MODE"](#) on page 881
 - [":POWer:PSRR:FREQuency:SINGLE"](#) on page 882
 - [":POWer:PSRR:PPDecade"](#) on page 883
 - [":POWer:PSRR:SOURce:INPut"](#) on page 884
 - [":POWer:PSRR:SOURce:OUTPut"](#) on page 885
 - [":POWer:PSRR:TRACe"](#) on page 886
 - [":POWer:PSRR:WGEN:LOAD"](#) on page 887
 - [":POWer:PSRR:WGEN:VOLTage"](#) on page 888
 - [":POWer:PSRR:WGEN:VOLTage:PROFile"](#) on page 889

:POWer:PSRR:DATA

N (see [page 1730](#))

Query Syntax :POWer:PSRR:DATA? [SWEep | SINGle]

The :POWer:PSRR:DATA? query returns data from the Power Supply Rejection Ratio (PSRR) power analysis.

The comma-separated value format is suitable for spreadsheet analysis.

You can use the :POWer:PSRR:TRACe command to specify whether to include gain data in the PSRR analysis results.

The SWEep or SINGle option specifies whether to get the data from a sweep or single-frequency analysis (see :POWer:PSRR:FREQuency:MODE). If this option is not specified, the data from the sweep analysis is returned by default.

Return Format <binary_block><NL>

<binary_block> ::= comma-separated data with newlines at the end of each row

- See Also**
- [":POWer:PSRR"](#) on page 876
 - [":POWer:PSRR:APPLy"](#) on page 877
 - [":POWer:PSRR:FREQuency:MAXimum"](#) on page 879
 - [":POWer:PSRR:FREQuency:MINimum"](#) on page 880
 - [":POWer:PSRR:FREQuency:MODE"](#) on page 881
 - [":POWer:PSRR:FREQuency:SINGle"](#) on page 882
 - [":POWer:PSRR:PPDecade"](#) on page 883
 - [":POWer:PSRR:SOURce:INPut"](#) on page 884
 - [":POWer:PSRR:SOURce:OUTPut"](#) on page 885
 - [":POWer:PSRR:TRACe"](#) on page 886
 - [":POWer:PSRR:WGEN:LOAD"](#) on page 887
 - [":POWer:PSRR:WGEN:VOLTage"](#) on page 888
 - [":POWer:PSRR:WGEN:VOLTage:PROFile"](#) on page 889

:POWer:PSRR:FREQuency:MAXimum

N (see [page 1730](#))

Command Syntax :POWer:PSRR:FREQuency:MAXimum <value>[suffix]

<value> ::= {10 | 100 | 1000 | 10000 | 100000 | 1000000 | 10000000
| 20000000}

[suffix] ::= {Hz | kHz | MHz}

The :POWer:PSRR:FREQuency:MAXimum command sets the end sweep frequency value. The PSRR measurement is displayed on a log scale, so you can select from decade values in addition to the maximum frequency of 20 MHz.

Query Syntax :POWer:PSRR:FREQuency:MAXimum?

The :POWer:PSRR:FREQuency:MAXimum query returns the maximum sweep frequency setting.

Return Format <value><NL>

<value> ::= {10 | 100 | 1000 | 10000 | 100000 | 1000000 | 10000000
| 20000000}

- See Also**
- [":POWer:PSRR"](#) on page 876
 - [":POWer:PSRR:APPLy"](#) on page 877
 - [":POWer:PSRR:DATA"](#) on page 878
 - [":POWer:PSRR:FREQuency:MINimum"](#) on page 880
 - [":POWer:PSRR:FREQuency:MODE"](#) on page 881
 - [":POWer:PSRR:PPDecade"](#) on page 883
 - [":POWer:PSRR:SOURce:INPut"](#) on page 884
 - [":POWer:PSRR:SOURce:OUTPut"](#) on page 885
 - [":POWer:PSRR:WGEN:LOAD"](#) on page 887
 - [":POWer:PSRR:WGEN:VOLTage"](#) on page 888
 - [":POWer:PSRR:WGEN:VOLTage:PROFile"](#) on page 889

:POWer:PSRR:FREQuency:MINimum

N (see [page 1730](#))

Command Syntax :POWer:PSRR:FREQuency:MINimum <value>[suffix]
 <value> ::= {1 | 10 | 100 | 1000 | 10000 | 100000 | 1000000 | 10000000}
 [suffix] ::= {Hz | kHz | MHz}

The :POWer:PSRR:FREQuency:MINimum command sets the start sweep frequency value. The measurement is displayed on a log scale, so you can select from decade values.

Query Syntax :POWer:PSRR:FREQuency:MINimum?

The :POWer:PSRR:FREQuency:MINimum query returns the minimum sweep frequency setting.

Return Format <value><NL>
 <value> ::= {1 | 10 | 100 | 1000 | 10000 | 100000 | 1000000 | 10000000}

- See Also**
- [":POWer:PSRR"](#) on page 876
 - [":POWer:PSRR:APPLy"](#) on page 877
 - [":POWer:PSRR:DATA"](#) on page 878
 - [":POWer:PSRR:FREQuency:MAXimum"](#) on page 879
 - [":POWer:PSRR:FREQuency:MODE"](#) on page 881
 - [":POWer:PSRR:PPDecade"](#) on page 883
 - [":POWer:PSRR:SOURce:INPut"](#) on page 884
 - [":POWer:PSRR:SOURce:OUTPut"](#) on page 885
 - [":POWer:PSRR:WGEN:LOAD"](#) on page 887
 - [":POWer:PSRR:WGEN:VOLTage"](#) on page 888
 - [":POWer:PSRR:WGEN:VOLTage:PROFile"](#) on page 889

:POWer:PSRR:FREQuency:MODE

N (see [page 1730](#))

Command Syntax :POWer:PSRR:FREQuency:MODE <mode>

<mode> ::= {SWEep | SINGle}

The :POWer:PSRR:FREQuency:MODE command specifies whether the analysis should be performed by sweeping through a range of frequencies (SWEep) or at a single frequency (SINGle).

The SINGle mode is useful for evaluating amplitudes at a single frequency. After running the test at a single frequency, you can manually adjust (increase) the waveform generator's amplitude until you begin to observe distortion in the waveforms on the oscilloscope's display. You can then use that amplitude at all frequencies in SWEep mode, or you can evaluate amplitudes at other frequencies in order to determine an optimized amplitude profile (see :POWer:PSRR:WGEN:VOLTage:PROFile).

Query Syntax :POWer:CLResponse:FREQuency:MODE?

The :POWer:PSRR:FREQuency:MODE? query returns the frequency mode setting.

Return Format <mode><NL>

<mode> ::= {SWE | SING}

- See Also**
- [":POWer:PSRR"](#) on page 876
 - [":POWer:PSRR:APPLy"](#) on page 877
 - [":POWer:PSRR:DATA"](#) on page 878
 - [":POWer:PSRR:FREQuency:MAXimum"](#) on page 879
 - [":POWer:PSRR:FREQuency:MINimum"](#) on page 880
 - [":POWer:PSRR:FREQuency:SINGle"](#) on page 882
 - [":POWer:PSRR:PPDecade"](#) on page 883
 - [":POWer:PSRR:SOURce:INPut"](#) on page 884
 - [":POWer:PSRR:SOURce:OUTPut"](#) on page 885
 - [":POWer:PSRR:WGEN:LOAD"](#) on page 887
 - [":POWer:PSRR:WGEN:VOLTage"](#) on page 888
 - [":POWer:PSRR:WGEN:VOLTage:PROFile"](#) on page 889

:POWer:PSRR:FREQuency:SINgLe

N (see [page 1730](#))

Command Syntax :POWer:PSRR:FREQuency:SINgLe <value>[suffix]

<value> ::= {1 | 10 | 100 | 1000 | 10000 | 100000 | 1000000 | 10000000
| 2000000}

[suffix] ::= {Hz | kHz | MHz}

The :POWer:PSRR:FREQuency:SINgLe command sets the single frequency value. The measurement is displayed on a log scale, so you can select from decade values.

Query Syntax :POWer:PSRR:FREQuency:SINgLe?

The :POWer:PSRR:FREQuency:SINgLe query returns the single frequency setting.

Return Format <value><NL>

<value> ::= {1 | 10 | 100 | 1000 | 10000 | 100000 | 1000000 | 10000000
| 2000000}

- See Also**
- [":POWer:PSRR"](#) on page 876
 - [":POWer:PSRR:APPLy"](#) on page 877
 - [":POWer:PSRR:DATA"](#) on page 878
 - [":POWer:PSRR:FREQuency:MODE"](#) on page 881
 - [":POWer:PSRR:PPDecade"](#) on page 883
 - [":POWer:PSRR:SOURce:INPut"](#) on page 884
 - [":POWer:PSRR:SOURce:OUTPut"](#) on page 885
 - [":POWer:PSRR:WGEN:LOAD"](#) on page 887
 - [":POWer:PSRR:WGEN:VOLTage"](#) on page 888
 - [":POWer:PSRR:WGEN:VOLTage:PROFile"](#) on page 889

:POWer:PSRR:PPDecade

N (see [page 1730](#))

Command Syntax :POWer:PSRR:PPDecade <pts>

<pts> ::= {10 | 20 | 30 | 40 | 50 | 60 | 70 | 80 | 90 | 100}

The :POWer:PSRR:PPDecade command selects the number of frequency test points per decade (in the log scale).

Query Syntax :POWer:CLResponse:PPDecade?

The :POWer:PSRR:PPDecade? query returns the points per decade setting.

Return Format <pts><NL>

<pts> ::= {10 | 20 | 30 | 40 | 50 | 60 | 70 | 80 | 90 | 100}

- See Also**
- [":POWer:PSRR"](#) on page 876
 - [":POWer:PSRR:APPLY"](#) on page 877
 - [":POWer:PSRR:DATA"](#) on page 878
 - [":POWer:PSRR:FREQuency:MAXimum"](#) on page 879
 - [":POWer:PSRR:FREQuency:MINimum"](#) on page 880
 - [":POWer:PSRR:FREQuency:MODE"](#) on page 881
 - [":POWer:PSRR:SOURce:INPut"](#) on page 884
 - [":POWer:PSRR:SOURce:OUTPut"](#) on page 885
 - [":POWer:PSRR:WGEN:LOAD"](#) on page 887
 - [":POWer:PSRR:WGEN:VOLTage"](#) on page 888
 - [":POWer:PSRR:WGEN:VOLTage:PROFile"](#) on page 889

:POWer:PSRR:SOURce:INPut

N (see [page 1730](#))

Command Syntax :POWer:PSRR:SOURce:INPut <source>

<source> ::= CHANnel<n>

<n> ::= 1 to (# analog channels) in NR1 format

The :POWer:PSRR:SOURce:INPut command selects the oscilloscope channel that is probing the power supply input.

Query Syntax :POWer:PSRR:SOURce:INPut?

The :POWer:PSRR:SOURce:INPut? query returns the channel selection.

Return Format <source><NL>

<source> ::= CHAN<n>

- See Also**
- [":POWer:PSRR"](#) on page 876
 - [":POWer:PSRR:APPLY"](#) on page 877
 - [":POWer:PSRR:DATA"](#) on page 878
 - [":POWer:PSRR:FREQuency:MAXimum"](#) on page 879
 - [":POWer:PSRR:FREQuency:MINimum"](#) on page 880
 - [":POWer:PSRR:FREQuency:MODE"](#) on page 881
 - [":POWer:PSRR:PPDecade"](#) on page 883
 - [":POWer:PSRR:SOURce:OUTPut"](#) on page 885
 - [":POWer:PSRR:WGEN:LOAD"](#) on page 887
 - [":POWer:PSRR:WGEN:VOLTage"](#) on page 888
 - [":POWer:PSRR:WGEN:VOLTage:PROFile"](#) on page 889

:POWer:PSRR:SOURce:OUTPut

N (see [page 1730](#))

Command Syntax :POWer:PSRR:SOURce:OUTPut <source>

<source> ::= CHANnel<n>

<n> ::= 1 to (# analog channels) in NR1 format

The :POWer:PSRR:SOURce:OUTPut command selects the oscilloscope channel that is probing the power supply output.

Query Syntax :POWer:PSRR:SOURce:OUTPut?

The :POWer:PSRR:SOURce:OUTPut? query returns the channel selection.

Return Format <source><NL>

<source> ::= CHAN<n>

- See Also**
- [":POWer:PSRR"](#) on page 876
 - [":POWer:PSRR:APPLY"](#) on page 877
 - [":POWer:PSRR:DATA"](#) on page 878
 - [":POWer:PSRR:FREQuency:MAXimum"](#) on page 879
 - [":POWer:PSRR:FREQuency:MINimum"](#) on page 880
 - [":POWer:PSRR:FREQuency:MODE"](#) on page 881
 - [":POWer:PSRR:PPDecade"](#) on page 883
 - [":POWer:PSRR:SOURce:INPut"](#) on page 884
 - [":POWer:PSRR:WGEN:LOAD"](#) on page 887
 - [":POWer:PSRR:WGEN:VOLTage"](#) on page 888
 - [":POWer:PSRR:WGEN:VOLTage:PROFile"](#) on page 889

:POWer:PSRR:TRACe

N (see [page 1730](#))

Command Syntax :POWer:PSRR:TRACe <selection>

<selection> ::= {NONE | GAIN}

The :POWer:PSRR:TRACe command specifies whether to include gain (PSRR) data in the power supply rejection ratio analysis results.

NOTE

This command affects the oscilloscope's front panel graphical user interface (plot and table) as well as when saving analysis data.

Query Syntax :POWer:PSRR:TRACe?

The :POWer:PSRR:TRACe? query returns the type of data that is currently included in the PSRR analysis results, or "NONE" if the gain data is not included.

Return Format <selection_list><NL>

<selection_list> ::= {"NONE" | "GAIN"}

- See Also**
- [":POWer:PSRR:APPLy"](#) on page 877
 - [":POWer:PSRR:DATA"](#) on page 878

:POWer:PSRR:WGEN:LOAD

N (see [page 1730](#))

Command Syntax :POWer:PSRR:WGEN:LOAD <impedance>

<impedance> ::= {ONEMeg | FIFTy}

The :POWer:PSRR:WGEN:LOAD command sets the waveform generator expected output load impedance.

The output impedance of the Gen Out signal is fixed at 50 ohms. However, the output load selection lets the waveform generator display the correct amplitude and offset levels for the expected output load. If the actual load impedance is different than the selected value, the displayed amplitude and offset levels will be incorrect.

Query Syntax :POWer:PSRR:WGEN:LOAD?

The :POWer:PSRR:WGEN:LOAD? query returns the waveform generator expected output load impedance setting.

Return Format <impedance><NL>

<impedance> ::= {ONEM | FIFT}

- See Also**
- [":POWer:PSRR"](#) on page 876
 - [":POWer:PSRR:APPLy"](#) on page 877
 - [":POWer:PSRR:DATA"](#) on page 878
 - [":POWer:PSRR:FREQuency:MAXimum"](#) on page 879
 - [":POWer:PSRR:FREQuency:MINimum"](#) on page 880
 - [":POWer:PSRR:FREQuency:MODE"](#) on page 881
 - [":POWer:PSRR:PPDecade"](#) on page 883
 - [":POWer:PSRR:SOURce:INPut"](#) on page 884
 - [":POWer:PSRR:SOURce:OUTPut"](#) on page 885
 - [":POWer:PSRR:WGEN:VOLTage"](#) on page 888
 - [":POWer:PSRR:WGEN:VOLTage:PROFile"](#) on page 889

:POWer:PSRR:WGEN:VOLTage

N (see [page 1730](#))

Command Syntax :POWer:PSRR:WGEN:VOLTage <amplitude>[,<range>]

<amplitude> ::= amplitude in volts in NR3 format

<range> ::= {F20HZ | F100HZ | F1KHZ | F10KHZ | F100KHZ | F1MHZ
| F10MHZ | F20MHZ}

The :POWer:PSRR:WGEN:VOLTage command sets the waveform generator output amplitude(s).

When the waveform generator amplitude profile is enabled (with the :POWer:PSRR:WGEN:VOLTage:PROFile command), you can set an initial ramp amplitude for each frequency range.

Without the <range> parameter, this command sets the waveform generator output amplitude used when the amplitude profile is disabled.

Query Syntax :POWer:PSRR:WGEN:VOLTage? [<range>]

The :POWer:PSRR:WGEN:VOLTage? query returns the waveform generator output amplitude setting(s).

Return Format <amplitude><NL>

<amplitude> ::= amplitude in volts in NR3 format

- See Also**
- [":POWer:PSRR"](#) on page 876
 - [":POWer:PSRR:APPLy"](#) on page 877
 - [":POWer:PSRR:DATA"](#) on page 878
 - [":POWer:PSRR:FREQuency:MAXimum"](#) on page 879
 - [":POWer:PSRR:FREQuency:MINimum"](#) on page 880
 - [":POWer:PSRR:FREQuency:MODE"](#) on page 881
 - [":POWer:PSRR:PPDecade"](#) on page 883
 - [":POWer:PSRR:SOURce:INPut"](#) on page 884
 - [":POWer:PSRR:SOURce:OUTPut"](#) on page 885
 - [":POWer:PSRR:WGEN:LOAD"](#) on page 887
 - [":POWer:PSRR:WGEN:VOLTage:PROFile"](#) on page 889

:POWer:PSRR:WGEN:VOLTage:PROFile

N (see [page 1730](#))

Command Syntax :POWer:PSRR:WGEN:VOLTage:PROFile {{0 | OFF} | {1 | ON}}

The :POWer:PSRR:WGEN:VOLTage:PROFile command enables or disables the ability to set initial waveform generator ramp amplitudes for each frequency range.

With amplitude profiling, you can use lower amplitudes at frequencies where the device under test (DUT) is sensitive to distortion and use higher amplitudes where the DUT is less sensitive to distortion.

You can often observe distortions during the test. If the input test sine wave begins to look lopsided, clipped, or somewhat triangular in shape (nonsinusoidal), you are probably encountering distortion due to overdriving your DUT. Optimizing test amplitudes to achieve the best dynamic range measurements is often an iterative process of running your frequency response measurements multiple times.

Query Syntax :POWer:CLResponse:WGEN:VOLTage:PROFile?

The :POWer:PSRR:WGEN:VOLTage:PROFile? query returns the voltage profile setting.

Return Format <setting><NL>
<setting> ::= {0 | 1}

- See Also**
- [":POWer:PSRR"](#) on page 876
 - [":POWer:PSRR:APPLy"](#) on page 877
 - [":POWer:PSRR:DATA"](#) on page 878
 - [":POWer:PSRR:FREQuency:MAXimum"](#) on page 879
 - [":POWer:PSRR:FREQuency:MINimum"](#) on page 880
 - [":POWer:PSRR:FREQuency:MODE"](#) on page 881
 - [":POWer:PSRR:PPDecade"](#) on page 883
 - [":POWer:PSRR:SOURce:INPut"](#) on page 884
 - [":POWer:PSRR:SOURce:OUTPut"](#) on page 885
 - [":POWer:PSRR:WGEN:LOAD"](#) on page 887
 - [":POWer:PSRR:WGEN:VOLTage"](#) on page 888

:POWer:QUALity:APPLy

N (see [page 1730](#))

Command Syntax :POWer:QUALity:APPLy

The :POWer:QUALity:APPLy command applies the selected power quality analysis type (:POWer:QUALity:TYPE).

The power quality analysis shows the quality of the AC input line.

Some AC current may flow back into and back out of the load without delivering energy. This current, called reactive or harmonic current, gives rise to an "apparent" power which is larger than the actual power consumed. Power quality is gauged by these measurements: power factor, apparent power, true power, reactive power, crest factor, and phase angle of the current and voltage of the AC line.

- See Also**
- [":MEASure:FACTor"](#) on page 768
 - [":MEASure:REAL"](#) on page 777
 - [":MEASure:APParent"](#) on page 763
 - [":MEASure:REACTive"](#) on page 776
 - [":MEASure:CRESt"](#) on page 765
 - [":MEASure:ANGLE"](#) on page 762

:POWer:RIPPlE:APPLy

N (see [page 1730](#))

Command Syntax :POWer:RIPPlE:APPLy

The :POWer:RIPPlE:APPLy command applies the output ripple analysis.

See Also • [":MEASure:RIPPlE"](#) on page 778

:POWer:SIGNals:AUTosetup

N (see [page 1730](#))

Command Syntax :POWer:SIGNals:AUTosetup <analysis>
 <analysis> ::= {HARMonics | EFFiciency | RIPple | MODulation | QUALity
 | SLEW | SWITCh | RDSVce}

The :POWer:SIGNals:AUTosetup command performs automated oscilloscope setup for the signals in the specified type of power analysis.

- See Also**
- [":POWer:HARMonics:DISPlay"](#) on page 853
 - [":POWer:EFFiciency:APPLY"](#) on page 848
 - [":POWer:RIPple:APPLY"](#) on page 891
 - [":POWer:MODulation:APPLY"](#) on page 867
 - [":POWer:QUALity:APPLY"](#) on page 890
 - [":POWer:SLEW:APPLY"](#) on page 911
 - [":POWer:SWITCh:APPLY"](#) on page 913
 - [":POWer:SIGNals:CYCLes:HARMonics"](#) on page 893
 - [":POWer:SIGNals:CYCLes:QUALity"](#) on page 894
 - [":POWer:SIGNals:DURation:EFFiciency"](#) on page 895
 - [":POWer:SIGNals:DURation:MODulation"](#) on page 896
 - [":POWer:SIGNals:DURation:RIPple"](#) on page 899
 - [":POWer:SIGNals:IEXpected"](#) on page 901
 - [":POWer:SIGNals:OVERshoot"](#) on page 902
 - [":POWer:SIGNals:SOURce:CURRENT<i>"](#) on page 909
 - [":POWer:SIGNals:SOURce:VOLTage<i>"](#) on page 910

:POWer:SIGNals:CYCLes:HARMonics

N (see [page 1730](#))

Command Syntax :POWer:SIGNals:CYCLes:HARMonics <count>

<count> ::= integer in NR1 format

Legal values are 1 to 100.

The :POWer:SIGNals:CYCLes:HARMonics command specifies the number of cycles to include in the current harmonics analysis.

Query Syntax :POWer:SIGNals:CYCLes:HARMonics?

The :POWer:SIGNals:CYCLes:HARMonics query returns the number of cycles currently set.

Return Format <count><NL>

<count> ::= integer in NR1 format

- See Also**
- [":POWer:HARMonics:DISPlay"](#) on page 853
 - [":POWer:HARMonics:APPLy"](#) on page 851
 - [":POWer:SIGNals:AUTosetup"](#) on page 892
 - [":POWer:SIGNals:IEXpected"](#) on page 901
 - [":POWer:SIGNals:OVERshoot"](#) on page 902
 - [":POWer:SIGNals:SOURce:CURRent<i>"](#) on page 909
 - [":POWer:SIGNals:SOURce:VOLTage<i>"](#) on page 910

:POWer:SIGNals:CYCLes:QUALity

N (see [page 1730](#))

Command Syntax :POWer:SIGNals:CYCLes:QUALity <count>

<count> ::= integer in NR1 format

Legal values are 1 to 100.

The :POWer:SIGNals:CYCLes:QUALity command specifies the number of cycles to include in the power quality analysis.

Query Syntax :POWer:SIGNals:CYCLes:QUALity?

The :POWer:SIGNals:CYCLes:QUALity query returns the number of cycles currently set.

Return Format <count><NL>

<count> ::= integer in NR1 format

- See Also**
- [":POWer:QUALity:APPLy"](#) on page 890
 - [":POWer:SIGNals:AUTOsetup"](#) on page 892
 - [":POWer:SIGNals:IEXpected"](#) on page 901
 - [":POWer:SIGNals:OVERshoot"](#) on page 902
 - [":POWer:SIGNals:SOURce:CURRent<i>"](#) on page 909
 - [":POWer:SIGNals:SOURce:VOLTage<i>"](#) on page 910

:POWer:SIGNals:DURation:EFFiciency

N (see [page 1730](#))

Command Syntax :POWer:SIGNals:DURation:EFFiciency <value>[suffix]

<value> ::= value in NR3 format

[suffix] ::= {s | ms | us | ns}

The :POWer:SIGNals:DURation:EFFiciency command specifies the duration of the efficiency analysis.

Query Syntax :POWer:SIGNals:DURation:EFFiciency?

The :POWer:SIGNals:DURation:EFFiciency query returns the set duration time value.

Return Format <value><NL>

<value> ::= value in NR3 format

- See Also**
- [":POWer:EFFiciency:APPLY"](#) on page 848
 - [":POWer:SIGNals:AUTosetup"](#) on page 892
 - [":POWer:SIGNals:IEXpected"](#) on page 901
 - [":POWer:SIGNals:OVERshoot"](#) on page 902
 - [":POWer:SIGNals:SOURce:CURRent<i>"](#) on page 909
 - [":POWer:SIGNals:SOURce:VOLTage<i>"](#) on page 910

:POWer:SIGNals:DURation:MODulation

N (see [page 1730](#))

Command Syntax :POWer:SIGNals:DURation:MODulation <value>[suffix]

<value> ::= value in NR3 format

[suffix] ::= {s | ms | us | ns}

The :POWer:SIGNals:DURation:MODulation command specifies the duration of the modulation analysis.

Query Syntax :POWer:SIGNals:DURation:MODulation?

The :POWer:SIGNals:DURation:MODulation query returns the set duration time value.

Return Format <value><NL>

<value> ::= value in NR3 format

- See Also**
- [":POWer:MODulation:APPLy"](#) on page 867
 - [":POWer:SIGNals:AUTosetup"](#) on page 892
 - [":POWer:SIGNals:IEXPected"](#) on page 901
 - [":POWer:SIGNals:OVERshoot"](#) on page 902
 - [":POWer:SIGNals:SOURce:CURRent<i>"](#) on page 909
 - [":POWer:SIGNals:SOURce:VOLTage<i>"](#) on page 910

:POWer:SIGNals:DURation:ONOFF:OFF

N (see [page 1730](#))

Command Syntax :POWer:SIGNals:DURation:ONOFF:OFF <value>[suffix]

<value> ::= value in NR3 format

[suffix] ::= {s | ms | us | ns}

The :POWer:SIGNals:DURation:ONOFF:OFF command specifies the duration of the turn off analysis.

Query Syntax :POWer:SIGNals:DURation:ONOFF:OFF?

The :POWer:SIGNals:DURation:ONOFF:OFF query returns the set duration time value.

Return Format <value><NL>

<value> ::= value in NR3 format

- See Also**
- [":POWer:ONOFF:APPLY"](#) on page 870
 - [":POWer:SIGNals:AUTOsetup"](#) on page 892
 - [":POWer:SIGNals:IEXpected"](#) on page 901
 - [":POWer:SIGNals:OVERshoot"](#) on page 902
 - [":POWer:SIGNals:VMAXimum:ONOFF:OFF"](#) on page 904
 - [":POWer:SIGNals:VSTeady:ONOFF:OFF"](#) on page 906
 - [":POWer:SIGNals:SOURce:CURRENT<i>"](#) on page 909
 - [":POWer:SIGNals:SOURce:VOLTage<i>"](#) on page 910

:POWer:SIGNals:DURation:ONOFF:ON

N (see [page 1730](#))

Command Syntax :POWer:SIGNals:DURation:ONOFF:ON <value> [suffix]

<value> ::= value in NR3 format

[suffix] ::= {s | ms | us | ns}

The :POWer:SIGNals:DURation:ONOFF:ON command specifies the duration of the turn on analysis.

Query Syntax :POWer:SIGNals:DURation:ONOFF:ON?

The :POWer:SIGNals:DURation:ONOFF:ON query returns the set duration time value.

Return Format <value><NL>

<value> ::= value in NR3 format

- See Also**
- [":POWer:ONOFF:APPLY"](#) on page 870
 - [":POWer:SIGNals:AUTosetup"](#) on page 892
 - [":POWer:SIGNals:IEXpected"](#) on page 901
 - [":POWer:SIGNals:OVERshoot"](#) on page 902
 - [":POWer:SIGNals:VMAXimum:ONOFF:ON"](#) on page 905
 - [":POWer:SIGNals:VSTeady:ONOFF:ON"](#) on page 907
 - [":POWer:SIGNals:SOURce:CURRENT<i>"](#) on page 909
 - [":POWer:SIGNals:SOURce:VOLTage<i>"](#) on page 910

:POWer:SIGNals:DURation:RIPPlE

N (see [page 1730](#))

Command Syntax :POWer:SIGNals:DURation:RIPPlE <value>[suffix]

<value> ::= value in NR3 format

[suffix] ::= {s | ms | us | ns}

The :POWer:SIGNals:DURation:RIPPlE command specifies the duration of the output ripple analysis.

Query Syntax :POWer:SIGNals:DURation:RIPPlE?

The :POWer:SIGNals:DURation:RIPPlE query returns the set duration time value.

Return Format <value><NL>

<value> ::= value in NR3 format

- See Also**
- [":POWer:RIPPlE:APPLy"](#) on page 891
 - [":POWer:SIGNals:AUTosetup"](#) on page 892
 - [":POWer:SIGNals:IEXPeCted"](#) on page 901
 - [":POWer:SIGNals:OVERshoot"](#) on page 902
 - [":POWer:SIGNals:SOURce:CURREnt<i>"](#) on page 909
 - [":POWer:SIGNals:SOURce:VOLTage<i>"](#) on page 910

:POWer:SIGNals:DURation:TRANsient

N (see [page 1730](#))

Command Syntax :POWer:SIGNals:DURation:TRANsient <value>[suffix]

<value> ::= value in NR3 format

[suffix] ::= {s | ms | us | ns}

The :POWer:SIGNals:DURation:TRANsient command specifies the duration of the transient response analysis.

Query Syntax :POWer:SIGNals:DURation:TRANsient?

The :POWer:SIGNals:DURation:TRANsient query returns the set duration time value.

Return Format <value><NL>

<value> ::= value in NR3 format

- See Also**
- [":POWer:TRANsient:APPLY"](#) on page 919
 - [":POWer:SIGNals:AUTosetup"](#) on page 892
 - [":POWer:SIGNals:IEXpected"](#) on page 901
 - [":POWer:SIGNals:OVERshoot"](#) on page 902
 - [":POWer:SIGNals:VSTeady:TRANsient"](#) on page 908
 - [":POWer:SIGNals:SOURce:CURRENT<i>"](#) on page 909
 - [":POWer:SIGNals:SOURce:VOLTage<i>"](#) on page 910

:POWer:SIGNals:IEXPected

N (see [page 1730](#))

Command Syntax :POWer:SIGNals:IEXPected <value>[suffix]
 <value> ::= Expected current value in NR3 format
 [suffix] ::= {A | mA}

The :POWer:SIGNals:IEXPected command specifies the expected inrush current amplitude. This value is used to set the vertical scale of the channel probing current.

Query Syntax :POWer:SIGNals:IEXPected?

The :POWer:SIGNals:IEXPected query returns the expected inrush current setting.

Return Format <value><NL>
 <value> ::= Expected current value in NR3 format

- See Also**
- [":POWer:INRush:APPLY"](#) on page 863
 - [":POWer:SIGNals:AUTosetup"](#) on page 892
 - [":POWer:SIGNals:OVERshoot"](#) on page 902
 - [":POWer:SIGNals:VMAXimum:INRush"](#) on page 903
 - [":POWer:SIGNals:SOURce:CURRENT<i>"](#) on page 909
 - [":POWer:SIGNals:SOURce:VOLTage<i>"](#) on page 910

:POWer:SIGNals:OVERshoot

N (see [page 1730](#))

Command Syntax :POWer:SIGNals:OVERshoot <percent>

<percent> ::= percent of overshoot value in NR1 format

The :POWer:SIGNals:OVERshoot command specifies the percent of overshoot of the output voltage. This value is used to determine the settling band value for the transient response and to adjust the vertical scale of the oscilloscope.

Query Syntax :POWer:SIGNals:OVERshoot?

The :POWer:SIGNals:OVERshoot query returns the overshoot percent setting.

Return Format <percent><NL>

<percent> ::= percent of overshoot value in NR1 format

- See Also**
- [":POWer:TRANsient:APPLY"](#) on page 919
 - [":POWer:SIGNals:AUTOsetup"](#) on page 892
 - [":POWer:SIGNals:DURATION:TRANsient"](#) on page 900
 - [":POWer:SIGNals:IXPECTed"](#) on page 901
 - [":POWer:SIGNals:VSTEady:TRANsient"](#) on page 908
 - [":POWer:SIGNals:SOURce:CURRENT<i>"](#) on page 909
 - [":POWer:SIGNals:SOURce:VOLTage<i>"](#) on page 910

:POWer:SIGNals:VMAXimum:INRush

N (see [page 1730](#))

Command Syntax :POWer:SIGNals:VMAXimum:INRush <value>[suffix]

<value> ::= Maximum expected input Voltage in NR3 format

[suffix] ::= {V | mV}

The :POWer:SIGNals:VMAXimum:INRush command specifies the maximum expected input voltage. This value is used to set the vertical scale of the channel probing voltage for inrush current analysis.

When the :POWer:ITYPE is DC, this command defines the maximum DC input voltage amplitude value. The values can be negative.

When the :POWer:ITYPE is AC, this command defines the maximum peak-to-peak input voltage. Only positive values are allowed.

Query Syntax :POWer:SIGNals:VMAXimum:INRush?

The :POWer:SIGNals:VMAXimum:INRush query returns the expected maximum input voltage setting.

Return Format <value><NL>

<value> ::= Maximum expected input Voltage in NR3 format

- See Also**
- [":POWer:ITYPE"](#) on page 866
 - [":POWer:INRush:APPLY"](#) on page 863
 - [":POWer:SIGNals:AUTOsetup"](#) on page 892
 - [":POWer:SIGNals:IEXpected"](#) on page 901
 - [":POWer:SIGNals:OVERshoot"](#) on page 902
 - [":POWer:SIGNals:SOURce:CURRENT<i>"](#) on page 909
 - [":POWer:SIGNals:SOURce:VOLTage<i>"](#) on page 910

:POWer:SIGNals:VMAXimum:ONOFF:OFF

N (see [page 1730](#))

Command Syntax :POWer:SIGNals:VMAXimum:ONOFF:OFF <value>[suffix]
 <value> ::= Maximum expected input Voltage in NR3 format
 [suffix] ::= {V | mV}

The :POWer:SIGNals:VMAXimum:ONOFF:OFF command specifies the maximum expected input voltage. This value is used to set the vertical scale of the channel probing voltage for turn off analysis.

When the :POWer:ITYPE is DC, this command defines the maximum DC input voltage amplitude value. The values can be negative.

When the :POWer:ITYPE is AC, this command defines the maximum peak-to-peak input voltage. Only positive values are allowed.

Query Syntax :POWer:SIGNals:VMAXimum:ONOFF:OFF?

The :POWer:SIGNals:VMAXimum:ONOFF:OFF query returns the expected maximum input voltage setting.

Return Format <value><NL>
 <value> ::= Maximum expected input Voltage in NR3 format

- See Also**
- [":POWer:ITYPE"](#) on page 866
 - [":POWer:ONOFF:APPLY"](#) on page 870
 - [":POWer:SIGNals:AUTOsetup"](#) on page 892
 - [":POWer:SIGNals:DURATION:ONOFF:OFF"](#) on page 897
 - [":POWer:SIGNals:IEXPECTED"](#) on page 901
 - [":POWer:SIGNals:OVERshoot"](#) on page 902
 - [":POWer:SIGNals:VSTEADY:ONOFF:OFF"](#) on page 906
 - [":POWer:SIGNals:SOURCE:CURRENT<i>"](#) on page 909
 - [":POWer:SIGNals:SOURCE:VOLTAGE<i>"](#) on page 910

:POWer:SIGNals:VMAXimum:ONOFF:ON

N (see [page 1730](#))

Command Syntax :POWer:SIGNals:VMAXimum:ONOFF:ON <value>[suffix]
 <value> ::= Maximum expected input Voltage in NR3 format
 [suffix] ::= {V | mV}

The :POWer:SIGNals:VMAXimum:ONOFF:ON command specifies the maximum expected input voltage. This value is used to set the vertical scale of the channel probing voltage for turn on analysis.

When the :POWer:ITYPE is DC, this command defines the maximum DC input voltage amplitude value. The values can be negative.

When the :POWer:ITYPE is AC, this command defines the maximum peak-to-peak input voltage. Only positive values are allowed.

Query Syntax :POWer:SIGNals:VMAXimum:ONOFF:ON?

The :POWer:SIGNals:VMAXimum:ONOFF:ON query returns the expected maximum input voltage setting.

Return Format <value><NL>
 <value> ::= Maximum expected input Voltage in NR3 format

- See Also**
- [":POWer:ITYPE"](#) on page 866
 - [":POWer:ONOFF:APPLY"](#) on page 870
 - [":POWer:SIGNals:AUTOsetup"](#) on page 892
 - [":POWer:SIGNals:DURATION:ONOFF:ON"](#) on page 898
 - [":POWer:SIGNals:IEXPECTED"](#) on page 901
 - [":POWer:SIGNals:OVERshoot"](#) on page 902
 - [":POWer:SIGNals:VSTEADY:ONOFF:ON"](#) on page 907
 - [":POWer:SIGNals:SOURCE:CURRENT<i>"](#) on page 909
 - [":POWer:SIGNals:SOURCE:VOLTage<i>"](#) on page 910

:POWer:SIGNals:VSTeady:ONOFF:OFF

N (see [page 1730](#))

Command Syntax :POWer:SIGNals:VSTeady:ONOFF:OFF <value>[suffix]

<value> ::= Expected steady state output Voltage value in NR3 format

[suffix] ::= {V | mV}

The :POWer:SIGNals:VSTeady:ONOFF:OFF command specifies the expected steady state output DC voltage of the power supply for turn off analysis.

Query Syntax :POWer:SIGNals:VSTeady:ONOFF:OFF?

The :POWer:SIGNals:VSTeady:ONOFF:OFF query returns the expected steady state voltage setting.

Return Format <value><NL>

<value> ::= Expected steady state output Voltage value in NR3 format

- See Also**
- [":POWer:ONOFF:APPLY"](#) on page 870
 - [":POWer:SIGNals:AUTosetup"](#) on page 892
 - [":POWer:SIGNals:DURation:ONOFF:OFF"](#) on page 897
 - [":POWer:SIGNals:IXPected"](#) on page 901
 - [":POWer:SIGNals:OVERshoot"](#) on page 902
 - [":POWer:SIGNals:VMAXimum:ONOFF:OFF"](#) on page 904
 - [":POWer:SIGNals:SOURce:CURRENT<i>"](#) on page 909
 - [":POWer:SIGNals:SOURce:VOLTage<i>"](#) on page 910

:POWer:SIGNals:VSTeady:ONOff:ON

N (see [page 1730](#))

Command Syntax :POWer:SIGNals:VSTeady:ONOff:ON <value>[suffix]

<value> ::= Expected steady state output Voltage value in NR3 format

[suffix] ::= {V | mV}

The :POWer:SIGNals:VSTeady:ONOff:ON command specifies the expected steady state output DC voltage of the power supply for turn on analysis.

Query Syntax :POWer:SIGNals:VSTeady:ONOff:ON?

The :POWer:SIGNals:VSTeady:ONOff:ON query returns the expected steady state voltage setting.

Return Format <value><NL>

<value> ::= Expected steady state output Voltage value in NR3 format

- See Also**
- [":POWer:ONOff:APPLy"](#) on page 870
 - [":POWer:SIGNals:AUToSetup"](#) on page 892
 - [":POWer:SIGNals:DURation:ONOff:ON"](#) on page 898
 - [":POWer:SIGNals:IEXpected"](#) on page 901
 - [":POWer:SIGNals:OVERshoot"](#) on page 902
 - [":POWer:SIGNals:VMAXimum:ONOff:ON"](#) on page 905
 - [":POWer:SIGNals:SOURce:CURREnt<i>"](#) on page 909
 - [":POWer:SIGNals:SOURce:VOLTage<i>"](#) on page 910

:POWer:SIGNals:VSTeady:TRANsient

N (see [page 1730](#))

Command Syntax :POWer:SIGNals:VSTeady:TRANsient <value>[suffix]

<value> ::= Expected steady state output Voltage value in NR3 format

[suffix] ::= {V | mV}

The :POWer:SIGNals:VSTeady:TRANsient command specifies the expected steady state output DC voltage of the power supply for transient response analysis.

This value is used along with the overshoot percentage to specify the settling band for the transient response and to adjust the vertical scale of the oscilloscope.

Query Syntax :POWer:SIGNals:VSTeady:TRANsient?

The :POWer:SIGNals:VSTeady:TRANsient query returns the expected steady state voltage setting.

Return Format <value><NL>

<value> ::= Expected steady state output Voltage value in NR3 format

- See Also**
- [":POWer:TRANsient:APPLY"](#) on page 919
 - [":POWer:SIGNals:AUTOsetup"](#) on page 892
 - [":POWer:SIGNals:DURATION:TRANsient"](#) on page 900
 - [":POWer:SIGNals:IEXPECTED"](#) on page 901
 - [":POWer:SIGNals:OVERshoot"](#) on page 902
 - [":POWer:SIGNals:SOURce:CURREnt<i>"](#) on page 909
 - [":POWer:SIGNals:SOURce:VOLTage<i>"](#) on page 910

:POWer:SIGNals:SOURce:CURRent<i>

N (see [page 1730](#))

Command Syntax :POWer:SIGNals:SOURce:CURRent<i> <source>

<i> ::= 1, 2 in NR1 format

<source> ::= CHANnel<n>

<n> ::= 1 to (# analog channels) in NR1 format

The :POWer:SIGNals:SOURce:CURRent<i> command specifies the first, and perhaps second, current source channel to be used in the power analysis.

Query Syntax :POWer:SIGNals:SOURce:CURRent<i>?

The :POWer:SIGNals:SOURce:CURRent<i> query returns the current source channel setting.

Return Format <source><NL>

<source> ::= CHANnel<n>

<n> ::= 1 to (# analog channels) in NR1 format

- See Also**
- [":POWer:SIGNals:AUTOsetup"](#) on page 892
 - [":POWer:SIGNals:CYCLes:HARMonics"](#) on page 893
 - [":POWer:SIGNals:CYCLes:QUALity"](#) on page 894
 - [":POWer:SIGNals:DURation:EFFiciency"](#) on page 895
 - [":POWer:SIGNals:DURation:MODulation"](#) on page 896
 - [":POWer:SIGNals:DURation:ONOFF:OFF"](#) on page 897
 - [":POWer:SIGNals:DURation:ONOFF:ON"](#) on page 898
 - [":POWer:SIGNals:DURation:RIPple"](#) on page 899
 - [":POWer:SIGNals:DURation:TRANsient"](#) on page 900
 - [":POWer:SIGNals:IEXPected"](#) on page 901
 - [":POWer:SIGNals:OVERshoot"](#) on page 902
 - [":POWer:SIGNals:VMAXimum:INRush"](#) on page 903
 - [":POWer:SIGNals:VMAXimum:ONOFF:OFF"](#) on page 904
 - [":POWer:SIGNals:VMAXimum:ONOFF:ON"](#) on page 905
 - [":POWer:SIGNals:VSTeady:ONOFF:OFF"](#) on page 906
 - [":POWer:SIGNals:VSTeady:ONOFF:ON"](#) on page 907
 - [":POWer:SIGNals:VSTeady:TRANsient"](#) on page 908
 - [":POWer:SIGNals:SOURce:VOLTage<i>"](#) on page 910

:POWer:SIGNals:SOURce:VOLTage<i>

N (see [page 1730](#))

Command Syntax :POWer:SIGNals:SOURce:VOLTage<i> <source>

<i> ::= 1, 2 in NR1 format

<source> ::= CHANnel<n>

<n> ::= 1 to (# analog channels) in NR1 format

The :POWer:SIGNals:SOURce:VOLTage<i> command specifies the first, and perhaps second, voltage source channel to be used in the power analysis.

Query Syntax :POWer:SIGNals:SOURce:VOLTage<i>?

The :POWer:SIGNals:SOURce:VOLTage<i> query returns the voltage source channel setting.

Return Format <source><NL>

<source> ::= CHANnel<n>

<n> ::= 1 to (# analog channels) in NR1 format

- See Also**
- [":POWer:SIGNals:AUTOsetup"](#) on page 892
 - [":POWer:SIGNals:CYCLes:HARMonics"](#) on page 893
 - [":POWer:SIGNals:CYCLes:QUALity"](#) on page 894
 - [":POWer:SIGNals:DURation:EFFiciency"](#) on page 895
 - [":POWer:SIGNals:DURation:MODulation"](#) on page 896
 - [":POWer:SIGNals:DURation:ONOFF:OFF"](#) on page 897
 - [":POWer:SIGNals:DURation:ONOFF:ON"](#) on page 898
 - [":POWer:SIGNals:DURation:RIPPlE"](#) on page 899
 - [":POWer:SIGNals:DURation:TRANsient"](#) on page 900
 - [":POWer:SIGNals:IEXpected"](#) on page 901
 - [":POWer:SIGNals:OVERshoot"](#) on page 902
 - [":POWer:SIGNals:VMAXimum:INRush"](#) on page 903
 - [":POWer:SIGNals:VMAXimum:ONOFF:OFF"](#) on page 904
 - [":POWer:SIGNals:VMAXimum:ONOFF:ON"](#) on page 905
 - [":POWer:SIGNals:VSTeady:ONOFF:OFF"](#) on page 906
 - [":POWer:SIGNals:VSTeady:ONOFF:ON"](#) on page 907
 - [":POWer:SIGNals:VSTeady:TRANsient"](#) on page 908
 - [":POWer:SIGNals:SOURce:CURREnt<i>"](#) on page 909

:POWer:SLEW:APPLY

N (see [page 1730](#))

Command Syntax :POWer:SLEW:APPLY

The :POWer:SLEW:APPLY command applies the slew rate analysis.

See Also • [":POWer:SLEW:SOURce"](#) on page 912

:POWer:SLEW:SOURce

N (see [page 1730](#))

Command Syntax :POWer:SLEW:SOURce <source>

<source> ::= {V | I}

The :POWer:SLEW:SOURce command selects either the voltage source or the current source as the source for the slew rate analysis.

Query Syntax :POWer:SLEW:SOURce?

The :POWer:SLEW:SOURce query returns the selected source for the slew rate analysis.

Return Format <source><NL>

<source> ::= {V | I}

See Also • [":POWer:SLEW:APPLY"](#) on page 911

:POWer:SWITCh:APPLy

N (see [page 1730](#))

Command Syntax :POWer:SWITCh:APPLy

The :POWer:SWITCh:APPLy command applies the switching loss analysis using the conduction calculation method, V reference, and I reference settings.

- See Also**
- [":POWer:SWITCh:CONDuction"](#) on page 914
 - [":POWer:SWITCh:IREFERENCE"](#) on page 915
 - [":POWer:SWITCh:RDS"](#) on page 916
 - [":POWer:SWITCh:VCE"](#) on page 917
 - [":POWer:SWITCh:VREFERENCE"](#) on page 918
 - [":MEASure:ELOSs"](#) on page 767
 - [":MEASure:PLOSs"](#) on page 774

:POWer:SWITCh:CONDUction

N (see [page 1730](#))

Command Syntax :POWer:SWITCh:CONDUction <conduction>

<conduction> ::= {WAVeform | RDS | VCE}

The :POWer:SWITCh:CONDUction command specifies the conduction calculation method:

- WAVeform – The Power waveform uses the original voltage waveform data, and the calculation is: $P = V \times I$
- RDS – Rds(on) – The Power waveform includes error correction:
 - In the On Zone (where the voltage level is below V Ref) – the Power calculation is: $P = Id^2 \times Rds(on)$
Specify Rds(on) using the :POWer:SWITCh:RDS command.
 - In the Off Zone (where the current level is below I Ref) – the Power calculation is: $P = 0$ Watt.
- VCE – Vce(sat) – The Power waveform includes error correction:
 - In the On Zone (where the voltage level is below V Ref) – the Power calculation is: $P = Vce(sat) \times Ic$
Specify Vce(sat) using the :POWer:SWITCh:VCE command.
 - In the Off Zone (where the current level is below I Ref) – the Power calculation is: $P = 0$ Watt.

Query Syntax :POWer:SWITCh:CONDUction?

The :POWer:SWITCh:CONDUction query returns the conduction calculation method.

Return Format <conduction><NL>

<conduction> ::= {WAV | RDS | VCE}

- See Also**
- [":POWer:SWITCh:APPLY"](#) on page 913
 - [":POWer:SWITCh:IREFERENCE"](#) on page 915
 - [":POWer:SWITCh:RDS"](#) on page 916
 - [":POWer:SWITCh:VCE"](#) on page 917
 - [":POWer:SWITCh:VREFERENCE"](#) on page 918

:POWer:SWITCh:IREFERENCE

N (see [page 1730](#))

Command Syntax :POWer:SWITCh:IREFERENCE <percent>
 <percent> ::= percent in NR1 format

The :POWer:SWITCh:IREFERENCE command to specify the current switching level for the start of switching edges. The value is in percentage of the maximum switch current.

You can adjust this value to ignore noise floors or null offset that is difficult to eliminate in current probes.

This value specifies the threshold that is used to determine the switching edges.

Query Syntax :POWer:SWITCh:IREFERENCE?

The :POWer:SWITCh:IREFERENCE query returns the current switching level percent value.

Return Format <percent><NL>
 <percent> ::= percent in NR1 format

- See Also**
- [":POWer:SWITCh:APPLY"](#) on page 913
 - [":POWer:SWITCh:CONDUCTION"](#) on page 914
 - [":POWer:SWITCh:RDS"](#) on page 916
 - [":POWer:SWITCh:VCE"](#) on page 917
 - [":POWer:SWITCh:VREFERENCE"](#) on page 918

:POWer:SWITCh:RDS

N (see [page 1730](#))

Command Syntax :POWer:SWITCh:RDS <value>[suffix]

<value> ::= Rds(on) value in NR3 format

[suffix] ::= {OHM | mOHM}

The :POWer:SWITCh:RDS command specifies the Rds(on) value when the RDS conduction calculation method is chosen (by :POWer:SWITCh:CONDUction).

Query Syntax :POWer:SWITCh:RDS?

The :POWer:SWITCh:RDS query returns the Rds(on) value.

Return Format <value><NL>

<value> ::= Rds(on) value in NR3 format

- See Also**
- [":POWer:SWITCh:APPLY"](#) on page 913
 - [":POWer:SWITCh:CONDUction"](#) on page 914
 - [":POWer:SWITCh:IREFERENCE"](#) on page 915
 - [":POWer:SWITCh:VCE"](#) on page 917
 - [":POWer:SWITCh:VREFERENCE"](#) on page 918

:POWer:SWITCh:VCE

N (see [page 1730](#))

Command Syntax :POWer:SWITCh:VCE <value>[suffix]

<value> ::= Vce(sat) value in NR3 format

[suffix] ::= {V | mV}

The :POWer:SWITCh:VCE command specifies the Vce(sat) value when the VCE conduction calculation method is chosen (by :POWer:SWITCh:CONDUction).

Query Syntax :POWer:SWITCh:VCE?

The :POWer:SWITCh:VCE query returns the Vce(sat) value.

Return Format <value><NL>

<value> ::= Vce(sat) value in NR3 format

- See Also**
- [":POWer:SWITCh:APPLy"](#) on page 913
 - [":POWer:SWITCh:CONDUction"](#) on page 914
 - [":POWer:SWITCh:IREFERENCE"](#) on page 915
 - [":POWer:SWITCh:RDS"](#) on page 916
 - [":POWer:SWITCh:VREFERENCE"](#) on page 918

:POWer:SWITCh:VREFeRence

N (see [page 1730](#))

Command Syntax :POWer:SWITCh:VREFeRence <percent>
 <percent> ::= percent in NR1 format

The :POWer:SWITCh:VREFeRence command to specify the voltage switching level for the switching edges. The value is in percentage of the maximum switch voltage.

You can adjust this value to ignore noise floors.

This value specifies the threshold that is used to determine the switching edges.

Query Syntax :POWer:SWITCh:VREFeRence?

The :POWer:SWITCh:VREFeRence query returns the voltage switching level percent value.

Return Format <percent><NL>
 <percent> ::= percent in NR1 format

- See Also**
- [":POWer:SWITCh:APPLY"](#) on page 913
 - [":POWer:SWITCh:CONDUction"](#) on page 914
 - [":POWer:SWITCh:IREFeRence"](#) on page 915
 - [":POWer:SWITCh:RDS"](#) on page 916
 - [":POWer:SWITCh:VCE"](#) on page 917

:POWer:TRANsient:APPLy

N (see [page 1730](#))

Command Syntax :POWer:TRANsient:APPLy

The :POWer:TRANsient:APPLy command applies the transient analysis using the initial current and new current settings.

- See Also**
- [":POWer:TRANsient:EXIT"](#) on page 920
 - [":POWer:TRANsient:IInitial"](#) on page 921
 - [":POWer:TRANsient:INew"](#) on page 922
 - [":POWer:TRANsient:NEXT"](#) on page 923
 - [":MEASure:TRESponse"](#) on page 779

:POWer:TRANsient:EXIT

N (see [page 1730](#))

Command Syntax :POWer:TRANsient:EXIT

The :POWer:TRANsient:EXIT command exits (stops) the transient analysis.

This command is equivalent to pressing the **Exit** softkey on the oscilloscope front panel during the analysis.

- See Also**
- [":POWer:TRANsient:APPLY"](#) on page 919
 - [":POWer:TRANsient:INitial"](#) on page 921
 - [":POWer:TRANsient:INEW"](#) on page 922
 - [":POWer:TRANsient:NEXT"](#) on page 923

:POWer:TRANsient:IINitial

N (see [page 1730](#))

Command Syntax :POWer:TRANsient:IINitial <value>[suffix]

<value> ::= Initial current value in NR3 format

[suffix] ::= {A | mA}

The :POWer:TRANsient:IINitial command to specify the initial load current value. The initial load current will be used as a reference and to trigger the oscilloscope.

Query Syntax :POWer:TRANsient:IINitial?

The :POWer:TRANsient:IINitial query returns the initial load current value.

Return Format <value><NL>

<value> ::= Initial current value in NR3 format

- See Also**
- [":POWer:SIGNals:VSTeady:TRANsient"](#) on page 908
 - [":POWer:TRANsient:APPLy"](#) on page 919
 - [":POWer:TRANsient:EXIT"](#) on page 920
 - [":POWer:TRANsient:INEW"](#) on page 922
 - [":POWer:TRANsient:NEXT"](#) on page 923

:POWer:TRANsient:INEW

N (see [page 1730](#))

Command Syntax :POWer:TRANsient:INEW <value>[suffix]

<value> ::= New current value in NR3 format

[suffix] ::= {A | mA}

The :POWer:TRANsient:INEW command to specify the new load current value. The new load current will be used as a reference and to trigger the oscilloscope.

Query Syntax :POWer:TRANsient:INEW?

The :POWer:TRANsient:INEW query returns the new load current value.

Return Format <value><NL>

<value> ::= New current value in NR3 format

- See Also**
- [":POWer:TRANsient:APPLY"](#) on page 919
 - [":POWer:TRANsient:EXIT"](#) on page 920
 - [":POWer:TRANsient:IInitial"](#) on page 921
 - [":POWer:TRANsient:NEXT"](#) on page 923

:POWer:TRANsient:NEXT

N (see [page 1730](#))

Command Syntax :POWer:TRANsient:NEXT

The :POWer:TRANsient:NEXT command goes to the next step of the transient analysis.

This command is equivalent to pressing the **Next** softkey on the oscilloscope front panel when prompted during the analysis.

- See Also**
- [":POWer:TRANsient:APPLY"](#) on page 919
 - [":POWer:TRANsient:EXIT"](#) on page 920
 - [":POWer:TRANsient:IInitial"](#) on page 921
 - [":POWer:TRANsient:INEW"](#) on page 922

34 :RECall Commands

Recall previously saved oscilloscope setups, reference waveforms, and masks.

Table 124 :RECall Commands Summary

Command	Query	Options and Query Returns
:RECall:ARBitrary:[ST ART] [<file_spec>] [, <column>] [, <wavegen_id>] (see page 928)	n/a	<file_spec> ::= {<internal_loc> <file_name>} <column> ::= Column in CSV file to load. Column number starts from 1. <internal_loc> ::= 0-3; an integer in NR1 format <file_name> ::= quoted ASCII string <wavegen_id> ::= {WGEN1 WGEN2}
:RECall:DBC[:START] [<file_name>] [, <serialbus>] (see page 929)	n/a	<file_name> ::= quoted ASCII string If extension included in file name, it must be ".dbc". <serialbus> ::= {SBUS<n>} <n> ::= 1 to (# of serial bus) in NR1 format
:RECall:FIleName <base_name> (see page 930)	:RECall:FIleName? (see page 930)	<base_name> ::= quoted ASCII string
:RECall:LDF[:START] [<file_name>] [, <serialbus>] (see page 931)	n/a	<file_name> ::= quoted ASCII string If extension included in file name, it must be ".ldf". <serialbus> ::= {SBUS<n>} <n> ::= 1 to (# of serial bus) in NR1 format

Table 124 :RECall Commands Summary (continued)

Command	Query	Options and Query Returns
:RECall:MASK[:START] [<file_spec>] (see page 932)	n/a	<file_spec> ::= {<internal_loc> <file_name>} <internal_loc> ::= 0-3; an integer in NR1 format <file_name> ::= quoted ASCII string
:RECall:PWD <path_name> (see page 933)	:RECall:PWD? (see page 933)	<path_name> ::= quoted ASCII string
:RECall:SETup[:START] [<file_spec>] (see page 934)	n/a	<file_spec> ::= {<internal_loc> <file_name>} <internal_loc> ::= 0-9; an integer in NR1 format <file_name> ::= quoted ASCII string
:RECall:WMEMemory<r>[:START] [<file_name> <data>] (see page 935)	n/a	<r> ::= 1 to (# ref waveforms) in NR1 format <file_name> ::= quoted ASCII string If extension included in file name, it must be ".h5". <data> ::= binary block data in IEEE 488.2 # format

Introduction to :RECall Commands The :RECall subsystem provides commands to recall previously saved oscilloscope setups, reference waveforms, and masks.

Reporting the Setup

Use :RECall? to query setup information for the RECall subsystem.

Return Format

The following is a sample response from the :RECall? query. In this case, the query was issued following the *RST command.

```
:REC:FIL "scope_0"
```

Recalling Files From a USB Storage Device

When :RECall commands have a "quoted ASCII string" <file_name> parameter, you can recall files from a connected USB storage device. For example:

```
' To recall a setup file from a connected USB storage device:  
myScope.WriteString ":RECall:SETup:START ""\usb\my_setup_file.scp""
```

:RECall:ARbitrary[:START]

N (see [page 1730](#))

Command Syntax :RECall:ARbitrary:[START] [<file_spec>][, <column>][, <wavegen_id>]
 <file_spec> ::= {<internal_loc> | <file_name>}
 <column> ::= Column in CSV file to load. Column number starts from 1.
 <wavegen_id> ::= {WGEN1 | WGEN2} - specifies which wavegen
 <internal_loc> ::= 0-3; an integer in NR1 format
 <file_name> ::= quoted ASCII string

The :RECall:ARbitrary:[START] command recalls an arbitrary waveform.

NOTE

If a file extension is provided as part of a specified <file_name>, it must be ".csv".

For internal locations, the <column> parameter is ignored.

For external (USB storage device) files, the column parameter is optional. If no <column> parameter is entered, and it is a 2-column file, the 2nd column (assumed to be voltage) is automatically be selected. If the <column> parameter is entered, and that column does not exist in the file, the operation fails.

When recalling arbitrary waveforms (from an external USB storage device) that were not saved from the oscilloscope, be aware that the oscilloscope uses a maximum of 8192 points for an arbitrary waveform. For more efficient recalls, make sure your arbitrary waveforms are 8192 points or less.

The <wavegen_id> parameter specifies which waveform generator to recall the arbitrary waveform into.

- See Also**
- ["Introduction to :RECall Commands"](#) on page 926
 - [":RECall:FILENAME"](#) on page 930
 - [":SAVE:ARbitrary\[:START\]"](#) on page 947

:RECall:DBC[:START]

N (see [page 1730](#))

Command Syntax :RECall:DBC[:START] [<file_name>] [, <serialbus>]

<file_name> ::= quoted ASCII string

<serialbus> ::= {SBUS<n>}

<n> ::= 1 to (# of serial bus) in NR1 format

The :RECall:DBC[:START] command loads a CAN DBC (communication database) symbolic data file into the oscilloscope.

NOTE

If a file extension is provided as part of a specified <file_name>, it must be ".dbc".

The <serialbus> parameter specifies which serial decode waveform the CAN symbolic data will be loaded for.

- See Also**
- ["Introduction to :RECall Commands"](#) on page 926
 - [":RECall:FILENAME"](#) on page 930
 - [":SBUS<n>:CAN:TRIGger"](#) on page 1018
 - [":SBUS<n>:CAN:TRIGger:SYMBOLic:MESSAge"](#) on page 1028
 - [":SBUS<n>:CAN:TRIGger:SYMBOLic:SIGNal"](#) on page 1029
 - [":SBUS<n>:CAN:TRIGger:SYMBOLic:VALue"](#) on page 1030
 - [":SEARCH:SERial:CAN:MODE"](#) on page 1311
 - [":SEARCH:SERial:CAN:SYMBOLic:MESSAge"](#) on page 1317
 - [":SEARCH:SERial:CAN:SYMBOLic:SIGNal"](#) on page 1318
 - [":SEARCH:SERial:CAN:SYMBOLic:VALue"](#) on page 1319

:RECall:FILename

N (see [page 1730](#))

Command Syntax :RECall:FILename <base_name>

<base_name> ::= quoted ASCII string

The :RECall:FILename command specifies the source for any RECall operations.

NOTE

This command specifies a file's base name only, without path information or an extension.

Query Syntax :RECall:FILename?

The :RECall:FILename? query returns the current RECall filename.

Return Format <base_name><NL>

<base_name> ::= quoted ASCII string

- See Also**
- ["Introduction to :RECall Commands"](#) on page 926
 - [":RECall:SETup\[:START\]"](#) on page 934
 - [":SAVE:FILename"](#) on page 949

:RECall:LDF[:START]

N (see [page 1730](#))

Command Syntax :RECall:LDF[:START] [<file_name>] [, <serialbus>]

<file_name> ::= quoted ASCII string

<serialbus> ::= {SBUS<n>}

<n> ::= 1 to (# of serial bus) in NR1 format

The :RECall:LDF[:START] command loads a LIN description file (LDF) symbolic data file into the oscilloscope.

NOTE

If a file extension is provided as part of a specified <file_name>, it must be ".ldf".

The <serialbus> parameter specifies which serial decode waveform the LIN symbolic data will be loaded for.

- See Also**
- ["Introduction to :RECall Commands"](#) on page 926
 - [":RECall:FILENAME"](#) on page 930
 - [":SBUS<n>:LIN:TRIGGER"](#) on page 1106
 - [":SBUS<n>:LIN:TRIGGER:SYMBOLIC:FRAME"](#) on page 1113
 - [":SBUS<n>:LIN:TRIGGER:SYMBOLIC:SIGNAL"](#) on page 1114
 - [":SBUS<n>:LIN:TRIGGER:SYMBOLIC:VALUE"](#) on page 1115
 - [":SEARCH:SERIAL:LIN:MODE"](#) on page 1341
 - [":SEARCH:SERIAL:LIN:SYMBOLIC:FRAME"](#) on page 1345
 - [":SEARCH:SERIAL:LIN:SYMBOLIC:SIGNAL"](#) on page 1346
 - [":SEARCH:SERIAL:LIN:SYMBOLIC:VALUE"](#) on page 1347

:RECall:MASK[:START]

N (see [page 1730](#))

Command Syntax :RECall:MASK[:START] [<file_spec>
 <file_spec> ::= {<internal_loc> | <file_name>}
 <internal_loc> ::= 0-3; an integer in NR1 format
 <file_name> ::= quoted ASCII string

The :RECall:MASK[:START] command recalls a mask.

NOTE

If a file extension is provided as part of a specified <file_name>, it must be ".msk".

- See Also**
- ["Introduction to :RECall Commands"](#) on page 926
 - [":RECall:FILENAME"](#) on page 930
 - [":RECall:PWD"](#) on page 933
 - [":SAVE:MASK\[:START\]"](#) on page 956
 - [":MTEST:DATA"](#) on page 796

:RECall:PWD

N (see [page 1730](#))

Command Syntax :RECall:PWD <path_name>
 <path_name> ::= quoted ASCII string

The :RECall:PWD command sets the present working directory for recall operations.

NOTE

Presently, the internal "/User Files" directory you see in the oscilloscope's front panel user interface is the "\Agilent Flash" directory you see in the remote interface.

Query Syntax :RECall:PWD?

The :RECall:PWD? query returns the currently set working directory for recall operations.

Return Format <path_name><NL>
 <path_name> ::= quoted ASCII string

- See Also**
- ["Introduction to :RECall Commands"](#) on page 926
 - [":SAVE:PWD"](#) on page 959

:RECall:SETup[:START]

N (see [page 1730](#))

Command Syntax :RECall:SETup[:START] [<file_spec>
 <file_spec> ::= {<internal_loc> | <file_name>}
 <internal_loc> ::= 0-9; an integer in NR1 format
 <file_name> ::= quoted ASCII string

The :RECall:SETup[:START] command recalls an oscilloscope setup.

NOTE

If a file extension is provided as part of a specified <file_name>, it must be ".scp".

- See Also**
- ["Introduction to :RECall Commands"](#) on page 926
 - [":RECall:FILENAME"](#) on page 930
 - [":RECall:PWD"](#) on page 933
 - [":SAVE\[:SETup\[:START\]\]"](#) on page 968

:RECall:WMEMemory<r>[:START]

N (see [page 1730](#))

Command Syntax :RECall:WMEMemory<r>[:START] [<file_name> | <data>]
 <r> ::= 1 to (# ref waveforms) in NR1 format
 <file_name> ::= quoted ASCII string
 <data> ::= binary block data in IEEE 488.2 # format

The :RECall:WMEMemory<r>[:START] command recalls a reference waveform.

NOTE

If a file extension is provided as part of a specified <file_name>, it must be ".h5".

The <data> option lets you recall a reference waveform from a local file on the controller PC (instead of from a USB storage device connected to the oscilloscope). In this case, your remote program reads data from the local ".h5" format reference waveform file in the same way that setup files are restored to the oscilloscope (see [":SYSTEM:SETup"](#) on page 1406).

- See Also**
- ["Introduction to :RECall Commands"](#) on page 926
 - [":RECall:FILEname"](#) on page 930
 - [":SAVE:WMEMemory\[:START\]"](#) on page 975

35 :RTEYe Commands

When the jitter analysis feature is licensed, the :RTEYe commands control the real-time eye analysis feature.

An eye diagram is a view of a signal in which the waveform is triggered using its data rate. A real-time eye accomplishes this by acquiring data, performing clock recovery, then superimposing (folding) successive unit intervals within a single plot. This is a statistical view in the form of a color grade.

When real-time eye analysis is enabled, the color grade analysis feature is no longer available.

To build the real-time eye, acquisitions are performed separately, by sending the :RTEYe:ACQuire command. Successive single acquisitions are used to get the largest acquisition record possible, resulting in the most accurate clock recovery and eye measurements possible.

Mask testing and unfolding the real-time eye (features available on other Keysight oscilloscopes) are not available on this oscilloscope.

Table 125 :RTEYe Commands Summary

Command	Query	Options and Query Returns
:RTEYe:ACQuire (see page 938)	n/a	n/a
:RTEYe:SOURce <source> (see page 939)	:RTEYe:SOURce? (see page 939)	<source> ::= CHANNEL<n> <n> ::= 1 to (# analog channels) in NR1 format
:RTEYe:STATe {{0 OFF} {1 ON}} (see page 940)	:RTEYe:STATe? (see page 940)	{0 1}
n/a	:RTEYe:TUINtervals? (see page 941)	<UI_intervals> ::= total number of UI intervals folded in eye diagram in NR1 format

:RTEYe:ACQuire

N (see [page 1730](#))

Command Syntax :RTEYe:ACQuire

The :RTEYe:ACQuire command starts building the real-time eye.

When building the real-time eye, full-length acquisitions are used to get the largest acquisition record possible, resulting in the most accurate clock recovery and eye measurements possible.

- See Also**
- [":RTEYe:SOURce"](#) on page 939
 - [":RTEYe:STATe"](#) on page 940
 - [":RTEYe:TUINtervals"](#) on page 941
 - [":MEASure:RTEYe:EHEight"](#) on page 722
 - [":MEASure:RTEYe:EWIDth"](#) on page 723

:RTEYe:SOURce

N (see [page 1730](#))

Command Syntax :RTEYe:SOURce <source>

<source> ::= CHANnel<n>

<n> ::= 1 to (# analog channels) in NR1 format

The :RTEYe:SOURce command specifies the analog channel input on which to perform the real-time eye analysis.

Query Syntax :RTEYe:SOURce?

The :RTEYe:SOURce? query returns the current real-time eye analysis source.

Return Format <source><NL>

- See Also**
- [":RTEYe:ACQuire"](#) on page 938
 - [":RTEYe:STATe"](#) on page 940
 - [":RTEYe:TUINtervals"](#) on page 941

:RTEYe:STATe

N (see [page 1730](#))

Command Syntax :RTEYe:STATe {{0 | OFF} | {1 | ON}}

The :RTEYe:STATe command enables or disables the real-time eye analysis display.

Query Syntax :RTEYe:STATe?

The :RTEYe:STATe? query returns whether the real-time eye analysis is enabled.

Return Format <off_on><NL>

{0 | 1}

- See Also**
- [":RTEYe:ACQuire"](#) on page 938
 - [":RTEYe:SOURce"](#) on page 939
 - [":RTEYe:TUINtervals"](#) on page 941

:RTEYe:TUINtervals

N (see [page 1730](#))

Query Syntax :RTEYe:TUINtervals?

The :RTEYe:TUINtervals? query returns the number of UI intervals folded into the real-time eye analysis.

Return Format <UI_intervals><NL>

<UI_intervals> ::= total number of UI intervals folded in eye diagram
in NR1 format

- See Also**
- [":RTEYe:ACQuire"](#) on page 938
 - [":RTEYe:SOURce"](#) on page 939
 - [":RTEYe:STATe"](#) on page 940
 - [":MEASure:RTEYe:EHEight"](#) on page 722
 - [":MEASure:RTEYe:EWIDth"](#) on page 723

36 :SAVE Commands

Save oscilloscope setups, screen images, and data. See "[Introduction to :SAVE Commands](#)" on page 946.

Table 126 :SAVE Commands Summary

Command	Query	Options and Query Returns
:SAVE:ARBitrary:[STARt] [<file_spec>][,<wavegen_id>] (see page 947)	n/a	<file_spec> ::= {<internal_loc> <file_name>} <internal_loc> ::= 0-3; an integer in NR1 format <file_name> ::= quoted ASCII string <wavegen_id> ::= {WGEN1 WGEN2}
:SAVE:COMpliance:USB[:START] [<file_name>] (see page 948)	n/a	<file_name> ::= quoted ASCII string
:SAVE:FILEname <base_name> (see page 949)	:SAVE:FILEname? (see page 949)	<base_name> ::= quoted ASCII string
:SAVE:IMAGe[:START] [<file_name>] (see page 950)	n/a	<file_name> ::= quoted ASCII string
:SAVE:IMAGe:FACTors {{0 OFF} {1 ON}} (see page 951)	:SAVE:IMAGe:FACTors? (see page 951)	{0 1}
:SAVE:IMAGe:FORMat <format> (see page 952)	:SAVE:IMAGe:FORMat? (see page 952)	<format> ::= {{BMP BMP24bit} BMP8bit PNG NONE}
:SAVE:IMAGe:INKSaver {{0 OFF} {1 ON}} (see page 953)	:SAVE:IMAGe:INKSaver? (see page 953)	{0 1}

Table 126 :SAVE Commands Summary (continued)

Command	Query	Options and Query Returns
:SAVE:IMAGe:PALette <palette> (see page 954)	:SAVE:IMAGe:PALette? (see page 954)	<palette> ::= {COLor GRAYscale}
:SAVE:LISTer[:START] [<file_name>] (see page 955)	n/a	<file_name> ::= quoted ASCII string
:SAVE:MASK[:START] [<file_spec>] (see page 956)	n/a	<file_spec> ::= {<internal_loc> <file_name>} <internal_loc> ::= 0-3; an integer in NR1 format <file_name> ::= quoted ASCII string
:SAVE:MULTi[:START] [<file_name>] (see page 957)	n/a	<file_name> ::= quoted ASCII string
:SAVE:POWER[:START] [<file_name>] (see page 958)	n/a	<file_name> ::= quoted ASCII string
:SAVE:PWD <path_name> (see page 959)	:SAVE:PWD? (see page 959)	<path_name> ::= quoted ASCII string
:SAVE:RESUltS:[START] [<file_spec>] (see page 960)	n/a	<file_name> ::= quoted ASCII string
:SAVE:RESUltS:FORMat: CGRade {{0 OFF} {1 ON}} (see page 961)	:SAVE:RESUltS:FORMat: CGRade? (see page 961)	{0 1}
:SAVE:RESUltS:FORMat: CURSor {{0 OFF} {1 ON}} (see page 962)	:SAVE:RESUltS:FORMat: CURSor? (see page 962)	{0 1}
:SAVE:RESUltS:FORMat: HISTogram {{0 OFF} {1 ON}} (see page 963)	:SAVE:RESUltS:FORMat: HISTogram? (see page 963)	{0 1}
:SAVE:RESUltS:FORMat: MASK {{0 OFF} {1 ON}} (see page 964)	:SAVE:RESUltS:FORMat: MASK? (see page 964)	{0 1}

Table 126 :SAVE Commands Summary (continued)

Command	Query	Options and Query Returns
:SAVE:RESults:FORMat:MEASurement {{0 OFF} {1 ON}} (see page 965)	:SAVE:RESults:FORMat:MEASurement? (see page 965)	{0 1}
:SAVE:RESults:FORMat:SEARch {{0 OFF} {1 ON}} (see page 966)	:SAVE:RESults:FORMat:SEARch? (see page 966)	{0 1}
:SAVE:RESults:FORMat:SEGmented {{0 OFF} {1 ON}} (see page 967)	:SAVE:RESults:FORMat:SEGmented? (see page 967)	{0 1}
:SAVE[:SETup[:START]] [<file_spec>] (see page 968)	n/a	<file_spec> ::= {<internal_loc> <file_name>} <internal_loc> ::= 0-9; an integer in NR1 format <file_name> ::= quoted ASCII string
:SAVE:WAVEform[:START] [<file_name>] (see page 969)	n/a	<file_name> ::= quoted ASCII string
:SAVE:WAVEform:FORMat <format> (see page 970)	:SAVE:WAVEform:FORMat ? (see page 970)	<format> ::= {ASCIixy CSV BINary NONE}
:SAVE:WAVEform:LENGth <length> (see page 971)	:SAVE:WAVEform:LENGth ? (see page 971)	<length> ::= 100 to max. length; an integer in NR1 format
:SAVE:WAVEform:LENGth:MAX {{0 OFF} {1 ON}} (see page 972)	:SAVE:WAVEform:LENGth:MAX? (see page 972)	{0 1}
:SAVE:WAVEform:SEGMen ted <option> (see page 973)	:SAVE:WAVEform:SEGMen ted? (see page 973)	<option> ::= {ALL CURRent}

Table 126 :SAVE Commands Summary (continued)

Command	Query	Options and Query Returns
:SAVE:WMEemory:SOURce <source> (see page 974)	:SAVE:WMEemory:SOURce? (see page 974)	<source> ::= {CHANnel<n> FUNctIon<m> MATH<m> WMEemory<r>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format NOTE: Only ADD or SUBtract math operations can be saved as reference waveforms. <return_value> ::= <source>
:SAVE:WMEemory[:START] [<file_name>] (see page 975)	n/a	<file_name> ::= quoted ASCII string If extension included in file name, it must be ".h5".

Introduction to :SAVE Commands

The :SAVE subsystem provides commands to save oscilloscope setups, screen images, and data.

:SAV is an acceptable short form for :SAVE.

Reporting the Setup

Use :SAVE? to query setup information for the SAVE subsystem.

Return Format

The following is a sample response from the :SAVE? query. In this case, the query was issued following the *RST command.

```
:SAVE:FIL " ";:SAVE:IMAG:AREA GRAT;FACT 0;FORM TIFF;INKS 0;PAL  
MON;:SAVE:PWD "C:/setups/";:SAVE:WAV:FORM NONE;LENG 1000;SEGM CURR
```

Saving Files to a USB Storage Device

When :SAVE commands have a "quoted ASCII string" <file_name> parameter, you can save files to a connected USB storage device. For example:

```
' To save a setup file to a connected USB storage device:  
myScope.WriteString ":SAVE:SETup:START ""\usb\my_setup_file.scp""
```

:SAVE:ARbitrary[:START]

N (see [page 1730](#))

Command Syntax :SAVE:ARbitrary:[START] [<file_spec>] [, <wavegen_id>]

<file_spec> ::= {<internal_loc> | <file_name>}

<internal_loc> ::= 0-3; an integer in NR1 format

<file_name> ::= quoted ASCII string

<wavegen_id> ::= {WGEN1 | WGEN2}

The :SAVE:ARbitrary:[START] command saves the current arbitrary waveform to an internal location or a file on a USB storage device.

The <wavegen_id> parameter specifies which waveform generator to save the arbitrary waveform from.

NOTE

If a file extension is provided as part of a specified <file_name>, it must be ".csv".

- See Also**
- ["Introduction to :SAVE Commands"](#) on page 946
 - [":SAVE:FILENAME"](#) on page 949
 - [":RECall:ARbitrary\[:START\]"](#) on page 928

:SAVE:COMPLIance:USB[:START]

N (see [page 1730](#))

Command Syntax :SAVE:COMPLIance:USB[:START] [<file_name>]

<file_name> ::= quoted ASCII string

The :SAVE:COMPLIance:USB[:START] command saves USB 2.0 signal quality test results to a file.

NOTE

If a file extension is provided as part of a specified <file_name>, it must be ".html".

-
- See Also**
- ["Introduction to :SAVE Commands"](#) on page 946
 - [":SAVE:FILENAME"](#) on page 949
 - [":SAVE:PWD"](#) on page 959
 - [Chapter 14](#), "COMPLIance Commands," starting on page 389

:SAVE:FILEname

N (see [page 1730](#))

Command Syntax :SAVE:FILEname <base_name>
 <base_name> ::= quoted ASCII string

The :SAVE:FILEname command specifies the source for any SAVE operations.

NOTE

This command specifies a file's base name only, without path information or an extension.

Query Syntax :SAVE:FILEname?

The :SAVE:FILEname? query returns the current SAVE filename.

Return Format <base_name><NL>
 <base_name> ::= quoted ASCII string

- See Also**
- ["Introduction to :SAVE Commands"](#) on page 946
 - [":SAVE:IMAGe\[:START\]"](#) on page 950
 - [":SAVE\[:SETup\[:START\]\]"](#) on page 968
 - [":SAVE:WAVEform\[:START\]"](#) on page 969
 - [":SAVE:PWD"](#) on page 959
 - [":RECall:FILEname"](#) on page 930

:SAVE:IMAGe[:START]

N (see [page 1730](#))

Command Syntax :SAVE:IMAGe[:START] [<file_name>
 <file_name> ::= quoted ASCII string

The :SAVE:IMAGe[:START] command saves an image.

NOTE

Be sure to set the :SAVE:IMAGe:FORMat before saving an image. If the format is NONE, the save image command will not succeed.

NOTE

If a file extension is provided as part of a specified <file_name>, and it does not match the extension expected by the format specified in :SAVE:IMAGe:FORMat, the format will be changed if the extension is a valid image file extension.

NOTE

If the extension ".bmp" is used and the current :SAVE:IMAGe:FORMat is not BMP or BMP8, the format will be changed to BMP.

- See Also**
- ["Introduction to :SAVE Commands"](#) on page 946
 - [":SAVE:IMAGe:FACTors"](#) on page 951
 - [":SAVE:IMAGe:FORMat"](#) on page 952
 - [":SAVE:IMAGe:INKSaver"](#) on page 953
 - [":SAVE:IMAGe:PALette"](#) on page 954
 - [":SAVE:FILename"](#) on page 949

:SAVE:IMAGe:FACTors

N (see [page 1730](#))

Command Syntax :SAVE:IMAGe:FACTors <factors>
 <factors> ::= {{OFF | 0} | {ON | 1}}

The :SAVE:IMAGe:FACTors command controls whether the oscilloscope factors are output along with the image.

NOTE

Factors are written to a separate file with the same path and base name but with the ".txt" extension.

Query Syntax :SAVE:IMAGe:FACTors?

The :SAVE:IMAGe:FACTors? query returns a flag indicating whether oscilloscope factors are output along with the image.

Return Format <factors><NL>
 <factors> ::= {0 | 1}

- See Also**
- ["Introduction to :SAVE Commands"](#) on page 946
 - [":SAVE:IMAGe\[:START\]"](#) on page 950
 - [":SAVE:IMAGe:FORMat"](#) on page 952
 - [":SAVE:IMAGe:INKSaver"](#) on page 953
 - [":SAVE:IMAGe:PALette"](#) on page 954

:SAVE:IMAGe:FORMat

N (see [page 1730](#))

Command Syntax :SAVE:IMAGe:FORMat <format>

<format> ::= {{BMP | BMP24bit} | BMP8bit | PNG}

The :SAVE:IMAGe:FORMat command sets the image format type.

Query Syntax :SAVE:IMAGe:FORMat?

The :SAVE:IMAGe:FORMat? query returns the selected image format type.

Return Format <format><NL>

<format> ::= {BMP | BMP8 | PNG | NONE}

When NONE is returned, it indicates that a waveform data file format is currently selected.

- See Also**
- ["Introduction to :SAVE Commands"](#) on page 946
 - [":SAVE:IMAGe\[:START\]"](#) on page 950
 - [":SAVE:IMAGe:FACTors"](#) on page 951
 - [":SAVE:IMAGe:INKSaver"](#) on page 953
 - [":SAVE:IMAGe:PALette"](#) on page 954
 - [":SAVE:WAVEform:FORMat"](#) on page 970

:SAVE:IMAGe:INKSaver

N (see [page 1730](#))

Command Syntax :SAVE:IMAGe:INKSaver <value>

<value> ::= {{OFF | 0} | {ON | 1}}

The :SAVE:IMAGe:INKSaver command controls whether the graticule colors are inverted or not.

Query Syntax :SAVE:IMAGe:INKSaver?

The :SAVE:IMAGe:INKSaver? query returns a flag indicating whether graticule colors are inverted or not.

Return Format <value><NL>

<value> ::= {0 | 1}

- See Also**
- ["Introduction to :SAVE Commands"](#) on page 946
 - [":SAVE:IMAGe\[:START\]"](#) on page 950
 - [":SAVE:IMAGe:FACTors"](#) on page 951
 - [":SAVE:IMAGe:FORMat"](#) on page 952
 - [":SAVE:IMAGe:PALette"](#) on page 954

:SAVE:IMAGe:PALette

N (see [page 1730](#))

Command Syntax :SAVE:IMAGe:PALette <palette>

<palette> ::= {COLor | GRAYscale}

The :SAVE:IMAGe:PALette command sets the image palette color.

Query Syntax :SAVE:IMAGe:PALette?

The :SAVE:IMAGe:PALette? query returns the selected image palette color.

Return Format <palette><NL>

<palette> ::= {COL | GRAY}

- See Also**
- ["Introduction to :SAVE Commands"](#) on page 946
 - [":SAVE:IMAGe\[:START\]"](#) on page 950
 - [":SAVE:IMAGe:FACTors"](#) on page 951
 - [":SAVE:IMAGe:FORMat"](#) on page 952
 - [":SAVE:IMAGe:INKSaver"](#) on page 953

:SAVE:LISTer[:START]

N (see [page 1730](#))

Command Syntax :SAVE:LISTer[:START] [<file_name>]

<file_name> ::= quoted ASCII string

The :SAVE:LISTer[:START] command saves the Lister display data to a file.

NOTE

If a file extension is provided as part of a specified <file_name>, it must be ".csv".

-
- See Also**
- ["Introduction to :SAVE Commands"](#) on page 946
 - [":SAVE:FILENAME"](#) on page 949
 - [Chapter 26](#), "LISTer Commands," starting on page 595

:SAVE:MASK[:START]

N (see [page 1730](#))

Command Syntax :SAVE:MASK[:START] [<file_spec>]
 <file_spec> ::= {<internal_loc> | <file_name>}
 <internal_loc> ::= 0-3; an integer in NR1 format
 <file_name> ::= quoted ASCII string

The :SAVE:MASK[:START] command saves a mask.

NOTE

If a file extension is provided as part of a specified <file_name>, it must be ".msk".

- See Also**
- ["Introduction to :SAVE Commands"](#) on page 946
 - [":SAVE:FILENAME"](#) on page 949
 - [":SAVE:PWD"](#) on page 959
 - [":RECALL:MASK\[:START\]"](#) on page 932
 - [":MTEST:DATA"](#) on page 796

:SAVE:MULTi[:START]

N (see [page 1730](#))

Command Syntax :SAVE:MULTi[:START] [<file_name>]

<file_name> ::= quoted ASCII string

The :SAVE:MULTi[:START] command saves multi-channel waveform data to a file. This file can be opened by the N8900A Infiniium Offline oscilloscope analysis software.

NOTE

If a file extension is provided as part of a specified <file_name>, it must be ".h5".

-
- See Also**
- ["Introduction to :SAVE Commands"](#) on page 946
 - [":SAVE:FILENAME"](#) on page 949
 - [":SAVE:PWD"](#) on page 959

:SAVE:POWer[:START]

N (see [page 1730](#))

Command Syntax :SAVE:POWer[:START] [<file_name>]

<file_name> ::= quoted ASCII string

The :SAVE:POWer[:START] command saves the power measurement application's current harmonics analysis results to a file.

NOTE

If a file extension is provided as part of a specified <file_name>, it must be ".csv".

-
- See Also**
- ["Introduction to :SAVE Commands"](#) on page 946
 - [":SAVE:FILENAME"](#) on page 949
 - [Chapter 33](#), ":POWer Commands," starting on page 821

:SAVE:PWD

N (see [page 1730](#))

Command Syntax :SAVE:PWD <path_name>
 <path_name> ::= quoted ASCII string

The :SAVE:PWD command sets the present working directory for save operations.

NOTE

Presently, the internal "/User Files" directory you see in the oscilloscope's front panel user interface is the "\Agilent Flash" directory you see in the remote interface.

Query Syntax :SAVE:PWD?

The :SAVE:PWD? query returns the currently set working directory for save operations.

Return Format <path_name><NL>
 <path_name> ::= quoted ASCII string

- See Also**
- ["Introduction to :SAVE Commands"](#) on page 946
 - [":SAVE:FILENAME"](#) on page 949
 - [":RECALL:PWD"](#) on page 933

:SAVE:RESults:[START]

N (see [page 1730](#))

Command Syntax `:SAVE:RESults:[START] [<file_spec>]`

`<file_name> ::= quoted ASCII string`

The `:SAVE:RESults:[START]` command saves analysis results to a comma-separated values (*.csv) file on a USB storage device.

Use the `:SAVE:RESults:FORMat` commands to specify the analysis types whose results are saved to the file.

When multiple types of analysis results are selected, they are all saved to the same file and separated by a blank line.

- See Also**
- [":SAVE:RESults:FORMat:CURSor"](#) on page 962
 - [":SAVE:RESults:FORMat:MASK"](#) on page 964
 - [":SAVE:RESults:FORMat:MEASurement"](#) on page 965
 - [":SAVE:RESults:FORMat:SEARch"](#) on page 966
 - [":SAVE:RESults:FORMat:SEGmented"](#) on page 967

:SAVE:RESuLts:FORMat:CGRade

N (see [page 1730](#))

Command Syntax :SAVE:RESuLts:FORMat:CGRade {{0 | OFF} | {1 | ON}}

The :SAVE:RESuLts:FORMat:CGRade command specifies whether color grade bin counts will be included when analysis results are saved.

Analysis results are saved using the :SAVE:RESuLts:[START] command.

Other :SAVE:RESuLts:FORMat commands specify whether other types of analysis results are also saved.

When multiple types of analysis results are saved, they are all saved to the same file and separated by a blank line.

Query Syntax :SAVE:RESuLts:FORMat:CGRade?

The :SAVE:RESuLts:FORMat:CGRade? query returns whether color grade bin counts will be included when analysis results are saved.

Return Format <off_on><NL>

{0 | 1}

- See Also**
- [":SAVE:RESuLts:\[START\]"](#) on page 960
 - [":SAVE:RESuLts:FORMat:CURSor"](#) on page 962
 - [":SAVE:RESuLts:FORMat:HISTogram"](#) on page 963
 - [":SAVE:RESuLts:FORMat:MASK"](#) on page 964
 - [":SAVE:RESuLts:FORMat:MEASurement"](#) on page 965
 - [":SAVE:RESuLts:FORMat:SEARch"](#) on page 966
 - [":SAVE:RESuLts:FORMat:SEGmented"](#) on page 967

:SAVE:RESuLts:FORMat:CURSor

N (see [page 1730](#))

Command Syntax :SAVE:RESuLts:FORMat:CURSor {{0 | OFF} | {1 | ON}}

The :SAVE:RESuLts:FORMat:CURSor command specifies whether cursor values will be included when analysis results are saved.

Analysis results are saved using the :SAVE:RESuLts:[START] command.

Other :SAVE:RESuLts:FORMat commands specify whether other types of analysis results are also saved.

When multiple types of analysis results are saved, they are all saved to the same file and separated by a blank line.

Query Syntax :SAVE:RESuLts:FORMat:CURSor?

The :SAVE:RESuLts:FORMat:CURSor? query returns whether cursor values will be included when analysis results are saved.

Return Format <off_on><NL>

{0 | 1}

- See Also**
- [":SAVE:RESuLts:\[START\]"](#) on page 960
 - [":SAVE:RESuLts:FORMat:MASK"](#) on page 964
 - [":SAVE:RESuLts:FORMat:MEASurement"](#) on page 965
 - [":SAVE:RESuLts:FORMat:SEARch"](#) on page 966
 - [":SAVE:RESuLts:FORMat:SEGmented"](#) on page 967

:SAVE:RESuLts:FORMat:HISTogram

N (see [page 1730](#))

Command Syntax :SAVE:RESuLts:FORMat:HISTogram {{0 | OFF} | {1 | ON}}

The :SAVE:RESuLts:FORMat:HISTogram command specifies whether histogram statistics will be included when analysis results are saved.

Analysis results are saved using the :SAVE:RESuLts:[START] command.

Other :SAVE:RESuLts:FORMat commands specify whether other types of analysis results are also saved.

When multiple types of analysis results are saved, they are all saved to the same file and separated by a blank line.

Query Syntax :SAVE:RESuLts:FORMat:HISTogram?

The :SAVE:RESuLts:FORMat:HISTogram? query returns whether histogram statistics will be included when analysis results are saved.

Return Format <off_on><NL>

{0 | 1}

- See Also**
- [":SAVE:RESuLts:\[START\]"](#) on page 960
 - [":SAVE:RESuLts:FORMat:CGRade"](#) on page 961
 - [":SAVE:RESuLts:FORMat:CURSor"](#) on page 962
 - [":SAVE:RESuLts:FORMat:MASK"](#) on page 964
 - [":SAVE:RESuLts:FORMat:MEASurement"](#) on page 965
 - [":SAVE:RESuLts:FORMat:SEARch"](#) on page 966
 - [":SAVE:RESuLts:FORMat:SEGMented"](#) on page 967

:SAVE:RESuLts:FORMat:MASK

N (see [page 1730](#))

Command Syntax :SAVE:RESuLts:FORMat:MASK {{0 | OFF} | {1 | ON}}

The :SAVE:RESuLts:FORMat:MASK command specifies whether mask statistics will be included when analysis results are saved.

Analysis results are saved using the :SAVE:RESuLts:[START] command.

Other :SAVE:RESuLts:FORMat commands specify whether other types of analysis results are also saved.

When multiple types of analysis results are saved, they are all saved to the same file and separated by a blank line.

Query Syntax :SAVE:RESuLts:FORMat:MASK?

The :SAVE:RESuLts:FORMat:MASK? query returns whether mask statistics will be included when analysis results are saved.

Return Format <off_on><NL>

{0 | 1}

- See Also**
- [":SAVE:RESuLts:\[START\]"](#) on page 960
 - [":SAVE:RESuLts:FORMat:CURSor"](#) on page 962
 - [":SAVE:RESuLts:FORMat:MEASurement"](#) on page 965
 - [":SAVE:RESuLts:FORMat:SEARch"](#) on page 966
 - [":SAVE:RESuLts:FORMat:SEGmented"](#) on page 967

:SAVE:RESuLts:FORMat:MEASurement

N (see [page 1730](#))

Command Syntax :SAVE:RESuLts:FORMat:MEASurement {{0 | OFF} | {1 | ON}}

The :SAVE:RESuLts:FORMat:MEASurement command specifies whether measurement results will be included when analysis results are saved.

Analysis results are saved using the :SAVE:RESuLts:[START] command.

Other :SAVE:RESuLts:FORMat commands specify whether other types of analysis results are also saved.

When multiple types of analysis results are saved, they are all saved to the same file and separated by a blank line.

Query Syntax :SAVE:RESuLts:FORMat:MEASurement?

The :SAVE:RESuLts:FORMat:MEASurement? query returns whether measurement results will be included when analysis results are saved.

Return Format <off_on><NL>

{0 | 1}

- See Also**
- [":SAVE:RESuLts:\[START\]"](#) on page 960
 - [":SAVE:RESuLts:FORMat:CURSor"](#) on page 962
 - [":SAVE:RESuLts:FORMat:MASK"](#) on page 964
 - [":SAVE:RESuLts:FORMat:SEARch"](#) on page 966
 - [":SAVE:RESuLts:FORMat:SEGMENTed"](#) on page 967

:SAVE:RESuLts:FORMat:SEARch

N (see [page 1730](#))

Command Syntax :SAVE:RESuLts:FORMat:SEARch {{0 | OFF} | {1 | ON}}

The :SAVE:RESuLts:FORMat:SEARch command specifies whether found search event times will be included when analysis results are saved.

Analysis results are saved using the :SAVE:RESuLts:[START] command.

Other :SAVE:RESuLts:FORMat commands specify whether other types of analysis results are also saved.

When multiple types of analysis results are saved, they are all saved to the same file and separated by a blank line.

Query Syntax :SAVE:RESuLts:FORMat:SEARch?

The :SAVE:RESuLts:FORMat:SEARch? query returns whether found search event times will be included when analysis results are saved.

Return Format <off_on><NL>

{0 | 1}

- See Also**
- [":SAVE:RESuLts:\[START\]"](#) on page 960
 - [":SAVE:RESuLts:FORMat:CURSor"](#) on page 962
 - [":SAVE:RESuLts:FORMat:MASK"](#) on page 964
 - [":SAVE:RESuLts:FORMat:MEASurement"](#) on page 965
 - [":SAVE:RESuLts:FORMat:SEGmented"](#) on page 967

:SAVE:RESuLts:FORMat:SEGmented

N (see [page 1730](#))

Command Syntax :SAVE:RESuLts:FORMat:SEGmented {{0 | OFF} | {1 | ON}}

The :SAVE:RESuLts:FORMat:SEGmented command specifies whether segmented memory acquisition times will be included when analysis results are saved.

Analysis results are saved using the :SAVE:RESuLts:[START] command.

Other :SAVE:RESuLts:FORMat commands specify whether other types of analysis results are also saved.

When multiple types of analysis results are saved, they are all saved to the same file and separated by a blank line.

Query Syntax :SAVE:RESuLts:FORMat:SEGmented?

The :SAVE:RESuLts:FORMat:SEGmented? query returns whether segmented memory acquisition times will be included when analysis results are saved.

Return Format <off_on><NL>

{0 | 1}

- See Also**
- [":SAVE:RESuLts:\[START\]"](#) on page 960
 - [":SAVE:RESuLts:FORMat:CURSor"](#) on page 962
 - [":SAVE:RESuLts:FORMat:MASK"](#) on page 964
 - [":SAVE:RESuLts:FORMat:MEASurement"](#) on page 965
 - [":SAVE:RESuLts:FORMat:SEARch"](#) on page 966

:SAVE[:SETup[:START]]

N (see [page 1730](#))

Command Syntax :SAVE[:SETup[:START]] [<file_spec>]
 <file_spec> ::= {<internal_loc> | <file_name>}
 <internal_loc> ::= 0-9; an integer in NR1 format
 <file_name> ::= quoted ASCII string

The :SAVE[:SETup[:START]] command saves an oscilloscope setup.

NOTE

If a file extension is provided as part of a specified <file_name>, it must be ".scp".

- See Also**
- ["Introduction to :SAVE Commands"](#) on page 946
 - [":SAVE:FILENAME"](#) on page 949
 - [":SAVE:PWD"](#) on page 959
 - [":RECall:SETup\[:START\]"](#) on page 934

:SAVE:WAVEform[:START]

N (see [page 1730](#))

Command Syntax :SAVE:WAVEform[:START] [<file_name>]

<file_name> ::= quoted ASCII string

The :SAVE:WAVEform[:START] command saves oscilloscope waveform data to a file.

NOTE

Be sure to set the :SAVE:WAVEform:FORMat before saving waveform data. If the format is NONE, the save waveform command will not succeed.

NOTE

If a file extension is provided as part of a specified <file_name>, and it does not match the extension expected by the format specified in :SAVE:WAVEform:FORMat, the format will be changed if the extension is a valid waveform file extension.

- See Also**
- ["Introduction to :SAVE Commands"](#) on page 946
 - [":SAVE:WAVEform:FORMat"](#) on page 970
 - [":SAVE:WAVEform:LENGth"](#) on page 971
 - [":SAVE:FILEname"](#) on page 949
 - [":RECall:SETup\[:START\]"](#) on page 934

:SAVE:WAVEform:FORMat

N (see [page 1730](#))

Command Syntax :SAVE:WAVEform:FORMat <format>

<format> ::= {ASCIixy | CSV | BINary}

The :SAVE:WAVEform:FORMat command sets the waveform data format type:

- ASCIixy – creates comma-separated value files for each analog channel that is displayed (turned on). The proper file extension for this format is ".csv".
- CSV – creates one comma-separated value file that contains information for all analog channels that are displayed (turned on). The proper file extension for this format is ".csv".
- BINary – creates an oscilloscope binary data format file. See the *User's Guide* for a description of this format. The proper file extension for this format is ".bin".

Query Syntax :SAVE:WAVEform:FORMat?

The :SAVE:WAVEform:FORMat? query returns the selected waveform data format type.

Return Format <format><NL>

<format> ::= {ASC | CSV | BIN | NONE}

When NONE is returned, it indicates that an image file format is currently selected.

- See Also**
- ["Introduction to :SAVE Commands"](#) on page 946
 - [":SAVE:WAVEform\[:START\]"](#) on page 969
 - [":SAVE:WAVEform:LENGth"](#) on page 971
 - [":SAVE:IMAGe:FORMat"](#) on page 952

:SAVE:WAVEform:LENGth

N (see [page 1730](#))

Command Syntax :SAVE:WAVEform:LENGth <length>

<length> ::= 100 to max. length; an integer in NR1 format

When the :SAVE:WAVEform:LENGth:MAX setting is OFF, the :SAVE:WAVEform:LENGth command sets the waveform data length (that is, the number of points saved).

When the :SAVE:WAVEform:LENGth:MAX setting is ON, the :SAVE:WAVEform:LENGth setting has no effect.

Query Syntax :SAVE:WAVEform:LENGth?

The :SAVE:WAVEform:LENGth? query returns the current waveform data length setting.

Return Format <length><NL>

<length> ::= 100 to max. length; an integer in NR1 format

- See Also**
- ["Introduction to :SAVE Commands"](#) on page 946
 - [":SAVE:WAVEform:LENGth:MAX"](#) on page 972
 - [":SAVE:WAVEform\[:START\]"](#) on page 969
 - [":WAVEform:POINts"](#) on page 1526
 - [":SAVE:WAVEform:FORMat"](#) on page 970

:SAVE:WAVEform:LENGth:MAX

N (see [page 1730](#))

Command Syntax :SAVE:WAVEform:LENGth:MAX <setting>

<setting> ::= {{OFF | 0} | {ON | 1}}

The :SAVE:WAVEform:LENGth:MAX command specifies whether maximum number of waveform data points is saved.

When OFF, the :SAVE:WAVEform:LENGth command specifies the number of waveform data points saved.

Query Syntax :SAVE:WAVEform:LENGth:MAX?

The :SAVE:WAVEform:LENGth:MAX? query returns the current setting.

Return Format <setting><NL>

<setting> ::= {0 | 1}

- See Also**
- ["Introduction to :SAVE Commands"](#) on page 946
 - [":SAVE:WAVEform\[:START\]"](#) on page 969
 - [":SAVE:WAVEform:LENGth"](#) on page 971

:SAVE:WAVEform:SEGmented

N (see [page 1730](#))

Command Syntax :SAVE:WAVEform:SEGmented <option>

<option> ::= {ALL | CURRent}

When segmented memory is used for acquisitions, the :SAVE:WAVEform:SEGmented command specifies which segments are included when the waveform is saved:

- ALL – all acquired segments are saved.
- CURRent – only the currently selected segment is saved.

Query Syntax :SAVE:WAVEform:SEGmented?

The :SAVE:WAVEform:SEGmented? query returns the current segmented waveform save option setting.

Return Format <option><NL>

<option> ::= {ALL | CURR}

- See Also**
- ["Introduction to :SAVE Commands"](#) on page 946
 - [":SAVE:WAVEform\[:START\]"](#) on page 969
 - [":SAVE:WAVEform:FORMat"](#) on page 970
 - [":SAVE:WAVEform:LENGth"](#) on page 971

:SAVE:WMEMemory:SOURce

N (see [page 1730](#))

Command Syntax :SAVE:WMEMemory:SOURce <source>
 <source> ::= {CHANnel<n> | FUNction<m> | MATH<m> | WMEMemory<r>}
 <n> ::= 1 to (# analog channels) in NR1 format
 <m> ::= 1 to (# math functions) in NR1 format
 <r> ::= 1 to (# ref waveforms) in NR1 format

The :SAVE:WMEMemory:SOURce command selects the source to be saved as a reference waveform file.

NOTE

Only ADD or SUBtract math operations can be saved as reference waveforms.

NOTE

MATH is an alias for FUNction. The query will return FUNC if the source is FUNction or MATH.

Query Syntax :SAVE:WMEMemory:SOURce?

The :SAVE:WMEMemory:SOURce? query returns the source to be saved as a reference waveform file.

Return Format <source><NL>

<source> ::= {CHAN<n> | FUNC | WMEM<r> | NONE}

- See Also**
- ["Introduction to :SAVE Commands"](#) on page 946
 - [":SAVE:WMEMemory\[:START\]"](#) on page 975
 - [":RECall:WMEMemory<r>\[:START\]"](#) on page 935

:SAVE:WMEMemory[:START]

N (see [page 1730](#))

Command Syntax :SAVE:WMEMemory[:START] [<file_name>]

<file_name> ::= quoted ASCII string

The :SAVE:WMEMemory[:START] command saves oscilloscope waveform data to a reference waveform file.

NOTE

If a file extension is provided as part of a specified <file_name>, it must be ".h5".

-
- See Also**
- ["Introduction to :SAVE Commands"](#) on page 946
 - [":SAVE:WMEMemory:SOURce"](#) on page 974
 - [":RECall:WMEMemory<r>\[:START\]"](#) on page 935

37 :SBUS<n> Commands

Control the modes and parameters for each serial bus decode/trigger type. See:

- "[Introduction to :SBUS<n> Commands](#)" on page 977
- "[General :SBUS<n> Commands](#)" on page 979
- "[:SBUS<n>:A429 Commands](#)" on page 982
- "[:SBUS<n>:CAN Commands](#)" on page 1001
- "[:SBUS<n>:CXPI Commands](#)" on page 1031
- "[:SBUS<n>:FLEXray Commands](#)" on page 1048
- "[:SBUS<n>:I2S Commands](#)" on page 1067
- "[:SBUS<n>:IIC Commands](#)" on page 1086
- "[:SBUS<n>:LIN Commands](#)" on page 1097
- "[:SBUS<n>:M1553 Commands](#)" on page 1116
- "[:SBUS<n>:MANchester Commands](#)" on page 1123
- "[:SBUS<n>:NRZ Commands](#)" on page 1142
- "[:SBUS<n>:SENT Commands](#)" on page 1161
- "[:SBUS<n>:SPI Commands](#)" on page 1197
- "[:SBUS<n>:UART Commands](#)" on page 1214
- "[:SBUS<n>:USB Commands](#)" on page 1236
- "[:SBUS<n>:USBPd Commands](#)" on page 1261

Introduction to
:SBUS<n>
Commands

The :SBUS subsystem commands control the serial decode bus viewing, mode, and other options.

NOTE

These commands are only valid on oscilloscope models when a serial decode option has been licensed.

The following serial bus decode/trigger types are available (see "[:TRIGger:MODE](#)" on page 1439).

- **CAN (Controller Area Network) triggering** – will trigger on CAN version 2.0A and 2.0B signals. Setup consists of connecting the oscilloscope to a CAN signal. Baud rate, signal source, and signal polarity, and type of data to trigger on can be specified. You can trigger on CAN data and identifier patterns and you can set the bit sample point.
- **CXPI triggering** – lets you trigger on CXPI serial data.
- **I2S (Inter-IC Sound or Integrated Interchip Sound bus) triggering** – consists of connecting the oscilloscope to the serial clock, word select, and serial data lines, then triggering on a data value.
- **IIC (Inter-IC bus) triggering** – consists of connecting the oscilloscope to the serial data (SDA) line and the serial clock (SCL) line, then triggering on a stop/start condition, a restart, a missing acknowledge, or on a read/write frame with a specific device address and data value.
- **LIN (Local Interconnect Network) triggering** – will trigger on LIN sync break at the beginning of a message frame. You can trigger on Sync Break, Frame IDs, or Frame IDs and Data.
- **SPI (Serial Peripheral Interface) triggering** – consists of connecting the oscilloscope to a clock, data (MOSI or MISO), and framing signal. You can then trigger on a data pattern during a specific framing period. The serial data string can be specified to be from 4 to 64 bits long.
- **UART/RS-232 triggering** – lets you trigger on RS-232 serial data.
- **SENT triggering** – lets you trigger on SENT serial data.
- **USB 2.0 triggering** – lets you trigger on USB 2.0 serial data.
- **USB PD triggering** – lets you trigger on USB PD serial data.

NOTE

Two I2S buses or two SPI buses cannot be decoded on both SBUS1 and SBUS2 at the same time.

Reporting the Setup

Use :SBUS<n>? to query setup information for the :SBUS<n> subsystem.

Return Format

The following is a sample response from the :SBUS1? query. In this case, the query was issued following a *RST command.

```
:SBUS1:DISP 0;MODE IIC;:SBUS1:IIC:ASIZ BIT7;:SBUS1:IIC:TRIG:TYPE
STAR;QUAL EQU;:SBUS1:IIC:SOUR:CLOC CHAN1;DATA
CHAN2;:SBUS1:IIC:TRIG:PATT:ADDR -1;DATA -1;DATA2 -1
```

General :SBUS<n> Commands

Table 127 General :SBUS<n> Commands Summary

Command	Query	Options and Query Returns
:SBUS<n>:DISPlay {{0 OFF} {1 ON}} (see page 980)	:SBUS<n>:DISPlay? (see page 980)	{0 1}
:SBUS<n>:MODE <mode> (see page 981)	:SBUS<n>:MODE? (see page 981)	<mode> ::= {A429 CAN CXPI FLEXray I2S IIC LIN M1553 MANchester NRZ SENT SPI UART USB USBPd}

:SBUS<n>:DISPlay

N (see [page 1730](#))

Command Syntax :SBUS<n>:DISPlay <display>
 <display> ::= {{1 | ON} | {0 | OFF}}

The :SBUS<n>:DISPlay command turns displaying of the serial decode bus on or off.

NOTE

This command is only valid when a serial decode option has been licensed.

NOTE

Two I2S buses or two SPI buses cannot be decoded on both SBUS1 and SBUS2 at the same time.

Query Syntax :SBUS<n>:DISPlay?

The :SBUS<n>:DISPlay? query returns the current display setting of the serial decode bus.

Return Format <display><NL>
 <display> ::= {0 | 1}

Errors • ["-241, Hardware missing"](#) on page 1671

- See Also** • ["Introduction to :SBUS<n> Commands"](#) on page 977
- [":CHANnel<n>:DISPlay"](#) on page 357
 - [":DIGital<d>:DISPlay"](#) on page 423
 - [":POD<n>:DISPlay"](#) on page 817
 - [":VIEW"](#) on page 300
 - [":BLANK"](#) on page 268
 - [":STATus"](#) on page 297

:SBUS<n>:MODE

N (see [page 1730](#))

Command Syntax :SBUS<n>:MODE <mode>

<mode> ::= {A429 | FLEXray | CAN | CXPI | I2S | IIC | LIN | M1553
| MANchester | NRZ | SENT | SPI | UART | USB | USBPd}

The :SBUS<n>:MODE command determines the decode mode for the serial bus.

NOTE

This command is only valid when a serial decode option has been licensed.

Query Syntax :SBUS<n>:MODE?

The :SBUS<n>:MODE? query returns the current serial bus decode mode setting.

Return Format <mode><NL>

<mode> ::= {A429 | FLEX | CAN | CXPI | I2S | IIC | LIN | M1553 | MANC
| NRZ | SENT | SPI | UART | USB | USBP | NONE}

Errors • ["-241, Hardware missing"](#) on page 1671

- See Also**
- ["Introduction to :SBUS<n> Commands"](#) on page 977
 - [":SBUS<n>:A429 Commands"](#) on page 982
 - [":SBUS<n>:CAN Commands"](#) on page 1001
 - [":SBUS<n>:FLEXray Commands"](#) on page 1048
 - [":SBUS<n>:I2S Commands"](#) on page 1067
 - [":SBUS<n>:IIC Commands"](#) on page 1086
 - [":SBUS<n>:LIN Commands"](#) on page 1097
 - [":SBUS<n>:M1553 Commands"](#) on page 1116
 - [":SBUS<n>:SENT Commands"](#) on page 1161
 - [":SBUS<n>:SPI Commands"](#) on page 1197
 - [":SBUS<n>:UART Commands"](#) on page 1214
 - [":SBUS<n>:USB Commands"](#) on page 1236

:SBUS<n>:A429 Commands

NOTE

These commands are valid when the MIL-STD-1553 and ARINC 429 triggering and serial decode license has been enabled.

Table 128 :SBUS<n>:A429 Commands Summary

Command	Query	Options and Query Returns
:SBUS<n>:A429:AUTOset up (see page 984)	n/a	n/a
:SBUS<n>:A429:BASE <base> (see page 985)	:SBUS<n>:A429:BASE? (see page 985)	<base> ::= {BINary HEX}
:SBUS<n>:A429:BAUDrat e <baudrate> (see page 986)	:SBUS<n>:A429:BAUDrat e? (see page 986)	<baudrate> ::= integer from 10000 to 1000000
n/a	:SBUS<n>:A429:COUNT:E RRor? (see page 987)	<error_count> ::= integer in NR1 format
:SBUS<n>:A429:COUNT:R ESet (see page 988)	n/a	n/a
n/a	:SBUS<n>:A429:COUNT:W ORD? (see page 989)	<word_count> ::= integer in NR1 format
:SBUS<n>:A429:FORMat <format> (see page 990)	:SBUS<n>:A429:FORMat? (see page 990)	<format> ::= {LDSDi LDSSm LDAData}
:SBUS<n>:A429:SIGNal <signal> (see page 991)	:SBUS<n>:A429:SIGNal? (see page 991)	<signal> ::= {A B DIFFerential}
:SBUS<n>:A429:SOURce <source> (see page 992)	:SBUS<n>:A429:SOURce? (see page 992)	<source> ::= {CHANnel<n>} <n> ::= 1 to (# analog channels) in NR1 format
:SBUS<n>:A429:SPEed <speed> (see page 993)	:SBUS<n>:A429:SPEed? (see page 993)	<speed> ::= {LOW HIGH USER}

Table 128 :SBUS<n>:A429 Commands Summary (continued)

Command	Query	Options and Query Returns
:SBUS<n>:A429:TRIGger :LAbel <value> (see page 994)	:SBUS<n>:A429:TRIGger :LAbel? (see page 994)	<value> ::= 8-bit integer in decimal, <hex>, <octal>, or <string> from 0-255 or "0xXX" (don't care) <hex> ::= #Hnn where n ::= {0,...,9 A,...,F} <octal> ::= #Qnnn where n ::= {0,...,7} <string> ::= "0xnn" where n ::= {0,...,9 A,...,F}
:SBUS<n>:A429:TRIGger :PATtern:DATA <string> (see page 995)	:SBUS<n>:A429:TRIGger :PATtern:DATA? (see page 995)	<string> ::= "nn...n" where n ::= {0 1 X}, length depends on FORMat
:SBUS<n>:A429:TRIGger :PATtern:SDI <string> (see page 996)	:SBUS<n>:A429:TRIGger :PATtern:SDI? (see page 996)	<string> ::= "nn" where n ::= {0 1 X}, length always 2 bits
:SBUS<n>:A429:TRIGger :PATtern:SSM <string> (see page 997)	:SBUS<n>:A429:TRIGger :PATtern:SSM? (see page 997)	<string> ::= "nn" where n ::= {0 1 X}, length always 2 bits
:SBUS<n>:A429:TRIGger :RANGe <min>,<max> (see page 998)	:SBUS<n>:A429:TRIGger :RANGe? (see page 998)	<min> ::= 8-bit integer in decimal, <hex>, <octal>, or <string> from 0-255 <max> ::= 8-bit integer in decimal, <hex>, <octal>, or <string> from 0-255 <hex> ::= #Hnn where n ::= {0,...,9 A,...,F} <octal> ::= #Qnnn where n ::= {0,...,7} <string> ::= "0xnn" where n ::= {0,...,9 A,...,F}
:SBUS<n>:A429:TRIGger :TYpe <condition> (see page 999)	:SBUS<n>:A429:TRIGger :TYpe? (see page 999)	<condition> ::= {WSTArt WSTOp LAbel LBITs PERror WERror GERror WGERrors ALLerrors LRANGe ABITs AOBits AZBits}

:SBUS<n>:A429:AUTosetup

N (see [page 1730](#))

Command Syntax :SBUS<n>:A429:AUTosetup

The :SBUS<n>:A429:AUTosetup command automatically sets these options for decoding and triggering on ARINC 429 signals:

- High Trigger Threshold: 3.0 V.
- Low Trigger Threshold: -3.0 V.
- Noise Reject: Off.
- Probe Attenuation: 10.0.
- Vertical Scale: 4 V/div.
- Serial Decode: On.
- Base (:SBUS<n>:A429:BASE): HEX.
- Word Format (:SBUS<n>:A429:FORMat): LDSDi (Label/SDI/Data/SSM).
- Trigger: the specified serial bus (n of SBUS<n>).
- Trigger Mode (:SBUS<n>:A429:TRIGger:TYPE): WStArt.

Errors • ["-241, Hardware missing"](#) on page 1671

- See Also**
- [":SBUS<n>:A429:BASE"](#) on page 985
 - [":SBUS<n>:A429:FORMat"](#) on page 990
 - [":SBUS<n>:A429:TRIGger:TYPE"](#) on page 999
 - ["Introduction to :SBUS<n> Commands"](#) on page 977
 - [":SBUS<n>:MODE"](#) on page 981
 - [":SBUS<n>:A429 Commands"](#) on page 982

:SBUS<n>:A429:BASE

N (see [page 1730](#))

Command Syntax :SBUS<n>:A429:BASE <base>

<base> ::= {BINary | HEX}

The :SBUS<n>:A429:BASE command selects between hexadecimal and binary display of the decoded data.

The BASE command has no effect on the SDI and SSM fields, which are always displayed in binary, nor the Label field, which is always displayed in octal.

Query Syntax :SBUS<n>:A429:BASE?

The :SBUS<n>:A429:BASE? query returns the current ARINC 429 base setting.

Return Format <base><NL>

<base> ::= {BIN | HEX}

Errors • ["-241, Hardware missing"](#) on page 1671

See Also • ["Introduction to :SBUS<n> Commands"](#) on page 977

• [":SBUS<n>:MODE"](#) on page 981

• [":SBUS<n>:A429:FORMat"](#) on page 990

:SBUS<n>:A429:BAUDrate

N (see [page 1730](#))

Command Syntax :SBUS<n>:A429:BAUDrate <baudrate>

<baudrate> ::= integer from 10000 to 1000000

When a user-defined baud rate is selected (with the ":SBUS<n>:A429:SPeEd USER" command), the :SBUS<n>:A429:BAUDrate command specifies the user-defined baud rate. The baud rate can be set in 100 b/s increments between 10000 and 100000 and in 1000 b/s increments between 100000 and 1000000.

Query Syntax :SBUS<n>:A429:BAUDrate?

The :SBUS<n>:A429:BAUDrate? query returns the user-defined baud rate setting.

Return Format <baudrate><NL>

See Also • [":SBUS<n>:A429:SPeEd"](#) on page 993

:SBUS<n>:A429:COUNT:ERRor

N (see [page 1730](#))

Query Syntax :SBUS<n>:A429:COUNT:ERRor?

Returns the error count.

Return Format <error_count><NL>

<error_count> ::= integer in NR1 format

Errors • ["-241, Hardware missing"](#) on page 1671

- See Also** • [":SBUS<n>:A429:COUNT:RESet"](#) on page 988
- [":SBUS<n>:A429:COUNT:WORD"](#) on page 989
 - ["Introduction to :SBUS<n> Commands"](#) on page 977
 - [":SBUS<n>:MODE"](#) on page 981
 - [":SBUS<n>:A429 Commands"](#) on page 982

:SBUS<n>:A429:COUNT:RESet

N (see [page 1730](#))

Command Syntax :SBUS<n>:A429:COUNT:RESet

Resets the word and error counters.

- Errors**
- ["-241, Hardware missing"](#) on page 1671
- See Also**
- [":SBUS<n>:A429:COUNT:WORD"](#) on page 989
 - [":SBUS<n>:A429:COUNT:ERRor"](#) on page 987
 - ["Introduction to :SBUS<n> Commands"](#) on page 977
 - [":SBUS<n>:MODE"](#) on page 981
 - [":SBUS<n>:A429 Commands"](#) on page 982

:SBUS<n>:A429:COUNT:WORD

N (see [page 1730](#))

Query Syntax :SBUS<n>:A429:COUNT:WORD?

Returns the word count.

Return Format <word_count><NL>

<word_count> ::= integer in NR1 format

Errors • ["-241, Hardware missing"](#) on page 1671

- See Also**
- [":SBUS<n>:A429:COUNT:RESet"](#) on page 988
 - [":SBUS<n>:A429:COUNT:ERRor"](#) on page 987
 - ["Introduction to :SBUS<n> Commands"](#) on page 977
 - [":SBUS<n>:MODE"](#) on page 981
 - [":SBUS<n>:A429 Commands"](#) on page 982

:SBUS<n>:A429:FORMat

N (see [page 1730](#))

Command Syntax :SBUS<n>:A429:FORMat <format>

<format> ::= {LDSDi | LDSSm | LDATa}

The :SBUS<n>:A429:FORMat command specifies the word decode format:

- LDSDi:
 - Label - 8 bits.
 - SDI - 2 bits.
 - Data - 19 bits.
 - SSM - 2 bits.
- LDSSm:
 - Label - 8 bits.
 - Data - 21 bits.
 - SSM - 2 bits.
- LDATa:
 - Label - 8 bits.
 - Data - 23 bits.

Query Syntax :SBUS<n>:A429:FORMat?

The :SBUS<n>:A429:FORMat? query returns the current ARINC 429 word decode format setting.

Return Format <format><NL>

<format> ::= {LDSD | LDSS | LDAT}

Errors • ["-241, Hardware missing"](#) on page 1671

- See Also**
- ["Introduction to :SBUS<n> Commands"](#) on page 977
 - [":SBUS<n>:MODE"](#) on page 981
 - [":SBUS<n>:A429:TRIGger:PATtern:DATA"](#) on page 995
 - [":SBUS<n>:A429:TRIGger:PATtern:SDI"](#) on page 996
 - [":SBUS<n>:A429:TRIGger:PATtern:SSM"](#) on page 997
 - [":SBUS<n>:A429:TRIGger:TYPE"](#) on page 999
 - [":SBUS<n>:A429:SIGNal"](#) on page 991
 - [":SBUS<n>:A429:SPEed"](#) on page 993
 - [":SBUS<n>:A429:BASE"](#) on page 985
 - [":SBUS<n>:A429:SOURce"](#) on page 992

:SBUS<n>:A429:SIGNal

N (see [page 1730](#))

Command Syntax :SBUS<n>:A429:SIGNal <signal>

<signal> ::= {A | B | DIFFerential}

The :SBUS<n>:A429:SIGNal command specifies the signal type:

- A – Line A (non-inverted).
- B – Line B (inverted).
- DIFFerential – Differential (A-B).

Query Syntax :SBUS<n>:A429:SIGNal?

The :SBUS<n>:A429:SIGNal? query returns the current ARINC 429 signal type setting.

Return Format <signal><NL>

<signal> ::= {A | B | DIFF}

Errors • ["-241, Hardware missing"](#) on page 1671

See Also • ["Introduction to :SBUS<n> Commands"](#) on page 977

- [":SBUS<n>:MODE"](#) on page 981
- [":SBUS<n>:A429:FORMat"](#) on page 990
- [":SBUS<n>:A429:SPEed"](#) on page 993
- [":SBUS<n>:A429:SOURce"](#) on page 992

:SBUS<n>:A429:SOURce

N (see [page 1730](#))

Command Syntax :SBUS<n>:A429:SOURce <source>

<source> ::= {CHANnel<n>}

<n> ::= 1 to (# analog channels) in NR1 format

The :SBUS<n>:A429:SOURce command sets the source of the ARINC 429 signal.

Query Syntax :SBUS<n>:A429:SOURce?

The :SBUS<n>:A429:SOURce? query returns the currently set source of the ARINC 429 signal.

Use the :TRIGger:LEVel:HIGH and :TRIGger:LEVel:LOW commands to set the threshold levels for the selected source.

Return Format <source><NL>

- See Also**
- [":TRIGger:LEVel:HIGH"](#) on page 1437
 - [":TRIGger:LEVel:LOW"](#) on page 1438
 - [":TRIGger:MODE"](#) on page 1439
 - [":SBUS<n>:MODE"](#) on page 981
 - [":SBUS<n>:A429:TRIGger:TYPE"](#) on page 999
 - [":SBUS<n>:A429:SIGNal"](#) on page 991
 - [":SBUS<n>:A429:SPEed"](#) on page 993
 - [":SBUS<n>:A429:FORMat"](#) on page 990
 - ["Introduction to :TRIGger Commands"](#) on page 1425

:SBUS<n>:A429:SPeEd

N (see [page 1730](#))

Command Syntax :SBUS<n>:A429:SPeEd <speed>
 <speed> ::= {LOW | HIGH | USER}

The :SBUS<n>:A429:SPeEd command specifies the signal speed:

- LOW – 12.5 kb/s.
- HIGH – 100 kb/s.
- USER – lets you specify a user-defined baud rate using the :SBUS<n>:A429:BAUDRate command.

Query Syntax :SBUS<n>:A429:SPeEd?

The :SBUS<n>:A429:SPeEd? query returns the current ARINC 429 signal speed setting.

Return Format <speed><NL>
 <speed> ::= {LOW | HIGH | USER}

Errors • ["-241, Hardware missing"](#) on page 1671

- See Also**
- [":SBUS<n>:A429:BAUDRate"](#) on page 986
 - ["Introduction to :SBUS<n> Commands"](#) on page 977
 - [":SBUS<n>:MODE"](#) on page 981
 - [":SBUS<n>:A429:SIGNal"](#) on page 991
 - [":SBUS<n>:A429:FORMat"](#) on page 990
 - [":SBUS<n>:A429:SOURce"](#) on page 992

:SBUS<n>:A429:TRIGger:LABel

N (see [page 1730](#))

Command Syntax :SBUS<n>:A429:TRIGger:LABel <value>

<value> ::= 8-bit integer in decimal, <hex>, <octal>, or <string>
from 0-255 or "0xXX" (don't care)

<hex> ::= #Hnn where n ::= {0,...,9 | A,...,F}

<octal> ::= #Qnnn where n ::= {0,...,7}

<string> ::= "0xnn" where n ::= {0,...,9 | A,...,F}

The :SBUS<n>:A429:TRIGger:LABel command defines the ARINC 429 label value when labels are used in the selected trigger type.

To set the label value to don't cares (0xXX), set the value to -1.

Query Syntax :SBUS<n>:A429:TRIGger:LABel?

The :SBUS<n>:A429:TRIGger:LABel? query returns the current label value in decimal format.

Return Format <value><NL> in decimal format

Errors · ["-241, Hardware missing"](#) on page 1671

See Also · ["Introduction to :TRIGger Commands"](#) on page 1425
· [":SBUS<n>:A429:TRIGger:TYPE"](#) on page 999

:SBUS<n>:A429:TRIGger:PATtern:DATA

N (see [page 1730](#))

Command Syntax :SBUS<n>:A429:TRIGger:PATtern:DATA <string>

<string> ::= "nn...n" where n ::= {0 | 1 | X}, length depends on FORMat

The :SBUS<n>:A429:TRIGger:PATtern:DATA command defines the ARINC 429 data pattern resource according to the string parameter. This pattern controls the data pattern searched for in each ARINC 429 word.

NOTE

If more bits are sent for <string> than specified by the :SBUS<n>:A429:FORMat command, the most significant bits will be truncated.

Query Syntax :SBUS<n>:A429:TRIGger:PATtern:DATA?

The :SBUS<n>:A429:TRIGger:PATtern:DATA? query returns the current settings of the specified ARINC 429 data pattern resource in the binary string format.

Return Format <string><NL> in nondecimal format

Errors · ["-241, Hardware missing"](#) on page 1671

See Also · ["Introduction to :TRIGger Commands"](#) on page 1425
 · [":SBUS<n>:A429:TRIGger:TYPE"](#) on page 999
 · [":SBUS<n>:A429:TRIGger:PATtern:SDI"](#) on page 996
 · [":SBUS<n>:A429:TRIGger:PATtern:SSM"](#) on page 997

:SBUS<n>:A429:TRIGger:PATtern:SDI

N (see [page 1730](#))

Command Syntax :SBUS<n>:A429:TRIGger:PATtern:SDI <string>

<string> ::= "nn" where n ::= {0 | 1 | X}, length always 2 bits

The :SBUS<n>:A429:TRIGger:PATtern:SDI command defines the ARINC 429 two-bit SDI pattern resource according to the string parameter. This pattern controls the SDI pattern searched for in each ARINC 429 word.

The specified SDI is only used if the :SBUS<n>:A429:FORMat includes the SDI field.

Query Syntax :SBUS<n>:A429:TRIGger:PATtern:SDI?

The :SBUS<n>:A429:TRIGger:PATtern:SDI? query returns the current settings of the specified ARINC 429 two-bit SDI pattern resource in the binary string format.

Return Format <string><NL> in nondecimal format

Errors • ["-241, Hardware missing"](#) on page 1671

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":SBUS<n>:A429:FORMat"](#) on page 990
 - [":SBUS<n>:A429:TRIGger:TYPE"](#) on page 999
 - [":SBUS<n>:A429:TRIGger:PATtern:DATA"](#) on page 995
 - [":SBUS<n>:A429:TRIGger:PATtern:SSM"](#) on page 997

:SBUS<n>:A429:TRIGger:PATtern:SSM

N (see [page 1730](#))

Command Syntax :SBUS<n>:A429:TRIGger:PATtern:SSM <string>

<string> ::= "nn" where n ::= {0 | 1 | X}, length always 2 bits

The :SBUS<n>:A429:TRIGger:PATtern:SSM command defines the ARINC 429 two-bit SSM pattern resource according to the string parameter. This pattern controls the SSM pattern searched for in each ARINC 429 word.

The specified SSM is only used if the :SBUS<n>:A429:FORMat includes the SSM field.

Query Syntax :SBUS<n>:A429:TRIGger:PATtern:SSM?

The :SBUS<n>:A429:TRIGger:PATtern:SSM? query returns the current settings of the specified ARINC 429 two-bit SSM pattern resource in the binary string format.

Return Format <string><NL> in nondecimal format

Errors • ["-241, Hardware missing"](#) on page 1671

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":SBUS<n>:A429:FORMat"](#) on page 990
 - [":SBUS<n>:A429:TRIGger:TYPE"](#) on page 999
 - [":SBUS<n>:A429:TRIGger:PATtern:DATA"](#) on page 995
 - [":SBUS<n>:A429:TRIGger:PATtern:SDI"](#) on page 996

:SBUS<n>:A429:TRIGger:RANGe

N (see [page 1730](#))

Command Syntax :SBUS<n>:A429:TRIGger:RANGe <min>,<max>

<min> ::= 8-bit integer in decimal, <hex>, <octal>, or <string>
from 0-255

<max> ::= 8-bit integer in decimal, <hex>, <octal>, or <string>
from 0-255

<hex> ::= #Hnn where n ::= {0,...,9 | A,...,F}

<octal> ::= #Qnnn where n ::= {0,...,7}

<string> ::= "0xnn" where n ::= {0,...,9 | A,...,F}

The :SBUS<n>:A429:TRIGger:RANGe command defines a range of ARINC 429 label values. This range is used when the LRANGe trigger type is selected.

Query Syntax :SBUS<n>:A429:TRIGger:RANGe?

The :SBUS<n>:A429:TRIGger:RANGe? query returns the current label values in decimal format.

Return Format <min>,<max><NL> in decimal format

Errors · ["-241, Hardware missing"](#) on page 1671

See Also · ["Introduction to :TRIGger Commands"](#) on page 1425

· [":SBUS<n>:A429:TRIGger:TYPE"](#) on page 999

:SBUS<n>:A429:TRIGger:TYPE

N (see [page 1730](#))

Command Syntax :SBUS<n>:A429:TRIGger:TYPE <condition>

```
<condition> ::= {WSTArt | WSTOp | LABel | LBITs | PERRor | WERRor
                | GERRor | WGERrors | ALLerrors | LRANge | ABITs
                | AOBits | AZBits}
```

The :SBUS<n>:A429:TRIGger command sets the ARINC 429 trigger on condition:

- WSTArt – triggers on the start of a word.
- WSTOp – triggers at the end of a word.
- LABel – triggers on the specified label value.
- LBITs – triggers on the label and the other word fields as specified.
- LRANge – triggers on a label within a min/max range.
- PERRor – triggers on words with a parity error.
- WERRor – triggers on an intra-word coding error.
- GERRor – triggers on an inter-word gap error.
- WGERrors – triggers on either a Word or Gap Error.
- ALLerrors – triggers on any of the above errors.
- ABITs – triggers on any bit, which will therefore form an eye diagram.
- AZBits – triggers on any bit with a value of zero.
- AOBits – triggers on any bit with a value of one.

Query Syntax :SBUS<n>:A429:TRIGger:TYPE?

The :SBUS<n>:A429:TRIGger:TYPE? query returns the current ARINC 429 trigger on condition.

Return Format <condition><NL>

```
<condition> ::= {WSTA | WSTO | LAB | LBIT | PERR | WERR | GERR | WGER
                | ALL | LRAN | ABIT | AOB | AZB}
```

Errors • ["-241, Hardware missing"](#) on page 1671

- See Also**
- ["Introduction to :SBUS<n> Commands"](#) on page 977
 - [":SBUS<n>:MODE"](#) on page 981
 - [":SBUS<n>:A429:TRIGger:LABel"](#) on page 994
 - [":SBUS<n>:A429:TRIGger:PATtern:DATA"](#) on page 995
 - [":SBUS<n>:A429:TRIGger:PATtern:SDI"](#) on page 996
 - [":SBUS<n>:A429:TRIGger:PATtern:SSM"](#) on page 997
 - [":SBUS<n>:A429:TRIGger:RANGe"](#) on page 998

- [":SBUS<n>:A429:SOURce"](#) on page 992

:SBUS<n>:CAN Commands

NOTE

These commands are valid when the CAN and LIN serial decode license has been enabled.

Table 129 :SBUS<n>:CAN Commands Summary

Command	Query	Options and Query Returns
n/a	:SBUS<n>:CAN:COUNT:ERror? (see page 1004)	<frame_count> ::= integer in NR1 format
n/a	:SBUS<n>:CAN:COUNT:OVERload? (see page 1005)	<frame_count> ::= 0 in NR1 format
:SBUS<n>:CAN:COUNT:RESet (see page 1006)	n/a	n/a
n/a	:SBUS<n>:CAN:COUNT:SPECerror? (see page 1007)	<spec_error_count> ::= integer in NR1 format
n/a	:SBUS<n>:CAN:COUNT:TOTAL? (see page 1008)	<frame_count> ::= integer in NR1 format
n/a	:SBUS<n>:CAN:COUNT:UTILization? (see page 1009)	<percent> ::= floating-point in NR3 format
:SBUS<n>:CAN:DISPlay <type> (see page 1010)	:SBUS<n>:CAN:DISPlay? (see page 1010)	<type> ::= {HEXadecimal SYMBOLic}
:SBUS<n>:CAN:FDSPoint <value> (see page 1011)	:SBUS<n>:CAN:FDSPoint? (see page 1011)	<value> ::= even numbered percentages from 30 to 90 in NR3 format.
:SBUS<n>:CAN:FDSTandard <std> (see page 1012)	:SBUS<n>:CAN:FDSTandard? (see page 1012)	<std> ::= {ISO NISO}
:SBUS<n>:CAN:SAMPLEpoint <percent> (see page 1013)	:SBUS<n>:CAN:SAMPLEpoint? (see page 1013)	<percent> ::= 30.0 to 90.0 in NR3 format
:SBUS<n>:CAN:SIGNAL:BAUDrate <baudrate> (see page 1014)	:SBUS<n>:CAN:SIGNAL:BAUDrate? (see page 1014)	<baudrate> ::= integer from 10000 to 4000000 in 100 b/s increments, or 5000000
:SBUS<n>:CAN:SIGNAL:DEFinition <value> (see page 1015)	:SBUS<n>:CAN:SIGNAL:DEFinition? (see page 1015)	<value> ::= {CANH CANL RX TX DIFFerential DIFL DIFH}

Table 129 :SBUS<n>:CAN Commands Summary (continued)

Command	Query	Options and Query Returns
:SBUS<n>:CAN:SIGNal:F DBaudrate <baudrate> (see page 1016)	:SBUS<n>:CAN:SIGNal:F DBaudrate? (see page 1016)	<baudrate> ::= integer from 10000 to 10000000 in 100 b/s increments.
:SBUS<n>:CAN:SOURce <source> (see page 1017)	:SBUS<n>:CAN:SOURce? (see page 1017)	<source> ::= {CHANnel<n> EXTernal} for DSO models <source> ::= {CHANnel<n> DIGital<d> } for MSO models <n> ::= 1 to (# analog channels) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format
:SBUS<n>:CAN:TRIGger <condition> (see page 1018)	:SBUS<n>:CAN:TRIGger? (see page 1019)	<condition> ::= {SOF EOF IDData DATA FDData IDRemote IDEither ERRor ACKerror FORMerror STUFFerror CRCerror SPECerror ALLerrors BRsBit CRCDbit EBActive EBPAssive OVERload MESSage MSIGNal FDMSignal}
:SBUS<n>:CAN:TRIGger: IDFilter {{0 OFF} {1 ON}} (see page 1021)	:SBUS<n>:CAN:TRIGger: IDFilter? (see page 1021)	{0 1}
:SBUS<n>:CAN:TRIGger: PATTern:DATA <string> (see page 1022)	:SBUS<n>:CAN:TRIGger: PATTern:DATA? (see page 1022)	<string> ::= "nn...n" where n ::= {0 1 X \$} <string ::= "0xnn...n" where n ::= {0,...,9 A,...,F X \$}
:SBUS<n>:CAN:TRIGger: PATTern:DATA:DLC <dlc> (see page 1023)	:SBUS<n>:CAN:TRIGger: PATTern:DATA:DLC? (see page 1023)	<dlc> ::= integer between -1 (don't care) and 64, in NR1 format.
:SBUS<n>:CAN:TRIGger: PATTern:DATA:LENGth <length> (see page 1024)	:SBUS<n>:CAN:TRIGger: PATTern:DATA:LENGth? (see page 1024)	<length> ::= integer from 1 to 8 in NR1 format
:SBUS<n>:CAN:TRIGger: PATTern:DATA:START <start> (see page 1025)	:SBUS<n>:CAN:TRIGger: PATTern:DATA:START? (see page 1025)	<start> ::= integer between 0 and 63, in NR1 format.

Table 129 :SBUS<n>:CAN Commands Summary (continued)

Command	Query	Options and Query Returns
:SBUS<n>:CAN:TRIGger: PATtern:ID <string> (see page 1026)	:SBUS<n>:CAN:TRIGger: PATtern:ID? (see page 1026)	<string> ::= "nn...n" where n ::= {0 1 X \$} <string ::= "0xnn...n" where n ::= {0,...,9 A,...,F X \$}
:SBUS<n>:CAN:TRIGger: PATtern:ID:MODE <value> (see page 1027)	:SBUS<n>:CAN:TRIGger: PATtern:ID:MODE? (see page 1027)	<value> ::= {STANdard EXTended}
:SBUS<n>:CAN:TRIGger: SYMBolic:MESSAge <name> (see page 1028)	:SBUS<n>:CAN:TRIGger: SYMBolic:MESSAge? (see page 1028)	<name> ::= quoted ASCII string
:SBUS<n>:CAN:TRIGger: SYMBolic:SIGNal <name> (see page 1029)	:SBUS<n>:CAN:TRIGger: SYMBolic:SIGNal? (see page 1029)	<name> ::= quoted ASCII string
:SBUS<n>:CAN:TRIGger: SYMBolic:VALue <data> (see page 1030)	:SBUS<n>:CAN:TRIGger: SYMBolic:VALue? (see page 1030)	<data> ::= value in NR3 format

:SBUS<n>:CAN:COUNT:ERRor

N (see [page 1730](#))

Query Syntax :SBUS<n>:CAN:COUNT:ERRor?

Returns the error frame count.

Return Format <frame_count><NL>

<frame_count> ::= integer in NR1 format

Errors • ["-241, Hardware missing"](#) on page 1671

- See Also**
- [":SBUS<n>:CAN:COUNT:RESet"](#) on page 1006
 - ["Introduction to :SBUS<n> Commands"](#) on page 977
 - [":SBUS<n>:MODE"](#) on page 981
 - [":SBUS<n>:CAN Commands"](#) on page 1001

:SBUS<n>:CAN:COUNT:OVERload

N (see [page 1730](#))

Query Syntax :SBUS<n>:CAN:COUNT:OVERload?

Returns the overload frame count.

Return Format <frame_count><NL>

<frame_count> ::= 0 in NR1 format

Errors • ["-241, Hardware missing"](#) on page 1671

- See Also**
- [":SBUS<n>:CAN:COUNT:RESet"](#) on page 1006
 - ["Introduction to :SBUS<n> Commands"](#) on page 977
 - [":SBUS<n>:MODE"](#) on page 981
 - [":SBUS<n>:CAN Commands"](#) on page 1001

:SBUS<n>:CAN:COUNT:RESet

N (see [page 1730](#))

Command Syntax :SBUS<n>:CAN:COUNT:RESet

Resets the frame counters.

Errors · ["-241, Hardware missing"](#) on page 1671

- See Also** · [":SBUS<n>:CAN:COUNT:ERRor"](#) on page 1004
- [":SBUS<n>:CAN:COUNT:OVERload"](#) on page 1005
 - [":SBUS<n>:CAN:COUNT:TOTal"](#) on page 1008
 - [":SBUS<n>:CAN:COUNT:UTILization"](#) on page 1009
 - ["Introduction to :SBUS<n> Commands"](#) on page 977
 - [":SBUS<n>:MODE"](#) on page 981
 - [":SBUS<n>:CAN Commands"](#) on page 1001

:SBUS<n>:CAN:COUNT:SPEC

N (see [page 1730](#))

Query Syntax :SBUS<n>:CAN:COUNT:SPEC?

Returns the Spec error (Ack + Form + Stuff + CRC errors) count.

Return Format <spec_error_count><NL>

<spec_error_count> ::= integer in NR1 format

Errors • ["-241, Hardware missing"](#) on page 1671

- See Also**
- [":SBUS<n>:CAN:COUNT:RESet"](#) on page 1006
 - ["Introduction to :SBUS<n> Commands"](#) on page 977
 - [":SBUS<n>:MODE"](#) on page 981
 - [":SBUS<n>:CAN Commands"](#) on page 1001

:SBUS<n>:CAN:COUNT:TOTAL

N (see [page 1730](#))

Query Syntax :SBUS<n>:CAN:COUNT:TOTAL?

Returns the total frame count.

Return Format <frame_count><NL>

<frame_count> ::= integer in NR1 format

Errors • ["-241, Hardware missing"](#) on page 1671

- See Also**
- [":SBUS<n>:CAN:COUNT:RESet"](#) on page 1006
 - ["Introduction to :SBUS<n> Commands"](#) on page 977
 - [":SBUS<n>:MODE"](#) on page 981
 - [":SBUS<n>:CAN Commands"](#) on page 1001

:SBUS<n>:CAN:COUNT:UTILization

N (see [page 1730](#))

Query Syntax :SBUS<n>:CAN:COUNT:UTILization?

Returns the percent utilization.

Return Format <percent><NL>

<percent> ::= floating-point in NR3 format

Errors • ["-241, Hardware missing"](#) on page 1671

- See Also**
- [":SBUS<n>:CAN:COUNT:RESet"](#) on page 1006
 - ["Introduction to :SBUS<n> Commands"](#) on page 977
 - [":SBUS<n>:MODE"](#) on page 981
 - [":SBUS<n>:CAN Commands"](#) on page 1001

:SBUS<n>:CAN:DISPlay

N (see [page 1730](#))

Command Syntax :SBUS<n>:CAN:DISPlay <type>

<type> ::= {HEXadecimal | SYMBolic}

The :SBUS<n>:CAN:DISPlay command specifies, when CAN symbolic data is loaded into the oscilloscope, whether symbolic values (from the DBC file) or hexadecimal values are displayed in the decode waveform and the Lister window.

Query Syntax :SBUS<n>:CAN:DISPlay?

The :SBUS<n>:CAN:DISPlay? query returns the CAN decode display type.

Return Format <type><NL>

<type> ::= {HEX | SYMB}

See Also • [":RECall:DBC\[:START\]"](#) on page 929

:SBUS<n>:CAN:FDSPoint

N (see [page 1730](#))

Command Syntax :SBUS<n>:CAN:FDSPoint <value>

<value> ::= even numbered percentages from 30 to 90 in NR3 format.

The :SBUS<n>:CAN:FDSPoint command sets the point during the bit time where the bit level is sampled to determine whether the bit is dominant or recessive. The sample point represents the percentage of time between the beginning of the bit time to the end of the bit time.

Query Syntax :SBUS<n>:CAN:FDSPoint?

The :SBUS<n>:CAN:FDSPoint? query returns the current CAN FD sample point setting.

Return Format <value><NL>

<value> ::= even numbered percentages from 30 to 90 in NR3 format.

See Also • [":SBUS<n>:CAN:SIGNal:FDbaudrate"](#) on page 1016

:SBUS<n>:CAN:FDStandard

N (see [page 1730](#))

Command Syntax :SBUS<n>:CAN:FDStandard <std>

<std> ::= {ISO | NISO}

The :SBUS<n>:CAN:FDStandard command lets you pick the standard that will be used when decoding or triggering on FD frames, ISO, or non-ISO.

This setting has no effect on the processing of non-FD (classical) frames.

Query Syntax :SBUS<n>:CAN:FDStandard?

The :SBUS<n>:CAN:FDStandard? query returns the selected CAN FD frame decode standard.

Return Format <std><NL>

<std> ::= {ISO | NISO}

See Also • [":SBUS<n>:CAN:FDSPoint"](#) on page 1011

:SBUS<n>:CAN:SAMPLepoint

N (see [page 1730](#))

Command Syntax :SBUS<n>:CAN:SAMPLepoint <percent>

<percent><NL>

<percent> ::= 30.0 to 90.0 in NR3 format

The :SBUS<n>:CAN:SAMPLepoint command sets the point during the bit time where the bit level is sampled to determine whether the bit is dominant or recessive. The sample point represents the percentage of time between the beginning of the bit time to the end of the bit time.

Query Syntax :SBUS<n>:CAN:SAMPLepoint?

The :SBUS<n>:CAN:SAMPLepoint? query returns the current CAN sample point setting.

Return Format <percent><NL>

<percent> ::= 30.0 to 90.0 in NR3 format

- See Also**
- ["Introduction to TRIGger Commands"](#) on page 1425
 - [":SBUS<n>:MODE"](#) on page 981
 - [":SBUS<n>:CAN:TRIGger"](#) on page 1018

:SBUS<n>:CAN:SIGNal:BAUDrate

N (see [page 1730](#))

Command Syntax :SBUS<n>:CAN:SIGNal:BAUDrate <baudrate>

<baudrate> ::= integer from 10000 to 4000000 in 100 b/s increments,
or 5000000

The :SBUS<n>:CAN:SIGNal:BAUDrate command sets the standard baud rate of the CAN signal from 10 kb/s to 4 Mb/s in 100 b/s increments. If you enter a baud rate that is not divisible by 100 b/s, the baud rate is set to the nearest baud rate divisible by 100 b/s.

You can also set the baud rate of the CAN signal to 5 Mb/s. Fractional baud rates between 4 Mb/s and 5 Mb/s are not allowed.

If the baud rate you select does not match the system baud rate, false triggers may occur.

Query Syntax :SBUS<n>:CAN:SIGNal:BAUDrate?

The :SBUS<n>:CAN:SIGNal:BAUDrate? query returns the current CAN baud rate setting.

Return Format <baudrate><NL>

<baudrate> ::= integer from 10000 to 4000000 in 100 b/s increments,
or 5000000

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":SBUS<n>:MODE"](#) on page 981
 - [":SBUS<n>:CAN:TRIGger"](#) on page 1018
 - [":SBUS<n>:CAN:SIGNal:DEFinition"](#) on page 1015
 - [":SBUS<n>:CAN:SOURce"](#) on page 1017

:SBUS<n>:CAN:SIGNal:DEFinition

N (see [page 1730](#))

Command Syntax :SBUS<n>:CAN:SIGNal:DEFinition <value>

<value> ::= {CANH | CANL | RX | TX | DIFFerential | DIFL | DIFH}

The :SBUS<n>:CAN:SIGNal:DEFinition command sets the CAN signal type when :SBUS<n>:CAN:TRIGger is set to SOF (start of frame). These signals can be set to:

Dominant high signals:

- CANH – the actual CAN_H differential bus signal.
- DIFH – the CAN differential (H-L) bus signal connected to an analog source channel using a differential probe.

Dominant low signals:

- CANL – the actual CAN_L differential bus signal.
- RX – the Receive signal from the CAN bus transceiver.
- TX – the Transmit signal to the CAN bus transceiver.
- DIFL – the CAN differential (L-H) bus signal connected to an analog source channel using a differential probe.
- DIFFerential – the CAN differential bus signal connected to an analog source channel using a differential probe. This is the same as DIFL.

Query Syntax :SBUS<n>:CAN:SIGNal:DEFinition?

The :SBUS<n>:CAN:SIGNal:DEFinition? query returns the current CAN signal type.

Return Format <value><NL>

<value> ::= {CANH | CANL | RX | TX | DIFL | DIFH}

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":SBUS<n>:MODE"](#) on page 981
 - [":SBUS<n>:CAN:SIGNal:BAUDrate"](#) on page 1014
 - [":SBUS<n>:CAN:SOURce"](#) on page 1017
 - [":SBUS<n>:CAN:TRIGger"](#) on page 1018

:SBUS<n>:CAN:SIGNal:FDBaudrate

N (see [page 1730](#))

Command Syntax :SBUS<n>:CAN:SIGNal:FDBaudrate <baudrate>

<baudrate> ::= integer from 10000 to 10000000 in 100 b/s increments.

The :SBUS<n>:CAN:SIGNal:FDBaudrate command sets the CAN FD baud rate from 10 kb/s to 10 Mb/s in 100 b/s increments. If you enter a baud rate that is not divisible by 100 b/s, the baud rate is set to the nearest baud rate divisible by 100 b/s.

For CAN FD, both the standard rate settings (see :SBUS<n>:CAN:SIGNal:BAUDrate) and the FD rate settings must be set correctly; otherwise, false triggers may occur.

Query Syntax :SBUS<n>:CAN:SIGNal:FDBaudrate?

The :SBUS<n>:CAN:SIGNal:FDBaudrate? query returns the current CAN FD baud rate setting.

Return Format <baudrate><NL>

<baudrate> ::= integer from 10000 to 10000000 in 100 b/s increments.

- See Also**
- [":SBUS<n>:CAN:FDSPoint"](#) on page 1011
 - [":SBUS<n>:CAN:SIGNal:BAUDrate"](#) on page 1014

:SBUS<n>:CAN:SOURce

N (see [page 1730](#))

Command Syntax :SBUS<n>:CAN:SOURce <source>

<source> ::= {CHANnel<n> | EXTernal} for the DSO models

<source> ::= {CHANnel<n> | DIGital<d>} for the MSO models

<n> ::= 1 to (# analog channels) in NR1 format

<d> ::= 0 to (# digital channels - 1) in NR1 format

The :SBUS<n>:CAN:SOURce command sets the source for the CAN signal.

Query Syntax :SBUS<n>:CAN:SOURce?

The :SBUS<n>:CAN:SOURce? query returns the current source for the CAN signal.

Return Format <source><NL>

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":SBUS<n>:MODE"](#) on page 981
 - [":SBUS<n>:CAN:TRIGger"](#) on page 1018
 - [":SBUS<n>:CAN:SIGNAL:DEFinition"](#) on page 1015

:SBUS<n>:CAN:TRIGger

N (see [page 1730](#))

Command Syntax :SBUS<n>:CAN:TRIGger <condition>

```
<condition> ::= {SOF | EOF | IDData | DATA | FDData | IDRemote
  | IDEither | ERRor | ACKerror | FORMerror | STUFFerror | CRCerror
  | SPECerror | ALLerrors | BRsBit | CRCDbit | EBActive | EBPassive
  | OVERload | MESSage | MSIGnal | FDMSignal}
```

The :SBUS<n>:CAN:TRIGger command sets the CAN trigger on condition:

Condition	Front-panel name	Description	Filter by ID*
SOF	SOF - Start of Frame	Triggers at the start bit for both data and overload frames.	
EOF	EOF - End of Frame	Triggers at the end of any frame.	X
IDEither	Frame ID	Triggers on any standard CAN (data or remote) or CAN FD frame at the end of the 11- or 29-bit ID field.	
IDData	Data Frame ID (non-FD)	Triggers on standard CAN data frames at the end of the 11- or 29-bit ID field.	
DATA	Data Frame ID and Data (non-FD)	Triggers on any standard CAN data frame at the end of the last data byte defined in the trigger. The DLC of the packet must match the number of bytes specified.	
FDData	Data Frame ID and Data (FD)	triggers on CAN FD frames at the end of the last data byte defined in the trigger. You can trigger on up to 8 bytes of data anywhere within the CAN FD data, which can be up to 64 bytes long.	
IDRemote	Remote Frame ID	Triggers on standard CAN remote frames at the end of the 11- or 29-bit ID field.	
ERRor	Error Frame	Triggers after 6 consecutive 0s while in a data frame, at the EOF.	X
ACKerror	Acknowledge Error	Triggers on the acknowledge bit if the polarity is incorrect.	X
FORMerror	Form Error	Triggers on reserved bit errors.	X
STUFFerror	Stuff Error	Triggers on 6 consecutive 1s or 6 consecutive 0s, while in a non-error or non overload frame.	X

Condition	Front-panel name	Description	Filter by ID*
CRCError	CRC Field Error	Triggers when the calculated CRC does not match the transmitted CRC. In addition, for FD frames, will also trigger if the Stuff Count is in error.	X
SPECError	Spec Error (Ack or Form or Stuff or CRC)	Triggers on Ack, Form, Stuff, or CRC errors.	X
ALLerrors	All Errors	Triggers on all Spec errors and error frames.	X
BRSBit	BRS Bit (FD)	Triggers on the BRS bit of CAN FD frames.	X
CRCDbit	CRC Delimiter Bit (FD)	Triggers on the CRC delimiter bit in CAN FD frames.	X
EBAActive	ESI Bit Active (FD)	Triggers on the ESI bit if set active.	X
EBPassive	ESI Bit Passive (FD)	Triggers on the ESI bit if set passive.	X
OVERload	Overload Frame	Triggers on an overload frame.	
MESSage	Message	Triggers on a symbolic message.	
MSIGnal	Message and Signal (non-FD)	Triggers on a symbolic message and a signal value.	
FDMSignal	Message and Signal (FD, first 8 bytes only)	Triggers on a symbolic message and a signal value, limited to the first 8 bytes of FD data.	
* Filtering by CAN IDs is available for these trigger conditions (see :SBUS<n>:CAN:TRIGger:IDFilter).			

CAN Id specification is set by the :SBUS<n>:CAN:TRIGger:PATtern:ID and :SBUS<n>:CAN:TRIGger:PATtern:ID:MODE commands.

CAN Data specification is set by the :SBUS<n>:CAN:TRIGger:PATtern:DATA command.

CAN Data Length Code is set by the :SBUS<n>:CAN:TRIGger:PATtern:DATA:LENGth command.

Query Syntax :SBUS<n>:CAN:TRIGger?

The :SBUS<n>:CAN:TRIGger? query returns the current CAN trigger on condition.

Return Format <condition><NL>

```
<condition> ::= {SOF | EOF | IDD | DATA | FDD | IDR | IDE | ERR | ACK
  | FORM | STUF | CRC | SPEC | ALL | BR SB | CRCD | EBA | EBP | OVER
  | MESS | MSIG | FDMS}
```

Errors • **"-241, Hardware missing"** on page 1671

See Also • **"Introduction to :SBUS<n> Commands"** on page 977

- **":SBUS<n>:MODE"** on page 981
- **":SBUS<n>:CAN:TRIGger:PATtern:DATA"** on page 1022
- **":SBUS<n>:CAN:TRIGger:PATtern:DATA:LENGth"** on page 1024
- **":SBUS<n>:CAN:TRIGger:PATtern:ID"** on page 1026
- **":SBUS<n>:CAN:TRIGger:PATtern:ID:MODE"** on page 1027
- **":SBUS<n>:CAN:TRIGger:IDFilter"** on page 1021
- **":SBUS<n>:CAN:SIGNal:DEFinition"** on page 1015
- **":SBUS<n>:CAN:SOURce"** on page 1017
- **":RECall:DBC[:STARt]"** on page 929
- **":SBUS<n>:CAN:TRIGger:SYMBolic:MESSage"** on page 1028
- **":SBUS<n>:CAN:TRIGger:SYMBolic:SIGNal"** on page 1029
- **":SBUS<n>:CAN:TRIGger:SYMBolic:VALue"** on page 1030

:SBUS<n>:CAN:TRIGger:IDFilter

N (see [page 1730](#))

Command Syntax :SBUS<n>:CAN:TRIGger:IDFilter {{0 | OFF} | {1 | ON}}

The :SBUS<n>:CAN:TRIGger:IDFilter command specifies, in certain error and bit trigger modes, whether triggers are filtered by CAN IDs.

Query Syntax :SBUS<n>:CAN:TRIGger:IDFilter?

The :SBUS<n>:CAN:TRIGger:IDFilter? query returns the CAN trigger ID filter setting.

Return Format <setting><NL>
<setting> ::= {0 | 1}

See Also • [":SBUS<n>:CAN:TRIGger"](#) on page 1018

:SBUS<n>:CAN:TRIGger:PATtern:DATA

N (see [page 1730](#))

Command Syntax :SBUS<n>:CAN:TRIGger:PATtern:DATA <string>

<string> ::= "nn...n" where n ::= {0 | 1 | X | \$}

<string ::= "0xnn...n" where n ::= {0,...,9 | A,...,F | X | \$}

The :SBUS<n>:CAN:TRIGger:PATtern:DATA command defines the CAN data pattern resource according to the string parameter. This pattern, along with the data length (set by the :SBUS<n>:CAN:TRIGger:PATtern:DATA:LENGth command), control the data pattern searched for in each CAN message.

If the string parameter starts with "0x", it is a hexadecimal string made up of hexadecimal and X (don't care) characters; otherwise, it is a binary string made up of 0, 1, and X (don't care) characters.

NOTE

If more bits are sent for <string> than specified by the :SBUS<n>:CAN:TRIGger:PATtern:DATA:LENGth command, the most significant bits will be truncated. If the data length is changed after the <string> is programmed, the added or deleted bits will be added to or deleted from the least significant bits.

Query Syntax :SBUS<n>:CAN:TRIGger:PATtern:DATA?

The :SBUS<n>:CAN:TRIGger:PATtern:DATA? query returns the current settings of the specified CAN data pattern resource in the binary string format.

Return Format <string><NL> in nondecimal format

Errors • ["-241, Hardware missing"](#) on page 1671

See Also • ["Introduction to :TRIGger Commands"](#) on page 1425
 • [":SBUS<n>:CAN:TRIGger:PATtern:DATA:LENGth"](#) on page 1024
 • [":SBUS<n>:CAN:TRIGger:PATtern:ID"](#) on page 1026

:SBUS<n>:CAN:TRIGger:PATtern:DATA:DLC

N (see [page 1730](#))

Command Syntax :SBUS<n>:CAN:TRIGger:PATtern:DATA:DLC <dlc>

<dlc> ::= integer between -1 (don't care) and 64, in NR1 format.

The :SBUS<n>:CAN:TRIGger:PATtern:DATA:DLC command specifies the DLC value to be used in the CAN FD data trigger mode. A specific valid FD value can be specified, or -1 can be specified to indicate "don't care".

Query Syntax :SBUS<n>:CAN:TRIGger:PATtern:DATA:START?

The :SBUS<n>:CAN:TRIGger:PATtern:DATA:DLC? query returns the currently set DLC value.

Return Format <dlc><NL>

<dlc> ::= integer between -1 (don't care) and 64, in NR1 format.

See Also • [":SBUS<n>:CAN:TRIGger:PATtern:DATA"](#) on page 1022

:SBUS<n>:CAN:TRIGger:PATtern:DATA:LENGth

N (see [page 1730](#))

Command Syntax :SBUS<n>:CAN:TRIGger:PATtern:DATA:LENGth <length>

<length> ::= integer from 1 to 8 in NR1 format

The :SBUS<n>:CAN:TRIGger:PATtern:DATA:LENGth command sets the number of 8-bit bytes in the CAN data string. The number of bytes in the string can be anywhere from 1 bytes to 8 bytes (64 bits). The value for these bytes is set by the :SBUS<n>:CAN:TRIGger:PATtern:DATA command.

Query Syntax :SBUS<n>:CAN:TRIGger:PATtern:DATA:LENGth?

The :SBUS<n>:CAN:TRIGger:PATtern:DATA:LENGth? query returns the current CAN data pattern length setting.

Return Format <count><NL>

<count> ::= integer from 1 to 8 in NR1 format

Errors • ["-241, Hardware missing"](#) on page 1671

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":SBUS<n>:CAN:TRIGger:PATtern:DATA"](#) on page 1022
 - [":SBUS<n>:CAN:SOURce"](#) on page 1017

:SBUS<n>:CAN:TRIGger:PATtern:DATA:START

N (see [page 1730](#))

Command Syntax :SBUS<n>:CAN:TRIGger:PATtern:DATA:START <start>

<start> ::= integer between 0 and 63, in NR1 format.

The :SBUS<n>:CAN:TRIGger:PATtern:DATA:START command specifies the starting byte position for CAN FD data triggers.

CAN FD frames can have up to 64 bytes of data. You can trigger on up to 8 bytes of data. The starting byte position setting lets you trigger on data anywhere within the frame.

Query Syntax :SBUS<n>:CAN:TRIGger:PATtern:DATA:START?

The :SBUS<n>:CAN:TRIGger:PATtern:DATA:START? query returns the starting byte position setting.

Return Format <start><NL>

<start> ::= integer between 0 and 63, in NR1 format.

- See Also**
- [":SBUS<n>:CAN:TRIGger:PATtern:DATA"](#) on page 1022
 - [":SBUS<n>:CAN:TRIGger:PATtern:DATA:LENGth"](#) on page 1024

:SBUS<n>:CAN:TRIGger:PATtern:ID

N (see [page 1730](#))

Command Syntax :SBUS<n>:CAN:TRIGger:PATtern:ID <string>

<string> ::= "nn...n" where n ::= {0 | 1 | X | \$}

<string ::= "0xnn...n" where n ::= {0,...,9 | A,...,F | X | \$}

The :SBUS<n>:CAN:TRIGger:PATtern:ID command defines the CAN identifier pattern resource according to the string parameter. This pattern, along with the identifier mode (set by the :SBUS<n>:CAN:TRIGger:PATtern:ID:MODE command), control the identifier pattern searched for in each CAN message.

If the string parameter starts with "0x", it is a hexadecimal string made up of hexadecimal and X (don't care) characters; otherwise, it is a binary string made up of 0, 1, and X (don't care) characters.

NOTE

The ID pattern resource string is always 29 bits. Only 11 of these bits are used when the :SBUS<n>:CAN:TRIGger:PATtern:ID:MODE is STANdard.

A string longer than 29 bits is truncated to 29 bits when setting the ID pattern resource.

Query Syntax :SBUS<n>:CAN:TRIGger:PATtern:ID?

The :SBUS<n>:CAN:TRIGger:PATtern:ID? query returns the current settings of the specified CAN identifier pattern resource in the 29-bit binary string format.

Return Format <string><NL> in 29-bit binary string format

Errors • ["-241, Hardware missing"](#) on page 1671

See Also • ["Introduction to :TRIGger Commands"](#) on page 1425
 • [":SBUS<n>:CAN:TRIGger:PATtern:ID:MODE"](#) on page 1027
 • [":SBUS<n>:CAN:TRIGger:PATtern:DATA"](#) on page 1022

:SBUS<n>:CAN:TRIGger:PATtern:ID:MODE

N (see [page 1730](#))

Command Syntax :SBUS<n>:CAN:TRIGger:PATtern:ID:MODE <value>

<value> ::= {STANdard | EXTended}

The :SBUS<n>:CAN:TRIGger:PATtern:ID:MODE command sets the CAN identifier mode. STANdard selects the standard 11-bit identifier. EXTended selects the extended 29-bit identifier. The CAN identifier is set by the :SBUS<n>:CAN:TRIGger:PATtern:ID command.

Query Syntax :SBUS<n>:CAN:TRIGger:PATtern:ID:MODE?

The :SBUS<n>:CAN:TRIGger:PATtern:ID:MODE? query returns the current setting of the CAN identifier mode.

Return Format <value><NL>

<value> ::= {STAN | EXT}

Errors • ["-241, Hardware missing"](#) on page 1671

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":SBUS<n>:MODE"](#) on page 981
 - [":SBUS<n>:CAN:TRIGger:PATtern:DATA"](#) on page 1022
 - [":SBUS<n>:CAN:TRIGger:PATtern:DATA:LENGth"](#) on page 1024
 - [":SBUS<n>:CAN:TRIGger:PATtern:ID"](#) on page 1026

:SBUS<n>:CAN:TRIGger:SYMBolic:MESSage

N (see [page 1730](#))

Command Syntax :SBUS<n>:CAN:TRIGger:SYMBolic:MESSage <name>

<name> ::= quoted ASCII string

The :SBUS<n>:CAN:TRIGger:SYMBolic:MESSage command specifies the message to trigger on when CAN symbolic data has been loaded (recalled) into the oscilloscope and the CAN trigger mode is set to MESSage or MSIGnal.

Query Syntax :SBUS<n>:CAN:TRIGger:SYMBolic:MESSage?

The :SBUS<n>:CAN:TRIGger:SYMBolic:MESSage? query returns the specified message.

Return Format <name><NL>

<name> ::= quoted ASCII string

- See Also**
- [":RECall:DBC\[:START\]"](#) on page 929
 - [":SBUS<n>:CAN:TRIGger"](#) on page 1018
 - [":SBUS<n>:CAN:TRIGger:SYMBolic:SIGNal"](#) on page 1029
 - [":SBUS<n>:CAN:TRIGger:SYMBolic:VALue"](#) on page 1030

:SBUS<n>:CAN:TRIGger:SYMBolic:SIGNal

N (see [page 1730](#))

Command Syntax :SBUS<n>:CAN:TRIGger:SYMBolic:SIGNal <name>

<name> ::= quoted ASCII string

The :SBUS<n>:CAN:TRIGger:SYMBolic:SIGNal command specifies the signal to trigger on when CAN symbolic data has been loaded (recalled) into the oscilloscope and the CAN trigger mode is set to MSIGNAL.

Query Syntax :SBUS<n>:CAN:TRIGger:SYMBolic:SIGNal?

The :SBUS<n>:CAN:TRIGger:SYMBolic:SIGNal? query returns the specified signal.

Return Format <name><NL>

<name> ::= quoted ASCII string

- See Also**
- [":RECall:DBC\[:START\]"](#) on page 929
 - [":SBUS<n>:CAN:TRIGger"](#) on page 1018
 - [":SBUS<n>:CAN:TRIGger:SYMBolic:MESSAge"](#) on page 1028
 - [":SBUS<n>:CAN:TRIGger:SYMBolic:VALue"](#) on page 1030

:SBUS<n>:CAN:TRIGger:SYMBolic:VALue

N (see [page 1730](#))

Command Syntax :SBUS<n>:CAN:TRIGger:SYMBolic:VALue <data>

<data> ::= value in NR3 format

The :SBUS<n>:CAN:TRIGger:SYMBolic:VALue command specifies the signal value to trigger on when CAN symbolic data has been loaded (recalled) into the oscilloscope and the CAN trigger mode is set to MSIGNAL.

NOTE

Encoded signal values are not supported in the remote interface (even though they can be used in the front panel graphical interface).

Query Syntax :SBUS<n>:CAN:TRIGger:SYMBolic:VALue?

The :SBUS<n>:CAN:TRIGger:SYMBolic:VALue? query returns the specified signal value.

Return Format <data><NL>

<data> ::= value in NR3 format

- See Also**
- [":RECall:DBC\[:START\]"](#) on page 929
 - [":SBUS<n>:CAN:TRIGger"](#) on page 1018
 - [":SBUS<n>:CAN:TRIGger:SYMBolic:MESSAge"](#) on page 1028
 - [":SBUS<n>:CAN:TRIGger:SYMBolic:SIGNal"](#) on page 1029

:SBUS<n>:CXPI Commands

NOTE

These commands are valid when the CXPI (Clock Extension Peripheral Interface) serial decode and triggering option has been licensed.

Table 130 :SBUS<n>:CXPI Commands Summary

Command	Query	Options and Query Returns
:SBUS<n>:CXPI:BAUDrate <baudrate> (see page 1033)	:SBUS<n>:CXPI:BAUDrate? (see page 1033)	<baudrate> ::= integer from 9600 to 40000 in 100 b/s increments.
:SBUS<n>:CXPI:PARity {{0 OFF} {1 ON}} (see page 1034)	:SBUS<n>:CXPI:PARity? (see page 1034)	{0 1}
:SBUS<n>:CXPI:SOURce <source> (see page 1035)	:SBUS<n>:CXPI:SOURce? (see page 1035)	<source> ::= {CHANnel<n>} <n> ::= 1 to (# analog channels) in NR1 format
:SBUS<n>:CXPI:TOLerance <percent> (see page 1036)	:SBUS<n>:CXPI:TOLerance? (see page 1036)	<percent> ::= from 1-30, in NR1 format.
:SBUS<n>:CXPI:TRIGger <mode> (see page 1037)	:SBUS<n>:CXPI:TRIGger? (see page 1038)	<mode> ::= {SOF EOF PTYPE ID DATA LDATa CRCerror PARityerror IBSError IFSerror FRAMingerror DLENgtherror SAMPlerror ALLerrors SLEepframe WAKEuppulse}
:SBUS<n>:CXPI:TRIGger:IDFilter {{0 OFF} {1 ON}} (see page 1039)	:SBUS<n>:CXPI:TRIGger:IDFilter? (see page 1039)	{0 1}
:SBUS<n>:CXPI:TRIGger:PTYPE {{0 OFF} {1 ON}} (see page 1040)	:SBUS<n>:CXPI:TRIGger:PTYPE? (see page 1040)	{0 1}
:SBUS<n>:CXPI:TRIGger:PATtern:DATA <string> (see page 1041)	:SBUS<n>:CXPI:TRIGger:PATtern:DATA? (see page 1041)	<string> ::= "nn...n" where n ::= {0 1 X} <string> ::= "0xnn...n" where n ::= {0,...,9 A,...,F X}
:SBUS<n>:CXPI:TRIGger:PATtern:DATA:LENGth <length> (see page 1042)	:SBUS<n>:CXPI:TRIGger:PATtern:DATA:LENGth? (see page 1042)	<start> ::= integer between 0 and 12, in NR1 format.

Table 130 :SBUS<n>:CXPI Commands Summary (continued)

Command	Query	Options and Query Returns
:SBUS<n>:CXPI:TRIGger :PATtern:DATA:START <start> (see page 1043)	:SBUS<n>:CXPI:TRIGger :PATtern:DATA:START? (see page 1043)	<start> ::= integer between 0 and 124, in NR1 format.
:SBUS<n>:CXPI:TRIGger :PATtern:ID <string> (see page 1044)	:SBUS<n>:CXPI:TRIGger :PATtern:ID? (see page 1044)	<string> ::= "nn...n" where n ::= {0 1 X} <string> ::= "0xnn...n" where n ::= {0,...,9 A,...,F X}
:SBUS<n>:CXPI:TRIGger :PATtern:INFO:CT <string> (see page 1045)	:SBUS<n>:CXPI:TRIGger :PATtern:INFO:CT? (see page 1045)	<string> ::= "nn" where n ::= {0 1 X}
:SBUS<n>:CXPI:TRIGger :PATtern:INFO:DLC <dlc> (see page 1046)	:SBUS<n>:CXPI:TRIGger :PATtern:INFO:DLC? (see page 1046)	<dlc> ::= integer between -1 (don't care) and 15, in NR1 format, when trigger is in DATA mode. <dlc> ::= integer between -1 (don't care) and 255, in NR1 format, when trigger is in LDATA mode.
:SBUS<n>:CXPI:TRIGger :PATtern:INFO:NM <string> (see page 1047)	:SBUS<n>:CXPI:TRIGger :PATtern:INFO:NM? (see page 1047)	<string> ::= "nn" where n ::= {0 1 X}

:SBUS<n>:CXPI:BAUDrate

N (see [page 1730](#))

Command Syntax :SBUS<n>:CXPI:BAUDrate <baudrate>

<baudrate> ::= integer from 9600 to 40000 in 100 b/s increments.

The :SBUS<n>:CXPI:BAUDrate command specifies the baud rate of the CXPI signal from your device under test.

The CXPI baud rate can be set from 9600 b/s to 40000 b/s in 100 b/s increments.

You must set the baud rate to match your device under test.

The default baud rate is 20 kb/s.

Query Syntax :SBUS<n>:CXPI:BAUDrate?

The :SBUS<n>:CXPI:BAUDrate? query returns the baud rate setting.

Return Format <baudrate><NL>

<baudrate> ::= integer from 9600 to 40000 in 100 b/s increments.

- See Also**
- [":SBUS<n>:CXPI:PARity"](#) on page 1034
 - [":SBUS<n>:CXPI:SOURce"](#) on page 1035
 - [":SBUS<n>:CXPI:TOLerance"](#) on page 1036
 - [":SBUS<n>:CXPI:TRIGger"](#) on page 1037

:SBUS<n>:CXPI:PARity

N (see [page 1730](#))

Command Syntax :SBUS<n>:CXPI:PARity {{0 | OFF} | {1 | ON}}

The :SBUS<n>:CXPI:PARity command specifies whether the parity bit should be displayed in the identifier field.

When OFF, the upper bit is masked. The parity is still checked, but it is not displayed unless a parity error occurs.

Query Syntax :SBUS<n>:CXPI:PARity?

The :SBUS<n>:CXPI:PARity? query returns the parity display setting.

Return Format <setting><NL>

<setting> ::= {0 | 1}

- See Also**
- [":SBUS<n>:CXPI:BAUDrate"](#) on page 1033
 - [":SBUS<n>:CXPI:SOURce"](#) on page 1035
 - [":SBUS<n>:CXPI:TOLerance"](#) on page 1036
 - [":SBUS<n>:CXPI:TRIGger"](#) on page 1037

:SBUS<n>:CXPI:SOURce

N (see [page 1730](#))

Command Syntax :SBUS<n>:CXPI:SOURce <source>

<source> ::= {CHANnel<n>}

<n> ::= 1 to (# analog channels) in NR1 format

The :SBUS<n>:CXPI:SOURce command selects the oscilloscope channel connected to the CXPI signal line.

Query Syntax :SBUS<n>:CXPI:SOURce?

The :SBUS<n>:CXPI:SOURce? query returns the selected oscilloscope channel source.

Return Format <source><NL>

<source> ::= {CHAN<n>}

- See Also**
- [":SBUS<n>:CXPI:BAUDrate"](#) on page 1033
 - [":SBUS<n>:CXPI:PARity"](#) on page 1034
 - [":SBUS<n>:CXPI:TOLerance"](#) on page 1036
 - [":SBUS<n>:CXPI:TRIGger"](#) on page 1037

:SBUS<n>:CXPI:TOLerance

N (see [page 1730](#))

Command Syntax :SBUS<n>:CXPI:TOLerance <percent>

<percent> ::= from 1-30, in NR1 format.

The :SBUS<n>:CXPI:TOLerance command specifies the tolerance as a percentage of the Tbit width.

Query Syntax :SBUS<n>:CXPI:TOLerance?

The :SBUS<n>:CXPI:TOLerance? query returns the tolerance setting.

Return Format <percent><NL>

<percent> ::= from 1-30, in NR1 format.

- See Also**
- [":SBUS<n>:CXPI:BAUDrate"](#) on page 1033
 - [":SBUS<n>:CXPI:PARity"](#) on page 1034
 - [":SBUS<n>:CXPI:SOURce"](#) on page 1035
 - [":SBUS<n>:CXPI:TRIGger"](#) on page 1037

:SBUS<n>:CXPI:TRIGger

N (see [page 1730](#))

Command Syntax :SBUS<n>:CXPI:TRIGger <mode>

```
<mode> ::= {SOF | EOF | PTYPe | ID | DATA | LDATa | CRCerror
            | PARityerror | IBSerror | IFSerror | FRAMingerror | DLENgtherror
            | SAMPlerror | ALLerrors | SLEepframe | WAKEuppulse}
```

The :SBUS<n>:CXPI:TRIGger command selects the CXPI trigger type:

- SOF – (Start of Frame) triggers at the start bit of any frame.
- EOF – (End of Frame) triggers at the end of any frame.
- PTYPe – triggers on any frame that starts with the special PTYPE byte.
 PTYPE frames begins with an extra PID byte with a Frame ID of 0000000b (reserved for only PTYPE frames). The PTYPE PID byte is then followed by a regular PID byte and the rest of the normal frame. The extra PTYPE byte is never included in the CRC calculation.
- ID – (Frame ID) triggers on a user-defined Frame ID at the end of the PID byte. The Frame ID value is user-defined, 7 bits, and has bitwise don't-cares. You can specify whether to trigger on PTYPE present or no PTYPE present.
- DATA – (Frame ID, Info and Data) triggers on CXPI frames at the end of the last data byte defined in the trigger. In addition to the PID value, you can specify the contents of the Frame Info byte with bitwise don't-cares. You can specify up to 12 data bytes on which to trigger with bitwise don't-cares.
- LDATa – (Frame ID, Info and Data (Long Frame)) triggers on CXPI frames at the end of the last data byte defined in the trigger. The standard DLC field will be locked to 1111b. You can specify up to 12 bytes of data on which to trigger and specify the start byte number as an offset. The offset can be up to 255.
- CRCerror – (CRC Field Error) triggers when the calculated CRC does not match the transmitted CRC. You can optionally filter by Frame ID and PTYPE as in the Frame ID trigger.
- PARityerror – triggers when the parity bit in the PID or PTYPE field is not correct.
- IBSerror – (Inter-Byte Space Error) triggers when there are more than 9 bits between consecutive bytes in a frame. You can optionally filter by Frame ID and PTYPE as in the Frame ID trigger.
- IFSerror – (Inter-Frame Space Error) triggers when there are fewer than 10 idle bits before a new frame begins.
- FRAMingerror – triggers when the stop bit of a byte is not logical 1. You can optionally filter by Frame ID and PTYPE as in the Frame ID trigger.

- **DLENgtherror** – (Data Length Error) triggers when there are more data bytes in a frame than is indicated by the DLC or Extended DLC field. You can optionally filter by Frame ID and PTYPE as in the Frame ID trigger.
- **SAMPlerror** – triggers when 10 consecutive logical 0s are detected.
- **ALLerrors** – triggers on all CRC, Parity, IBS, Stop Bit, Data Length, and Sample errors.
- **SLEepframe** – triggers when a normal frame is transmitted matching the definition of a sleep frame in the CXPI specification.
- **WAKEuppulse** – triggers when a wakeup pulse is detected.

Query Syntax :SBUS<n>:CXPI:TRIGger?

The :SBUS<n>:CXPI:TRIGger? query returns the CXPI trigger type setting.

Return Format <mode><NL>

```
<mode> ::= {SOF | EOF | PTYP | ID | DATA | LDAT | CRC | PAR | IBS
           | IFS | FRAM | DLEN | SAMP | ALL | SLE | WAK}
```

- See Also**
- **":SBUS<n>:CXPI:BAUDRate"** on page 1033
 - **":SBUS<n>:CXPI:PARity"** on page 1034
 - **":SBUS<n>:CXPI:SOURce"** on page 1035
 - **":SBUS<n>:CXPI:TOLerance"** on page 1036
 - **":SBUS<n>:CXPI:TRIGger:IDFilter"** on page 1039
 - **":SBUS<n>:CXPI:TRIGger:PTYPE"** on page 1040
 - **":SBUS<n>:CXPI:TRIGger:PATTern:DATA"** on page 1041
 - **":SBUS<n>:CXPI:TRIGger:PATTern:DATA:LENGth"** on page 1042
 - **":SBUS<n>:CXPI:TRIGger:PATTern:DATA:START"** on page 1043
 - **":SBUS<n>:CXPI:TRIGger:PATTern:ID"** on page 1044
 - **":SBUS<n>:CXPI:TRIGger:PATTern:INFO:CT"** on page 1045
 - **":SBUS<n>:CXPI:TRIGger:PATTern:INFO:DLC"** on page 1046
 - **":SBUS<n>:CXPI:TRIGger:PATTern:INFO:NM"** on page 1047

:SBUS<n>:CXPI:TRIGger:IDFilter

N (see [page 1730](#))

Command Syntax :SBUS<n>:CXPI:TRIGger:IDFilter {{0 | OFF} | {1 | ON}}

When triggering on CRC Field Errors, Inter-Byte Space Errors, Framing Errors, or Data Length Errors, the :SBUS<n>:CXPI:TRIGger:IDFilter command lets you enable/disable modification of the trigger so that it occurs only for a specified ID.

Query Syntax :SBUS<n>:CXPI:TRIGger:IDFilter?

The :SBUS<n>:CXPI:TRIGger:IDFilter? query returns the ID filter setting.

Return Format <setting><NL>
<setting> ::= {0 | 1}

- See Also**
- [":SBUS<n>:CXPI:TRIGger"](#) on page 1037
 - [":SBUS<n>:CXPI:TRIGger:PTYPe"](#) on page 1040
 - [":SBUS<n>:CXPI:TRIGger:PATTern:DATA"](#) on page 1041
 - [":SBUS<n>:CXPI:TRIGger:PATTern:DATA:LENGth"](#) on page 1042
 - [":SBUS<n>:CXPI:TRIGger:PATTern:DATA:START"](#) on page 1043
 - [":SBUS<n>:CXPI:TRIGger:PATTern:ID"](#) on page 1044
 - [":SBUS<n>:CXPI:TRIGger:PATTern:INFO:CT"](#) on page 1045
 - [":SBUS<n>:CXPI:TRIGger:PATTern:INFO:DLC"](#) on page 1046
 - [":SBUS<n>:CXPI:TRIGger:PATTern:INFO:NM"](#) on page 1047

:SBUS<n>:CXPI:TRIGger:PTYPE

N (see [page 1730](#))

Command Syntax :SBUS<n>:CXPI:TRIGger:PTYPE {{0 | OFF} | {1 | ON}}

For the trigger types that let you trigger on data, the :SBUS<n>:CXPI:TRIGger:PTYPE command specifies whether you want to trigger when the special PTYPE byte is present (ON) or not present (OFF).

Query Syntax :SBUS<n>:CXPI:TRIGger:PTYPE?

The :SBUS<n>:CXPI:TRIGger:PTYPE? query returns the PTYPE trigger setting.

Return Format <setting><NL>
<setting> ::= {0 | 1}

- See Also**
- [":SBUS<n>:CXPI:TRIGger"](#) on page 1037
 - [":SBUS<n>:CXPI:TRIGger:IDFilter"](#) on page 1039
 - [":SBUS<n>:CXPI:TRIGger:PATtern:DATA"](#) on page 1041
 - [":SBUS<n>:CXPI:TRIGger:PATtern:DATA:LENGth"](#) on page 1042
 - [":SBUS<n>:CXPI:TRIGger:PATtern:DATA:STARt"](#) on page 1043
 - [":SBUS<n>:CXPI:TRIGger:PATtern:ID"](#) on page 1044
 - [":SBUS<n>:CXPI:TRIGger:PATtern:INFO:CT"](#) on page 1045
 - [":SBUS<n>:CXPI:TRIGger:PATtern:INFO:DLC"](#) on page 1046
 - [":SBUS<n>:CXPI:TRIGger:PATtern:INFO:NM"](#) on page 1047

:SBUS<n>:CXPI:TRIGger:PATtern:DATA

N (see [page 1730](#))

Command Syntax :SBUS<n>:CXPI:TRIGger:PATtern:DATA <string>
 <string> ::= "nn...n" where n ::= {0 | 1 | X}
 <string ::= "0xnn...n" where n ::= {0,...,9 | A,...,F | X}

For the trigger types that let you trigger on data, the :SBUS<n>:CXPI:TRIGger:PATtern:DATA command lets you specify the data value.

The :SBUS<n>:CXPI:TRIGger:PATtern:DATA:LENGth command specifies the length of the data to trigger on, from 0 to 12 bytes, limited by the data length code (DLC) setting of the :SBUS<n>:CXPI:TRIGger:PATtern:INFO:DLC command.

When triggering on long frames (with the LDATa trigger type) that can have up to 255 data bytes, the maximum number of data bytes you can include in the trigger specification is still only 12 bytes. In this case, you can use the :SBUS<n>:CXPI:TRIGger:PATtern:DATA:STARt command to specify the starting byte location where the data value should be found.

Query Syntax :SBUS<n>:CXPI:TRIGger:PATtern:DATA?

The :SBUS<n>:CXPI:TRIGger:PATtern:DATA? query returns the specified data value.

Returned data values are always quoted binary format strings.

Return Format <string><NL>
 <string> ::= "nn...n" where n ::= {0 | 1 | X}

- See Also**
- [":SBUS<n>:CXPI:TRIGger"](#) on page 1037
 - [":SBUS<n>:CXPI:TRIGger:IDFilter"](#) on page 1039
 - [":SBUS<n>:CXPI:TRIGger:PTYPE"](#) on page 1040
 - [":SBUS<n>:CXPI:TRIGger:PATtern:DATA:LENGth"](#) on page 1042
 - [":SBUS<n>:CXPI:TRIGger:PATtern:DATA:STARt"](#) on page 1043
 - [":SBUS<n>:CXPI:TRIGger:PATtern:ID"](#) on page 1044
 - [":SBUS<n>:CXPI:TRIGger:PATtern:INFO:CT"](#) on page 1045
 - [":SBUS<n>:CXPI:TRIGger:PATtern:INFO:DLC"](#) on page 1046
 - [":SBUS<n>:CXPI:TRIGger:PATtern:INFO:NM"](#) on page 1047

:SBUS<n>:CXPI:TRIGger:PATtern:DATA:LENGth

N (see [page 1730](#))

Command Syntax :SBUS<n>:CXPI:TRIGger:PATtern:DATA:LENGth <length>
 <length> ::= integer between 0 and 12, in NR1 format.

For the trigger types that let you trigger on data, the :SBUS<n>:CXPI:TRIGger:PATtern:DATA:LENGth command specifies the length of the data to trigger on, from 0 to 12 bytes, limited by the data length code (DLC) setting of the :SBUS<n>:CXPI:TRIGger:PATtern:INFO:DLC command.

The :SBUS<n>:CXPI:TRIGger:PATtern:DATA command lets you specify the data value to trigger on.

Query Syntax :SBUS<n>:CXPI:TRIGger:PATtern:DATA:LENGth?

The :SBUS<n>:CXPI:TRIGger:PATtern:DATA:LENGth? query returns the data length setting.

Return Format <length><NL>
 <length> ::= integer between 0 and 12, in NR1 format.

- See Also**
- [":SBUS<n>:CXPI:TRIGger"](#) on page 1037
 - [":SBUS<n>:CXPI:TRIGger:IDFilter"](#) on page 1039
 - [":SBUS<n>:CXPI:TRIGger:PTYPE"](#) on page 1040
 - [":SBUS<n>:CXPI:TRIGger:PATtern:DATA"](#) on page 1041
 - [":SBUS<n>:CXPI:TRIGger:PATtern:DATA:START"](#) on page 1043
 - [":SBUS<n>:CXPI:TRIGger:PATtern:ID"](#) on page 1044
 - [":SBUS<n>:CXPI:TRIGger:PATtern:INFO:CT"](#) on page 1045
 - [":SBUS<n>:CXPI:TRIGger:PATtern:INFO:DLC"](#) on page 1046
 - [":SBUS<n>:CXPI:TRIGger:PATtern:INFO:NM"](#) on page 1047

:SBUS<n>:CXPI:TRIGger:PATtern:DATA:START

N (see [page 1730](#))

Command Syntax :SBUS<n>:CXPI:TRIGger:PATtern:DATA:START <start>

<start> ::= integer between 0 and 124, in NR1 format.

When triggering on long frames (with the LDATA trigger type) that can have up to 255 data bytes, the maximum number of data bytes you can include in the trigger specification is still only 12 bytes. In this case, you can use the :SBUS<n>:CXPI:TRIGger:PATtern:DATA:START command to specify the starting byte location where the data value should be found.

The starting byte location must be within the first 123 bytes when PTYPE is present or 124 bytes when PTYPE is not present.

The :SBUS<n>:CXPI:TRIGger:PATtern:DATA:LENGth command lets you specify the length of the data value to trigger on.

The :SBUS<n>:CXPI:TRIGger:PATtern:DATA command lets you specify the data value to trigger on.

Query Syntax :SBUS<n>:CXPI:TRIGger:PATtern:DATA:START?

The :SBUS<n>:CXPI:TRIGger:PATtern:DATA:START? query returns the start byte setting.

Return Format <start><NL>

<start> ::= integer between 0 and 124, in NR1 format.

- See Also**
- [":SBUS<n>:CXPI:TRIGger"](#) on page 1037
 - [":SBUS<n>:CXPI:TRIGger:IDFilter"](#) on page 1039
 - [":SBUS<n>:CXPI:TRIGger:PTYPE"](#) on page 1040
 - [":SBUS<n>:CXPI:TRIGger:PATtern:DATA"](#) on page 1041
 - [":SBUS<n>:CXPI:TRIGger:PATtern:DATA:LENGth"](#) on page 1042
 - [":SBUS<n>:CXPI:TRIGger:PATtern:ID"](#) on page 1044
 - [":SBUS<n>:CXPI:TRIGger:PATtern:INFO:CT"](#) on page 1045
 - [":SBUS<n>:CXPI:TRIGger:PATtern:INFO:DLC"](#) on page 1046
 - [":SBUS<n>:CXPI:TRIGger:PATtern:INFO:NM"](#) on page 1047

:SBUS<n>:CXPI:TRIGger:PATtern:ID

N (see [page 1730](#))

Command Syntax :SBUS<n>:CXPI:TRIGger:PATtern:ID <string>

<string> ::= "nn...n" where n ::= {0 | 1 | X}

<string ::= "0xnn...n" where n ::= {0,...,9 | A,...,F | X}

For the trigger types that let you specify frame ID values in the trigger or allow filtering by the frame ID, the :SBUS<n>:CXPI:TRIGger:PATtern:ID command lets you specify the frame ID value.

Query Syntax :SBUS<n>:CXPI:TRIGger:PATtern:ID?

The :SBUS<n>:CXPI:TRIGger:PATtern:ID? query returns the specified frame ID value.

Returned frame ID values are always quoted binary format strings.

Return Format <string><NL>

<string> ::= "nn...n" where n ::= {0 | 1 | X}

- See Also**
- [":SBUS<n>:CXPI:TRIGger"](#) on page 1037
 - [":SBUS<n>:CXPI:TRIGger:IDFilter"](#) on page 1039
 - [":SBUS<n>:CXPI:TRIGger:PTYPE"](#) on page 1040
 - [":SBUS<n>:CXPI:TRIGger:PATtern:DATA"](#) on page 1041
 - [":SBUS<n>:CXPI:TRIGger:PATtern:DATA:LENGth"](#) on page 1042
 - [":SBUS<n>:CXPI:TRIGger:PATtern:DATA:START"](#) on page 1043
 - [":SBUS<n>:CXPI:TRIGger:PATtern:INFO:CT"](#) on page 1045
 - [":SBUS<n>:CXPI:TRIGger:PATtern:INFO:DLC"](#) on page 1046
 - [":SBUS<n>:CXPI:TRIGger:PATtern:INFO:NM"](#) on page 1047

:SBUS<n>:CXPI:TRIGger:PATtern:INFO:CT

N (see [page 1730](#))

Command Syntax :SBUS<n>:CXPI:TRIGger:PATtern:INFO:CT <string>

<string> ::= "nn" where n ::= {0 | 1 | X}

The command ...

For the trigger types that let you trigger on data, as well as frame ID and frame information bits, the :SBUS<n>:CXPI:TRIGger:PATtern:INFO:CT command lets you specify the Count (CT) value of the CXPI frame you wish to trigger on. This is a two-bit binary value.

Query Syntax :SBUS<n>:CXPI:TRIGger:PATtern:INFO:CT?

The :SBUS<n>:CXPI:TRIGger:PATtern:INFO:CT? query returns the specified CT bits included in the trigger.

Return Format <string><NL>

<string> ::= "nn" where n ::= {0 | 1 | X}

- See Also**
- [":SBUS<n>:CXPI:TRIGger"](#) on page 1037
 - [":SBUS<n>:CXPI:TRIGger:IDFilter"](#) on page 1039
 - [":SBUS<n>:CXPI:TRIGger:PTYPE"](#) on page 1040
 - [":SBUS<n>:CXPI:TRIGger:PATtern:DATA"](#) on page 1041
 - [":SBUS<n>:CXPI:TRIGger:PATtern:DATA:LENGth"](#) on page 1042
 - [":SBUS<n>:CXPI:TRIGger:PATtern:DATA:START"](#) on page 1043
 - [":SBUS<n>:CXPI:TRIGger:PATtern:ID"](#) on page 1044
 - [":SBUS<n>:CXPI:TRIGger:PATtern:INFO:DLC"](#) on page 1046
 - [":SBUS<n>:CXPI:TRIGger:PATtern:INFO:NM"](#) on page 1047

:SBUS<n>:CXPI:TRIGger:PATtern:INFO:DLC

N (see [page 1730](#))

Command Syntax :SBUS<n>:CXPI:TRIGger:PATtern:INFO:DLC <dlc>

<dlc> ::= integer between -1 (don't care) and 15, in NR1 format, when trigger is in DATA mode.

<dlc> ::= integer between -1 (don't care) and 255, in NR1 format, when trigger is in LDATa mode.

For the trigger types that let you trigger on data, the :SBUS<n>:CXPI:TRIGger:PATtern:INFO:DLC command specifies the data length code of the CXPI frame you wish to trigger on.

This will also affect the number of data bytes you can specify in the trigger.

Query Syntax :SBUS<n>:CXPI:TRIGger:PATtern:INFO:DLC?

The :SBUS<n>:CXPI:TRIGger:PATtern:INFO:DLC? query returns the DLC trigger value setting.

Return Format <dlc><NL>

<dlc> ::= integer between -1 (don't care) and 15, in NR1 format, when trigger is in DATA mode.

<dlc> ::= integer between -1 (don't care) and 255, in NR1 format, when trigger is in LDATa mode.

- See Also**
- [":SBUS<n>:CXPI:TRIGger"](#) on page 1037
 - [":SBUS<n>:CXPI:TRIGger:IDFilter"](#) on page 1039
 - [":SBUS<n>:CXPI:TRIGger:PTYPE"](#) on page 1040
 - [":SBUS<n>:CXPI:TRIGger:PATtern:DATA"](#) on page 1041
 - [":SBUS<n>:CXPI:TRIGger:PATtern:DATA:LENGth"](#) on page 1042
 - [":SBUS<n>:CXPI:TRIGger:PATtern:DATA:START"](#) on page 1043
 - [":SBUS<n>:CXPI:TRIGger:PATtern:ID"](#) on page 1044
 - [":SBUS<n>:CXPI:TRIGger:PATtern:INFO:CT"](#) on page 1045
 - [":SBUS<n>:CXPI:TRIGger:PATtern:INFO:NM"](#) on page 1047

:SBUS<n>:CXPI:TRIGger:PATtern:INFO:NM

N (see [page 1730](#))

Command Syntax :SBUS<n>:CXPI:TRIGger:PATtern:INFO:NM <string>

<string> ::= "nn" where n ::= {0 | 1 | X}

For the trigger types that let you trigger on data, as well as frame ID and frame information bits, the :SBUS<n>:CXPI:TRIGger:PATtern:INFO:NM command lets you specify the Network Management (NM) value of the CXPI frame you wish to trigger on. This is a two-bit binary value.

Query Syntax :SBUS<n>:CXPI:TRIGger:PATtern:INFO:NM?

The :SBUS<n>:CXPI:TRIGger:PATtern:INFO:NM? query returns the specified NM bits included in the trigger.

Return Format <string><NL>

<string> ::= "nn" where n ::= {0 | 1 | X}

- See Also**
- [":SBUS<n>:CXPI:TRIGger"](#) on page 1037
 - [":SBUS<n>:CXPI:TRIGger:IDFilter"](#) on page 1039
 - [":SBUS<n>:CXPI:TRIGger:PTYPE"](#) on page 1040
 - [":SBUS<n>:CXPI:TRIGger:PATtern:DATA"](#) on page 1041
 - [":SBUS<n>:CXPI:TRIGger:PATtern:DATA:LENGth"](#) on page 1042
 - [":SBUS<n>:CXPI:TRIGger:PATtern:DATA:START"](#) on page 1043
 - [":SBUS<n>:CXPI:TRIGger:PATtern:ID"](#) on page 1044
 - [":SBUS<n>:CXPI:TRIGger:PATtern:INFO:CT"](#) on page 1045
 - [":SBUS<n>:CXPI:TRIGger:PATtern:INFO:DLC"](#) on page 1046

:SBUS<n>:FLEXray Commands

NOTE

These commands are only valid when the FLEXray triggering and serial decode option has been licensed.

Table 131 :SBUS<n>:FLEXray Commands Summary

Command	Query	Options and Query Returns
:SBUS<n>:FLEXray:AUTOsetup (see page 1050)	n/a	n/a
:SBUS<n>:FLEXray:BAUDrate <baudrate> (see page 1051)	:SBUS<n>:FLEXray:BAUDrate? (see page 1051)	<baudrate> ::= {2500000 5000000 10000000}
:SBUS<n>:FLEXray:CHANnel <channel> (see page 1052)	:SBUS<n>:FLEXray:CHANnel? (see page 1052)	<channel> ::= {A B}
n/a	:SBUS<n>:FLEXray:COUNt:NULL? (see page 1053)	<frame_count> ::= integer in NR1 format
:SBUS<n>:FLEXray:COUNt:RESet (see page 1054)	n/a	n/a
n/a	:SBUS<n>:FLEXray:COUNt:SYNC? (see page 1055)	<frame_count> ::= integer in NR1 format
n/a	:SBUS<n>:FLEXray:COUNt:TOTal? (see page 1056)	<frame_count> ::= integer in NR1 format
:SBUS<n>:FLEXray:SOURce <source> (see page 1057)	:SBUS<n>:FLEXray:SOURce? (see page 1057)	<source> ::= {CHANnel<n>} <n> ::= 1-2 or 1-4 in NR1 format
:SBUS<n>:FLEXray:TRIGger <condition> (see page 1058)	:SBUS<n>:FLEXray:TRIGger? (see page 1058)	<condition> ::= {FRAME ERROR EVENT}
:SBUS<n>:FLEXray:TRIGger:ERROR:TYPE <error_type> (see page 1059)	:SBUS<n>:FLEXray:TRIGger:ERROR:TYPE? (see page 1059)	<error_type> ::= {ALL HCRC FCRC}
:SBUS<n>:FLEXray:TRIGger:EVENT:AUTOset (see page 1060)	n/a	n/a

Table 131 :SBUS<n>:FLEXray Commands Summary (continued)

Command	Query	Options and Query Returns
:SBUS<n>:FLEXray:TRIGGER:EVENT:BSS:ID <frame_id> (see page 1061)	:SBUS<n>:FLEXray:TRIGGER:EVENT:BSS:ID? (see page 1061)	<frame_id> ::= {ALL <frame #>} <frame #> ::= integer from 1-2047
:SBUS<n>:FLEXray:TRIGGER:EVENT:TYPE <event> (see page 1062)	:SBUS<n>:FLEXray:TRIGGER:EVENT:TYPE? (see page 1062)	<event> ::= {WAKEup TSS {FES DTS} BSS}
:SBUS<n>:FLEXray:TRIGGER:FRAME:CCBase <cycle_count_base> (see page 1063)	:SBUS<n>:FLEXray:TRIGGER:FRAME:CCBase? (see page 1063)	<cycle_count_base> ::= integer from 0-63
:SBUS<n>:FLEXray:TRIGGER:FRAME:CCRepetition <cycle_count_repetition> (see page 1064)	:SBUS<n>:FLEXray:TRIGGER:FRAME:CCRepetition? (see page 1064)	<cycle_count_repetition> ::= {ALL <rep #>} <rep #> ::= integer values 2, 4, 8, 16, 32, or 64
:SBUS<n>:FLEXray:TRIGGER:FRAME:ID <frame_id> (see page 1065)	:SBUS<n>:FLEXray:TRIGGER:FRAME:ID? (see page 1065)	<frame_id> ::= {ALL <frame #>} <frame #> ::= integer from 1-2047
:SBUS<n>:FLEXray:TRIGGER:FRAME:TYPE <frame_type> (see page 1066)	:SBUS<n>:FLEXray:TRIGGER:FRAME:TYPE? (see page 1066)	<frame_type> ::= {NORMAL STARTup NULL SYNC NSTARTup NNULL NSYNc ALL}

:SBUS<n>:FLEXray:AUTosetup

N (see [page 1730](#))

Command Syntax :SBUS<n>:FLEXray:AUTosetup

The :SBUS<n>:FLEXray:AUTosetup command automatically configures oscilloscope settings to facilitate FlexRay triggering and serial decode.

- Sets the selected source channel's impedance to 50 Ohms.
- Sets the selected source channel's probe attenuation to 10:1.
- Sets the trigger level (on the selected source channel) to -300 mV.
- Turns on trigger Noise Reject.
- Turns on Serial Decode.
- Sets the trigger to the specified serial bus (n of SBUS<n>).

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":SBUS<n>:FLEXray:TRIGger"](#) on page 1058
 - [":SBUS<n>:FLEXray:BAUDrate"](#) on page 1051
 - [":TRIGger\[:EDGE\]:LEVel"](#) on page 1457
 - [":SBUS<n>:FLEXray:SOURce"](#) on page 1057

:SBUS<n>:FLEXray:BAUDrate

N (see [page 1730](#))

Command Syntax :SBUS<n>:FLEXray:BAUDrate <baudrate>

<baudrate> ::= {2500000 | 5000000 | 10000000}

The :SBUS<n>:FLEXray:BAUDrate command specifies the baud rate as 2.5 Mb/s, 5 Mb/s, or 10 Mb/s.

Query Syntax :SBUS<n>:FLEXray:BAUDrate?

The :SBUS<n>:FLEXray:BAUDrate? query returns the current baud rate setting.

Return Format <baudrate><NL>

<baudrate> ::= {2500000 | 5000000 | 10000000}

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":SBUS<n>:FLEXray Commands"](#) on page 1048

:SBUS<n>:FLEXray:CHANnel

N (see [page 1730](#))

Command Syntax :SBUS<n>:FLEXray:CHANnel <channel>

<channel> ::= {A | B}

The :SBUS<n>:FLEXray:CHANnel command specifies the bus channel, A or B, of the FlexRay signal.

Query Syntax :SBUS<n>:FLEXray:CHANnel?

The :SBUS<n>:FLEXray:CHANnel? query returns the current bus channel setting.

Return Format <channel><NL>

<channel> ::= {A | B}

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":SBUS<n>:FLEXray Commands"](#) on page 1048

:SBUS<n>:FLEXray:COUNT:NULL

N (see [page 1730](#))

Query Syntax :SBUS<n>:FLEXray:COUNT:NULL?

Returns the FlexRay null frame count.

Return Format <frame_count><NL>

<frame_count> ::= integer in NR1 format

Errors • ["-241, Hardware missing"](#) on page 1671

- See Also**
- [":SBUS<n>:FLEXray:COUNT:RESet"](#) on page 1054
 - [":SBUS<n>:FLEXray:COUNT:TOTal"](#) on page 1056
 - [":SBUS<n>:FLEXray:COUNT:SYNC"](#) on page 1055
 - ["Introduction to :SBUS<n> Commands"](#) on page 977
 - [":SBUS<n>:MODE"](#) on page 981
 - [":SBUS<n>:FLEXray Commands"](#) on page 1048

:SBUS<n>:FLEXray:COUNT:RESet

N (see [page 1730](#))

Command Syntax :SBUS<n>:FLEXray:COUNT:RESet

Resets the FlexRay frame counters.

- Errors**
- ["-241, Hardware missing"](#) on page 1671
- See Also**
- [":SBUS<n>:FLEXray:COUNT:NULL"](#) on page 1053
 - [":SBUS<n>:FLEXray:COUNT:TOTal"](#) on page 1056
 - [":SBUS<n>:FLEXray:COUNT:SYNC"](#) on page 1055
 - ["Introduction to :SBUS<n> Commands"](#) on page 977
 - [":SBUS<n>:MODE"](#) on page 981
 - [":SBUS<n>:FLEXray Commands"](#) on page 1048

:SBUS<n>:FLEXray:COUNT:SYNC

N (see [page 1730](#))

Query Syntax :SBUS<n>:FLEXray:COUNT:SYNC?

Returns the FlexRay sync frame count.

Return Format <frame_count><NL>

<frame_count> ::= integer in NR1 format

Errors • ["-241, Hardware missing"](#) on page 1671

- See Also**
- [":SBUS<n>:FLEXray:COUNT:RESet"](#) on page 1054
 - [":SBUS<n>:FLEXray:COUNT:TOTal"](#) on page 1056
 - [":SBUS<n>:FLEXray:COUNT:NULL"](#) on page 1053
 - ["Introduction to :SBUS<n> Commands"](#) on page 977
 - [":SBUS<n>:MODE"](#) on page 981
 - [":SBUS<n>:FLEXray Commands"](#) on page 1048

:SBUS<n>:FLEXray:COUNT:TOTal

N (see [page 1730](#))

Query Syntax :SBUS<n>:FLEXray:COUNT:TOTal?

Returns the FlexRay total frame count.

Return Format <frame_count><NL>

<frame_count> ::= integer in NR1 format

Errors • ["-241, Hardware missing"](#) on page 1671

- See Also**
- [":SBUS<n>:FLEXray:COUNT:RESet"](#) on page 1054
 - [":SBUS<n>:FLEXray:COUNT:TOTal"](#) on page 1056
 - [":SBUS<n>:FLEXray:COUNT:NULL"](#) on page 1053
 - [":SBUS<n>:FLEXray:COUNT:SYNC"](#) on page 1055
 - ["Introduction to :SBUS<n> Commands"](#) on page 977
 - [":SBUS<n>:MODE"](#) on page 981
 - [":SBUS<n>:FLEXray Commands"](#) on page 1048

:SBUS<n>:FLEXray:SOURce

N (see [page 1730](#))

Command Syntax :SBUS<n>:FLEXray:SOURce <source>

<source> ::= {CHANnel<n>}

<n> ::= {1 | 2 | 3 | 4}

The :SBUS<n>:FLEXray:SOURce command specifies the input source for the FlexRay signal.

Query Syntax :SBUS<n>:FLEXray:SOURce?

The :SBUS<n>:FLEXray:SOURce? query returns the current source for the FlexRay signal.

Return Format <source><NL>

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":SBUS<n>:FLEXray:TRIGger"](#) on page 1058
 - [":SBUS<n>:FLEXray:TRIGger:EVENT:TYPE"](#) on page 1062
 - [":SBUS<n>:FLEXray:AUTOsetup"](#) on page 1050

:SBUS<n>:FLEXray:TRIGger

N (see [page 1730](#))

Command Syntax :SBUS<n>:FLEXray:TRIGger <condition>

<condition> ::= {FRAMe | ERRor | EVENT}

The :SBUS<n>:FLEXray:TRIGger:TRIGger command sets the FLEXray trigger on condition:

- FRAMe – triggers on specified frames (without errors).
- ERRor – triggers on selected active error frames and unknown bus conditions.
- EVENT – triggers on specified FlexRay event/symbol.

Query Syntax :SBUS<n>:FLEXray:TRIGger?

The :SBUS<n>:FLEXray:TRIGger? query returns the current FLEXray trigger on condition.

Return Format <condition><NL>

<condition> ::= {FRAM | ERR | EVEN}

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:MODE"](#) on page 1439
 - [":SBUS<n>:FLEXray:TRIGger:ERRor:TYPE"](#) on page 1059
 - [":SBUS<n>:FLEXray:TRIGger:EVENT:AUToset"](#) on page 1060
 - [":SBUS<n>:FLEXray:TRIGger:EVENT:BSS:ID"](#) on page 1061
 - [":SBUS<n>:FLEXray:TRIGger:EVENT:TYPE"](#) on page 1062
 - [":SBUS<n>:FLEXray:TRIGger:FRAME:CCBase"](#) on page 1063
 - [":SBUS<n>:FLEXray:TRIGger:FRAME:CCRepetition"](#) on page 1064
 - [":SBUS<n>:FLEXray:TRIGger:FRAME:ID"](#) on page 1065
 - [":SBUS<n>:FLEXray:TRIGger:FRAME:TYPE"](#) on page 1066

:SBUS<n>:FLEXray:TRIGger:ERRor:TYPE

N (see [page 1730](#))

Command Syntax :SBUS<n>:FLEXray:TRIGger:ERRor:TYPE <error_type>

<error_type> ::= {ALL | HCRC | FCRC}

Selects the FlexRay error type to trigger on. The error type setting is only valid when the FlexRay trigger mode is set to ERRor.

- ALL – triggers on ALL errors.
- HCRC – triggers on only Header CRC errors.
- FCRC – triggers on only Frame CRC errors.

Query Syntax :SBUS<n>:FLEXray:TRIGger:ERRor:TYPE?

The :SBUS<n>:FLEXray:TRIGger:ERRor:TYPE? query returns the currently selected FLEXray error type.

Return Format <error_type><NL>

<error_type> ::= {ALL | HCRC | FCRC}

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":SBUS<n>:FLEXray:TRIGger"](#) on page 1058

:SBUS<n>:FLEXray:TRIGger:EVENT:AUToset

N (see [page 1730](#))

Command Syntax :SBUS<n>:FLEXray:TRIGger:EVENT:AUToset

The :SBUS<n>:FLEXray:TRIGger:EVENT:AUToset command automatically configures oscilloscope settings (as shown on the display) for the selected event trigger.

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":SBUS<n>:FLEXray:TRIGger:EVENT:TYPE"](#) on page 1062
 - [":SBUS<n>:FLEXray:TRIGger:EVENT:BSS:ID"](#) on page 1061
 - [":SBUS<n>:FLEXray:TRIGger"](#) on page 1058
 - [":SBUS<n>:FLEXray:BAUDrate"](#) on page 1051
 - [":TRIGger\[:EDGE\]:LEVel"](#) on page 1457
 - [":SBUS<n>:FLEXray:SOURce"](#) on page 1057

:SBUS<n>:FLEXray:TRIGger:EVENT:BSS:ID

N (see [page 1730](#))

Command Syntax :SBUS<n>:FLEXray:TRIGger:EVENT:BSS:ID <frame_id>

<frame_id> ::= {ALL | <frame #>}

<frame #> ::= integer from 1-2047

The :SBUS<N>:FLEXray:TRIGger:EVENT:BSS:ID command sets the frame ID used by the Byte Start Sequence (BSS) event trigger. This setting is only valid if the trigger mode is EVENT and the EVENT:TYPE is BSS.

Query Syntax :SBUS<n>:FLEXray:TRIGger:EVENT:BSS:ID?

The :SBUS<n>:FLEXray:TRIGger:EVENT:BSS:ID? query returns the current frame ID setting for the Byte Start Sequence (BSS) event trigger setup.

Return Format <frame_id><NL>

<frame_id> ::= {ALL | <frame #>}

<frame #> ::= integer from 1-2047

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":SBUS<n>:FLEXray:TRIGger:EVENT:TYPE"](#) on page 1062
 - [":SBUS<n>:FLEXray:TRIGger:EVENT:AUToset"](#) on page 1060
 - [":TRIGger:MODE"](#) on page 1439
 - [":SBUS<n>:FLEXray:TRIGger"](#) on page 1058

:SBUS<n>:FLEXray:TRIGger:EVENT:TYPE

N (see [page 1730](#))

Command Syntax :SBUS<n>:FLEXray:TRIGger:EVENT:TYPE <event>

<event> ::= {WAKEup | TSS | {FES | DTS} | BSS}

Selects the FlexRay event to trigger on. The event setting is only valid when the FlexRay trigger mode is set to EVENT.

- WAKEup – triggers on Wake-Up event.
- TSS – triggers on Transmission Start Sequence event.
- FES – triggers on either Frame End or Dynamic Trailing Sequence event.
- DTS – triggers on either Frame End or Dynamic Trailing Sequence event.
- BSS – triggers on Byte Start Sequence event.

Query Syntax :SBUS<n>:FLEXray:TRIGger:EVENT:TYPE?

The :SBUS<n>:FLEXray:TRIGger:EVENT:TYPE? query returns the currently selected FLEXray event.

Return Format <event><NL>

<event> ::= {WAK | TSS | {FES | DTS} | BSS}

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":SBUS<n>:FLEXray:TRIGger:EVENT:AUToset"](#) on page 1060
 - [":SBUS<n>:FLEXray:TRIGger:EVENT:BSS:ID"](#) on page 1061
 - [":SBUS<n>:FLEXray:TRIGger"](#) on page 1058
 - [":SBUS<n>:FLEXray:AUTosetup"](#) on page 1050
 - [":SBUS<n>:FLEXray:SOURce"](#) on page 1057

:SBUS<n>:FLEXray:TRIGger:FRAME:CCBase

N (see [page 1730](#))

Command Syntax :SBUS<n>:FLEXray:TRIGger:FRAME:CCBase <cycle_count_base>

<cycle_count_base> ::= integer from 0-63

The :SBUS<n>:FLEXray:TRIGger:FRAME:CCBase command sets the base of the FlexRay cycle count (in the frame header) to trigger on. The cycle count base setting is only valid when the FlexRay trigger mode is set to FRAME.

Query Syntax :SBUS<n>:FLEXray:TRIGger:FRAME:CCBase?

The :SBUS<n>:FLEXray:TRIGger:FRAME:CCBase? query returns the current cycle count base setting for the FlexRay frame trigger setup.

Return Format <cycle_count_base><NL>

<cycle_count_base> ::= integer from 0-63

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":SBUS<n>:FLEXray:TRIGger"](#) on page 1058

:SBUS<n>:FLEXray:TRIGger:FRAME:CCRepetition

N (see [page 1730](#))

Command Syntax :SBUS<n>:FLEXray:TRIGger:FRAME:CCRepetition <cycle_count_repetition>

<cycle_count_repetition> ::= {ALL | <rep #>}

<rep #> ::= integer values 2, 4, 8, 16, 32, or 64

The :SBUS<n>:FLEXray:TRIGger:FRAME:CCRepetition command sets the repetition number of the FlexRay cycle count (in the frame header) to trigger on. The cycle count repetition setting is only valid when the FlexRay trigger mode is set to FRAME.

Query Syntax :SBUS<n>:FLEXray:TRIGger:FRAME:CCRepetition?

The :SBUS<n>:FLEXray:TRIGger:FRAME:CCRepetition? query returns the current cycle count repetition setting for the FlexRay frame trigger setup.

Return Format <cycle_count_repetition><NL>

<cycle_count_repetition> ::= {ALL | <rep #>}

<rep #> ::= integer values 2, 4, 8, 16, 32, or 64

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":SBUS<n>:FLEXray:TRIGger"](#) on page 1058

:SBUS<n>:FLEXray:TRIGger:FRAME:ID

N (see [page 1730](#))

Command Syntax :SBUS<n>:FLEXray:TRIGger:FRAME:ID <frame_id>

<frame_id> ::= {ALL | <frame #>}

<frame #> ::= integer from 1-2047

The :SBUS<n>:FLEXray:TRIGger:FRAME:ID command sets the FlexRay frame ID to trigger on. The frame ID setting is only valid when the FlexRay trigger mode is set to FRAME.

Query Syntax :SBUS<n>:FLEXray:TRIGger:FRAME:ID?

The :SBUS<n>:FLEXray:TRIGger:FRAME:ID? query returns the current frame ID setting for the FlexRay frame trigger setup.

Return Format <frame_id><NL>

<frame_id> ::= {ALL | <frame #>}

<frame #> ::= integer from 1-2047

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:MODE"](#) on page 1439
 - [":SBUS<n>:FLEXray:TRIGger"](#) on page 1058

:SBUS<n>:FLEXray:TRIGger:FRAME:TYPE

N (see [page 1730](#))

Command Syntax :SBUS<n>:FLEXray:TRIGger:FRAME:TYPE <frame_type>

<frame_type> ::= {NORMAL | STARTup | NULL | SYNC | NSTArtup | NNULl | NSYNc | ALL}

The :SBUS<n>:FLEXray:TRIGger:FRAME:TYPE command sets the FlexRay frame type to trigger on. The frame type setting is only valid when the FlexRay trigger mode is set to FRAME.

- NORMAL – will trigger on only normal (NSTArtup & NNULl & NSYNc) frames.
- STARTup – will trigger on only startup frames.
- NULL – will trigger on only null frames.
- SYNC – will trigger on only sync frames.
- NSTArtup – will trigger on frames other than startup frames.
- NNULl – will trigger on frames other than null frames.
- NSYNc – will trigger on frames other than sync frames.
- ALL – will trigger on all FlexRay frame types.

Query Syntax :SBUS<n>:FLEXray:TRIGger:FRAME:TYPE?

The :SBUS<n>:FLEXray:TRIGger:FRAME:TYPE? query returns the current frame type setting for the FlexRay frame trigger setup.

Return Format <frame_type><NL>

<frame_type> ::= {NORM | STAR | NULL | SYNC | NSTA | NNUL | NSYN | ALL}

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - ["::TRIGger:MODE"](#) on page 1439
 - ["::SBUS<n>:FLEXray:TRIGger"](#) on page 1058

:SBUS<n>:I2S Commands

NOTE

These commands are only valid when the I2S serial decode option has been licensed.

Table 132 :SBUS<n>:I2S Commands Summary

Command	Query	Options and Query Returns
:SBUS<n>:I2S:ALIGnment <setting> (see page 1070)	:SBUS<n>:I2S:ALIGnment? (see page 1070)	<setting> ::= {I2S LJ RJ}
:SBUS<n>:I2S:BASE <base> (see page 1071)	:SBUS<n>:I2S:BASE? (see page 1071)	<base> ::= {DECimal HEX}
:SBUS<n>:I2S:CLOCK:SLOPe <slope> (see page 1072)	:SBUS<n>:I2S:CLOCK:SLOPe? (see page 1072)	<slope> ::= {NEGative POSitive}
:SBUS<n>:I2S:RWIDth <receiver> (see page 1073)	:SBUS<n>:I2S:RWIDth? (see page 1073)	<receiver> ::= 4-32 in NR1 format
:SBUS<n>:I2S:SOURce:CLOCK <source> (see page 1074)	:SBUS<n>:I2S:SOURce:CLOCK? (see page 1074)	<source> ::= {CHANnel<n> EXTernal} for DSO models <source> ::= {CHANnel<n> DIGital<d> } for MSO models <n> ::= 1 to (# analog channels) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format
:SBUS<n>:I2S:SOURce:DATA <source> (see page 1075)	:SBUS<n>:I2S:SOURce:DATA? (see page 1075)	<source> ::= {CHANnel<n> EXTernal} for DSO models <source> ::= {CHANnel<n> DIGital<d> } for MSO models <n> ::= 1 to (# analog channels) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format

Table 132 :SBUS<n>:I2S Commands Summary (continued)

Command	Query	Options and Query Returns
:SBUS<n>:I2S:SOURce:WSElect <source> (see page 1076)	:SBUS<n>:I2S:SOURce:WSElect? (see page 1076)	<source> ::= {CHANnel<n> EXTErnal} for DSO models <source> ::= {CHANnel<n> DIGital<d>} for MSO models <n> ::= 1 to (# analog channels) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format
:SBUS<n>:I2S:TRIGger<operator> (see page 1077)	:SBUS<n>:I2S:TRIGger? (see page 1077)	<operator> ::= {EQUal NOTequal LESSthan GREATERthan INRange OUTRange INCRasing DECRasing}
:SBUS<n>:I2S:TRIGger:AUDio <audio_ch> (see page 1079)	:SBUS<n>:I2S:TRIGger:AUDio? (see page 1079)	<audio_ch> ::= {RIGHT LEFT EITHer}
:SBUS<n>:I2S:TRIGger:PATtern:DATA <string> (see page 1080)	:SBUS<n>:I2S:TRIGger:PATtern:DATA? (see page 1081)	<string> ::= "n" where n ::= 32-bit integer in signed decimal when <base> = DECimal <string> ::= "nn...n" where n ::= {0 1 X \$} when <base> = BINary <string> ::= "0xnn...n" where n ::= {0,...,9 A,...,F X \$} when <base> = HEX
:SBUS<n>:I2S:TRIGger:PATtern:FORMat <base> (see page 1082)	:SBUS<n>:I2S:TRIGger:PATtern:FORMat? (see page 1082)	<base> ::= {BINary HEX DECimal}
:SBUS<n>:I2S:TRIGger:RANGe <lower>, <upper> (see page 1083)	:SBUS<n>:I2S:TRIGger:RANGe? (see page 1083)	<lower> ::= 32-bit integer in signed decimal, <nondecimal>, or <string> <upper> ::= 32-bit integer in signed decimal, <nondecimal>, or <string> <nondecimal> ::= #Hnn...n where n ::= {0,...,9 A,...,F} for hexadecimal <nondecimal> ::= #Bnn...n where n ::= {0 1} for binary <string> ::= "0xnn...n" where n ::= {0,...,9 A,...,F} for hexadecimal

Table 132 :SBUS<n>:I2S Commands Summary (continued)

Command	Query	Options and Query Returns
:SBUS<n>:I2S:TWIDth <word_size> (see page 1084)	:SBUS<n>:I2S:TWIDth? (see page 1084)	<word_size> ::= 4-32 in NR1 format
:SBUS<n>:I2S:WSLow <low_def> (see page 1085)	:SBUS<n>:I2S:WSLow? (see page 1085)	<low_def> ::= {LEFT RIGHT}

:SBUS<n>:I2S:ALIGNment

N (see [page 1730](#))

Command Syntax :SBUS<n>:I2S:ALIGNment <setting>

<setting> ::= { I2S | LJ | RJ }

The :SBUS<n>:I2S:ALIGNment command selects the data alignment of the I2S bus for the serial decoder and/or trigger when in I2S mode:

- I2S – standard.
- LJ – left justified.
- RJ – right justified.

Note that the word select (WS) polarity is specified separately with the :SBUS<n>:I2S:WSLow command.

Query Syntax :SBUS<n>:I2S:ALIGNment?

The :SBUS<n>:I2S:ALIGNment? query returns the currently selected I2S data alignment.

Return Format <setting><NL>

<setting> ::= { I2S | LJ | RJ }

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":SBUS<n>:I2S:CLOCK:SLOPe"](#) on page 1072
 - [":SBUS<n>:I2S:RWIDth"](#) on page 1073
 - [":SBUS<n>:I2S:TWIDth"](#) on page 1084
 - [":SBUS<n>:I2S:WSLow"](#) on page 1085

:SBUS<n>:I2S:BASE

N (see [page 1730](#))

Command Syntax :SBUS<n>:I2S:BASE <base>

<base> ::= {DECimal | HEX}

The :SBUS<n>:I2S:BASE command determines the base to use for the I2S decode display.

Query Syntax :SBUS<n>:I2S:BASE?

The :SBUS<n>:I2S:BASE? query returns the current I2S display decode base.

Return Format <base><NL>

<base> ::= {DECimal | HEX}

Errors • ["-241, Hardware missing"](#) on page 1671

See Also • ["Introduction to :SBUS<n> Commands"](#) on page 977

• [":SBUS<n>:I2S Commands"](#) on page 1067

:SBUS<n>:I2S:CLOCK:SLOPe

N (see [page 1730](#))

Command Syntax :SBUS<n>:I2S:CLOCK:SLOPe <slope>

<slope> ::= {NEGative | POSitive}

The :SBUS<n>:I2S:CLOCK:SLOPe command specifies which edge of the I2S serial clock signal clocks in data.

- NEGative – Falling edge.
- POSitive – Rising edge.

Query Syntax :SBUS<n>:I2S:CLOCK:SLOPe?

The :SBUS<n>:I2S:CLOCK:SLOPe? query returns the current I2S clock slope setting.

Return Format <slope><NL>

<slope> ::= {NEG | POS}

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":SBUS<n>:I2S:ALIGNment"](#) on page 1070
 - [":SBUS<n>:I2S:RWIDth"](#) on page 1073
 - [":SBUS<n>:I2S:TWIDth"](#) on page 1084
 - [":SBUS<n>:I2S:WSLow"](#) on page 1085

:SBUS<n>:I2S:RWIDth

N (see [page 1730](#))

Command Syntax :SBUS<n>:I2S:RWIDth <receiver>

<receiver> ::= 4-32 in NR1 format

The :SBUS<n>:I2S:RWIDth command sets the width of the receiver (decoded) data word in I2S anywhere from 4 bits to 32 bits.

Query Syntax :SBUS<n>:I2S:RWIDth?

The :SBUS<n>:I2S:RWIDth? query returns the currently set I2S receiver data word width.

Return Format <receiver><NL>

<receiver> ::= 4-32 in NR1 format

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":SBUS<n>:I2S:ALIGNment"](#) on page 1070
 - [":SBUS<n>:I2S:CLOCK:SLOPe"](#) on page 1072
 - [":SBUS<n>:I2S:TWIDth"](#) on page 1084
 - [":SBUS<n>:I2S:WSLow"](#) on page 1085

:SBUS<n>:I2S:SOURce:CLOCK

N (see [page 1730](#))

Command Syntax :SBUS<n>:I2S:SOURce:CLOCK <source>

<source> ::= {CHANnel<n> | EXTernal} for the DSO models

<source> ::= {CHANnel<n> | DIGital<d>} for the MSO models

<n> ::= 1 to (# analog channels) in NR1 format

<d> ::= 0 to (# digital channels - 1) in NR1 format

The :SBUS<n>:I2S:SOURce:CLOCK controls which signal is used as the serial clock (SCLK) source by the serial decoder and/or trigger when in I2S mode.

Query Syntax :SBUS<n>:I2S:SOURce:CLOCK?

The :SBUS<n>:I2S:SOURce:CLOCK? query returns the current source for the I2S serial clock (SCLK).

Return Format <source><NL>

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":SBUS<n>:I2S:SOURce:DATA"](#) on page 1075
 - [":SBUS<n>:I2S:SOURce:WSElect"](#) on page 1076

:SBUS<n>:I2S:SOURce:DATA

N (see [page 1730](#))

Command Syntax :SBUS<n>:I2S:SOURce:DATA <source>

<source> ::= {CHANnel<n> | EXTernal} for the DSO models

<source> ::= {CHANnel<n> | DIGital<d>} for the MSO models

<n> ::= 1 to (# analog channels) in NR1 format

<d> ::= 0 to (# digital channels - 1) in NR1 format

The :SBUS<n>:I2S:SOURce:DATA command controls which signal is used as the serial data (SDATA) source by the serial decoder and/or trigger when in I2S mode.

Query Syntax :SBUS<n>:I2S:SOURce:DATA?

The :SBUS<n>:I2S:SOURce:DATA? query returns the current source for the I2S serial data (SDATA).

Return Format <source><NL>

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":SBUS<n>:I2S:SOURce:CLOCK"](#) on page 1074
 - [":SBUS<n>:I2S:SOURce:WSElect"](#) on page 1076

:SBUS<n>:I2S:SOURce:WSElect

N (see [page 1730](#))

Command Syntax :SBUS<n>:I2S:SOURce:WSElect <source>

<source> ::= {CHANnel<n> | EXTernal} for the DSO models

<source> ::= {CHANnel<n> | DIGital<d>} for the MSO models

<n> ::= 1 to (# analog channels) in NR1 format

<d> ::= 0 to (# digital channels - 1) in NR1 format

The :SBUS<n>:I2S:SOURce:WSElect command controls which signal is used as the word select (WS) source by the serial decoder and/or trigger when in I2S mode.

Query Syntax :SBUS<n>:I2S:SOURce:WSElect?

The :SBUS<n>:I2S:SOURce:WSElect? query returns the current source for I2S word select (WS).

Return Format <source><NL>

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":SBUS<n>:I2S:SOURce:CLOCK"](#) on page 1074
 - [":SBUS<n>:I2S:SOURce:DATA"](#) on page 1075

:SBUS<n>:I2S:TRIGger


N (see [page 1730](#))

Command Syntax :SBUS<n>:I2S:TRIGger <operator>

<operator> ::= {EQUal | NOTequal | LESSthan | GREaterthan | INRange
| OUTRange | INCReasing | DECReasing}

The :SBUS<n>:I2S:TRIGger command sets the I2S trigger operator:

- EQUal— triggers on the specified audio channel's data word when it equals the specified word.
- NOTequal – triggers on any word other than the specified word.
- LESSthan – triggers when the channel's data word is less than the specified value.
- GREaterthan – triggers when the channel's data word is greater than the specified value.
- INRange – enter upper and lower values to specify the range in which to trigger.
- OUTRange – enter upper and lower values to specify range in which trigger will not occur.
- INCReasing – triggers when the data value makes a certain increase over time and the specified value is met or exceeded. Use the :SBUS<n>:I2S:TRIGger:RANGe command to set "Trigger" and "Armed" values. The "Trigger" value is the value that must be met or exceeded to cause the trigger. The "Armed" value is the value the data must go below in order to re-arm the oscilloscope (ready it to trigger again).



- DECReasing – similar to INCReasing except the trigger occurs on a certain decrease over time and the "Trigger" data value is less than the "Armed" data value.

Query Syntax :SBUS<n>:I2S:TRIGger?

The :SBUS<n>:I2S:TRIGger? query returns the current I2S trigger operator.

Return Format <operator><NL>

<operator> ::= {EQU | NOT | LESS | GRE | INR | OUTR | INCR | DECR}

- See Also**
- [":SBUS<n>:TRIGger:COMMANDS"](#) on page 1425
 - [":SBUS<n>:I2S:TRIGger:AUDio"](#) on page 1079
 - [":SBUS<n>:I2S:TRIGger:RANGe"](#) on page 1083
 - [":SBUS<n>:I2S:TRIGger:PATtern:FORMat"](#) on page 1082

:SBUS<n>:I2S:TRIGger:AUDio

N (see [page 1730](#))

Command Syntax :SBUS<n>:I2S:TRIGger:AUDio <audio_ch>

<audio_ch> ::= {RIGHT | LEFT | EITHER}

The :SBUS<n>:I2S:TRIGger:AUDio command specifies the audio channel to trigger on:

- RIGHT – right channel.
- LEFT – left channel.
- EITHER – right or left channel.

Query Syntax :SBUS<n>:I2S:TRIGger:AUDio?

The :SBUS<n>:I2S:TRIGger:AUDio? query returns the current audio channel for the I2S trigger.

Return Format <audio_ch><NL>

<audio_ch> ::= {RIGH | LEFT | EITH}

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":SBUS<n>:I2S:TRIGger"](#) on page 1077

:SBUS<n>:I2S:TRIGger:PATtern:DATA

N (see [page 1730](#))

Command Syntax :SBUS<n>:I2S:TRIGger:PATtern:DATA <string>

<string> ::= "n" where n ::= 32-bit integer in signed decimal when
<base> = DECimal

<string> ::= "nn...n" where n ::= {0 | 1 | X | \$} when
<base> = BINary

<string> ::= "0xnn...n" where n ::= {0,...,9 | A,...,F | X | \$} when
<base> = HEX

NOTE

<base> is specified with the :SBUS<n>:I2S:TRIGger:PATtern:FORMat command. The default <base> is DECimal.

The :SBUS<n>:I2S:TRIGger:PATtern:DATA command specifies the I2S trigger data pattern searched for in each I2S message.

Set a <string> bit to "0" or "1" to set the corresponding bit in the data pattern to low or high, respectively.

Set a <string> bit to "X" to ignore (mask off) that bit in the data pattern.

Use the "\$" character to indicate that the value of the corresponding bit will not be changed (the existing bit value is used).

When <base> = DECimal, the "X" and "\$" characters cannot be entered. When queried, the "\$" character is returned when any bits in the pattern have the value of "X" and <base> = DECimal. When any bits in a given nibble have the value of "X" and <base> = HEX, the "\$" character is returned for the corresponding nibble.

NOTE

The :SBUS<n>:I2S:TRIGger:PATtern:DATA command specifies the I2S trigger data pattern used by the EQUal, NOTequal, GREaterthan, and LESSthan trigger conditions. If the GREaterthan or LESSthan trigger condition is selected, the bits specified to be masked off ("X") will be interpreted as 0's.

NOTE

The length of the trigger data value is determined by the :SBUS<n>:I2S:RWIDth and :SBUS<n>:I2S:TWIDth commands. When the receiver word size is less than the transmitter word size, the data length is equal to the receiver word size. When the receiver word size is greater than the transmitter word size, the data length is equal to the transmitter word size.

NOTE

If more bits are sent for <string> than the specified trigger data length, the most significant bits will be truncated. If the word size is changed after the <string> is programmed, the added or deleted bits will be added to or deleted from the least significant bits.

Query Syntax :SBUS<n>:I2S:TRIGger:PATtern:DATA?

The :SBUS<n>:I2S:TRIGger:PATtern:DATA? query returns the currently specified I2S trigger data pattern.

Return Format <string><NL>

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":SBUS<n>:I2S:TRIGger:PATtern:FORMat"](#) on page 1082
 - [":SBUS<n>:I2S:TRIGger"](#) on page 1077
 - [":SBUS<n>:I2S:RWIDth"](#) on page 1073
 - [":SBUS<n>:I2S:TWIDth"](#) on page 1084
 - [":SBUS<n>:I2S:TRIGger:AUDio"](#) on page 1079

:SBUS<n>:I2S:TRIGger:PATtern:FORMat

N (see [page 1730](#))

Command Syntax :SBUS<n>:I2S:TRIGger:PATtern:FORMat <base>

<base> ::= {BINary | HEX | DECimal}

The :SBUS<n>:I2S:TRIGger:PATtern:FORMat command sets the entry (and query) number base used by the :SBUS<n>:I2S:TRIGger:PATtern:DATA command. The default <base> is DECimal.

Query Syntax :SBUS<n>:I2S:TRIGger:PATtern:FORMat?

The :SBUS<n>:I2S:TRIGger:PATtern:FORMat? query returns the currently set number base for I2S pattern data.

Return Format <base><NL>

<base> ::= {BIN | HEX | DEC}

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":SBUS<n>:I2S:TRIGger:AUDio"](#) on page 1079
 - [":SBUS<n>:I2S:TRIGger"](#) on page 1077

:SBUS<n>:I2S:TRIGger:RANGe

N (see [page 1730](#))

Command Syntax :SBUS<n>:I2S:TRIGger:RANGe <lower>,<upper>

<lower> ::= 32-bit integer in signed decimal, <nondecimal>
or <string>

<upper> ::= 32-bit integer in signed decimal, <nondecimal>,
or <string>

<nondecimal> ::= #Hnn...n where n ::= {0,...,9 | A,...,F}
for hexadecimal

<nondecimal> ::= #Bnn...n where n ::= {0 | 1} for binary

<string> ::= "0xnn...n" where n ::= {0,...,9 | A,...,F} for hexadecimal

The :SBUS<n>:I2S:TRIGger:RANGe command sets the lower and upper range boundaries used by the INRange, OUTRange, INCReasing, and DECReasing trigger conditions. You can enter the parameters in any order – the smaller value becomes the <lower> and the larger value becomes the <upper>.

Note that for INCReasing and DECReasing, the <lower> and <upper> values correspond to the "Armed" and "Trigger" softkeys.

NOTE

The length of the <lower> and <upper> values is determined by the :SBUS<n>:I2S:RWIDth and :SBUS<n>:I2S:TWIDth commands. When the receiver word size is less than the transmitter word size, the length is equal to the receiver word size. When the receiver word size is greater than the transmitter word size, the length is equal to the transmitter word size.

Query Syntax :SBUS<n>:I2S:TRIGger:RANGe?

The :SBUS<n>:I2S:TRIGger:RANGe? query returns the currently set lower and upper range boundaries.

Return Format <lower>,<upper><NL>

<lower> ::= 32-bit integer in signed decimal

<upper> ::= 32-bit integer in signed decimal

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":SBUS<n>:I2S:TRIGger"](#) on page 1077
 - [":SBUS<n>:I2S:RWIDth"](#) on page 1073
 - [":SBUS<n>:I2S:TWIDth"](#) on page 1084
 - [":SBUS<n>:I2S:WSLow"](#) on page 1085

:SBUS<n>:I2S:TWIDth

N (see [page 1730](#))

Command Syntax :SBUS<n>:I2S:TWIDth <word_size>

<word_size> ::= 4-32 in NR1 format

The :SBUS<n>:I2S:TWIDth command sets the width of the transmitted data word in I2S anywhere from 4 bits to 32 bits.

Query Syntax :SBUS<n>:I2S:TWIDth?

The :SBUS<n>:I2S:TWIDth? query returns the currently set I2S transmitted data word width.

Return Format <word_size><NL>

<word_size> ::= 4-32 in NR1 format

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":SBUS<n>:I2S:ALIGNment"](#) on page 1070
 - [":SBUS<n>:I2S:CLOCK:SLOPe"](#) on page 1072
 - [":SBUS<n>:I2S:RWIDth"](#) on page 1073
 - [":SBUS<n>:I2S:WSLow"](#) on page 1085

:SBUS<n>:I2S:WSLow

N (see [page 1730](#))

Command Syntax :SBUS<n>:I2S:WSLow <low_def>

<low_def> ::= {LEFT | RIGHT}

The :SBUS<n>:I2S:WSLow command selects the polarity of the word select (WS) signal:

- LEFT— a word select (WS) state of low indicates left channel data is active on the I2S bus, and a WS state of high indicates right channel data is active on the bus.
- RIGHT — a word select (WS) state of low indicates right channel data is active on the I2S bus, and a WS state of high indicates left channel data is active on the bus.

Query Syntax :SBUS<n>:I2S:WSLow?

The :SBUS<n>:I2S:WSLow? query returns the currently selected I2S word select (WS) polarity.

Return Format <low_def><NL>

<low_def> ::= {LEFT | RIGHT}

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":SBUS<n>:I2S:ALIGNment"](#) on page 1070
 - [":SBUS<n>:I2S:CLOCK:SLOPe"](#) on page 1072
 - [":SBUS<n>:I2S:RWIDth"](#) on page 1073
 - [":SBUS<n>:I2S:TWIDth"](#) on page 1084

:SBUS<n>:IIC Commands

NOTE

These commands are only valid when the low-speed IIC and SPI serial decode option has been licensed.

Table 133 :SBUS<n>:IIC Commands Summary

Command	Query	Options and Query Returns
:SBUS<n>:IIC:ASIZE <size> (see page 1088)	:SBUS<n>:IIC:ASIZE? (see page 1088)	<size> ::= {BIT7 BIT8}
:SBUS<n>:IIC[:SOURce] :CLOCK <source> (see page 1089)	:SBUS<n>:IIC[:SOURce] :CLOCK? (see page 1089)	<source> ::= {CHANnel<n> EXTernal} for DSO models <source> ::= {CHANnel<n> DIGital<d>} for MSO models <n> ::= 1 to (# analog channels) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format
:SBUS<n>:IIC[:SOURce] :DATA <source> (see page 1090)	:SBUS<n>:IIC[:SOURce] :DATA? (see page 1090)	<source> ::= {CHANnel<n> EXTernal} for DSO models <source> ::= {CHANnel<n> DIGital<d>} for MSO models <n> ::= 1 to (# analog channels) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format
:SBUS<n>:IIC:TRIGger: PATtern:ADDRESS <value> (see page 1091)	:SBUS<n>:IIC:TRIGger: PATtern:ADDRESS? (see page 1091)	<value> ::= integer or <string> <string> ::= "0xnn" n ::= {0,...,9 A,...,F}
:SBUS<n>:IIC:TRIGger: PATtern:DATA <value> (see page 1092)	:SBUS<n>:IIC:TRIGger: PATtern:DATA? (see page 1092)	<value> ::= integer or <string> <string> ::= "0xnn" n ::= {0,...,9 A,...,F}
:SBUS<n>:IIC:TRIGger: PATtern:DATA2 <value> (see page 1093)	:SBUS<n>:IIC:TRIGger: PATtern:DATA2? (see page 1093)	<value> ::= integer or <string> <string> ::= "0xnn" n ::= {0,...,9 A,...,F}

Table 133 :SBUS<n>:IIC Commands Summary (continued)

Command	Query	Options and Query Returns
:SBUS<n>:IIC:TRIGger: QUALifier <value> (see page 1094)	:SBUS<n>:IIC:TRIGger: QUALifier? (see page 1094)	<value> ::= {EQUAL NOTequal LESSthan GREATERthan}
:SBUS<n>:IIC:TRIGger[:TYPE] <type> (see page 1095)	:SBUS<n>:IIC:TRIGger[:TYPE]? (see page 1095)	<type> ::= {START STOP REStart ADDRESS ANACK DNACK NACKnowledge READEprom READ7 WRITe7 R7Data2 W7Data2 WRITe10}

:SBUS<n>:IIC:ASIZe

N (see [page 1730](#))

Command Syntax :SBUS<n>:IIC:ASIZe <size>

<size> ::= {BIT7 | BIT8}

The :SBUS<n>:IIC:ASIZe command determines whether the Read/Write bit is included as the LSB in the display of the IIC address field of the decode bus.

Query Syntax :SBUS<n>:IIC:ASIZe?

The :SBUS<n>:IIC:ASIZe? query returns the current IIC address width setting.

Return Format <mode><NL>

<mode> ::= {BIT7 | BIT8}

Errors • ["-241, Hardware missing"](#) on page 1671

See Also • ["Introduction to :SBUS<n> Commands"](#) on page 977

• [":SBUS<n>:IIC Commands"](#) on page 1086

:SBUS<n>:IIC[:SOURce]:CLOCK

N (see [page 1730](#))

Command Syntax :SBUS<n>:IIC[:SOURce]:CLOCK <source>

<source> ::= {CHANnel<n> | EXTernal} for the DSO models

<source> ::= {CHANnel<n> | DIGital<d>} for the MSO models

<n> ::= 1 to (# analog channels) in NR1 format

<d> ::= 0 to (# digital channels - 1) in NR1 format

The :SBUS<n>:IIC[:SOURce]:CLOCK command sets the source for the IIC serial clock (SCL).

Query Syntax :SBUS<n>:IIC[:SOURce]:CLOCK?

The :SBUS<n>:IIC[:SOURce]:CLOCK? query returns the current source for the IIC serial clock.

Return Format <source><NL>

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":SBUS<n>:IIC\[:SOURce\]:DATA"](#) on page 1090

:SBUS<n>:IIC[:SOURce]:DATA

N (see [page 1730](#))

Command Syntax :SBUS<n>:IIC[:SOURce]:DATA <source>

<source> ::= {CHANnel<n> | EXTernal} for the DSO models

<source> ::= {CHANnel<n> | DIGital<d>} for the MSO models

<n> ::= 1 to (# analog channels) in NR1 format

<d> ::= 0 to (# digital channels - 1) in NR1 format

The :SBUS<n>:IIC[:SOURce]:DATA command sets the source for IIC serial data (SDA).

Query Syntax :SBUS<n>:IIC[:SOURce]:DATA?

The :SBUS<n>:IIC[:SOURce]:DATA? query returns the current source for IIC serial data.

Return Format <source><NL>

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":SBUS<n>:IIC\[:SOURce\]:CLOCK"](#) on page 1089

:SBUS<n>:IIC:TRIGger:PATtern:ADDress

N (see [page 1730](#))

Command Syntax :SBUS<n>:IIC:TRIGger:PATtern:ADDress <value>

<value> ::= integer or <string>

<string> ::= "0xnn" where n ::= {0,...,9 | A,...,F}

The :SBUS<n>:IIC:TRIGger:PATtern:ADDress command sets the address for IIC data. The address can range from 0x00 to 0x7F (7-bit) or 0x3FF (10-bit) hexadecimal. Use the don't care address (-1 or 0xFFFFFFFF) to ignore the address value.

Query Syntax :SBUS<n>:IIC:TRIGger:PATtern:ADDress?

The :SBUS<n>:IIC:TRIGger:PATtern:ADDress? query returns the current address for IIC data.

Return Format <value><NL>

<value> ::= integer

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":SBUS<n>:IIC:TRIGger:PATtern:DATA"](#) on page 1092
 - [":SBUS<n>:IIC:TRIGger:PATtern:DATA2"](#) on page 1093
 - [":SBUS<n>:IIC:TRIGger\[:TYPE\]"](#) on page 1095

:SBUS<n>:IIC:TRIGger:PATtern:DATA

N (see [page 1730](#))

Command Syntax :SBUS<n>:IIC:TRIGger:PATtern:DATA <value>

<value> ::= integer or <string>

<string> ::= "0xnn" where n ::= {0,...,9 | A,...,F}

The :SBUS<n>:IIC:TRIGger:PATtern:DATA command sets IIC data. The data value can range from 0x00 to 0xFF (hexadecimal). Use the don't care data pattern (-1 or 0xFFFFFFFF) to ignore the data value.

Query Syntax :SBUS<n>:IIC:TRIGger:PATtern:DATA?

The :SBUS<n>:IIC:TRIGger:PATtern:DATA? query returns the current pattern for IIC data.

Return Format <value><NL>

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":SBUS<n>:IIC:TRIGger:PATtern:ADDRess"](#) on page 1091
 - [":SBUS<n>:IIC:TRIGger:PATtern:DATA2"](#) on page 1093
 - [":SBUS<n>:IIC:TRIGger\[:TYPE\]"](#) on page 1095

:SBUS<n>:IIC:TRIGger:PATtern:DATA2

N (see [page 1730](#))

Command Syntax :SBUS<n>:IIC:TRIGger:PATtern:DATA2 <value>

<value> ::= integer or <string>

<string> ::= "0xnn" where n ::= {0,...,9 | A,...,F}

The :SBUS<n>:IIC:TRIGger:PATtern:DATA2 command sets IIC data 2. The data value can range from 0x00 to 0xFF (hexadecimal). Use the don't care data pattern (-1 or 0xFFFFFFFF) to ignore the data value.

Query Syntax :SBUS<n>:IIC:TRIGger:PATtern:DATA2?

The :SBUS<n>:IIC:TRIGger:PATtern:DATA2? query returns the current pattern for IIC data 2.

Return Format <value><NL>

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":SBUS<n>:IIC:TRIGger:PATtern:ADDRESS"](#) on page 1091
 - [":SBUS<n>:IIC:TRIGger:PATtern:DATA"](#) on page 1092
 - [":SBUS<n>:IIC:TRIGger\[:TYPE\]"](#) on page 1095

:SBUS<n>:IIC:TRIGger:QUALifier

N (see [page 1730](#))

Command Syntax :SBUS<n>:IIC:TRIGger:QUALifier <value>

<value> ::= {EQUAL | NOTequal | LESSthan | GREATERthan}

The :SBUS<n>:IIC:TRIGger:QUALifier command sets the IIC data qualifier when TRIGger:IIC:TRIGger[:TYPE] is set to READEprom.

Query Syntax :SBUS<n>:IIC:TRIGger:QUALifier?

The :SBUS<n>:IIC:TRIGger:QUALifier? query returns the current IIC data qualifier value.

Return Format <value><NL>

<value> ::= {EQUAL | NOTequal | LESSthan | GREATERthan}

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:MODE"](#) on page 1439
 - [":SBUS<n>:IIC:TRIGger\[:TYPE\]"](#) on page 1095

:SBUS<n>:IIC:TRIGger[:TYPE]

N (see [page 1730](#))

Command Syntax :SBUS<n>:IIC:TRIGger[:TYPE] <value>

```
<value> ::= {START | STOP | REStart | ADDRess | ANACk | DNACk
            | NACKnowledge | READEprom | READ7 | WRITe7 | R7Data2 | W7Data2
            | WRITe10}
```

The :SBUS<n>:IIC:TRIGger[:TYPE] command sets the IIC trigger type:

- START – Start condition.
- STOP – Stop condition.
- REStart – Another start condition occurs before a stop condition.
- ADDRess – Triggers on the selected address. The R/W bit is ignored.
- ANACk – Address with no acknowledge.
- DNACk – Write data with no acknowledge.
- NACKnowledge – Missing acknowledge.
- READEprom – EEPROM data read.
- READ7 – 7-bit address frame containing (Start:Address7:Read:Ack:Data). The value READ is also accepted for READ7.
- WRITe7 – 7-bit address frame containing (Start:Address7:Write:Ack:Data). The value WRITe is also accepted for WRITe7.
- R7Data2 – 7-bit address frame containing (Start:Address7:Read:Ack:Data:Ack:Data2).
- W7Data2 – 7-bit address frame containing (Start:Address7:Write:Ack:Data:Ack:Data2).
- WRITe10 – 10-bit address frame containing (Start:Address byte1:Write:Ack:Address byte 2:Data).

NOTE

The short form of READ7 (READ7), READEprom (READE), WRITe7 (WRIT7), and WRITe10 (WRIT10) do not follow the defined Long Form to Short Form Truncation Rules (see [page 1732](#)).

Query Syntax :SBUS<n>:IIC:TRIGger[:TYPE] ?

The :SBUS<n>:IIC:TRIGger[:TYPE]? query returns the current IIC trigger type value.

Return Format <value><NL>

```
<value> ::= {STAR | STOP | REST | ADDR | ANAC | DNAC | NACK | READE
            | READ7 | WRIT7 | R7D2 | W7D2 | WRIT10}
```

See Also • ["Introduction to :TRIGger Commands"](#) on page 1425

- **":TRIGger:MODE"** on page 1439
- **":SBUS<n>:IIC:TRIGger:PATtern:ADDResS"** on page 1091
- **":SBUS<n>:IIC:TRIGger:PATtern:DATA"** on page 1092
- **":SBUS<n>:IIC:TRIGger:PATtern:DATA2"** on page 1093
- **":SBUS<n>:IIC:TRIGger:QUALifier"** on page 1094
- **"Long Form to Short Form Truncation Rules"** on page 1732

:SBUS<n>:LIN Commands

NOTE

These commands are valid when the CAN and LIN serial decode license has been enabled.

Table 134 :SBUS<n>:LIN Commands Summary

Command	Query	Options and Query Returns
:SBUS<n>:LIN:DISPlay <type> (see page 1099)	:SBUS<n>:LIN:DISPlay? (see page 1099)	<type> ::= {HEXadecimal SYMBOLic}
:SBUS<n>:LIN:PARity { {0 OFF} {1 ON} } (see page 1100)	:SBUS<n>:LIN:PARity? (see page 1100)	{0 1}
:SBUS<n>:LIN:SAMPlepo int <value> (see page 1101)	:SBUS<n>:LIN:SAMPlepo int? (see page 1101)	<value> ::= {60 62.5 68 70 75 80 87.5} in NR3 format
:SBUS<n>:LIN:SIGNAL:B AUDrate <baudrate> (see page 1102)	:SBUS<n>:LIN:SIGNAL:B AUDrate? (see page 1102)	<baudrate> ::= integer from 2400 to 625000 in 100 b/s increments
:SBUS<n>:LIN:SOURce <source> (see page 1103)	:SBUS<n>:LIN:SOURce? (see page 1103)	<source> ::= {CHANnel<n> EXTernal} for DSO models <source> ::= {CHANnel<n> DIGital<d>} for MSO models <n> ::= 1 to (# analog channels) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format
:SBUS<n>:LIN:STANdard <std> (see page 1104)	:SBUS<n>:LIN:STANdard ? (see page 1104)	<std> ::= {LIN13 LIN13NLC LIN20}
:SBUS<n>:LIN:SYNCbrea k <value> (see page 1105)	:SBUS<n>:LIN:SYNCbrea k? (see page 1105)	<value> ::= integer = {11 12 13}
:SBUS<n>:LIN:TRIGger <condition> (see page 1106)	:SBUS<n>:LIN:TRIGger? (see page 1106)	<condition> ::= {SYNCbreak ID DATA}

Table 134 :SBUS<n>:LIN Commands Summary (continued)

Command	Query	Options and Query Returns
:SBUS<n>:LIN:TRIGger:ID <value> (see page 1108)	:SBUS<n>:LIN:TRIGger:ID? (see page 1108)	<value> ::= 7-bit integer in decimal, <nondecimal>, or <string> from 0-63 or 0x00-0xf <nondecimal> ::= #Hnn where n ::= {0,...,9 A,...,F} for hexadecimal <nondecimal> ::= #Bnn...n where n ::= {0 1} for binary <string> ::= "0xnn" where n ::= {0,...,9 A,...,F} for hexadecimal
:SBUS<n>:LIN:TRIGger:PATtern:DATA <string> (see page 1109)	:SBUS<n>:LIN:TRIGger:PATtern:DATA? (see page 1109)	<string> ::= "n" where n ::= 32-bit integer in unsigned decimal when <base> = DECimal <string> ::= "nn...n" where n ::= {0 1 X \$} when <base> = BINary <string> ::= "0xnn...n" where n ::= {0,...,9 A,...,F X \$} when <base> = HEX
:SBUS<n>:LIN:TRIGger:PATtern:DATA:LENGth <length> (see page 1111)	:SBUS<n>:LIN:TRIGger:PATtern:DATA:LENGth? (see page 1111)	<length> ::= integer from 1 to 8 in NR1 format
:SBUS<n>:LIN:TRIGger:PATtern:FORMat <base> (see page 1112)	:SBUS<n>:LIN:TRIGger:PATtern:FORMat? (see page 1112)	<base> ::= {BINary HEX DECimal}
:SBUS<n>:LIN:TRIGger:SYMBolic:FRAMe <name> (see page 1113)	:SBUS<n>:LIN:TRIGger:SYMBolic:FRAMe? (see page 1113)	<name> ::= quoted ASCII string
:SBUS<n>:LIN:TRIGger:SYMBolic:SIGNal <name> (see page 1114)	:SBUS<n>:LIN:TRIGger:SYMBolic:SIGNal? (see page 1114)	<name> ::= quoted ASCII string
:SBUS<n>:LIN:TRIGger:SYMBolic:VALue <data> (see page 1115)	:SBUS<n>:LIN:TRIGger:SYMBolic:VALue? (see page 1115)	<data> ::= value in NR3 format

:SBUS<n>:LIN:DISPlay

N (see [page 1730](#))

Command Syntax :SBUS<n>:LIN:DISPlay <type>
 <type> ::= {HEXadecimal | SYMBolic}

The :SBUS<n>:LIN:DISPlay command specifies, when LIN symbolic data is loaded into the oscilloscope, whether symbolic values (from the LDF file) or hexadecimal values are displayed in the decode waveform and the Lister window.

Query Syntax :SBUS<n>:LIN:DISPlay?

The :SBUS<n>:LIN:DISPlay? query returns the LIN decode display type.

Return Format <type><NL>
 <type> ::= {HEX | SYMB}

See Also • [":RECall:LDF\[:START\]"](#) on page 931

:SBUS<n>:LIN:PARity

N (see [page 1730](#))

Command Syntax :SBUS<n>:LIN:PARity <display>

<display> ::= {{1 | ON} | {0 | OFF}}

The :SBUS<n>:LIN:PARity command determines whether the parity bits are included as the most significant bits (MSB) in the display of the Frame Id field in the LIN decode bus.

Query Syntax :SBUS<n>:LIN:PARity?

The :SBUS<n>:LIN:PARity? query returns the current LIN parity bits display setting of the serial decode bus.

Return Format <display><NL>

<display> ::= {0 | 1}

Errors • ["-241, Hardware missing"](#) on page 1671

See Also • ["Introduction to :SBUS<n> Commands"](#) on page 977

• [":SBUS<n>:LIN Commands"](#) on page 1097

:SBUS<n>:LIN:SAMPlEpoint

N (see [page 1730](#))

Command Syntax :SBUS<n>:LIN:SAMPlEpoint <value>

<value><NL>

<value> ::= {60 | 62.5 | 68 | 70 | 75 | 80 | 87.5} in NR3 format

The :SBUS<n>:LIN:SAMPlEpoint command sets the point during the bit time where the bit level is sampled to determine whether the bit is dominant or recessive. The sample point represents the percentage of time between the beginning of the bit time to the end of the bit time.

NOTE

The sample point values are not limited by the baud rate.

Query Syntax :SBUS<n>:LIN:SAMPlEpoint?

The :SBUS<n>:LIN:SAMPlEpoint? query returns the current LIN sample point setting.

Return Format <value><NL>

<value> ::= {60 | 62.5 | 68 | 70 | 75 | 80 | 87.5} in NR3 format

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:MODE"](#) on page 1439
 - [":SBUS<n>:LIN:TRIGger"](#) on page 1106

:SBUS<n>:LIN:SIGNal:BAUDrate

N (see [page 1730](#))

Command Syntax :SBUS<n>:LIN:SIGNal:BAUDrate <baudrate>

<baudrate> ::= integer from 2400 to 625000 in 100 b/s increments

The :SBUS<n>:LIN:SIGNal:BAUDrate command sets the standard baud rate of the LIN signal from 2400 b/s to 625 kb/s in 100 b/s increments. If you enter a baud rate that is not divisible by 100 b/s, the baud rate is set to the nearest baud rate divisible by 100 b/s.

Query Syntax :SBUS<n>:LIN:SIGNal:BAUDrate?

The :SBUS<n>:LIN:SIGNal:BAUDrate? query returns the current LIN baud rate setting.

Return Format <baudrate><NL>

<baudrate> ::= integer from 2400 to 625000 in 100 b/s increments

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:MODE"](#) on page 1439
 - [":SBUS<n>:LIN:TRIGger"](#) on page 1106
 - [":SBUS<n>:LIN:SIGNal:DEFinition"](#) on page 1663
 - [":SBUS<n>:LIN:SOURce"](#) on page 1103

:SBUS<n>:LIN:SOURce

N (see [page 1730](#))

Command Syntax :SBUS<n>:LIN:SOURce <source>

<source> ::= {CHANnel<n> | EXTernal} for the DSO models

<source> ::= {CHANnel<n> | DIGital<d>} for the MSO models

<n> ::= 1 to (# analog channels) in NR1 format

<d> ::= 0 to (# digital channels - 1) in NR1 format

The :SBUS<n>:LIN:SOURce command sets the source for the LIN signal.

Query Syntax :SBUS<n>:LIN:SOURce?

The :SBUS<n>:LIN:SOURce? query returns the current source for the LIN signal.

Return Format <source><NL>

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:MODE"](#) on page 1439
 - [":SBUS<n>:LIN:TRIGger"](#) on page 1106
 - [":SBUS<n>:LIN:SIGNAL:DEFinition"](#) on page 1663

:SBUS<n>:LIN:STANdard

N (see [page 1730](#))

Command Syntax :SBUS<n>:LIN:STANdard <std>

<std> ::= {LIN13 | LIN13NLC | LIN20}

The :SBUS<n>:LIN:STANdard command sets the LIN standard in effect for triggering and decoding:

- LIN13 – LIN 1.3.
- LIN13NLC – LIN 1.3 (no length control). Select this for systems where length control is not used and all nodes have knowledge of the data packet size. In LIN 1.3, the ID may or may not be used to indicate the number of bytes. (In LIN 2.X, there is no length control.)
- LIN20 – LIN 2.X.

For LIN 1.2 signals, use the LIN 1.3 setting. The LIN 1.3 setting assumes the signal follows the "Table of Valid ID Values" as shown in section A.2 of the LIN Specification dated December 12, 2002. If your signal does not comply with the table, use the LIN 2.X setting.

Query Syntax :SBUS<n>:LIN:STANdard?

The :SBUS<n>:LIN:STANdard? query returns the current LIN standard setting.

Return Format <std><NL>

<std> ::= {LIN13 | LIN13NLC | LIN20}

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:MODE"](#) on page 1439
 - [":SBUS<n>:LIN:SIGNal:DEFinition"](#) on page 1663
 - [":SBUS<n>:LIN:SOURce"](#) on page 1103

:SBUS<n>:LIN:SYNCbreak

N (see [page 1730](#))

Command Syntax :SBUS<n>:LIN:SYNCbreak <value>

<value> ::= integer = {11 | 12 | 13}

The :SBUS<n>:LIN:SYNCbreak command sets the length of the LIN sync break to be greater than or equal to 11, 12, or 13 clock lengths. The sync break is the idle period in the bus activity at the beginning of each packet that distinguishes one information packet from the previous one.

Query Syntax :SBUS<n>:LIN:SYNCbreak?

The :SBUS<n>:LIN:SYNCbreak? query returns the current LIN sync break setting.

Return Format <value><NL>

<value> ::= {11 | 12 | 13}

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:MODE"](#) on page 1439
 - [":SBUS<n>:LIN:SIGNal:DEFinition"](#) on page 1663
 - [":SBUS<n>:LIN:SOURce"](#) on page 1103

:SBUS<n>:LIN:TRIGger

N (see [page 1730](#))

Command Syntax :SBUS<n>:LIN:TRIGger <condition>

```
<condition> ::= {SYNCbreak | ID | DATA | PARityerror | CSUMerror
                | FRAME | FSIGnal}
```

The :SBUS<n>:LIN:TRIGger command sets the LIN trigger condition to be:

- SYNCbreak – Sync Break.
- ID – Frame ID.

Use the :SBUS<n>:LIN:TRIGger:ID command to specify the frame ID.

- DATA – Frame ID and Data.

Use the :SBUS<n>:LIN:TRIGger:ID command to specify the frame ID.

Use the :SBUS<n>:LIN:TRIGger:PATtern:DATA:LENGth and :SBUS<n>:LIN:TRIGger:PATtern:DATA commands to specify the data string length and value.

- PARityerror – parity errors.
- CSUMerror – checksum errors.
- FRAME – Triggers on a symbolic frame.
- FSIGnal – Triggers on a symbolic frame and a signal value.

Query Syntax :SBUS<n>:LIN:TRIGger?

The :SBUS<n>:LIN:TRIGger? query returns the current LIN trigger value.

Return Format <condition><NL>

```
<condition> ::= {SYNC | ID | DATA | PAR | CSUM | FRAM | FSIG}
```

Errors • ["-241, Hardware missing"](#) on page 1671

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:MODE"](#) on page 1439
 - [":SBUS<n>:LIN:TRIGger:ID"](#) on page 1108
 - [":SBUS<n>:LIN:TRIGger:PATtern:DATA:LENGth"](#) on page 1111
 - [":SBUS<n>:LIN:TRIGger:PATtern:DATA"](#) on page 1109
 - [":SBUS<n>:LIN:SIGnal:DEFinition"](#) on page 1663
 - [":SBUS<n>:LIN:SOURce"](#) on page 1103
 - [":RECall:LDF\[:START\]"](#) on page 931
 - [":SBUS<n>:LIN:TRIGger:SYMBolic:FRAME"](#) on page 1113
 - [":SBUS<n>:LIN:TRIGger:SYMBolic:SIGnal"](#) on page 1114

- [":SBUS<n>:LIN:TRIGger:SYMBolic:VALue"](#) on page 1115

:SBUS<n>:LIN:TRIGger:ID

N (see [page 1730](#))

Command Syntax :SBUS<n>:LIN:TRIGger:ID <value>

<value> ::= 7-bit integer in decimal, <nondecimal>, or <string>
from 0-63 or 0x00-0x3f

<nondecimal> ::= #Hnn where n ::= {0,...,9 | A,...,F} for hexadecimal

<nondecimal> ::= #Bnn...n where n ::= {0 | 1} for binary

<string> ::= "0xnn" where n ::= {0,...,9 | A,...,F} for hexadecimal

The :SBUS<n>:LIN:TRIGger:ID command defines the LIN identifier searched for in each CAN message when the LIN trigger mode is set to frame ID.

Setting the ID to a value of "-1" results in "0xXX" which is equivalent to all IDs.

Query Syntax :SBUS<n>:LIN:TRIGger:ID?

The :SBUS<n>:LIN:TRIGger:ID? query returns the current LIN identifier setting.

Return Format <value><NL>

<value> ::= integer in decimal

Errors • ["-241, Hardware missing"](#) on page 1671

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:MODE"](#) on page 1439
 - [":SBUS<n>:LIN:TRIGger"](#) on page 1106
 - [":SBUS<n>:LIN:SIGNAL:DEFinition"](#) on page 1663
 - [":SBUS<n>:LIN:SOURce"](#) on page 1103

:SBUS<n>:LIN:TRIGger:PATtern:DATA

N (see [page 1730](#))

Command Syntax :SBUS<n>:LIN:TRIGger:PATtern:DATA <string>

<string> ::= "n" where n ::= 32-bit integer in unsigned decimal when
<base> = DECimal

<string> ::= "nn...n" where n ::= {0 | 1 | X | \$} when
<base> = BINary

<string> ::= "0xnn...n" where n ::= {0,...,9 | A,...,F | X | \$} when
<base> = HEX

NOTE

<base> is specified with the :SBUS<n>:LIN:TRIGger:PATtern:FORMat command. The default <base> is BINary.

The :SBUS<n>:LIN:TRIGger:PATtern:DATA command specifies the LIN trigger data pattern searched for in each LIN data field.

Set a <string> bit to "0" or "1" to set the corresponding bit in the data pattern to low or high, respectively.

Set a <string> bit to "X" to ignore (mask off) that bit in the data pattern.

Use the "\$" character to indicate that the value of the corresponding bit will not be changed (the existing bit value is used).

When <base> = DECimal, the "X" and "\$" characters cannot be entered. When queried, the "\$" character is returned when any bits in the pattern have the value of "X" and <base> = DECimal. When any bits in a given nibble have the value of "X" and <base> = HEX, the "\$" character is returned for the corresponding nibble.

NOTE

The length of the trigger data value is determined by the :SBUS<n>:LIN:TRIGger:PATtern:DATA:LENGth command.

NOTE

If more bits are sent for <string> than the specified trigger pattern data length, the most significant bits will be truncated. If the data length size is changed after the <string> is programmed, the added or deleted bits will be added to or deleted from the least significant bits.

Query Syntax :SBUS<n>:LIN:TRIGger:PATtern:DATA?

The :SBUS<n>:LIN:TRIGger:PATtern:DATA? query returns the currently specified LIN trigger data pattern.

Return Format <string><NL>

- See Also**
- [":SBUS<n>:LIN:TRIGger:COMMANDS"](#) on page 1425
 - [":SBUS<n>:LIN:TRIGger:PATTERN:FORMAT"](#) on page 1112
 - [":SBUS<n>:LIN:TRIGger"](#) on page 1106
 - [":SBUS<n>:LIN:TRIGger:PATTERN:DATA:LENGTH"](#) on page 1111

:SBUS<n>:LIN:TRIGger:PATtern:DATA:LENGth

N (see [page 1730](#))

Command Syntax :SBUS<n>:LIN:TRIGger:PATtern:DATA:LENGth <length>

<length> ::= integer from 1 to 8 in NR1 format

The :SBUS<n>:LIN:TRIGger:PATtern:DATA:LENGth command sets the number of 8-bit bytes in the LIN data string. The number of bytes in the string can be anywhere from 1 bytes to 8 bytes (64 bits). The value for these bytes is set by the :SBUS<n>:LIN:TRIGger:PATtern:DATA command.

Query Syntax :SBUS<n>:LIN:TRIGger:PATtern:DATA:LENGth?

The :SBUS<n>:LIN:TRIGger:PATtern:DATA:LENGth? query returns the current LIN data pattern length setting.

Return Format <count><NL>

<count> ::= integer from 1 to 8 in NR1 format

Errors • ["-241, Hardware missing"](#) on page 1671

- See Also** • ["Introduction to :TRIGger Commands"](#) on page 1425
- [":SBUS<n>:LIN:TRIGger:PATtern:DATA"](#) on page 1109
 - [":SBUS<n>:LIN:SOURce"](#) on page 1103

:SBUS<n>:LIN:TRIGger:PATtern:FORMat

N (see [page 1730](#))

Command Syntax :SBUS<n>:LIN:TRIGger:PATtern:FORMat <base>

<base> ::= {BINary | HEX | DECimal}

The :SBUS<n>:LIN:TRIGger:PATtern:FORMat command sets the entry (and query) number base used by the :SBUS<n>:LIN:TRIGger:PATtern:DATA command. The default <base> is BINary.

Query Syntax :SBUS<n>:LIN:TRIGger:PATtern:FORMat?

The :SBUS<n>:LIN:TRIGger:PATtern:FORMat? query returns the currently set number base for LIN pattern data.

Return Format <base><NL>

<base> ::= {BIN | HEX | DEC}

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":SBUS<n>:LIN:TRIGger:PATtern:DATA"](#) on page 1109
 - [":SBUS<n>:LIN:TRIGger:PATtern:DATA:LENGth"](#) on page 1111

:SBUS<n>:LIN:TRIGger:SYMBolic:FRAMe

N (see [page 1730](#))

Command Syntax :SBUS<n>:LIN:TRIGger:SYMBolic:FRAMe <name>

<name> ::= quoted ASCII string

The :SBUS<n>:LIN:TRIGger:SYMBolic:FRAMe command specifies the message to trigger on when LIN symbolic data has been loaded (recalled) into the oscilloscope and the LIN trigger mode is set to FRAMe or FSIGnal.

Query Syntax :SBUS<n>:LIN:TRIGger:SYMBolic:FRAMe?

The :SBUS<n>:LIN:TRIGger:SYMBolic:FRAMe? query returns the specified message.

Return Format <name><NL>

<name> ::= quoted ASCII string

- See Also**
- [":RECall:LDF\[:START\]"](#) on page 931
 - [":SBUS<n>:LIN:TRIGger"](#) on page 1106
 - [":SBUS<n>:LIN:TRIGger:SYMBolic:SIGNal"](#) on page 1114
 - [":SBUS<n>:LIN:TRIGger:SYMBolic:VALue"](#) on page 1115

:SBUS<n>:LIN:TRIGger:SYMBolic:SIGNal

N (see [page 1730](#))

Command Syntax :SBUS<n>:LIN:TRIGger:SYMBolic:SIGNal <name>

<name> ::= quoted ASCII string

The :SBUS<n>:LIN:TRIGger:SYMBolic:SIGNal command specifies the signal to trigger on when LIN symbolic data has been loaded (recalled) into the oscilloscope and the LIN trigger mode is set to FSIGNAL.

Query Syntax :SBUS<n>:LIN:TRIGger:SYMBolic:SIGNal?

The :SBUS<n>:LIN:TRIGger:SYMBolic:SIGNal? query returns the specified signal.

Return Format <name><NL>

<name> ::= quoted ASCII string

- See Also**
- [":RECall:LDF\[:START\]"](#) on page 931
 - [":SBUS<n>:LIN:TRIGger"](#) on page 1106
 - [":SBUS<n>:LIN:TRIGger:SYMBolic:FRAME"](#) on page 1113
 - [":SBUS<n>:LIN:TRIGger:SYMBolic:VALue"](#) on page 1115

:SBUS<n>:LIN:TRIGger:SYMBolic:VALue

N (see [page 1730](#))

Command Syntax :SBUS<n>:LIN:TRIGger:SYMBolic:VALue <data>

<data> ::= value in NR3 format

The :SBUS<n>:LIN:TRIGger:SYMBolic:VALue command specifies the signal value to trigger on when LIN symbolic data has been loaded (recalled) into the oscilloscope and the LIN trigger mode is set to FSIgnal.

NOTE

Encoded signal values are not supported in the remote interface (even though they can be used in the front panel graphical interface).

Query Syntax :SBUS<n>:LIN:TRIGger:SYMBolic:VALue?

The :SBUS<n>:LIN:TRIGger:SYMBolic:VALue? query returns the specified signal value.

Return Format <data><NL>

<data> ::= value in NR3 format

- See Also**
- [":RECall:LDF\[:START\]"](#) on page 931
 - [":SBUS<n>:LIN:TRIGger"](#) on page 1106
 - [":SBUS<n>:LIN:TRIGger:SYMBolic:FRAME"](#) on page 1113
 - [":SBUS<n>:LIN:TRIGger:SYMBolic:SIGNal"](#) on page 1114

:SBUS<n>:M1553 Commands

NOTE

These commands are valid when the MIL-STD-1553 and ARINC 429 triggering and serial decode license has been enabled.

Table 135 :SBUS<n>:M1553 Commands Summary

Command	Query	Options and Query Returns
:SBUS<n>:M1553:AUTOsetup (see page 1117)	n/a	n/a
:SBUS<n>:M1553:BASE<base> (see page 1118)	:SBUS<n>:M1553:BASE? (see page 1118)	<base> ::= {BINary HEX}
:SBUS<n>:M1553:SOURcE<source> (see page 1119)	:SBUS<n>:M1553:SOURcE? (see page 1119)	<source> ::= {CHANnel<n>} <n> ::= 1 to (# analog channels) in NR1 format
:SBUS<n>:M1553:TRIGger:PATtern:DATA<string> (see page 1120)	:SBUS<n>:M1553:TRIGger:PATtern:DATA? (see page 1120)	<string> ::= "nn...n" where n ::= {0 1 X}
:SBUS<n>:M1553:TRIGger:RTA<value> (see page 1121)	:SBUS<n>:M1553:TRIGger:RTA? (see page 1121)	<value> ::= 5-bit integer in decimal, <nondecimal>, or <string> from 0-31 <nondecimal> ::= #Hnn where n ::= {0,...,9 A,...,F} <string> ::= "0xnn" where n ::= {0,...,9 A,...,F}
:SBUS<n>:M1553:TRIGger:TYPE<type> (see page 1122)	:SBUS<n>:M1553:TRIGger:TYPE? (see page 1122)	<type> ::= {DStArt DStOp CStArt CStOp RTA PERRor SERRor MERRor RTA11}

:SBUS<n>:M1553:AUTOsetup

N (see [page 1730](#))

Command Syntax :SBUS<n>:M1553:TRIGger:AUTOsetup

The :SBUS<n>:M1553:AUTOsetup command automatically sets these options for decoding and triggering on MIL-STD-1553 signals:

- High/Low Trigger Thresholds: to a voltage value equal to $\pm 1/3$ division based on the source channel's current V/div setting.
- Noise Reject: Off.
- Probe Attenuation: 10.0.
- Serial Decode: On.
- Trigger: the specified serial bus (n of SBUS<n>).

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:MODE"](#) on page 1439
 - [":SBUS<n>:M1553:SOURce"](#) on page 1119

:SBUS<n>:M1553:BASE

N (see [page 1730](#))

Command Syntax :SBUS<n>:M1553:BASE <base>

<base> ::= {BINary | HEX}

The :SBUS<n>:M1553:BASE command determines the base to use for the MIL-STD-1553 decode display.

Query Syntax :SBUS<n>:M1553:BASE?

The :SBUS<n>:M1553:BASE? query returns the current MIL-STD-1553 display decode base.

Return Format <base><NL>

<base> ::= {BIN | HEX}

Errors • ["-241, Hardware missing"](#) on page 1671

See Also • ["Introduction to :SBUS<n> Commands"](#) on page 977
 • [":SBUS<n>:M1553 Commands"](#) on page 1116

:SBUS<n>:M1553:SOURce

N (see [page 1730](#))

Command Syntax :SBUS<n>:M1553:SOURce <source>

<source> ::= {CHANnel<n>}

<n> ::= 1 to (# analog channels) in NR1 format

The :SBUS<n>:M1553:SOURce command sets the source of the MIL-STD 1553 signal.

Use the :TRIGger:LEVel:HIGH and :TRIGger:LEVel:LOW commands to set the threshold levels for the selected source.

Query Syntax :SBUS<n>:M1553:TRIGger:SOURce?

The :SBUS<n>:M1553:SOURce? query returns the currently set source of the MIL-STD 1553 signal.

Return Format <source><NL>

<source> ::= {CHAN<n>}

<n> ::= 1 to (# analog channels) in NR1 format

- See Also**
- [":TRIGger:LEVel:HIGH"](#) on page 1437
 - [":TRIGger:LEVel:LOW"](#) on page 1438
 - [":TRIGger:MODE"](#) on page 1439
 - ["Introduction to :TRIGger Commands"](#) on page 1425

:SBUS<n>:M1553:TRIGger:PATtern:DATA

N (see [page 1730](#))

Command Syntax :SBUS<n>:M1553:TRIGger:PATtern:DATA <string>

<string> ::= "nn...n" where n ::= {0 | 1 | X}

The :SBUS<n>:M1553:TRIGger:PATtern:DATA command sets the 11 bits to trigger on if the trigger type has been set to RTA11 (RTA + 11 Bits) using the :SBUS<n>:M1553:TRIGger:TYPE command.

Query Syntax :SBUS<n>:M1553:TRIGger:PATtern:DATA?

The :SBUS<n>:M1553:TRIGger:PATtern:DATA? query returns the current 11-bit setting.

Return Format <string><NL>

<string> ::= "nn...n" where n ::= {0 | 1 | X}

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":SBUS<n>:M1553:TRIGger:TYPE"](#) on page 1122
 - [":SBUS<n>:M1553:TRIGger:RTA"](#) on page 1121

:SBUS<n>:M1553:TRIGger:RTA

N (see [page 1730](#))

Command Syntax :SBUS<n>:M1553:TRIGger:RTA <value>

<value> ::= 5-bit integer in decimal, <nondecimal>, or
<string> from 0-31

<nondecimal> ::= #Hnn where n ::= {0,...,9|A,...,F}

<string> ::= "0xnn" where n ::= {0,...,9|A,...,F}

The :SBUS<n>:M1553:TRIGger:RTA command sets the Remote Terminal Address (RTA) to trigger on when the trigger type has been set to RTA or RTA11 (using the :SBUS<n>:M1553:TRIGger:TYPE command).

To set the RTA value to don't cares (0xXX), set the value to -1.

Query Syntax :SBUS<n>:M1553:TRIGger:RTA?

The :SBUS<n>:M1553:TRIGger:RTA? query returns the RTA value.

Return Format <value><NL> in decimal format

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":SBUS<n>:M1553:TRIGger:TYPE"](#) on page 1122

:SBUS<n>:M1553:TRIGger:TYPE

N (see [page 1730](#))

Command Syntax :SBUS<n>:M1553:TRIGger:TYPE <type>

<type> ::= {DStArt | DStOp | CStArt | CStOp | RTA | PERRor | SERRor
| MERRor | RTA11}

The :SBUS<n>:M1553:TRIGger:TYPE command specifies the type of MIL-STD-1553 trigger to be used:

- DStArt – (Data Word Start) triggers on the start of a Data word (at the end of a valid Data Sync pulse).
- DStOp – (Data Word Stop) triggers on the end of a Data word.
- CStArt – (Command/Status Word Start) triggers on the start of Command/Status word (at the end of a valid C/S Sync pulse).
- CStOp – (Command/Status Word Stop) triggers on the end of a Command/Status word.
- RTA – (Remote Terminal Address) triggers if the RTA of the Command/Status word matches the specified value. The value is specified in hex.
- RTA11 – (RTA + 11 Bits) triggers if the RTA and the remaining 11 bits match the specified criteria. The RTA can be specified as a hex value, and the remaining 11 bits can be specified as a 1, 0, or X (don't care).
- PERRor – (Parity Error) triggers if the (odd) parity bit is incorrect for the data in the word.
- MERRor – (Manchester Error) triggers if a Manchester encoding error is detected.
- SERRor – (Sync Error) triggers if an invalid Sync pulse is found.

Query Syntax :SBUS<n>:M1553:TRIGger:TYPE?

The :SBUS<n>:M1553:TRIGger:TYPE? query returns the currently set MIL-STD-1553 trigger type.

Return Format <type><NL>

<type> ::= {DStA | DStO | CStA | CStO | RTA | PERR | SERR
| MERR | RTA11}

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":SBUS<n>:M1553:TRIGger:RTA"](#) on page 1121
 - [":SBUS<n>:M1553:TRIGger:PATtern:DATA"](#) on page 1120
 - [":TRIGger:MODE"](#) on page 1439

:SBUS<n>:MANChEster Commands

NOTE

These commands are valid when the automotive MANChEster serial decode and triggering option has been licensed.

Table 136 :SBUS<n>:MANChEster Commands Summary

Command	Query	Options and Query Returns
:SBUS<n>:MANChEster:BASE <base> (see page 1125)	:SBUS<n>:MANChEster:BASE? (see page 1125)	<base> ::= {HEX DECimal ASCii}
:SBUS<n>:MANChEster:BAUDrate <baudrate> (see page 1126)	:SBUS<n>:MANChEster:BAUDrate? (see page 1126)	<baudrate> ::= integer from 500 to 5000000 in 100 b/s increments
:SBUS<n>:MANChEster:BITorder <bitorder> (see page 1127)	:SBUS<n>:MANChEster:BITorder? (see page 1127)	<bitorder> ::= {MSBFirst LSBFirst}
:SBUS<n>:MANChEster:DISPlay <format> (see page 1128)	:SBUS<n>:MANChEster:DISPlay? (see page 1128)	<format> ::= {BIT WORD}
:SBUS<n>:MANChEster:DISize {AUTO <#words>} (see page 1129)	:SBUS<n>:MANChEster:DISize? (see page 1129)	<#words> ::= from 1-255, in NR1 format
:SBUS<n>:MANChEster:HSize <#bits> (see page 1130)	:SBUS<n>:MANChEster:HSize? (see page 1130)	<#bits> ::= from 0-32, in NR1 format
:SBUS<n>:MANChEster:IDLE:BITS <#bits> (see page 1131)	:SBUS<n>:MANChEster:IDLE:BITS? (see page 1131)	<#bits> ::= minimum idle time in terms of bit width, from 1.50 to 32.0, in NR3 format.
:SBUS<n>:MANChEster:LOGic <logic> (see page 1132)	:SBUS<n>:MANChEster:LOGic? (see page 1132)	<logic> ::= {FALLing RISing}
:SBUS<n>:MANChEster:SOURce <source> (see page 1133)	:SBUS<n>:MANChEster:SOURce? (see page 1133)	<source> ::= {CHANnel<n> DIGital<d>}
:SBUS<n>:MANChEster:SSize <#bits> (see page 1134)	:SBUS<n>:MANChEster:SSize? (see page 1134)	<#bits> ::= from 0-255, in NR1 format
:SBUS<n>:MANChEster:START <edge#> (see page 1135)	:SBUS<n>:MANChEster:START? (see page 1135)	<edge#> ::= from 1-256, in NR1 format

Table 136 :SBUS<n>:MANchester Commands Summary (continued)

Command	Query	Options and Query Returns
:SBUS<n>:MANchester:TOLerance <percent> (see page 1136)	:SBUS<n>:MANchester:TOLerance? (see page 1136)	<percent> ::= from 1-30, in NR1 format
:SBUS<n>:MANchester:T RIGger <mode> (see page 1137)	:SBUS<n>:MANchester:T RIGger? (see page 1137)	<mode> ::= {SOF VALue MERRor}
:SBUS<n>:MANchester:T RIGger:PATtern:VALue:DATA <string> (see page 1138)	:SBUS<n>:MANchester:T RIGger:PATtern:VALue:DATA? (see page 1138)	<string> ::= "nn...n" where n ::= {0 1 X \$} <string ::= "0xnn...n" where n ::= {0,...,9 A,...,F X \$}
:SBUS<n>:MANchester:T RIGger:PATtern:VALue:WIDTh <width> (see page 1139)	:SBUS<n>:MANchester:T RIGger:PATtern:VALue:WIDTh? (see page 1139)	<width> ::= integer from 4 to 128 in NR1 format
:SBUS<n>:MANchester:T SIZE <#bits> (see page 1140)	:SBUS<n>:MANchester:T SIZE? (see page 1140)	<#bits> ::= from 0-32, in NR1 format
:SBUS<n>:MANchester:W SIZE <#bits> (see page 1141)	:SBUS<n>:MANchester:W SIZE? (see page 1141)	<#bits> ::= from 2-32, in NR1 format

:SBUS<n>:MANChEster:BASE

N (see [page 1730](#))

Command Syntax :SBUS<n>:MANChEster:BASE <base>

<base> ::= {HEX | DECimal | ASCii | BINary}

When the display format is WORD (see :SBUS<n>:MANChEster:DISPlay), the :SBUS<n>:MANChEster:BASE command specifies the base for the Manchester bus decode and Lister display.

- HEX – hexadecimal
- DECimal – unsigned decimal
- ASCii

When the display format is BIT, the only legal decode base value is BINary.

Query Syntax :SBUS<n>:MANChEster:BASE?

The :SBUS<n>:MANChEster:BASE? query returns the decode number base setting.

Return Format <base><NL>

<base> ::= {HEX | DEC | ASC | BIN}

- See Also**
- [":SBUS<n>:MANChEster:BITOrder"](#) on page 1127
 - [":SBUS<n>:MANChEster:IDLE:BITS"](#) on page 1131
 - [":SBUS<n>:MANChEster:LOGic"](#) on page 1132
 - [":SBUS<n>:MANChEster:START"](#) on page 1135

:SBUS<n>:MANChester:BAUDrate

N (see [page 1730](#))

Command Syntax :SBUS<n>:MANChester:BAUDrate <baudrate>

<baudrate> ::= integer from 500 to 5000000 in 100 b/s increments

The :SBUS<n>:MANChester:BAUDrate command specifies the baud rate of the Manchester signal.

Query Syntax :SBUS<n>:MANChester:BAUDrate?

The :SBUS<n>:MANChester:BAUDrate? query returns the specified baud rate.

Return Format <baudrate><NL>

- See Also**
- [":SBUS<n>:MANChester:SOURce"](#) on page 1133
 - [":SBUS<n>:MANChester:TOLerance"](#) on page 1136

:SBUS<n>:MANChester:BITOrder

N (see [page 1730](#))

Command Syntax :SBUS<n>:MANChester:BITOrder <bitorder>

<bitorder> ::= {MSBFirst | LSBFirst}

When the display format is WORD (see :SBUS<n>:MANChester:DISPlay), the :SBUS<n>:MANChester:BITOrder command specifies the order of transmission on the Manchester bus:

- MSBFirst – specifies the most significant bit is transmitted first.
- LSBFirst – specifies the least significant bit is transmitted first.

Query Syntax :SBUS<n>:MANChester:BITOrder?

The :SBUS<n>:MANChester:BITOrder? query returns the bit order setting.

Return Format <bitorder><NL>

<bitorder> ::= {MSBF | LSBF}

- See Also**
- [":SBUS<n>:MANChester:BASE"](#) on page 1125
 - [":SBUS<n>:MANChester:IDLE:BITS"](#) on page 1131
 - [":SBUS<n>:MANChester:LOGic"](#) on page 1132
 - [":SBUS<n>:MANChester:START"](#) on page 1135

:SBUS<n>:MANChester:DISPlay

N (see [page 1730](#))

Command Syntax :SBUS<n>:MANChester:DISPlay <format>

<format> ::= {BIT | WORD}

The :SBUS<n>:MANChester:DISPlay command specifies the format of the Manchester bus display.

Query Syntax :SBUS<n>:MANChester:DISPlay?

The :SBUS<n>:MANChester:DISPlay? query returns the bus display format setting.

Return Format <format><NL>

<format> ::= {BIT | WORD}

- See Also**
- [":SBUS<n>:MANChester:DSIZE"](#) on page 1129
 - [":SBUS<n>:MANChester:HSIZE"](#) on page 1130
 - [":SBUS<n>:MANChester:SSIZE"](#) on page 1134
 - [":SBUS<n>:MANChester:TSIZE"](#) on page 1140
 - [":SBUS<n>:MANChester:WSIZE"](#) on page 1141

:SBUS<n>:MANChEster:DSIZe

N (see [page 1730](#))

Command Syntax :SBUS<n>:MANChEster:DSIZe {AUTO | <#words>}

<#words> ::= from 1-255, in NR1 format

When the display format is WORD (see :SBUS<n>:MANChEster:DISPlay), the :SBUS<n>:MANChEster:DSIZe command specifies the number of words in the data field of your Manchester protocol definition.

AUTO is available as a selection only when the trailer field size is 0 (see :SBUS<n>:MANChEster:TSIZe).

Query Syntax :SBUS<n>:MANChEster:DSIZe?

The :SBUS<n>:MANChEster:DSIZe? query returns the number of data field words setting.

Return Format <#words><NL>

<#words> ::= from 0-255, in NR1 format

In AUTO mode, the query returns 0.

In BIT format the only legal value is 0 (for AUTO).

- See Also**
- [":SBUS<n>:MANChEster:DISPlay"](#) on page 1128
 - [":SBUS<n>:MANChEster:HSIZe"](#) on page 1130
 - [":SBUS<n>:MANChEster:SSIZe"](#) on page 1134
 - [":SBUS<n>:MANChEster:TSIZe"](#) on page 1140
 - [":SBUS<n>:MANChEster:WSIZe"](#) on page 1141

:SBUS<n>:MANChester:HSIZe

N (see [page 1730](#))

Command Syntax :SBUS<n>:MANChester:HSIZe <#bits>

<#bits> ::= from 0-32, in NR1 format

When the display format is WORD (see :SBUS<n>:MANChester:DISPlay), the :SBUS<n>:MANChester:HSIZe command specifies the number of bits in the header field of your Manchester protocol definition.

Query Syntax :SBUS<n>:MANChester:HSIZe?

The :SBUS<n>:MANChester:HSIZe? query returns the number of header field bits setting.

Return Format <#bits><NL>

- See Also**
- [":SBUS<n>:MANChester:DISPlay"](#) on page 1128
 - [":SBUS<n>:MANChester:DSIZe"](#) on page 1129
 - [":SBUS<n>:MANChester:SSIZe"](#) on page 1134
 - [":SBUS<n>:MANChester:TSIZe"](#) on page 1140
 - [":SBUS<n>:MANChester:WSIZe"](#) on page 1141

:SBUS<n>:MANChester:IDLE:BITS

N (see [page 1730](#))

Command Syntax :SBUS<n>:MANChester:IDLE:BITS <#bits>

<#bits> ::= minimum idle time, from 1.50 to 32.00 in 0.25 increments, in NR3 format.

The :SBUS<n>:MANChester:IDLE:BITS command specifies the minimum idle time or inter-frame gap time in terms of the number of bits.

Query Syntax :SBUS<n>:MANChester:IDLE:BITS?

The :SBUS<n>:MANChester:IDLE:BITS? query returns the specified idle time in terms of the number of bits.

Return Format <#bits><NL>

- See Also**
- [":SBUS<n>:MANChester:BASE"](#) on page 1125
 - [":SBUS<n>:MANChester:BITOrder"](#) on page 1127
 - [":SBUS<n>:MANChester:LOGic"](#) on page 1132
 - [":SBUS<n>:MANChester:START"](#) on page 1135

:SBUS<n>:MANChester:LOGic

N (see [page 1730](#))

Command Syntax :SBUS<n>:MANChester:LOGic <logic>

<logic> ::= {FALLing | RISing}

The :SBUS<n>:MANChester:LOGic command specifies the polarity of the Manchester signal:

- FALLing – specifies that a falling edge is used to encode a bit value of logic 1 (and a rising edge encodes a bit value of logic 0).
- RISing – specifies that a rising edge is used to encode a bit value of logic 1.

Query Syntax :SBUS<n>:MANChester:LOGic?

The :SBUS<n>:MANChester:LOGic? query returns the polarity setting.

Return Format <logic><NL>

<logic> ::= {FALL | RIS}

- See Also**
- [":SBUS<n>:MANChester:BASE"](#) on page 1125
 - [":SBUS<n>:MANChester:BITOrder"](#) on page 1127
 - [":SBUS<n>:MANChester:IDLE:BITS"](#) on page 1131
 - [":SBUS<n>:MANChester:START"](#) on page 1135

:SBUS<n>:MANChester:SOURce

N (see [page 1730](#))

Command Syntax :SBUS<n>:MANChester:SOURce <source>

<source> ::= {CHANnel<n> | DIGital<d>}

<n> ::= 1 to (# analog channels) in NR1 format

<d> ::= 0 to (# digital channels - 1) in NR1 format

The :SBUS<n>:MANChester:SOURce command selects the oscilloscope channel connected to the Manchester signal line.

Query Syntax :SBUS<n>:MANChester:SOURce?

The :SBUS<n>:MANChester:SOURce? query returns the selected oscilloscope channel source.

Return Format <source><NL>

<source> ::= {CHAN<n> | DIG<d>}

- See Also**
- [":SBUS<n>:MANChester:BAUDrate"](#) on page 1126
 - [":SBUS<n>:MANChester:TOLerance"](#) on page 1136

:SBUS<n>:MANChester:SSIZe

N (see [page 1730](#))

Command Syntax :SBUS<n>:MANChester:SSIZe <#bits>

<#bits> ::= from 0-255, in NR1 format

The :SBUS<n>:MANChester:SSIZe command specifies the number of sync bits for the Manchester signal.

Query Syntax :SBUS<n>:MANChester:SSIZe?

The :SBUS<n>:MANChester:SSIZe? query returns the number of sync bits setting.

Return Format <#bits><NL>

- See Also**
- [":SBUS<n>:MANChester:DISPlay"](#) on page 1128
 - [":SBUS<n>:MANChester:DSIZe"](#) on page 1129
 - [":SBUS<n>:MANChester:HSIZe"](#) on page 1130
 - [":SBUS<n>:MANChester:TSIZe"](#) on page 1140
 - [":SBUS<n>:MANChester:WSIZe"](#) on page 1141

:SBUS<n>:MANChesTer:STARt

N (see [page 1730](#))

Command Syntax :SBUS<n>:MANChesTer:STARt <edge#>

<edge#> ::= from 1-256, in NR1 format

The :SBUS<n>:MANChesTer:STARt command specifies the starting edge of the Manchester signal.

Query Syntax :SBUS<n>:MANChesTer:STARt?

The :SBUS<n>:MANChesTer:STARt? query returns the starting edge number setting.

Return Format <edge#><NL>

- See Also**
- [":SBUS<n>:MANChesTer:BASE"](#) on page 1125
 - [":SBUS<n>:MANChesTer:BITOrder"](#) on page 1127
 - [":SBUS<n>:MANChesTer:IDLE:BITS"](#) on page 1131
 - [":SBUS<n>:MANChesTer:LOGic"](#) on page 1132

:SBUS<n>:MANChesTer:TOLerance

N (see [page 1730](#))

Command Syntax :SBUS<n>:MANChesTer:TOLerance <percent>

<percent> ::= from 5-30, in NR1 format

The :SBUS<n>:MANChesTer:TOLerance command specifies the tolerance for the Manchester signal in terms of the percentage of the bit period.

Query Syntax :SBUS<n>:MANChesTer:TOLerance?

The :SBUS<n>:MANChesTer:TOLerance? query returns the tolerance setting.

Return Format <percent><NL>

<percent> ::= from 5-30, in NR1 format

- See Also**
- [":SBUS<n>:MANChesTer:BAUDrate"](#) on page 1126
 - [":SBUS<n>:MANChesTer:SOURce"](#) on page 1133

:SBUS<n>:MANChester:TRIGger

N (see [page 1730](#))

Command Syntax :SBUS<n>:MANChester:TRIGger <mode>

<mode> ::= {SOF | VALue | MERRor}

The :SBUS<n>:MANChester:TRIGger command specifies the trigger mode:

- SOF (Start Of Frame) – triggers at the start of a Manchester frame, after the starting edge.
- VALue – triggers on the specified bit values.
- MERRor – triggers on a Manchester error.

Query Syntax :SBUS<n>:MANChester:TRIGger?

The :SBUS<n>:MANChester:TRIGger? query returns the trigger mode setting.

Return Format <mode><NL>

<mode> ::= {SOF | VAL | MERR}

- See Also**
- [":SBUS<n>:MANChester:TRIGger:PATtern:VALue:DATA"](#) on page 1138
 - [":SBUS<n>:MANChester:TRIGger:PATtern:VALue:WIDTh"](#) on page 1139

:SBUS<n>:MANChesTer:TRIGger:PATtern:VALue:DATA

N (see [page 1730](#))

Command Syntax :SBUS<n>:MANChesTer:TRIGger:PATtern:VALue:DATA <string>

<string> ::= "nn...n" where n ::= {0 | 1 | X | \$}

<string ::= "0xnn...n" where n ::= {0,...,9 | A,...,F | X | \$}

When the VALue trigger mode is selected (:SBUS<n>:MANChesTer:TRIGger), the :SBUS<n>:MANChesTer:TRIGger:PATtern:VALue:DATA command specifies the value to trigger on.

Note that the trigger value bit order is always for bits as they arrive (that is, MSB first) regardless of the serial decode bit order setting (in :SBUS<n>:MANChesTer:BITorder).

The bit width (length) of the value is set with the :SBUS<n>:MANChesTer:TRIGger:PATtern:VALue:WIDTH command.

Query Syntax :SBUS<n>:MANChesTer:TRIGger:PATtern:VALue:DATA?

The :SBUS<n>:MANChesTer:TRIGger:PATtern:VALue:DATA? query returns the specified trigger value as a string of binary digits.

Return Format <string><NL>

<string> ::= "nn...n" where n ::= {0 | 1 | X | \$}

- See Also**
- [":SBUS<n>:MANChesTer:BITorder"](#) on page 1127
 - [":SBUS<n>:MANChesTer:TRIGger"](#) on page 1137
 - [":SBUS<n>:MANChesTer:TRIGger:PATtern:VALue:WIDTH"](#) on page 1139

:SBUS<n>:MANChester:TRIGger:PATtern:VALue:WIDTh

N (see [page 1730](#))

Command Syntax :SBUS<n>:MANChester:TRIGger:PATtern:VALue:WIDTh <width>

<width> ::= integer from 4 to 128 in NR1 format

When the VALue trigger mode is selected (:SBUS<n>:MANChester:TRIGger), the :SBUS<n>:MANChester:TRIGger:PATtern:VALue:WIDTh command specifies the bit width (length) of the value to trigger on.

The actual value to trigger on is set with the :SBUS<n>:MANChester:TRIGger:PATtern:VALue:DATA command.

Query Syntax :SBUS<n>:MANChester:TRIGger:PATtern:VALue:WIDTh?

The :SBUS<n>:MANChester:TRIGger:PATtern:VALue:WIDTh? query returns the specified trigger value bit width (length).

Return Format <width><NL>

- See Also**
- [":SBUS<n>:MANChester:BITOrder"](#) on page 1127
 - [":SBUS<n>:MANChester:TRIGger"](#) on page 1137
 - [":SBUS<n>:MANChester:TRIGger:PATtern:VALue:DATA"](#) on page 1138

:SBUS<n>:MANChester:TSIZe

N (see [page 1730](#))

Command Syntax :SBUS<n>:MANChester:TSIZe <#bits>

<#bits> ::= from 0-32, in NR1 format

When the display format is WORD (see :SBUS<n>:MANChester:DISPlay), the :SBUS<n>:MANChester:TSIZe command specifies the number of bits in the trailer field of your Manchester protocol definition.

Query Syntax :SBUS<n>:MANChester:TSIZe?

The :SBUS<n>:MANChester:TSIZe? query returns the number of trailer field bits setting.

Return Format <#bits><NL>

<#bits> ::= from 0-32, in NR1 format

- See Also**
- [":SBUS<n>:MANChester:DISPlay"](#) on page 1128
 - [":SBUS<n>:MANChester:DSIZe"](#) on page 1129
 - [":SBUS<n>:MANChester:HSIZe"](#) on page 1130
 - [":SBUS<n>:MANChester:SSIZe"](#) on page 1134
 - [":SBUS<n>:MANChester:WSIZe"](#) on page 1141

:SBUS<n>:MANChester:WSize

N (see [page 1730](#))

Command Syntax :SBUS<n>:MANChester:WSize <#bits>

<#bits> ::= from 2-32, in NR1 format

When the display format is WORD (see :SBUS<n>:MANChester:DISPlay), the :SBUS<n>:MANChester:WSize command the number of bits per word in the data field of your Manchester protocol definition.

Query Syntax :SBUS<n>:MANChester:WSize?

The :SBUS<n>:MANChester:WSize? query returns the number of bits per word setting.

Return Format <#bits><NL>

- See Also**
- [":SBUS<n>:MANChester:DISPlay"](#) on page 1128
 - [":SBUS<n>:MANChester:DSIZE"](#) on page 1129
 - [":SBUS<n>:MANChester:HSIZE"](#) on page 1130
 - [":SBUS<n>:MANChester:SSIZE"](#) on page 1134
 - [":SBUS<n>:MANChester:TSIZE"](#) on page 1140

:SBUS<n>:NRZ Commands

NOTE

These commands are valid when the automotive NRZ serial decode and triggering option has been licensed.

Table 137 :SBUS<n>:NRZ Commands Summary

Command	Query	Options and Query Returns
:SBUS<n>:NRZ:BASE <base> (see page 1144)	:SBUS<n>:NRZ:BASE? (see page 1144)	<base> ::= {HEX DECimal ASCii}
:SBUS<n>:NRZ:BAUDrate <baudrate> (see page 1145)	:SBUS<n>:NRZ:BAUDrate? (see page 1145)	<baudrate> ::= integer from 5000 to 5000000 in 100 b/s increments
:SBUS<n>:NRZ:BITorder <bitorder> (see page 1146)	:SBUS<n>:NRZ:BITorder? (see page 1146)	<bitorder> ::= {MSBFirst LSBFirst}
:SBUS<n>:NRZ:DISPlay <format> (see page 1147)	:SBUS<n>:NRZ:DISPlay? (see page 1147)	<format> ::= {BIT WORD}
:SBUS<n>:NRZ:DSIZE <#words> (see page 1148)	:SBUS<n>:NRZ:DSIZE? (see page 1148)	<#words> ::= from 1-255, in NR1 format
:SBUS<n>:NRZ:FSIZE <#bits> (see page 1149)	:SBUS<n>:NRZ:FSIZE? (see page 1149)	<#bits> ::= from 2-255, in NR1 format
:SBUS<n>:NRZ:HSIZE <#bits> (see page 1150)	:SBUS<n>:NRZ:HSIZE? (see page 1150)	<#bits> ::= from 0-32, in NR1 format
:SBUS<n>:NRZ:IDLE:BIT S <#bits> (see page 1151)	:SBUS<n>:NRZ:IDLE:BIT S? (see page 1151)	<#bits> ::= minimum idle time in terms of bit width, from 1.50 to 32.0, in NR3 format.
:SBUS<n>:NRZ:IDLE:STA Te <state> (see page 1152)	:SBUS<n>:NRZ:IDLE:STA Te? (see page 1152)	<state> ::= {LOW HIGH}
:SBUS<n>:NRZ:LOGic <logic> (see page 1153)	:SBUS<n>:NRZ:LOGic? (see page 1153)	<logic> ::= {HIGH LOW}
:SBUS<n>:NRZ:SOURce <source> (see page 1154)	:SBUS<n>:NRZ:SOURce? (see page 1154)	<source> ::= {CHANnel<n> DIGital<d>}

Table 137 :SBUS<n>:NRZ Commands Summary (continued)

Command	Query	Options and Query Returns
:SBUS<n>:NRZ:START <#bits> (see page 1155)	:SBUS<n>:NRZ:START? (see page 1155)	<#bits> ::= from 0-255, in NR1 format
:SBUS<n>:NRZ:TRIGger <mode> (see page 1156)	:SBUS<n>:NRZ:TRIGger? (see page 1156)	<mode> ::= {SOF VALue}
:SBUS<n>:NRZ:TRIGger: PATtern:VALue:DATA <string> (see page 1157)	:SBUS<n>:NRZ:TRIGger: PATtern:VALue:DATA? (see page 1157)	<string> ::= "nn...n" where n ::= {0 1 X \$} <string ::= "0xnn...n" where n ::= {0,...,9 A,...,F X \$}
:SBUS<n>:NRZ:TRIGger: PATtern:VALue:WIDTh <width> (see page 1158)	:SBUS<n>:NRZ:TRIGger: PATtern:VALue:WIDTh? (see page 1158)	<width> ::= integer from 4 to 128 in NR1 format
:SBUS<n>:NRZ:TSIZe <#bits> (see page 1159)	:SBUS<n>:NRZ:TSIZe? (see page 1159)	<#bits> ::= from 0-32, in NR1 format
:SBUS<n>:NRZ:WSIZe <#bits> (see page 1160)	:SBUS<n>:NRZ:WSIZe? (see page 1160)	<#bits> ::= from 2-32, in NR1 format

:SBUS<n>:NRZ:BASE

N (see [page 1730](#))

Command Syntax :SBUS<n>:NRZ:BASE <base>

<base> ::= {HEX | DECimal | ASCii | BINary}

When the display format is WORD (see :SBUS<n>:NRZ:DISPlay), the :SBUS<n>:NRZ:BASE command specifies the base for the NRZ bus decode and Lister display.

- HEX – hexadecimal
- DECimal – unsigned decimal
- ASCii

When the display format is BIT, the only legal decode base value is BINary.

Query Syntax :SBUS<n>:NRZ:BASE?

The :SBUS<n>:NRZ:BASE? query returns the decode number base setting.

Return Format <base><NL>

<base> ::= {HEX | DEC | ASC | BIN}

- See Also**
- [":SBUS<n>:NRZ:BITOrder"](#) on page 1146
 - [":SBUS<n>:NRZ:IDLE:BITS"](#) on page 1151
 - [":SBUS<n>:NRZ:IDLE:STATe"](#) on page 1152
 - [":SBUS<n>:NRZ:LOGic"](#) on page 1153

:SBUS<n>:NRZ:BAUDrate

N (see [page 1730](#))

Command Syntax :SBUS<n>:NRZ:BAUDrate <baudrate>

<baudrate> ::= integer from 5000 to 5000000 in 100 b/s increments

The :SBUS<n>:NRZ:BAUDrate command specifies the baud rate of the NRZ signal.

Query Syntax :SBUS<n>:NRZ:BAUDrate?

The :SBUS<n>:NRZ:BAUDrate? query returns the specified baud rate.

Return Format <baudrate><NL>

See Also • [":SBUS<n>:NRZ:SOURce"](#) on page 1154

:SBUS<n>:NRZ:BITOrder

N (see [page 1730](#))

Command Syntax :SBUS<n>:NRZ:BITOrder <bitorder>

<bitorder> ::= {MSBFirst | LSBFirst}

When the display format is WORD (see :SBUS<n>:NRZ:DISPlay), the :SBUS<n>:NRZ:BITOrder command specifies the order of transmission on the NRZ bus:

- MSBFirst – specifies the most significant bit is transmitted first.
- LSBFirst – specifies the least significant bit is transmitted first.

Query Syntax :SBUS<n>:NRZ:BITOrder?

The :SBUS<n>:NRZ:BITOrder? query returns the bit order setting.

Return Format <bitorder><NL>

<bitorder> ::= {MSBF | LSBF}

- See Also**
- [":SBUS<n>:NRZ:BASE"](#) on page 1144
 - [":SBUS<n>:NRZ:IDLE:BITS"](#) on page 1151
 - [":SBUS<n>:NRZ:IDLE:STATe"](#) on page 1152
 - [":SBUS<n>:NRZ:LOGic"](#) on page 1153

:SBUS<n>:NRZ:DISPlay

N (see [page 1730](#))

Command Syntax :SBUS<n>:NRZ:DISPlay <format>

<format> ::= {BIT | WORD}

The :SBUS<n>:NRZ:DISPlay command specifies the format of the NRZ bus display.

Query Syntax :SBUS<n>:NRZ:DISPlay?

The :SBUS<n>:NRZ:DISPlay? query returns the bus display format setting.

Return Format <format><NL>

<format> ::= {BIT | WORD}

- See Also**
- [":SBUS<n>:NRZ:DSIZe"](#) on page 1148
 - [":SBUS<n>:NRZ:FSIZe"](#) on page 1149
 - [":SBUS<n>:NRZ:HSIZe"](#) on page 1150
 - [":SBUS<n>:NRZ:STArT"](#) on page 1155
 - [":SBUS<n>:NRZ:TSIZe"](#) on page 1159
 - [":SBUS<n>:NRZ:WSIZe"](#) on page 1160

:SBUS<n>:NRZ:DSIZe

N (see [page 1730](#))

Command Syntax :SBUS<n>:NRZ:DSIZe <#words>
 <#words> ::= from 1-255, in NR1 format

The :SBUS<n>:NRZ:DSIZe command ...

When the display format is WORD (see :SBUS<n>:NRZ:DISPlay), the :SBUS<n>:NRZ:DSIZe command specifies the number of words in the data field of your NRZ protocol definition.

AUTO is available as a selection only when the trailer field size is 0 (see :SBUS<n>:NRZ:TSIZe).

Query Syntax :SBUS<n>:NRZ:DSIZe?

The :SBUS<n>:NRZ:DSIZe? query returns the number of data field words setting.

Return Format <#words><NL>
 <#words> ::= from 1-255, in NR1 format

In AUTO mode, the query returns 0.

In BIT format the only legal value is 0 (for AUTO).

- See Also**
- [":SBUS<n>:NRZ:DISPlay"](#) on page 1147
 - [":SBUS<n>:NRZ:FSIZe"](#) on page 1149
 - [":SBUS<n>:NRZ:HSIZe"](#) on page 1150
 - [":SBUS<n>:NRZ:START"](#) on page 1155
 - [":SBUS<n>:NRZ:TSIZe"](#) on page 1159
 - [":SBUS<n>:NRZ:WSIZe"](#) on page 1160

:SBUS<n>:NRZ:FSIZe

N (see [page 1730](#))

Command Syntax :SBUS<n>:NRZ:FSIZe <#bits>

<#bits> ::= from 2-255, in NR1 format

When the NRZ bus display format (:SBUS<n>:NRZ:DISPlay) is BIT, the :SBUS<n>:NRZ:FSIZe command lets you specify the total frame size of the NRZ signal from 2 to 255 bits. This would be equivalent to the sum of the number of bits in the header, data, and trailer fields in WORD format.

Query Syntax :SBUS<n>:NRZ:FSIZe?

The :SBUS<n>:NRZ:FSIZe? query returns the specified total frame size.

Return Format <#bits><NL>

- See Also**
- [":SBUS<n>:NRZ:DISPlay"](#) on page 1147
 - [":SBUS<n>:NRZ:DSIZe"](#) on page 1148
 - [":SBUS<n>:NRZ:HSIZe"](#) on page 1150
 - [":SBUS<n>:NRZ:START"](#) on page 1155
 - [":SBUS<n>:NRZ:TSIZe"](#) on page 1159
 - [":SBUS<n>:NRZ:WSIZe"](#) on page 1160

:SBUS<n>:NRZ:HSIZe

N (see [page 1730](#))

Command Syntax :SBUS<n>:NRZ:HSIZe <#bits>

<#bits> ::= from 0-32, in NR1 format

When the display format is WORD (see :SBUS<n>:NRZ:DISPlay), the :SBUS<n>:NRZ:HSIZe command specifies the number of bits in the header field of your NRZ protocol definition.

Query Syntax :SBUS<n>:NRZ:HSIZe?

The :SBUS<n>:NRZ:HSIZe? query returns the number of header field bits setting.

Return Format <#bits><NL>

- See Also**
- [":SBUS<n>:NRZ:DISPlay"](#) on page 1147
 - [":SBUS<n>:NRZ:DSIZe"](#) on page 1148
 - [":SBUS<n>:NRZ:FSIZe"](#) on page 1149
 - [":SBUS<n>:NRZ:START"](#) on page 1155
 - [":SBUS<n>:NRZ:TSIZe"](#) on page 1159
 - [":SBUS<n>:NRZ:WSIZe"](#) on page 1160

:SBUS<n>:NRZ:IDLE:BITS

N (see [page 1730](#))

Command Syntax :SBUS<n>:NRZ:IDLE:BITS <#bits>

<#bits> ::= minimum idle time, from 1.50 to 32.00 in 0.25 increments, in NR3 format.

The :SBUS<n>:NRZ:IDLE:BITS command specifies the minimum idle time or inter-frame gap time in terms of the number of bits.

Query Syntax :SBUS<n>:NRZ:IDLE:BITS?

The :SBUS<n>:NRZ:IDLE:BITS? query returns the specified idle time in terms of the number of bits.

Return Format <#bits><NL>

- See Also**
- [":SBUS<n>:NRZ:BASE"](#) on page 1144
 - [":SBUS<n>:NRZ:BITorder"](#) on page 1146
 - [":SBUS<n>:NRZ:IDLE:STATE"](#) on page 1152
 - [":SBUS<n>:NRZ:LOGic"](#) on page 1153

:SBUS<n>:NRZ:IDLE:STATE

N (see [page 1730](#))

Command Syntax :SBUS<n>:NRZ:IDLE:STATE <state>

<state> ::= {LOW | HIGH}

The :SBUS<n>:NRZ:IDLE:STATE command specifies the idle state of the NRZ signal.

Query Syntax :SBUS<n>:NRZ:IDLE:STATE?

The :SBUS<n>:NRZ:IDLE:STATE? query returns the idle state setting.

Return Format <state><NL>

<state> ::= {LOW | HIGH}

- See Also**
- [":SBUS<n>:NRZ:BASE"](#) on page 1144
 - [":SBUS<n>:NRZ:BITOrder"](#) on page 1146
 - [":SBUS<n>:NRZ:IDLE:BITS"](#) on page 1151
 - [":SBUS<n>:NRZ:LOGic"](#) on page 1153

:SBUS<n>:NRZ:LOGic

N (see [page 1730](#))

Command Syntax :SBUS<n>:NRZ:LOGic <logic>

<logic> ::= {HIGH | LOW}

The :SBUS<n>:NRZ:LOGic command specifies the polarity of the NRZ signal:

- HIGH – specifies that a positive voltage is used to encode a bit value of logic 1 (and a negative voltage encodes a bit value of logic 0).
- LOW – specifies that a negative voltage is used to encode a bit value of logic 1.

Query Syntax :SBUS<n>:NRZ:LOGic?

The :SBUS<n>:NRZ:LOGic? query returns the polarity setting.

Return Format <logic><NL>

<logic> ::= {HIGH | LOW}

- See Also**
- [":SBUS<n>:NRZ:BASE"](#) on page 1144
 - [":SBUS<n>:NRZ:BITorder"](#) on page 1146
 - [":SBUS<n>:NRZ:IDLE:BITS"](#) on page 1151
 - [":SBUS<n>:NRZ:IDLE:STATe"](#) on page 1152

:SBUS<n>:NRZ:SOURce

N (see [page 1730](#))

Command Syntax :SBUS<n>:NRZ:SOURce <source>

<source> ::= {CHANnel<n> | DIGital<d>}

<n> ::= 1 to (# analog channels) in NR1 format

<d> ::= 0 to (# digital channels - 1) in NR1 format

The :SBUS<n>:NRZ:SOURce command selects the oscilloscope channel connected to the NRZ signal

Query Syntax :SBUS<n>:NRZ:SOURce?

The :SBUS<n>:NRZ:SOURce? query returns the selected oscilloscope channel source.

Return Format <source><NL>

<source> ::= {CHAN<n> | DIG<d>}

See Also • [":SBUS<n>:NRZ:BAUDrate"](#) on page 1145

:SBUS<n>:NRZ:START

N (see [page 1730](#))

Command Syntax :SBUS<n>:NRZ:START <#bits>

<#bits> ::= from 0-255, in NR1 format

The :SBUS<n>:NRZ:START command specifies the number of start bits for the NRZ signal.

Query Syntax :SBUS<n>:NRZ:START?

The :SBUS<n>:NRZ:START? query returns the number of start bits setting.

Return Format <#bits><NL>

- See Also**
- [":SBUS<n>:NRZ:DISPlay"](#) on page 1147
 - [":SBUS<n>:NRZ:DSIZe"](#) on page 1148
 - [":SBUS<n>:NRZ:FSIZe"](#) on page 1149
 - [":SBUS<n>:NRZ:HSIZe"](#) on page 1150
 - [":SBUS<n>:NRZ:TSIZe"](#) on page 1159
 - [":SBUS<n>:NRZ:WSIZe"](#) on page 1160

:SBUS<n>:NRZ:TRIGger

N (see [page 1730](#))

Command Syntax :SBUS<n>:NRZ:TRIGger <mode>

<mode> ::= {SOF | VALue}

The :SBUS<n>:NRZ:TRIGger command specifies the trigger mode:

- SOF (Start Of Frame) – triggers at the start of a NRZ frame, before the header field.
- VALue – triggers on the specified bit values (see :SBUS<n>:NRZ:TRIGger:PATtern:VALue:WIDTh and :SBUS<n>:NRZ:TRIGger:PATtern:VALue:DATA), up to 128 bits, after the specified number of starting bits.

Note that the trigger value is always for bits as they arrive (that is, MSB first).

When the decode bit order (see :SBUS<n>:NRZ:BITorder) is MSBFirst, the decoded value bit order matches the trigger value bit order.

When the serial decode bit order is LSBFirst, the decoded value bit order is opposite of the trigger value bit order.

Query Syntax :SBUS<n>:NRZ:TRIGger?

The :SBUS<n>:NRZ:TRIGger? query returns returns the trigger mode setting.

Return Format <mode><NL>

<mode> ::= {SOF | VAL}

- See Also**
- [":SBUS<n>:NRZ:TRIGger:PATtern:VALue:DATA"](#) on page 1157
 - [":SBUS<n>:NRZ:TRIGger:PATtern:VALue:WIDTh"](#) on page 1158

:SBUS<n>:NRZ:TRIGger:PATtern:VALue:DATA

N (see [page 1730](#))

Command Syntax :SBUS<n>:NRZ:TRIGger:PATtern:VALue:DATA <string>

<string> ::= "nn...n" where n ::= {0 | 1 | X | \$}

<string ::= "0xnn...n" where n ::= {0,...,9 | A,...,F | X | \$}

When the VALue trigger mode is selected (:SBUS<n>:NRZ:TRIGger), the :SBUS<n>:NRZ:TRIGger:PATtern:VALue:DATA command specifies the value to trigger on.

Note that the trigger value bit order is always for bits as they arrive (that is, MSB first) regardless of the serial decode bit order setting (in :SBUS<n>:NRZ:BITorder).

The bit width (length) of the value is set with the :SBUS<n>:NRZ:TRIGger:PATtern:VALue:WIDTH command.

Query Syntax :SBUS<n>:NRZ:TRIGger:PATtern:VALue:DATA?

The :SBUS<n>:NRZ:TRIGger:PATtern:VALue:DATA? query returns the specified trigger value as a string of binary digits.

Return Format <string><NL>

<string> ::= "nn...n" where n ::= {0 | 1 | X | \$}

- See Also**
- [":SBUS<n>:NRZ:BITorder"](#) on page 1146
 - [":SBUS<n>:NRZ:TRIGger"](#) on page 1156
 - [":SBUS<n>:NRZ:TRIGger:PATtern:VALue:WIDTH"](#) on page 1158

:SBUS<n>:NRZ:TRIGger:PATtern:VALue:WIDTh

N (see [page 1730](#))

Command Syntax :SBUS<n>:NRZ:TRIGger:PATtern:VALue:WIDTh <width>

<width> ::= integer from 4 to 128 in NR1 format

When the VALue trigger mode is selected (:SBUS<n>:NRZ:TRIGger), the :SBUS<n>:NRZ:TRIGger:PATtern:VALue:WIDTh command specifies the bit width (length) of the value to trigger on.

The actual value to trigger on is set with the :SBUS<n>:NRZ:TRIGger:PATtern:VALue:DATA command.

Query Syntax :SBUS<n>:NRZ:TRIGger:PATtern:VALue:WIDTh?

The :SBUS<n>:NRZ:TRIGger:PATtern:VALue:WIDTh? query returns the specified trigger value bit width (length).

Return Format <width><NL>

- See Also**
- [":SBUS<n>:NRZ:BITorder"](#) on page 1146
 - [":SBUS<n>:NRZ:TRIGger"](#) on page 1156
 - [":SBUS<n>:NRZ:TRIGger:PATtern:VALue:DATA"](#) on page 1157

:SBUS<n>:NRZ:TSIZE

N (see [page 1730](#))

Command Syntax :SBUS<n>:NRZ:TSIZE <#bits>

<#bits> ::= from 0-32, in NR1 format

When the display format is WORD (see :SBUS<n>:NRZ:DISPlay), the :SBUS<n>:NRZ:TSIZE command specifies the number of bits in the trailer field of your NRZ protocol definition.

Query Syntax :SBUS<n>:NRZ:TSIZE?

The :SBUS<n>:NRZ:TSIZE? query returns the number of trailer field bits setting.

Return Format <opt><NL>

<#bits> ::= from 0-32, in NR1 format

- See Also**
- [":SBUS<n>:NRZ:DISPlay"](#) on page 1147
 - [":SBUS<n>:NRZ:DSIZE"](#) on page 1148
 - [":SBUS<n>:NRZ:FSIZE"](#) on page 1149
 - [":SBUS<n>:NRZ:HSIZE"](#) on page 1150
 - [":SBUS<n>:NRZ:START"](#) on page 1155
 - [":SBUS<n>:NRZ:WSIZE"](#) on page 1160

:SBUS<n>:NRZ:WSize

N (see [page 1730](#))

Command Syntax :SBUS<n>:NRZ:WSize <#bits>

<#bits> ::= from 2-32, in NR1 format

When the display format is WORD (see :SBUS<n>:NRZ:DISPlay), the :SBUS<n>:NRZ:WSize command specifies the number of bits per word in the data field of your NRZ protocol definition.

Query Syntax :SBUS<n>:NRZ:WSize?

The :SBUS<n>:NRZ:WSize? query returns the number of bits per word setting.

Return Format <#bits><NL>

- See Also**
- [":SBUS<n>:NRZ:DISPlay"](#) on page 1147
 - [":SBUS<n>:NRZ:DSIZE"](#) on page 1148
 - [":SBUS<n>:NRZ:FSIZE"](#) on page 1149
 - [":SBUS<n>:NRZ:HSIZE"](#) on page 1150
 - [":SBUS<n>:NRZ:START"](#) on page 1155
 - [":SBUS<n>:NRZ:TSIZE"](#) on page 1159

:SBUS<n>:SENT Commands

NOTE

These commands are valid when the automotive SENT serial decode and triggering option has been licensed.

Table 138 :SBUS<n>:SENT Commands Summary

Command	Query	Options and Query Returns
:SBUS<n>:SENT:CLOCK <period> (see page 1164)	:SBUS<n>:SENT:CLOCK? (see page 1164)	<period> ::= the nominal clock period (tick), from 500 ns to 300 us, in NR3 format.
:SBUS<n>:SENT:CRC <format> (see page 1165)	:SBUS<n>:SENT:CRC? (see page 1165)	<format> ::= {LEGacy RECommended}
:SBUS<n>:SENT:DISPlay <base> (see page 1166)	:SBUS<n>:SENT:DISPlay ? (see page 1166)	<base> ::= {HEX DECimal SYMBolic}
:SBUS<n>:SENT:FORMat <decode> (see page 1168)	:SBUS<n>:SENT:FORMat? (see page 1168)	<decode> ::= {NIBBles FSIGnal FSSerial FESerial SSERial ESERial}
:SBUS<n>:SENT:IDLE <state> (see page 1170)	:SBUS<n>:SENT:IDLE? (see page 1170)	<state> ::= {LOW HIGH}
:SBUS<n>:SENT:LENGth <#_nibbles> (see page 1171)	:SBUS<n>:SENT:LENGth? (see page 1171)	<#_nibbles> ::= from 1-6, in NR1 format.
:SBUS<n>:SENT:PPULse { {0 OFF} {1 ON} SPC } (see page 1172)	:SBUS<n>:SENT:PPULse? (see page 1172)	{0 1 SPC}
:SBUS<n>:SENT:SIGnal<s>:DISPlay { {0 OFF} {1 ON} } (see page 1174)	:SBUS<n>:SENT:SIGnal<s>:DISPlay? (see page 1174)	<s> ::= 1-6, in NR1 format. {0 1}
:SBUS<n>:SENT:SIGnal<s>:LENGth <length> (see page 1175)	:SBUS<n>:SENT:SIGnal<s>:LENGth? (see page 1175)	<s> ::= 1-6, in NR1 format. <length> ::= from 1-24, in NR1 format.
:SBUS<n>:SENT:SIGnal<s>:MULTIplier <multiplier> (see page 1177)	:SBUS<n>:SENT:SIGnal<s>:MULTIplier? (see page 1177)	<s> ::= 1-6, in NR1 format. <multiplier> ::= from 1-24, in NR3 format.

Table 138 :SBUS<n>:SENT Commands Summary (continued)

Command	Query	Options and Query Returns
:SBUS<n>:SENT:SIGnAl<s>:OFFSet <offset> (see page 1179)	:SBUS<n>:SENT:SIGnAl<s>:OFFSet? (see page 1179)	<s> ::= 1-6, in NR1 format. <offset> ::= from 1-24, in NR3 format.
:SBUS<n>:SENT:SIGnAl<s>:ORDer <order> (see page 1181)	:SBUS<n>:SENT:SIGnAl<s>:ORDer? (see page 1181)	<s> ::= 1-6, in NR1 format. <order> ::= {MSNFirst LSNFirst}
:SBUS<n>:SENT:SIGnAl<s>:STARt <position> (see page 1183)	:SBUS<n>:SENT:SIGnAl<s>:STARt? (see page 1183)	<s> ::= 1-6, in NR1 format. <position> ::= from 0-23, in NR1 format.
:SBUS<n>:SENT:SOURce <source> (see page 1185)	:SBUS<n>:SENT:SOURce? (see page 1185)	<source> ::= {CHANnel<n> DIGital<d>} <n> ::= 1 to (# analog channels) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format
:SBUS<n>:SENT:TOLerance <percent> (see page 1187)	:SBUS<n>:SENT:TOLerance? (see page 1187)	<percent> ::= from 3-30, in NR1 format.
:SBUS<n>:SENT:TRIGger <mode> (see page 1188)	:SBUS<n>:SENT:TRIGger? (see page 1188)	<mode> ::= {SFCMessage SSCMessage FCData SCMid SCData FCCerror SCCerror CRCerror TOLerror PPERror SSPerror}
:SBUS<n>:SENT:TRIGger:FAST:DATA <string> (see page 1190)	:SBUS<n>:SENT:TRIGger:FAST:DATA? (see page 1190)	<string> ::= "nnnn..." where n ::= {0 1 X} <string> ::= "0xn..." where n ::= {0,...,9 A,...,F X \$}
:SBUS<n>:SENT:TRIGger:SLOW:DATA <data> (see page 1191)	:SBUS<n>:SENT:TRIGger:SLOW:DATA? (see page 1191)	<data> ::= when ILENgth = SHORT, from -1 (don't care) to 65535, in NR1 format. <data> ::= when ILENgth = LONG, from -1 (don't care) to 4095, in NR1 format.
:SBUS<n>:SENT:TRIGger:SLOW:ID <id> (see page 1193)	:SBUS<n>:SENT:TRIGger:SLOW:ID? (see page 1193)	<id> ::= when ILENgth = SHORT, from -1 (don't care) to 15, in NR1 format. <id> ::= when ILENgth = LONG, from -1 (don't care) to 255, in NR1 format.

Table 138 :SBUS<n>:SENT Commands Summary (continued)

Command	Query	Options and Query Returns
:SBUS<n>:SENT:TRIGger :SLOW:ILENgtH <length> (see page 1195)	:SBUS<n>:SENT:TRIGger :SLOW:ILENgtH? (see page 1195)	<length> ::= {SHORT LONG}
:SBUS<n>:SENT:TRIGger :TOLerance <percent> (see page 1196)	:SBUS<n>:SENT:TRIGger :TOLerance? (see page 1196)	<percent> ::= from 1-18, in NR1 format.

:SBUS<n>:SENT:CLOCK

N (see [page 1730](#))

Command Syntax :SBUS<n>:SENT:CLOCK <period>

<period> ::= the nominal clock period (tick), from 500 ns to 300 us, in NR3 format.

The :SBUS<n>:SENT:CLOCK command specifies the nominal clock period (tick), from 500 ns to 300 μs.

Query Syntax :SBUS<n>:SENT:CLOCK?

The :SBUS<n>:SENT:CLOCK? query returns the clock period setting.

Return Format <period><NL>

<period> ::= the nominal clock period (tick), from 500 ns to 300 us, in NR3 format.

- See Also**
- [":SBUS<n>:SENT:CRC"](#) on page 1165
 - [":SBUS<n>:SENT:DISPlay"](#) on page 1166
 - [":SBUS<n>:SENT:FORMat"](#) on page 1168
 - [":SBUS<n>:SENT:IDLE"](#) on page 1170
 - [":SBUS<n>:SENT:LENGth"](#) on page 1171
 - [":SBUS<n>:SENT:PPULse"](#) on page 1172
 - [":SBUS<n>:SENT:SIGNal<s>:DISPlay"](#) on page 1174
 - [":SBUS<n>:SENT:SIGNal<s>:LENGth"](#) on page 1175
 - [":SBUS<n>:SENT:SIGNal<s>:MULTIplier"](#) on page 1177
 - [":SBUS<n>:SENT:SIGNal<s>:OFFSet"](#) on page 1179
 - [":SBUS<n>:SENT:SIGNal<s>:ORDer"](#) on page 1181
 - [":SBUS<n>:SENT:SIGNal<s>:START"](#) on page 1183
 - [":SBUS<n>:SENT:SOURce"](#) on page 1185
 - [":SBUS<n>:SENT:TOLerance"](#) on page 1187
 - [":SBUS<n>:SENT:TRIGger"](#) on page 1188
 - [":SBUS<n>:SENT:TRIGger:FAST:DATA"](#) on page 1190
 - [":SBUS<n>:SENT:TRIGger:SLOW:DATA"](#) on page 1191
 - [":SBUS<n>:SENT:TRIGger:SLOW:ID"](#) on page 1193
 - [":SBUS<n>:SENT:TRIGger:SLOW:ILENght"](#) on page 1195
 - [":SBUS<n>:SENT:TRIGger:TOLerance"](#) on page 1196

:SBUS<n>:SENT:CRC

N (see [page 1730](#))

Command Syntax :SBUS<n>:SENT:CRC <format>

<format> ::= {LEGacy | RECommended}

The :SBUS<n>:SENT:CRC command specifies the format of the CRC. Either Legacy (2008) or Recommended (2010).

Enhanced Serial Message CRCs are always calculated using the 2010 format, but for the Fast Channel Messages, and for Short Serial Message CRCs, this setting is used.

Query Syntax :SBUS<n>:SENT:CRC?

The :SBUS<n>:SENT:CRC? query returns the CRC format setting.

Return Format <format><NL>

<format> ::= {LEG | REC}

- See Also**
- [":SBUS<n>:SENT:CLOCK"](#) on page 1164
 - [":SBUS<n>:SENT:DISPlay"](#) on page 1166
 - [":SBUS<n>:SENT:FORMat"](#) on page 1168
 - [":SBUS<n>:SENT:IDLE"](#) on page 1170
 - [":SBUS<n>:SENT:LENGth"](#) on page 1171
 - [":SBUS<n>:SENT:PPULse"](#) on page 1172
 - [":SBUS<n>:SENT:SIGNal<s>:DISPlay"](#) on page 1174
 - [":SBUS<n>:SENT:SIGNal<s>:LENGth"](#) on page 1175
 - [":SBUS<n>:SENT:SIGNal<s>:MULTIplier"](#) on page 1177
 - [":SBUS<n>:SENT:SIGNal<s>:OFFSet"](#) on page 1179
 - [":SBUS<n>:SENT:SIGNal<s>:ORDer"](#) on page 1181
 - [":SBUS<n>:SENT:SIGNal<s>:START"](#) on page 1183
 - [":SBUS<n>:SENT:SOURce"](#) on page 1185
 - [":SBUS<n>:SENT:TOLerance"](#) on page 1187
 - [":SBUS<n>:SENT:TRIGger"](#) on page 1188
 - [":SBUS<n>:SENT:TRIGger:FAST:DATA"](#) on page 1190
 - [":SBUS<n>:SENT:TRIGger:SLOW:DATA"](#) on page 1191
 - [":SBUS<n>:SENT:TRIGger:SLOW:ID"](#) on page 1193
 - [":SBUS<n>:SENT:TRIGger:SLOW:ILENght"](#) on page 1195
 - [":SBUS<n>:SENT:TRIGger:TOLerance"](#) on page 1196

:SBUS<n>:SENT:DISPlay

N (see [page 1730](#))

Command Syntax :SBUS<n>:SENT:DISPlay <base>

<base> ::= {HEX | DECimal | SYMBolic}

The :SBUS<n>:SENT:DISPlay command specifies the number base used by the decoder. The chosen base is used for the data nibbles in Raw decode format, the defined Signals in the other formats, and for the data field of the Serial Messages.

This selection is used for both the Lister and the decode line displays.

When SYMBolic is selected, Fast Channel Signals display a calculated physical value based on the specified multiplier and offset:

- $PhysicalValue = (Multiplier * SignalValueAsUnsignedInteger) + Offset$

When SYMBolic is selected, the CRC and Slow Channel information is displayed in hex.

Query Syntax :SBUS<n>:SENT:DISPlay?

The :SBUS<n>:SENT:DISPlay? query returns the SENT decode number base setting.

Return Format <base><NL>

<base> ::= {HEX | DEC | SYMB}

- See Also**
- [":SBUS<n>:SENT:CLOCK"](#) on page 1164
 - [":SBUS<n>:SENT:CRC"](#) on page 1165
 - [":SBUS<n>:SENT:FORMat"](#) on page 1168
 - [":SBUS<n>:SENT:IDLE"](#) on page 1170
 - [":SBUS<n>:SENT:LENGth"](#) on page 1171
 - [":SBUS<n>:SENT:PPULse"](#) on page 1172
 - [":SBUS<n>:SENT:SIGNal<s>:DISPlay"](#) on page 1174
 - [":SBUS<n>:SENT:SIGNal<s>:LENGth"](#) on page 1175
 - [":SBUS<n>:SENT:SIGNal<s>:MULTiplier"](#) on page 1177
 - [":SBUS<n>:SENT:SIGNal<s>:OFFSet"](#) on page 1179
 - [":SBUS<n>:SENT:SIGNal<s>:ORDer"](#) on page 1181
 - [":SBUS<n>:SENT:SIGNal<s>:START"](#) on page 1183
 - [":SBUS<n>:SENT:SOURce"](#) on page 1185
 - [":SBUS<n>:SENT:TOLerance"](#) on page 1187
 - [":SBUS<n>:SENT:TRIGger"](#) on page 1188
 - [":SBUS<n>:SENT:TRIGger:FAST:DATA"](#) on page 1190

- `":SBUS<n>:SENT:TRIGger:SLOW:DATA"` on page 1191
- `":SBUS<n>:SENT:TRIGger:SLOW:ID"` on page 1193
- `":SBUS<n>:SENT:TRIGger:SLOW:ILENgtH"` on page 1195
- `":SBUS<n>:SENT:TRIGger:TOLerance"` on page 1196

:SBUS<n>:SENT:FORMat

N (see [page 1730](#))

Command Syntax :SBUS<n>:SENT:FORMat <decode>

<decode> ::= {NIBBles | FSIGnal | FSSerial | FESerial | SSERial | ESERial}

The :SBUS<n>:SENT:FORMat command specifies the message decode/triggering format:

- NIBBles – displays the raw transmitted nibble values.
- FSIGnal – displays Fast Channel Message Signals.
- FSSerial – displays both Fast and Slow Messages (Short format) simultaneously.
- FESerial – displays both Fast and Slow Messages (Enhanced format) simultaneously.
- SSERial – displays Slow Channel Messages in Short format.
- ESERial – displays Slow Channel Messages in Enhanced format.

This selection affects both decoding and triggering. The decode is affected both in how the system interprets the data, and what will be displayed. The trigger is affected in that the trigger hardware needs to be configured to trigger on serial messages correctly.

You can specify the nibble display order for Fast Channel Message Signals (see :SBUS<n>:SENT:SIGNa<s>:ORDer). Raw transmitted nibble values are displayed in the order received.

Note that for the Slow Channel, the proper format, Short or Enhanced, must be chosen for proper decoding and triggering to occur.

Slow Channel Serial Messages are always displayed as defined by the SENT specification.

Query Syntax :SBUS<n>:SENT:FORMat?

The :SBUS<n>:SENT:FORMat? query returns the message decode/triggering format setting.

Return Format <decode><NL>

<decode> ::= {NIBB | FSIG | FSS | FES | SSER | ESER}

- See Also**
- **" :SBUS<n>:SENT:CLOCK "** on page 1164
 - **" :SBUS<n>:SENT:CRC "** on page 1165
 - **" :SBUS<n>:SENT:DISPlay "** on page 1166
 - **" :SBUS<n>:SENT:IDLE "** on page 1170

- **":SBUS<n>:SENT:LENGth"** on page 1171
- **":SBUS<n>:SENT:PPULse"** on page 1172
- **":SBUS<n>:SENT:SIGNal<s>:DISPlay"** on page 1174
- **":SBUS<n>:SENT:SIGNal<s>:LENGth"** on page 1175
- **":SBUS<n>:SENT:SIGNal<s>:MULTIplier"** on page 1177
- **":SBUS<n>:SENT:SIGNal<s>:OFFSet"** on page 1179
- **":SBUS<n>:SENT:SIGNal<s>:ORDer"** on page 1181
- **":SBUS<n>:SENT:SIGNal<s>:STARt"** on page 1183
- **":SBUS<n>:SENT:SOURce"** on page 1185
- **":SBUS<n>:SENT:TOLerance"** on page 1187
- **":SBUS<n>:SENT:TRIGger"** on page 1188
- **":SBUS<n>:SENT:TRIGger:FAST:DATA"** on page 1190
- **":SBUS<n>:SENT:TRIGger:SLOW:DATA"** on page 1191
- **":SBUS<n>:SENT:TRIGger:SLOW:ID"** on page 1193
- **":SBUS<n>:SENT:TRIGger:SLOW:ILENght"** on page 1195
- **":SBUS<n>:SENT:TRIGger:TOLerance"** on page 1196

:SBUS<n>:SENT:IDLE

N (see [page 1730](#))

Command Syntax :SBUS<n>:SENT:IDLE <state>

<state> ::= {LOW | HIGH}

The :SBUS<n>:SENT:IDLE command specifies the idle state of the SENT bus.

Query Syntax :SBUS<n>:SENT:IDLE?

The :SBUS<n>:SENT:IDLE? query returns the idle state setting.

Return Format <state><NL>

<state> ::= {LOW | HIGH}

- See Also**
- [":SBUS<n>:SENT:CLOCK"](#) on page 1164
 - [":SBUS<n>:SENT:CRC"](#) on page 1165
 - [":SBUS<n>:SENT:DISPlay"](#) on page 1166
 - [":SBUS<n>:SENT:FORMat"](#) on page 1168
 - [":SBUS<n>:SENT:LENGth"](#) on page 1171
 - [":SBUS<n>:SENT:PPULse"](#) on page 1172
 - [":SBUS<n>:SENT:SIGNal<s>:DISPlay"](#) on page 1174
 - [":SBUS<n>:SENT:SIGNal<s>:LENGth"](#) on page 1175
 - [":SBUS<n>:SENT:SIGNal<s>:MULTIplier"](#) on page 1177
 - [":SBUS<n>:SENT:SIGNal<s>:OFFSet"](#) on page 1179
 - [":SBUS<n>:SENT:SIGNal<s>:ORDer"](#) on page 1181
 - [":SBUS<n>:SENT:SIGNal<s>:START"](#) on page 1183
 - [":SBUS<n>:SENT:SOURce"](#) on page 1185
 - [":SBUS<n>:SENT:TOLerance"](#) on page 1187
 - [":SBUS<n>:SENT:TRIGger"](#) on page 1188
 - [":SBUS<n>:SENT:TRIGger:FAST:DATA"](#) on page 1190
 - [":SBUS<n>:SENT:TRIGger:SLOW:DATA"](#) on page 1191
 - [":SBUS<n>:SENT:TRIGger:SLOW:ID"](#) on page 1193
 - [":SBUS<n>:SENT:TRIGger:SLOW:ILENght"](#) on page 1195
 - [":SBUS<n>:SENT:TRIGger:TOLerance"](#) on page 1196

:SBUS<n>:SENT:LENGth

N (see [page 1730](#))

Command Syntax :SBUS<n>:SENT:LENGth <#_nibbles>

<#_nibbles> ::= from 1-6, in NR1 format.

The :SBUS<n>:SENT:LENGth command specifies the number of nibbles in a SENT message, from 1 to 6.

Query Syntax :SBUS<n>:SENT:LENGth?

The :SBUS<n>:SENT:LENGth? query returns the number of nibbles setting.

Return Format <#_nibbles><NL>

<#_nibbles> ::= from 1-6, in NR1 format.

- See Also**
- [":SBUS<n>:SENT:CLOCK"](#) on page 1164
 - [":SBUS<n>:SENT:CRC"](#) on page 1165
 - [":SBUS<n>:SENT:DISPlay"](#) on page 1166
 - [":SBUS<n>:SENT:FORMat"](#) on page 1168
 - [":SBUS<n>:SENT:IDLE"](#) on page 1170
 - [":SBUS<n>:SENT:PPULse"](#) on page 1172
 - [":SBUS<n>:SENT:SIGNal<s>:DISPlay"](#) on page 1174
 - [":SBUS<n>:SENT:SIGNal<s>:LENGth"](#) on page 1175
 - [":SBUS<n>:SENT:SIGNal<s>:MULTIplier"](#) on page 1177
 - [":SBUS<n>:SENT:SIGNal<s>:OFFSet"](#) on page 1179
 - [":SBUS<n>:SENT:SIGNal<s>:ORDer"](#) on page 1181
 - [":SBUS<n>:SENT:SIGNal<s>:START"](#) on page 1183
 - [":SBUS<n>:SENT:SOURce"](#) on page 1185
 - [":SBUS<n>:SENT:TOLerance"](#) on page 1187
 - [":SBUS<n>:SENT:TRIGger"](#) on page 1188
 - [":SBUS<n>:SENT:TRIGger:FAST:DATA"](#) on page 1190
 - [":SBUS<n>:SENT:TRIGger:SLOW:DATA"](#) on page 1191
 - [":SBUS<n>:SENT:TRIGger:SLOW:ID"](#) on page 1193
 - [":SBUS<n>:SENT:TRIGger:SLOW:ILENGth"](#) on page 1195
 - [":SBUS<n>:SENT:TRIGger:TOLerance"](#) on page 1196

:SBUS<n>:SENT:PPULse

N (see [page 1730](#))

Command Syntax :SBUS<n>:SENT:PPULse {{0 | OFF} | {1 | ON} | SPC}

The :SBUS<n>:SENT:PPULse command specifies whether there is a pause pulse between Fast Channel Messages:

- OFF – There is no pause pulse between Fast Channel Messages.

Note that a SENT serial bus with no pause pulse is never idle. This means, during normal operation, the fast channel decode line will show a continuous stream of packets, with a new packet opening as soon as the previous one has closed.

- ON – Pause pulses are added between Fast Channel Messages so that frames come at a regular interval.

If there is a pause pulse (and **Pause Pulse** is on), idle time is shown between messages.

- SPC (Short PWM Code) – In SENT SPC, there are no pause pulses. Instead, the message event is triggered by the master when it wants to receive data. SENT SPC ends the transmission after the CRC so it almost appears as if there is a pause pulse from the end until the next master trigger.

Query Syntax :SBUS<n>:SENT:PPULse?

The :SBUS<n>:SENT:PPULse? query returns the pause mode setting.

Return Format <setting><NL>

<setting> ::= {0 | 1 | SPC}

- See Also**
- [":SBUS<n>:SENT:CLOCK"](#) on page 1164
 - [":SBUS<n>:SENT:CRC"](#) on page 1165
 - [":SBUS<n>:SENT:DISPlay"](#) on page 1166
 - [":SBUS<n>:SENT:FORMat"](#) on page 1168
 - [":SBUS<n>:SENT:IDLE"](#) on page 1170
 - [":SBUS<n>:SENT:LENGth"](#) on page 1171
 - [":SBUS<n>:SENT:SIGNal<s>:DISPlay"](#) on page 1174
 - [":SBUS<n>:SENT:SIGNal<s>:LENGth"](#) on page 1175
 - [":SBUS<n>:SENT:SIGNal<s>:MULTIplier"](#) on page 1177
 - [":SBUS<n>:SENT:SIGNal<s>:OFFSet"](#) on page 1179
 - [":SBUS<n>:SENT:SIGNal<s>:ORDer"](#) on page 1181
 - [":SBUS<n>:SENT:SIGNal<s>:START"](#) on page 1183
 - [":SBUS<n>:SENT:SOURce"](#) on page 1185

- `":SBUS<n>:SENT:TOLerance"` on page 1187
- `":SBUS<n>:SENT:TRIGger"` on page 1188
- `":SBUS<n>:SENT:TRIGger:FAST:DATA"` on page 1190
- `":SBUS<n>:SENT:TRIGger:SLOW:DATA"` on page 1191
- `":SBUS<n>:SENT:TRIGger:SLOW:ID"` on page 1193
- `":SBUS<n>:SENT:TRIGger:SLOW:ILENght"` on page 1195
- `":SBUS<n>:SENT:TRIGger:TOLerance"` on page 1196

:SBUS<n>:SENT:SIGNAl<s>:DISPlay

N (see [page 1730](#))

Command Syntax :SBUS<n>:SENT:SIGNAl<s>:DISPlay {{0 | OFF} | {1 | ON}}

<s> ::= 1-6, in NR1 format.

The :SBUS<n>:SENT:SIGNAl<s>:DISPlay command specifies whether the given signal is on or off.

Query Syntax :SBUS<n>:SENT:SIGNAl<s>:DISPlay?

The :SBUS<n>:SENT:SIGNAl<s>:DISPlay? query returns the signal on/off setting.

Return Format <setting><NL>

<setting> ::= {0 | 1}

- See Also**
- [":SBUS<n>:SENT:CLOCK"](#) on page 1164
 - [":SBUS<n>:SENT:CRC"](#) on page 1165
 - [":SBUS<n>:SENT:DISPlay"](#) on page 1166
 - [":SBUS<n>:SENT:FORMat"](#) on page 1168
 - [":SBUS<n>:SENT:IDLE"](#) on page 1170
 - [":SBUS<n>:SENT:LENGth"](#) on page 1171
 - [":SBUS<n>:SENT:PPULse"](#) on page 1172
 - [":SBUS<n>:SENT:SIGNAl<s>:LENGth"](#) on page 1175
 - [":SBUS<n>:SENT:SIGNAl<s>:MULTIplier"](#) on page 1177
 - [":SBUS<n>:SENT:SIGNAl<s>:OFFSet"](#) on page 1179
 - [":SBUS<n>:SENT:SIGNAl<s>:ORDer"](#) on page 1181
 - [":SBUS<n>:SENT:SIGNAl<s>:START"](#) on page 1183
 - [":SBUS<n>:SENT:SOURce"](#) on page 1185
 - [":SBUS<n>:SENT:TOLerance"](#) on page 1187
 - [":SBUS<n>:SENT:TRIGger"](#) on page 1188
 - [":SBUS<n>:SENT:TRIGger:FAST:DATA"](#) on page 1190
 - [":SBUS<n>:SENT:TRIGger:SLOW:DATA"](#) on page 1191
 - [":SBUS<n>:SENT:TRIGger:SLOW:ID"](#) on page 1193
 - [":SBUS<n>:SENT:TRIGger:SLOW:ILENgth"](#) on page 1195
 - [":SBUS<n>:SENT:TRIGger:TOLerance"](#) on page 1196

:SBUS<n>:SENT:SIGNAl<s>:LENGth

N (see [page 1730](#))

Command Syntax :SBUS<n>:SENT:SIGNAl<s>:LENGth <length>


<s> ::= 1-6, in NR1 format.

<length> ::= from 1-24, in NR1 format.


The :SBUS<n>:SENT:SIGNAl<s>:LENGth command specifies the bit length of the signal being defined.

Fast Signal definition examples:

Example 1: Start Bit # = 13, # of bits = 8, Nibble Order = LSN First



Example 2: Start Bit # = 10, # of bits = 5, Nibble Order = MSN First



Query Syntax :SBUS<n>:SENT:SIGNAl<s>:LENGth?

The :SBUS<n>:SENT:SIGNAl<s>:LENGth? query returns the signal bit length setting.

Return Format <length><NL>

<length> ::= from 1-24, in NR1 format.

- See Also**
- [":SBUS<n>:SENT:CLOCK"](#) on page 1164
 - [":SBUS<n>:SENT:CRC"](#) on page 1165
 - [":SBUS<n>:SENT:DISPlay"](#) on page 1166
 - [":SBUS<n>:SENT:FORMat"](#) on page 1168
 - [":SBUS<n>:SENT:IDLE"](#) on page 1170
 - [":SBUS<n>:SENT:LENGth"](#) on page 1171
 - [":SBUS<n>:SENT:PPULse"](#) on page 1172
 - [":SBUS<n>:SENT:SIGNAl<s>:DISPlay"](#) on page 1174
 - [":SBUS<n>:SENT:SIGNAl<s>:MULTIplier"](#) on page 1177
 - [":SBUS<n>:SENT:SIGNAl<s>:OFFSet"](#) on page 1179

- **":SBUS<n>:SENT:SIGNal<s>:ORDER"** on page 1181
- **":SBUS<n>:SENT:SIGNal<s>:START"** on page 1183
- **":SBUS<n>:SENT:SOURce"** on page 1185
- **":SBUS<n>:SENT:TOLerance"** on page 1187
- **":SBUS<n>:SENT:TRIGger"** on page 1188
- **":SBUS<n>:SENT:TRIGger:FAST:DATA"** on page 1190
- **":SBUS<n>:SENT:TRIGger:SLOW:DATA"** on page 1191
- **":SBUS<n>:SENT:TRIGger:SLOW:ID"** on page 1193
- **":SBUS<n>:SENT:TRIGger:SLOW:ILENght"** on page 1195
- **":SBUS<n>:SENT:TRIGger:TOLerance"** on page 1196

:SBUS<n>:SENT:SIGNAl<s>:MULTIplier

N (see [page 1730](#))

Command Syntax :SBUS<n>:SENT:SIGNAl<s>:MULTIplier <multiplier>

<s> ::= 1-6, in NR1 format.

<multiplier> ::= from 1-24, in NR3 format.

When the display mode setting is SYMBolic (see :SBUS<n>:SENT:DISPlay), the :SBUS<n>:SENT:SIGNAl<s>:MULTIplier command specifies the multiplier to be used in calculating a physical value displayed for a Fast Channel Signal.

- $PhysicalValue = (Multiplier * SignalValueAsUnsignedInteger) + Offset$

Query Syntax :SBUS<n>:SENT:SIGNAl<s>:MULTIplier?

The :SBUS<n>:SENT:SIGNAl<s>:MULTIplier? query returns the multiplier value for the Fast Channel Signal.

Return Format <multiplier><NL>

<multiplier> ::= from 1-24, in NR3 format.

- See Also**
- [":SBUS<n>:SENT:CLOCK"](#) on page 1164
 - [":SBUS<n>:SENT:CRC"](#) on page 1165
 - [":SBUS<n>:SENT:DISPlay"](#) on page 1166
 - [":SBUS<n>:SENT:FORMat"](#) on page 1168
 - [":SBUS<n>:SENT:IDLE"](#) on page 1170
 - [":SBUS<n>:SENT:LENGth"](#) on page 1171
 - [":SBUS<n>:SENT:PPULse"](#) on page 1172
 - [":SBUS<n>:SENT:SIGNAl<s>:DISPlay"](#) on page 1174
 - [":SBUS<n>:SENT:SIGNAl<s>:LENGth"](#) on page 1175
 - [":SBUS<n>:SENT:SIGNAl<s>:OFFSet"](#) on page 1179
 - [":SBUS<n>:SENT:SIGNAl<s>:ORDer"](#) on page 1181
 - [":SBUS<n>:SENT:SIGNAl<s>:START"](#) on page 1183
 - [":SBUS<n>:SENT:SOURce"](#) on page 1185
 - [":SBUS<n>:SENT:TOLerance"](#) on page 1187
 - [":SBUS<n>:SENT:TRIGger"](#) on page 1188
 - [":SBUS<n>:SENT:TRIGger:FAST:DATA"](#) on page 1190
 - [":SBUS<n>:SENT:TRIGger:SLOW:DATA"](#) on page 1191
 - [":SBUS<n>:SENT:TRIGger:SLOW:ID"](#) on page 1193
 - [":SBUS<n>:SENT:TRIGger:SLOW:ILENgth"](#) on page 1195

- [":SBUS<n>:SENT:TRIGger:TOLerance"](#) on page 1196

:SBUS<n>:SENT:SIGNal<s>:OFFSet

N (see [page 1730](#))

Command Syntax :SBUS<n>:SENT:SIGNal<s>:OFFSet <offset>

<s> ::= 1-6, in NR1 format.

<offset> ::= from 1-24, in NR3 format.

When the display mode setting is SYMBolic (see :SBUS<n>:SENT:DISPlay), the :SBUS<n>:SENT:SIGNal<s>:OFFSet command is used in calculating a physical value displayed for the Fast Channel Signal:

- $PhysicalValue = (Multiplier * SignalValueAsUnsignedInteger) + Offset$

Query Syntax :SBUS<n>:SENT:SIGNal<s>:OFFSet?

The :SBUS<n>:SENT:SIGNal<s>:OFFSet? query returns the offset value for the Fast Channel Signal.

Return Format <offset><NL>

<offset> ::= from 1-24, in NR3 format.

- See Also**
- [":SBUS<n>:SENT:CLOCK"](#) on page 1164
 - [":SBUS<n>:SENT:CRC"](#) on page 1165
 - [":SBUS<n>:SENT:DISPlay"](#) on page 1166
 - [":SBUS<n>:SENT:FORMat"](#) on page 1168
 - [":SBUS<n>:SENT:IDLE"](#) on page 1170
 - [":SBUS<n>:SENT:LENGth"](#) on page 1171
 - [":SBUS<n>:SENT:PPULse"](#) on page 1172
 - [":SBUS<n>:SENT:SIGNal<s>:DISPlay"](#) on page 1174
 - [":SBUS<n>:SENT:SIGNal<s>:LENGth"](#) on page 1175
 - [":SBUS<n>:SENT:SIGNal<s>:MULTIplier"](#) on page 1177
 - [":SBUS<n>:SENT:SIGNal<s>:ORDer"](#) on page 1181
 - [":SBUS<n>:SENT:SIGNal<s>:START"](#) on page 1183
 - [":SBUS<n>:SENT:SOURce"](#) on page 1185
 - [":SBUS<n>:SENT:TOLerance"](#) on page 1187
 - [":SBUS<n>:SENT:TRIGger"](#) on page 1188
 - [":SBUS<n>:SENT:TRIGger:FAST:DATA"](#) on page 1190
 - [":SBUS<n>:SENT:TRIGger:SLOW:DATA"](#) on page 1191
 - [":SBUS<n>:SENT:TRIGger:SLOW:ID"](#) on page 1193
 - [":SBUS<n>:SENT:TRIGger:SLOW:ILENGth"](#) on page 1195

- [":SBUS<n>:SENT:TRIGger:TOLerance"](#) on page 1196

:SBUS<n>:SENT:SIGNAl<s>:ORDER

N (see [page 1730](#))

Command Syntax :SBUS<n>:SENT:SIGNAl<s>:ORDER <order>


<s> ::= 1-6, in NR1 format.

<order> ::= {MSNFirst | LSNFirst}


The :SBUS<n>:SENT:SIGNAl<s>:ORDER command specifies the nibble order of the signal being defined, either Most Significant Nibble first, or Least Significant Nibble first.

Fast Signal definition examples:

Example 1: Start Bit # = 13, # of bits = 8, Nibble Order = LSN First



Example 2: Start Bit # = 10, # of bits = 5, Nibble Order = MSN First



Query Syntax :SBUS<n>:SENT:SIGNAl<s>:ORDER?

The :SBUS<n>:SENT:SIGNAl<s>:ORDER? query returns the nibble order setting.

Return Format <order><NL>

<order> ::= {MSNF | LSNF}

- See Also**
- [":SBUS<n>:SENT:CLOCK"](#) on page 1164
 - [":SBUS<n>:SENT:CRC"](#) on page 1165
 - [":SBUS<n>:SENT:DISPlay"](#) on page 1166
 - [":SBUS<n>:SENT:FORMat"](#) on page 1168
 - [":SBUS<n>:SENT:IDLE"](#) on page 1170
 - [":SBUS<n>:SENT:LENGth"](#) on page 1171
 - [":SBUS<n>:SENT:PPULse"](#) on page 1172
 - [":SBUS<n>:SENT:SIGNAl<s>:DISPlay"](#) on page 1174
 - [":SBUS<n>:SENT:SIGNAl<s>:LENGth"](#) on page 1175
 - [":SBUS<n>:SENT:SIGNAl<s>:MULTiplier"](#) on page 1177

- **":SBUS<n>:SENT:SIGNal<s>:OFFSet"** on page 1179
- **":SBUS<n>:SENT:SIGNal<s>:START"** on page 1183
- **":SBUS<n>:SENT:SOURce"** on page 1185
- **":SBUS<n>:SENT:TOLerance"** on page 1187
- **":SBUS<n>:SENT:TRIGger"** on page 1188
- **":SBUS<n>:SENT:TRIGger:FAST:DATA"** on page 1190
- **":SBUS<n>:SENT:TRIGger:SLOW:DATA"** on page 1191
- **":SBUS<n>:SENT:TRIGger:SLOW:ID"** on page 1193
- **":SBUS<n>:SENT:TRIGger:SLOW:ILENght"** on page 1195
- **":SBUS<n>:SENT:TRIGger:TOLerance"** on page 1196

:SBUS<n>:SENT:SIGNAl<s>:START

N (see [page 1730](#))

Command Syntax :SBUS<n>:SENT:SIGNAl<s>:START <position>


<s> ::= 1-6, in NR1 format.

<position> ::= from 0-23, in NR1 format.


The :SBUS<n>:SENT:SIGNAl<s>:START command specifies the starting bit of the Fast Signal being defined.

Fast Signal definition examples:

Example 1: Start Bit # = 13, # of bits = 8, Nibble Order = LSN First



Example 2: Start Bit # = 10, # of bits = 5, Nibble Order = MSN First



Query Syntax :SBUS<n>:SENT:SIGNAl<s>:START?

The :SBUS<n>:SENT:SIGNAl<s>:START? query returns the Fast Signal starting bit setting.

Return Format <position><NL>

<position> ::= from 0-23, in NR1 format.

- See Also**
- [":SBUS<n>:SENT:CLOCK"](#) on page 1164
 - [":SBUS<n>:SENT:CRC"](#) on page 1165
 - [":SBUS<n>:SENT:DISPlay"](#) on page 1166
 - [":SBUS<n>:SENT:FORMat"](#) on page 1168
 - [":SBUS<n>:SENT:IDLE"](#) on page 1170
 - [":SBUS<n>:SENT:LENGth"](#) on page 1171
 - [":SBUS<n>:SENT:PPULse"](#) on page 1172
 - [":SBUS<n>:SENT:SIGNAl<s>:DISPlay"](#) on page 1174
 - [":SBUS<n>:SENT:SIGNAl<s>:LENGth"](#) on page 1175
 - [":SBUS<n>:SENT:SIGNAl<s>:MULTIplier"](#) on page 1177

- **":SBUS<n>:SENT:SIGNal<s>:OFFSet"** on page 1179
- **":SBUS<n>:SENT:SIGNal<s>:ORDer"** on page 1181
- **":SBUS<n>:SENT:SOURce"** on page 1185
- **":SBUS<n>:SENT:TOLerance"** on page 1187
- **":SBUS<n>:SENT:TRIGger"** on page 1188
- **":SBUS<n>:SENT:TRIGger:FAST:DATA"** on page 1190
- **":SBUS<n>:SENT:TRIGger:SLOW:DATA"** on page 1191
- **":SBUS<n>:SENT:TRIGger:SLOW:ID"** on page 1193
- **":SBUS<n>:SENT:TRIGger:SLOW:ILENght"** on page 1195
- **":SBUS<n>:SENT:TRIGger:TOLerance"** on page 1196

:SBUS<n>:SENT:SOURce

N (see [page 1730](#))

Command Syntax :SBUS<n>:SENT:SOURce <source>

<source> ::= {CHANnel<n> | DIGital<d>}

<n> ::= 1 to (# analog channels) in NR1 format

<d> ::= 0 to (# digital channels - 1) in NR1 format

The :SBUS<n>:SENT:SOURce command specifies the input channel for SENT decode and triggering.

Query Syntax :SBUS<n>:SENT:SOURce?

The :SBUS<n>:SENT:SOURce? query returns the specified SENT input source.

Return Format <source><NL>

<source> ::= {CHANnel<n> | DIGital<d>}

<n> ::= 1 to (# analog channels) in NR1 format

<d> ::= 0 to (# digital channels - 1) in NR1 format

- See Also**
- [":SBUS<n>:SENT:CLOCK"](#) on page 1164
 - [":SBUS<n>:SENT:CRC"](#) on page 1165
 - [":SBUS<n>:SENT:DISPlay"](#) on page 1166
 - [":SBUS<n>:SENT:FORMat"](#) on page 1168
 - [":SBUS<n>:SENT:IDLE"](#) on page 1170
 - [":SBUS<n>:SENT:LENGth"](#) on page 1171
 - [":SBUS<n>:SENT:PPULse"](#) on page 1172
 - [":SBUS<n>:SENT:SIGNal<s>:DISPlay"](#) on page 1174
 - [":SBUS<n>:SENT:SIGNal<s>:LENGth"](#) on page 1175
 - [":SBUS<n>:SENT:SIGNal<s>:MULTIplier"](#) on page 1177
 - [":SBUS<n>:SENT:SIGNal<s>:OFFSet"](#) on page 1179
 - [":SBUS<n>:SENT:SIGNal<s>:ORDer"](#) on page 1181
 - [":SBUS<n>:SENT:SIGNal<s>:START"](#) on page 1183
 - [":SBUS<n>:SENT:TOLerance"](#) on page 1187
 - [":SBUS<n>:SENT:TRIGger"](#) on page 1188
 - [":SBUS<n>:SENT:TRIGger:FAST:DATA"](#) on page 1190
 - [":SBUS<n>:SENT:TRIGger:SLOW:DATA"](#) on page 1191
 - [":SBUS<n>:SENT:TRIGger:SLOW:ID"](#) on page 1193
 - [":SBUS<n>:SENT:TRIGger:SLOW:ILENgth"](#) on page 1195

- **":SBUS<n>:SENT:TRIGger:TOLerance"** on page 1196

:SBUS<n>:SENT:TOLerance

N (see [page 1730](#))

Command Syntax :SBUS<n>:SENT:TOLerance <percent>

<percent> ::= from 3-30, in NR1 format.

The :SBUS<n>:SENT:TOLerance command specifies the tolerance for determining whether the sync pulse is valid. Valid values range from 3% to 30%.

Query Syntax :SBUS<n>:SENT:TOLerance?

The :SBUS<n>:SENT:TOLerance? query returns the tolerance setting.

Return Format <percent><NL>

<percent> ::= from 3-30, in NR1 format.

- See Also**
- [":SBUS<n>:SENT:CLOCK"](#) on page 1164
 - [":SBUS<n>:SENT:CRC"](#) on page 1165
 - [":SBUS<n>:SENT:DISPlay"](#) on page 1166
 - [":SBUS<n>:SENT:FORMat"](#) on page 1168
 - [":SBUS<n>:SENT:IDLE"](#) on page 1170
 - [":SBUS<n>:SENT:LENGth"](#) on page 1171
 - [":SBUS<n>:SENT:PPULse"](#) on page 1172
 - [":SBUS<n>:SENT:SIGNal<s>:DISPlay"](#) on page 1174
 - [":SBUS<n>:SENT:SIGNal<s>:LENGth"](#) on page 1175
 - [":SBUS<n>:SENT:SIGNal<s>:MULTIplier"](#) on page 1177
 - [":SBUS<n>:SENT:SIGNal<s>:OFFSet"](#) on page 1179
 - [":SBUS<n>:SENT:SIGNal<s>:ORDer"](#) on page 1181
 - [":SBUS<n>:SENT:SIGNal<s>:START"](#) on page 1183
 - [":SBUS<n>:SENT:SOURce"](#) on page 1185
 - [":SBUS<n>:SENT:TRIGger"](#) on page 1188
 - [":SBUS<n>:SENT:TRIGger:FAST:DATA"](#) on page 1190
 - [":SBUS<n>:SENT:TRIGger:SLOW:DATA"](#) on page 1191
 - [":SBUS<n>:SENT:TRIGger:SLOW:ID"](#) on page 1193
 - [":SBUS<n>:SENT:TRIGger:SLOW:ILENgth"](#) on page 1195
 - [":SBUS<n>:SENT:TRIGger:TOLerance"](#) on page 1196

:SBUS<n>:SENT:TRIGger

N (see [page 1730](#))

Command Syntax :SBUS<n>:SENT:TRIGger <mode>

```
<mode> ::= {SFCMessage | SSCMessage | FCData | SCMid | SCData
            | TOLerror | FCCerror | SCCerror | CRCerror | PPERror | SSPerror}
```

The :SBUS<n>:SENT:TRIGger command specifies the SENT trigger mode:

- SFCMessage – triggers on the start of any Fast Channel Message (after 56 Synchronization/Calibration ticks).
- SSCMessage – trigger on the start of any Slow Channel Message.
- FCData – triggers on a Fast Channel Message when the Status & Communication nibble and the data nibbles match the values entered using additional softkeys.
- SCMid – triggers when a Slow Channel Message ID matches the value entered using additional softkeys.
- SCData – triggers when a Slow Channel Message ID and Data field both match the values entered using additional softkeys.
- TOLerror – triggers when the sync pulse width varies from the nominal value by greater than the entered percentage.
- FCCerror – triggers on any Fast Channel Message CRC error.
- SCCerror – triggers on any Slow Channel Message CRC error.
- CRCerror – triggers on any CRC error, Fast or Slow.
- PPERror – triggers if a nibble is either too wide or too narrow (for example, data nibble < 12 (11.5) or > 27 (27.5) ticks wide). Sync, S&C, data, or checksum pulse periods are checked.
- SSPerror – triggers on a sync pulse whose width varies from the previous sync pulse's width by greater than 1/64 (1.5625%, as defined in the SENT specification).

Query Syntax :SBUS<n>:SENT:TRIGger?

The :SBUS<n>:SENT:TRIGger? query returns the trigger mode setting.

Return Format <mode><NL>

```
<mode> ::= {SFCM | SSCM | FCD | SCM | SCD | TOL | FCC | SCC | CRC
            | PPER | SSP}
```

- See Also**
- **":SBUS<n>:SENT:CLOCK"** on page 1164
 - **":SBUS<n>:SENT:CRC"** on page 1165
 - **":SBUS<n>:SENT:DISPlay"** on page 1166
 - **":SBUS<n>:SENT:FORMat"** on page 1168

- **":SBUS<n>:SENT:IDLE"** on page 1170
- **":SBUS<n>:SENT:LENGth"** on page 1171
- **":SBUS<n>:SENT:PPULse"** on page 1172
- **":SBUS<n>:SENT:SIGNal<s>:DISPlay"** on page 1174
- **":SBUS<n>:SENT:SIGNal<s>:LENGth"** on page 1175
- **":SBUS<n>:SENT:SIGNal<s>:MULTIplier"** on page 1177
- **":SBUS<n>:SENT:SIGNal<s>:OFFSet"** on page 1179
- **":SBUS<n>:SENT:SIGNal<s>:ORDer"** on page 1181
- **":SBUS<n>:SENT:SIGNal<s>:START"** on page 1183
- **":SBUS<n>:SENT:SOURce"** on page 1185
- **":SBUS<n>:SENT:TOLerance"** on page 1187
- **":SBUS<n>:SENT:TRIGger:FAST:DATA"** on page 1190
- **":SBUS<n>:SENT:TRIGger:SLOW:DATA"** on page 1191
- **":SBUS<n>:SENT:TRIGger:SLOW:ID"** on page 1193
- **":SBUS<n>:SENT:TRIGger:SLOW:ILENght"** on page 1195
- **":SBUS<n>:SENT:TRIGger:TOLerance"** on page 1196

:SBUS<n>:SENT:TRIGger:FAST:DATA

N (see [page 1730](#))

Command Syntax :SBUS<n>:SENT:TRIGger:FAST:DATA <string>

<string> ::= "nnnn..." where n ::= {0 | 1 | X}

<string> ::= "0xn..." where n ::= {0,...,9 | A,...,F | X | \$}

The :SBUS<n>:SENT:TRIGger:FAST:DATA command specifies the status and data nibbles that will be triggered on when the FCData trigger mode is chosen.

Query Syntax :SBUS<n>:SENT:TRIGger:FAST:DATA?

The :SBUS<n>:SENT:TRIGger:FAST:DATA? query returns the fast channel data trigger setting.

Return Format <string><NL>

<string> ::= "nnnn..." where n ::= {0 | 1 | X}

<string> ::= "0xn..." where n ::= {0,...,9 | A,...,F | X | \$}

- See Also**
- [":SBUS<n>:SENT:CLOCK"](#) on page 1164
 - [":SBUS<n>:SENT:CRC"](#) on page 1165
 - [":SBUS<n>:SENT:DISPlay"](#) on page 1166
 - [":SBUS<n>:SENT:FORMat"](#) on page 1168
 - [":SBUS<n>:SENT:IDLE"](#) on page 1170
 - [":SBUS<n>:SENT:LENGth"](#) on page 1171
 - [":SBUS<n>:SENT:PPULse"](#) on page 1172
 - [":SBUS<n>:SENT:SIGNal<s>:DISPlay"](#) on page 1174
 - [":SBUS<n>:SENT:SIGNal<s>:LENGth"](#) on page 1175
 - [":SBUS<n>:SENT:SIGNal<s>:MULTIplier"](#) on page 1177
 - [":SBUS<n>:SENT:SIGNal<s>:OFFSet"](#) on page 1179
 - [":SBUS<n>:SENT:SIGNal<s>:ORDer"](#) on page 1181
 - [":SBUS<n>:SENT:SIGNal<s>:START"](#) on page 1183
 - [":SBUS<n>:SENT:SOURce"](#) on page 1185
 - [":SBUS<n>:SENT:TOLerance"](#) on page 1187
 - [":SBUS<n>:SENT:TRIGger"](#) on page 1188
 - [":SBUS<n>:SENT:TRIGger:SLOW:DATA"](#) on page 1191
 - [":SBUS<n>:SENT:TRIGger:SLOW:ID"](#) on page 1193
 - [":SBUS<n>:SENT:TRIGger:SLOW:ILENGth"](#) on page 1195
 - [":SBUS<n>:SENT:TRIGger:TOLerance"](#) on page 1196

:SBUS<n>:SENT:TRIGger:SLOW:DATA

N (see [page 1730](#))

Command Syntax :SBUS<n>:SENT:TRIGger:SLOW:DATA <data>

<data> ::= when ILENgth = SHORt, from -1 (don't care) to 65535, in NR1 format.

<data> ::= when ILENgth = LONG, from -1 (don't care) to 4095, in NR1 format.

The :SBUS<n>:SENT:TRIGger:SLOW:DATA command specifies the data to trigger on for the Slow Channel Message ID and Data trigger mode.

Query Syntax :SBUS<n>:SENT:TRIGger:SLOW:DATA?

The :SBUS<n>:SENT:TRIGger:SLOW:DATA? query returns the data value setting for the slow channel ID and data trigger.

Return Format <data><NL>

<data> ::= when ILENgth = SHORt, from -1 (don't care) to 65535, in NR1 format.

<data> ::= when ILENgth = LONG, from -1 (don't care) to 4095, in NR1 format.

- See Also**
- [":SBUS<n>:SENT:CLOCK"](#) on page 1164
 - [":SBUS<n>:SENT:CRC"](#) on page 1165
 - [":SBUS<n>:SENT:DISPlay"](#) on page 1166
 - [":SBUS<n>:SENT:FORMat"](#) on page 1168
 - [":SBUS<n>:SENT:IDLE"](#) on page 1170
 - [":SBUS<n>:SENT:LENgth"](#) on page 1171
 - [":SBUS<n>:SENT:PPULse"](#) on page 1172
 - [":SBUS<n>:SENT:SIGNal<s>:DISPlay"](#) on page 1174
 - [":SBUS<n>:SENT:SIGNal<s>:LENgth"](#) on page 1175
 - [":SBUS<n>:SENT:SIGNal<s>:MULTiplier"](#) on page 1177
 - [":SBUS<n>:SENT:SIGNal<s>:OFFSet"](#) on page 1179
 - [":SBUS<n>:SENT:SIGNal<s>:ORDer"](#) on page 1181
 - [":SBUS<n>:SENT:SIGNal<s>:START"](#) on page 1183
 - [":SBUS<n>:SENT:SOURce"](#) on page 1185
 - [":SBUS<n>:SENT:TOLerance"](#) on page 1187
 - [":SBUS<n>:SENT:TRIGger"](#) on page 1188
 - [":SBUS<n>:SENT:TRIGger:FAST:DATA"](#) on page 1190
 - [":SBUS<n>:SENT:TRIGger:SLOW:ID"](#) on page 1193

- `":SBUS<n>:SENT:TRIGger:SLOW:ILENgtH"` on page 1195
- `":SBUS<n>:SENT:TRIGger:TOLerance"` on page 1196

:SBUS<n>:SENT:TRIGger:SLOW:ID

N (see [page 1730](#))

Command Syntax :SBUS<n>:SENT:TRIGger:SLOW:ID <id>

<id> ::= when ILENgth = SHORt, from -1 (don't care) to 15, in NR1 format
.

<id> ::= when ILENgth = LONG, from -1 (don't care) to 255, in NR1 format
.

The :SBUS<n>:SENT:TRIGger:SLOW:ID command specifies the ID to trigger on for the "Slow Channel Message ID" and "Slow Channel Message ID & Data" trigger modes. The ID can be from -1 (don't care) to 255 (depending on the message length).

Query Syntax :SBUS<n>:SENT:TRIGger:SLOW:ID?

The :SBUS<n>:SENT:TRIGger:SLOW:ID? query returns the slow channel ID setting.

Return Format <id><NL>

<id> ::= when ILENgth = SHORt, from -1 (don't care) to 15, in NR1 format
.

<id> ::= when ILENgth = LONG, from -1 (don't care) to 255, in NR1 format
.

- See Also**
- [":SBUS<n>:SENT:CLOCK"](#) on page 1164
 - [":SBUS<n>:SENT:CRC"](#) on page 1165
 - [":SBUS<n>:SENT:DISPlay"](#) on page 1166
 - [":SBUS<n>:SENT:FORMat"](#) on page 1168
 - [":SBUS<n>:SENT:IDLE"](#) on page 1170
 - [":SBUS<n>:SENT:LENgth"](#) on page 1171
 - [":SBUS<n>:SENT:PPULse"](#) on page 1172
 - [":SBUS<n>:SENT:SIGNal<s>:DISPlay"](#) on page 1174
 - [":SBUS<n>:SENT:SIGNal<s>:LENgth"](#) on page 1175
 - [":SBUS<n>:SENT:SIGNal<s>:MULTiplier"](#) on page 1177
 - [":SBUS<n>:SENT:SIGNal<s>:OFFSet"](#) on page 1179
 - [":SBUS<n>:SENT:SIGNal<s>:ORDer"](#) on page 1181
 - [":SBUS<n>:SENT:SIGNal<s>:START"](#) on page 1183
 - [":SBUS<n>:SENT:SOURce"](#) on page 1185
 - [":SBUS<n>:SENT:TOLerance"](#) on page 1187
 - [":SBUS<n>:SENT:TRIGger"](#) on page 1188
 - [":SBUS<n>:SENT:TRIGger:FAST:DATA"](#) on page 1190

- `":SBUS<n>:SENT:TRIGger:SLOW:DATA"` on page 1191
- `":SBUS<n>:SENT:TRIGger:SLOW:ILENgtH"` on page 1195
- `":SBUS<n>:SENT:TRIGger:TOLerance"` on page 1196

:SBUS<n>:SENT:TRIGger:SLOW:ILENgtH

N (see [page 1730](#))

Command Syntax :SBUS<n>:SENT:TRIGger:SLOW:ILENgtH <length>

<length> ::= {SHORT | LONG}

The :SBUS<n>:SENT:TRIGger:SLOW:ILENgtH command specifies the ID and data lengths for the Slow Message Enhanced messages. Either "SHORT" for the 4-bit ID, 16-bit data format, or "LONG" for the 8-bit ID, 12-bit data format.

Query Syntax :SBUS<n>:SENT:TRIGger:SLOW:ILENgtH?

The :SBUS<n>:SENT:TRIGger:SLOW:ILENgtH? query returns the ID and data length setting.

Return Format <length><NL>

<length> ::= {SHOR | LONG}

- See Also**
- [":SBUS<n>:SENT:CLOCK"](#) on page 1164
 - [":SBUS<n>:SENT:CRC"](#) on page 1165
 - [":SBUS<n>:SENT:DISPlay"](#) on page 1166
 - [":SBUS<n>:SENT:FORMat"](#) on page 1168
 - [":SBUS<n>:SENT:IDLE"](#) on page 1170
 - [":SBUS<n>:SENT:LENGth"](#) on page 1171
 - [":SBUS<n>:SENT:PPULse"](#) on page 1172
 - [":SBUS<n>:SENT:SIGNal<s>:DISPlay"](#) on page 1174
 - [":SBUS<n>:SENT:SIGNal<s>:LENGth"](#) on page 1175
 - [":SBUS<n>:SENT:SIGNal<s>:MULTIplier"](#) on page 1177
 - [":SBUS<n>:SENT:SIGNal<s>:OFFSet"](#) on page 1179
 - [":SBUS<n>:SENT:SIGNal<s>:ORDer"](#) on page 1181
 - [":SBUS<n>:SENT:SIGNal<s>:START"](#) on page 1183
 - [":SBUS<n>:SENT:SOURce"](#) on page 1185
 - [":SBUS<n>:SENT:TOLerance"](#) on page 1187
 - [":SBUS<n>:SENT:TRIGger"](#) on page 1188
 - [":SBUS<n>:SENT:TRIGger:FAST:DATA"](#) on page 1190
 - [":SBUS<n>:SENT:TRIGger:SLOW:DATA"](#) on page 1191
 - [":SBUS<n>:SENT:TRIGger:SLOW:ID"](#) on page 1193
 - [":SBUS<n>:SENT:TRIGger:TOLerance"](#) on page 1196

:SBUS<n>:SENT:TRIGger:TOLerance

N (see [page 1730](#))

Command Syntax :SBUS<n>:SENT:TRIGger:TOLerance <percent>

<percent> ::= from 1-28, in NR1 format.

The :SBUS<n>:SENT:TRIGger:TOLerance command specifies the tolerance variation that is considered a violation.

The trigger tolerance can be up to the :SBUS<n>:SENT:TOLerance setting minus two percent. For example, after sending ":SBUS1:SENT:TOLerance 20", the :SBUS1:SENT:TRIGger:TOLerance setting can be from 1 to 18.

Query Syntax :SBUS<n>:SENT:TRIGger:TOLerance?

The :SBUS<n>:SENT:TRIGger:TOLerance? query returns tolerance variation percent setting.

Return Format <percent><NL>

<percent> ::= from 1-28, in NR1 format.

- See Also**
- [":SBUS<n>:SENT:CLOCK"](#) on page 1164
 - [":SBUS<n>:SENT:CRC"](#) on page 1165
 - [":SBUS<n>:SENT:DISPlay"](#) on page 1166
 - [":SBUS<n>:SENT:FORMat"](#) on page 1168
 - [":SBUS<n>:SENT:IDLE"](#) on page 1170
 - [":SBUS<n>:SENT:LENGth"](#) on page 1171
 - [":SBUS<n>:SENT:PPULse"](#) on page 1172
 - [":SBUS<n>:SENT:SIGNal<s>:DISPlay"](#) on page 1174
 - [":SBUS<n>:SENT:SIGNal<s>:LENGth"](#) on page 1175
 - [":SBUS<n>:SENT:SIGNal<s>:MULTiplier"](#) on page 1177
 - [":SBUS<n>:SENT:SIGNal<s>:OFFSet"](#) on page 1179
 - [":SBUS<n>:SENT:SIGNal<s>:ORDer"](#) on page 1181
 - [":SBUS<n>:SENT:SIGNal<s>:START"](#) on page 1183
 - [":SBUS<n>:SENT:SOURce"](#) on page 1185
 - [":SBUS<n>:SENT:TOLerance"](#) on page 1187
 - [":SBUS<n>:SENT:TRIGger"](#) on page 1188
 - [":SBUS<n>:SENT:TRIGger:FAST:DATA"](#) on page 1190
 - [":SBUS<n>:SENT:TRIGger:SLOW:DATA"](#) on page 1191
 - [":SBUS<n>:SENT:TRIGger:SLOW:ID"](#) on page 1193
 - [":SBUS<n>:SENT:TRIGger:SLOW:ILENgtH"](#) on page 1195

:SBUS<n>:SPI Commands

NOTE

These commands are only valid when the low-speed IIC and SPI serial decode option has been licensed.

Table 139 :SBUS<n>:SPI Commands Summary

Command	Query	Options and Query Returns
:SBUS<n>:SPI:BITOrder <order> (see page 1199)	:SBUS<n>:SPI:BITOrder ? (see page 1199)	<order> ::= {LSBFirst MSBFirst}
:SBUS<n>:SPI:CLOCK:SL OPe <slope> (see page 1200)	:SBUS<n>:SPI:CLOCK:SL OPe? (see page 1200)	<slope> ::= {NEGative POSitive}
:SBUS<n>:SPI:CLOCK:TI Meout <time_value> (see page 1201)	:SBUS<n>:SPI:CLOCK:TI Meout? (see page 1201)	<time_value> ::= time in seconds in NR3 format
:SBUS<n>:SPI:DELAy <value> (see page 1202)	:SBUS<n>:SPI:DELAy? (see page 1202)	<value> ::= {OFF 2-63}
:SBUS<n>:SPI:FRAMing <value> (see page 1203)	:SBUS<n>:SPI:FRAMing? (see page 1203)	<value> ::= {CHIPselect {NCHipselect NOTC} TIMEout}
:SBUS<n>:SPI:SOURce:C LOCK <source> (see page 1204)	:SBUS<n>:SPI:SOURce:C LOCK? (see page 1204)	<value> ::= {CHANnel<n> EXTernal} for the DSO models <value> ::= {CHANnel<n> DIGital<d>} for the MSO models <n> ::= 1 to (# analog channels) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format
:SBUS<n>:SPI:SOURce:F RAME <source> (see page 1205)	:SBUS<n>:SPI:SOURce:F RAME? (see page 1205)	<value> ::= {CHANnel<n> EXTernal} for the DSO models <value> ::= {CHANnel<n> DIGital<d>} for the MSO models <n> ::= 1 to (# analog channels) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format

Table 139 :SBUS<n>:SPI Commands Summary (continued)

Command	Query	Options and Query Returns
:SBUS<n>:SPI:SOURce:MISO <source> (see page 1206)	:SBUS<n>:SPI:SOURce:MISO? (see page 1206)	<value> ::= {CHANnel<n> EXTernal} for the DSO models <value> ::= {CHANnel<n> DIGital<d>} for the MSO models <n> ::= 1 to (# analog channels) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format
:SBUS<n>:SPI:SOURce:MOSI <source> (see page 1207)	:SBUS<n>:SPI:SOURce:MOSI? (see page 1207)	<value> ::= {CHANnel<n> EXTernal} for the DSO models <value> ::= {CHANnel<n> DIGital<d>} for the MSO models <n> ::= 1 to (# analog channels) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format
:SBUS<n>:SPI:TRIGger:PATtern:MISO:DATA <string> (see page 1208)	:SBUS<n>:SPI:TRIGger:PATtern:MISO:DATA? (see page 1208)	<string> ::= "nn...n" where n ::= {0 1 X \$} <string ::= "0xnn...n" where n ::= {0,...,9 A,...,F X \$}
:SBUS<n>:SPI:TRIGger:PATtern:MISO:WIDTH <width> (see page 1209)	:SBUS<n>:SPI:TRIGger:PATtern:MISO:WIDTH? (see page 1209)	<width> ::= integer from 4 to 64 in NR1 format
:SBUS<n>:SPI:TRIGger:PATtern:MOSI:DATA <string> (see page 1210)	:SBUS<n>:SPI:TRIGger:PATtern:MOSI:DATA? (see page 1210)	<string> ::= "nn...n" where n ::= {0 1 X \$} <string ::= "0xnn...n" where n ::= {0,...,9 A,...,F X \$}
:SBUS<n>:SPI:TRIGger:PATtern:MOSI:WIDTH <width> (see page 1211)	:SBUS<n>:SPI:TRIGger:PATtern:MOSI:WIDTH? (see page 1211)	<width> ::= integer from 4 to 64 in NR1 format
:SBUS<n>:SPI:TRIGger:TYPE <value> (see page 1212)	:SBUS<n>:SPI:TRIGger:TYPE? (see page 1212)	<value> ::= {MOSI MISO}
:SBUS<n>:SPI:WIDTH <word_width> (see page 1213)	:SBUS<n>:SPI:WIDTH? (see page 1213)	<word_width> ::= integer 4-16 in NR1 format

:SBUS<n>:SPI:BITOrder

N (see [page 1730](#))

Command Syntax :SBUS<n>:SPI:BITOrder <order>

<order> ::= {LSBFirst | MSBFirst}

The :SBUS<n>:SPI:BITOrder command selects the bit order, most significant bit first (MSB) or least significant bit first (LSB), used when displaying data in the serial decode waveform and in the Lister.

Query Syntax :SBUS<n>:SPI:BITOrder?

The :SBUS<n>:SPI:BITOrder? query returns the current SPI decode bit order.

Return Format <order><NL>

<order> ::= {LSBF | MSBF}

Errors • ["-241, Hardware missing"](#) on page 1671

See Also • ["Introduction to :SBUS<n> Commands"](#) on page 977

• [":SBUS<n>:MODE"](#) on page 981

• [":SBUS<n>:SPI Commands"](#) on page 1197

:SBUS<n>:SPI:CLOCK:SLOPe

N (see [page 1730](#))

Command Syntax :SBUS<n>:SPI:CLOCK:SLOPe <slope>

<slope> ::= {NEGative | POSitive}

The :SBUS<n>:SPI:CLOCK:SLOPe command specifies the rising edge (POSitive) or falling edge (NEGative) of the SPI clock source that will clock in the data.

Query Syntax :SBUS<n>:SPI:CLOCK:SLOPe?

The :SBUS<n>:SPI:CLOCK:SLOPe? query returns the current SPI clock source slope.

Return Format <slope><NL>

<slope> ::= {NEG | POS}

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":SBUS<n>:SPI:CLOCK:TIMEout"](#) on page 1201
 - [":SBUS<n>:SPI:SOURce:CLOCK"](#) on page 1204

:SBUS<n>:SPI:CLOCK:TIMEout

N (see [page 1730](#))

Command Syntax :SBUS<n>:SPI:CLOCK:TIMEout <time_value>

<time_value> ::= time in seconds in NR3 format

The :SBUS<n>:SPI:CLOCK:TIMEout command sets the SPI signal clock timeout resource in seconds from 100 ns to 10 s when the :SBUS<n>:SPI:FRAMing command is set to TIMEout. The timer is used to frame a signal by a clock timeout.

Query Syntax :SBUS<n>:SPI:CLOCK:TIMEout?

The :SBUS<n>:SPI:CLOCK:TIMEout? query returns current SPI clock timeout setting.

Return Format <time value><NL>

<time_value> ::= time in seconds in NR3 format

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":SBUS<n>:SPI:CLOCK:SLOPe"](#) on page 1200
 - [":SBUS<n>:SPI:SOURce:CLOCK"](#) on page 1204
 - [":SBUS<n>:SPI:FRAMing"](#) on page 1203

:SBUS<n>:SPI:DElay

N (see [page 1730](#))

Command Syntax :SBUS<n>:SPI:DElay <value>

<value> ::= {OFF | 2-63}

The :SBUS<n>:SPI:DElay command specifies the number of bits to ignore (delay) before decoding the MISO stream.

Query Syntax :SBUS<n>:SPI:DElay?

The :SBUS<n>:SPI:DElay? query returns the specified number of delay bits or "OFF" if there are none.

Return Format <value><NL>

<value> ::= {OFF | 2-63}

See Also • [":SBUS<n>:SPI:SOURce:MISO"](#) on page 1206

:SBUS<n>:SPI:FRAMing

N (see [page 1730](#))

Command Syntax :SBUS<n>:SPI:FRAMing <value>
 <value> ::= {CHIPselect | {NCHipselect | NOTC} | TIMEout}

The :SBUS<n>:SPI:FRAMing command sets the SPI trigger framing value. If TIMEout is selected, the timeout value is set by the :SBUS<n>:SPI:CLOCK:TIMEout command.

NOTE

The NOTC value is deprecated. It is the same as NCHipselect.

Query Syntax :SBUS<n>:SPI:FRAMing?

The :SBUS<n>:SPI:FRAMing? query returns the current SPI framing value.

Return Format <value><NL>
 <value> ::= {CHIP | NCH | TIM}

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:MODE"](#) on page 1439
 - [":SBUS<n>:SPI:CLOCK:TIMEout"](#) on page 1201
 - [":SBUS<n>:SPI:SOURce:FRAME"](#) on page 1205

:SBUS<n>:SPI:SOURce:CLOCK

N (see [page 1730](#))

Command Syntax :SBUS<n>:SPI:SOURce:CLOCK <source>

<source> ::= {CHANnel<n> | EXTernal} for the DSO models

<source> ::= {CHANnel<n> | DIGital<d>} for the MSO models

<n> ::= 1 to (# analog channels) in NR1 format

<d> ::= 0 to (# digital channels - 1) in NR1 format

The :SBUS<n>:SPI:SOURce:CLOCK command sets the source for the SPI serial clock.

Query Syntax :SBUS<n>:SPI:SOURce:CLOCK?

The :SBUS<n>:SPI:SOURce:CLOCK? query returns the current source for the SPI serial clock.

Return Format <source><NL>

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":SBUS<n>:SPI:CLOCK:SLOPe"](#) on page 1200
 - [":SBUS<n>:SPI:CLOCK:TIMeout"](#) on page 1201
 - [":SBUS<n>:SPI:SOURce:FRAMe"](#) on page 1205
 - [":SBUS<n>:SPI:SOURce:MOSI"](#) on page 1207
 - [":SBUS<n>:SPI:SOURce:MISO"](#) on page 1206

:SBUS<n>:SPI:SOURce:FRAMe

N (see [page 1730](#))

Command Syntax :SBUS<n>:SPI:SOURce:FRAMe <source>

<source> ::= {CHANnel<n> | EXTernal} for the DSO models

<source> ::= {CHANnel<n> | DIGital<d>} for the MSO models

<n> ::= 1 to (# analog channels) in NR1 format

<d> ::= 0 to (# digital channels - 1) in NR1 format

The :SBUS<n>:SPI:SOURce:FRAMe command sets the frame source when :SBUS<n>:SPI:FRAMing is set to CHIPselect or NOTChipselect.

Query Syntax :SBUS<n>:SPI:SOURce:FRAMe?

The :SBUS<n>:SPI:SOURce:FRAMe? query returns the current frame source for the SPI serial frame.

Return Format <source><NL>

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":SBUS<n>:SPI:SOURce:CLOCK"](#) on page 1204
 - [":SBUS<n>:SPI:SOURce:MOSI"](#) on page 1207
 - [":SBUS<n>:SPI:SOURce:MISO"](#) on page 1206
 - [":SBUS<n>:SPI:FRAMing"](#) on page 1203

:SBUS<n>:SPI:SOURce:MISO

N (see [page 1730](#))

Command Syntax :SBUS<n>:SPI:SOURce:MISO <source>

<source> ::= {CHANnel<n> | EXTernal} for the DSO models

<source> ::= {CHANnel<n> | DIGital<d>} for the MSO models

<n> ::= 1 to (# analog channels) in NR1 format

<d> ::= 0 to (# digital channels - 1) in NR1 format

The :SBUS<n>:SPI:SOURce:MISO command sets the source for the SPI serial MISO data.

Query Syntax :SBUS<n>:SPI:SOURce:MISO?

The :SBUS<n>:SPI:SOURce:MISO? query returns the current source for the SPI serial MISO data.

Return Format <source><NL>

- See Also**
- [":SBUS<n>:SPI:DELaY"](#) on page 1202
 - ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":SBUS<n>:SPI:SOURce:MOSI"](#) on page 1207
 - [":SBUS<n>:SPI:SOURce:CLOCK"](#) on page 1204
 - [":SBUS<n>:SPI:SOURce:FRAMe"](#) on page 1205
 - [":SBUS<n>:SPI:TRIGger:PATtern:MISO:DATA"](#) on page 1208
 - [":SBUS<n>:SPI:TRIGger:PATtern:MOSI:DATA"](#) on page 1210
 - [":SBUS<n>:SPI:TRIGger:PATtern:MISO:WIDTh"](#) on page 1209
 - [":SBUS<n>:SPI:TRIGger:PATtern:MOSI:WIDTh"](#) on page 1211

:SBUS<n>:SPI:SOURce:MOSI

N (see [page 1730](#))

Command Syntax :SBUS<n>:SPI:SOURce:MOSI <source>

<source> ::= {CHANnel<n> | EXTernal} for the DSO models

<source> ::= {CHANnel<n> | DIGital<d>} for the MSO models

<n> ::= 1 to (# analog channels) in NR1 format

<d> ::= 0 to (# digital channels - 1) in NR1 format

The :SBUS<n>:SPI:SOURce:MOSI command sets the source for the SPI serial MOSI data.

Query Syntax :SBUS<n>:SPI:SOURce:MOSI?

The :SBUS<n>:SPI:SOURce:MOSI? query returns the current source for the SPI serial MOSI data.

Return Format <source><NL>

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":SBUS<n>:SPI:SOURce:MISO"](#) on page 1206
 - [":SBUS<n>:SPI:SOURce:CLOCK"](#) on page 1204
 - [":SBUS<n>:SPI:SOURce:FRAME"](#) on page 1205
 - [":SBUS<n>:SPI:TRIGger:PATtern:MISO:DATA"](#) on page 1208
 - [":SBUS<n>:SPI:TRIGger:PATtern:MOSI:DATA"](#) on page 1210
 - [":SBUS<n>:SPI:TRIGger:PATtern:MISO:WIDTH"](#) on page 1209
 - [":SBUS<n>:SPI:TRIGger:PATtern:MOSI:WIDTH"](#) on page 1211

:SBUS<n>:SPI:TRIGger:PATtern:MISO:DATA

N (see [page 1730](#))

Command Syntax :SBUS<n>:SPI:TRIGger:PATtern:MISO:DATA <string>

<string> ::= "nn...n" where n ::= {0 | 1 | X | \$}

<string ::= "0xnn...n" where n ::= {0,...,9 | A,...,F | X | \$}

The :SBUS<n>:SPI:TRIGger:PATtern:MISO:DATA command defines the SPI data pattern resource according to the string parameter. This pattern, along with the data width, control the data pattern searched for in the data stream.

If the string parameter starts with "0x", it is a hexadecimal string made up of hexadecimal and X (don't care) characters; otherwise, it is a binary string made up of 0, 1, and X (don't care) characters.

NOTE

The :SBUS<n>:SPI:TRIGger:PATtern:MISO:WIDTH should be set before :SBUS<n>:SPI:TRIGger:PATtern:MISO:DATA.

Query Syntax :SBUS<n>:SPI:TRIGger:PATtern:MISO:DATA?

The :SBUS<n>:SPI:TRIGger:PATtern:MISO:DATA? query returns the current settings of the specified SPI data pattern resource in the binary string format.

Return Format <string><NL>

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":SBUS<n>:SPI:TRIGger:PATtern:MISO:WIDTH"](#) on page 1209
 - [":SBUS<n>:SPI:SOURce:MISO"](#) on page 1206

:SBUS<n>:SPI:TRIGger:PATtern:MISO:WIDTh

N (see [page 1730](#))

Command Syntax :SBUS<n>:SPI:TRIGger:PATtern:MISO:WIDTh <width>

<width> ::= integer from 4 to 64 in NR1 format

The :SBUS<n>:SPI:TRIGger:PATtern:MISO:WIDTh command sets the width of the SPI data pattern anywhere from 4 bits to 64 bits.

NOTE

The :SBUS<n>:SPI:TRIGger:PATtern:MISO:WIDTh should be set before :SBUS<n>:SPI:TRIGger:PATtern:MISO:DATA.

Query Syntax :SBUS<n>:SPI:TRIGger:PATtern:MISO:WIDTh?

The :SBUS<n>:SPI:TRIGger:PATtern:MISO:WIDTh? query returns the current SPI data pattern width setting.

Return Format <width><NL>

<width> ::= integer from 4 to 64 in NR1 format

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":SBUS<n>:SPI:TRIGger:PATtern:MISO:DATA"](#) on page 1208
 - [":SBUS<n>:SPI:SOURce:MISO"](#) on page 1206

:SBUS<n>:SPI:TRIGger:PATtern:MOSI:DATA

N (see [page 1730](#))

Command Syntax :SBUS<n>:SPI:TRIGger:PATtern:MOSI:DATA <string>

<string> ::= "nn...n" where n ::= {0 | 1 | X | \$}

<string ::= "0xnn...n" where n ::= {0,...,9 | A,...,F | X | \$}

The :SBUS<n>:SPI:TRIGger:PATtern:MOSI:DATA command defines the SPI data pattern resource according to the string parameter. This pattern, along with the data width, control the data pattern searched for in the data stream.

If the string parameter starts with "0x", it is a hexadecimal string made up of hexadecimal and X (don't care) characters; otherwise, it is a binary string made up of 0, 1, and X (don't care) characters.

NOTE

The :SBUS<n>:SPI:TRIGger:PATtern:MOSI:WIDTH should be set before :SBUS<n>:SPI:TRIGger:PATtern:MOSI:DATA.

Query Syntax :SBUS<n>:SPI:TRIGger:PATtern:MOSI:DATA?

The :SBUS<n>:SPI:TRIGger:PATtern:MOSI:DATA? query returns the current settings of the specified SPI data pattern resource in the binary string format.

Return Format <string><NL>

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":SBUS<n>:SPI:TRIGger:PATtern:MOSI:WIDTH"](#) on page 1211
 - [":SBUS<n>:SPI:SOURce:MOSI"](#) on page 1207

:SBUS<n>:SPI:TRIGger:PATtern:MOSI:WIDTh

N (see [page 1730](#))

Command Syntax :SBUS<n>:SPI:TRIGger:PATtern:MOSI:WIDTh <width>

<width> ::= integer from 4 to 64 in NR1 format

The :SBUS<n>:SPI:TRIGger:PATtern:MOSI:WIDTh command sets the width of the SPI data pattern anywhere from 4 bits to 64 bits.

NOTE

The :SBUS<n>:SPI:TRIGger:PATtern:MOSI:WIDTh should be set before :SBUS<n>:SPI:TRIGger:PATtern:MOSI:DATA.

Query Syntax :SBUS<n>:SPI:TRIGger:PATtern:MOSI:WIDTh?

The :SBUS<n>:SPI:TRIGger:PATtern:MOSI:WIDTh? query returns the current SPI data pattern width setting.

Return Format <width><NL>

<width> ::= integer from 4 to 64 in NR1 format

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":SBUS<n>:SPI:TRIGger:PATtern:MOSI:DATA"](#) on page 1210
 - [":SBUS<n>:SPI:SOURce:MOSI"](#) on page 1207

:SBUS<n>:SPI:TRIGger:TYPE

N (see [page 1730](#))

Command Syntax :SBUS<n>:SPI:TRIGger:TYPE <value>

<value> ::= {MOSI | MISO}

The :SBUS<n>:SPI:TRIGger:TYPE command specifies whether the SPI trigger will be on the MOSI data or the MISO data.

When triggering on MOSI data, the data value is specified by the :SBUS<n>:SPI:TRIGger:PATtern:MOSI:DATA and :SBUS<n>:SPI:TRIGger:PATtern:MOSI:WIDTH commands.

When triggering on MISO data, the data value is specified by the :SBUS<n>:SPI:TRIGger:PATtern:MISO:DATA and :SBUS<n>:SPI:TRIGger:PATtern:MISO:WIDTH commands.

Query Syntax :SBUS<n>:SPI:TRIGger:TYPE?

The :SBUS<n>:SPI:TRIGger:TYPE? query returns the current SPI trigger type setting.

Return Format <value><NL>

<value> ::= {MOSI | MISO}

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":SBUS<n>:SPI:SOURce:MOSI"](#) on page 1207
 - [":SBUS<n>:SPI:SOURce:MISO"](#) on page 1206
 - [":SBUS<n>:SPI:TRIGger:PATtern:MISO:DATA"](#) on page 1208
 - [":SBUS<n>:SPI:TRIGger:PATtern:MOSI:DATA"](#) on page 1210
 - [":SBUS<n>:SPI:TRIGger:PATtern:MISO:WIDTH"](#) on page 1209
 - [":SBUS<n>:SPI:TRIGger:PATtern:MOSI:WIDTH"](#) on page 1211
 - [":TRIGger:MODE"](#) on page 1439

:SBUS<n>:SPI:WIDTH

N (see [page 1730](#))

Command Syntax :SBUS<n>:SPI:WIDTH <word_width>

<word_width> ::= integer 4-16 in NR1 format

The :SBUS<n>:SPI:WIDTH command determines the number of bits in a word of data for SPI.

Query Syntax :SBUS<n>:SPI:WIDTH?

The :SBUS<n>:SPI:WIDTH? query returns the current SPI decode word width.

Return Format <word_width><NL>

<word_width> ::= integer 4-16 in NR1 format

Errors • ["-241, Hardware missing"](#) on page 1671

See Also • ["Introduction to :SBUS<n> Commands"](#) on page 977

• [":SBUS<n>:MODE"](#) on page 981

• [":SBUS<n>:SPI Commands"](#) on page 1197

:SBUS<n>:UART Commands

NOTE

These commands are only valid when the UART/RS-232 triggering and serial decode option has been licensed.

Table 140 :SBUS<n>:UART Commands Summary

Command	Query	Options and Query Returns
:SBUS<n>:UART:BASE <base> (see page 1217)	:SBUS<n>:UART:BASE? (see page 1217)	<base> ::= {ASCIi BINary HEX}
:SBUS<n>:UART:BAUDrate <baudrate> (see page 1218)	:SBUS<n>:UART:BAUDrate? (see page 1218)	<baudrate> ::= integer from 100 to 8000000, 10000000, or 12000000
:SBUS<n>:UART:BITorder <bitorder> (see page 1219)	:SBUS<n>:UART:BITorder? (see page 1219)	<bitorder> ::= {LSBFirst MSBFirst}
n/a	:SBUS<n>:UART:COUNT:ERRor? (see page 1220)	<frame_count> ::= integer in NR1 format
:SBUS<n>:UART:COUNT:RESet (see page 1221)	n/a	n/a
n/a	:SBUS<n>:UART:COUNT:RXFrames? (see page 1222)	<frame_count> ::= integer in NR1 format
n/a	:SBUS<n>:UART:COUNT:TXFrames? (see page 1223)	<frame_count> ::= integer in NR1 format
:SBUS<n>:UART:FRAMing <value> (see page 1224)	:SBUS<n>:UART:FRAMing? (see page 1224)	<value> ::= {OFF <decimal> <nondecimal>} <decimal> ::= 8-bit integer from 0-255 (0x00-0xff) <nondecimal> ::= #Hnn where n ::= {0,...,9 A,...,F} for hexadecimal <nondecimal> ::= #Bnn...n where n ::= {0 1} for binary
:SBUS<n>:UART:PARity <parity> (see page 1225)	:SBUS<n>:UART:PARity? (see page 1225)	<parity> ::= {EVEN ODD NONE}
:SBUS<n>:UART:POLarity <polarity> (see page 1226)	:SBUS<n>:UART:POLarity? (see page 1226)	<polarity> ::= {HIGH LOW}

Table 140 :SBUS<n>:UART Commands Summary (continued)

Command	Query	Options and Query Returns
:SBUS<n>:UART:SOURce:RX <source> (see page 1227)	:SBUS<n>:UART:SOURce:RX? (see page 1227)	<source> ::= {CHANnel<n> EXTernal} for DSO models <source> ::= {CHANnel<n> DIGital<d>} for MSO models <n> ::= 1 to (# analog channels) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format
:SBUS<n>:UART:SOURce:TX <source> (see page 1228)	:SBUS<n>:UART:SOURce:TX? (see page 1228)	<source> ::= {CHANnel<n> EXTernal} for DSO models <source> ::= {CHANnel<n> DIGital<d>} for MSO models <n> ::= 1 to (# analog channels) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format
:SBUS<n>:UART:TRIGger:BASE <base> (see page 1229)	:SBUS<n>:UART:TRIGger:BASE? (see page 1229)	<base> ::= {ASCii HEX}
:SBUS<n>:UART:TRIGger:BURSt <value> (see page 1230)	:SBUS<n>:UART:TRIGger:BURSt? (see page 1230)	<value> ::= {OFF 1 to 4096 in NR1 format}
:SBUS<n>:UART:TRIGger:DATA <value> (see page 1231)	:SBUS<n>:UART:TRIGger:DATA? (see page 1231)	<value> ::= 8-bit integer from 0-255 (0x00-0xff) in decimal, <hexadecimal>, <binary>, or <quoted_string> format <hexadecimal> ::= #Hnn where n ::= {0,...,9 A,...,F} for hexadecimal <binary> ::= #Bnn...n where n ::= {0 1} for binary <quoted_string> ::= any of the 128 valid 7-bit ASCII characters (or standard abbreviations)
:SBUS<n>:UART:TRIGger:IDLE <time_value> (see page 1232)	:SBUS<n>:UART:TRIGger:IDLE? (see page 1232)	<time_value> ::= time from 1 us to 10 s in NR3 format
:SBUS<n>:UART:TRIGger:QUALifier <value> (see page 1233)	:SBUS<n>:UART:TRIGger:QUALifier? (see page 1233)	<value> ::= {EQUal NOTequal GREATERthan LESSthan}

Table 140 :SBUS<n>:UART Commands Summary (continued)

Command	Query	Options and Query Returns
:SBUS<n>:UART:TRIGger :TYPE <value> (see page 1234)	:SBUS<n>:UART:TRIGger :TYPE? (see page 1234)	<value> ::= {RStArt RStOp RDATA RD1 RD0 RDX PARityerror TStArt TStOp TDATA TD1 TD0 TDX}
:SBUS<n>:UART:WIDTh <width> (see page 1235)	:SBUS<n>:UART:WIDTh? (see page 1235)	<width> ::= {5 6 7 8 9}

:SBUS<n>:UART:BASE

N (see [page 1730](#))

Command Syntax :SBUS<n>:UART:BASE <base>

<base> ::= {ASCIi | BINary | HEX}

The :SBUS<n>:UART:BASE command determines the base to use for the UART decode and Lister display.

Query Syntax :SBUS<n>:UART:BASE?

The :SBUS<n>:UART:BASE? query returns the current UART decode and Lister base setting.

Return Format <base><NL>

<base> ::= {ASCIi | BINary | HEX}

Errors • ["-241, Hardware missing"](#) on page 1671

See Also • ["Introduction to :SBUS<n> Commands"](#) on page 977
 • [":SBUS<n>:UART Commands"](#) on page 1214

:SBUS<n>:UART:BAUDrate

N (see [page 1730](#))

Command Syntax :SBUS<n>:UART:BAUDrate <baudrate>

<baudrate> ::= integer from 100 to 8000000, 10000000, or 12000000

The :SBUS<n>:UART:BAUDrate command selects the bit rate (in bps) for the serial decoder and/or trigger when in UART mode. The baud rate can be set in the range from from 100 b/s to 8 Mb/s or to the specific values of 10 Mb/s or 12 Mb/s.

If the baud rate you select does not match the system baud rate, false triggers may occur.

Query Syntax :SBUS<n>:UART:BAUDrate?

The :SBUS<n>:UART:BAUDrate? query returns the current UART baud rate setting.

Return Format <baudrate><NL>

<baudrate> ::= integer from 100 to 8000000, 10000000, or 12000000

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:MODE"](#) on page 1439
 - [":SBUS<n>:UART:TRIGger:TYPE"](#) on page 1234

:SBUS<n>:UART:BITOrder

N (see [page 1730](#))

Command Syntax :SBUS<n>:UART:BITOrder <bitorder>

<bitorder> ::= {LSBFirst | MSBFirst}

The :SBUS<n>:UART:BITOrder command specifies the order of transmission used by the physical Tx and Rx input signals for the serial decoder and/or trigger when in UART mode. LSBFirst sets the least significant bit of each message "byte" as transmitted first. MSBFirst sets the most significant bit as transmitted first.

Query Syntax :SBUS<n>:UART:BITOrder?

The :SBUS<n>:UART:BITOrder? query returns the current UART bit order setting.

Return Format <bitorder><NL>

<bitorder> ::= {LSBF | MSBF}

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:MODE"](#) on page 1439
 - [":SBUS<n>:UART:TRIGger:TYPE"](#) on page 1234
 - [":SBUS<n>:UART:SOURce:RX"](#) on page 1227
 - [":SBUS<n>:UART:SOURce:TX"](#) on page 1228

:SBUS<n>:UART:COUNT:ERRor

N (see [page 1730](#))

Query Syntax :SBUS<n>:UART:COUNT:ERRor?

Returns the UART error frame count.

Return Format <frame_count><NL>

<frame_count> ::= integer in NR1 format

Errors • ["-241, Hardware missing"](#) on page 1671

- See Also**
- [":SBUS<n>:UART:COUNT:RESet"](#) on page 1221
 - ["Introduction to :SBUS<n> Commands"](#) on page 977
 - [":SBUS<n>:MODE"](#) on page 981
 - [":SBUS<n>:UART Commands"](#) on page 1214

:SBUS<n>:UART:COUNT:RESet

N (see [page 1730](#))

Command Syntax :SBUS<n>:UART:COUNT:RESet

Resets the UART frame counters.

Errors · ["-241, Hardware missing"](#) on page 1671

- See Also** · [":SBUS<n>:UART:COUNT:ERRor"](#) on page 1220
- [":SBUS<n>:UART:COUNT:RXFRames"](#) on page 1222
 - [":SBUS<n>:UART:COUNT:TXFRames"](#) on page 1223
 - ["Introduction to :SBUS<n> Commands"](#) on page 977
 - [":SBUS<n>:MODE"](#) on page 981
 - [":SBUS<n>:UART Commands"](#) on page 1214

:SBUS<n>:UART:COUNT:RXFRames

N (see [page 1730](#))

Query Syntax :SBUS<n>:UART:COUNT:RXFRames?

Returns the UART Rx frame count.

Return Format <frame_count><NL>

<frame_count> ::= integer in NR1 format

Errors • ["-241, Hardware missing"](#) on page 1671

- See Also**
- [":SBUS<n>:UART:COUNT:RESet"](#) on page 1221
 - ["Introduction to :SBUS<n> Commands"](#) on page 977
 - [":SBUS<n>:MODE"](#) on page 981
 - [":SBUS<n>:UART Commands"](#) on page 1214

:SBUS<n>:UART:COUNT:TXFRames

N (see [page 1730](#))

Query Syntax :SBUS<n>:UART:COUNT:TXFRames?

Returns the UART Tx frame count.

Return Format <frame_count><NL>

<frame_count> ::= integer in NR1 format

Errors • ["-241, Hardware missing"](#) on page 1671

- See Also**
- [":SBUS<n>:UART:COUNT:RESet"](#) on page 1221
 - ["Introduction to :SBUS<n> Commands"](#) on page 977
 - [":SBUS<n>:MODE"](#) on page 981
 - [":SBUS<n>:UART Commands"](#) on page 1214

:SBUS<n>:UART:FRAMing

N (see [page 1730](#))

Command Syntax :SBUS<n>:UART:FRAMing <value>

<value> ::= {OFF | <decimal> | <nondecimal>}

<decimal> ::= 8-bit integer in decimal from 0-255 (0x00-0xff)

<nondecimal> ::= #Hnn where n ::= {0,...,9 | A,...,F} for hexadecimal

<nondecimal> ::= #Bnn...n where n ::= {0 | 1} for binary

The :SBUS<n>:UART:FRAMing command determines the byte value to use for framing (end of packet) or to turn off framing for UART decode.

Query Syntax :SBUS<n>:UART:FRAMing?

The :SBUS<n>:UART:FRAMing? query returns the current UART decode base setting.

Return Format <value><NL>

<value> ::= {OFF | <decimal>}

<decimal> ::= 8-bit integer in decimal from 0-255

Errors • ["-241, Hardware missing"](#) on page 1671

See Also • ["Introduction to :SBUS<n> Commands"](#) on page 977

• [":SBUS<n>:UART Commands"](#) on page 1214

:SBUS<n>:UART:PARity

N (see [page 1730](#))

Command Syntax :SBUS<n>:UART:PARity <parity>

<parity> ::= {EVEN | ODD | NONE}

The :SBUS<n>:UART:PARity command selects the parity to be used with each message "byte" for the serial decoder and/or trigger when in UART mode.

Query Syntax :SBUS<n>:UART:PARity?

The :SBUS<n>:UART:PARity? query returns the current UART parity setting.

Return Format <parity><NL>

<parity> ::= {EVEN | ODD | NONE}

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:MODE"](#) on page 1439
 - [":SBUS<n>:UART:TRIGger:TYPE"](#) on page 1234

:SBUS<n>:UART:POLarity

N (see [page 1730](#))

Command Syntax :SBUS<n>:UART:POLarity <polarity>

<polarity> ::= {HIGH | LOW}

The :SBUS<n>:UART:POLarity command selects the polarity as idle low or idle high for the serial decoder and/or trigger when in UART mode.

Query Syntax :SBUS<n>:UART:POLarity?

The :SBUS<n>:UART:POLarity? query returns the current UART polarity setting.

Return Format <polarity><NL>

<polarity> ::= {HIGH | LOW}

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:MODE"](#) on page 1439
 - [":SBUS<n>:UART:TRIGger:TYPE"](#) on page 1234

:SBUS<n>:UART:SOURce:RX

N (see [page 1730](#))

Command Syntax :SBUS<n>:UART:SOURce:RX <source>

<source> ::= {CHANnel<n> | EXTernal} for the DSO models

<source> ::= {CHANnel<n> | DIGital<d>} for the MSO models

<n> ::= 1 to (# analog channels) in NR1 format

<d> ::= 0 to (# digital channels - 1) in NR1 format

The :SBUS<n>:UART:SOURce:RX command controls which signal is used as the Rx source by the serial decoder and/or trigger when in UART mode.

Query Syntax :SBUS<n>:UART:SOURce:RX?

The :SBUS<n>:UART:SOURce:RX? query returns the current source for the UART Rx signal.

Return Format <source><NL>

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:MODE"](#) on page 1439
 - [":SBUS<n>:UART:TRIGger:TYPE"](#) on page 1234
 - [":SBUS<n>:UART:BITorder"](#) on page 1219

:SBUS<n>:UART:SOURce:TX

N (see [page 1730](#))

Command Syntax :SBUS<n>:UART:SOURce:TX <source>

<source> ::= {CHANnel<n> | EXTernal} for the DSO models

<source> ::= {CHANnel<n> | DIGital<d>} for the MSO models

<n> ::= 1 to (# analog channels) in NR1 format

<d> ::= 0 to (# digital channels - 1) in NR1 format

The :SBUS<n>:UART:SOURce:TX command controls which signal is used as the Tx source by the serial decoder and/or trigger when in UART mode.

Query Syntax :SBUS<n>:UART:SOURce:TX?

The :SBUS<n>:UART:SOURce:TX? query returns the current source for the UART Tx signal.

Return Format <source><NL>

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:MODE"](#) on page 1439
 - [":SBUS<n>:UART:TRIGger:TYPE"](#) on page 1234
 - [":SBUS<n>:UART:BITorder"](#) on page 1219

:SBUS<n>:UART:TRIGger:BASE

N (see [page 1730](#))

Command Syntax :SBUS<n>:UART:TRIGger:BASE <base>

<base> ::= {ASCii | HEX}

The :SBUS<n>:UART:TRIGger:BASE command sets the front panel UART/RS232 trigger setup data selection option:

- ASCii – front panel data selection is from ASCII values.
- HEX – front panel data selection is from hexadecimal values.

The :SBUS<n>:UART:TRIGger:BASE setting does not affect the :SBUS<n>:UART:TRIGger:DATA command which can always set data values using ASCII or hexadecimal values.

NOTE

The :SBUS<n>:UART:TRIGger:BASE command is independent of the :SBUS<n>:UART:BASE command which affects decode and Lister only.

Query Syntax :SBUS<n>:UART:TRIGger:BASE?

The :SBUS<n>:UART:TRIGger:BASE? query returns the current UART base setting.

Return Format <base><NL>

<base> ::= {ASC | HEX}

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:MODE"](#) on page 1439
 - [":SBUS<n>:UART:TRIGger:DATA"](#) on page 1231

:SBUS<n>:UART:TRIGger:BURSt

N (see [page 1730](#))

Command Syntax :SBUS<n>:UART:TRIGger:BURSt <value>

<value> ::= {OFF | 1 to 4096 in NR1 format}

The :SBUS<n>:UART:TRIGger:BURSt command selects the burst value (Nth frame after idle period) in the range 1 to 4096 or OFF, for the trigger when in UART mode.

Query Syntax :SBUS<n>:UART:TRIGger:BURSt?

The :SBUS<n>:UART:TRIGger:BURSt? query returns the current UART trigger burst value.

Return Format <value><NL>

<value> ::= {OFF | 1 to 4096 in NR1 format}

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:MODE"](#) on page 1439
 - [":SBUS<n>:UART:TRIGger:IDLE"](#) on page 1232
 - [":SBUS<n>:UART:TRIGger:TYPE"](#) on page 1234

:SBUS<n>:UART:TRIGger:DATA

N (see [page 1730](#))

Command Syntax :SBUS<n>:UART:TRIGger:DATA <value>

<value> ::= 8-bit integer from 0-255 (0x00-0xff) in decimal,
<hexadecimal>, <binary>, or <quoted_string> format

<hexadecimal> ::= #Hnn where n ::= {0,...,9 | A,...,F} for hexadecimal

<binary> ::= #Bnn...n where n ::= {0 | 1} for binary

<quoted_string> ::= any of the 128 valid 7-bit ASCII characters
(or standard abbreviations)

The :SBUS<n>:UART:TRIGger:DATA command selects the data byte value (0x00 to 0xFF) for the trigger QUALifier when in UART mode. The data value is used when one of the RD or TD trigger types is selected.

When entering an ASCII character via the quoted string, it must be one of the 128 valid characters (case-sensitive): "NUL", "SOH", "STX", "ETX", "EOT", "ENQ", "ACK", "BEL", "BS", "HT", "LF", "VT", "FF", "CR", "SO", "SI", "DLE", "DC1", "DC2", "DC3", "DC4", "NAK", "SYN", "ETB", "CAN", "EM", "SUB", "ESC", "FS", "GS", "RS", "US", "SP", "!", "\", "#", "\$", "%", "&", "\'", "(,)", "*", "+", ",", "-", ".", "/", "0", "1", "2", "3", "4", "5", "6", "7", "8", "9", ":", ";", "<", "=", ">", "?", "@", "A", "B", "C", "D", "E", "F", "G", "H", "I", "J", "K", "L", "M", "N", "O", "P", "Q", "R", "S", "T", "U", "V", "W", "X", "Y", "Z", "[", "\\", "]", "^", "_", "`", "a", "b", "c", "d", "e", "f", "g", "h", "i", "j", "k", "l", "m", "n", "o", "p", "q", "r", "s", "t", "u", "v", "w", "x", "y", "z", "{", "|", "}", "~", or "DEL".

Query Syntax :SBUS<n>:UART:TRIGger:DATA?

The :SBUS<n>:UART:TRIGger:DATA? query returns the current UART trigger data value.

Return Format <value><NL>

<value> ::= 8-bit integer in decimal from 0-255

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:MODE"](#) on page 1439
 - [":SBUS<n>:UART:TRIGger:BASE"](#) on page 1229
 - [":SBUS<n>:UART:TRIGger:TYPE"](#) on page 1234

:SBUS<n>:UART:TRIGger:IDLE

N (see [page 1730](#))

Command Syntax :SBUS<n>:UART:TRIGger:IDLE <time_value>

<time_value> ::= time from 1 us to 10 s in NR3 format

The :SBUS<n>:UART:TRIGger:IDLE command selects the value of the idle period for burst trigger in the range from 1 us to 10 s when in UART mode.

Query Syntax :SBUS<n>:UART:TRIGger:IDLE?

The :SBUS<n>:UART:TRIGger:IDLE? query returns the current UART trigger idle period time.

Return Format <time_value><NL>

<time_value> ::= time from 1 us to 10 s in NR3 format

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:MODE"](#) on page 1439
 - [":SBUS<n>:UART:TRIGger:BURSt"](#) on page 1230
 - [":SBUS<n>:UART:TRIGger:TYPE"](#) on page 1234

:SBUS<n>:UART:TRIGger:QUALifier

N (see [page 1730](#))

Command Syntax :SBUS<n>:UART:TRIGger:QUALifier <value>

<value> ::= {EQUal | NOTequal | GREaterthan | LESSthan}

The :SBUS<n>:UART:TRIGger:QUALifier command selects the data qualifier when :TYPE is set to RDATA, RD1, RD0, RDX, TDATA, TD1, TD0, or TDX for the trigger when in UART mode.

Query Syntax :SBUS<n>:UART:TRIGger:QUALifier?

The :SBUS<n>:UART:TRIGger:QUALifier? query returns the current UART trigger qualifier.

Return Format <value><NL>

<value> ::= {EQU | NOT | GRE | LESS}

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:MODE"](#) on page 1439
 - [":SBUS<n>:UART:TRIGger:TYPE"](#) on page 1234

:SBUS<n>:UART:TRIGger:TYPE

N (see [page 1730](#))

Command Syntax :SBUS<n>:UART:TRIGger:TYPE <value>

<value> ::= {RSTArt | RSTOp | RDATA | RD1 | RD0 | RDX | PARityerror
| TSTArt | TSTOp | TDATa | TD1 | TD0 | TDX}

The :SBUS<n>:UART:TRIGger:TYPE command selects the UART trigger type.

When one of the RD or TD types is selected, the :SBUS<n>:UART:TRIGger:DATA and :SBUS<n>:UART:TRIGger:QUALifier commands are used to specify the data value and comparison operator.

The RD1, RD0, RDX, TD1, TD0, and TDX types (for triggering on data and alert bit values) are only valid when a 9-bit width has been selected.

Query Syntax :SBUS<n>:UART:TRIGger:TYPE?

The :SBUS<n>:UART:TRIGger:TYPE? query returns the current UART trigger data value.

Return Format <value><NL>

<value> ::= {RSTA | RSTO | RDATA | RD1 | RD0 | RDX | PAR | TSTA |
TSTO | TDAT | TD1 | TD0 | TDX}

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:MODE"](#) on page 1439
 - [":SBUS<n>:UART:TRIGger:DATA"](#) on page 1231
 - [":SBUS<n>:UART:TRIGger:QUALifier"](#) on page 1233
 - [":SBUS<n>:UART:WIDTH"](#) on page 1235

:SBUS<n>:UART:WIDTh

N (see [page 1730](#))

Command Syntax :SBUS<n>:UART:WIDTh <width>
 <width> ::= {5 | 6 | 7 | 8 | 9}

The :SBUS<n>:UART:WIDTh command determines the number of bits (5-9) for each message "byte" for the serial decoder and/or trigger when in UART mode.

Query Syntax :SBUS<n>:UART:WIDTh?

The :SBUS<n>:UART:WIDTh? query returns the current UART width setting.

Return Format <width><NL>
 <width> ::= {5 | 6 | 7 | 8 | 9}

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:MODE"](#) on page 1439
 - [":SBUS<n>:UART:TRIGger:TYPE"](#) on page 1234

:SBUS<n>:USB Commands

NOTE

These commands are only valid when a USB 2.0 triggering and serial decode option has been licensed.

Table 141 :SBUS<n>:USB Commands Summary

Command	Query	Options and Query Returns
:SBUS<n>:USB:BASE <base> (see page 1239)	:SBUS<n>:USB:BASE? (see page 1239)	<base> ::= {ASCIi BINary DECimal HEX}
:SBUS<n>:USB:SOURce:D MINus <source> (see page 1240)	:SBUS<n>:USB:SOURce:D MINus? (see page 1240)	<source> ::= {CHANnel<n>} for DSO models <source> ::= {CHANnel<n> DIGital<d>} for MSO models <n> ::= 1 to (# analog channels) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format
:SBUS<n>:USB:SOURce:D PLus <source> (see page 1241)	:SBUS<n>:USB:SOURce:D PLus? (see page 1241)	<source> ::= {CHANnel<n>} for DSO models <source> ::= {CHANnel<n> DIGital<d>} for MSO models <n> ::= 1 to (# analog channels) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format
:SBUS<n>:USB:SOURce:D IFFerential <source> (see page 1242)	:SBUS<n>:USB:SOURce:D IFFerential? (see page 1242)	<source> ::= {CHANnel<n>} <n> ::= 1 to (# analog channels) in NR1 format
:SBUS<n>:USB:SPEEd <speed> (see page 1243)	:SBUS<n>:USB:SPEEd? (see page 1243)	<speed> ::= {LOW FULL HIGH}
:SBUS<n>:USB:TRIGger <condition> (see page 1244)	:SBUS<n>:USB:TRIGger? (see page 1244)	<condition> ::= {SOP EOP ENTersuspend EXITSuspend RESet TOKen DATA HANDshake SPECial ALLerrors PIDerror CRC5error CRC16error GLITCherror STUFFerror SE1error}

Table 141 :SBUS<n>:USB Commands Summary (continued)

Command	Query	Options and Query Returns
:SBUS<n>:USB:TRIGger:ADDRESS <string> (see page 1245)	:SBUS<n>:USB:TRIGger:ADDRESS? (see page 1245)	<string> ::= "nnnnnnn" where n ::= {0 1 X} <string> ::= "0xnn" where n ::= {0,...,9 A,...,F X \$}
:SBUS<n>:USB:TRIGger:CRC <string> (see page 1246)	:SBUS<n>:USB:TRIGger:CRC? (see page 1246)	<string> ::= "nnnnn" where n ::= {0 1 X} <string> ::= "0xnn" where n ::= {0,...,9 A,...,F X \$}
:SBUS<n>:USB:TRIGger:DATA <string> (see page 1247)	:SBUS<n>:USB:TRIGger:DATA? (see page 1247)	<string> ::= "nnnn..." where n ::= {0 1 X} <string> ::= "0xn..." where n ::= {0,...,9 A,...,F X \$}
:SBUS<n>:USB:TRIGger:DATA:LENGth <value> (see page 1248)	:SBUS<n>:USB:TRIGger:DATA:LENGth? (see page 1248)	<length> ::= data length between 1-20
:SBUS<n>:USB:TRIGger:ENDPoint <string> (see page 1249)	:SBUS<n>:USB:TRIGger:ENDPoint? (see page 1249)	<string> ::= "nnnn" where n ::= {0 1 X} <string> ::= "0xn" where n ::= {0,...,9 A,...,F X \$}
:SBUS<n>:USB:TRIGger:ET <string> (see page 1250)	:SBUS<n>:USB:TRIGger:ET? (see page 1250)	<string> ::= "nn" where n ::= {0 1 X} <string> ::= "0xn" where n ::= {0 1 2 3 X \$}
:SBUS<n>:USB:TRIGger:FRaME <string> (see page 1251)	:SBUS<n>:USB:TRIGger:FRaME? (see page 1251)	<string> ::= "nnnnnnnnnnnn" where n ::= {0 1 X} <string> ::= "0xnnnn" where n ::= {0,...,9 A,...,F X \$}
:SBUS<n>:USB:TRIGger:HADDRESS <string> (see page 1252)	:SBUS<n>:USB:TRIGger:HADDRESS? (see page 1252)	<string> ::= "nnnnnnnn" where n ::= {0 1 X} <string> ::= "0xnnn" where n ::= {0,...,9 A,...,F X \$}
:SBUS<n>:USB:TRIGger:PCHeck <string> (see page 1253)	:SBUS<n>:USB:TRIGger:PCHeck? (see page 1253)	<string> ::= "nnnn" where n ::= {0 1 X} <string> ::= "0xn" where n ::= {0,...,9 A,...,F X \$}
:SBUS<n>:USB:TRIGger:PID:DATA <pid> (see page 1254)	:SBUS<n>:USB:TRIGger:PID:DATA? (see page 1254)	<pid> ::= {DATA0 DATA1 DATA2 MDATA}

Table 141 :SBUS<n>:USB Commands Summary (continued)

Command	Query	Options and Query Returns
:SBUS<n>:USB:TRIGger:PID:HANDshake <pid> (see page 1255)	:SBUS<n>:USB:TRIGger:PID:HANDshake? (see page 1255)	<pid> ::= {ACK NAK STALL NYET}
:SBUS<n>:USB:TRIGger:PID:SPECIAL <pid> (see page 1256)	:SBUS<n>:USB:TRIGger:PID:SPECIAL? (see page 1256)	<pid> ::= {PING PRE ERR SPLIT}
:SBUS<n>:USB:TRIGger:PID:TOKEN <pid> (see page 1257)	:SBUS<n>:USB:TRIGger:PID:TOKEN? (see page 1257)	<pid> ::= {OUT IN SETUP SOF}
:SBUS<n>:USB:TRIGger:PORT <string> (see page 1258)	:SBUS<n>:USB:TRIGger:PORT? (see page 1258)	<string> ::= "nnnnnnnn" where n ::= {0 1 X} <string> ::= "0xnn" where n ::= {0,...,9 A,...,F X \$}
:SBUS<n>:USB:TRIGger:SC <string> (see page 1259)	:SBUS<n>:USB:TRIGger:SC? (see page 1259)	<string> ::= "n" where n ::= {0 1 X} <string> ::= "0xn" where n ::= {0 1 X \$}
:SBUS<n>:USB:TRIGger:SEU <string> (see page 1260)	:SBUS<n>:USB:TRIGger:SEU? (see page 1260)	<string> ::= "nn" where n ::= {0 1 X} <string> ::= "0xn" where n ::= {0 1 2 3 X \$}

:SBUS<n>:USB:BASE

N (see [page 1730](#))

Command Syntax :SBUS<n>:USB:BASE <base>

<base> ::= {ASCii | BINary | DECimal | HEX}

The :SBUS<n>:USB:BASE command determines the base to use for the USB decode and Lister display, controlling how the data or payload field is displayed.

All other fields are displayed in hex

Query Syntax :SBUS<n>:USB:BASE?

The :SBUS<n>:USB:BASE? query returns the currently specified base.

Return Format <base><NL>

<base> ::= {ASC | BIN | DEC | HEX}

:SBUS<n>:USB:SOURce:DMINus

N (see [page 1730](#))

Command Syntax :SBUS<n>:USB:SOURce:DMINus <source>

<source> ::= {CHANnel<n>} for DSO models

<source> ::= {CHANnel<n> | DIGital<d>} for MSO models

<n> ::= 1 to (# analog channels) in NR1 format

<d> ::= 0 to (# digital channels - 1) in NR1 format

The :SBUS<n>:USB:SOURce:DMINus command specifies which signal is used as the USB D- source for the selected bus.

The D- source is only used for Low and Full Speed USB.

Query Syntax :SBUS<n>:USB:SOURce:DMINus?

The :SBUS<n>:USB:SOURce:DMINus? query returns the specified D- source.

Return Format <source><NL>

<source> ::= {CHAN<n> | DIG<d>}

- See Also**
- [":SBUS<n>:USB:SOURce:DPLus"](#) on page 1241
 - [":SBUS<n>:USB:SPEed"](#) on page 1243

:SBUS<n>:USB:SOURce:DPLus

N (see [page 1730](#))

Command Syntax :SBUS<n>:USB:SOURce:DPLus <source>

<source> ::= {CHANnel<n>} for DSO models

<source> ::= {CHANnel<n> | DIGital<d>} for MSO models

<n> ::= 1 to (# analog channels) in NR1 format

<d> ::= 0 to (# digital channels - 1) in NR1 format

The :SBUS<n>:USB:SOURce:DPLus command specifies which signal is used as the USB D+ source for the selected bus.

The D+ source is only used for Low and Full Speed USB.

Query Syntax :SBUS<n>:USB:SOURce:DPLus?

The :SBUS<n>:USB:SOURce:DPLus? query returns the specified D+ source.

Return Format <source><NL>

<source> ::= {CHAN<n> | DIG<d>}

- See Also**
- [":SBUS<n>:USB:SOURce:DMINus"](#) on page 1240
 - [":SBUS<n>:USB:SPEed"](#) on page 1243

:SBUS<n>:USB:SOURce:DIFFerential

N (see [page 1730](#))

Command Syntax :SBUS<n>:USB:SOURce:DIFFerential <source>

<source> ::= {CHANnel<n>}

<n> ::= 1 to (# analog channels) in NR1 format

The :SBUS<n>:USB:SOURce:DIFFerential command specifies which signal is used as the differential source for the selected bus.

Differential sources are only used for High Speed USB.

Query Syntax :SBUS<n>:USB:SOURce:DIFFerential?

The :SBUS<n>:USB:SOURce:DIFFerential? query returns the specified differential source.

Return Format <source><NL>

<source> ::= {CHAN<n>}

See Also • [":SBUS<n>:USB:SPEed"](#) on page 1243

:SBUS<n>:USB:SPEed

N (see [page 1730](#))

Command Syntax :SBUS<n>:USB:SPEed <speed>

<speed> ::= {LOW | FULL | HIGH}

The :SBUS<n>:USB:SPEed command specifies the speed of the USB interface for the selected bus.

Query Syntax :SBUS<n>:USB:SPEed?

The :SBUS<n>:USB:SPEed? query returns the speed setting.

Return Format <speed><NL>

<speed> ::= {LOW | FULL | HIGH}

- See Also**
- [":SBUS<n>:USB:SOURce:DPLus"](#) on page 1241
 - [":SBUS<n>:USB:SOURce:DMINus"](#) on page 1240
 - [":SBUS<n>:USB:SOURce:DIFFerential"](#) on page 1242

:SBUS<n>:USB:TRIGger

N (see [page 1730](#))

Command Syntax :SBUS<n>:USB:TRIGger <condition>

```
<condition> ::= {SOP | EOP | ENTersuspend | EXITsuspend | RESet
                | TOKen | DATA | HANDshake | SPECial | ALLerrors
                | PIDerror | CRC5error | CRC16error | GLITCherror
                | STUFFerror | SE1error}
```

The :SBUS<n>:USB:TRIGger command specifies the USB trigger mode for the selected bus.

Query Syntax :SBUS<n>:USB:TRIGger?

The :SBUS<n>:USB:TRIGger? query returns the specified USB trigger mode.

Return Format <condition><NL>

```
<condition> ::= {SOP | EOP | ENT | EXIT | RES | TOK | DATA | HAND
                | SPEC | ALL | PID | CRC5 | CRC16 | GLIT | STUFF
                | SE1}
```

- See Also**
- [":SBUS<n>:USB:TRIGger:PID:DATA"](#) on page 1254
 - [":SBUS<n>:USB:TRIGger:PID:HANDshake"](#) on page 1255
 - [":SBUS<n>:USB:TRIGger:PID:SPECial"](#) on page 1256
 - [":SBUS<n>:USB:TRIGger:PID:TOKen"](#) on page 1257

:SBUS<n>:USB:TRIGger:ADDRess

N (see [page 1730](#))

Command Syntax :SBUS<n>:USB:TRIGger:ADDRess <string>

<string> ::= "nnnnnnn" where n ::= {0 | 1 | X}

<string> ::= "0xnn" where n ::= {0,...,9 | A,...,F | X | \$}

The :SBUS<n>:USB:TRIGger:ADDRess command specifies the 7-bit Address portion of the trigger for the selected bus, in binary or hex.

Query Syntax :SBUS<n>:USB:TRIGger:ADDRess?

The :SBUS<n>:USB:TRIGger:ADDRess? query returns the specified Address portion of the trigger.

Return Format <string><NL>

<string> ::= "nnnnnnn" where n ::= {0 | 1 | X}

- See Also**
- [":SBUS<n>:USB:TRIGger:PID:SPECial"](#) on page 1256
 - [":SBUS<n>:USB:TRIGger:PID:TOKEN"](#) on page 1257

:SBUS<n>:USB:TRIGger:CRc

N (see [page 1730](#))

Command Syntax :SBUS<n>:USB:TRIGger:CRc <string>

<string> ::= "nnnnn" where n ::= {0 | 1 | X}

<string> ::= "0xnn" where n ::= {0,...,9 | A,...,F | X | \$}

The :SBUS<n>:USB:TRIGger:CRc command specifies the CRC portion of the trigger for the selected bus, in binary or hex.

Query Syntax :SBUS<n>:USB:TRIGger:CRc?

The :SBUS<n>:USB:TRIGger:CRc? query returns the specified CRC portion of the trigger.

Return Format <string><NL>

<string> ::= "nnnnn" where n ::= {0 | 1 | X}

- See Also**
- [":SBUS<n>:USB:TRIGger:PID:SPECial"](#) on page 1256
 - [":SBUS<n>:USB:TRIGger:PID:TOKen"](#) on page 1257

:SBUS<n>:USB:TRIGger:DATA

N (see [page 1730](#))

Command Syntax :SBUS<n>:USB:TRIGger:DATA <string>

<string> ::= "nnnn..." where n ::= {0 | 1 | X}

<string> ::= "0xn..." where n ::= {0,...,9 | A,...,F | X | \$}

The :SBUS<n>:USB:TRIGger:DATA command specifies the Data portion of the trigger for the selected bus, in binary or hex.

See the :SBUS<n>:USB:TRIGger:DATA:LENGth command for setting the length of the data value.

Query Syntax :SBUS<n>:USB:TRIGger:DATA?

The :SBUS<n>:USB:TRIGger:DATA? query returns the specified Data portion of the trigger.

Return Format <string><NL>

<string> ::= "nnnn..." where n ::= {0 | 1 | X}

See Also • [":SBUS<n>:USB:TRIGger:DATA:LENGth"](#) on page 1248

:SBUS<n>:USB:TRIGger:DATA:LENGth

N (see [page 1730](#))

Command Syntax :SBUS<n>:USB:TRIGger:DATA:LENGth <length>

<length> ::= data length between 1-20

The :SBUS<n>:USB:TRIGger:DATA:LENGth command specifies the data length in bytes.

Query Syntax :SBUS<n>:USB:TRIGger:DATA:LENGth?

The :SBUS<n>:USB:TRIGger:DATA:LENGth? query returns the specified data length.

Return Format <length><NL>

<length> ::= data length between 1-20

See Also • [":SBUS<n>:USB:TRIGger:DATA"](#) on page 1247

:SBUS<n>:USB:TRIGger:ENDPoint

N (see [page 1730](#))

Command Syntax :SBUS<n>:USB:TRIGger:ENDPoint <string>

<string> ::= "nnnn" where n ::= {0 | 1 | X}

<string> ::= "0xn" where n ::= {0,...,9 | A,...,F | X | \$}

The :SBUS<n>:USB:TRIGger:ENDPoint command specifies the 4-bit Endpoint portion of the trigger for the selected bus, in binary or hex.

Query Syntax :SBUS<n>:USB:TRIGger:ENDPoint?

The :SBUS<n>:USB:TRIGger:ENDPoint? query returns the specified Endpoint portion of the trigger.

Return Format <string><NL>

<string> ::= "nnnn" where n ::= {0 | 1 | X}

- See Also**
- [":SBUS<n>:USB:TRIGger:PID:SPECial"](#) on page 1256
 - [":SBUS<n>:USB:TRIGger:PID:TOKEN"](#) on page 1257

:SBUS<n>:USB:TRIGger:ET

N (see [page 1730](#))

Command Syntax :SBUS<n>:USB:TRIGger:ET <string>

<string> ::= "nn" where n ::= {0 | 1 | X}

<string> ::= "0xn" where n ::= {0 | 1 | 2 | 3 | X | \$}

The :SBUS<n>:USB:TRIGger:ET command specifies the 2-bit ET portion of the trigger for the selected bus, in binary or hex.

Query Syntax :SBUS<n>:USB:TRIGger:ET?

The :SBUS<n>:USB:TRIGger:ET? query returns the specified ET portion of the trigger.

Return Format <string><NL>

<string> ::= "nn" where n ::= {0 | 1 | X}

See Also • [":SBUS<n>:USB:TRIGger:PID:SPECial"](#) on page 1256

:SBUS<n>:USB:TRIGger:FRAME

N (see [page 1730](#))

Command Syntax :SBUS<n>:USB:TRIGger:FRAME <string>

<string> ::= "nnnnnnnnnnn" where n ::= {0 | 1 | X}

<string> ::= "0xnnn" where n ::= {0,...,9 | A,...,F | X | \$}

The :SBUS<n>:USB:TRIGger:FRAME command specifies the 11-bit Frame portion of the trigger for the selected bus, in binary or hex.

Query Syntax :SBUS<n>:USB:TRIGger:FRAME?

The :SBUS<n>:USB:TRIGger:FRAME? query returns the specified Frame portion of the trigger.

Return Format <string><NL>

<string> ::= "nnnnnnnnnnn" where n ::= {0 | 1 | X}

See Also • [":SBUS<n>:USB:TRIGger:PID:TOKEN"](#) on page 1257

:SBUS<n>:USB:TRIGger:HADDress

N (see [page 1730](#))

Command Syntax :SBUS<n>:USB:TRIGger:HADDress <string>

<string> ::= "nnnnnnn" where n ::= {0 | 1 | X}

<string> ::= "0xnn" where n ::= {0,...,9 | A,...,F | X | \$}

The :SBUS<n>:USB:TRIGger:HADDress command specifies the 7-bit Hub Address portion of the trigger for the selected bus, in binary or hex.

Query Syntax :SBUS<n>:USB:TRIGger:HADDress?

The :SBUS<n>:USB:TRIGger:HADDress? query returns the specified Hub Address portion of the trigger.

Return Format <string><NL>

<string> ::= "nnnnnnn" where n ::= {0 | 1 | X}

See Also • [":SBUS<n>:USB:TRIGger:PID:SPECial"](#) on page 1256

:SBUS<n>:USB:TRIGger:PCHeck

N (see [page 1730](#))

Command Syntax :SBUS<n>:USB:TRIGger:PCHeck <string>

<string> ::= "nnnn" where n ::= {0 | 1 | X}

<string> ::= "0xn" where n ::= {0,...,9 | A,...,F | X | \$}

The :SBUS<n>:USB:TRIGger:PCHeck command specifies the 4-bit PID check portion of the trigger for the selected bus, in binary or hex.

See the :SBUS<n>:USB:TRIGger:PID commands for setting the PID.

Query Syntax :SBUS<n>:USB:TRIGger:PCHeck?

The :SBUS<n>:USB:TRIGger:PCHeck? query returns the specified PID check portion of the trigger.

Return Format <string><NL>

<string> ::= "nnnn" where n ::= {0 | 1 | X}

- See Also**
- [":SBUS<n>:USB:TRIGger:PID:DATA"](#) on page 1254
 - [":SBUS<n>:USB:TRIGger:PID:HANDshake"](#) on page 1255
 - [":SBUS<n>:USB:TRIGger:PID:SPECial"](#) on page 1256
 - [":SBUS<n>:USB:TRIGger:PID:TOKen"](#) on page 1257

:SBUS<n>:USB:TRIGger:PID:DATA

N (see [page 1730](#))

Command Syntax :SBUS<n>:USB:TRIGger:PID:DATA <pid>

<pid> ::= {DATA0 | DATA1 | DATA2 | MDATA}

The :SBUS<n>:USB:TRIGger:PID:DATA command specifies the USB data PID to trigger on for the selected bus.

The specified PID does not include the PID check value, which is specified using the :SBUS<n>:USB:TRIGger:PIDCheck command.

The DATA USB trigger mode can be selected using the :SBUS<n>:USB:TRIGger command.

Query Syntax :SBUS<n>:USB:TRIGger:PID:DATA?

The :SBUS<n>:USB:TRIGger:PID:DATA? query returns the specified data PID.

Return Format <pid><NL>

<pid> ::= {DATA0 | DATA1 | DATA2 | MDATA}

- See Also**
- [":SBUS<n>:USB:TRIGger:PCheck"](#) on page 1253
 - [":SBUS<n>:USB:TRIGger"](#) on page 1244

:SBUS<n>:USB:TRIGger:PID:HANDshake

N (see [page 1730](#))

Command Syntax :SBUS<n>:USB:TRIGger:PID:HANDshake <pid>

<pid> ::= {ACK | NAK | STAL1 | NYET}

The :SBUS<n>:USB:TRIGger:PID:HANDshake command specifies the USB handshake PID to trigger on for the selected bus.

The specified PID does not include the PID check value, which is specified using the :SBUS<n>:USB:TRIGger:PIDCheck command.

The HANDshake USB trigger mode can be selected using the :SBUS<n>:USB:TRIGger command.

Query Syntax :SBUS<n>:USB:TRIGger:PID:HANDshake?

The :SBUS<n>:USB:TRIGger:PID:HANDshake? query returns the specified handshake PID.

Return Format <pid><NL>

<pid> ::= {ACK | NAK | STAL | NYET}

- See Also**
- [":SBUS<n>:USB:TRIGger:PCheck"](#) on page 1253
 - [":SBUS<n>:USB:TRIGger"](#) on page 1244

:SBUS<n>:USB:TRIGger:PID:SPECIAL

N (see [page 1730](#))

Command Syntax :SBUS<n>:USB:TRIGger:PID:SPECIAL <pid>

<pid> ::= {PING | PRE | ERR | SPLit}

The :SBUS<n>:USB:TRIGger:PID:SPECIAL command specifies the USB special PID to trigger on for the selected bus.

The specified PID does not include the PID check value, which is specified using the :SBUS<n>:USB:TRIGger:PIDCheck command.

The SPECIAL USB trigger mode can be selected using the :SBUS<n>:USB:TRIGger command.

Query Syntax :SBUS<n>:USB:TRIGger:PID:SPECIAL?

The :SBUS<n>:USB:TRIGger:PID:SPECIAL? query returns the specified special PID.

Return Format <pid><NL>

<pid> ::= {PING | PRE | ERR | SPL}

- See Also**
- [":SBUS<n>:USB:TRIGger:PCheck"](#) on page 1253
 - [":SBUS<n>:USB:TRIGger"](#) on page 1244

:SBUS<n>:USB:TRIGger:PID:TOKen

N (see [page 1730](#))

Command Syntax :SBUS<n>:USB:TRIGger:PID:TOKen <pid>

<pid> ::= {OUT | IN | SETup | SOF}

The :SBUS<n>:USB:TRIGger:PID:TOKen command specifies the USB token PID to trigger on for the selected bus.

The specified PID does not include the PID check value, which is specified using the :SBUS<n>:USB:TRIGger:PIDCheck command.

The TOKen USB trigger mode can be selected using the :SBUS<n>:USB:TRIGger command.

Query Syntax :SBUS<n>:USB:TRIGger:PID:TOKen?

The :SBUS<n>:USB:TRIGger:PID:TOKen? query returns the specified token PID.

Return Format <pid><NL>

<pid> ::= {OUT | IN | SETup | SOF}

- See Also**
- [":SBUS<n>:USB:TRIGger:PCheck"](#) on page 1253
 - [":SBUS<n>:USB:TRIGger"](#) on page 1244

:SBUS<n>:USB:TRIGger:PORT

N (see [page 1730](#))

Command Syntax :SBUS<n>:USB:TRIGger:PORT <string>

<string> ::= "nnnnnnn" where n ::= {0 | 1 | X}

<string> ::= "0xnn" where n ::= {0,...,9 | A,...,F | X | \$}

The :SBUS<n>:USB:TRIGger:PORT command specifies the 7-bit Port portion of the trigger for the selected bus, in binary or hex.

Query Syntax :SBUS<n>:USB:TRIGger:PORT?

The :SBUS<n>:USB:TRIGger:PORT? query returns the specified Port portion of the trigger.

Return Format <string><NL>

<string> ::= "nnnnnnn" where n ::= {0 | 1 | X}

See Also • [":SBUS<n>:USB:TRIGger:PID:SPECial"](#) on page 1256

:SBUS<n>:USB:TRIGger:SC

N (see [page 1730](#))

Command Syntax :SBUS<n>:USB:TRIGger:SC <string>

<string> ::= "n" where n ::= {0 | 1 | X}

<string> ::= "0xn" where n ::= {0 | 1 | X | \$}

The :SBUS<n>:USB:TRIGger:SC command specifies the 1-bit SC portion of the trigger for the selected bus, in binary or hex.

Query Syntax :SBUS<n>:USB:TRIGger:SC?

The :SBUS<n>:USB:TRIGger:SC? query returns the specified SC portion of the trigger.

Return Format <string><NL>

<string> ::= "nnnn" where n ::= {0 | 1 | X}

See Also • [":SBUS<n>:USB:TRIGger:PID:SPECial"](#) on page 1256

:SBUS<n>:USB:TRIGger:SEU

N (see [page 1730](#))

Command Syntax :SBUS<n>:USB:TRIGger:SEU <string>

<string> ::= "nn" where n ::= {0 | 1 | X}

<string> ::= "0xn" where n ::= {0 | 1 | 2 | 3 | X | \$}

The :SBUS<n>:USB:TRIGger:SEU command specifies the 2-bit S and E or U portion of the trigger for the selected bus, in binary or hex.

Query Syntax :SBUS<n>:USB:TRIGger:SEU?

The :SBUS<n>:USB:TRIGger:SEU? query returns the specified S and E or U portion of the trigger.

Return Format <string><NL>

<string> ::= "nn" where n ::= {0 | 1 | X}

See Also • [":SBUS<n>:USB:TRIGger:PID:SPECial"](#) on page 1256

:SBUS<n>:USBPd Commands

NOTE

These commands are valid when the USB PD (Power Delivery) serial decode and triggering option has been licensed.

Table 142 :SBUS<n>:USBPd Commands Summary

Command	Query	Options and Query Returns
:SBUS<n>:USBPd:SOURce <source> (see page 1262)	:SBUS<n>:USBPd:SOURce? (see page 1262)	<source> ::= {CHANnel<n>} <n> ::= 1 to (# analog channels) in NR1 format
:SBUS<n>:USBPd:TRIGger <mode> (see page 1263)	:SBUS<n>:USBPd:TRIGger? (see page 1263)	<mode> ::= {PStart EOP SOP SPRime SDPRime SPDebug SDPDebug HRST CRST CRCerror PERRor HEADer}
:SBUS<n>:USBPd:TRIGger:HEADer <type> (see page 1264)	:SBUS<n>:USBPd:TRIGger:HEADer? (see page 1264)	<type> ::= {CMESsage DMESsage EMESsage VALue}
:SBUS<n>:USBPd:TRIGger:HEADer:CMESsage <type> (see page 1266)	:SBUS<n>:USBPd:TRIGger:HEADer:CMESsage? (see page 1266)	<type> ::= {GOODcrc GOTOmin ACCEpt REJect PING PSRDy GSRCap GSNCap DRSWap PRSWap VCSWap WAIT SRST GSCX GSTatus FRSWap GPSTatus GCCodes}
:SBUS<n>:USBPd:TRIGger:HEADer:DMESsage <type> (see page 1268)	:SBUS<n>:USBPd:TRIGger:HEADer:DMESsage? (see page 1268)	<type> ::= {SRCap REQuEst BIST SNCap BSTatus ALERt GCINfo VDEFined}
:SBUS<n>:USBPd:TRIGger:HEADer:EMESsage <type> (see page 1269)	:SBUS<n>:USBPd:TRIGger:HEADer:EMESsage? (see page 1269)	<type> ::= {SCX STATus GBCap GBSTatus BCAP GMINfo MINfo SREQuEst SRESponse FREQuEst FRESponse PStatus CINfo CCODEs}
:SBUS<n>:USBPd:TRIGger:HEADer:VALue <string> (see page 1271)	:SBUS<n>:USBPd:TRIGger:HEADer:VALue? (see page 1271)	<string> ::= "nn...n" where n ::= {0 1 X} <string ::= "0xnn...n" where n ::= {0,...,9 A,...,F X}
:SBUS<n>:USBPd:TRIGger:HEADer:QUALifier <type> (see page 1272)	:SBUS<n>:USBPd:TRIGger:HEADer:QUALifier? (see page 1272)	<type> ::= {NONE SOP SPRime SDPRime}

:SBUS<n>:USBPd:SOURce

N (see [page 1730](#))

Command Syntax :SBUS<n>:USBPd:SOURce <source>

<source> ::= {CHANnel<n>}

<n> ::= 1 to (# analog channels) in NR1 format

The :SBUS<n>:USBPd:SOURce command selects the USB PD waveform source. You can use analog channels.

Query Syntax :SBUS<n>:USBPd:SOURce?

The :SBUS<n>:USBPd:SOURce? query returns the selected analog input channel.

Return Format <source><NL>

<source> ::= {CHAN<n>}

- See Also**
- [":SBUS<n>:USBPd:TRIGger"](#) on page 1263
 - [":SBUS<n>:USBPd:TRIGger:HEADer"](#) on page 1264
 - [":SBUS<n>:USBPd:TRIGger:HEADer:CMESsage"](#) on page 1266
 - [":SBUS<n>:USBPd:TRIGger:HEADer:DMESsage"](#) on page 1268
 - [":SBUS<n>:USBPd:TRIGger:HEADer:EMESsage"](#) on page 1269
 - [":SBUS<n>:USBPd:TRIGger:HEADer:VALue"](#) on page 1271
 - [":SBUS<n>:USBPd:TRIGger:HEADer:QUALifier"](#) on page 1272

:SBUS<n>:USBPd:TRIGger

N (see [page 1730](#))

Command Syntax :SBUS<n>:USBPd:TRIGger <mode>

```
<mode> ::= {PSTart | EOP | SOP | SPRime | SDPRime | SPDebug | SDPDebug
            | HRST | CRST | CRCerror | PERRor | HEADer}
```

The :SBUS<n>:USBPd:TRIGger command selects the USB PD trigger mode:

- PSTart – **Preamble Start**, triggers at the start of a preamble, which starts with 0.
- EOP – **EOP**, triggers at the end of packet.
- SOP – **SOP**, triggers on ordered set Sync-1, Sync-1, Sync-1, Sync-2.
- SPRime – **SOP'**, triggers on ordered set Sync-1, Sync-1, Sync-3, Sync-3.
- SDPRime – **SOP''**, triggers on ordered set Sync-1, Sync-3, Sync-1, Sync-3.
- SPDebug – **SOP' Debug**, triggers on ordered set Sync-1, RST-2, RST-2, Sync-3.
- SDPDebug – **SOP'' Debug**, triggers on ordered set Sync-1, RST-2, Sync-3, Sync-2.
- HRST – **Hard Reset**, triggers on ordered set RST-1, RST-1, RST-1, RST-2.
- CRST – **Cable Reset**, triggers on ordered set RST-1, Sync-1, RST-1, Sync-3.
- CRCerror – **CRC Error**, triggers when an error is detected on a 32-bit CRC.
- PERRor – **Preamble Error**, triggers when an error is detected on a 64-bit sequence of alternating 0 and 1.
- HEADer – **Header Content**, triggers on a user-defined 16-bit value.

In this mode, use the :SBUS<n>:USBPd:TRIGger:HEADer command to select the header type.

Query Syntax :SBUS<n>:USBPd:TRIGger?

The :SBUS<n>:USBPd:TRIGger? query returns the selected USB PD trigger mode.

Return Format <mode><NL>

```
<mode> ::= {PST | EOP | SOP | SPR | SDPR | SPD | SDPD | HRST | CRST
            | CRC | PERR | HEAD}
```

- See Also**
- [":SBUS<n>:USBPd:SOURce"](#) on page 1262
 - [":SBUS<n>:USBPd:TRIGger:HEADer"](#) on page 1264
 - [":SBUS<n>:USBPd:TRIGger:HEADer:CMESsage"](#) on page 1266
 - [":SBUS<n>:USBPd:TRIGger:HEADer:DMESsage"](#) on page 1268
 - [":SBUS<n>:USBPd:TRIGger:HEADer:EMESsage"](#) on page 1269
 - [":SBUS<n>:USBPd:TRIGger:HEADer:VALue"](#) on page 1271
 - [":SBUS<n>:USBPd:TRIGger:HEADer:QUALifier"](#) on page 1272

:SBUS<n>:USBPd:TRIGger:HEADer

N (see [page 1730](#))

Command Syntax :SBUS<n>:USBPd:TRIGger:HEADer <type>

<type> ::= {CMESsage | DMESsage | EMESsage | VALue}

When the **Header Content** trigger mode is selected (with the ":SBUS<n>:USBPd:TRIGger:HEADer" command), the :SBUS<n>:USBPd:TRIGger:HEADer command selects the header type:

- CMESsage – **Control Message**, triggers on control message types (0 data object).

When the CMESsage header type is selected, use the :SBUS<n>:USBPd:TRIGger:HEADer:CMESsage command to select the control message type.

- DMESsage – **Data Message**, triggers on data message types (1 or more data objects).

When the DMESsage header type is selected, use the :SBUS<n>:USBPd:TRIGger:HEADer:DMESsage command to select the data message type.

- EMESsage – **Extended Message**, triggers on extended message types (bit 15 is set).

When the EMESsage header type is selected, use the :SBUS<n>:USBPd:TRIGger:HEADer:EMESsage command to select the extended message type.

- VALue – **Value**, triggers on a user-defined header value.

When the CMESsage header type is selected, use the :SBUS<n>:USBPd:TRIGger:HEADer:VALue command to specify the user-defined header value.

Query Syntax :SBUS<n>:USBPd:TRIGger:HEADer?

The :SBUS<n>:USBPd:TRIGger:HEADer? query returns the selected header type.

Return Format <type><NL>

<type> ::= {CMES | DMES | EMES | VAL}

- See Also**
- [":SBUS<n>:USBPd:SOURce"](#) on page 1262
 - [":SBUS<n>:USBPd:TRIGger"](#) on page 1263
 - [":SBUS<n>:USBPd:TRIGger:HEADer:CMESsage"](#) on page 1266
 - [":SBUS<n>:USBPd:TRIGger:HEADer:DMESsage"](#) on page 1268
 - [":SBUS<n>:USBPd:TRIGger:HEADer:EMESsage"](#) on page 1269
 - [":SBUS<n>:USBPd:TRIGger:HEADer:VALue"](#) on page 1271

- [":SBUS<n>:USBPd:TRIGger:HEADer:QUALifier"](#) on page 1272

:SBUS<n>:USBPd:TRIGger:HEADer:CMESsage

N (see [page 1730](#))

Command Syntax :SBUS<n>:USBPd:TRIGger:HEADer:CMESsage <type>

```
<type> ::= {GOODcrc | GOTOmin | ACcept | REJect | PING | PSRDy
            | GSRCap | GSNCap | DRSWap | PRSWap | VCSWap | WAIT | SRST | GSCX
            | GSTatus | FRSWap | GPSTatus | GCCodes}
```

When the **Header Content** trigger mode is selected (with the ":SBUS<n>:USBPd:TRIGger HEADer" command) and the **Control Message** header type is selected (with the ":SBUS<n>:USBPd:TRIGger:HEADer CMESsage" command), the :SBUS<n>:USBPd:TRIGger:HEADer:CMESsage command selects the control message type:

- GOODcrc – GoodCRC
- GOTOmin – GotoMin
- ACcept – Accept
- REJect – Reject
- PING – Ping
- PSRDy – PS_RDY
- GSRCap – Get_Source_Cap
- GSNCap – Get_Sink_Cap
- DRSWap – DR_Swap
- PRSWap – PR_Swap
- VCSWap – VCONN_Swap
- WAIT – Wait
- SRST – Soft_Reset
- GSCX – Get_Source_Cap_Extended
- GSTatus – Get_Status
- FRSWap – FR_Swap
- GPSTatus – Get_PPS_Status
- GCCodes – Get_Country_Codes

Query Syntax :SBUS<n>:USBPd:TRIGger:HEADer:CMESsage?

The :SBUS<n>:USBPd:TRIGger:HEADer:CMESsage? query returns the selected control message type.

Return Format <type><NL>

```
<type> ::= {GOOD | GOTO | ACC | REJ | PING | PSRD | GSRC | GSNC | DRSW
            | PRSW | VCSW | WAIT | SRST | GSCX | GST | FRSW | GPST | GCC}
```

- See Also
- [":SBUS<n>:USBPd:SOURce"](#) on page 1262
 - [":SBUS<n>:USBPd:TRIGger"](#) on page 1263
 - [":SBUS<n>:USBPd:TRIGger:HEADer"](#) on page 1264
 - [":SBUS<n>:USBPd:TRIGger:HEADer:DMESsage"](#) on page 1268
 - [":SBUS<n>:USBPd:TRIGger:HEADer:EMESsage"](#) on page 1269
 - [":SBUS<n>:USBPd:TRIGger:HEADer:VALue"](#) on page 1271
 - [":SBUS<n>:USBPd:TRIGger:HEADer:QUALifier"](#) on page 1272

:SBUS<n>:USBPd:TRIGger:HEADer:DMESsage

N (see [page 1730](#))

Command Syntax :SBUS<n>:USBPd:TRIGger:HEADer:DMESsage <type>

<type> ::= {SRCap | REQuest | BIST | SNCap | BSTatus | ALERt | GCINfo
| VDEFined}

When the **Header Content** trigger mode is selected (with the ":SBUS<n>:USBPd:TRIGger HEADer" command) and the **Data Message** header type is selected (with the ":SBUS<n>:USBPd:TRIGger:HEADer DMESsage" command), the :SBUS<n>:USBPd:TRIGger:HEADer:DMESsage command selects the data message type:

- SRCap – Source_Capabilities
- REQuest – Request
- BIST – BIST
- SNCap – Sink_Capabilities
- BSTatus – Battery_Status
- ALERt – Alert
- GCINfo – Get_Country_Info
- VDEFined – Vendor_Defined

Query Syntax :SBUS<n>:USBPd:TRIGger:HEADer:DMESsage?

The :SBUS<n>:USBPd:TRIGger:HEADer:DMESsage? query returns the selected data message type.

Return Format <type><NL>

<type> ::= {SRC | REQ | BIST | SNC | BST | ALER | GCIN | VDEF}

- See Also**
- [":SBUS<n>:USBPd:SOURce"](#) on page 1262
 - [":SBUS<n>:USBPd:TRIGger"](#) on page 1263
 - [":SBUS<n>:USBPd:TRIGger:HEADer"](#) on page 1264
 - [":SBUS<n>:USBPd:TRIGger:HEADer:CMESsage"](#) on page 1266
 - [":SBUS<n>:USBPd:TRIGger:HEADer:EMESsage"](#) on page 1269
 - [":SBUS<n>:USBPd:TRIGger:HEADer:VALue"](#) on page 1271
 - [":SBUS<n>:USBPd:TRIGger:HEADer:QUALifier"](#) on page 1272

:SBUS<n>:USBPd:TRIGger:HEADer:EMESsage

N (see [page 1730](#))

Command Syntax :SBUS<n>:USBPd:TRIGger:HEADer:EMESsage <type>

```
<type> ::= {SCX | STATus | GBCap | GBStatus | BCAP | GMINfo | MINFo
           | SREQuest | SRESponse | FREQuest | FRESponse | PSTatus | CINfo
           | CCODes}
```

When the **Header Content** trigger mode is selected (with the ":SBUS<n>:USBPd:TRIGger:HEADer" command) and the **Extended Message** header type is selected (with the ":SBUS<n>:USBPd:TRIGger:HEADer:EMESsage" command), the :SBUS<n>:USBPd:TRIGger:HEADer:EMESsage command selects the extended message type:

- SCX – Source_Capabilities_Extended
- STATus – Status
- GBCap – Get_Battery_Cap
- GBStatus – Get_Battery_Status
- BCAP – Battery_Capabilities
- GMINfo – Get_Manufacturer_Info
- MINFo – Manufacturer_Info
- SREQuest – Security_Request
- SRESponse – Security_Response
- FREQuest – Firmware_Update_Request
- FRESponse – Firmware_Update_Response
- PSTatus – PPS_Status
- CINfo – Country_Info
- CCODes – Country_Codes

Query Syntax :SBUS<n>:USBPd:TRIGger:HEADer:EMESsage?

The :SBUS<n>:USBPd:TRIGger:HEADer:EMESsage? query returns the selected extended message type

Return Format <type><NL>

```
<type> ::= {SCX | STATus | GBC | GBST | BCAP | GMIN | MINF | SREQ
           | SRES | FREQ | FRES | PSTatus | CINF | CCOD}
```

- See Also**
- **":SBUS<n>:USBPd:SOURce"** on page 1262
 - **":SBUS<n>:USBPd:TRIGger"** on page 1263
 - **":SBUS<n>:USBPd:TRIGger:HEADer"** on page 1264
 - **":SBUS<n>:USBPd:TRIGger:HEADer:CMESsage"** on page 1266

- `":SBUS<n>:USBPd:TRIGger:HEADer:DMESsage"` on page 1268
- `":SBUS<n>:USBPd:TRIGger:HEADer:VALue"` on page 1271
- `":SBUS<n>:USBPd:TRIGger:HEADer:QUALifier"` on page 1272

:SBUS<n>:USBPd:TRIGger:HEADer:VALue

N (see [page 1730](#))

Command Syntax :SBUS<n>:USBPd:TRIGger:HEADer:VALue <string>
 <string> ::= "nn...n" where n ::= {0 | 1 | X}
 <string ::= "0xnn...n" where n ::= {0,...,9 | A,...,F | X}

When the **Header Content** trigger mode is selected (with the ":SBUS<n>:USBPd:TRIGger HEADer" command) and the user-defined **Value** type is selected (with the ":SBUS<n>:USBPd:TRIGger:HEADer VALue" command), the :SBUS<n>:USBPd:TRIGger:HEADer:VALue command specifies the user-defined header value.

Query Syntax :SBUS<n>:USBPd:TRIGger:HEADer:VALue?

The :SBUS<n>:USBPd:TRIGger:HEADer:VALue? query returns the specified user-defined header value.

Returned data values are always quoted binary format strings.

Return Format <string><NL>
 <string> ::= "nn...n" where n ::= {0 | 1 | X}

- See Also**
- [":SBUS<n>:USBPd:SOURce"](#) on page 1262
 - [":SBUS<n>:USBPd:TRIGger"](#) on page 1263
 - [":SBUS<n>:USBPd:TRIGger:HEADer"](#) on page 1264
 - [":SBUS<n>:USBPd:TRIGger:HEADer:CMESsage"](#) on page 1266
 - [":SBUS<n>:USBPd:TRIGger:HEADer:DMESsage"](#) on page 1268
 - [":SBUS<n>:USBPd:TRIGger:HEADer:EMESsage"](#) on page 1269
 - [":SBUS<n>:USBPd:TRIGger:HEADer:QUALifier"](#) on page 1272

:SBUS<n>:USBPd:TRIGger:HEADer:QUALifier

N (see [page 1730](#))

Command Syntax :SBUS<n>:USBPd:TRIGger:HEADer:QUALifier <type>

<type> ::= {NONE | SOP | SPRime | SDPRime}

When the **Header Content** trigger mode is selected (with the ":SBUS<n>:USBPd:TRIGger HEADer" command), the :SBUS<n>:USBPd:TRIGger:HEADer:QUALifier command selects an additional qualifier for the Header Content trigger:

- NONE – **None**. There is no additional qualifier for the trigger.
- SOP – **SOP**. The trigger occurs on Sync-1, Sync-1, Sync-1, Sync-2 ordered sets only.
- SPRime – **SOP'**. The trigger occurs on Sync-1, Sync-1, Sync-3, Sync-3 ordered sets only.
- SDPRime – **SOP"**. The trigger occurs on Sync-1, Sync-3, Sync-1, Sync-3 ordered sets only.

Query Syntax :SBUS<n>:USBPd:TRIGger:HEADer:QUALifier?

The :SBUS<n>:USBPd:TRIGger:HEADer:QUALifier? query returns the selected header content trigger qualifier.

Return Format <type><NL>

<type> ::= {NONE | SOP | SPRime | SDPRime}

- See Also**
- [":SBUS<n>:USBPd:SOURce"](#) on page 1262
 - [":SBUS<n>:USBPd:TRIGger"](#) on page 1263
 - [":SBUS<n>:USBPd:TRIGger:HEADer"](#) on page 1264
 - [":SBUS<n>:USBPd:TRIGger:HEADer:CMESsage"](#) on page 1266
 - [":SBUS<n>:USBPd:TRIGger:HEADer:DMESsage"](#) on page 1268
 - [":SBUS<n>:USBPd:TRIGger:HEADer:EMESsage"](#) on page 1269
 - [":SBUS<n>:USBPd:TRIGger:HEADer:VALue"](#) on page 1271

38 :SEARCh Commands

Control the event search modes and parameters for each search type. See:

- "**General :SEARCh Commands**" on page 1274
- "**:SEARCh:EDGE Commands**" on page 1279
- "**:SEARCh:GLITCh Commands**" on page 1282 (Pulse Width search)
- "**:SEARCh:PEAK Commands**" on page 1289
- "**:SEARCh:RUNT Commands**" on page 1294
- "**:SEARCh:TRANSition Commands**" on page 1299
- "**:SEARCh:SERial:A429 Commands**" on page 1304
- "**:SEARCh:SERial:CAN Commands**" on page 1310
- "**:SEARCh:SERial:FLEXray Commands**" on page 1320
- "**:SEARCh:SERial:I2S Commands**" on page 1326
- "**:SEARCh:SERial:IIC Commands**" on page 1332
- "**:SEARCh:SERial:LIN Commands**" on page 1339
- "**:SEARCh:SERial:M1553 Commands**" on page 1348
- "**:SEARCh:SERial:SENT Commands**" on page 1352
- "**:SEARCh:SERial:SPI Commands**" on page 1357
- "**:SEARCh:SERial:UART Commands**" on page 1361
- "**:SEARCh:SERial:USB Commands**" on page 1365

General :SEARCH Commands

Table 143 General :SEARCH Commands Summary

Command	Query	Options and Query Returns
n/a	:SEARCH:COUNT? (see page 1275)	<count> ::= an integer count value
:SEARCH:EVENT <event_number> (see page 1276)	:SEARCH:EVENT? (see page 1276)	<event_number> ::= the integer number of a found search event
:SEARCH:MODE <value> (see page 1277)	:SEARCH:MODE? (see page 1277)	<value> ::= {EDGE GLITCh RUNT TRANSition SERIAL{1 2} PEAK}
:SEARCH:STATE <value> (see page 1278)	:SEARCH:STATE? (see page 1278)	<value> ::= {{0 OFF} {1 ON}}

:SEARCh:COUNT

N (see [page 1730](#))

Query Syntax :SEARCh:COUNT?

The :SEARCh:COUNT? query returns the number of search events found.

NOTE

This query performs a digitize operation, so it's important that your trigger is set up so that data is captured and is available to perform the search on.

If this query times out because there is no data to search, you may need to send a device clear to the oscilloscope to cancel its wait for the data.

Return Format <count><NL>

<count> ::= an integer count value

- See Also**
- [Chapter 38](#), “:SEARCh Commands,” starting on page 1273
 - [":SEARCh:EVENT"](#) on page 1276
 - [":SEARCh:STATe"](#) on page 1278
 - [":SEARCh:MODE"](#) on page 1277

:SEARch:EVENT

N (see [page 1730](#))

Command Syntax :SEARch:EVENT <event_number>

<event_number> ::= the integer number of a found search event

The :SEARch:EVENT command navigates to a found search event.

If the :SEARch:STATE is ON, the horizontal position is changed so that the specified event is located at the time reference.

Query Syntax :SEARch:EVENT?

The :SEARch:EVENT? query returns the currently selected event number.

Return Format <event_number><NL>

<event_number> ::= the integer number of a found search event

- See Also**
- [Chapter 38](#), “:SEARch Commands,” starting on page 1273
 - [":SEARch:COUNt"](#) on page 1275
 - [":SEARch:STATe"](#) on page 1278
 - [":SEARch:MODE"](#) on page 1277

:SEARCh:MODE

N (see [page 1730](#))

Command Syntax :SEARCh:MODE <value>

<value> ::= {EDGE | GLITCh | RUNT | TRANsition | SERial{1 | 2} | PEAK}

The :SEARCh:MODE command selects the search mode.

The command is only valid when the :SEARCh:STAtE is ON.

Query Syntax :SEARCh:MODE?

The :SEARCh:MODE? query returns the currently selected mode or OFF if the :SEARCh:STAtE is OFF.

Return Format <value><NL>

<value> ::= {EDGE | GLIT | RUNT | TRAN | SER{1 | 2} | PEAK | OFF}

- See Also**
- [Chapter 38](#), “:SEARCh Commands,” starting on page 1273
 - [":SEARCh:STAtE"](#) on page 1278
 - [":SEARCh:COUNt"](#) on page 1275
 - [":SEARCh:EVENT"](#) on page 1276

:SEARCh:STATe

N (see [page 1730](#))

Command Syntax :SEARCh:STATe <value>

<value> ::= {{0 | OFF} | {1 | ON}}

The :SEARCh:STATe command enables or disables the search feature.

Query Syntax :SEARCh:STATe?

The :SEARCh:STATe? query returns returns the current setting.

Return Format <value><NL>

<value> ::= {0 | 1}

- See Also**
- [Chapter 38](#), “:SEARCh Commands,” starting on page 1273
 - [":SEARCh:MODE"](#) on page 1277
 - [":SEARCh:COUNt"](#) on page 1275
 - [":SEARCh:EVENT"](#) on page 1276

:SEARCh:EDGE Commands

Table 144 :SEARCh:EDGE Commands Summary

Command	Query	Options and Query Returns
:SEARCh:EDGE:SLOPe <slope> (see page 1280)	:SEARCh:EDGE:SLOPe? (see page 1280)	<slope> ::= {POSitive NEGative EITHer}
:SEARCh:EDGE:SOURce <source> (see page 1281)	:SEARCh:EDGE:SOURce? (see page 1281)	<source> ::= CHANnel<n> <n> ::= 1 to (# analog channels) in NR1 format

:SEARCh:EDGE:SLOPe

N (see [page 1730](#))

Command Syntax :SEARCh:EDGE:SLOPe <slope>

<slope> ::= {NEGative | POSitive | EITHer}

The :SEARCh:EDGE:SLOPe command specifies the slope of the edge for the search.

Query Syntax :SEARCh:EDGE:SLOPe?

The :SEARCh:EDGE:SLOPe? query returns the current slope setting.

Return Format <slope><NL>

<slope> ::= {NEG | POS | EITH}

See Also • [Chapter 38](#), “:SEARCh Commands,” starting on page 1273

:SEARCh:EDGE:SOURce

N (see [page 1730](#))

Command Syntax :SEARCh:EDGE:SOURce <source>

<source> ::= CHANnel<n>

<n> ::= 1 to (# analog channels) in NR1 format

The :SEARCh:EDGE:SOURce command selects the channel on which to search for edges.

Query Syntax :SEARCh:EDGE:SOURce?

The :SEARCh:EDGE:SOURce? query returns the current source.

Return Format <source><NL>

<source> ::= CHAN<n>

See Also • [Chapter 38](#), “:SEARCh Commands,” starting on page 1273

:SEARCH:GLITCh Commands

Table 145 :SEARCH:GLITCh Commands Summary

Command	Query	Options and Query Returns
:SEARCH:GLITCh:GREate rthan <greater_than_time>[s uffix] (see page 1283)	:SEARCH:GLITCh:GREate rthan? (see page 1283)	<greater_than_time> ::= floating-point number in NR3 format [suffix] ::= {s ms us ns ps}
:SEARCH:GLITCh:LESSt han <less_than_time>[suff ix] (see page 1284)	:SEARCH:GLITCh:LESSt han? (see page 1284)	<less_than_time> ::= floating-point number in NR3 format [suffix] ::= {s ms us ns ps}
:SEARCH:GLITCh:POLari ty <polarity> (see page 1285)	:SEARCH:GLITCh:POLari ty? (see page 1285)	<polarity> ::= {POSitive NEGative}
:SEARCH:GLITCh:QUALif ier <qualifier> (see page 1286)	:SEARCH:GLITCh:QUALif ier? (see page 1286)	<qualifier> ::= {GREaterthan LESSthan RANGE}
:SEARCH:GLITCh:RANGE <less_than_time>[suff ix], <greater_than_time>[s uffix] (see page 1287)	:SEARCH:GLITCh:RANGE? (see page 1287)	<less_than_time> ::= 15 ns to 10 seconds in NR3 format <greater_than_time> ::= 10 ns to 9.99 seconds in NR3 format [suffix] ::= {s ms us ns ps}
:SEARCH:GLITCh:SOURce <source> (see page 1288)	:SEARCH:GLITCh:SOURce ? (see page 1288)	<source> ::= CHANNEL<n> <n> ::= 1 to (# analog channels) in NR1 format

:SEARCh:GLITCh:GREaterthan

N (see [page 1730](#))

Command Syntax :SEARCh:GLITCh:GREaterthan <greater_than_time>[<suffix>]

<greater_than_time> ::= floating-point number in NR3 format

<suffix> ::= {s | ms | us | ns | ps}

The :SEARCh:GLITCh:GREaterthan command sets the minimum pulse width duration for the selected :SEARCh:GLITCh:SOURce.

Query Syntax :SEARCh:GLITCh:GREaterthan?

The :SEARCh:GLITCh:GREaterthan? query returns the minimum pulse width duration time for :SEARCh:GLITCh:SOURce.

Return Format <greater_than_time><NL>

<greater_than_time> ::= floating-point number in NR3 format.

- See Also**
- [Chapter 38](#), “:SEARCh Commands,” starting on page 1273
 - [":SEARCh:GLITCh:SOURce"](#) on page 1288
 - [":SEARCh:GLITCh:QUALifier"](#) on page 1286
 - [":SEARCh:MODE"](#) on page 1277

:SEARCH:GLITCh:LESSthan

N (see [page 1730](#))

Command Syntax :SEARCH:GLITCh:LESSthan <less_than_time>[<suffix>]
 <less_than_time> ::= floating-point number in NR3 format
 <suffix> ::= {s | ms | us | ns | ps}
 The :SEARCH:GLITCh:LESSthan command sets the maximum pulse width duration for the selected :SEARCH:GLITCh:SOURce.

Query Syntax :SEARCH:GLITCh:LESSthan?
 The :SEARCH:GLITCh:LESSthan? query returns the pulse width duration time for :SEARCH:GLITCh:SOURce.

Return Format <less_than_time><NL>
 <less_than_time> ::= floating-point number in NR3 format.

- See Also**
- [Chapter 38](#), “:SEARCH Commands,” starting on page 1273
 - [":SEARCH:GLITCh:SOURce"](#) on page 1288
 - [":SEARCH:GLITCh:QUALifier"](#) on page 1286
 - [":SEARCH:MODE"](#) on page 1277

:SEARCh:GLITCh:POLarity

N (see [page 1730](#))

Command Syntax :SEARCh:GLITCh:POLarity <polarity>
 <polarity> ::= {POSitive | NEGative}

The :SEARCh:GLITCh:POLarity command sets the polarity for the glitch (pulse width) search.

Query Syntax :SEARCh:GLITCh:POLarity?

The :SEARCh:GLITCh:POLarity? query returns the current polarity setting for the glitch (pulse width) search.

Return Format <polarity><NL>
 <polarity> ::= {POS | NEG}

- See Also**
- [Chapter 38](#), “:SEARCh Commands,” starting on page 1273
 - [":SEARCh:MODE"](#) on page 1277
 - [":SEARCh:GLITCh:SOURce"](#) on page 1288

:SEARCh:GLITCh:QUALifier

N (see [page 1730](#))

Command Syntax :SEARCh:GLITCh:QUALifier <operator>

<operator> ::= {GREATERthan | LESSthan | RANGE}

This command sets the mode of operation of the glitch (pulse width) search. The oscilloscope can search for a pulse width that is greater than a time value, less than a time value, or within a range of time values.

Query Syntax :SEARCh:GLITCh:QUALifier?

The :SEARCh:GLITCh:QUALifier? query returns the glitch (pulse width) qualifier.

Return Format <operator><NL>

<operator> ::= {GRE | LESS | RANG}

- See Also**
- [Chapter 38](#), “:SEARCh Commands,” starting on page 1273
 - [":SEARCh:GLITCh:SOURce"](#) on page 1288
 - [":SEARCh:MODE"](#) on page 1277

:SEARCH:GLITCH:SOURCE

N (see [page 1730](#))

Command Syntax :SEARCH:GLITCH:SOURCE <source>

<source> ::= CHANNEL<n>

<n> ::= 1 to (# analog channels) in NR1 format

The :SEARCH:GLITCH:SOURCE command selects the channel on which to search for glitches (pulse widths).

Query Syntax :SEARCH:GLITCH:SOURCE?

The :SEARCH:GLITCH:SOURCE? query returns the current pulse width source.

If all channels are off, the query returns "NONE."

Return Format <source><NL>

- See Also**
- [Chapter 38](#), “:SEARCH Commands,” starting on page 1273
 - [Chapter 38](#), “:SEARCH Commands,” starting on page 1273
 - [":SEARCH:MODE"](#) on page 1277
 - [":SEARCH:GLITCH:POLARITY"](#) on page 1285
 - [":SEARCH:GLITCH:QUALIFIER"](#) on page 1286
 - [":SEARCH:GLITCH:RANGE"](#) on page 1287

:SEARCh:PEAK Commands

Table 146 :SEARCh:PEAK Commands Summary

Command	Query	Options and Query Returns
:SEARCh:PEAK:EXCURsion <delta_level> (see page 1290)	:SEARCh:PEAK:EXCURsion? (see page 1290)	<delta_level> ::= required change in level to be recognized as a peak, in NR3 format.
:SEARCh:PEAK:NPEaks <number> (see page 1291)	:SEARCh:PEAK:NPEaks? (see page 1291)	<number> ::= max number of peaks to find, 1-11 in NR1 format.
:SEARCh:PEAK:SOURce <source> (see page 1292)	:SEARCh:PEAK:SOURce? (see page 1292)	<source> ::= {FUNCTION<m> MATH<m>} (must be an FFT waveform) <m> ::= 1 to 4 in NR1 format
:SEARCh:PEAK:THReshold <level> (see page 1293)	:SEARCh:PEAK:THReshold? (see page 1293)	<level> ::= necessary level to be considered a peak, in NR3 format.

:SEARch:PEAK:EXCursion

N (see [page 1730](#))

Command Syntax :SEARch:PEAK:EXCursion <delta_level>

<delta_level> ::= required change in level to be recognized as a peak, in NR3 format.

The :SEARch:PEAK:EXCursion command specifies the change in level that must occur (in other words, hysteresis) to be recognized as a peak.

The threshold level units are specified by the :FUNction<m>[:FFT]:VTYPe command.

Query Syntax :SEARch:PEAK:EXCursion?

The :SEARch:PEAK:EXCursion? query returns the specified excursion delta level value.

Return Format <delta_level><NL>

<delta_level> ::= in NR3 format.

- See Also**
- [":FUNction<m>\[:FFT\]:VTYPe"](#) on page 510
 - [":SEARch:PEAK:NPEaks"](#) on page 1291
 - [":SEARch:PEAK:SOURce"](#) on page 1292
 - [":SEARch:PEAK:THReshold"](#) on page 1293

:SEARCh:PEAK:NPEaks

N (see [page 1730](#))

Command Syntax :SEARCh:PEAK:NPEaks <number>

<number> ::= max number of peaks to find, 1-11 in NR1 format.

The :SEARCh:PEAK:NPEaks command specifies the maximum number of FFT peaks to find. This number can be from 1 to 11.

Query Syntax :SEARCh:PEAK:NPEaks?

The :SEARCh:PEAK:NPEaks? query returns the specified maximum number of FFT peaks to find.

Return Format <number><NL>

<number> ::= in NR1 format.

- See Also**
- [":SEARCh:PEAK:EXCURsion"](#) on page 1290
 - [":SEARCh:PEAK:SOURce"](#) on page 1292
 - [":SEARCh:PEAK:THReshold"](#) on page 1293

:SEARCh:PEAK:SOURce

N (see [page 1730](#))

Command Syntax :SEARCh:PEAK:SOURce <source>

<source> ::= {FUNcTION<m> | MATH<m>} (must be an FFT waveform)

<m> ::= 1 to 4 in NR1 format

The :SEARCh:PEAK:SOURce command selects the FFT math function waveform to search.

Query Syntax :SEARCh:PEAK:SOURce?

The :SEARCh:PEAK:SOURce? query returns the FFT math function waveform that is being searched.

Return Format <source><NL>

<source> ::= FUNC<m> (must be FFT)

<m> ::= 1 to 4 in NR1 format

- See Also**
- [":SEARCh:PEAK:EXCURsion"](#) on page 1290
 - [":SEARCh:PEAK:NPEaks"](#) on page 1291
 - [":SEARCh:PEAK:THReshold"](#) on page 1293

:SEARCh:PEAK:THReshold

N (see [page 1730](#))

Command Syntax :SEARCh:PEAK:THReshold <level>

<level> ::= necessary level to be considered a peak, in NR3 format.

The :SEARCh:PEAK:THReshold command specifies the threshold level necessary to be considered a peak.

The threshold level units are specified by the :FUNCTion<m>[:FFT]:VTYPe command.

Query Syntax :SEARCh:PEAK:THReshold?

The :SEARCh:PEAK:THReshold? query returns the specified threshold level for FFT peak search.

Return Format <level><NL>

<level> ::= in NR3 format.

- See Also**
- [":FUNCTion<m>\[:FFT\]:VTYPe"](#) on page 510
 - [":SEARCh:PEAK:EXCURsion"](#) on page 1290
 - [":SEARCh:PEAK:NPEaks"](#) on page 1291
 - [":SEARCh:PEAK:SOURce"](#) on page 1292

:SEARCH:RUNT Commands

Table 147 :SEARCH:RUNT Commands Summary

Command	Query	Options and Query Returns
:SEARCH:RUNT:POLarity <polarity> (see page 1295)	:SEARCH:RUNT:POLarity ? (see page 1295)	<polarity> ::= {POSitive NEGative EITHER}
:SEARCH:RUNT:QUALifier <qualifier> (see page 1296)	:SEARCH:RUNT:QUALifier? (see page 1296)	<qualifier> ::= {GREaterthan LESSthan NONE}
:SEARCH:RUNT:SOURce <source> (see page 1297)	:SEARCH:RUNT:SOURce? (see page 1297)	<source> ::= CHANNEL<n> <n> ::= 1 to (# analog channels) in NR1 format
:SEARCH:RUNT:TIME <time>[suffix] (see page 1298)	:SEARCH:RUNT:TIME? (see page 1298)	<time> ::= floating-point number in NR3 format [suffix] ::= {s ms us ns ps}

:SEARCh:RUNT:POLarity

N (see [page 1730](#))

Command Syntax :SEARCh:RUNT:POLarity <slope>

<polarity> ::= {POSitive | NEGative | EITHer}

The :SEARCh:RUNT:POLarity command sets the polarity for the runt search.

Query Syntax :SEARCh:RUNT:POLarity?

The :SEARCh:RUNT:POLarity? query returns the currently set runt polarity.

Return Format <slope><NL>

<polarity> ::= {POS | NEG | EITH}

- See Also**
- [Chapter 38](#), “:SEARCh Commands,” starting on page 1273
 - [":SEARCh:MODE"](#) on page 1277
 - [":SEARCh:RUNT:SOURce"](#) on page 1297

:SEARCh:RUNT:QUALifier

N (see [page 1730](#))

Command Syntax :SEARCh:RUNT:QUALifier <qualifier>

<qualifier> ::= {GREATERthan | LESSthan | NONE}

The :SEARCh:RUNT:QUALifier command specifies whether to search for a runt that is greater than a time value, less than a time value, or any time value.

Query Syntax :SEARCh:RUNT:QUALifier?

The :SEARCh:RUNT:QUALifier? query returns the current runt search qualifier.

Return Format <qualifier><NL>

<qualifier> ::= {GRE | LESS NONE}

- See Also**
- [Chapter 38](#), “:SEARCh Commands,” starting on page 1273
 - [":SEARCh:MODE"](#) on page 1277

:SEARCh:RUNT:SOURce

N (see [page 1730](#))

Command Syntax :SEARCh:RUNT:SOURce <source>

<source> ::= CHANnel<n>

<n> ::= 1 to (# analog channels) in NR1 format

The :SEARCh:RUNT:SOURce command selects the channel on which to search for the runt pulse.

Query Syntax :SEARCh:RUNT:SOURce?

The :SEARCh:RUNT:SOURce? query returns the current runt search source.

Return Format <source><NL>

<source> ::= CHAN<n>

- See Also**
- [Chapter 38](#), “:SEARCh Commands,” starting on page 1273
 - [":SEARCh:RUNT:POLarity"](#) on page 1295

:SEARCH:RUNT:TIME

N (see [page 1730](#))

Command Syntax :SEARCH:RUNT:TIME <time>[suffix]

<time> ::= floating-point number in NR3 format

[suffix] ::= {s | ms | us | ns | ps}

When searching for runt pulses whose widths are greater than or less than a time (see :SEARCH:RUNT:QUALifier), the :SEARCH:RUNT:TIME command specifies the time value.

Query Syntax :SEARCH:RUNT:TIME?

The :SEARCH:RUNT:TIME? query returns the currently specified runt time value.

Return Format <time><NL>

<time> ::= floating-point number in NR3 format

- See Also**
- [Chapter 38](#), “:SEARCH Commands,” starting on page 1273
 - [":SEARCH:RUNT:QUALifier"](#) on page 1296

:SEARCh:TRANSition Commands

Table 148 :SEARCh:TRANSition Commands Summary

Command	Query	Options and Query Returns
:SEARCh:TRANSition:QU ALifier <qualifier> (see page 1300)	:SEARCh:TRANSition:QU ALifier? (see page 1300)	<qualifier> ::= {GREATERthan LESSthan}
:SEARCh:TRANSition:SL OPe <slope> (see page 1301)	:SEARCh:TRANSition:SL OPe? (see page 1301)	<slope> ::= {NEGative POSitive}
:SEARCh:TRANSition:SO URce <source> (see page 1302)	:SEARCh:TRANSition:SO URce? (see page 1302)	<source> ::= CHANnel<n> <n> ::= 1 to (# analog channels) in NR1 format
:SEARCh:TRANSition:TI ME <time>[suffix] (see page 1303)	:SEARCh:TRANSition:TI ME? (see page 1303)	<time> ::= floating-point number in NR3 format [suffix] ::= {s ms us ns ps}

:SEARCh:TRANsition:QUALifier

N (see [page 1730](#))

Command Syntax :SEARCh:TRANsition:QUALifier <qualifier>
 <qualifier> ::= {GREATERthan | LESSthan}

The :SEARCh:TRANsition:QUALifier command specifies whether to search for edge transitions greater than or less than a time.

Query Syntax :SEARCh:TRANsition:QUALifier?

The :SEARCh:TRANsition:QUALifier? query returns the current transition search qualifier.

Return Format <qualifier><NL>
 <qualifier> ::= {GRE | LESS}

- See Also**
- [Chapter 38](#), “:SEARCh Commands,” starting on page 1273
 - [":SEARCh:MODE"](#) on page 1277
 - [":SEARCh:TRANsition:TIME"](#) on page 1303

:SEARCh:TRANSition:SLOPe

N (see [page 1730](#))

Command Syntax :SEARCh:TRANSition:SLOPe <slope>

<slope> ::= {NEGative | POSitive}

The :SEARCh:TRANSition:SLOPe command selects whether to search for rising edge (POSitive slope) transitions or falling edge (NEGative slope) transitions.

Query Syntax :SEARCh:TRANSition:SLOPe?

The :SEARCh:TRANSition:SLOPe? query returns the current transition search slope setting.

Return Format <slope><NL>

<slope> ::= {NEG | POS}

- See Also**
- [Chapter 38](#), “:SEARCh Commands,” starting on page 1273
 - [":SEARCh:MODE"](#) on page 1277
 - [":SEARCh:TRANSition:SOURce"](#) on page 1302
 - [":SEARCh:TRANSition:TIME"](#) on page 1303

:SEARCh:TRANSition:SOURce

N (see [page 1730](#))

Command Syntax :SEARCh:TRANSition:SOURce <source>

<source> ::= CHANnel<n>

<n> ::= 1 to (# analog channels) in NR1 format

The :SEARCh:TRANSition:SOURce command selects the channel on which to search for edge transitions.

Query Syntax :SEARCh:TRANSition:SOURce?

The :SEARCh:TRANSition:SOURce? query returns the current transition search source.

Return Format <source><NL>

<source> ::= CHAN<n>

- See Also**
- [Chapter 38](#), “:SEARCh Commands,” starting on page 1273
 - [":SEARCh:MODE"](#) on page 1277
 - [":SEARCh:TRANSition:SLOPe"](#) on page 1301

:SEARCh:TRANSition:TIME

N (see [page 1730](#))

Command Syntax :SEARCh:TRANSition:TIME <time>[suffix]

<time> ::= floating-point number in NR3 format

[suffix] ::= {s | ms | us | ns | ps}

The :SEARCh:TRANSition:TIME command sets the time of the transition to search for. You can search for transitions greater than or less than this time.

Query Syntax :SEARCh:TRANSition:TIME?

The :SEARCh:TRANSition:TIME? query returns the current transition time value.

Return Format <time><NL>

<time> ::= floating-point number in NR3 format

- See Also**
- [Chapter 38](#), “:SEARCh Commands,” starting on page 1273
 - [":SEARCh:TRANSition:QUALifier"](#) on page 1300

:SEARCH:SERIAL:A429 Commands

Table 149 :SEARCH:SERIAL:A429 Commands Summary

Command	Query	Options and Query Returns
:SEARCH:SERIAL:A429:LABel <value> (see page 1305)	:SEARCH:SERIAL:A429:LABel? (see page 1305)	<value> ::= 8-bit integer in decimal, <hex>, <octal>, or <string> from 0-255 <hex> ::= #Hnn where n ::= {0,...,9 A,...,F} <octal> ::= #Qnnn where n ::= {0,...,7} <string> ::= "0xnn" where n ::= {0,...,9 A,...,F}
:SEARCH:SERIAL:A429:MODE <condition> (see page 1306)	:SEARCH:SERIAL:A429:MODE? (see page 1306)	<condition> ::= {LABel LBITs PERRor WERRor GERRor WGERrors ALLerrors}
:SEARCH:SERIAL:A429:PATTern:DATA <string> (see page 1307)	:SEARCH:SERIAL:A429:PATTern:DATA? (see page 1307)	<string> ::= "nn...n" where n ::= {0 1}, length depends on FORMat
:SEARCH:SERIAL:A429:PATTern:SDI <string> (see page 1308)	:SEARCH:SERIAL:A429:PATTern:SDI? (see page 1308)	<string> ::= "nn" where n ::= {0 1}, length always 2 bits
:SEARCH:SERIAL:A429:PATTern:SSM <string> (see page 1309)	:SEARCH:SERIAL:A429:PATTern:SSM? (see page 1309)	<string> ::= "nn" where n ::= {0 1}, length always 2 bits

:SEARCh:SERial:A429:LABel

N (see [page 1730](#))

Command Syntax :SEARCh:SERial:A429:LABel <value>

<value> ::= 8-bit integer in decimal, <hex>, <octal>, or <string>
from 0-255

<hex> ::= #Hnn where n ::= {0,...,9 | A,...,F}

<octal> ::= #Qnnn where n ::= {0,...,7}

<string> ::= "0xnn" where n ::= {0,...,9 | A,...,F}

The :SEARCh:SERial:A429:LABel command defines the ARINC 429 label value when labels are used in the selected search mode.

Query Syntax :SEARCh:SERial:A429:LABel?

The :SEARCh:SERial:A429:LABel? query returns the current label value in decimal format.

Return Format <value><NL> in decimal format

Errors · ["-241, Hardware missing"](#) on page 1671

See Also · ["Introduction to :TRIGger Commands"](#) on page 1425

· [":SEARCh:SERial:A429:MODE"](#) on page 1306

:SEARCH:SERIAL:A429:MODE

N (see [page 1730](#))

Command Syntax :SEARCH:SERIAL:A429:MODE <condition>

<condition> ::= { LABEL | LBITs | PERRor | WERRor | GERRor | WGERrors
| ALLerrors }

The :SEARCH:SERIAL:A429:MODE command selects the type of ARINC 429 information to find in the Lister display:

- LABEL – finds the specified label value.
- LBITs – finds the label and the other word fields as specified.
- PERRor – finds words with a parity error.
- WERRor – finds an intra-word coding error.
- GERRor – finds an inter-word gap error.
- WGERrors – finds either a Word or Gap Error.
- ALLerrors – finds any of the above errors.

Query Syntax :SEARCH:SERIAL:A429:MODE?

The :SEARCH:SERIAL:A429:MODE? query returns the current ARINC 429 search mode condition.

Return Format <condition><NL>

<condition> ::= { LAB | LBIT | PERR | WERR | GERR | WGER | ALL }

Errors • ["-241, Hardware missing"](#) on page 1671

- See Also**
- ["Introduction to :SBUS<n> Commands"](#) on page 977
 - [":SBUS<n>:MODE"](#) on page 981
 - [":SEARCH:SERIAL:A429:LABEL"](#) on page 1305
 - [":SEARCH:SERIAL:A429:PATTERN:DATA"](#) on page 1307
 - [":SEARCH:SERIAL:A429:PATTERN:SDI"](#) on page 1308
 - [":SEARCH:SERIAL:A429:PATTERN:SSM"](#) on page 1309
 - [":SBUS<n>:A429:SOURce"](#) on page 992

:SEARCh:SERial:A429:PATtern:DATA

N (see [page 1730](#))

Command Syntax :SEARCh:SERial:A429:PATtern:DATA <string>
 <string> ::= "nn...n" where n ::= {0 | 1}, length depends on FORMat

The :SEARCh:SERial:A429:PATtern:DATA command defines the ARINC 429 data pattern resource according to the string parameter. This pattern controls the data pattern searched for in each ARINC 429 word.

NOTE

If more bits are sent for <string> than specified by the :SBUS<n>:A429:FORMat command, the most significant bits will be truncated.

Query Syntax :SEARCh:SERial:A429:PATtern:DATA?

The :SEARCh:SERial:A429:PATtern:DATA? query returns the current settings of the specified ARINC 429 data pattern resource in the binary string format.

Return Format <string><NL>

Errors · ["-241, Hardware missing"](#) on page 1671

See Also · ["Introduction to :TRIGger Commands"](#) on page 1425
 · [":SEARCh:SERial:A429:MODE"](#) on page 1306
 · [":SEARCh:SERial:A429:PATtern:SDI"](#) on page 1308
 · [":SEARCh:SERial:A429:PATtern:SSM"](#) on page 1309

:SEARCh:SERial:A429:PATtern:SDI

N (see [page 1730](#))

Command Syntax :SEARCh:SERial:A429:PATtern:SDI <string>

<string> ::= "nn" where n ::= {0 | 1}, length always 2 bits

The :SEARCh:SERial:A429:PATtern:SDI command defines the ARINC 429 two-bit SDI pattern resource according to the string parameter. This pattern controls the SDI pattern searched for in each ARINC 429 word.

The specified SDI is only used if the :SBUS<n>:A429:FORMat includes the SDI field.

Query Syntax :SEARCh:SERial:A429:PATtern:SDI?

The :SEARCh:SERial:A429:PATtern:SDI? query returns the current settings of the specified ARINC 429 two-bit SDI pattern resource in the binary string format.

Return Format <string><NL>

Errors · ["-241, Hardware missing"](#) on page 1671

- See Also** · ["Introduction to :TRIGger Commands"](#) on page 1425
- [":SBUS<n>:A429:FORMat"](#) on page 990
 - [":SEARCh:SERial:A429:MODE"](#) on page 1306
 - [":SEARCh:SERial:A429:PATtern:DATA"](#) on page 1307
 - [":SEARCh:SERial:A429:PATtern:SSM"](#) on page 1309

:SEARCh:SERial:A429:PATtern:SSM

N (see [page 1730](#))

Command Syntax :SEARCh:SERial:A429:PATtern:SSM <string>

<string> ::= "nn" where n ::= {0 | 1}, length always 2 bits

The :SEARCh:SERial:A429:PATtern:SSM command defines the ARINC 429 two-bit SSM pattern resource according to the string parameter. This pattern controls the SSM pattern searched for in each ARINC 429 word.

The specified SSM is only used if the :SBUS<n>:A429:FORMat includes the SSM field.

Query Syntax :SEARCh:SERial:A429:PATtern:SSM?

The :SEARCh:SERial:A429:PATtern:SSM? query returns the current settings of the specified ARINC 429 two-bit SSM pattern resource in the binary string format.

Return Format <string><NL>

Errors · ["-241, Hardware missing"](#) on page 1671

- See Also** · ["Introduction to :TRIGger Commands"](#) on page 1425
- [":SBUS<n>:A429:FORMat"](#) on page 990
 - [":SEARCh:SERial:A429:MODE"](#) on page 1306
 - [":SEARCh:SERial:A429:PATtern:DATA"](#) on page 1307
 - [":SEARCh:SERial:A429:PATtern:SDI"](#) on page 1308

:SEARCH:SERIAL:CAN Commands

Table 150 :SEARCH:SERIAL:CAN Commands Summary

Command	Query	Options and Query Returns
:SEARCH:SERIAL:CAN:MODE <value> (see page 1311)	:SEARCH:SERIAL:CAN:MODE? (see page 1311)	<value> ::= {IDEither IDData DATA IDRemote ERROR ACKerror FORMerror STUFFerror CRCerror ALLerrors OVERload MESSAGE MSIGNAL}
:SEARCH:SERIAL:CAN:PARTtern:DATA <string> (see page 1313)	:SEARCH:SERIAL:CAN:PARTtern:DATA? (see page 1313)	<string> ::= "0xn...n" where n ::= {0,...,9 A,...,F X} for hexadecimal
:SEARCH:SERIAL:CAN:PARTtern:DATA:LENGTH <length> (see page 1314)	:SEARCH:SERIAL:CAN:PARTtern:DATA:LENGTH? (see page 1314)	<length> ::= integer from 1 to 8 in NR1 format
:SEARCH:SERIAL:CAN:PARTtern:ID <string> (see page 1315)	:SEARCH:SERIAL:CAN:PARTtern:ID? (see page 1315)	<string> ::= "0xn...n" where n ::= {0,...,9 A,...,F X} for hexadecimal
:SEARCH:SERIAL:CAN:PARTtern:ID:MODE <value> (see page 1316)	:SEARCH:SERIAL:CAN:PARTtern:ID:MODE? (see page 1316)	<value> ::= {STANDARD EXTENDED}
:SEARCH:SERIAL:CAN:SYMBOLic:MESSAGE <name> (see page 1317)	:SEARCH:SERIAL:CAN:SYMBOLic:MESSAGE? (see page 1317)	<name> ::= quoted ASCII string
:SEARCH:SERIAL:CAN:SYMBOLic:SIGNAL <name> (see page 1318)	:SEARCH:SERIAL:CAN:SYMBOLic:SIGNAL? (see page 1318)	<name> ::= quoted ASCII string
:SEARCH:SERIAL:CAN:SYMBOLic:VALUE <data> (see page 1319)	:SEARCH:SERIAL:CAN:SYMBOLic:VALUE? (see page 1319)	<data> ::= value in NR3 format

:SEARCh:SERial:CAN:MODE

N (see [page 1730](#))

Command Syntax :SEARCh:SERial:CAN:MODE <value>

```
<value> ::= {IDEither | IDData | DATA | IDRemote | ERRor | ACKerror
            | FORMerror | STUFFerror | CRCerror | ALLerrors | OVERload
            | MESSage | MSIGnal}
```

The :SEARCh:SERial:CAN:MODE command selects the type of CAN information to find in the Lister display:

Condition	Front-panel name	Description
IDEither	Frame ID	Finds remote or data frames matching the specified ID.
IDData	Data Frame ID	Finds data frames matching the specified ID.
DATA	Data Frame ID and Data	Finds data frames matching the specified ID and data.
IDRemote	Remote Frame ID	Finds remote frames with the specified ID.
ERRor	Error Frame	Finds CAN active error frames.
ACKerror	Acknowledge Error	Finds the acknowledge bit if the polarity is incorrect.
FORMerror	Form Error	Finds reserved bit errors.
STUFFerror	Stuff Error	Finds 6 consecutive 1s or 6 consecutive 0s, while in a non-error or non overload frame.
CRCerror	CRC Field Error	Finds when the calculated CRC does not match the transmitted CRC.
ALLerrors	All Errors	Finds any form error or active error.
OVERload	Overload Frame	Finds CAN overload frames.
MESSage	Message	Finds a symbolic message.
MSIGnal	Message and Signal (non-FD)	Finds a symbolic message and a signal value.

Query Syntax :SEARCh:SERial:CAN:MODE?

The :SEARCh:SERial:CAN:MODE? query returns the currently selected mode.

Return Format <value><NL>

```
<value> ::= {IDE | IDD | DATA | IDR | ERR | ACK | FORM | STUF | CRC
            | ALL | OVER | MESS | MSIG}
```

- See Also**
- [Chapter 38](#), “:SEARCh Commands,” starting on page 1273
 - [":SEARCh:SERial:CAN:PATtern:DATA"](#) on page 1313
 - [":SEARCh:SERial:CAN:PATtern:ID"](#) on page 1315

- **":RECall:DBC[:START]"** on page 929
- **":SEARch:SERial:CAN:SYMBolic:MESSage"** on page 1317
- **":SEARch:SERial:CAN:SYMBolic:SIGNal"** on page 1318
- **":SEARch:SERial:CAN:SYMBolic:VALue"** on page 1319

:SEARCh:SERial:CAN:PATtern:DATA

N (see [page 1730](#))

Command Syntax :SEARCh:SERial:CAN:PATtern:DATA <string>

<string> ::= "0xnn...n" where n ::= {0,...,9 | A,...,F | X}
for hexadecimal

The :SEARCh:SERial:CAN:PATtern:DATA command specifies the data value when searching for Data Frame ID and Data.

The length of the data value is specified using the :SEARCh:SERial:CAN:PATtern:DATA:LENGth command.

Query Syntax :SEARCh:SERial:CAN:PATtern:DATA?

The :SEARCh:SERial:CAN:PATtern:DATA? query returns the current data value setting.

Return Format <string><NL>

<string> ::= "0xnn...n" where n ::= {0,...,9 | A,...,F | X}
for hexadecimal

- See Also**
- [Chapter 38](#), “:SEARCh Commands,” starting on page 1273
 - [":SEARCh:SERial:CAN:MODE"](#) on page 1311
 - [":SEARCh:SERial:CAN:PATtern:DATA:LENGth"](#) on page 1314

:SEARCH:SERIAL:CAN:PATTERN:DATA:LENGTH

N (see [page 1730](#))

Command Syntax :SEARCH:SERIAL:CAN:PATTERN:DATA:LENGTH <length>

<length> ::= integer from 1 to 8 in NR1 format

The :SEARCH:SERIAL:CAN:PATTERN:DATA:LENGTH command specifies the length of the data value when searching for Data Frame ID and Data.

The data value is specified using the :SEARCH:SERIAL:CAN:PATTERN:DATA command.

Query Syntax :SEARCH:SERIAL:CAN:PATTERN:DATA:LENGTH?

The :SEARCH:SERIAL:CAN:PATTERN:DATA:LENGTH? query returns the current data length setting.

Return Format <length><NL>

<length> ::= integer from 1 to 8 in NR1 format

- See Also**
- [Chapter 38](#), “:SEARCH Commands,” starting on page 1273
 - [":SEARCH:SERIAL:CAN:MODE"](#) on page 1311
 - [":SEARCH:SERIAL:CAN:PATTERN:DATA"](#) on page 1313

:SEARCh:SERial:CAN:PATTErn:ID

N (see [page 1730](#))

Command Syntax :SEARCh:SERial:CAN:PATTErn:ID <string>

<string> ::= "0xnn...n" where n ::= {0,...,9 | A,...,F | X}
for hexadecimal

The :SEARCh:SERial:CAN:PATTErn:ID command specifies the ID value when searching for a CAN event.

The value can be a standard ID or an extended ID, depending on the :SEARCh:SERial:CAN:PATTErn:ID:MODE command's setting.

Query Syntax :SEARCh:SERial:CAN:PATTErn:ID?

The :SEARCh:SERial:CAN:PATTErn:ID? query returns the current ID value setting.

Return Format <string><NL>

<string> ::= "0xnn...n" where n ::= {0,...,9 | A,...,F | X}
for hexadecimal

- See Also**
- [Chapter 38](#), “:SEARCh Commands,” starting on page 1273
 - [":SEARCh:SERial:CAN:MODE"](#) on page 1311
 - [":SEARCh:SERial:CAN:PATTErn:ID:MODE"](#) on page 1316

:SEARCH:SERIAL:CAN:PATTERN:ID:MODE

N (see [page 1730](#))

Command Syntax :SEARCH:SERIAL:CAN:PATTERN:ID:MODE <value>

<value> ::= {STANDARD | EXTENDED}

The :SEARCH:SERIAL:CAN:PATTERN:ID:MODE command specifies whether a standard ID value or an extended ID value is used when searching for a CAN event.

The ID value is specified using the :SEARCH:SERIAL:CAN:PATTERN:ID command.

Query Syntax :SEARCH:SERIAL:CAN:PATTERN:ID:MODE?

The :SEARCH:SERIAL:CAN:PATTERN:ID:MODE? query returns the current setting.

Return Format <value><NL>

<value> ::= {STAN | EXT}

- See Also**
- [Chapter 38](#), “:SEARCH Commands,” starting on page 1273
 - [":SEARCH:SERIAL:CAN:MODE"](#) on page 1311
 - [":SEARCH:SERIAL:CAN:PATTERN:ID"](#) on page 1315

:SEARCh:SERial:CAN:SYMBolic:MESSage

N (see [page 1730](#))

Command Syntax :SEARCh:SERial:CAN:SYMBolic:MESSage <name>

<name> ::= quoted ASCII string

The :SEARCh:SERial:CAN:SYMBolic:MESSage command specifies the message to search for when CAN symbolic data has been loaded (recalled) into the oscilloscope and the CAN serial search mode is set to MESSage or MSIGNAL.

Query Syntax :SEARCh:SERial:CAN:SYMBolic:MESSage?

The :SEARCh:SERial:CAN:SYMBolic:MESSage? query returns the specified message.

Return Format <name><NL>

<name> ::= quotes ASCII string

- See Also**
- [":RECall:DBC\[:START\]"](#) on page 929
 - [":SEARCh:SERial:CAN:MODE"](#) on page 1311
 - [":SEARCh:SERial:CAN:SYMBolic:SIGNal"](#) on page 1318
 - [":SEARCh:SERial:CAN:SYMBolic:VALue"](#) on page 1319

:SEARCh:SERial:CAN:SYMBolic:SIGNal

N (see [page 1730](#))

Command Syntax :SEARCh:SERial:CAN:SYMBolic:SIGNal <name>

<name> ::= quoted ASCII string

The :SEARCh:SERial:CAN:SYMBolic:SIGNal command specifies the signal to search for when CAN symbolic data has been loaded (recalled) into the oscilloscope and the CAN serial search mode is set to MSIGnal.

Query Syntax :SEARCh:SERial:CAN:SYMBolic:SIGNal?

The :SEARCh:SERial:CAN:SYMBolic:SIGNal? query returns the specified signal.

Return Format <name><NL>

<name> ::= quoted ASCII string

- See Also**
- [":RECall:DBC\[:START\]"](#) on page 929
 - [":SEARCh:SERial:CAN:MODE"](#) on page 1311
 - [":SEARCh:SERial:CAN:SYMBolic:MESSAge"](#) on page 1317
 - [":SEARCh:SERial:CAN:SYMBolic:VALue"](#) on page 1319

:SEARCh:SERial:CAN:SYMBolic:VALue

N (see [page 1730](#))

Command Syntax :SEARCh:SERial:CAN:SYMBolic:VALue <data>

<data> ::= value in NR3 format

The :SEARCh:SERial:CAN:SYMBolic:VALue command specifies the signal value to search for when CAN symbolic data has been loaded (recalled) into the oscilloscope and the CAN serial search mode is set to MSIGnal.

NOTE

Encoded signal values are not supported in the remote interface (even though they can be used in the front panel graphical interface).

Query Syntax :SEARCh:SERial:CAN:SYMBolic:VALue?

The :SEARCh:SERial:CAN:SYMBolic:VALue? query returns the specified signal value.

Return Format <data><NL>

<data> ::= value in NR3 format

- See Also**
- [":RECall:DBC\[:START\]"](#) on page 929
 - [":SEARCh:SERial:CAN:MODE"](#) on page 1311
 - [":SEARCh:SERial:CAN:SYMBolic:MESSAge"](#) on page 1317
 - [":SEARCh:SERial:CAN:SYMBolic:SIGNal"](#) on page 1318

:SEARCH:SERIAL:FLEXray Commands

Table 151 :SEARCH:SERIAL:FLEXray Commands Summary

Command	Query	Options and Query Returns
:SEARCH:SERIAL:FLEXray:CYCLE <cycle> (see page 1321)	:SEARCH:SERIAL:FLEXray:CYCLE? (see page 1321)	<cycle> ::= {ALL <cycle #>} <cycle #> ::= integer from 0-63
:SEARCH:SERIAL:FLEXray:DATA <string> (see page 1322)	:SEARCH:SERIAL:FLEXray:DATA? (see page 1322)	<string> ::= "0xnn...n" where n ::= {0,...,9 A,...,F X }
:SEARCH:SERIAL:FLEXray:DATA:LENGTH <length> (see page 1323)	:SEARCH:SERIAL:FLEXray:DATA:LENGTH? (see page 1323)	<length> ::= integer from 1 to 12 in NR1 format
:SEARCH:SERIAL:FLEXray:FRAME <frame id> (see page 1324)	:SEARCH:SERIAL:FLEXray:FRAME? (see page 1324)	<frame_id> ::= {ALL <frame #>} <frame #> ::= integer from 1-2047
:SEARCH:SERIAL:FLEXray:MODE <value> (see page 1325)	:SEARCH:SERIAL:FLEXray:MODE? (see page 1325)	<value> ::= {FRAME CYCLE DATA HERRor FERRor AERRor}

:SEARCh:SERial:FLEXray:CYCLe

N (see [page 1730](#))

Command Syntax :SEARCh:SERial:FLEXray:CYCLe <cycle>

<cycle> ::= {ALL | <cycle #>}

<cycle #> ::= integer from 0-63

The :SEARCh:SERial:FLEXray:CYCLe command specifies the cycle value to find when searching for FlexRay frames.

A cycle value of -1 is the same as ALL.

Query Syntax :SEARCh:SERial:FLEXray:CYCLe?

The :SEARCh:SERial:FLEXray:CYCLe? query returns the current cycle value setting.

Return Format <cycle><NL>

<cycle> ::= {ALL | <cycle #>}

<cycle #> ::= integer from 0-63

- See Also**
- [Chapter 38](#), “:SEARCh Commands,” starting on page 1273
 - [":SEARCh:SERial:FLEXray:MODE"](#) on page 1325

:SEARCH:SERIAL:FLEXray:DATA

N (see [page 1730](#))

Command Syntax :SEARCH:SERIAL:FLEXray:DATA <string>

<string> ::= "0xnn...n" where n ::= {0,...,9 | A,...,F | X }

The :SEARCH:SERIAL:FLEXray:DATA command specifies the data value to find when searching for FlexRay frames.

The length of the data value is specified by the :SEARCH:SERIAL:FLEXray:DATA:LENGTH command.

Query Syntax :SEARCH:SERIAL:FLEXray:DATA?

The :SEARCH:SERIAL:FLEXray:DATA? query returns the current data value setting.

Return Format <string><NL>

<string> ::= "0xnn...n" where n ::= {0,...,9 | A,...,F | X }

- See Also**
- [Chapter 38](#), “:SEARCH Commands,” starting on page 1273
 - [":SEARCH:SERIAL:FLEXray:MODE"](#) on page 1325
 - [":SEARCH:SERIAL:FLEXray:DATA:LENGTH"](#) on page 1323

:SEARCh:SERial:FLEXray:DATA:LENGTh

N (see [page 1730](#))

Command Syntax :SEARCh:SERial:FLEXray:DATA:LENGTh <length>

<length> ::= integer from 1 to 12 in NR1 format

The :SEARCh:SERial:FLEXray:DATA:LENGTh command specifies the length of data values when searching for FlexRay frames.

The data value is specified using the :SEARCh:SERial:FLEXray:DATA command.

Query Syntax :SEARCh:SERial:FLEXray:DATA:LENGTh?

The :SEARCh:SERial:FLEXray:DATA:LENGTh? query returns the current data length setting.

Return Format <length><NL>

<length> ::= integer from 1 to 12 in NR1 format

- See Also**
- [Chapter 38](#), “:SEARCh Commands,” starting on page 1273
 - [":SEARCh:SERial:FLEXray:MODE"](#) on page 1325
 - [":SEARCh:SERial:FLEXray:DATA"](#) on page 1322

:SEARCH:SERIAL:FLEXray:FRAME

N (see [page 1730](#))

Command Syntax :SEARCH:SERIAL:FLEXray:FRAME <frame_id>

<frame_id> ::= {ALL | <frame #>}

<frame #> ::= integer from 1-2047

The :SEARCH:SERIAL:FLEXray:FRAME command specifies the frame ID value to find when searching for FlexRay frames.

Query Syntax :SEARCH:SERIAL:FLEXray:FRAME?

The :SEARCH:SERIAL:FLEXray:FRAME? query returns the current frame ID setting.

Return Format <frame_id><NL>

<frame_id> ::= {ALL | <frame #>}

<frame #> ::= integer from 1-2047

- See Also**
- [Chapter 38](#), “:SEARCH Commands,” starting on page 1273
 - [":SEARCH:SERIAL:FLEXray:MODE"](#) on page 1325

:SEARCh:SERial:FLEXray:MODE

N (see [page 1730](#))

Command Syntax :SEARCh:SERial:FLEXray:MODE <value>

<value> := {FRAME | CYCLe | DATA | HERRor | FERRor | AERRor}

The :SEARCh:SERial:FLEXray:MODE command selects the type of FlexRay information to find in the Lister display:

- FRAME – searches for FlexRay frames with the specified frame ID.
- CYCLe – searches for FlexRay frames with the specified cycle number and frame ID.
- DATA – searches for FlexRay frames with the specified data, cycle number, and frame ID.
- HERRor – searches for header CRC errors.
- FERRor – searches for frame CRC errors.
- AERRor – searches for all errors.

Query Syntax :SEARCh:SERial:FLEXray:MODE?

The :SEARCh:SERial:FLEXray:MODE? query returns the currently selected mode.

Return Format <value><NL>

<value> := {FRAM | CYCL | DATA | HERR | FERR | AERR}

- See Also**
- [Chapter 38](#), “:SEARCh Commands,” starting on page 1273
 - [":SEARCh:SERial:FLEXray:FRAME"](#) on page 1324
 - [":SEARCh:SERial:FLEXray:CYCLe"](#) on page 1321
 - [":SEARCh:SERial:FLEXray:DATA"](#) on page 1322

:SEARCH:SERIAL:I2S Commands

Table 152 :SEARCH:SERIAL:I2S Commands Summary

Command	Query	Options and Query Returns
:SEARCH:SERIAL:I2S:AUDIO <audio_ch> (see page 1327)	:SEARCH:SERIAL:I2S:AUDIO? (see page 1327)	<audio_ch> ::= {RIGHT LEFT EITHER}
:SEARCH:SERIAL:I2S:MODE <value> (see page 1328)	:SEARCH:SERIAL:I2S:MODE? (see page 1328)	<value> ::= {EQUAL NOTEQUAL LESSTHAN GREATERTHAN INRANGE OTRANGE}
:SEARCH:SERIAL:I2S:PARTTERN:DATA <string> (see page 1329)	:SEARCH:SERIAL:I2S:PARTTERN:DATA? (see page 1329)	<string> ::= "n" where n ::= 32-bit integer in signed decimal when <base> = DECIMAL <string> ::= "nn...n" where n ::= {0 1 X} when <base> = BINARY <string> ::= "0xnn...n" where n ::= {0,...,9 A,...,F X} when <base> = HEX
:SEARCH:SERIAL:I2S:PARTTERN:FORMAT <base> (see page 1330)	:SEARCH:SERIAL:I2S:PARTTERN:FORMAT? (see page 1330)	<base> ::= {BINARY HEX DECIMAL}
:SEARCH:SERIAL:I2S:RANGE <lower>, <upper> (see page 1331)	:SEARCH:SERIAL:I2S:RANGE? (see page 1331)	<lower> ::= 32-bit integer in signed decimal, <nondecimal>, or <string> <upper> ::= 32-bit integer in signed decimal, <nondecimal>, or <string> <nondecimal> ::= #Hnn...n where n ::= {0,...,9 A,...,F} for hexadecimal <nondecimal> ::= #Bnn...n where n ::= {0 1} for binary <string> ::= "0xnn...n" where n ::= {0,...,9 A,...,F} for hexadecimal

:SEARCh:SERial:I2S:AUDio

N (see [page 1730](#))

Command Syntax :SEARCh:SERial:I2S:AUDio <audio_ch>

<audio_ch> ::= {RIGHT | LEFT | EITHER}

The :SEARCh:SERial:I2S:AUDio command specifies the channel on which to search for I2S events: right, left, or either channel.

Query Syntax :SEARCh:SERial:I2S:AUDio?

The :SEARCh:SERial:I2S:AUDio? query returns the current channel setting.

Return Format <audio_ch><NL>

<audio_ch> ::= {RIGH | LEFT | EITH}

- See Also**
- [Chapter 38](#), “:SEARCh Commands,” starting on page 1273
 - [":SEARCh:SERial:I2S:MODE"](#) on page 1328

:SEARCH:SERIAL:I2S:MODE

N (see [page 1730](#))

Command Syntax :SEARCH:SERIAL:I2S:MODE <value>

<value> ::= {EQUAL | NOTequal | LESSthan | GREATERthan | INRange
| OUTRange}

The :SEARCH:SERIAL:I2S:MODE command selects the type of I2S information to find in the Lister display:

- EQUAL— searches for the specified audio channel's data word when it equals the specified word.
- NOTequal – searches for any word other than the specified word.
- LESSthan – searches for channel data words less than the specified value.
- GREATERthan – searches for channel data words greater than the specified value.
- INRange – searches for channel data words in the range.
- OUTRange – searches for channel data words outside the range.

Data word values are specified using the :SEARCH:SERIAL:I2S:PATTERN:DATA command.

Value ranges are specified using the :SEARCH:SERIAL:I2S:RANGE command.

Query Syntax :SEARCH:SERIAL:I2S:MODE?

The :SEARCH:SERIAL:I2S:MODE? query returns the currently selected mode.

Return Format <value><NL>

<value> ::= {EQU | NOT | LESS | GRE | INR | OUTR}

- See Also**
- [Chapter 38](#), “:SEARCH Commands,” starting on page 1273
 - [":SEARCH:SERIAL:I2S:PATTERN:DATA"](#) on page 1329
 - [":SEARCH:SERIAL:I2S:RANGE"](#) on page 1331
 - [":SEARCH:SERIAL:I2S:AUDIO"](#) on page 1327

:SEARCh:SERial:I2S:PATtern:DATA

N (see [page 1730](#))

Command Syntax :SEARCh:SERial:I2S:PATtern:DATA <string>

<string> ::= "n" where n ::= 32-bit integer in signed decimal
when <base> = DECimal

<string> ::= "nn...n" where n ::= {0 | 1 | X} when <base> = BINary

<string> ::= "0xnn...n" where n ::= {0,...,9 | A,...,F | X}
when <base> = HEX

The :SEARCh:SERial:I2S:PATtern:DATA command specifies the data word value when searching for I2S events.

The base of the value entered with this command is specified using the :SEARCh:SERial:I2S:PATtern:FORMat command.

Query Syntax :SEARCh:SERial:I2S:PATtern:DATA?

The :SEARCh:SERial:I2S:PATtern:DATA? query returns the current data word value setting.

Return Format <string><NL>

<string> ::= "n" where n ::= 32-bit integer in signed decimal
when <base> = DECimal

<string> ::= "nn...n" where n ::= {0 | 1 | X} when <base> = BINary

<string> ::= "0xnn...n" where n ::= {0,...,9 | A,...,F | X}
when <base> = HEX

- See Also**
- [Chapter 38](#), “:SEARCh Commands,” starting on page 1273
 - [":SEARCh:SERial:I2S:MODE"](#) on page 1328
 - [":SEARCh:SERial:I2S:PATtern:FORMat"](#) on page 1330

:SEARCH:SERIAL:I2S:PATTERN:FORMAT

N (see [page 1730](#))

Command Syntax :SEARCH:SERIAL:I2S:PATTERN:FORMAT <base>

<base> ::= {BINARY | HEX | DECIMAL}

The :SEARCH:SERIAL:I2S:PATTERN:FORMAT command specifies the number base used with the :SEARCH:SERIAL:I2S:PATTERN:DATA command.

Query Syntax :SEARCH:SERIAL:I2S:PATTERN:FORMAT?

The :SEARCH:SERIAL:I2S:PATTERN:FORMAT? query returns the current number base setting.

Return Format <base><NL>

<base> ::= {BIN | HEX | DEC}

- See Also**
- [Chapter 38](#), “:SEARCH Commands,” starting on page 1273
 - [":SEARCH:SERIAL:I2S:PATTERN:DATA"](#) on page 1329

:SEARCh:SERial:I2S:RANGe

N (see [page 1730](#))

Command Syntax :SEARCh:SERial:I2S:RANGe <lower>, <upper>

<lower> ::= 32-bit integer in signed decimal, <nondecimal>, or <string>

<upper> ::= 32-bit integer in signed decimal, <nondecimal>, or <string>

<nondecimal> ::= #Hnn...n where n ::= {0,...,9 | A,...,F} for hexadecimal

<nondecimal> ::= #Bnn...n where n ::= {0 | 1} for binary

<string> ::= "0xnn...n" where n ::= {0,...,9 | A,...,F} for hexadecimal

The :SEARCh:SERial:I2S:RANGe command specifies the data value range when searching for I2S events in the INRange and OUTRange search modes (set by the :SEARCh:SERial:I2S:MODE command).

You can enter the parameters in any order – the smaller value becomes the <lower> and the larger value becomes the <upper>.

Query Syntax :SEARCh:SERial:I2S:RANGe?

The :SEARCh:SERial:I2S:RANGe? query returns the current data value range setting.

Return Format <lower>, <upper><NL>

<lower> ::= 32-bit integer in signed decimal

<upper> ::= 32-bit integer in signed decimal

- See Also**
- [Chapter 38](#), “:SEARCh Commands,” starting on page 1273
 - [":SEARCh:SERial:I2S:MODE"](#) on page 1328

:SEARCH:SERIAL:IIC Commands

Table 153 :SEARCH:SERIAL:IIC Commands Summary

Command	Query	Options and Query Returns
:SEARCH:SERIAL:IIC:MODE <value> (see page 1333)	:SEARCH:SERIAL:IIC:MODE? (see page 1333)	<value> ::= {REStart ADDRESS ANACK NACKnowledge READEprom READ7 WRITE7 R7Data2 W7Data2}
:SEARCH:SERIAL:IIC:PA TTern:ADDRESS <value> (see page 1335)	:SEARCH:SERIAL:IIC:PA TTern:ADDRESS? (see page 1335)	<value> ::= integer or <string> <string> ::= "0xnn" n ::= {0,...,9 A,...,F}
:SEARCH:SERIAL:IIC:PA TTern:DATA <value> (see page 1336)	:SEARCH:SERIAL:IIC:PA TTern:DATA? (see page 1336)	<value> ::= integer or <string> <string> ::= "0xnn" n ::= {0,...,9 A,...,F}
:SEARCH:SERIAL:IIC:PA TTern:DATA2 <value> (see page 1337)	:SEARCH:SERIAL:IIC:PA TTern:DATA2? (see page 1337)	<value> ::= integer or <string> <string> ::= "0xnn" n ::= {0,...,9 A,...,F}
:SEARCH:SERIAL:IIC:QUALifier <value> (see page 1338)	:SEARCH:SERIAL:IIC:QUALifier? (see page 1338)	<value> ::= {EQUAL NOTequal LESSthan GREATERthan}

:SEARCh:SERial:IIC:MODE

N (see [page 1730](#))

Command Syntax :SEARCh:SERial:IIC:MODE <value>

```
<value> ::= {REStart | ADDRESS | ANACK | NACKnowledge | READEprom
             | READ7 | WRITE7 | R7Data2 | W7Data2}
```

The :SEARCh:SERial:IIC:MODE command selects the type of IIC information to find in the Lister display:

- REStart – searches for another start condition occurring before a stop condition.
- ADDRESS – searches for a packet with the specified address, ignoring the R/W bit.
- ANACK – searches for address with no acknowledge events.
- NACKnowledge – searches for missing acknowledge events.
- READEprom – searches for EEPROM data reads.
- READ7 – searches for 7-bit address frames containing Start:Address7:Read:Ack:Data. The value READ is also accepted for READ7.
- WRITe7 – searches for 7-bit address frames containing Start:Address7:Write:Ack:Data. The value WRITe is also accepted for WRITe7.
- R7Data2 – searches for 7-bit address frames containing Start:Address7:Read:Ack:Data:Ack:Data2.
- W7Data2 – searches for 7-bit address frames containing Start:Address7:Write:Ack:Data:Ack:Data2.

NOTE

The short form of READ7 (READ7), READEprom (READE), and WRITe7 (WRIT7) do not follow the defined Long Form to Short Form Truncation Rules (see [page 1732](#)).

When searching for events containing addresses, address values are specified using the :SEARCh:SERial:IIC:PATtern:ADDRess command.

When searching for events containing data, data values are specified using the :SEARCh:SERial:IIC:PATtern:DATA and :SEARCh:SERial:IIC:PATtern:DATA2 commands.

Query Syntax :SEARCh:SERial:IIC:MODE?

The :SEARCh:SERial:IIC:MODE? query returns the currently selected mode.

Return Format <value><NL>

```
<value> ::= {REST | ADDR | ANAC | NACK | READE | READ7 | WRITE7
             | R7D2 | W7D2}
```

- See Also**
- **Chapter 38**, “:SEARCh Commands,” starting on page 1273
 - **":SEARCh:SERial:IIC:PATtern:ADDResS"** on page 1335
 - **":SEARCh:SERial:IIC:PATtern:DATA"** on page 1336
 - **":SEARCh:SERial:IIC:PATtern:DATA2"** on page 1337
 - **":SEARCh:SERial:IIC:QUALifier"** on page 1338

:SEARCh:SERial:IIC:PATtern:ADDRes

N (see [page 1730](#))

Command Syntax :SEARCh:SERial:IIC:PATtern:ADDRes <value>

<value> ::= integer or <string>

<string> ::= "0xnn" n ::= {0,...,9 | A,...,F}

The :SEARCh:SERial:IIC:PATtern:ADDRes command specifies address values when searching for IIC events.

To set don't care values, use the integer -1.

Query Syntax :SEARCh:SERial:IIC:PATtern:ADDRes?

The :SEARCh:SERial:IIC:PATtern:ADDRes? query returns the current address value setting.

Return Format <value><NL>

<value> ::= integer

- See Also**
- [Chapter 38](#), “:SEARCh Commands,” starting on page 1273
 - [":SEARCh:SERial:IIC:MODE"](#) on page 1333

:SEARCH:SERIAL:IIC:PATTERN:DATA

N (see [page 1730](#))

Command Syntax :SEARCH:SERIAL:IIC:PATTERN:DATA <value>

<value> ::= integer or <string>

<string> ::= "0xnn" n ::= {0,...,9 | A,...,F}

The :SEARCH:SERIAL:IIC:PATTERN:DATA command specifies data values when searching for IIC events.

To set don't care values, use the integer -1.

When searching for IIC EEPROM data read events, you specify the data value qualifier using the :SEARCH:SERIAL:IIC:QUALIFIER command.

Query Syntax :SEARCH:SERIAL:IIC:PATTERN:DATA?

The :SEARCH:SERIAL:IIC:PATTERN:DATA? query returns the current data value setting.

Return Format <value><NL>

<value> ::= integer

- See Also**
- [Chapter 38](#), “:SEARCH Commands,” starting on page 1273
 - [":SEARCH:SERIAL:IIC:MODE"](#) on page 1333
 - [":SEARCH:SERIAL:IIC:QUALIFIER"](#) on page 1338
 - [":SEARCH:SERIAL:IIC:PATTERN:DATA2"](#) on page 1337

:SEARCh:SERial:IIC:PATtern:DATA2

N (see [page 1730](#))

Command Syntax :SEARCh:SERial:IIC:PATtern:DATA2 <value>

<value> ::= integer or <string>

<string> ::= "0xnn" n ::= {0,...,9 | A,...,F}

The :SEARCh:SERial:IIC:PATtern:DATA2 command specifies the second data value when searching for IIC events with two data values.

To set don't care values, use the integer -1.

Query Syntax :SEARCh:SERial:IIC:PATtern:DATA2?

The :SEARCh:SERial:IIC:PATtern:DATA2? query returns the current second data value setting.

Return Format <value><NL>

<value> ::= integer

- See Also**
- [Chapter 38](#), “:SEARCh Commands,” starting on page 1273
 - [":SEARCh:SERial:IIC:MODE"](#) on page 1333
 - [":SEARCh:SERial:IIC:PATtern:DATA"](#) on page 1336

:SEARCH:SERIAL:IIC:QUALIFIER

N (see [page 1730](#))

Command Syntax :SEARCH:SERIAL:IIC:QUALIFIER <value>

<value> ::= {EQUAL | NOTequal | LESSthan | GREATERthan}

The :SEARCH:SERIAL:IIC:QUALIFIER command specifies the data value qualifier used when searching for IIC EEPROM data read events.

Query Syntax :SEARCH:SERIAL:IIC:QUALIFIER?

The :SEARCH:SERIAL:IIC:QUALIFIER? query returns the current data value qualifier setting.

Return Format <value><NL>

<value> ::= {EQU | NOT | LESS | GRE}

- See Also**
- [Chapter 38](#), “:SEARCH Commands,” starting on page 1273
 - [":SEARCH:SERIAL:IIC:MODE"](#) on page 1333
 - [":SEARCH:SERIAL:IIC:PATTERN:DATA"](#) on page 1336

:SEARCh:SERIAL:LIN Commands

Table 154 :SEARCh:SERIAL:LIN Commands Summary

Command	Query	Options and Query Returns
:SEARCh:SERIAL:LIN:ID <value> (see page 1340)	:SEARCh:SERIAL:LIN:ID ? (see page 1340)	<value> ::= 7-bit integer in decimal, <nondecimal>, or <string> from 0-63 or 0x00-0x3f <nondecimal> ::= #Hnn where n ::= {0,...,9 A,...,F} for hexadecimal <nondecimal> ::= #Bnn...n where n ::= {0 1} for binary <string> ::= "0xnn" where n ::= {0,...,9 A,...,F} for hexadecimal
:SEARCh:SERIAL:LIN:MODE <value> (see page 1341)	:SEARCh:SERIAL:LIN:MODE? (see page 1341)	<value> ::= {ID DATA ERRor}
:SEARCh:SERIAL:LIN:PATTERN:DATA <string> (see page 1342)	:SEARCh:SERIAL:LIN:PATTERN:DATA? (see page 1342)	When :SEARCh:SERIAL:LIN:PATTERN:FORMAT DECimal, <string> ::= "n" where n ::= 32-bit integer in unsigned decimal, returns "\$" if data has any don't cares When :SEARCh:SERIAL:LIN:PATTERN:FORMAT HEX, <string> ::= "0xnn...n" where n ::= {0,...,9 A,...,F X }
:SEARCh:SERIAL:LIN:PATTERN:DATA:LENGTH <length> (see page 1343)	:SEARCh:SERIAL:LIN:PATTERN:DATA:LENGTH? (see page 1343)	<length> ::= integer from 1 to 8 in NR1 format
:SEARCh:SERIAL:LIN:PATTERN:FORMAT <base> (see page 1344)	:SEARCh:SERIAL:LIN:PATTERN:FORMAT? (see page 1344)	<base> ::= {HEX DECimal}
:SEARCh:SERIAL:LIN:SYMBOLIC:FRAME <name> (see page 1345)	:SEARCh:SERIAL:LIN:SYMBOLIC:FRAME? (see page 1345)	<name> ::= quoted ASCII string
:SEARCh:SERIAL:LIN:SYMBOLIC:SIGNAL <name> (see page 1346)	:SEARCh:SERIAL:LIN:SYMBOLIC:SIGNAL? (see page 1346)	<name> ::= quoted ASCII string
:SEARCh:SERIAL:LIN:SYMBOLIC:VALUE <data> (see page 1347)	:SEARCh:SERIAL:LIN:SYMBOLIC:VALUE? (see page 1347)	<data> ::= value in NR3 format

:SEARCH:SERIAL:LIN:ID

N (see [page 1730](#))

Command Syntax :SEARCH:SERIAL:LIN:ID <value>

<value> ::= 7-bit integer in decimal, <nondecimal>, or <string>
from 0-63 or 0x00-0x3f

<nondecimal> ::= #Hnn where n ::= {0,...,9 | A,...,F} for hexadecimal

<nondecimal> ::= #Bnn...n where n ::= {0 | 1} for binary

<string> ::= "0xnn" where n ::= {0,...,9 | A,...,F} for hexadecimal

The :SEARCH:SERIAL:LIN:ID command specifies the frame ID value when searching for LIN events.

Query Syntax :SEARCH:SERIAL:LIN:ID?

The :SEARCH:SERIAL:LIN:ID? query returns the current frame ID setting.

Return Format <value><NL>

<value> ::= 7-bit integer in decimal

- See Also**
- [Chapter 38](#), “:SEARCH Commands,” starting on page 1273
 - [":SEARCH:SERIAL:LIN:MODE"](#) on page 1341

:SEARCh:SERial:LIN:MODE

N (see [page 1730](#))

Command Syntax :SEARCh:SERial:LIN:MODE <value>

<value> ::= {ID | DATA | ERRor | FRAMe | FSIGNal}

The :SEARCh:SERial:LIN:MODE command selects the type of LIN information to find in the Lister display:

- ID – searches for a frame ID.
- DATA – searches for a frame ID and data.
- ERRor – searches for errors.
- FRAMe – searches for symbolic frames.
- FSIGNal – searched for symbolic frames and a signal values.

Frame IDs are specified using the :SEARCh:SERial:LIN:ID command.

Data values are specified using the :SEARCh:SERial:LIN:PATtern:DATA command.

Frames, signals, and signal values are specified using the :SEARCh:SERial:LIN:SYMBolic:FRAMe, :SEARCh:SERial:LIN:SYMBolic:SIGNal, and :SEARCh:SERial:LIN:SYMBolic:VALue commands. LIN symbolic data files are loaded (recalled) using the :RECall:LDF[:START] command.

Query Syntax :SEARCh:SERial:LIN:MODE?

The :SEARCh:SERial:LIN:MODE? query returns the currently selected mode.

Return Format <value><NL>

<value> ::= {ID | DATA | ERR | FRAM | FSIG}

- See Also**
- [Chapter 38](#), “:SEARCh Commands,” starting on page 1273
 - [":SEARCh:SERial:LIN:ID"](#) on page 1340
 - [":SEARCh:SERial:LIN:PATtern:DATA"](#) on page 1342
 - [":RECall:LDF\[:START\]"](#) on page 931
 - [":SEARCh:SERial:LIN:SYMBolic:FRAMe"](#) on page 1345
 - [":SEARCh:SERial:LIN:SYMBolic:SIGNal"](#) on page 1346
 - [":SEARCh:SERial:LIN:SYMBolic:VALue"](#) on page 1347

:SEARCH:SERIAL:LIN:PATTERN:DATA

N (see [page 1730](#))

Command Syntax :SEARCH:SERIAL:LIN:PATTERN:DATA <string>

When :SEARCH:SERIAL:LIN:PATTERN:FORMAT DECIMAL,
<string> ::= "n" where n ::= 32-bit integer in unsigned decimal

When :SEARCH:SERIAL:LIN:PATTERN:FORMAT HEX,
<string> ::= "0xnn...n" where n ::= {0,...,9 | A,...,F | X }

The :SEARCH:SERIAL:LIN:PATTERN:DATA command specifies the data value when searching for LIN events.

The number base of the value entered with this command is specified using the :SEARCH:SERIAL:LIN:PATTERN:FORMAT command. To set don't care values with the DATA command, the FORMAT must be HEX.

The length of the data value entered is specified using the :SEARCH:SERIAL:LIN:PATTERN:DATA:LENGTH command.

Query Syntax :SEARCH:SERIAL:LIN:PATTERN:DATA?

The :SEARCH:SERIAL:LIN:PATTERN:DATA? query returns the current data value setting.

Return Format <string><NL>

When :SEARCH:SERIAL:LIN:PATTERN:FORMAT DECIMAL,
<string> ::= "n" where n ::= 32-bit integer in unsigned decimal or "\$" if data has any don't cares

When :SEARCH:SERIAL:LIN:PATTERN:FORMAT HEX,
<string> ::= "0xnn...n" where n ::= {0,...,9 | A,...,F | X }

- See Also**
- [Chapter 38](#), “:SEARCH Commands,” starting on page 1273
 - [":SEARCH:SERIAL:LIN:MODE"](#) on page 1341
 - [":SEARCH:SERIAL:LIN:PATTERN:FORMAT"](#) on page 1344
 - [":SEARCH:SERIAL:LIN:PATTERN:DATA:LENGTH"](#) on page 1343

:SEARCh:SERial:LIN:PATtern:DATA:LENGth

N (see [page 1730](#))

Command Syntax :SEARCh:SERial:LIN:PATtern:DATA:LENGth <length>

<length> ::= integer from 1 to 8 in NR1 format

The :SEARCh:SERial:LIN:PATtern:DATA:LENGth command specifies the the length of the data value when searching for LIN events.

The data value is specified using the :SEARCh:SERial:LIN:PATtern:DATA command.

Query Syntax :SEARCh:SERial:LIN:PATtern:DATA:LENGth?

The :SEARCh:SERial:LIN:PATtern:DATA:LENGth? query returns the current data value length setting.

Return Format <length><NL>

<length> ::= integer from 1 to 8 in NR1 format

- See Also**
- [Chapter 38](#), “:SEARCh Commands,” starting on page 1273
 - [":SEARCh:SERial:LIN:PATtern:DATA"](#) on page 1342

:SEARCH:SERIAL:LIN:PATTERN:FORMAT

N (see [page 1730](#))

Command Syntax :SEARCH:SERIAL:LIN:PATTERN:FORMAT <base>

<base> ::= {HEX | DECIMAL}

The :SEARCH:SERIAL:LIN:PATTERN:FORMAT command specifies the number base used with the :SEARCH:SERIAL:LIN:PATTERN:DATA command.

Query Syntax :SEARCH:SERIAL:LIN:PATTERN:FORMAT?

The :SEARCH:SERIAL:LIN:PATTERN:FORMAT? query returns the current number base setting.

Return Format <base><NL>

<base> ::= {HEX | DEC}

- See Also**
- [Chapter 38](#), “:SEARCH Commands,” starting on page 1273
 - [":SEARCH:SERIAL:LIN:PATTERN:DATA"](#) on page 1342

:SEARCh:SERial:LIN:SYMBolic:FRAMe

N (see [page 1730](#))

Command Syntax :SEARCh:SERial:LIN:SYMBolic:FRAMe <name>

<name> ::= quoted ASCII string

The :SEARCh:SERial:LIN:SYMBolic:FRAMe command specifies the message to search for when LIN symbolic data has been loaded (recalled) into the oscilloscope and the LIN serial search mode is set to FRAME or FSIGNAL.

Query Syntax :SEARCh:SERial:LIN:SYMBolic:FRAMe?

The :SEARCh:SERial:LIN:SYMBolic:FRAMe? query returns the specified message.

Return Format <name><NL>

<name> ::= quotes ASCII string

- See Also**
- [":RECall:LDF\[:START\]"](#) on page 931
 - [":SEARCh:SERial:LIN:MODE"](#) on page 1341
 - [":SEARCh:SERial:LIN:SYMBolic:SIGNal"](#) on page 1346
 - [":SEARCh:SERial:LIN:SYMBolic:VALue"](#) on page 1347

:SEARCh:SERial:LIN:SYMBolic:SIGNal

N (see [page 1730](#))

Command Syntax :SEARCh:SERial:LIN:SYMBolic:SIGNal <name>

<name> ::= quoted ASCII string

The :SEARCh:SERial:LIN:SYMBolic:SIGNal command specifies the signal to search for when LIN symbolic data has been loaded (recalled) into the oscilloscope and the LIN serial search mode is set to FSignal.

Query Syntax :SEARCh:SERial:LIN:SYMBolic:SIGNal?

The :SEARCh:SERial:LIN:SYMBolic:SIGNal? query returns the specified signal.

Return Format <name><NL>

<name> ::= quoted ASCII string

- See Also**
- [":RECall:LDF\[:START\]"](#) on page 931
 - [":SEARCh:SERial:LIN:MODE"](#) on page 1341
 - [":SEARCh:SERial:LIN:SYMBolic:FRAMe"](#) on page 1345
 - [":SEARCh:SERial:LIN:SYMBolic:VALue"](#) on page 1347

:SEARCh:SERial:LIN:SYMBolic:VALue

N (see [page 1730](#))

Command Syntax :SEARCh:SERial:LIN:SYMBolic:VALue <data>

<data> ::= value in NR3 format

The :SEARCh:SERial:LIN:SYMBolic:VALue command specifies the signal value to search for when LIN symbolic data has been loaded (recalled) into the oscilloscope and the LIN serial search mode is set to FSIGNAL.

NOTE

Encoded signal values are not supported in the remote interface (even though they can be used in the front panel graphical interface).

Query Syntax :SEARCh:SERial:LIN:SYMBolic:VALue?

The :SEARCh:SERial:LIN:SYMBolic:VALue? query returns the specified signal value.

Return Format <data><NL>

<data> ::= value in NR3 format

- See Also**
- [":RECall:LDF\[:START\]"](#) on page 931
 - [":SEARCh:SERial:LIN:MODE"](#) on page 1341
 - [":SEARCh:SERial:LIN:SYMBolic:FRAMe"](#) on page 1345
 - [":SEARCh:SERial:LIN:SYMBolic:SIGNal"](#) on page 1346

:SEARCH:SERIAL:M1553 Commands

Table 155 :SEARCH:SERIAL:M1553 Commands Summary

Command	Query	Options and Query Returns
:SEARCH:SERIAL:M1553:MODE <value> (see page 1349)	:SEARCH:SERIAL:M1553:MODE? (see page 1349)	<value> ::= {DStArt CStArt RTA RTA11 PERRor SERRor MERRor}
:SEARCH:SERIAL:M1553:PATtern:DATA <string> (see page 1350)	:SEARCH:SERIAL:M1553:PATtern:DATA? (see page 1350)	<string> ::= "nn...n" where n ::= {0 1}
:SEARCH:SERIAL:M1553:RTA <value> (see page 1351)	:SEARCH:SERIAL:M1553:RTA? (see page 1351)	<value> ::= 5-bit integer in decimal, <hexadecimal>, <binary>, or <string> from 0-31 < hexadecimal > ::= #Hnn where n ::= {0,...,9 A,...,F} <binary> ::= #Bnn...n where n ::= {0 1} for binary <string> ::= "0xnn" where n ::= {0,...,9 A,...,F}

:SEARCh:SERial:M1553:MODE

N (see [page 1730](#))

Command Syntax :SEARCh:SERial:M1553:MODE <value>

<value> ::= {DSTArt | CSTArt | RTA | RTA11 | PERRor | SERRor | MERRor}

The :SEARCh:SERial:M1553:MODE command selects the type of MIL-STD-1553 information to find in the Lister display:

- DSTArt – searches for the start of a Data word (at the end of a valid Data Sync pulse).
- CSTArt – searches for the start of a Command/Status word (at the end of a valid C/S Sync pulse).
- RTA – searches for the Remote Terminal Address (RTA) of a Command/Status word.
- RTA11 – searches for the Remote Terminal Address (RTA) and the additional 11 bits of a Command/Status word.
- PERRor – searches for (odd) parity errors for the data in the word.
- SERRor – searches for invalid Sync pulses.
- MERRor – searches for Manchester encoding errors.

In the RTA or RTA11 modes, the Remote Terminal Address is specified using the :SEARCh:SERial:M1553:RTA command.

In the RTA11 mode, the additional 11 bits are specified using the :SEARCh:SERial:M1553:PATtern:DATA command.

Query Syntax :SEARCh:SERial:M1553:MODE?

The :SEARCh:SERial:M1553:MODE? query returns the currently selected mode.

Return Format <value><NL>

<value> ::= {DSTA | CSTA | RTA | RTA11 | PERR | SERR | MERR}

- See Also**
- [Chapter 38](#), “:SEARCh Commands,” starting on page 1273
 - [":SEARCh:SERial:M1553:RTA"](#) on page 1351
 - [":SEARCh:SERial:M1553:PATtern:DATA"](#) on page 1350

:SEARCh:SERial:M1553:PATtern:DATA

N (see [page 1730](#))

Command Syntax :SEARCh:SERial:M1553:PATtern:DATA <string>

<string> ::= "nn...n" where n ::= {0 | 1}

The :SEARCh:SERial:M1553:PATtern:DATA command specifies the additional 11 bits when searching for the MIL-STD-1553 Remote Terminal Address + 11 Bits.

Query Syntax :SEARCh:SERial:M1553:PATtern:DATA?

The :SEARCh:SERial:M1553:PATtern:DATA? query returns the current value setting for the additional 11 bits.

Return Format <string><NL>

<string> ::= "nn...n" where n ::= {0 | 1}

- See Also**
- [Chapter 38](#), “:SEARCh Commands,” starting on page 1273
 - [":SEARCh:SERial:M1553:MODE"](#) on page 1349

:SEARCh:SERial:M1553:RTA

N (see [page 1730](#))

Command Syntax :SEARCh:SERial:M1553:RTA <value>

<value> ::= 5-bit integer in decimal, <hexadecimal>, <binary>, or <string> from 0-31

<hexadecimal> ::= #Hnn where n ::= {0,...,9|A,...,F}

<binary> ::= #Bnn...n where n ::= {0 | 1} for binary

<string> ::= "0xnn" where n ::= {0,...,9|A,...,F}

The :SEARCh:SERial:M1553:RTA command specifies the Remote Terminal Address (RTA) value when searching for MIL-STD-1553 events.

Query Syntax :SEARCh:SERial:M1553:RTA?

The :SEARCh:SERial:M1553:RTA? query returns the current Remote Terminal Address value setting.

Return Format <value><NL>

<value> ::= 5-bit integer in decimal from 0-31

See Also • [Chapter 38](#), “:SEARCh Commands,” starting on page 1273

:SEARCH:SERIAL:SENT Commands

Table 156 :SEARCH:SERIAL:SENT Commands Summary

Command	Query	Options and Query Returns
:SEARCH:SERIAL:SENT:F AST:DATA <string> (see page 1353)	:SEARCH:SERIAL:SENT:F AST:DATA? (see page 1353)	<string> ::= "0xn..." where n ::= {0,...,9 A,...,F X \$}
:SEARCH:SERIAL:SENT:M ODE <mode> (see page 1354)	:SEARCH:SERIAL:SENT:M ODE? (see page 1354)	<mode> ::= {FCData SCMid SCData CRCerror PPErrror}
:SEARCH:SERIAL:SENT:S LOW:DATA <data> (see page 1355)	:SEARCH:SERIAL:SENT:S LOW:DATA? (see page 1355)	<data> ::= from -1 (don't care) to 65535, in NR1 format.
:SEARCH:SERIAL:SENT:S LOW:ID <id> (see page 1356)	:SEARCH:SERIAL:SENT:S LOW:ID? (see page 1356)	<id> ::= from -1 (don't care) to 255, in NR1 format.

:SEARCh:SERial:SENT:FAST:DATA

N (see [page 1730](#))

Command Syntax :SEARCh:SERial:SENT:FAST:DATA <string>

<string> ::= "0xn..." where n ::= {0,...,9 | A,...,F | X | \$}

The :SEARCh:SERial:SENT:FAST:DATA command specifies the status and data nibbles that will be searched for when the FCData search mode is chosen.

Query Syntax :SEARCh:SERial:SENT:FAST:DATA?

The :SEARCh:SERial:SENT:FAST:DATA? query returns the fast channel data search value setting.

Return Format <string><NL>

<string> ::= "0xn..." where n ::= {0,...,9 | A,...,F | X | \$}

- See Also**
- [":SEARCh:SERial:SENT:MODE"](#) on page 1354
 - [":SEARCh:SERial:SENT:SLOW:DATA"](#) on page 1355
 - [":SEARCh:SERial:SENT:SLOW:ID"](#) on page 1356

:SEARCH:SERIAL:SENT:MODE

N (see [page 1730](#))

Command Syntax :SEARCH:SERIAL:SENT:MODE <mode>

<mode> ::= {FCData | SCMid | SCData | CRCError | PPERror}

When SENT serial decode is turned on and displayed in the Lister, the :SEARCH:SERIAL:SENT:MODE command specifies what to search for in the decoded data:

- FCData – finds Fast Channel data nibbles that match the values entered using additional softkeys.
- SCMid – finds Slow Channel Message IDs that match the value entered using additional softkeys.
- SCData – finds Slow Channel Message IDs and Data that match the values entered using additional softkeys.
- CRCError – finds any CRC error, Fast or Slow.
- PPERror – finds where a nibble is either too wide or too narrow (for example, data nibble < 12 (11.5) or > 27 (27.5) ticks wide). Sync, S&C, data, or checksum pulse periods are checked.

Query Syntax :SEARCH:SERIAL:SENT:MODE?

The :SEARCH:SERIAL:SENT:MODE? query returns the search mode setting.

Return Format <mode><NL>

<mode> ::= {FCD | SCM | SCD | CRC | PPER}

- See Also**
- [":SEARCH:SERIAL:SENT:FAST:DATA"](#) on page 1353
 - [":SEARCH:SERIAL:SENT:SLOW:DATA"](#) on page 1355
 - [":SEARCH:SERIAL:SENT:SLOW:ID"](#) on page 1356

:SEARCh:SERial:SENT:SLOW:DATA

N (see [page 1730](#))

Command Syntax :SEARCh:SERial:SENT:SLOW:DATA <data>

<data> ::= from -1 (don't care) to 65535, in NR1 format.

The :SEARCh:SERial:SENT:SLOW:DATA command specifies the data to search for in the Slow Channel Message ID and Data search mode.

Query Syntax :SEARCh:SERial:SENT:SLOW:DATA?

The :SEARCh:SERial:SENT:SLOW:DATA? query returns the slow channel data search value setting.

Return Format <data><NL>

<data> ::= from -1 (don't care) to 65535, in NR1 format.

- See Also**
- [":SEARCh:SERial:SENT:FAST:DATA"](#) on page 1353
 - [":SEARCh:SERial:SENT:MODE"](#) on page 1354
 - [":SEARCh:SERial:SENT:SLOW:ID"](#) on page 1356

:SEARCH:SERIAL:SENT:SLOW:ID

N (see [page 1730](#))

Command Syntax :SEARCH:SERIAL:SENT:SLOW:ID <id>

<id> ::= from -1 (don't care) to 255, in NR1 format.

The :SEARCH:SERIAL:SENT:SLOW:ID command specifies the ID to search for in the "Slow Channel Message ID" and "Slow Channel Message ID & Data" trigger modes. The ID can be from -1 (don't care) to 255 (depending on the message length).

Query Syntax :SEARCH:SERIAL:SENT:SLOW:ID?

The :SEARCH:SERIAL:SENT:SLOW:ID? query returns the slow channel ID search value setting.

Return Format <id><NL>

<id> ::= from -1 (don't care) to 255, in NR1 format.

- See Also**
- [":SEARCH:SERIAL:SENT:FAST:DATA"](#) on page 1353
 - [":SEARCH:SERIAL:SENT:MODE"](#) on page 1354
 - [":SEARCH:SERIAL:SENT:SLOW:DATA"](#) on page 1355

:SEARCh:SERial:SPI Commands

Table 157 :SEARCh:SERial:SPI Commands Summary

Command	Query	Options and Query Returns
:SEARCh:SERial:SPI:MO DE <value> (see page 1358)	:SEARCh:SERial:SPI:MO DE? (see page 1358)	<value> ::= {MOSI MISO}
:SEARCh:SERial:SPI:PA TTern:DATA <string> (see page 1359)	:SEARCh:SERial:SPI:PA TTern:DATA? (see page 1359)	<string> ::= "0xnn...n" where n ::= {0,...,9 A,...,F X}
:SEARCh:SERial:SPI:PA TTern:WIDTh <width> (see page 1360)	:SEARCh:SERial:SPI:PA TTern:WIDTh? (see page 1360)	<width> ::= integer from 1 to 10

:SEARCh:SERial:SPI:MODE

N (see [page 1730](#))

Command Syntax :SEARCh:SERial:SPI:MODE <value>

<value> ::= {MOSI | MISO}

The :SEARCh:SERial:SPI:MODE command specifies whether the SPI search will be on the MOSI data or the MISO data.

Data values are specified using the :SEARCh:SERial:SPI:PATtern:DATA command.

Query Syntax :SEARCh:SERial:SPI:MODE?

The :SEARCh:SERial:SPI:MODE? query returns the current SPI search mode setting.

Return Format <value><NL>

<value> ::= {MOSI | MISO}

- See Also**
- [Chapter 38](#), “:SEARCh Commands,” starting on page 1273
 - [":SEARCh:SERial:SPI:PATtern:DATA"](#) on page 1359

:SEARCH:SERIAL:SPI:PATTERN:DATA

N (see [page 1730](#))

Command Syntax :SEARCH:SERIAL:SPI:PATTERN:DATA <string>

<string> ::= "0xnn...n" where n ::= {0,...,9 | A,...,F | X}

The :SEARCH:SERIAL:SPI:PATTERN:DATA command specifies the data value when searching for SPI events.

The width of the data value is specified using the :SEARCH:SERIAL:SPI:PATTERN:WIDTH command.

Query Syntax :SEARCH:SERIAL:SPI:PATTERN:DATA?

The :SEARCH:SERIAL:SPI:PATTERN:DATA? query returns the current data value setting.

Return Format <string><NL>

<string> ::= "0xnn...n" where n ::= {0,...,9 | A,...,F | X}

- See Also**
- [Chapter 38](#), “:SEARCH Commands,” starting on page 1273
 - [":SEARCH:SERIAL:SPI:PATTERN:WIDTH"](#) on page 1360

:SEARCh:SERial:SPI:PATtern:WIDTh

N (see [page 1730](#))

Command Syntax :SEARCh:SERial:SPI:PATtern:WIDTh <width>

<width> ::= integer from 1 to 10

The :SEARCh:SERial:SPI:PATtern:WIDTh command specifies the width of the data value (in bytes) when searching for SPI events.

The data value is specified using the :SEARCh:SERial:SPI:PATtern:DATA command.

Query Syntax :SEARCh:SERial:SPI:PATtern:WIDTh?

The :SEARCh:SERial:SPI:PATtern:WIDTh? query returns the current data width setting.

Return Format <width><NL>

<width> ::= integer from 1 to 10

- See Also**
- [Chapter 38](#), “:SEARCh Commands,” starting on page 1273
 - [":SEARCh:SERial:SPI:PATtern:DATA"](#) on page 1359

:SEARCh:SERial:UART Commands

Table 158 :SEARCh:SERial:UART Commands Summary

Command	Query	Options and Query Returns
:SEARCh:SERial:UART:D ATA <value> (see page 1362)	:SEARCh:SERial:UART:D ATA? (see page 1362)	<value> ::= 8-bit integer from 0-255 (0x00-0xff) in decimal, <hexadecimal>, <binary>, or <quoted_string> format <hexadecimal> ::= #Hnn where n ::= {0,...,9 A,...,F} for hexadecimal <binary> ::= #Bnn...n where n ::= {0 1} for binary <quoted_string> ::= any of the 128 valid 7-bit ASCII characters (or standard abbreviations)
:SEARCh:SERial:UART:M ODE <value> (see page 1363)	:SEARCh:SERial:UART:M ODE? (see page 1363)	<value> ::= {RDATa RD1 RD0 RDX TDATa TD1 TD0 TDX PARityerror AERRor}
:SEARCh:SERial:UART:Q UALifier <value> (see page 1364)	:SEARCh:SERial:UART:Q UALifier? (see page 1364)	<value> ::= {EQUal NOTequal GREaterthan LESSthan}

:SEARCh:SERial:UART:DATA

N (see [page 1730](#))

Command Syntax :SEARCh:SERial:UART:DATA <value>

<value> ::= 8-bit integer from 0-255 (0x00-0xff) in decimal, <hexadecimal>, <binary>, or <quoted_string> format
 <hexadecimal> ::= #Hnn where n ::= {0,...,9| A,...,F} for hexadecimal
 <binary> ::= #Bnn...n where n ::= {0 | 1} for binary
 <quoted_string> ::= any of the 128 valid 7-bit ASCII characters (or standard abbreviations)

The :SEARCh:SERial:UART:DATA command specifies a data value when searching for UART/RS232 events.

The data value qualifier is specified using the :SEARCh:SERial:UART:QUALifier command.

Query Syntax :SEARCh:SERial:UART:DATA?

The :SEARCh:SERial:UART:DATA? query returns the current data value setting.

Return Format <value><NL>

<value> ::= 8-bit integer from 0-255 (0x00-0xff) in decimal format

- See Also**
- [Chapter 38](#), “:SEARCh Commands,” starting on page 1273
 - [":SEARCh:SERial:UART:MODE"](#) on page 1363
 - [":SEARCh:SERial:UART:QUALifier"](#) on page 1364

:SEARCh:SERial:UART:MODE

N (see [page 1730](#))

Command Syntax :SEARCh:SERial:UART:MODE <value>

```
<value> ::= {RDATa | RD1 | RD0 | RDX | TDATa | TD1 | TD0 | TDX
             | PARityerror | AERRor}
```

The :SEARCh:SERial:UART:MODE command selects the type of UART/RS232 information to find in the Lister display:

- RDATa – searches for a receive data value when data words are from 5 to 8 bits long.
- RD1 – searches for a receive data value when data words are 9 bits long and the 9th (alert) bit is 1.
- RD0 – searches for a receive data value when data words are 9 bits long and the 9th (alert) bit is 0.
- RDX – searches for a receive data value when data words are 9 bits long and the 9th (alert) bit is a don't care (X).
- TDATa – searches for a transmit data value when data words are from 5 to 8 bits long.
- TD1 – searches for a transmit data value when data words are 9 bits long and the 9th (alert) bit is 1.
- TD0 – searches for a transmit data value when data words are 9 bits long and the 9th (alert) bit is 0.
- TDX – searches for a transmit data value when data words are 9 bits long and the 9th (alert) bit is a don't care (X).
- PARityerror – searches for parity errors.
- AERRor – searches for any error.

Data values are specified using the :SEARCh:SERial:UART:DATA command.

Data value qualifiers are specified using the :SEARCh:SERial:UART:QUALifier command.

Query Syntax :SEARCh:SERial:UART:MODE?

The :SEARCh:SERial:UART:MODE? query returns ...

Return Format <value><NL>

```
<value> ::= {RDAT | RD1 | RD0 | RDX | TDAT | TD1 | TD0 | TDX | PAR
             | AERR}
```

- See Also**
- [Chapter 38](#), “:SEARCh Commands,” starting on page 1273
 - [":SEARCh:SERial:UART:DATA"](#) on page 1362
 - [":SEARCh:SERial:UART:QUALifier"](#) on page 1364

:SEARCH:SERIAL:UART:QUALIFIER

N (see [page 1730](#))

Command Syntax :SEARCH:SERIAL:UART:QUALIFIER <value>

<value> ::= {EQUAL | NOTEQUAL | GREATERTHAN | LESSTHAN}

The :SEARCH:SERIAL:UART:QUALIFIER command specifies the data value qualifier when searching for UART/RS232 events.

Query Syntax :SEARCH:SERIAL:UART:QUALIFIER?

The :SEARCH:SERIAL:UART:QUALIFIER? query returns the current data value qualifier setting.

Return Format <value><NL>

<value> ::= {EQU | NOT | GRE | LESS}

- See Also**
- [Chapter 38](#), “:SEARCH Commands,” starting on page 1273
 - [":SEARCH:SERIAL:UART:DATA"](#) on page 1362

:SEARCh:SERIAL:USB Commands

Table 159 :SEARCh:SERIAL:USB Commands Summary

Command	Query	Options and Query Returns
:SEARCh:SERIAL:USB:MODE <condition> (see page 1367)	:SEARCh:SERIAL:USB:MODE? (see page 1367)	<event> ::= {TOKEN DATA HANDshake SPECial ALLerrors PIDerror CRC5error CRC16error GLITCherror STUFFerror SE1error}
:SEARCh:SERIAL:USB:ADDRESS <string> (see page 1368)	:SEARCh:SERIAL:USB:ADDRESS? (see page 1368)	<string> ::= "0xnn" where n ::= {0,...,9 A,...,F X \$}
:SEARCh:SERIAL:USB:CRCC <string> (see page 1369)	:SEARCh:SERIAL:USB:CRCC? (see page 1369)	<string> ::= "0xnn" where n ::= {0,...,9 A,...,F X \$}
:SEARCh:SERIAL:USB:DATA <string> (see page 1370)	:SEARCh:SERIAL:USB:DATA? (see page 1370)	<string> ::= "0xn..." where n ::= {0,...,9 A,...,F X \$}
:SEARCh:SERIAL:USB:DATA:LENGTH <value> (see page 1371)	:SEARCh:SERIAL:USB:DATA:LENGTH? (see page 1371)	<length> ::= data length between 1-20
:SEARCh:SERIAL:USB:ENDPOINT <string> (see page 1372)	:SEARCh:SERIAL:USB:ENDPOINT? (see page 1372)	<string> ::= "0xn" where n ::= {0,...,9 A,...,F X \$}
:SEARCh:SERIAL:USB:ET <string> (see page 1373)	:SEARCh:SERIAL:USB:ET? (see page 1373)	<string> ::= "0xn" where n ::= {0 1 2 3 X \$}
:SEARCh:SERIAL:USB:FRAME <string> (see page 1374)	:SEARCh:SERIAL:USB:FRAME? (see page 1374)	<string> ::= "0xnnnn" where n ::= {0,...,9 A,...,F X \$}
:SEARCh:SERIAL:USB:ADDRESS:ADDRESS <string> (see page 1375)	:SEARCh:SERIAL:USB:ADDRESS:ADDRESS? (see page 1375)	<string> ::= "0xnn" where n ::= {0,...,9 A,...,F X \$}
:SEARCh:SERIAL:USB:PID:DATA <pid> (see page 1376)	:SEARCh:SERIAL:USB:PID:DATA? (see page 1376)	<pid> ::= {DATA0 DATA1 DATA2 MDATA}
:SEARCh:SERIAL:USB:PID:HANDshake <pid> (see page 1377)	:SEARCh:SERIAL:USB:PID:HANDshake? (see page 1377)	<pid> ::= {ACK NAK STALL NYET}
:SEARCh:SERIAL:USB:PID:SPECIAL <pid> (see page 1378)	:SEARCh:SERIAL:USB:PID:SPECIAL? (see page 1378)	<pid> ::= {PING PRE ERR SPLit}

Table 159 :SEARCH:SERIAL:USB Commands Summary (continued)

Command	Query	Options and Query Returns
:SEARCH:SERIAL:USB:PID:TOKEN <pid> (see page 1379)	:SEARCH:SERIAL:USB:PID:TOKEN? (see page 1379)	<pid> ::= {OUT IN SETUP SOF}
:SEARCH:SERIAL:USB:PORT <string> (see page 1380)	:SEARCH:SERIAL:USB:PORT? (see page 1380)	<string> ::= "0xnn" where n ::= {0,...,9 A,...,F X \$}
:SEARCH:SERIAL:USB:SC <string> (see page 1381)	:SEARCH:SERIAL:USB:SC? (see page 1381)	<string> ::= "0xn" where n ::= {0 1 X \$}
:SEARCH:SERIAL:USB:SEU <string> (see page 1382)	:SEARCH:SERIAL:USB:SEU? (see page 1382)	<string> ::= "0xn" where n ::= {0 1 2 3 X \$}

:SEARCh:SERial:USB:MODE

N (see [page 1730](#))

Command Syntax :SEARCh:SERial:USB:MODE <mode>

```
<mode> ::= {TOKen | DATA | HANDshake | SPECial | ALLerrors
            | PIDerror | CRC5error | CRC16error | GLITCherror
            | STUFFerror | SE1error}
```

The :SEARCh:SERial:USB:MODE command specifies the USB search mode.

Query Syntax :SEARCh:SERial:USB:MODE?

The :SEARCh:SERial:USB:MODE? query returns the specified USB search mode.

Return Format <mode><NL>

```
<mode> ::= {TOK | DATA | HAND | SPEC | ALL | PID | CRC5
            | CRC16 | GLIT | STUFF | SE1}
```

- See Also**
- [":SEARCh:SERial:USB:PID:DATA"](#) on page 1376
 - [":SEARCh:SERial:USB:PID:HANDshake"](#) on page 1377
 - [":SEARCh:SERial:USB:PID:SPECial"](#) on page 1378
 - [":SEARCh:SERial:USB:PID:TOKen"](#) on page 1379

:SEARCH:SERIAL:USB:ADDRESS

N (see [page 1730](#))

Command Syntax :SEARCH:SERIAL:USB:ADDRESS <string>

<string> ::= "0xnn" where n ::= {0,...,9 | A,...,F | X | \$}

The :SEARCH:SERIAL:USB:ADDRESS command specifies the 7-bit Address portion of the search value, in hex.

Query Syntax :SEARCH:SERIAL:USB:ADDRESS?

The :SEARCH:SERIAL:USB:ADDRESS? query returns the specified Address portion of the search value.

Return Format <string><NL>

<string> ::= "0xnn" where n ::= {0,...,9 | A,...,F | X | \$}

- See Also**
- [":SEARCH:SERIAL:USB:PID:SPECIAL"](#) on page 1378
 - [":SEARCH:SERIAL:USB:PID:TOKEN"](#) on page 1379

:SEARCh:SERial:USB:CRc

N (see [page 1730](#))

Command Syntax :SEARCh:SERial:USB:CRc <string>

<string> ::= "0xnn" where n ::= {0,...,9 | A,...,F | X | \$}

The :SEARCh:SERial:USB:CRc command specifies the CRC portion of the search value, in hex.

Query Syntax :SEARCh:SERial:USB:CRc?

The :SEARCh:SERial:USB:CRc? query returns the specified CRC portion of the search value.

Return Format <string><NL>

<string> ::= "0xnn" where n ::= {0,...,9 | A,...,F | X | \$}

- See Also**
- [":SEARCh:SERial:USB:PID:SPECial"](#) on page 1378
 - [":SEARCh:SERial:USB:PID:TOKen"](#) on page 1379

:SEARCH:SERIAL:USB:DATA

N (see [page 1730](#))

Command Syntax :SEARCH:SERIAL:USB:DATA <string>

<string> ::= "0xn..." where n ::= {0,...,9 | A,...,F | X | \$}

The :SEARCH:SERIAL:USB:DATA command specifies the Data portion of the search value, in hex.

See the :SEARCH:SERIAL:USB:DATA:LENGTH command for setting the length of the data value.

Query Syntax :SEARCH:SERIAL:USB:DATA?

The :SEARCH:SERIAL:USB:DATA? query returns the specified Data portion of the search value.

Return Format <string><NL>

<string> ::= "0xn..." where n ::= {0,...,9 | A,...,F | X | \$}

See Also • [":SEARCH:SERIAL:USB:DATA:LENGTH"](#) on page 1371

:SEARCh:SERial:USB:DATA:LENGTh

N (see [page 1730](#))

Command Syntax :SEARCh:SERial:USB:DATA:LENGTh <length>

<length> ::= data length between 1-20

The :SEARCh:SERial:USB:DATA:LENGTh command specifies the data length in bytes.

Query Syntax :SEARCh:SERial:USB:DATA:LENGTh?

The :SEARCh:SERial:USB:DATA:LENGTh? query returns the specified data length.

Return Format <length><NL>

<length> ::= data length between 1-20

See Also • [":SEARCh:SERial:USB:DATA"](#) on page 1370

:SEARCH:SERIAL:USB:ENDPOINT

N (see [page 1730](#))

Command Syntax :SEARCH:SERIAL:USB:ENDPOINT <string>

<string> ::= "0xn" where n ::= {0,...,9 | A,...,F | X | \$}

The :SEARCH:SERIAL:USB:ENDPOINT command specifies the 4-bit Endpoint portion of the search value, in hex.

Query Syntax :SEARCH:SERIAL:USB:ENDPOINT?

The :SEARCH:SERIAL:USB:ENDPOINT? query returns the specified Endpoint portion of the search value.

Return Format <string><NL>

<string> ::= "0xn" where n ::= {0,...,9 | A,...,F | X | \$}

- See Also**
- [":SEARCH:SERIAL:USB:PID:SPECIAL"](#) on page 1378
 - [":SEARCH:SERIAL:USB:PID:TOKEN"](#) on page 1379

:SEARCh:SERial:USB:ET

N (see [page 1730](#))

Command Syntax :SEARCh:SERial:USB:ET <string>

<string> ::= "0xn" where n ::= {0 | 1 | 2 | 3 | X | \$}

The :SEARCh:SERial:USB:ET command specifies the 2-bit ET portion of the search value, in hex.

Query Syntax :SEARCh:SERial:USB:ET?

The :SEARCh:SERial:USB:ET? query returns the specified ET portion of the search value.

Return Format <string><NL>

<string> ::= "0xn" where n ::= {0 | 1 | 2 | 3 | X | \$}

See Also • [":SEARCh:SERial:USB:PID:SPECial"](#) on page 1378

:SEARCH:SERIAL:USB:FRAME

N (see [page 1730](#))

Command Syntax :SEARCH:SERIAL:USB:FRAME <string>

<string> ::= "0xnnn" where n ::= {0,...,9 | A,...,F | X | \$}

The :SEARCH:SERIAL:USB:FRAME command specifies the 11-bit Frame portion of the search value, in hex.

Query Syntax :SEARCH:SERIAL:USB:FRAME?

The :SEARCH:SERIAL:USB:FRAME? query returns the specified Frame portion of the search value.

Return Format <string><NL>

<string> ::= "0xnnn" where n ::= {0,...,9 | A,...,F | X | \$}

See Also • [":SEARCH:SERIAL:USB:PID:TOKEN"](#) on page 1379

:SEARCh:SERial:USB:HADDress

N (see [page 1730](#))

Command Syntax :SEARCh:SERial:USB:HADDress <string>

<string> ::= "0xnn" where n ::= {0,...,9 | A,...,F | X | \$}

The :SEARCh:SERial:USB:HADDress command specifies the 7-bit Hub Address portion of the search value, in hex.

Query Syntax :SEARCh:SERial:USB:HADDress?

The :SEARCh:SERial:USB:HADDress? query returns the specified Hub Address portion of the search value.

Return Format <string><NL>

<string> ::= "0xnn" where n ::= {0,...,9 | A,...,F | X | \$}

See Also • [":SEARCh:SERial:USB:PID:SPECial"](#) on page 1378

:SEARCH:SERIAL:USB:PID:DATA

N (see [page 1730](#))

Command Syntax :SEARCH:SERIAL:USB:PID:DATA <pid>

<pid> ::= {DATA0 | DATA1 | DATA2 | MDATA}

The :SEARCH:SERIAL:USB:PID:DATA command specifies the USB data PID to find.

The DATA USB search mode can be selected using the :SEARCH:SERIAL:USB:MODE command.

Query Syntax :SEARCH:SERIAL:USB:PID:DATA?

The :SEARCH:SERIAL:USB:PID:DATA? query returns the specified data PID.

Return Format <pid><NL>

<pid> ::= {DATA0 | DATA1 | DATA2 | MDATA}

See Also • [":SEARCH:SERIAL:USB:MODE"](#) on page 1367

:SEARCh:SERial:USB:PID:HANDshake

N (see [page 1730](#))

Command Syntax :SEARCh:SERial:USB:PID:HANDshake <pid>

<pid> ::= {ACK | NAK | STAl1 | NYET}

The :SEARCh:SERial:USB:PID:HANDshake command specifies the USB handshake PID to find.

The HANDshake USB search mode can be selected using the :SEARCh:SERial:USB:MODE command.

Query Syntax :SEARCh:SERial:USB:PID:HANDshake?

The :SEARCh:SERial:USB:PID:HANDshake? query returns the specified handshake PID.

Return Format <pid><NL>

<pid> ::= {ACK | NAK | STAl | NYET}

See Also • [":SEARCh:SERial:USB:MODE"](#) on page 1367

:SEARCh:SERial:USB:PID:SPECial

N (see [page 1730](#))

Command Syntax :SEARCh:SERial:USB:PID:SPECial <pid>

<pid> ::= {PING | PRE | ERR | SPLit}

The :SEARCh:SERial:USB:PID:SPECial command specifies the USB special PID to find.

The SPECial USB search mode can be selected using the :SEARCh:SERial:USB:MODE command.

Query Syntax :SEARCh:SERial:USB:PID:SPECial?

The :SEARCh:SERial:USB:PID:SPECial? query returns the specified special PID.

Return Format <pid><NL>

<pid> ::= {PING | PRE | ERR | SPL}

See Also • [":SEARCh:SERial:USB:MODE"](#) on page 1367

:SEARCh:SERial:USB:PID:TOKEN

N (see [page 1730](#))

Command Syntax :SEARCh:SERial:USB:PID:TOKEN <pid>

<pid> ::= {OUT | IN | SETup | SOF}

The :SEARCh:SERial:USB:PID:TOKEN command specifies the USB token PID to find.

The TOKEN USB search mode can be selected using the :SEARCh:SERial:USB:MODE command.

Query Syntax :SEARCh:SERial:USB:PID:TOKEN?

The :SEARCh:SERial:USB:PID:TOKEN? query returns the specified token PID.

Return Format <pid><NL>

<pid> ::= {OUT | IN | SETup | SOF}

See Also • [":SEARCh:SERial:USB:MODE"](#) on page 1367

:SEARCH:SERIAL:USB:PORT

N (see [page 1730](#))

Command Syntax :SEARCH:SERIAL:USB:PORT <string>

<string> ::= "0xnn" where n ::= {0,...,9 | A,...,F | X | \$}

The :SEARCH:SERIAL:USB:PORT command specifies the 7-bit Port portion of the search value, in hex.

Query Syntax :SEARCH:SERIAL:USB:PORT?

The :SEARCH:SERIAL:USB:PORT? query returns the specified Port portion of the search value.

Return Format <string><NL>

<string> ::= "0xnn" where n ::= {0,...,9 | A,...,F | X | \$}

See Also • [":SEARCH:SERIAL:USB:PID:SPECIAL"](#) on page 1378

:SEARCh:SERial:USB:SC

N (see [page 1730](#))

Command Syntax :SEARCh:SERial:USB:SC <string>

<string> ::= "0xn" where n ::= {0 | 1 | X | \$}

The :SEARCh:SERial:USB:SC command specifies the 1-bit SC portion of the search value, in hex.

Query Syntax :SEARCh:SERial:USB:SC?

The :SEARCh:SERial:USB:SC? query returns the specified SC portion of the search value.

Return Format <string><NL>

<string> ::= "0xn" where n ::= {0 | 1 | X | \$}

See Also • [":SEARCh:SERial:USB:PID:SPECial"](#) on page 1378

:SEARCH:SERIAL:USB:SEU

N (see [page 1730](#))

Command Syntax :SEARCH:SERIAL:USB:SEU <string>

<string> ::= "0xn" where n ::= {0 | 1 | 2 | 3 | X | \$}

The :SEARCH:SERIAL:USB:SEU command specifies the 2-bit S and E or U portion of the search value, in hex.

Query Syntax :SEARCH:SERIAL:USB:SEU?

The :SEARCH:SERIAL:USB:SEU? query returns the specified S and E or U portion of the search value.

Return Format <string><NL>

<string> ::= "0xn" where n ::= {0 | 1 | 2 | 3 | X | \$}

See Also • [":SEARCH:SERIAL:USB:PID:SPECIAL"](#) on page 1378

39 :SYSTem Commands

Control basic system functions of the oscilloscope. See "[Introduction to :SYSTem Commands](#)" on page 1385.

Table 160 :SYSTem Commands Summary

Command	Query	Options and Query Returns
:SYSTem:DATE <date> (see page 1386)	:SYSTem:DATE? (see page 1386)	<date> ::= <year>,<month>,<day> <year> ::= 4-digit year in NR1 format <month> ::= {1,...,12 JANuary FEBruary MARCH APRil MAY JUNE JULy AUGust SEPTember OCTober NOVember DECember} <day> ::= {1,...31}
n/a	:SYSTem:DIDentifier? (see page 1387)	n/a
:SYSTem:DSP <string> (see page 1388)	n/a	<string> ::= up to 75 characters as a quoted ASCII string
n/a	:SYSTem:ERRor? (see page 1389)	<error> ::= an integer error code <error string> ::= quoted ASCII string. See Error Messages (see page 1669).
:SYSTem:LOCK {{1 ON} {0 OFF}} (see page 1390)	:SYSTem:LOCK? (see page 1390)	{1 0}
:SYSTem:PERSONa[:MANu facturer] <manufacturer_string> (see page 1391)	:SYSTem:PERSONa[:MANu facturer]? (see page 1391)	<manufacturer_string> ::= quoted ASCII string, up to 63 characters
:SYSTem:PERSONa[:MANu facturer]:DEFault (see page 1392)	n/a	Sets manufacturer string to "KEYSIGHT TECHNOLOGIES"

Table 160 :SYSTem Commands Summary (continued)

Command	Query	Options and Query Returns
:SYSTem:PRECision {{1 ON} {0 OFF}} (see page 1393)	:SYSTem:PRECision? (see page 1393)	{1 0}
:SYSTem:PRECision:LENGth <length> (see page 1394)	:SYSTem:PRECision:LENGth? (see page 1394)	<length> ::= between 100k and 1M points in NR1 format
:SYSTem:PRESet (see page 1395)	n/a	See :SYSTem:PRESet (see page 1395)
:SYSTem:PROTection:LOCK {{1 ON} {0 OFF}} (see page 1398)	:SYSTem:PROTection:LOCK? (see page 1398)	{1 0}
:SYSTem:RLOGger <setting>[, <file_name>[, <write_mode>]] (see page 1399)	n/a	<setting> ::= {{0 OFF} {1 ON}} <file_name> ::= quoted ASCII string <write_mode> ::= {CREate APPend}
:SYSTem:RLOGger:DESTination <dest> (see page 1400)	:SYSTem:RLOGger:DESTination? (see page 1400)	<dest> ::= {FILE SCReen BOTH}
:SYSTem:RLOGger:DISPlay {{0 OFF} {1 ON}} (see page 1401)	:SYSTem:RLOGger:DISPlay? (see page 1401)	<setting> ::= {0 1}
:SYSTem:RLOGger:FNAME <file_name> (see page 1402)	:SYSTem:RLOGger:FNAME? (see page 1402)	<file_name> ::= quoted ASCII string
:SYSTem:RLOGger:STATe {{0 OFF} {1 ON}} (see page 1403)	:SYSTem:RLOGger:STATe? (see page 1403)	<setting> ::= {0 1}
:SYSTem:RLOGger:TRANSPARENT {{0 OFF} {1 ON}} (see page 1404)	:SYSTem:RLOGger:TRANSPARENT? (see page 1404)	<setting> ::= {0 1}
:SYSTem:RLOGger:WMODe <write_mode> (see page 1405)	:SYSTem:RLOGger:WMODe? (see page 1405)	<write_mode> ::= {CREate APPend}
:SYSTem:SETup <setup_data> (see page 1406)	:SYSTem:SETup? (see page 1406)	<setup_data> ::= data in IEEE 488.2 # format.

Table 160 :SYSTem Commands Summary (continued)

Command	Query	Options and Query Returns
:SYSTem:TIME <time> (see page 1408)	:SYSTem:TIME? (see page 1408)	<time> ::= hours, minutes, seconds in NR1 format
:SYSTem:TOUCh {{1 ON} {0 OFF}} (see page 1409)	:SYSTem:TOUCh? (see page 1409)	{1 0}

Introduction to :SYSTem Commands SYSTem subsystem commands enable writing messages to the display, setting and reading both the time and the date, querying for errors, and saving and recalling setups.

:SYSTem:DATE

N (see [page 1730](#))

Command Syntax :SYSTem:DATE <date>

<date> ::= <year>,<month>,<day>

<year> ::= 4-digit year in NR1 format

<month> ::= {1,...,12 | JANuary | FEBruary | MARCH | APRil | MAY | JUNE
| JULy | AUGust | SEPTember | OCTober | NOVember | DECember}

<day> ::= {1,...,31}

The :SYSTem:DATE command sets the date. Validity checking is performed to ensure that the date is valid.

Query Syntax :SYSTem:DATE?

The SYSTem:DATE? query returns the date.

Return Format <year>,<month>,<day><NL>

- See Also**
- ["Introduction to :SYSTem Commands"](#) on page 1385
 - [":SYSTem:TIME"](#) on page 1408

:SYSTem:DIIdentifier

N (see [page 1730](#))

Query Syntax :SYSTem:DIIdentifier?

The :SYSTem:DIIdentifier? query returns the oscilloscope's Host ID as (part of) a quoted string.

The oscilloscope's Host ID is needed when redeeming licenses for oscilloscope upgrades or other licensed features.

The exact format of returned string are product-specific. This example returns the model number, serial number, and host ID in a comma-separated format:

```
"X12345A,US12345678,G1EFDNLPAF2YPLRN"
```

Portable programs should not attempt to parse the contents of the returned string. Use the *IDN? query instead to get the model number and/or serial number in a defined portable format.

Return Format <host_id><NL>

```
<host_id> ::= quoted ASCII string
```

See Also • ["*IDN \(Identification Number\)"](#) on page 240

:SYSTem:DSP

N (see [page 1730](#))

Command Syntax :SYSTem:DSP <string>

<string> ::= quoted ASCII string (up to 75 characters)

The :SYSTem:DSP command writes the quoted string (excluding quotation marks) to a text box on-screen.

Use :SYSTem:DSP "" to remotely remove the message from the display. (Two sets of quote marks without a space between them creates a NULL string.)

Press any menu key to manually remove the message from the display.

See Also • ["Introduction to :SYSTem Commands"](#) on page 1385

:SYSTem:ERRor

C (see [page 1730](#))

Query Syntax :SYSTem:ERRor?

The :SYSTem:ERRor? query outputs the next error number and text from the error queue. The instrument has an error queue that is 30 errors deep and operates on a first-in, first-out basis. Repeatedly sending the :SYSTem:ERRor? query returns the errors in the order that they occurred until the queue is empty. Any further queries then return zero until another error occurs.

When remote logging is enabled (using the oscilloscope's front panel), additional debug information can be included in the returned error string. If the error is detected by the SCPI command parser, such as a header error or other syntax error, the extra debug information is generated and included. But if the error is detected by the oscilloscope system, such as when an out-of-range value is sent, then no extra debug information is included.

Return Format

`<error number>,<error string><NL>`

`<error number> ::= an integer error code in NR1 format`

`<error string> ::= quoted ASCII string containing the error message`

Error messages are listed in [Chapter 46](#), "Error Messages," starting on page 1669.

See Also

- ["Introduction to :SYSTem Commands"](#) on page 1385
- ["*ESR \(Standard Event Status Register\)"](#) on page 238
- ["*CLS \(Clear Status\)"](#) on page 235

:SYSTem:LOCK

N (see [page 1730](#))

Command Syntax :SYSTem:LOCK <on_off>
 <on_off> ::= {{1 | ON} | {0 | OFF}}

The :SYSTem:LOCK command disables the front panel. LOCK ON is the equivalent of sending a local lockout message over the programming interface.

Query Syntax :SYSTem:LOCK?

The :SYSTem:LOCK? query returns the lock status of the front panel.

Return Format <on_off><NL>
 <on_off> ::= {1 | 0}

See Also • ["Introduction to :SYSTem Commands"](#) on page 1385

:SYSTem:PERSONa[:MANufacturer]

N (see [page 1730](#))

Command Syntax :SYSTem:PERSONa[:MANufacturer] <manufacturer_string>
 <manufacturer_string> ::= ::= quoted ASCII string, up to 63 characters

The :SYSTem:PERSONa[:MANufacturer] command lets you change the manufacturer string portion of the identification string returned by the *IDN? query.

The default manufacturer string is "KEYSIGHT TECHNOLOGIES".

If your remote programs depend on a legacy manufacturer string, for example, you could use this command to set the manufacturer string to "AGILENT TECHNOLOGIES".

Query Syntax :SYSTem:PERSONa[:MANufacturer]?

The :SYSTem:PERSONa[:MANufacturer]? query returns the currently set manufacturer string.

Return Format <manufacturer_string><NL>

- See Also**
- ["*IDN \(Identification Number\)"](#) on page 240
 - [":SYSTem:PERSONa\[:MANufacturer\]:DEFAULT"](#) on page 1392
 - ["Introduction to :SYSTem Commands"](#) on page 1385

:SYSTem:PERSONa[:MANufacturer]:DEFault

N (see [page 1730](#))

Command Syntax :SYSTem:PERSONa[:MANufacturer]:DEFault

The :SYSTem:PERSONa[:MANufacturer]:DEFault command sets the manufacturer string to "KEYSIGHT TECHNOLOGIES".

- See Also**
- ["*IDN \(Identification Number\)"](#) on page 240
 - [":SYSTem:PERSONa\[:MANufacturer\]"](#) on page 1391
 - ["Introduction to :SYSTem Commands"](#) on page 1385

:SYSTEM:PRECision

N (see [page 1730](#))

Command Syntax :SYSTEM:PRECision <on_off>
 <on_off> ::= {{1 | ON} | {0 | OFF}}

The :SYSTEM:PRECision command turns the oscilloscope's precision analysis setting on or off.

- OFF (0) – provides the maximum oscilloscope waveform update rate by performing measurements and math functions on the default 65535-point (maximum) *measurement record*.
- ON (1) – at the expense of oscilloscope waveform update rate, this setting allows measurements and math functions to be performed on a longer, *precision analysis record* (see [":WAVEform:POINTS:MODE"](#) on page 1528).

The length of the precision analysis record is specified by the :SYSTEM:PRECision:LENGth command.

The precision analysis setting is OFF after a *RST command.

Precision analysis is not available when:

- Realtime sampling mode is off.
- Averaging acquisition modes is selected.
- XY or Roll time modes are selected.

Query Syntax :SYSTEM:PRECision?

The :SYSTEM:PRECision? query returns the current precision analysis setting.

Return Format <on_off><NL>
 <on_off> ::= {1 | 0}

- See Also**
- ["Introduction to :SYSTEM Commands"](#) on page 1385
 - [":SYSTEM:PRECision:LENGth"](#) on page 1394
 - [":WAVEform:POINTS:MODE"](#) on page 1528
 - ["*RST \(Reset\)"](#) on page 246

:SYSTem:PRECision:LENGth

N (see [page 1730](#))

Command Syntax :SYSTem:PRECision:LENGth <length>

<length> ::= between 100k and 1M points in NR1 format

The :SYSTem:PRECision:LENGth command specifies the length of the precision analysis record (when precision measurements and math functions mode is enabled). You can specify between 100k and 1M points.

Query Syntax :SYSTem:PRECision:LENGth?

The :SYSTem:PRECision:LENGth? query returns the current precision analysis record length setting.

Return Format <length><NL>

<length> ::= between 100k and 1M points in NR1 format

- See Also**
- ["Introduction to :SYSTem Commands"](#) on page 1385
 - [":SYSTem:PRECision"](#) on page 1393
 - [":WAVEform:POINts:MODE"](#) on page 1528
 - ["*RST \(Reset\)"](#) on page 246

:SYSTem:PRESet

C (see [page 1730](#))

Command Syntax :SYSTem:PRESet

The :SYSTem:PRESet command places the instrument in a known state. This is the same as pressing the **[Default Setup]** key or **[Save/Recall] > Default/Erse > Default Setup** on the front panel.

When you perform a default setup, some user settings (like preferences) remain unchanged. To reset all user settings to their factory defaults, use the *RST command.

Reset conditions are:

Acquire Menu	
Mode	Normal
Averaging	Off
# Averages	8

Analog Channel Menu	
Channel 1	On
Channel 2	Off
Volts/division	5.00 V
Offset	0.00
Coupling	DC
Probe attenuation	10:1
Vernier	Off
Invert	Off
BW limit	Off
Impedance	1 M Ohm (cannot be changed)
Units	Volts
Skew	0

Cursor Menu	
Source	Channel 1

Digital Channel Menu (MSO models only)	
Channel 0 - 7	Off
Labels	Off
Threshold	TTL (1.4 V)

Display Menu	
Persistence	Off
Grid	20%

Quick Meas Menu	
Source	Channel 1

Run Control	
	Scope is running

Time Base Menu	
Main time/division	100 us
Main time base delay	0.00 s
Delay time/division	500 ns
Delay time base delay	0.00 s
Reference	center
Mode	main
Vernier	Off

Trigger Menu	
Type	Edge
Mode	Auto
Coupling	dc
Source	Channel 1
Level	0.0 V
Slope	Positive

Trigger Menu	
HF Reject and noise reject	Off
Holdoff	40 ns
External probe attenuation	10:1
External Units	Volts
External Impedance	1 M Ohm (cannot be changed)

- See Also
- ["Introduction to Common \(*\) Commands"](#) on page 233
 - ["*RST \(Reset\)"](#) on page 246

:SYSTem:PROTection:LOCK

N (see [page 1730](#))

Command Syntax :SYSTem:PROTection:LOCK <on_off>
 <on_off> ::= {{1 | ON} | {0 | OFF}}

The :SYSTem:PROTection:LOCK command disables the fifty ohm impedance setting for all analog channels.

NOTE

Be careful when turning ON the :SYSTem:PROTection:LOCK because there is no visual indication of this setting in the front-panel user interface (other than a disabled 50 Ω channel input impedance selection), and a user could think the oscilloscope is not working properly.

Query Syntax :SYSTem:PROTection:LOCK?

The :SYSTem:PROTection:LOCK? query returns the analog channel protection lock status.

Return Format <on_off><NL>
 <on_off> ::= {1 | 0}

See Also • ["Introduction to :SYSTem Commands"](#) on page 1385

:SYSTem:RLOGger

N (see [page 1730](#))

Command Syntax :SYSTem:RLOGger <setting>[,<file_name>[,<write_mode>]]

<setting> ::= {{0 | OFF} | {1 | ON}}

<file_name> ::= quoted ASCII string

<write_mode> ::= {CREate | APPend}

The :SYSTem:RLOGger command enables or disables remote command logging, optionally specifying the log file name and write mode.

- See Also**
- [":SYSTem:RLOGger:DESTination"](#) on page 1400
 - [":SYSTem:RLOGger:DISPlay"](#) on page 1401
 - [":SYSTem:RLOGger:FNAME"](#) on page 1402
 - [":SYSTem:RLOGger:STATE"](#) on page 1403
 - [":SYSTem:RLOGger:TRANSPARENT"](#) on page 1404
 - [":SYSTem:RLOGger:WMODE"](#) on page 1405

:SYSTem:RLOGger:DESTination

N (see [page 1730](#))

Command Syntax :SYSTem:RLOGger:DESTination <dest>

<dest> ::= {FILE | SCReen | BOTH}

The :SYSTem:RLOGger:DESTination command specifies whether remote commands are logged to a text file (on a connected USB storage device), logged to the screen, or both.

NOTE

If the destination is changed while remote command logging is running, remote command logging is turned off.

Query Syntax :SYSTem:RLOGger:DESTination?

The :SYSTem:RLOGger:DESTination? query returns the remote command logging destination.

Return Format <dest><NL>

<dest> ::= {FILE | SCR | BOTH}

- See Also**
- [":SYSTem:RLOGger"](#) on page 1399
 - [":SYSTem:RLOGger:DISPlay"](#) on page 1401
 - [":SYSTem:RLOGger:FNAME"](#) on page 1402
 - [":SYSTem:RLOGger:STATE"](#) on page 1403
 - [":SYSTem:RLOGger:TRANSPARENT"](#) on page 1404
 - [":SYSTem:RLOGger:WMODe"](#) on page 1405

:SYSTem:RLOGger:DISPlay

N (see [page 1730](#))

Command Syntax :SYSTem:RLOGger:DISPlay {{0 | OFF} | {1 | ON}}

The :SYSTem:RLOGger:DISPlay command enables or disables the screen display of logged remote commands and their return values (if applicable).

Query Syntax :SYSTem:RLOGger:DISPlay?

The :SYSTem:RLOGger:DISPlay? query returns whether the screen display for remote command logging is enabled or disabled.

Return Format <setting><NL>
<setting> ::= {0 | 1}

- See Also**
- [":SYSTem:RLOGger"](#) on page 1399
 - [":SYSTem:RLOGger:DESTination"](#) on page 1400
 - [":SYSTem:RLOGger:FNAME"](#) on page 1402
 - [":SYSTem:RLOGger:STATE"](#) on page 1403
 - [":SYSTem:RLOGger:TRANSPARENT"](#) on page 1404
 - [":SYSTem:RLOGger:WMODE"](#) on page 1405

:SYSTem:RLOGger:FNAME

N (see [page 1730](#))

Command Syntax :SYSTem:RLOGger:FNAME <file_name>
 <file_name> ::= quoted ASCII string

The :SYSTem:RLOGger:FNAME command specifies the remote command log file name.

Because log files are ASCII text files, the ".txt" extension is automatically added to the name specified.

Query Syntax :SYSTem:RLOGger:FNAME?

The :SYSTem:RLOGger:FNAME? query returns the remote command log file name.

Return Format <file_name><NL>

- See Also**
- [":SYSTem:RLOGger"](#) on page 1399
 - [":SYSTem:RLOGger:DESTination"](#) on page 1400
 - [":SYSTem:RLOGger:DISPlay"](#) on page 1401
 - [":SYSTem:RLOGger:STAtE"](#) on page 1403
 - [":SYSTem:RLOGger:TRANSPARENT"](#) on page 1404
 - [":SYSTem:RLOGger:WMODe"](#) on page 1405

:SYSTem:RLOGger:STATe

N (see [page 1730](#))

Command Syntax :SYSTem:RLOGger:STATe {{0 | OFF} | {1 | ON}}

The :SYSTem:RLOGger:STATe command enables or disables remote command logging.

Query Syntax :SYSTem:RLOGger:STATe?

The :SYSTem:RLOGger:STATe? query returns the remote command logging state.

Return Format <setting><NL>

<setting> ::= {0 | 1}

- See Also**
- [":SYSTem:RLOGger"](#) on page 1399
 - [":SYSTem:RLOGger:DESTination"](#) on page 1400
 - [":SYSTem:RLOGger:DISPlay"](#) on page 1401
 - [":SYSTem:RLOGger:FNAME"](#) on page 1402
 - [":SYSTem:RLOGger:TRANSPARENT"](#) on page 1404
 - [":SYSTem:RLOGger:WMODE"](#) on page 1405

:SYSTem:RLOGger:TRANSPARENT

N (see [page 1730](#))

Command Syntax :SYSTem:RLOGger:TRANSPARENT {{0 | OFF} | {1 | ON}}

The :SYSTem:RLOGger:TRANSPARENT command specifies whether the screen display background for remote command logging is transparent or solid.

Query Syntax :SYSTem:RLOGger:TRANSPARENT?

The :SYSTem:RLOGger:TRANSPARENT? query returns the setting for transparent screen display background.

Return Format <setting><NL>
<setting> ::= {0 | 1}

- See Also**
- [":SYSTem:RLOGger"](#) on page 1399
 - [":SYSTem:RLOGger:DESTination"](#) on page 1400
 - [":SYSTem:RLOGger:DISPlay"](#) on page 1401
 - [":SYSTem:RLOGger:FNAME"](#) on page 1402
 - [":SYSTem:RLOGger:STATE"](#) on page 1403
 - [":SYSTem:RLOGger:WMODE"](#) on page 1405

:SYSTem:RLOGger:WMODe

N (see [page 1730](#))

Command Syntax :SYSTem:RLOGger:WMODe <write_mode>
 <write_mode> ::= {CREate | APPend}

The :SYSTem:RLOGger:WMODe command specifies the remote command logging write mode.

Query Syntax :SYSTem:RLOGger:WMODe?

The :SYSTem:RLOGger:WMODe? query returns the remote command logging write mode.

Return Format <write_mode><NL>
 <write_mode> ::= {CRE | APP}

- See Also**
- [":SYSTem:RLOGger"](#) on page 1399
 - [":SYSTem:RLOGger:DESTination"](#) on page 1400
 - [":SYSTem:RLOGger:DISPlay"](#) on page 1401
 - [":SYSTem:RLOGger:FNAME"](#) on page 1402
 - [":SYSTem:RLOGger:STATE"](#) on page 1403
 - [":SYSTem:RLOGger:TRANSPARENT"](#) on page 1404

:SYSTem:SETup

C (see [page 1730](#))

Command Syntax :SYSTem:SETup <setup_data>
<setup_data> ::= binary block data in IEEE 488.2 # format.

The :SYSTem:SETup command sets the oscilloscope as defined by the data in the setup (learn) string sent from the controller. The setup string does not change the interface mode or interface address.

Query Syntax :SYSTem:SETup?

The :SYSTem:SETup? query operates the same as the *LRN? query. It outputs the current oscilloscope setup in the form of a learn string to the controller. The setup (learn) string is sent and received as a binary block of data. The format for the data transmission is the # format defined in the IEEE 488.2 specification.

Return Format <setup_data><NL>
<setup_data> ::= binary block data in IEEE 488.2 # format

- See Also**
- ["Introduction to :SYSTEM Commands"](#) on page 1385
 - ["*LRN \(Learn Device Setup\)"](#) on page 241

Example Code

```
' SAVE_SYSTEM_SETUP - The :SYSTEM:SETUP? query returns a program
' message that contains the current state of the instrument. Its
' format is a definite-length binary block, for example,
' #800075595<setup string><NL>
' where the setup string is 75595 bytes in length.
myScope.WriteString ":SYSTEM:SETUP?"
varQueryResult = myScope.ReadIEEEBlock(BinaryType_UI1)
CheckForInstrumentErrors ' After reading query results.

' Output setup string to a file:
Dim strPath As String
strPath = "c:\scope\config\setup.dat"

' Open file for output.
Close #1 ' If #1 is open, close it.
Open strPath For Binary Access Write Lock Write As #1
Put #1, , varQueryResult ' Write data.
Close #1 ' Close file.

' RESTORE_SYSTEM_SETUP - Read the setup string from a file and
' write it back to the oscilloscope.
Dim varSetupString As Variant
strPath = "c:\scope\config\setup.dat"

' Open file for input.
Open strPath For Binary Access Read As #1
Get #1, , varSetupString ' Read data.
Close #1 ' Close file.
```

```
' Write setup string back to oscilloscope using ":SYSTEM:SETUP"  
' command:  
myScope.WriteIEEEBlock ":SYSTEM:SETUP ", varSetupString  
CheckForInstrumentErrors
```

See complete example programs at: [Chapter 50](#), "Programming Examples," starting on page 1739

:SYSTem:TIME

N (see [page 1730](#))

Command Syntax :SYSTem:TIME <time>

<time> ::= hours,minutes,seconds in NR1 format

The :SYSTem:TIME command sets the system time, using a 24-hour format. Commas are used as separators. Validity checking is performed to ensure that the time is valid.

Query Syntax :SYSTem:TIME? <time>

The :SYSTem:TIME? query returns the current system time.

Return Format <time><NL>

<time> ::= hours,minutes,seconds in NR1 format

- See Also**
- ["Introduction to :SYSTem Commands"](#) on page 1385
 - [":SYSTem:DATE"](#) on page 1386

:SYSTem:TOUCh

N (see [page 1730](#))

Command Syntax :SYSTem:TOUCh <on_off>

<on_off> ::= {{1 | ON} | {0 | OFF}}

The :SYSTem:TOUCh command disables or enables the touchscreen.

Query Syntax :SYSTem:TOUCh?

The :SYSTem:TOUCh? query returns the touchscreen's on/off status.

Return Format <on_off><NL>

<on_off> ::= {1 | 0}

See Also · ["Introduction to :SYSTem Commands"](#) on page 1385

40 :TIMebase Commands

Control all horizontal sweep functions. See "[Introduction to :TIMebase Commands](#)" on page 1412.

Table 161 :TIMebase Commands Summary

Command	Query	Options and Query Returns
:TIMebase:MODE <value> (see page 1413)	:TIMebase:MODE? (see page 1413)	<value> ::= {MAIN WINDow XY ROLL}
:TIMebase:POSition <pos> (see page 1414)	:TIMebase:POSition? (see page 1414)	<pos> ::= time from the trigger event to the display reference point in NR3 format
:TIMebase:RANGe <range_value> (see page 1415)	:TIMebase:RANGe? (see page 1415)	<range_value> ::= time for 10 div in seconds in NR3 format
:TIMebase:REFClock {0 OFF} {1 ON} (see page 1416)	:TIMebase:REFClock? (see page 1416)	{0 1}
:TIMebase:REFerence {LEFT CENTer RIGHT CUSTom} (see page 1417)	:TIMebase:REFerence? (see page 1417)	<return_value> ::= {LEFT CENTer RIGHT CUSTom}
:TIMebase:REFerence:LOCation <loc> (see page 1418)	:TIMebase:REFerence:LOCation? (see page 1418)	<loc> ::= 0.0 to 1.0 in NR3 format
:TIMebase:SCALe <scale_value> (see page 1419)	:TIMebase:SCALe? (see page 1419)	<scale_value> ::= time/div in seconds in NR3 format
:TIMebase:VERNier {0 OFF} {1 ON} (see page 1420)	:TIMebase:VERNier? (see page 1420)	{0 1}
:TIMebase:WINDow:POSition <pos> (see page 1421)	:TIMebase:WINDow:POSition? (see page 1421)	<pos> ::= time from the trigger event to the zoomed view reference point in NR3 format

Table 161 :TIMebase Commands Summary (continued)

Command	Query	Options and Query Returns
:TIMebase:WINDow:RANGe <range_value> (see page 1422)	:TIMebase:WINDow:RANGe? (see page 1422)	<range_value> ::= range value in seconds in NR3 format for the zoomed window
:TIMebase:WINDow:SCALe <scale_value> (see page 1423)	:TIMebase:WINDow:SCALe? (see page 1423)	<scale_value> ::= scale value in seconds in NR3 format for the zoomed window

Introduction to :TIMebase Commands The TIMebase subsystem commands control the horizontal (X-axis) functions and set the oscilloscope to X-Y mode (where channel 1 becomes the X input and channel 2 becomes the Y input). The time per division, delay, vernier control, and reference can be controlled for the main and window (zoomed) time bases.

Reporting the Setup

Use :TIMebase? to query setup information for the TIMebase subsystem.

Return Format

The following is a sample response from the :TIMebase? query. In this case, the query was issued following a *RST command.

```
:TIM:MODE MAIN;REF CENT;MAIN:RANG +1.00E-03;POS +0.0E+00
```

:TIMEbase:MODE

C (see [page 1730](#))

Command Syntax :TIMEbase:MODE <value>
 <value> ::= {MAIN | WINDow | XY | ROLL}

The :TIMEbase:MODE command sets the current time base. There are four time base modes:

- MAIN – The normal time base mode is the main time base. It is the default time base mode after the *RST (Reset) command.
- WINDow – In the WINDow (zoomed or delayed) time base mode, measurements are made in the zoomed time base if possible; otherwise, the measurements are made in the main time base.
- XY – In the XY mode, the :TIMEbase:RANGe, :TIMEbase:POSition, and :TIMEbase:REFerence commands are not available. No measurements are available in this mode.
- ROLL – In the ROLL mode, data moves continuously across the display from left to right. The oscilloscope runs continuously and is untriggered. The :TIMEbase:REFerence selection changes to RIGHT.

Query Syntax :TIMEbase:MODE?

The :TIMEbase:MODE query returns the current time base mode.

Return Format <value><NL>
 <value> ::= {MAIN | WIND | XY | ROLL}

- See Also**
- ["Introduction to :TIMEbase Commands"](#) on page 1412
 - ["*RST \(Reset\)"](#) on page 246
 - [":TIMEbase:RANGe"](#) on page 1415
 - [":TIMEbase:POSition"](#) on page 1414
 - [":TIMEbase:REFerence"](#) on page 1417

Example Code

```
' TIMEBASE_MODE - (not executed in this example)
' Set the time base mode to MAIN, DELAYED, XY, or ROLL.

' Set time base mode to main.
myScope.WriteString ":TIMEBASE:MODE MAIN"
```

See complete example programs at: [Chapter 50](#), "Programming Examples," starting on page 1739

:TIMebase:POSition

C (see [page 1730](#))

Command Syntax :TIMebase:POSition <pos>

<pos> ::= time in seconds from the trigger to the display reference
in NR3 format

The :TIMebase:POSition command sets the time interval between the trigger event and the display reference point on the screen. The display reference point is either left, right, or center and is set with the :TIMebase:REFerence command. The maximum position value depends on the time/division settings.

NOTE

This command is an alias for the :TIMebase:DELay command.

Query Syntax :TIMebase:POSition?

The :TIMebase:POSition? query returns the current time from the trigger to the display reference in seconds.

Return Format <pos><NL>

<pos> ::= time in seconds from the trigger to the display reference
in NR3 format

- See Also**
- ["Introduction to :TIMebase Commands"](#) on page 1412
 - [":TIMebase:REFerence"](#) on page 1417
 - [":TIMebase:RANGe"](#) on page 1415
 - [":TIMebase:SCALe"](#) on page 1419
 - [":TIMebase:WINDow:POSition"](#) on page 1421
 - [":TIMebase:DELay"](#) on page 1666

:TIMebase:RANGe

C (see [page 1730](#))

Command Syntax :TIMebase:RANGe <range_value>

<range_value> ::= time for 10 div in seconds in NR3 format

The :TIMebase:RANGe command sets the full-scale horizontal time in seconds for the main window. The range is 10 times the current time-per-division setting.

Query Syntax :TIMebase:RANGe?

The :TIMebase:RANGe query returns the current full-scale range value for the main window.

Return Format <range_value><NL>

<range_value> ::= time for 10 div in seconds in NR3 format

- See Also**
- ["Introduction to :TIMebase Commands"](#) on page 1412
 - [":TIMebase:MODE"](#) on page 1413
 - [":TIMebase:SCALE"](#) on page 1419
 - [":TIMebase:WINDow:RANGe"](#) on page 1422

Example Code

```
' TIME_RANGE - Sets the full scale horizontal time in seconds. The
' range value is 10 times the time per division.
myScope.WriteString ":TIM:RANG 2e-3" ' Set the time range to 0.002
seconds.
```

See complete example programs at: [Chapter 50](#), "Programming Examples," starting on page 1739

:TIMebase:REFClock

N (see [page 1730](#))

Command Syntax :TIMebase:REFClock <value>
 <value> ::= {{1 | ON} | {0 | OFF}}

The :TIMebase:REFClock command enables or disables the 10 MHz REF BNC located on the rear panel of the oscilloscope.

The 10 MHz REF BNC can be used as an input for the oscilloscope's reference clock (instead of the internal 10 MHz reference), or it can be used to output the internal 10 MHz reference clock when synchronizing multiple instruments (see [":ACQuire:RSIGnal"](#) on page 311).

The :TIMebase:REFClock ON command enables the 10 MHz REF BNC and sets the reference signal mode to IN. The :TIMebase:REFClock OFF command disables the 10 MHz REF BNC (the same as setting the reference signal mode to OFF).

Query Syntax :TIMebase:REFClock?

The :TIMebase:REFClock? query returns the current state of the 10 MHz reference signal mode. A "1" indicates that the 10 MHz REF input is enabled (on), and a "0" indicates that either the 10 MHz REF BNC is disabled (off) or that it is set as an output (by the :ACQuire:RSIGnal command).

Return Format <value><NL>
 <value> ::= {0 | 1}

See Also • [":ACQuire:RSIGnal"](#) on page 311

:TIMebase:REFeRence

C (see [page 1730](#))

Command Syntax :TIMebase:REFeRence <reference>

<reference> ::= {LEFT | CENTer | RIGHT | CUSTom}

The :TIMebase:REFeRence command sets the time reference to:

- LEFT – one division from the left side of the screen.
- CENTer – the center of the screen.
- RIGHT – one division from the right side of the screen.
- CUSTom – lets you use the :TIMebase:REFeRence:LOCation command to place the time reference location at a percent of the graticule width (where 0.0 is the left edge and 1.0 is the right edge).

The time reference is the point on the display where the trigger point is referenced.

Query Syntax :TIMebase:REFeRence?

The :TIMebase:REFeRence? query returns the current display reference for the main window.

Return Format <reference><NL>

<reference> ::= {LEFT | CENT | RIGH | CUST}

- See Also**
- ["Introduction to :TIMebase Commands"](#) on page 1412
 - [":TIMebase:REFeRence:LOCation"](#) on page 1418
 - [":TIMebase:MODE"](#) on page 1413

Example Code

```
myScope.WriteString ":TIMebase:REFeRence CENTER" ' Set reference to center.
```

See complete example programs at: [Chapter 50](#), "Programming Examples," starting on page 1739

:TIMebase:REFerence:LOCation

N (see [page 1730](#))

Command Syntax :TIMebase:REFerence:LOCation <loc>

<loc> ::= 0.0 to 1.0 in NR3 format

When the :TIMebase:REFerence is set to CUSTom, the :TIMebase:REFerence:LOCation command lets you place the time reference location at a percent of the graticule width (where 0.0 is the left edge and 1.0 is the right edge).

Query Syntax :TIMebase:REFerence:LOCation?

The :TIMebase:REFerence:LOCation? query returns the time base reference custom location setting.

Return Format <loc><NL>

<loc> ::= 0.0 to 1.0 in NR3 format

See Also • [":TIMebase:REFerence"](#) on page 1417

:TIMEbase:SCALE

N (see [page 1730](#))

Command Syntax :TIMEbase:SCALE <scale_value>

<scale_value> ::= time/div in seconds in NR3 format

The :TIMEbase:SCALE command sets the horizontal scale or units per division for the main window.

Query Syntax :TIMEbase:SCALE?

The :TIMEbase:SCALE? query returns the current horizontal scale setting in seconds per division for the main window.

Return Format <scale_value><NL>

<scale_value> ::= time/div in seconds in NR3 format

- See Also**
- ["Introduction to :TIMEbase Commands"](#) on page 1412
 - [":TIMEbase:RANGe"](#) on page 1415
 - [":TIMEbase:WINDow:SCALE"](#) on page 1423
 - [":TIMEbase:WINDow:RANGe"](#) on page 1422

:TIMEbase:VERNier

N (see [page 1730](#))

Command Syntax :TIMEbase:VERNier <vernier value>

<vernier value> ::= {{1 | ON} | {0 | OFF}}

The :TIMEbase:VERNier command specifies whether the time base control's vernier (fine horizontal adjustment) setting is ON (1) or OFF (0).

Query Syntax :TIMEbase:VERNier?

The :TIMEbase:VERNier? query returns the current state of the time base control's vernier setting.

Return Format <vernier value><NL>

<vernier value> ::= {0 | 1}

See Also • ["Introduction to :TIMEbase Commands"](#) on page 1412

:TIMebase:WINDow:POSition

C (see [page 1730](#))

Command Syntax :TIMebase:WINDow:POSition <pos value>

<pos value> ::= time from the trigger event to the zoomed (delayed) view reference point in NR3 format

The :TIMebase:WINDow:POSition command sets the horizontal position in the zoomed (delayed) view of the main sweep. The main sweep range and the main sweep horizontal position determine the range for this command. The value for this command must keep the zoomed view window within the main sweep range.

Query Syntax :TIMebase:WINDow:POSition?

The :TIMebase:WINDow:POSition? query returns the current horizontal window position setting in the zoomed view.

Return Format <value><NL>

<value> ::= position value in seconds

- See Also**
- ["Introduction to :TIMebase Commands"](#) on page 1412
 - [":TIMebase:MODE"](#) on page 1413
 - [":TIMebase:POSition"](#) on page 1414
 - [":TIMebase:RANGe"](#) on page 1415
 - [":TIMebase:SCALE"](#) on page 1419
 - [":TIMebase:WINDow:RANGe"](#) on page 1422
 - [":TIMebase:WINDow:SCALE"](#) on page 1423

:TIMebase:WINDow:RANGe

C (see [page 1730](#))

Command Syntax :TIMebase:WINDow:RANGe <range value>

<range value> ::= range value in seconds in NR3 format

The :TIMebase:WINDow:RANGe command sets the full-scale horizontal time in seconds for the zoomed (delayed) window. The range is 10 times the current zoomed view window seconds per division setting. The main sweep range determines the range for this command. The maximum value is one half of the :TIMebase:RANGe value.

Query Syntax :TIMebase:WINDow:RANGe?

The :TIMebase:WINDow:RANGe? query returns the current window timebase range setting.

Return Format <value><NL>

<value> ::= range value in seconds

- See Also**
- ["Introduction to :TIMebase Commands"](#) on page 1412
 - [":TIMebase:RANGe"](#) on page 1415
 - [":TIMebase:POSition"](#) on page 1414
 - [":TIMebase:SCALe"](#) on page 1419

:TIMebase:WINDow:SCALE

N (see [page 1730](#))

Command Syntax :TIMebase:WINDow:SCALE <scale_value>

<scale_value> ::= scale value in seconds in NR3 format

The :TIMebase:WINDow:SCALE command sets the zoomed (delayed) window horizontal scale (seconds/division). The main sweep scale determines the range for this command. The maximum value is one half of the :TIMebase:SCALE value.

Query Syntax :TIMebase:WINDow:SCALE?

The :TIMebase:WINDow:SCALE? query returns the current zoomed window scale setting.

Return Format <scale_value><NL>

<scale_value> ::= current seconds per division for the zoomed window

- See Also**
- ["Introduction to :TIMebase Commands"](#) on page 1412
 - [":TIMebase:RANGe"](#) on page 1415
 - [":TIMebase:POSition"](#) on page 1414
 - [":TIMebase:SCALE"](#) on page 1419
 - [":TIMebase:WINDow:RANGe"](#) on page 1422

41 :TRIGger Commands

Control the trigger modes and parameters for each trigger type. See:

- "[Introduction to :TRIGger Commands](#)" on page 1425
- "[General :TRIGger Commands](#)" on page 1427
- "[:TRIGger:DELAy Commands](#)" on page 1442
- "[:TRIGger:EBURst Commands](#)" on page 1449
- "[:TRIGger\[:EDGE\] Commands](#)" on page 1454
- "[:TRIGger:GLITCh Commands](#)" on page 1461 (Pulse Width trigger)
- "[:TRIGger:OR Commands](#)" on page 1470
- "[:TRIGger:PATtern Commands](#)" on page 1472
- "[:TRIGger:RUNT Commands](#)" on page 1480
- "[:TRIGger:SHOLd Commands](#)" on page 1485
- "[:TRIGger:TRANSition Commands](#)" on page 1491
- "[:TRIGger:TV Commands](#)" on page 1496
- "[:TRIGger:ZONE Commands](#)" on page 1506

Introduction to :TRIGger Commands

The commands in the TRIGger subsystem define the conditions for an internal trigger. Many of these commands are valid in multiple trigger modes.

The default trigger mode is :EDGE.

The trigger subsystem controls the trigger sweep mode and the trigger specification. The trigger sweep (see "[:TRIGger:SWEep](#)" on page 1441) can be AUTO or NORMAl.

- **NORMAl** mode – displays a waveform only if a trigger signal is present and the trigger conditions are met. Otherwise the oscilloscope does not trigger and the display is not updated. This mode is useful for low-repetitive-rate signals.
- **AUTO** trigger mode – generates an artificial trigger event if the trigger specification is not satisfied within a preset time, acquires unsynchronized data and displays it.

AUTO mode is useful for signals other than low-repetitive-rate signals. You must use this mode to display a DC signal because there are no edges on which to trigger.

The following trigger types are available (see "**:TRIGger:MODE**" on page 1439).

- **Edge triggering** – identifies a trigger by looking for a specified slope and voltage level on a waveform.
- **Nth Edge Burst triggering** – lets you trigger on the Nth edge of a burst that occurs after an idle time.
- **Pulse width triggering** – (:TRIGger:GLITCh commands) sets the oscilloscope to trigger on a positive pulse or on a negative pulse of a specified width.
- **Pattern triggering** – identifies a trigger condition by looking for a specified pattern. This pattern is a logical AND combination of the channels. You can also trigger on a specified time duration of a pattern.
- **TV triggering** – is used to capture the complicated waveforms of television equipment. The trigger circuitry detects the vertical and horizontal interval of the waveform and produces triggers based on the TV trigger settings you selected. TV triggering requires greater than ¼ division of sync amplitude with any analog channel as the trigger source.
- **USB (Universal Serial Bus) triggering** – will trigger on a Start of Packet (SOP), End of Packet (EOP), Reset Complete, Enter Suspend, or Exit Suspend signal on the differential USB data lines. USB Low Speed and Full Speed are supported by this trigger.

Reporting the Setup

Use :TRIGger? to query setup information for the TRIGger subsystem.

Return Format

The return format for the TRIGger? query varies depending on the current mode. The following is a sample response from the :TRIGger? query. In this case, the query was issued following a *RST command.

```
:TRIG:MODE EDGE;SWE AUTO;NREJ 0;HFR 0;HOLD +60.0000000000000E-09;
:TRIG:EDGE:SOUR CHAN1;LEV +0.00000E+00;SLOP POS;REJ OFF;COUP DC;
:TRIG:ZONE:STAT 0
```

General :TRIGger Commands

Table 162 General :TRIGger Commands Summary

Command	Query	Options and Query Returns
:TRIGger:FORCe (see page 1429)	n/a	n/a
:TRIGger:HFReject {{0 OFF} {1 ON}} (see page 1430)	:TRIGger:HFReject? (see page 1430)	{0 1}
:TRIGger:HOLDoff <holdoff_time> (see page 1431)	:TRIGger:HOLDoff? (see page 1431)	<holdoff_time> ::= 40 ns to 10 s in NR3 format
:TRIGger:HOLDoff:MAXimum <max_holdoff> (see page 1432)	:TRIGger:HOLDoff:MAXimum? (see page 1432)	<max_holdoff> ::= maximum holdoff time in seconds in NR3 format
:TRIGger:HOLDoff:MINimum <min_holdoff> (see page 1433)	:TRIGger:HOLDoff:MINimum? (see page 1433)	<min_holdoff> ::= minimum holdoff time in seconds in NR3 format
:TRIGger:HOLDoff:RANDOM {{0 OFF} {1 ON}} (see page 1434)	:TRIGger:HOLDoff:RANDOM? (see page 1434)	<setting> ::= {0 1}
:TRIGger:JFRee {{0 OFF} {1 ON}} (see page 1435)	:TRIGger:JFRee? (see page 1435)	{0 1}
:TRIGger:LEVel:ASETup (see page 1436)	n/a	n/a
:TRIGger:LEVel:HIGH <level>, <source> (see page 1437)	:TRIGger:LEVel:HIGH? <source> (see page 1437)	<level> ::= .75 x full-scale voltage from center screen in NR3 format. <source> ::= CHANNEL<n> <n> ::= 1 to (# analog channels) in NR1 format
:TRIGger:LEVel:LOW <level>, <source> (see page 1438)	:TRIGger:LEVel:LOW? <source> (see page 1438)	<level> ::= .75 x full-scale voltage from center screen in NR3 format. <source> ::= CHANNEL<n> <n> ::= 1 to (# analog channels) in NR1 format

Table 162 General :TRIGger Commands Summary (continued)

Command	Query	Options and Query Returns
:TRIGger:MODE <mode> (see page 1439)	:TRIGger:MODE? (see page 1439)	<mode> ::= {EDGE GLITCh PATTern TV DELay EBURst OR RUNT SHOLd TRANSition SBUS{1 2}} <return_value> ::= {<mode> <none>} <none> ::= query returns "NONE" if the :TIMEbase:MODE is ROLL or XY
:TRIGger:NREJect {{0 OFF} {1 ON}} (see page 1440)	:TRIGger:NREJect? (see page 1440)	{0 1}
:TRIGger:SWEep <sweep> (see page 1441)	:TRIGger:SWEep? (see page 1441)	<sweep> ::= {AUTO NORMal}

:TRIGger:FORCe

N (see [page 1730](#))

Command Syntax :TRIGger:FORCe

The :TRIGger:FORCe command causes an acquisition to be captured even though the trigger condition has not been met. This command is equivalent to the front panel **[Force Trigger]** key.

See Also · ["Introduction to :TRIGger Commands"](#) on page 1425

:TRIGger:HFReject

C (see [page 1730](#))

Command Syntax :TRIGger:HFReject <value>
 <value> ::= {{0 | OFF} | {1 | ON}}

The :TRIGger:HFReject command turns the high frequency reject filter off and on. The high frequency reject filter adds a 50 kHz low-pass filter in the trigger path to remove high frequency components from the trigger waveform. Use this filter to remove high-frequency noise, such as AM or FM broadcast stations, from the trigger path.

Query Syntax :TRIGger:HFReject?

The :TRIGger:HFReject? query returns the current high frequency reject filter mode.

Return Format <value><NL>
 <value> ::= {0 | 1}

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger\[:EDGE\]:REJect"](#) on page 1458

:TRIGger:HOLDoff

C (see [page 1730](#))

Command Syntax :TRIGger:HOLDoff <holdoff_time>
 <holdoff_time> ::= 40 ns to 10 s in NR3 format

The :TRIGger:HOLDoff command defines the holdoff time value in seconds. Holdoff keeps a trigger from occurring until after a certain amount of time has passed since the last trigger. This feature is valuable when a waveform crosses the trigger level multiple times during one period of the waveform. Without holdoff, the oscilloscope could trigger on each of the crossings, producing a confusing waveform. With holdoff set correctly, the oscilloscope always triggers on the same crossing. The correct holdoff setting is typically slightly less than one period.

Query Syntax :TRIGger:HOLDoff?

The :TRIGger:HOLDoff? query returns the holdoff time value for the current trigger mode.

Return Format <holdoff_time><NL>
 <holdoff_time> ::= the holdoff time value in seconds in NR3 format.

See Also • ["Introduction to :TRIGger Commands"](#) on page 1425

:TRIGger:HOLDoff:MAXimum

N (see [page 1730](#))

Command Syntax :TRIGger:HOLDoff:MAXimum <max_holdoff>

<max_holdoff> ::= maximum holdoff time in seconds in NR3 format

When the random trigger holdoff mode is enabled (see :TRIGger:HOLDoff:RANDom), the :TRIGger:HOLDoff:MAXimum command specifies the maximum trigger holdoff time.

Query Syntax :TRIGger:HOLDoff:MAXimum?

The :TRIGger:HOLDoff:MAXimum? query returns the maximum random trigger holdoff time setting.

Return Format <max_holdoff><NL>

- See Also**
- [":TRIGger:HOLDoff:MINimum"](#) on page 1433
 - [":TRIGger:HOLDoff:RANDom"](#) on page 1434

:TRIGger:HOLDoff:MINimum

N (see [page 1730](#))

Command Syntax :TRIGger:HOLDoff:MINimum <min_holdoff>

<min_holdoff> ::= minimum holdoff time in seconds in NR3 format

When the random trigger holdoff mode is enabled (see :TRIGger:HOLDoff:RANDom), the :TRIGger:HOLDoff:MINimum command specifies the minimum trigger holdoff time.

Query Syntax :TRIGger:HOLDoff:MINimum?

The :TRIGger:HOLDoff:MINimum? query returns the minimum random trigger holdoff time setting.

Return Format <min_holdoff><NL>

- See Also**
- [":TRIGger:HOLDoff:MAXimum"](#) on page 1432
 - [":TRIGger:HOLDoff:RANDom"](#) on page 1434

:TRIGger:HOLDoff:RANDom

N (see [page 1730](#))

Command Syntax :TRIGger:HOLDoff:RANDom {{0 | OFF} | {1 | ON}}

The :TRIGger:HOLDoff:RANDom command enables or disables the random trigger holdoff mode. This mode randomizes the holdoff time from one acquisition to the next. The randomized holdoff time values will be between the values specified by the :TRIGger:HOLDoff:MINimum and :TRIGger:HOLDoff:MAXimum commands.

The random trigger holdoff mode ensures that the oscilloscope re-arms after each acquisition in a manner that minimizes or eliminates the likelihood of triggering at the beginning of a DDR burst. Randomizing the holdoff time increases the likelihood that the oscilloscope will trigger on different data phases of a multi-phase (8 data transfer) burst. This mode mixes up the traffic pattern the oscilloscope triggers on and is very effective when used on repeating patterns.

Query Syntax :TRIGger:HOLDoff:RANDom?

The :TRIGger:HOLDoff:RANDom? query returns random trigger holdoff mode setting.

Return Format <setting><NL>

<setting> ::= {0 | 1}

- See Also**
- [":TRIGger:HOLDoff:MAXimum"](#) on page 1432
 - [":TRIGger:HOLDoff:MINimum"](#) on page 1433

:TRIGger:JFRee

N (see [page 1730](#))

Command Syntax :TRIGger:JFRee {{0 | OFF} | {1 | ON}}

The :TRIGger:JFRee command disables or enables the Jitter-Free Trigger option.

Oscilloscope trigger circuitry introduces a certain amount of noise and jitter that result in horizontal error. To correct for this error, in certain trigger modes and at certain timebase ranges, hardware Jitter-Free Trigger correction is used to minimize trigger jitter at the trigger point.

The effect seen on the oscilloscope display is that all plotted acquisitions cross through the same pixel location at the intersection of the trigger level and time=0.

Jitter-Free Trigger correction works well for fast digital edges, but you may want to turn it off for some slow slew rate analog signals.

Query Syntax :TRIGger:JFRee?

The :TRIGger:JFRee? query returns the Jitter-Free Trigger option setting.

Return Format {0 | 1}

:TRIGger:LEVel:ASETup

N (see [page 1730](#))

Command Syntax :TRIGger:LEVel:ASETup

The :TRIGger:LEVel:ASETup command automatically sets the trigger levels of all displayed analog channels to their waveforms' 50% values.

If AC coupling is used, the trigger levels are set to 0 V.

When High and Low (dual) trigger levels are used (as with Rise/Fall Time and Runt triggers, for example), this command has no effect.

See Also · [":TRIGger\[:EDGE\]:LEVel"](#) on page 1457

:TRIGger:LEVel:HIGH

N (see [page 1730](#))

Command Syntax :TRIGger:LEVel:HIGH <level>, <source>

<level> ::= 0.75 x full-scale voltage from center screen in NR3 format
for internal triggers

<source> ::= CHANnel<n>

<n> ::= 1 to (# analog channels) in NR1 format

The :TRIGger:LEVel:HIGH command sets the high trigger voltage level voltage for the specified source.

High and low trigger levels are used with runt triggers and rise/fall time (transition) triggers.

Query Syntax :TRIGger:LEVel:HIGH? <source>

The :TRIGger:LEVel:HIGH? query returns the high trigger voltage level for the specified source.

Return Format <level><NL>

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:LEVel:LOW"](#) on page 1438
 - [":TRIGger:RUNT Commands"](#) on page 1480
 - [":TRIGger:TRANSition Commands"](#) on page 1491
 - [":TRIGger\[:EDGE\]:SOURce"](#) on page 1460

:TRIGger:LEVel:LOW

N (see [page 1730](#))

Command Syntax :TRIGger:LEVel:LOW <level>, <source>

<level> ::= 0.75 x full-scale voltage from center screen in NR3 format
for internal triggers

<source> ::= CHANnel<n>

<n> ::= 1 to (# analog channels) in NR1 format

The :TRIGger:LEVel:LOW command sets the low trigger voltage level voltage for the specified source.

High and low trigger levels are used with runt triggers and rise/fall time (transition) triggers.

Query Syntax :TRIGger:LEVel:LOW? <source>

The :TRIGger:LEVel:LOW? query returns the low trigger voltage level for the specified source.

Return Format <level><NL>

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:LEVel:HIGH"](#) on page 1437
 - [":TRIGger:RUNT Commands"](#) on page 1480
 - [":TRIGger:TRANSition Commands"](#) on page 1491
 - [":TRIGger\[:EDGE\]:SOURce"](#) on page 1460

:TRIGger:MODE

C (see [page 1730](#))

Command Syntax :TRIGger:MODE <mode>

```
<mode> ::= {EDGE | GLITch | PATTern | TV | DELay | EBURst | OR | RUNT
           | SHOLd | TRANsition | SBUS{1 | 2}}
```

The :TRIGger:MODE command selects the trigger mode (trigger type).

Query Syntax :TRIGger:MODE?

The :TRIGger:MODE? query returns the current trigger mode. If the :TIMebase:MODE is ROLL or XY, the query returns "NONE".

Return Format <mode><NL>

```
<mode> ::= {EDGE | GLIT | PATT | TV | DEL | EBUR | OR | RUNT | SHOL
           | TRAN | SBUS{1 | 2}}
```

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:SWEep"](#) on page 1441
 - [":TIMebase:MODE"](#) on page 1413

Example Code

```
' TRIGGER_MODE - Set the trigger mode to EDGE.
  myScope.WriteString ":TRIGger:MODE EDGE"
```

See complete example programs at: [Chapter 50](#), "Programming Examples," starting on page 1739

:TRIGger:NREJect

C (see [page 1730](#))

Command Syntax :TRIGger:NREJect <value>
<value> ::= {{0 | OFF} | {1 | ON}}

The :TRIGger:NREJect command turns the noise reject filter off and on. When the noise reject filter is on, the trigger circuitry is less sensitive to noise but may require a greater amplitude waveform to trigger the oscilloscope. This command is not valid in TV trigger mode.

Query Syntax :TRIGger:NREJect?

The :TRIGger:NREJect? query returns the current noise reject filter mode.

Return Format <value><NL>
<value> ::= {0 | 1}

See Also • ["Introduction to :TRIGger Commands"](#) on page 1425

:TRIGger:SWEep

C (see [page 1730](#))

Command Syntax :TRIGger:SWEep <sweep>

<sweep> ::= {AUTO | NORMal}

The :TRIGger:SWEep command selects the trigger sweep mode.

When AUTO sweep mode is selected, a baseline is displayed in the absence of a signal. If a signal is present but the oscilloscope is not triggered, the unsynchronized signal is displayed instead of a baseline.

When NORMal sweep mode is selected and no trigger is present, the instrument does not sweep, and the data acquired on the previous trigger remains on the screen.

NOTE

This feature is called "Mode" on the instrument's front panel.

Query Syntax :TRIGger:SWEep?

The :TRIGger:SWEep? query returns the current trigger sweep mode.

Return Format <sweep><NL>

<sweep> ::= current trigger sweep mode

See Also • ["Introduction to :TRIGger Commands"](#) on page 1425

:TRIGger:DElay Commands

Table 163 :TRIGger:DElay Commands Summary

Command	Query	Options and Query Returns
:TRIGger:DElay:ARM:SL OPe <slope> (see page 1443)	:TRIGger:DElay:ARM:SL OPe? (see page 1443)	<slope> ::= {NEGative POSitive}
:TRIGger:DElay:ARM:SO URce <source> (see page 1444)	:TRIGger:DElay:ARM:SO URce? (see page 1444)	<source> ::= {CHANnel<n> DIGital<d>} <n> ::= 1 to (# analog channels) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format
:TRIGger:DElay:TDElay :TIME <time_value> (see page 1445)	:TRIGger:DElay:TDElay :TIME? (see page 1445)	<time_value> ::= time in seconds in NR3 format
:TRIGger:DElay:TRIGge r:COUNT <count> (see page 1446)	:TRIGger:DElay:TRIGge r:COUNT? (see page 1446)	<count> ::= integer in NR1 format
:TRIGger:DElay:TRIGge r:SLOPe <slope> (see page 1447)	:TRIGger:DElay:TRIGge r:SLOPe? (see page 1447)	<slope> ::= {NEGative POSitive}
:TRIGger:DElay:TRIGge r:SOURce <source> (see page 1448)	:TRIGger:DElay:TRIGge r:SOURce? (see page 1448)	<source> ::= {CHANnel<n> DIGital<d>} <n> ::= 1 to (# analog channels) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format

The :TRIGger:DElay:ARM:SOURce and :TRIGger:DElay:TRIGger:SOURce commands are used to specify the source channel for the arming edge and the trigger edge in the Edge Then Edge trigger.

If an analog channel is selected as a source, the :TRIGger:EDGE:LEvel command is used to set the trigger level.

If a digital channel is selected as the source, the :DIGital<n>:THReshold or :POD<n>:THReshold command is used to set the trigger level.

:TRIGger:DElay:ARM:SLOPe

N (see [page 1730](#))

Command Syntax :TRIGger:DElay:ARM:SLOPe <slope>

<slope> ::= {NEGative | POSitive}

The :TRIGger:DElay:ARM:SLOPe command specifies rising (POSitive) or falling (NEGative) for the arming edge in the Edge Then Edge trigger.

Query Syntax :TRIGger:DElay:ARM:SLOPe?

The :TRIGger:DElay:ARM:SLOPe? query returns the current arming edge slope setting.

Return Format <slope><NL>

<slope> ::= {NEG | POS}

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:DElay:ARM:SOURce"](#) on page 1444
 - [":TRIGger:DElay:TDElay:TIME"](#) on page 1445

:TRIGger:DElay:ARM:SOURce

N (see [page 1730](#))

Command Syntax :TRIGger:DElay:ARM:SOURce <source>

<source> ::= {CHANnel<n> | DIGital<d>}

<n> ::= 1 to (# analog channels) in NR1 format

<d> ::= 0 to (# digital channels - 1) in NR1 format

The :TRIGger:DElay:ARM:SOURce command selects the input used for the arming edge in the Edge Then Edge trigger.

Query Syntax :TRIGger:DElay:ARM:SOURce?

The :TRIGger:DElay:ARM:SOURce? query returns the current arming edge source.

Return Format <source><NL>

<source> ::= {CHAN<n> | DIG<d>}

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:DElay:ARM:SLOPe"](#) on page 1443
 - [":TRIGger:DElay:TDElay:TIME"](#) on page 1445
 - [":TRIGger:MODE"](#) on page 1439

:TRIGger:DElay:TDElay:TIME

N (see [page 1730](#))

Command Syntax :TRIGger:DElay:TDElay:TIME <time_value>

<time_value> ::= time in seconds in NR3 format

The :TRIGger:DElay:TDElay:TIME command sets the delay time between the arming edge and the trigger edge in the Edge Then Edge trigger. The time is in seconds and must be from 4 ns to 10 s.

Query Syntax :TRIGger:DElay:TDElay:TIME?

The :TRIGger:DElay:TDElay:TIME? query returns current delay time setting.

Return Format <time_value><NL>

<time_value> ::= time in seconds in NR3 format

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:DElay:TRIGger:SLOPe"](#) on page 1447
 - [":TRIGger:DElay:TRIGger:COUNt"](#) on page 1446

:TRIGger:DElay:TRIGger:COUNT

N (see [page 1730](#))

Command Syntax :TRIGger:DElay:TRIGger:COUNT <count>

<count> ::= integer in NR1 format

The :TRIGger:DElay:TRIGger:COUNT command sets the Nth edge of the trigger source to trigger on.

Query Syntax :TRIGger:DElay:TRIGger:COUNT?

The :TRIGger:DElay:TRIGger:COUNT? query returns the current Nth trigger edge setting.

Return Format <count><NL>

<count> ::= integer in NR1 format

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:DElay:TRIGger:SLOPe"](#) on page 1447
 - [":TRIGger:DElay:TRIGger:SOURce"](#) on page 1448
 - [":TRIGger:DElay:TDElay:TIME"](#) on page 1445

:TRIGger:DElay:TRIGger:SLOPe

N (see [page 1730](#))

Command Syntax :TRIGger:DElay:TRIGger:SLOPe <slope>

<slope> ::= {NEGative | POSitive}

The :TRIGger:DElay:TRIGger:SLOPe command specifies rising (POSitive) or falling (NEGative) for the trigger edge in the Edge Then Edge trigger.

Query Syntax :TRIGger:DElay:TRIGger:SLOPe?

The :TRIGger:DElay:TRIGger:SLOPe? query returns the current trigger edge slope setting.

Return Format <slope><NL>

<slope> ::= {NEG | POS}

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:DElay:TRIGger:SOURce"](#) on page 1448
 - [":TRIGger:DElay:TDElay:TIME"](#) on page 1445
 - [":TRIGger:DElay:TRIGger:COUNt"](#) on page 1446

:TRIGger:DElay:TRIGger:SOURce

N (see [page 1730](#))

Command Syntax :TRIGger:DElay:TRIGger:SOURce <source>

<source> ::= {CHANnel<n> | DIGital<d>}

<n> ::= 1 to (# analog channels) in NR1 format

<d> ::= 0 to (# digital channels - 1) in NR1 format

The :TRIGger:DElay:TRIGger:SOURce command selects the input used for the trigger edge in the Edge Then Edge trigger.

Query Syntax :TRIGger:DElay:TRIGger:SOURce?

The :TRIGger:DElay:TRIGger:SOURce? query returns the current trigger edge source.

Return Format <source><NL>

<source> ::= {CHAN<n> | DIG<d>}

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:DElay:TRIGger:SLOPe"](#) on page 1447
 - [":TRIGger:DElay:TDElay:TIME"](#) on page 1445
 - [":TRIGger:DElay:TRIGger:COUNt"](#) on page 1446
 - [":TRIGger:MODE"](#) on page 1439

:TRIGger:EBURst Commands

Table 164 :TRIGger:EBURst Commands Summary

Command	Query	Options and Query Returns
:TRIGger:EBURst:COUNT <count> (see page 1450)	:TRIGger:EBURst:COUNT ? (see page 1450)	<count> ::= integer in NR1 format
:TRIGger:EBURst:IDLE <time_value> (see page 1451)	:TRIGger:EBURst:IDLE? (see page 1451)	<time_value> ::= time in seconds in NR3 format
:TRIGger:EBURst:SLOPe <slope> (see page 1452)	:TRIGger:EBURst:SLOPe ? (see page 1452)	<slope> ::= {NEGative POSitive}
:TRIGger:EBURst:SOURc e <source> (see page 1453)	:TRIGger:EBURst:SOURc e? (see page 1453)	<source> ::= {CHANnel<n> DIGital<d>} <n> ::= 1 to (# analog channels) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format

The :TRIGger:EBURst:SOURce command is used to specify the source channel for the Nth Edge Burst trigger. If an analog channel is selected as the source, the :TRIGger:EDGE:LEVel command is used to set the Nth Edge Burst trigger level. If a digital channel is selected as the source, the :DIGital<n>:THReshold or :POD<n>:THReshold command is used to set the Nth Edge Burst trigger level.

:TRIGger:EBURst:COUNT

N (see [page 1730](#))

Command Syntax :TRIGger:EBURst:COUNT <count>

<count> ::= integer in NR1 format

The :TRIGger:EBURst:COUNT command sets the Nth edge at burst counter resource. The edge counter is used in the trigger stage to determine which edge in a burst will generate a trigger.

Query Syntax :TRIGger:EBURst:COUNT?

The :TRIGger:EBURst:COUNT? query returns the current Nth edge of burst edge counter setting.

Return Format <count><NL>

<count> ::= integer in NR1 format

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:EBURst:SLOPe"](#) on page 1452
 - [":TRIGger:EBURst:IDLE"](#) on page 1451

:TRIGger:EBURst:IDLE

N (see [page 1730](#))

Command Syntax :TRIGger:EBURst:IDLE <time_value>

<time_value> ::= time in seconds in NR3 format

The :TRIGger:EBURst:IDLE command sets the Nth edge in a burst idle resource in seconds from 10 ns to 10 s. The timer is used to set the minimum time before the next burst.

Query Syntax :TRIGger:EBURst:IDLE?

The :TRIGger:EBURst:IDLE? query returns current Nth edge in a burst idle setting.

Return Format <time value><NL>

<time_value> ::= time in seconds in NR3 format

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:EBURst:SLOPe"](#) on page 1452
 - [":TRIGger:EBURst:COUNt"](#) on page 1450

:TRIGger:EBURst:SLOPe

N (see [page 1730](#))

Command Syntax :TRIGger:EBURst:SLOPe <slope>

<slope> ::= {NEGative | POSitive}

The :TRIGger:EBURst:SLOPe command specifies whether the rising edge (POSitive) or falling edge (NEGative) of the Nth edge in a burst will generate a trigger.

Query Syntax :TRIGger:EBURst:SLOPe?

The :TRIGger:EBURst:SLOPe? query returns the current Nth edge in a burst slope.

Return Format <slope><NL>

<slope> ::= {NEG | POS}

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:EBURst:IDLE"](#) on page 1451
 - [":TRIGger:EBURst:COUNt"](#) on page 1450

:TRIGger:EBURst:SOURce

C (see [page 1730](#))

Command Syntax :TRIGger:EBURst:SOURce <source>

<source> ::= {CHANnel<n> | DIGital<d>}

<n> ::= 1 to (# analog channels) in NR1 format

<d> ::= 0 to (# digital channels - 1) in NR1 format

The :TRIGger:EBURst:SOURce command selects the input that produces the Nth edge burst trigger.

Query Syntax :TRIGger:EBURst:SOURce?

The :TRIGger:EBURst:SOURce? query returns the current Nth edge burst trigger source. If all channels are off, the query returns "NONE."

Return Format <source><NL>

<source> ::= {CHAN<n> | DIG<d>}

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:MODE"](#) on page 1439

:TRIGger[:EDGE] Commands

Table 165 :TRIGger[:EDGE] Commands Summary

Command	Query	Options and Query Returns
:TRIGger[:EDGE]:COUPling {AC DC LFReject} (see page 1456)	:TRIGger[:EDGE]:COUPling? (see page 1456)	{AC DC LFReject}
:TRIGger[:EDGE]:LEVel <level> [, <source>] (see page 1457)	:TRIGger[:EDGE]:LEVel? [<source>] (see page 1457)	<p>For internal triggers, <level> ::= .75 x full-scale voltage from center screen in NR3 format.</p> <p>For external triggers, <level> ::= ±(external range setting) in NR3 format.</p> <p>For digital channels (MSO models), <level> ::= ±8 V.</p> <p><source> ::= {CHANnel<n> EXTErnal} for DSO models</p> <p><source> ::= {CHANnel<n> DIGital<d> EXTErnal } for MSO models</p> <p><n> ::= 1 to (# analog channels) in NR1 format</p> <p><d> ::= 0 to (# digital channels - 1) in NR1 format</p>
:TRIGger[:EDGE]:REJect {OFF LFReject HFReject} (see page 1458)	:TRIGger[:EDGE]:REJect? (see page 1458)	{OFF LFReject HFReject}

Table 165 :TRIGger[:EDGE] Commands Summary (continued)

Command	Query	Options and Query Returns
:TRIGger[:EDGE]:SLOPe <polarity> (see page 1459)	:TRIGger[:EDGE]:SLOPe ? (see page 1459)	<polarity> ::= {POSitive NEGative EITHER ALternate}
:TRIGger[:EDGE]:SOURc e <source> (see page 1460)	:TRIGger[:EDGE]:SOURc e? (see page 1460)	<source> ::= {CHANnel<n> EXTernal LINE WGEN WGEN1 WGEN2 WMOD} for the DSO models <source> ::= {CHANnel<n> DIGital<d> EXTernal LINE WGEN WGEN1 WGEN2 WMOD} for the MSO models <n> ::= 1 to (# analog channels) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format Note: WGEN and WGEN1 are equivalent. Note: WGEN2 only available on models with 2 WaveGen outputs.

:TRIGger[:EDGE]:COUPLing

C (see [page 1730](#))

Command Syntax :TRIGger[:EDGE]:COUPLing <coupling>

<coupling> ::= {AC | DC | LFReject}

The :TRIGger[:EDGE]:COUPLing command sets the input coupling for the selected trigger sources. The coupling can be set to AC, DC, or LFReject.

- AC coupling places a high-pass filter (10 Hz for analog channels, and 3.5 Hz for all External trigger inputs) in the trigger path, removing dc offset voltage from the trigger waveform. Use AC coupling to get a stable edge trigger when your waveform has a large dc offset.
- LFReject coupling places a 50 kHz high-pass filter in the trigger path.
- DC coupling allows dc and ac signals into the trigger path.

NOTE

The :TRIGger[:EDGE]:COUPLing and the :TRIGger[:EDGE]:REJect selections are coupled. Changing the setting of the :TRIGger[:EDGE]:REJect can change the COUPLing setting.

Query Syntax :TRIGger[:EDGE]:COUPLing?

The :TRIGger[:EDGE]:COUPLing? query returns the current coupling selection.

Return Format <coupling><NL>

<coupling> ::= {AC | DC | LFR}

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:MODE"](#) on page 1439
 - [":TRIGger\[:EDGE\]:REJect"](#) on page 1458

:TRIGger[:EDGE]:LEVel

C (see [page 1730](#))

Command Syntax :TRIGger[:EDGE]:LEVel <level>
 <level> ::= <level>[,<source>]
 <level> ::= 0.75 x full-scale voltage from center screen in NR3 format
 for internal triggers
 <level> ::= ±(external range setting) in NR3 format
 for external triggers
 <level> ::= ±8 V for digital channels (MSO models)
 <source> ::= {CHANnel<n> | EXTernal} for the DSO models
 <source> ::= {CHANnel<n> | DIGital<d> | EXTernal}
 for the MSO models
 <n> ::= 1 to (# analog channels) in NR1 format
 <d> ::= 0 to (# digital channels - 1) in NR1 format

The :TRIGger[:EDGE]:LEVel command sets the trigger level voltage for the active trigger source.

NOTE

If the optional source is specified and is not the active source, the level on the active source is not affected and the active source is not changed.

Query Syntax :TRIGger[:EDGE]:LEVel? [<source>]

The :TRIGger[:EDGE]:LEVel? query returns the trigger level of the current trigger source.

Return Format <level><NL>

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger\[:EDGE\]:SOURce"](#) on page 1460
 - [":EXTernal:RANGe"](#) on page 464
 - [":POD<n>:THReshold"](#) on page 819
 - [":DIGital<d>:THReshold"](#) on page 427

:TRIGger[:EDGE]:REJect

C (see [page 1730](#))

Command Syntax :TRIGger[:EDGE]:REJect <reject>
<reject> ::= {OFF | LFReject | HFReject}

The :TRIGger[:EDGE]:REJect command turns the low-frequency or high-frequency reject filter on or off. You can turn on one of these filters at a time.

- The high frequency reject filter adds a 50 kHz low-pass filter in the trigger path to remove high frequency components from the trigger waveform. Use the high frequency reject filter to remove high-frequency noise, such as AM or FM broadcast stations, from the trigger path.
- The low frequency reject filter adds a 50 kHz high-pass filter in series with the trigger waveform to remove any unwanted low frequency components from a trigger waveform, such as power line frequencies, that can interfere with proper triggering.

NOTE

The :TRIGger[:EDGE]:REJect and the :TRIGger[:EDGE]:COUPling selections are coupled. Changing the setting of the :TRIGger[:EDGE]:COUPling can change the COUPling setting.

Query Syntax :TRIGger[:EDGE]:REJect?

The :TRIGger[:EDGE]:REJect? query returns the current status of the reject filter.

Return Format <reject><NL>
<reject> ::= {OFF | LFR | HFR}

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:HFReject"](#) on page 1430
 - [":TRIGger\[:EDGE\]:COUPling"](#) on page 1456

:TRIGger[:EDGE]:SLOPe

C (see [page 1730](#))

Command Syntax :TRIGger[:EDGE]:SLOPe <slope>

<slope> ::= {NEGative | POSitive | EITHer | ALTernate}

The :TRIGger[:EDGE]:SLOPe command specifies the slope of the edge for the trigger. The SLOPe command is not valid in TV trigger mode. Instead, use :TRIGger:TV:POLarity to set the polarity in TV trigger mode.

Query Syntax :TRIGger[:EDGE]:SLOPe?

The :TRIGger[:EDGE]:SLOPe? query returns the current trigger slope.

Return Format <slope><NL>

<slope> ::= {NEG | POS | EITH | ALT}

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:MODE"](#) on page 1439
 - [":TRIGger:TV:POLarity"](#) on page 1499

Example Code

```
' TRIGGER_EDGE_SLOPE - Sets the slope of the edge for the trigger.
' Set the slope to positive.
myScope.WriteString ":TRIGGER:EDGE:SLOPE POSITIVE"
```

See complete example programs at: [Chapter 50](#), "Programming Examples," starting on page 1739

:TRIGger[:EDGE]:SOURce

C (see [page 1730](#))

Command Syntax :TRIGger[:EDGE]:SOURce <source>

<source> ::= {CHANnel<n> | EXTERNAL | LINE | WGEN | WGEN1 | WGEN2
| WMOD} for the DSO models

<source> ::= {CHANnel<n> | DIGital<d> | EXTERNAL | LINE | WGEN | WGEN1
| WGEN2 | WMOD} for the MSO models

<n> ::= 1 to (# analog channels) in NR1 format

<d> ::= 0 to (# digital channels - 1) in NR1 format

Note: WAVE and WGEN1 are equivalent.

Note: WGEN2 only available on models with 2 WaveGen outputs.

The :TRIGger[:EDGE]:SOURce command selects the input that produces the trigger.

- EXTERNAL – triggers on the rear panel EXT TRIG IN signal.
- LINE – triggers at the 50% level of the rising or falling edge of the AC power source signal.
- WGEN, WGEN1, WGEN2 – triggers at the 50% level of the rising edge of the waveform generator output signal. This option is not available when the DC, NOISE, or CARDIAC waveforms are selected.
- WMOD – when waveform generator FSK or FM modulation is used, triggers at the 50% level of the rising edge of the modulating signal.

Query Syntax :TRIGger[:EDGE]:SOURce?

The :TRIGger[:EDGE]:SOURce? query returns the current source. If all channels are off, the query returns "NONE."

Return Format <source><NL>

<source> ::= {CHAN<n> | EXT | LINE | WGEN | WGEN1 | WGEN2 | WMOD
| NONE} for the DSO models

<source> ::= {CHAN<n> | DIG<d> | EXTERNAL | LINE | WGEN | WGEN1
| WGEN2 | WMOD | NONE} for the MSO models

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:MODE"](#) on page 1439

Example Code

```
' TRIGGER_EDGE_SOURCE - Selects the channel that actually produces the
edge trigger. Any channel can be selected.
myScope.WriteString ":TRIGger:EDGE:SOURce CHANnel1"
```

See complete example programs at: [Chapter 50](#), "Programming Examples," starting on page 1739

:TRIGger:GLITch Commands

Table 166 :TRIGger:GLITch Commands Summary

Command	Query	Options and Query Returns
:TRIGger:GLITch:GREAt erthan <greater_than_time>[s uffix] (see page 1463)	:TRIGger:GLITch:GREAt erthan? (see page 1463)	<greater_than_time> ::= floating-point number in NR3 format [suffix] ::= {s ms us ns ps}
:TRIGger:GLITch:LESSt han <less_than_time>[suff ix] (see page 1464)	:TRIGger:GLITch:LESSt han? (see page 1464)	<less_than_time> ::= floating-point number in NR3 format [suffix] ::= {s ms us ns ps}
:TRIGger:GLITch:LEVel <level> [<source>] (see page 1465)	:TRIGger:GLITch:LEVel ? (see page 1465)	For internal triggers, <level> ::= .75 x full-scale voltage from center screen in NR3 format. For external triggers (DSO models), <level> ::= ±(external range setting) in NR3 format. For digital channels (MSO models), <level> ::= ±8 V. <source> ::= {CHANnel<n> EXTernal} for DSO models <source> ::= {CHANnel<n> DIGital<d>} for MSO models <n> ::= 1 to (# analog channels) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format
:TRIGger:GLITch:POLar ity <polarity> (see page 1466)	:TRIGger:GLITch:POLar ity? (see page 1466)	<polarity> ::= {POSitive NEGative}
:TRIGger:GLITch:QUALi fier <qualifier> (see page 1467)	:TRIGger:GLITch:QUALi fier? (see page 1467)	<qualifier> ::= {GREATERthan LESSthan RANGE}

Table 166 :TRIGger:GLITCh Commands Summary (continued)

Command	Query	Options and Query Returns
:TRIGger:GLITCh:RANGe <less_than_time>[suffix], <greater_than_time>[suffix] (see page 1468)	:TRIGger:GLITCh:RANGe? (see page 1468)	<less_than_time> ::= 15 ns to 10 seconds in NR3 format <greater_than_time> ::= 10 ns to 9.99 seconds in NR3 format [suffix] ::= {s ms us ns ps}
:TRIGger:GLITCh:SOURCe <source> (see page 1469)	:TRIGger:GLITCh:SOURCe? (see page 1469)	<source> ::= {CHANnel<n> DIGital<d>} <n> ::= 1 to (# analog channels) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format

:TRIGger:GLITCh:GREaterthan

N (see [page 1730](#))

Command Syntax :TRIGger:GLITCh:GREaterthan <greater_than_time>[<suffix>]

<greater_than_time> ::= floating-point number in NR3 format

<suffix> ::= {s | ms | us | ns | ps}

The :TRIGger:GLITCh:GREaterthan command sets the minimum pulse width duration for the selected :TRIGger:GLITCh:SOURce.

Query Syntax :TRIGger:GLITCh:GREaterthan?

The :TRIGger:GLITCh:GREaterthan? query returns the minimum pulse width duration time for :TRIGger:GLITCh:SOURce.

Return Format <greater_than_time><NL>

<greater_than_time> ::= floating-point number in NR3 format.

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:GLITCh:SOURce"](#) on page 1469
 - [":TRIGger:GLITCh:QUALifier"](#) on page 1467
 - [":TRIGger:MODE"](#) on page 1439

:TRIGger:GLITch:LESSthan

N (see [page 1730](#))

Command Syntax :TRIGger:GLITch:LESSthan <less_than_time> [<suffix>]

<less_than_time> ::= floating-point number in NR3 format

<suffix> ::= {s | ms | us | ns | ps}

The :TRIGger:GLITch:LESSthan command sets the maximum pulse width duration for the selected :TRIGger:GLITch:SOURce.

Query Syntax :TRIGger:GLITch:LESSthan?

The :TRIGger:GLITch:LESSthan? query returns the pulse width duration time for :TRIGger:GLITch:SOURce.

Return Format <less_than_time><NL>

<less_than_time> ::= floating-point number in NR3 format.

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:GLITch:SOURce"](#) on page 1469
 - [":TRIGger:GLITch:QUALifier"](#) on page 1467
 - [":TRIGger:MODE"](#) on page 1439

:TRIGger:GLITch:LEVel

N (see [page 1730](#))

Command Syntax :TRIGger:GLITch:LEVel <level>[,<source>]

<level> ::= .75 x full-scale voltage from center screen in NR3 format
for internal triggers

<level> ::= ±(external range setting) in NR3 format
for external triggers (DSO models)

<level> ::= ±8 V for digital channels (MSO models)

<source> ::= {CHANnel<n> | EXTernal} for DSO models

<source> ::= {CHANnel<n> | DIGital<d>} for MSO models

<n> ::= 1 to (# analog channels) in NR1 format

<d> ::= 0 to (# digital channels - 1) in NR1 format

The :TRIGger:GLITch:LEVel command sets the trigger level voltage for the active pulse width trigger.

Query Syntax :TRIGger:GLITch:LEVel?

The :TRIGger:GLITch:LEVel? query returns the trigger level of the current pulse width trigger mode. If all channels are off, the query returns "NONE."

Return Format <level><NL>

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:MODE"](#) on page 1439
 - [":TRIGger:GLITch:SOURce"](#) on page 1469
 - [":EXTernal:RANGe"](#) on page 464

:TRIGger:GLITch:POLarity

N (see [page 1730](#))

Command Syntax :TRIGger:GLITch:POLarity <polarity>
 <polarity> ::= {POSitive | NEGative}

The :TRIGger:GLITch:POLarity command sets the polarity for the glitch pulse width trigger.

Query Syntax :TRIGger:GLITch:POLarity?

The :TRIGger:GLITch:POLarity? query returns the glitch pulse width trigger polarity.

Return Format <polarity><NL>
 <polarity> ::= {POS | NEG}

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:MODE"](#) on page 1439
 - [":TRIGger:GLITch:SOURce"](#) on page 1469

:TRIGger:GLITch:QUALifier

N (see [page 1730](#))

Command Syntax :TRIGger:GLITch:QUALifier <operator>

<operator> ::= {GREATERthan | LESSthan | RANGE}

This command sets the mode of operation of the glitch pulse width trigger. The oscilloscope can trigger on a pulse width that is greater than a time value, less than a time value, or within a range of time values.

Query Syntax :TRIGger:GLITch:QUALifier?

The :TRIGger:GLITch:QUALifier? query returns the glitch pulse width qualifier.

Return Format <operator><NL>

<operator> ::= {GRE | LESS | RANG}

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:GLITch:SOURce"](#) on page 1469
 - [":TRIGger:MODE"](#) on page 1439

:TRIGger:GLITch:RANGe**N** (see [page 1730](#))

Command Syntax `:TRIGger:GLITch:RANGe <less_than_time>[suffix],
<greater_than_time>[suffix]`

`<less_than_time> ::= (15 ns - 10 seconds) in NR3 format`

`<greater_than_time> ::= (10 ns - 9.99 seconds) in NR3 format`

`[suffix] ::= {s | ms | us | ns | ps}`

The `:TRIGger:GLITch:RANGe` command sets the pulse width duration for the selected `:TRIGger:GLITch:SOURce`. You can enter the parameters in any order – the smaller value becomes the `<greater_than_time>` and the larger value becomes the `<less_than_time>`.

Query Syntax `:TRIGger:GLITch:RANGe?`

The `:TRIGger:GLITch:RANGe?` query returns the pulse width duration time for `:TRIGger:GLITch:SOURce`.

Return Format `<less_than_time>,<greater_than_time><NL>`

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:GLITch:SOURce"](#) on page 1469
 - [":TRIGger:GLITch:QUALifier"](#) on page 1467
 - [":TRIGger:MODE"](#) on page 1439

:TRIGger:GLITch:SOURce

N (see [page 1730](#))

Command Syntax :TRIGger:GLITch:SOURce <source>

<source> ::= {DIGital<d> | CHANnel<n>}

<n> ::= 1 to (# analog channels) in NR1 format

<d> ::= 0 to (# digital channels - 1) in NR1 format

The :TRIGger:GLITch:SOURce command selects the channel that produces the pulse width trigger.

Query Syntax :TRIGger:GLITch:SOURce?

The :TRIGger:GLITch:SOURce? query returns the current pulse width source. If all channels are off, the query returns "NONE".

Return Format <source><NL>

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:MODE"](#) on page 1439
 - [":TRIGger:GLITch:LEVel"](#) on page 1465
 - [":TRIGger:GLITch:POLarity"](#) on page 1466
 - [":TRIGger:GLITch:QUALifier"](#) on page 1467
 - [":TRIGger:GLITch:RANGE"](#) on page 1468

Example Code • ["Example Code"](#) on page 1460

:TRIGger:OR Commands

Table 167 :TRIGger:OR Commands Summary

Command	Query	Options and Query Returns
:TRIGger:OR <string> (see page 1471)	:TRIGger:OR? (see page 1471)	<string> ::= "nn...n" where n ::= {R F E X} R = rising edge, F = falling edge, E = either edge, X = don't care. Each character in the string is for an analog or digital channel as shown on the front panel display.

:TRIGger:OR

N (see [page 1730](#))

Command Syntax :TRIGger:OR <string>

<string> ::= "nn...n" where n ::= {R | F | E | X}

R = rising edge, F = falling edge, E = either edge, X = don't care.

The :TRIGger:OR command specifies the edges to include in the OR'ed edge trigger.

In the <string> parameter, each bit corresponds to a channel as described in the following table:

Oscilloscope Models	Value and Mask Bit Assignments
4 analog + 16 digital channels (mixed-signal)	Bits 0 through 15 - digital channels 0 through 15. Bits 16 through 19 - analog channels 4 through 1.
2 analog + 16 digital channels (mixed-signal)	Bits 0 through 15 - digital channels 0 through 15. Bits 16 and 17 - analog channels 2 and 1.
4 analog channels only	Bits 0 through 3 - analog channels 4 through 1.
2 analog channels only	Bits 0 and 1 - analog channels 2 and 1.

Query Syntax :TRIGger:OR?

The :TRIGger:OR? query returns the current OR'ed edge trigger string.

Return Format <string><NL>

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:MODE"](#) on page 1439

:TRIGger:PATtern Commands

Table 168 :TRIGger:PATtern Commands Summary

Command	Query	Options and Query Returns
:TRIGger:PATtern <string>[,<edge_source>,<edge>] (see page 1473)	:TRIGger:PATtern? (see page 1474)	<string> ::= "nn...n" where n ::= {0 1 X R F} when <base> = ASCII <string> ::= "0xnn...n" where n ::= {0,...,9 A,...,F X \$} when <base> = HEX <edge_source> ::= {CHANnel<n> NONE} for DSO models <edge_source> ::= {CHANnel<n> DIGital<d> NONE} for MSO models <n> ::= 1 to (# analog channels) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format <edge> ::= {POSitive NEGative}
:TRIGger:PATtern:FORM at <base> (see page 1475)	:TRIGger:PATtern:FORM at? (see page 1475)	<base> ::= {ASCII HEX}
:TRIGger:PATtern:GREa terthan <greater_than_time>[suffix] (see page 1476)	:TRIGger:PATtern:GREa terthan? (see page 1476)	<greater_than_time> ::= floating-point number in NR3 format [suffix] ::= {s ms us ns ps}
:TRIGger:PATtern:LESS than <less_than_time>[suffix] (see page 1477)	:TRIGger:PATtern:LESS than? (see page 1477)	<less_than_time> ::= floating-point number in NR3 format [suffix] ::= {s ms us ns ps}
:TRIGger:PATtern:QUAL ifier <qualifier> (see page 1478)	:TRIGger:PATtern:QUAL ifier? (see page 1478)	<qualifier> ::= {ENTERed GREaterthan LESSthan INRange OUTRange TIMEout}
:TRIGger:PATtern:RANG e <less_than_time>[suffix], <greater_than_time>[suffix] (see page 1479)	:TRIGger:PATtern:RANG e? (see page 1479)	<less_than_time> ::= 15 ns to 10 seconds in NR3 format <greater_than_time> ::= 10 ns to 9.99 seconds in NR3 format [suffix] ::= {s ms us ns ps}

:TRIGger:PATtern

C (see [page 1730](#))

Command Syntax :TRIGger:PATtern <pattern>

<pattern> ::= <string>[,<edge_source>,<edge>]

<string> ::= "nn...n" where n ::= {0 | 1 | X | R | F} when
<base> = ASCii

<string> ::= "0xnn...n" where n ::= {0,...,9 | A,...,F | X | \$} when
<base> = HEX

<edge_source> ::= {CHANnel<n> | NONE} for DSO models

<edge_source> ::= {CHANnel<n> | DIGital<d>
| NONE} for MSO models

<n> ::= 1 to (# of analog channels) in NR1 format

<d> ::= 0 to (# digital channels - 1) in NR1 format

<edge> ::= {POSitive | NEGative}

The :TRIGger:PATtern command specifies the channel values to be used in the pattern trigger.

In the <string> parameter, each bit corresponds to a channel as described in the following table:

Oscilloscope Models	Value and Mask Bit Assignments
4 analog + 16 digital channels (mixed-signal)	Bits 0 through 15 - digital channels 0 through 15. Bits 16 through 19 - analog channels 4 through 1.
2 analog + 16 digital channels (mixed-signal)	Bits 0 through 15 - digital channels 0 through 15. Bits 16 and 17 - analog channels 2 and 1.
4 analog channels only	Bits 0 through 3 - analog channels 4 through 1.
2 analog channels only	Bits 0 and 1 - analog channels 2 and 1.

The format of the <string> parameter depends on the :TRIGger:PATtern:FORMat command setting:

- When the format is ASCii, the string looks just like the string you see on the oscilloscope's front panel, made up of 0, 1, X (don't care), R (rising edge), and F (falling edge) characters.
- When the format is HEX, the string begins with "0x" and contains hex digit characters or X (don't care for all four bits in the nibble).

With the hex format string, you can use the <edge_source> and <edge> parameters to specify an edge on one of the channels.

NOTE

The optional <edge_source> and <edge> parameters should be sent together or not at all. The edge can be specified in the ASCII <string> parameter. If the edge source and edge parameters are used, they take precedence.

You can only specify an edge on one channel. When an edge is specified, the :TRIGger:PATtern:QUALifier does not apply.

Query Syntax :TRIGger:PATtern?

The :TRIGger:PATtern? query returns the pattern string, edge source, and edge.

Return Format <string>, <edge_source>, <edge><NL>

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:PATtern:FORMat"](#) on page 1475
 - [":TRIGger:PATtern:QUALifier"](#) on page 1478
 - [":TRIGger:MODE"](#) on page 1439

:TRIGger:PATtern:FORMat

N (see [page 1730](#))

Command Syntax :TRIGger:PATtern:FORMat <base>

<base> ::= {ASCii | HEX}

The :TRIGger:PATtern:FORMat command sets the entry (and query) number base used by the :TRIGger:PATtern command. The default <base> is ASCii.

Query Syntax :TRIGger:PATtern:FORMat?

The :TRIGger:PATtern:FORMat? query returns the currently set number base for pattern trigger patterns.

Return Format <base><NL>

<base> ::= {ASC | HEX}

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:PATtern"](#) on page 1473

:TRIGger:PATtern:GREaterthan

N (see [page 1730](#))

Command Syntax :TRIGger:PATtern:GREaterthan <greater_than_time> [<suffix>]
 <greater_than_time> ::= minimum trigger duration in seconds
 in NR3 format
 <suffix> ::= {s | ms | us | ns | ps }

The :TRIGger:PATtern:GREaterthan command sets the minimum duration for the defined pattern when :TRIGger:PATtern:QUALifier is set to GREaterthan. The command also sets the timeout value when the :TRIGger:PATtern:QUALifier is set to TIMEout.

Query Syntax :TRIGger:PATtern:GREaterthan?

The :TRIGger:PATtern:GREaterthan? query returns the minimum duration time for the defined pattern.

Return Format <greater_than_time><NL>

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:PATtern"](#) on page 1473
 - [":TRIGger:PATtern:QUALifier"](#) on page 1478
 - [":TRIGger:MODE"](#) on page 1439

:TRIGger:PATtern:LESSthan

N (see [page 1730](#))

Command Syntax :TRIGger:PATtern:LESSthan <less_than_time>[<suffix>]
 <less_than_time> ::= maximum trigger duration in seconds
 in NR3 format
 <suffix> ::= {s | ms | us | ns | ps}

The :TRIGger:PATtern:LESSthan command sets the maximum duration for the defined pattern when :TRIGger:PATtern:QUALifier is set to LESSthan.

Query Syntax :TRIGger:PATtern:LESSthan?

The :TRIGger:PATtern:LESSthan? query returns the duration time for the defined pattern.

Return Format <less_than_time><NL>

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:PATtern"](#) on page 1473
 - [":TRIGger:PATtern:QUALifier"](#) on page 1478
 - [":TRIGger:MODE"](#) on page 1439

:TRIGger:PATtern:QUALifier

N (see [page 1730](#))

Command Syntax :TRIGger:PATtern:QUALifier <qualifier>

```
<qualifier> ::= {ENTERed | GREATERthan | LESSthan | INRange | OUTRange
                | TIMEout}
```

The :TRIGger:PATtern:QUALifier command qualifies when the trigger occurs:

- ENTERed – when the pattern is entered.
- LESSthan – when the pattern is present for less than a time value.
- GREATERthan – when the pattern is present for greater than a time value. The trigger occurs when the pattern exits (not when the GREATERthan time value is exceeded).
- TIMEout – when the pattern is present for greater than a time value. In this case, the trigger occurs when the GREATERthan time value is exceeded (not when the pattern exits).
- INRange – when the pattern is present for a time within a range of values.
- OUTRange – when the pattern is present for a time outside of range of values.

Pattern durations are evaluated using a timer. The timer starts on the last edge that makes the pattern (logical AND) true. Except when the TIMEout qualifier is selected, the trigger occurs on the first edge that makes the pattern false, provided the time qualifier criteria has been met.

Set the GREATERthan qualifier value with the :TRIGger:PATtern:GREATERthan command.

Set the LESSthan qualifier value with the :TRIGger:PATtern:LESSthan command.

Set the INRange and OUTRange qualifier values with the :TRIGger:PATtern:RANGE command.

Set the TIMEout qualifier value with the :TRIGger:PATtern:GREATERthan command.

Query Syntax :TRIGger:PATtern:QUALifier?

The :TRIGger:PATtern:QUALifier? query returns the trigger duration qualifier.

Return Format <qualifier><NL>

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:PATtern:GREATERthan"](#) on page 1476
 - [":TRIGger:PATtern:LESSthan"](#) on page 1477
 - [":TRIGger:PATtern:RANGE"](#) on page 1479

:TRIGger:RUNT Commands

Table 169 :TRIGger:RUNT Commands Summary

Command	Query	Options and Query Returns
:TRIGger:RUNT:POLarity <polarity> (see page 1481)	:TRIGger:RUNT:POLarity? (see page 1481)	<polarity> ::= {POSitive NEGative EITHer}
:TRIGger:RUNT:QUALifier <qualifier> (see page 1482)	:TRIGger:RUNT:QUALifier? (see page 1482)	<qualifier> ::= {GREaterthan LESSthan NONE}
:TRIGger:RUNT:SOURce <source> (see page 1483)	:TRIGger:RUNT:SOURce? (see page 1483)	<source> ::= CHANnel<n> <n> ::= 1 to (# analog channels) in NR1 format
:TRIGger:RUNT:TIME <time>[suffix] (see page 1484)	:TRIGger:RUNT:TIME? (see page 1484)	<time> ::= floating-point number in NR3 format [suffix] ::= {s ms us ns ps}

:TRIGger:RUNT:POLarity

N (see [page 1730](#))

Command Syntax :TRIGger:RUNT:POLarity <polarity>

<polarity> ::= {POSitive | NEGative | EITHer}

The :TRIGger:RUNT:POLarity command sets the polarity for the runt trigger:

- POSitive – positive runt pulses.
- NEGative – negative runt pulses.
- EITHer – either positive or negative runt pulses.

Query Syntax :TRIGger:RUNT:POLarity?

The :TRIGger:RUNT:POLarity? query returns the runt trigger polarity.

Return Format <polarity><NL>

<polarity> ::= {POS | NEG | EITH}

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:MODE"](#) on page 1439
 - [":TRIGger:LEVel:HIGH"](#) on page 1437
 - [":TRIGger:LEVel:LOW"](#) on page 1438
 - [":TRIGger:RUNT:SOURce"](#) on page 1483

:TRIGger:RUNT:QUALifier

N (see [page 1730](#))

Command Syntax :TRIGger:RUNT:QUALifier <qualifier>

<qualifier> ::= {GREaterthan | LESSthan | NONE}

The :TRIGger:RUNT:QUALifier command selects the qualifier used for specifying runt pulse widths:

- GREaterthan – triggers on runt pulses whose width is greater than the :TRIGger:RUNT:TIME.
- LESSthan – triggers on runt pulses whose width is less than the :TRIGger:RUNT:TIME.
- NONE – triggers on runt pulses of any width.

Query Syntax :TRIGger:RUNT:QUALifier?

The :TRIGger:RUNT:QUALifier? query returns the runt trigger qualifier setting.

Return Format <qualifier><NL>

<qualifier> ::= {GRE | LESS NONE}

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:MODE"](#) on page 1439
 - [":TRIGger:RUNT:TIME"](#) on page 1484

:TRIGger:RUNT:SOURce

N (see [page 1730](#))

Command Syntax :TRIGger:RUNT:SOURce <source>

<source> ::= CHANnel<n>

<n> ::= 1 to (# analog channels) in NR1 format

The :TRIGger:RUNT:SOURce command selects the channel used to produce the trigger.

Query Syntax :TRIGger:RUNT:SOURce?

The :TRIGger:RUNT:SOURce? query returns the current runt trigger source.

Return Format <source><NL>

<source> ::= CHAN<n>

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:RUNT:POLarity"](#) on page 1481

:TRIGger:RUNT:TIME

N (see [page 1730](#))

Command Syntax :TRIGger:RUNT:TIME <time>[suffix]

<time> ::= floating-point number in NR3 format

[suffix] ::= {s | ms | us | ns | ps}

When triggering on runt pulses whose width is greater than or less than a certain value (see :TRIGger:RUNT:QUALifier), the :TRIGger:RUNT:TIME command specifies the time used with the qualifier.

Query Syntax :TRIGger:RUNT:TIME?

The :TRIGger:RUNT:TIME? query returns the current runt pulse qualifier time setting.

Return Format <time><NL>

<time> ::= floating-point number in NR3 format

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:RUNT:QUALifier"](#) on page 1482

:TRIGger:SHOLd Commands

Table 170 :TRIGger:SHOLd Commands Summary

Command	Query	Options and Query Returns
:TRIGger:SHOLd:SLOPe <slope> (see page 1486)	:TRIGger:SHOLd:SLOPe? (see page 1486)	<slope> ::= {NEGative POSitive}
:TRIGger:SHOLd:SOURce :CLOCK <source> (see page 1487)	:TRIGger:SHOLd:SOURce :CLOCK? (see page 1487)	<source> ::= {CHANnel<n> DIGital<d>} <n> ::= 1 to (# analog channels) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format
:TRIGger:SHOLd:SOURce :DATA <source> (see page 1488)	:TRIGger:SHOLd:SOURce :DATA? (see page 1488)	<source> ::= {CHANnel<n> DIGital<d>} <n> ::= 1 to (# analog channels) in NR1 format <d> ::= 0 to (# digital channels - 1) in NR1 format
:TRIGger:SHOLd:TIME:H OLD <time>[suffix] (see page 1489)	:TRIGger:SHOLd:TIME:H OLD? (see page 1489)	<time> ::= floating-point number in NR3 format [suffix] ::= {s ms us ns ps}
:TRIGger:SHOLd:TIME:S ETup <time>[suffix] (see page 1490)	:TRIGger:SHOLd:TIME:S ETup? (see page 1490)	<time> ::= floating-point number in NR3 format [suffix] ::= {s ms us ns ps}

:TRIGger:SHOLd:SLOPe

N (see [page 1730](#))

Command Syntax :TRIGger:SHOLd:SLOPe <slope>

<slope> ::= {NEGative | POSitive}

The :TRIGger:SHOLd:SLOPe command specifies whether the rising edge or the falling edge of the clock signal is used.

Query Syntax :TRIGger:SHOLd:SLOPe?

The :TRIGger:SHOLd:SLOPe? query returns the current rising or falling edge setting.

Return Format <slope><NL>

<slope> ::= {NEG | POS}

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:MODE"](#) on page 1439
 - [":TRIGger:SHOLd:SOURce:CLOCK"](#) on page 1487
 - [":TRIGger:SHOLd:SOURce:DATA"](#) on page 1488

:TRIGger:SHOLd:SOURce:CLOCK

N (see [page 1730](#))

Command Syntax :TRIGger:SHOLd:SOURce:CLOCK <source>

<source> ::= {CHANnel<n> | DIGital<d>}

<n> ::= 1 to (# analog channels) in NR1 format

<d> ::= 0 to (# digital channels - 1) in NR1 format

The :TRIGger:SHOLd:SOURce:CLOCK command selects the input channel probing the clock signal.

Query Syntax :TRIGger:SHOLd:SOURce:CLOCK?

The :TRIGger:SHOLd:SOURce:CLOCK? query returns the currently set clock signal source.

Return Format <source><NL>

<source> ::= {CHAN<n> | DIG<d>}

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:MODE"](#) on page 1439
 - [":TRIGger:SHOLd:SLOPe"](#) on page 1486

:TRIGger:SHOLd:SOURce:DATA

N (see [page 1730](#))

Command Syntax :TRIGger:SHOLd:SOURce:DATA <source>

<source> ::= {CHANnel<n> | DIGital<d>}

<n> ::= 1 to (# analog channels) in NR1 format

<d> ::= 0 to (# digital channels - 1) in NR1 format

The :TRIGger:SHOLd:SOURce:DATA command selects the input channel probing the data signal.

Query Syntax :TRIGger:SHOLd:SOURce:DATA?

The :TRIGger:SHOLd:SOURce:DATA? query returns the currently set data signal source.

Return Format <source><NL>

<source> ::= {CHAN<n> | DIG<d>}

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:MODE"](#) on page 1439
 - [":TRIGger:SHOLd:SLOPe"](#) on page 1486

:TRIGger:SHOLd:TIME:HOLD

N (see [page 1730](#))

Command Syntax :TRIGger:SHOLd:TIME:HOLD <time>[suffix]

<time> ::= floating-point number in NR3 format

[suffix] ::= {s | ms | us | ns | ps}

The :TRIGger:SHOLd:TIME:HOLD command sets the hold time.

Query Syntax :TRIGger:SHOLd:TIME:HOLD?

The :TRIGger:SHOLd:TIME:HOLD? query returns the currently specified hold time.

Return Format <time><NL>

<time> ::= floating-point number in NR3 format

See Also • ["Introduction to :TRIGger Commands"](#) on page 1425

:TRIGger:SHOLd:TIME:SETup

N (see [page 1730](#))

Command Syntax :TRIGger:SHOLd:TIME:SETup <time>[suffix]
 <time> ::= floating-point number in NR3 format
 [suffix] ::= {s | ms | us | ns | ps}

The :TRIGger:SHOLd:TIME:SETup command sets the setup time.

Query Syntax :TRIGger:SHOLd:TIME:SETup?

The :TRIGger:SHOLd:TIME:SETup? query returns the currently specified setup time.

Return Format <time><NL>
 <time> ::= floating-point number in NR3 format

See Also • ["Introduction to :TRIGger Commands"](#) on page 1425

:TRIGger:TRANSition Commands

The :TRIGger:TRANSition commands set the rise/fall time trigger options.

Table 171 :TRIGger:TRANSition Commands Summary

Command	Query	Options and Query Returns
:TRIGger:TRANSition:Q UALifier <qualifier> (see page 1492)	:TRIGger:TRANSition:Q UALifier? (see page 1492)	<qualifier> ::= {GREATERthan LESSthan}
:TRIGger:TRANSition:S LOPe <slope> (see page 1493)	:TRIGger:TRANSition:S LOPe? (see page 1493)	<slope> ::= {NEGative POSitive}
:TRIGger:TRANSition:S OURce <source> (see page 1494)	:TRIGger:TRANSition:S OURce? (see page 1494)	<source> ::= CHANNEL<n> <n> ::= 1 to (# analog channels) in NR1 format
:TRIGger:TRANSition:T IME <time>[suffix] (see page 1495)	:TRIGger:TRANSition:T IME? (see page 1495)	<time> ::= floating-point number in NR3 format [suffix] ::= {s ms us ns ps}

:TRIGger:TRANSition:QUALifier

N (see [page 1730](#))

Command Syntax :TRIGger:TRANSition:QUALifier <qualifier>

<qualifier> ::= {GREATERthan | LESSthan}

The :TRIGger:TRANSition:QUALifier command specifies whether you are looking for rise/fall times greater than or less than a certain time value. The time value is set using the :TRIGger:TRANSition:TIME command.

Query Syntax :TRIGger:TRANSition:QUALifier?

The :TRIGger:TRANSition:QUALifier? query returns the current rise/fall time trigger qualifier setting.

Return Format <qualifier><NL>

<qualifier> ::= {GRE | LESS}

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:TRANSition:TIME"](#) on page 1495
 - [":TRIGger:MODE"](#) on page 1439

:TRIGger:TRANSition:SLOPe

N (see [page 1730](#))

Command Syntax :TRIGger:TRANSition:SLOPe <slope>

<slope> ::= {NEGative | POSitive}

The :TRIGger:TRANSition:SLOPe command specifies a POSitive rising edge or a NEGative falling edge.

Query Syntax :TRIGger:TRANSition:SLOPe?

The :TRIGger:TRANSition:SLOPe? query returns the current rise/fall time trigger slope setting.

Return Format <slope><NL>

<slope> ::= {NEG | POS}

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:MODE"](#) on page 1439
 - [":TRIGger:TRANSition:SOURce"](#) on page 1494

:TRIGger:TRANSition:SOURce

N (see [page 1730](#))

Command Syntax :TRIGger:TRANSition:SOURce <source>

<source> ::= CHANnel<n>

<n> ::= 1 to (# analog channels) in NR1 format

The :TRIGger:TRANSition:SOURce command selects the channel used to produce the trigger.

Query Syntax :TRIGger:TRANSition:SOURce?

The :TRIGger:TRANSition:SOURce? query returns the current transition trigger source.

Return Format <source><NL>

<source> ::= CHAN<n>

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:MODE"](#) on page 1439
 - [":TRIGger:TRANSition:SLOPe"](#) on page 1493

:TRIGger:TRANSition:TIME

N (see [page 1730](#))

Command Syntax :TRIGger:TRANSition:TIME <time>[suffix]

<time> ::= floating-point number in NR3 format

[suffix] ::= {s | ms | us | ns | ps}

The :TRIGger:TRANSition:TIME command sets the time value for rise/fall time triggers. You also use the :TRIGger:TRANSition:QUALifier command to specify whether you are triggering on times greater than or less than this time value.

Query Syntax :TRIGger:TRANSition:TIME?

The :TRIGger:TRANSition:TIME? query returns the current rise/fall time trigger time value.

Return Format <time><NL>

<time> ::= floating-point number in NR3 format

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:TRANSition:QUALifier"](#) on page 1492

:TRIGger:TV Commands

Table 172 :TRIGger:TV Commands Summary

Command	Query	Options and Query Returns
:TRIGger:TV:LINE <line number> (see page 1497)	:TRIGger:TV:LINE? (see page 1497)	<line number> ::= integer in NR1 format
:TRIGger:TV:MODE <tv mode> (see page 1498)	:TRIGger:TV:MODE? (see page 1498)	<tv mode> ::= {FIELD1 FIELD2 AFIELDS ALINES LINE LFIELD1 LFIELD2 LALTERNATE}
:TRIGger:TV:POLarity <polarity> (see page 1499)	:TRIGger:TV:POLarity? (see page 1499)	<polarity> ::= {POSitive NEGative}
:TRIGger:TV:SOURce <source> (see page 1500)	:TRIGger:TV:SOURce? (see page 1500)	<source> ::= {CHANnel<n>} <n> ::= 1 to (# analog channels) in NR1 format
:TRIGger:TV:STANdard <standard> (see page 1501)	:TRIGger:TV:STANdard? (see page 1501)	<standard> ::= {NTSC PAL PALM SECam} <standard> ::= {GENeric {P480L60HZ P480} {P720L60HZ P720} {P1080L24HZ P1080} P1080L25HZ P1080L50HZ P1080L60HZ {I1080L50HZ I1080} I1080L60HZ} with extended video triggering license
:TRIGger:TV:UDTV:ENUM ber <count> (see page 1502)	:TRIGger:TV:UDTV:ENUM ber? (see page 1502)	<count> ::= edge number in NR1 format
:TRIGger:TV:UDTV:HSYN c {{0 OFF} {1 ON}} (see page 1503)	:TRIGger:TV:UDTV:HSYN c? (see page 1503)	{0 1}
:TRIGger:TV:UDTV:HTIM e <time> (see page 1504)	:TRIGger:TV:UDTV:HTIM e? (see page 1504)	<time> ::= seconds in NR3 format
:TRIGger:TV:UDTV:PGTH an <min_time> (see page 1505)	:TRIGger:TV:UDTV:PGTH an? (see page 1505)	<min_time> ::= seconds in NR3 format

:TRIGger:TV:LINE

N (see [page 1730](#))

Command Syntax :TRIGger:TV:LINE <line_number>

<line_number> ::= integer in NR1 format

The :TRIGger:TV:LINE command allows triggering on a specific line of video. The line number limits vary with the standard and mode, as shown in the following table.

Table 173 TV Trigger Line Number Limits

TV Standard	Mode				
	LINE	LField1	LField2	LALternate	VERTical
NTSC		1 to 263	1 to 262	1 to 262	
PAL		1 to 313	314 to 625	1 to 312	
PAL-M		1 to 263	264 to 525	1 to 262	
SECAM		1 to 313	314 to 625	1 to 312	
GENERIC		1 to 1024	1 to 1024		1 to 1024
P480L60HZ	1 to 525				
P720L60HZ	1 to 750				
P1080L24HZ	1 to 1125				
P1080L25HZ	1 to 1125				
P1080L50HZ	1 to 1125				
P1080L60HZ	1 to 1125				
I1080L50HZ	1 to 1125				
I1080L60HZ	1 to 1125				

Query Syntax :TRIGger:TV:LINE?

The :TRIGger:TV:LINE? query returns the current TV trigger line number setting.

Return Format <line_number><NL>

<line_number> ::= integer in NR1 format

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:TV:STANdard"](#) on page 1501
 - [":TRIGger:TV:MODE"](#) on page 1498

:TRIGger:TV:MODE

N (see [page 1730](#))

Command Syntax :TRIGger:TV:MODE <mode>

```
<mode> ::= {FIEld1 | FIEld2 | AFIElds | ALINes | LINE | LFIeld1
           | LFIeld2 | LALTernate}
```

The :TRIGger:TV:MODE command selects the TV trigger mode and field. The LALTernate parameter is not available when :TRIGger:TV:STANdard is GENeric.

Old forms for <mode> are accepted:

<mode>	Old Forms Accepted
FIEld1	F1
FIEld2	F2
AFIElds	ALLFields, ALLFLDS
ALINes	ALLLines
LFIeld1	LINEF1, LINEFIELD1
LFIeld2	LINEF2, LINEFIELD2
LALTernate	LINEAlt

Query Syntax :TRIGger:TV:MODE?

The :TRIGger:TV:MODE? query returns the TV trigger mode.

Return Format <value><NL>

```
<value> ::= {FIE1 | FIE2 | AFI | ALIN | LINE | LFI1 | LFI2 | LALT}
```

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:TV:STANdard"](#) on page 1501
 - [":TRIGger:MODE"](#) on page 1439

:TRIGger:TV:POLarity

N (see [page 1730](#))

Command Syntax :TRIGger:TV:POLarity <polarity>

<polarity> ::= {POSitive | NEGative}

The :TRIGger:TV:POLarity command sets the polarity for the TV trigger.

Query Syntax :TRIGger:TV:POLarity?

The :TRIGger:TV:POLarity? query returns the TV trigger polarity.

Return Format <polarity><NL>

<polarity> ::= {POS | NEG}

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:MODE"](#) on page 1439
 - [":TRIGger:TV:SOURce"](#) on page 1500

:TRIGger:TV:SOURce

N (see [page 1730](#))

Command Syntax :TRIGger:TV:SOURce <source>

<source> ::= {CHANnel<n>}

<n> ::= 1 to (# analog channels) in NR1 format

The :TRIGger:TV:SOURce command selects the channel used to produce the trigger.

Query Syntax :TRIGger:TV:SOURce?

The :TRIGger:TV:SOURce? query returns the current TV trigger source.

Return Format <source><NL>

<source> ::= {CHAN<n>}

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:MODE"](#) on page 1439
 - [":TRIGger:TV:POLarity"](#) on page 1499

Example Code • ["Example Code"](#) on page 1460

:TRIGger:TV:STANdard

N (see [page 1730](#))

Command Syntax :TRIGger:TV:STANdard <standard>

```
1234567890123456789012345678901234567890123456789012345678901234567890
```

```
<standard> ::= {GENeric | NTSC | PALM | PAL | SECam
  | {P480L60HZ | P480} | P567L50HZ | P720L50HZ | {P720L60HZ | P720}
  | {P1080L24HZ | P1080} | P1080L25HZ | P1080L30HZ | P1080L50HZ
  | P1080L60HZ | {I1080L50HZ | I1080} | I1080L60HZ}
```

The :TRIGger:TV:STANdard command selects the video standard:

- NTSC
- PAL
- PAL-M
- SECAM

With an extended Video triggering license, the oscilloscope additionally supports these standards:

- Generic – GENeric mode is non-interlaced.
- EDTV 480p/60
- EDTV 567p/50
- HDTV 720p/50
- HDTV 720p/60
- HDTV 1080p/24
- HDTV 1080p/25
- HDTV 1080p/30
- HDTV 1080i/50
- HDTV 1080i/60

Query Syntax :TRIGger:TV:STANdard?

The :TRIGger:TV:STANdard? query returns the current TV trigger standard setting.

Return Format <standard><NL>

```
<standard> ::= {GEN | NTSC | PALM | PAL | SEC | P480L60HZ | P567L50HZ
  | P720L50HZ | P760L60HZ | P1080L24HZ | P1080L25HZ | P1080L30HZ
  | P1080L50HZ | P1080L60HZ | I1080L50HZ | I1080L60HZ}
```

:TRIGger:TV:UDTV:ENUMber

N (see [page 1730](#))

Command Syntax :TRIGger:TV:UDTV:ENUMber <count>

<count> ::= edge number in NR1 format

The :TRIGger:TV:UDTV:ENUMber command specifies the Generic video trigger's Nth edge to trigger on after synchronizing with the vertical sync.

Query Syntax :TRIGger:TV:UDTV:ENUMber?

The :TRIGger:TV:UDTV:ENUMber query returns the edge count setting.

Return Format <count><NL>

<count> ::= edge number in NR1 format

- See Also**
- [":TRIGger:TV:STANdard"](#) on page 1501
 - [":TRIGger:TV:UDTV:PGTHan"](#) on page 1505
 - [":TRIGger:TV:UDTV:HSYNc"](#) on page 1503

:TRIGger:TV:UDTV:HSYNc

N (see [page 1730](#))

Command Syntax :TRIGger:TV:UDTV:HSYNc {{0 | OFF} | {1 | ON}}

The :TRIGger:TV:UDTV:HSYNc command enables or disables the horizontal sync control in the Generic video trigger.

For interleaved video, enabling the HSYNc control and setting the HTIME adjustment to the sync time of the probed video signal allows the ENUMber function to count only lines and not double count during equalization. Additionally, the Field Holdoff can be adjusted so that the oscilloscope triggers once per frame.

Similarly, for progressive video with a tri-level sync, enabling the HSYNc control and setting the HTIME adjustment to the sync time of the probed video signal allows the ENUMber function to count only lines and not double count during vertical sync.

Query Syntax :TRIGger:TV:UDTV:HSYNc?

The :TRIGger:TV:UDTV:HSYNc query returns the horizontal sync control setting.

Return Format {0 | 1}

- See Also**
- [":TRIGger:TV:STANdard"](#) on page 1501
 - [":TRIGger:TV:UDTV:HTIME"](#) on page 1504
 - [":TRIGger:TV:UDTV:ENUMber"](#) on page 1502
 - [":TRIGger:TV:UDTV:PGTHan"](#) on page 1505

:TRIGger:TV:UDTV:HTIME

N (see [page 1730](#))

Command Syntax :TRIGger:TV:UDTV:HTIME <time>

<time> ::= seconds in NR3 format

When the Generic video trigger's horizontal sync control is enabled, the :TRIGger:TV:UDTV:HTIME command sets the minimum time the horizontal sync pulse must be present to be considered valid.

Query Syntax :TRIGger:TV:UDTV:HTIME?

The :TRIGger:TV:UDTV:HTIME query returns the horizontal sync time setting.

Return Format <time><NL>

<time> ::= seconds in NR3 format

- See Also**
- [":TRIGger:TV:STANdard"](#) on page 1501
 - [":TRIGger:TV:UDTV:HSYNc"](#) on page 1503

:TRIGger:TV:UDTV:PGTHan

N (see [page 1730](#))

Command Syntax :TRIGger:TV:UDTV:PGTHan <min_time>
 <min_time> ::= seconds in NR3 format

The :TRIGger:TV:UDTV:PGTHan command specifies the "greater than the sync pulse width" time in the Generic video trigger. This setting allows oscilloscope synchronization to the vertical sync.

Query Syntax :TRIGger:TV:UDTV:PGTHan?

The :TRIGger:TV:UDTV:PGTHan query returns the "greater than the sync pulse width" time setting.

Return Format <min_time><NL>
 <min_time> ::= seconds in NR3 format

- See Also**
- [":TRIGger:TV:STANdard"](#) on page 1501
 - [":TRIGger:TV:UDTV:ENUMber"](#) on page 1502
 - [":TRIGger:TV:UDTV:HSYNc"](#) on page 1503

:TRIGger:ZONE Commands

Table 174 :TRIGger:ZONE Commands Summary

Command	Query	Options and Query Returns
:TRIGger:ZONE:SOURce <source> (see page 1507)	:TRIGger:ZONE:SOURce? (see page 1507)	<source> ::= {CHANnel<n>} <n> ::= 1 to (# analog channels) in NR1 format
:TRIGger:ZONE:STATe {{0 OFF} {1 ON}} (see page 1508)	:TRIGger:ZONE:STATe? (see page 1508)	{0 1}
:TRIGger:ZONE<n>:MODE <mode> (see page 1509)	:TRIGger:ZONE<n>:MODE ? (see page 1509)	<mode> ::= {INTersect NOTintersect} <n> ::= 1-2 in NR1 format
:TRIGger:ZONE<n>:PLAC ement <width>, <height>, <x_center>, <y_center> (see page 1510)	:TRIGger:ZONE<n>:PLAC ement? (see page 1510)	<width> ::= width of zone in seconds <height> ::= height of zone in volts <x_center> ::= center of zone in seconds <y_center> ::= center of zone in volts <n> ::= 1-2 in NR1 format
n/a	:TRIGger:ZONE<n>:VALi dity? (see page 1511)	<value> ::= {VALid INValid OSCRreen} <n> ::= 1-2 in NR1 format
:TRIGger:ZONE<n>:STAT e {{0 OFF} {1 ON}} (see page 1512)	:TRIGger:ZONE<n>:STAT e? (see page 1512)	{0 1} <n> ::= 1-2 in NR1 format

:TRIGger:ZONE:SOURce

N (see [page 1730](#))

Command Syntax :TRIGger:ZONE:SOURce <source>

<source> ::= {CHANnel<n>}

<n> ::= 1 to (# analog channels) in NR1 format

The :TRIGger:ZONE:SOURce command sets the analog source channel shared by all zones.

Query Syntax :TRIGger:ZONE:SOURce?

The :TRIGger:ZONE:SOURce? query returns the analog source channel specified for zone qualified triggers.

Return Format <source><NL>

<source> ::= {CHAN<n>}

See Also • [":TRIGger:ZONE:STATe"](#) on page 1508

:TRIGger:ZONE:STATe

N (see [page 1730](#))

Command Syntax :TRIGger:ZONE:STATe <on_off>

<on_off> ::= {{0 | OFF} | {1 | ON}}

The :TRIGger:ZONE:STATe command enables or disables the zone qualified trigger feature.

When the zone qualified trigger is on, the zone(s) are actively being used to qualify the trigger.

Note that the :TRIGger:ZONE<n>:STATe setting must also be ON for a zone to be active.

Note that :TRIGger:ZONE:STATe mimics the behavior of the **[Zone]** key on the front panel, and :TRIGger:ZONE<n>:STATe mimics the behavior of the **Zone 1 On** and **Zone 2 On** softkeys. At least one zone's state must be on for the Zone Trigger feature (:TRIGger:ZONE:STATe) to be on. When the states of both individual zones are turned off, Zone Trigger is automatically turned off. In this case, when Zone Trigger is turned back on Zone 1 is forced to on. Otherwise, if at least one zone was on when Zone Trigger was turned off, the same configuration of individual zone on/off states will be restored when Zone Trigger is turned back on.

Query Syntax :TRIGger:ZONE:STATe?

The :TRIGger:ZONE:STATe? query returns whether the zone qualified trigger feature is enabled or disabled.

Return Format <on_off><NL>

<on_off> ::= {0 | 1}

- See Also**
- **":TRIGger:ZONE<n>:STATe"** on page 1512
 - **":TRIGger:ZONE:SOURce"** on page 1507

:TRIGger:ZONE<n>:MODE

N (see [page 1730](#))

Command Syntax :TRIGger:ZONE<n>:MODE <mode>

<mode> ::= {INTersect | NOTintersect}

<n> ::= 1-2 in NR1 format

The :TRIGger:ZONE<n>:MODE command sets the zone qualifying condition for Zone 1 or Zone 2 as either "Must Intersect" or "Must Not Intersect".

Query Syntax :TRIGger:ZONE<n>:MODE?

The :TRIGger:ZONE<n>:MODE? query returns the zone qualifying condition for Zone 1 or Zone 2.

Return Format <mode><NL>

<mode> ::= {INT | NOT}

- See Also**
- [":TRIGger:ZONE<n>:STATe"](#) on page 1512
 - [":TRIGger:ZONE<n>:PLACement"](#) on page 1510
 - [":TRIGger:ZONE<n>:VALidity"](#) on page 1511

:TRIGger:ZONE<n>:PLACement

N (see [page 1730](#))

Command Syntax :TRIGger:ZONE<n>:PLACement <width>, <height>, <x_center>, <y_center>

<width> ::= width of zone in seconds

<height> ::= height of zone in volts

<x_center> ::= center of zone in seconds

<y_center> ::= center of zone in volts

<n> ::= 1-2 in NR1 format

The :TRIGger:ZONE<n>:PLACement command sets the size and location of Zone 1 or Zone 2.

No error is returned if the zone is placed off-screen, or if the zones overlap such that Zone 2 becomes invalid. The :TRIGger:ZONE<n>:VALidity? query is used to retrieve this information.

Query Syntax :TRIGger:ZONE<n>:PLACement?

The :TRIGger:ZONE<n>:PLACement? query returns the size and location of Zone 1 or Zone 2.

Return Format <opt><NL>

<opt> ::= <width>, <height>, <x_center>, <y_center>

- See Also**
- [":TRIGger:ZONE<n>:STATe"](#) on page 1512
 - [":TRIGger:ZONE<n>:MODE"](#) on page 1509
 - [":TRIGger:ZONE<n>:VALidity"](#) on page 1511

:TRIGger:ZONE<n>:VALidity

N (see [page 1730](#))

Query Syntax :TRIGger:ZONE<n>:VALidity?

<n> ::= 1-2 in NR1 format

The :TRIGger:ZONE<n>:VALidity? query returns the validity of Zone 1 or Zone 2.

- INValid is returned (for Zone 2 only) when Zone 1 and Zone 2 overlap and have opposing qualifying conditions (modes). Zone 1 can never be invalid.
- OSCReen (off-screen) is returned when the associated zone is off-screen, and thus not being used to qualify the trigger.
- A zone is valid when it is neither invalid nor off-screen.

The validity of a zone is not affected by the zone's state. For example, a zone can be valid and off. You cannot directly set the validity of a zone.

Return Format <validity><NL>

<validity> ::= {VALid | INValid | OSCReen}

- See Also**
- [":TRIGger:ZONE<n>:STATe"](#) on page 1512
 - [":TRIGger:ZONE<n>:MODE"](#) on page 1509
 - [":TRIGger:ZONE<n>:PLACement"](#) on page 1510

:TRIGger:ZONE<n>:STATe

N (see [page 1730](#))

Command Syntax :TRIGger:ZONE<n>:STATe <on_off>
 <n> ::= {1 | 2}
 <on_off> ::= {{0 | OFF} | {1 | ON}}
 <n> ::= 1-2 in NR1 format

The :TRIGger:ZONE<n>:STATe command sets the state for Zone 1 or Zone 2.

- When a zone's state is on, and the Zone Trigger feature is on (see [":TRIGger:ZONE:STATe"](#) on page 1508), that zone is actively being used to qualify the trigger if it is not invalid or off-screen (see [":TRIGger:ZONE<n>:VALidity"](#) on page 1511).
- When the Zone Trigger feature is off, no zones are being used to qualify the trigger, regardless of their individual states.

Note that :TRIGger:ZONE:STATe mimics the behavior of the **[Zone]** key on the front panel, and :TRIGger:ZONE<n>:STATe mimics the behavior of the **Zone 1 On** and **Zone 2 On** softkeys. At least one zone's state must be on for the Zone Trigger feature (:TRIGger:ZONE:STATe) to be on. When the states of both individual zones are turned off, Zone Trigger is automatically turned off. In this case, when Zone Trigger is turned back on Zone 1 is forced to on. Otherwise, if at least one zone was on when Zone Trigger was turned off, the same configuration of individual zone on/off states will be restored when Zone Trigger is turned back on.

Query Syntax :TRIGger:ZONE<n>:STATe?

The :TRIGger:ZONE<n>:STATe? query returns the state of Zone 1 or Zone 2.

Return Format <on_off><NL>
 <on_off> ::= {0 | 1}

- See Also**
- [":TRIGger:ZONE:STATe"](#) on page 1508
 - [":TRIGger:ZONE<n>:VALidity"](#) on page 1511

42 :WAVEform Commands

Provide access to waveform data. See "[Introduction to :WAVEform Commands](#)" on page 1516.

Table 175 :WAVEform Commands Summary

Command	Query	Options and Query Returns
:WAVEform:BYTeorder <value> (see page 1521)	:WAVEform:BYTeorder? (see page 1521)	<value> ::= {LSBFirst MSBFirst}
n/a	:WAVEform:COUnT? (see page 1522)	<count> ::= an integer from 1 to 65536 in NR1 format
n/a	:WAVEform:DATA? (see page 1523)	<binary block length bytes>, <binary data> For example, to transmit 1000 bytes of data, the syntax would be: #800001000<1000 bytes of data><NL> 8 is the number of digits that follow 00001000 is the number of bytes to be transmitted <1000 bytes of data> is the actual data
:WAVEform:FORMat <value> (see page 1525)	:WAVEform:FORMat? (see page 1525)	<value> ::= {WORD BYTE ASCII}
:WAVEform:POINts <wfm_points> (see page 1526)	:WAVEform:POINts? (see page 1526)	<wfm_points> ::= {<#_points> <points_mode>} <#_points> ::= an integer between 100 and 10000000 <points_mode> ::= {NORMal MAXimum RAW}

Table 175 :WAVeform Commands Summary (continued)

Command	Query	Options and Query Returns
:WAVeform:POINTs:MODE <points_mode> (see page 1528)	:WAVeform:POINTs:MODE ? (see page 1529)	<points_mode> ::= {NORMAL MAXimum RAW}
n/a	:WAVeform:PREAmble? (see page 1530)	<preamble_block> ::= <format NR1>, <type NR1>, <points NR1>, <count NR1>, <xincrement NR3>, <xorigin NR3>, <xreference NR1>, <yincrement NR3>, <yorigin NR3>, <yreference NR1> <format> ::= an integer in NR1 format: <ul style="list-style-type: none">• 0 for BYTE format• 1 for WORD format• 2 for ASCii format <type> ::= an integer in NR1 format: <ul style="list-style-type: none">• 0 for NORMal type• 1 for PEAK detect type• 3 for AVERAge type• 4 for HRESolution type <count> ::= Average count, or 1 if PEAK detect type or NORMal; an integer in NR1 format
:WAVeform:SEGmented:ALL {0 OFF} {1 ON} (see page 1533)	:WAVeform:SEGmented:ALL? (see page 1533)	<setting> ::= {0 1}
n/a	:WAVeform:SEGmented:COUNT? (see page 1534)	<count> ::= an integer from 2 to 1000 in NR1 format
n/a	:WAVeform:SEGmented:TAG? (see page 1535)	<time_tag> ::= in NR3 format
n/a	:WAVeform:SEGmented:XLIST? <xlist_type> (see page 1536)	<xlist_type> ::= {RELXorigin ABSXorigin TTAG} <return_value> ::= X-info for all segments

Table 175 :WAVeform Commands Summary (continued)

Command	Query	Options and Query Returns
:WAVeform:SOURce <source> (see page 1537)	:WAVeform:SOURce? (see page 1537)	<source> ::= {CHANnel<n> FUNCTION<m> MATH<m> SBUS} for DSO models <source> ::= {CHANnel<n> POD{1 2} BUS{1 2} FUNCTION<m> MATH<m> SBUS} for MSO models <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format
:WAVeform:SOURce:SUBS ource <subsource> (see page 1541)	:WAVeform:SOURce:SUBS ource? (see page 1541)	<subsource> ::= {{SUB0 RX MOSI} {SUB1 TX MISO}}
n/a	:WAVeform:TYPE? (see page 1542)	<return_mode> ::= {NORM PEAK AVER HRES}
:WAVeform:UNSigned {0 OFF} {1 ON}} (see page 1543)	:WAVeform:UNSigned? (see page 1543)	{0 1}
:WAVeform:VIEW <view> (see page 1544)	:WAVeform:VIEW? (see page 1544)	<view> ::= {MAIN}
n/a	:WAVeform:XINCrement? (see page 1545)	<return_value> ::= x-increment in the current preamble in NR3 format
n/a	:WAVeform:XORigin? (see page 1546)	<return_value> ::= x-origin value in the current preamble in NR3 format
n/a	:WAVeform:XREFerence? (see page 1547)	<return_value> ::= 0 (x-reference value in the current preamble in NR1 format)
n/a	:WAVeform:YINCrement? (see page 1548)	<return_value> ::= y-increment value in the current preamble in NR3 format
n/a	:WAVeform:YORigin? (see page 1549)	<return_value> ::= y-origin in the current preamble in NR3 format
n/a	:WAVeform:YREFerence? (see page 1550)	<return_value> ::= y-reference value in the current preamble in NR1 format

Introduction to :WAVEform Commands The WAVEform subsystem is used to transfer data to a controller from the oscilloscope waveform memories. The queries in this subsystem will only operate when the channel selected by :WAVEform:SOURce is on.

Waveform Data and Preamble

The waveform record is actually contained in two portions: the preamble and waveform data. The waveform record must be read from the oscilloscope by the controller using two separate commands, :WAVEform:DATA (see [page 1523](#)) and :WAVEform:PREAmble (see [page 1530](#)). The waveform data is the actual data acquired for each point in the specified source. The preamble contains the information for interpreting the waveform data, which includes the number of points acquired, the format of acquired data, and the type of acquired data. The preamble also contains the X and Y increments, origins, and references for the acquired data, so that word and byte data can be translated to time and voltage values.

Data Acquisition Types

There are four types of waveform acquisitions that can be selected for analog channels with the :ACQUIRE:TYPE command (see [page 318](#)): NORMal, AVERage, PEAK, and HRESolution. Digital channels are always acquired using NORMal. When the data is acquired using the :DIGitize command (see [page 270](#)) or :RUN command (see [page 294](#)), the data is placed in the channel buffer of the specified source.

Once you have acquired data with the :DIGitize command, the instrument is stopped. If the instrument is restarted (via the programming interface or the front panel), or if any instrument setting is changed, the data acquired with the :DIGitize command may be overwritten. You should first acquire the data with the :DIGitize command, then immediately read the data with the :WAVEform:DATA? query (see [page 1523](#)) before changing any instrument setup.

A waveform record consists of either all of the acquired points or a subset of the acquired points. The number of points acquired may be queried using :ACQUIRE:POINTS? (see [page 310](#)).

Helpful Hints:

The number of points transferred to the computer is controlled using the :WAVEform:POINTS command (see [page 1526](#)). If :WAVEform:POINTS MAXimum is specified and the instrument is not running (stopped), all of the points that are displayed are transferred. This can be as many as 4,000,000 in some operating modes or as many as 8,000,000 for a digital channel on the mixed signal oscilloscope. Fewer points may be specified to speed data transfers and minimize controller analysis time. The :WAVEform:POINTS may be varied even after data on a channel is acquired. However, this decimation may result in lost pulses and transitions. The number of points selected for transfer using :WAVEform:POINTS

must be an even divisor of 1,000 or be set to MAXimum. :WAVeform:POINts determines the increment between time buckets that will be transferred. If POINts = MAXimum, the data cannot be decimated. For example:

- :WAVeform:POINts 1000 – returns time buckets 0, 1, 2, 3, 4 ..., 999.
- :WAVeform:POINts 500 – returns time buckets 0, 2, 4, 6, 8 ..., 998.
- :WAVeform:POINts 250 – returns time buckets 0, 4, 8, 12, 16 ..., 996.
- :WAVeform:POINts 100 – returns time buckets 0, 10, 20, 30, 40 ..., 990.

Analog Channel Data

NORMAL Data

Normal data consists of the last data point (hit) in each time bucket. This data is transmitted over the programming interface in a linear fashion starting with time bucket 0 and going through time bucket $n - 1$, where n is the number returned by the :WAVeform:POINts? query (see [page 1526](#)). Only the magnitude values of each data point are transmitted. The first voltage value corresponds to the first time bucket on the left side of the screen and the last value corresponds to the next-to-last time bucket on the right side of the screen. Time buckets without data return 0. The time values for each data point correspond to the position of the data point in the data array. These time values are not transmitted.

AVERage Data

AVERage data consists of the average of the first n hits in a time bucket, where n is the value returned by the :ACQUIRE:COUNt query (see [page 306](#)). Time buckets that have fewer than n hits return the average of the data they do have. If a time bucket does not have any data in it, it returns 0.

This data is transmitted over the interface linearly, starting with time bucket 0 and proceeding through time bucket $n-1$, where n is the number returned by the :WAVeform:POINts? query (see [page 1526](#)). The first value corresponds to a point at the left side of the screen and the last value corresponds to one point away from the right side of the screen. The maximum number of points that can be returned in average mode is 1000 unless ACQUIRE:COUNt has been set to 1.

PEAK Data

Peak detect display mode is used to detect glitches for time base settings of 500 us/div and slower. In this mode, the oscilloscope can sample more data than it can store and display. So, when peak detect is turned on, the oscilloscope scans through the extra data, picks up the minimum and maximum for each time bucket, then stores the data in an array. Each time bucket contains two data sample.

The array is transmitted over the interface bus linearly, starting with time bucket 0 proceeding through time bucket $n-1$, where n is the number returned by the :WAVeform:POINts? query (see [page 1526](#)). In each time bucket, two values are transmitted, first the minimum, followed by the maximum. The first pair of values

corresponds to the time bucket at the leftmost side of the screen. The last pair of values corresponds to the time bucket at the far right side of the screen. In :ACQuire:TYPE PEAK mode (see [page 318](#)), the value returned by the :WAVeform:XINCrement query (see [page 1545](#)) should be doubled to find the time difference between the min-max pairs.

HREsolution Data

The high resolution (*smoothing*) mode is used to reduce noise at slower sweep speeds where the digitizer samples faster than needed to fill memory for the displayed time range.

Data Conversion

Word or byte data sent from the oscilloscope must be scaled for useful interpretation. The values used to interpret the data are the X and Y references, X and Y origins, and X and Y increments. These values are read from the waveform preamble. Each channel has its own waveform preamble.

In converting a data value to a voltage value, the following formula is used:

$$\text{voltage} = [(\text{data value} - \text{yreference}) * \text{yincrement}] + \text{yorigin}$$

If the :WAVeform:FORMat data format is ASCII (see [page 1525](#)), the data values are converted internally and sent as floating point values separated by commas.

In converting a data value to time, the time value of a data point can be determined by the position of the data point. For example, the fourth data point sent with :WAVeform:XORigin = 16 ns, :WAVeform:XREFerence = 0, and :WAVeform:XINCrement = 2 ns, can be calculated using the following formula:

$$\text{time} = [(\text{data point number} - \text{xreference}) * \text{xincrement}] + \text{xorigin}$$

This would result in the following calculation for time bucket 3:

$$\text{time} = [(3 - 0) * 2 \text{ ns}] + 16 \text{ ns} = 22 \text{ ns}$$

In :ACQuire:TYPE PEAK mode (see [page 318](#)), because data is acquired in max-min pairs, modify the previous time formula to the following:

$$\text{time} = [(\text{data pair number} - \text{xreference}) * \text{xincrement} * 2] + \text{xorigin}$$

Data Format for Transfer

There are three formats for transferring waveform data over the interface: BYTE, WORD and ASCII (see [":WAVeform:FORMat"](#) on page 1525). BYTE, WORD and ASCII formatted waveform records are transmitted using the arbitrary block program data format specified in IEEE 488.2.

When you use the block data format, the ASCII character string "#8<DD...D>" is sent prior to sending the actual data. The 8 indicates how many Ds follow. The Ds are ASCII numbers that indicate how many data bytes follow.

For example, if 1000 points will be transferred, and the WORD format was specified, the block header "#800001000" would be sent. The 8 indicates that eight length bytes follow, and 00001000 indicates that 1000 binary data bytes follow.

Use the :WAVeform:UNSigned command (see [page 1543](#)) to control whether data values are sent as unsigned or signed integers. This command can be used to match the instrument's internal data type to the data type used by the programming language. This command has no effect if the data format is ASCII.

Data Format for Transfer - ASCII format

The ASCII format (see [":WAVeform:FORMat"](#) on page 1525) provides access to the waveform data as real Y-axis values without using Y origin, Y reference, and Y increment to convert the binary data. Values are transferred as ASCII digits in floating point format separated by commas. In ASCII format, holes are represented by the value 9.9e+37. The setting of :WAVeform:BYTeorder (see [page 1521](#)) and :WAVeform:UNSigned (see [page 1543](#)) have no effect when the format is ASCII.

Data Format for Transfer - WORD format

WORD format (see [":WAVeform:FORMat"](#) on page 1525) provides 16-bit access to the waveform data. In the WORD format, the number of data bytes is twice the number of data points. The number of data points is the value returned by the :WAVeform:POINts? query (see [page 1526](#)). If the data intrinsically has less than 16 bits of resolution, the data is left-shifted to provide 16 bits of resolution and the least significant bits are set to 0. Currently, the greatest intrinsic resolution of any data is 12 bits, so at least the lowest 4 bits of data will be 0. If there is a hole in the data, the hole is represented by a 16 bit value equal to 0.

Use :WAVeform:BYTeorder (see [page 1521](#)) to determine if the least significant byte or most significant byte is to be transferred first. The :BYTeorder command can be used to alter the transmit sequence to match the storage sequence of an integer in the programming language being used.

Data Format for Transfer - BYTE format

The BYTE format (see [":WAVeform:FORMat"](#) on page 1525) allows 8-bit access to the waveform data. If the data intrinsically has more than 8 bits of resolution (averaged data), the data is right-shifted (truncated) to fit into 8 bits. If there is a hole in the data, the hole is represented by a value of 0. The BYTE-formatted data transfers over the programming interface faster than ASCII or WORD-formatted data, because in ASCII format, as many as 13 bytes per point are transferred, in BYTE format one byte per point is transferred, and in WORD format two bytes per point are transferred.

The :WAVeform:BYTeorder command (see [page 1521](#)) has no effect when the data format is BYTE.

Digital Channel Data (MSO models only)

The waveform record for digital channels is similar to that of analog channels. The main difference is that the data points represent either DIGital0,...,7 (POD1), DIGital8,...,15 (POD2), or any grouping of digital channels (BUS1 or BUS2).

For digital channels, :WAVEform:UNSigned (see [page 1543](#)) must be set to ON.

Digital Channel POD Data Format

Data for digital channels is only available in groups of 8 bits (Pod1 = D0 - D7, Pod2 = D8 - D15). The bytes are organized as:

:WAVEform:SOURce	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
POD1	D7	D6	D5	D4	D3	D2	D1	D0
POD2	D15	D14	D13	D12	D11	D10	D9	D8

If the :WAVEform:FORMat is WORD (see [page 1525](#)) is WORD, every other data byte will be 0. The setting of :WAVEform:BYTeorder (see [page 1521](#)) controls which byte is 0.

If a digital channel is not displayed, its bit value in the pod data byte is not defined.

Digital Channel BUS Data Format

Digital channel BUS definitions can include any or all of the digital channels. Therefore, data is always returned as 16-bit values. :BUS commands (see [page 321](#)) are used to select the digital channels for a bus.

Reporting the Setup

The following is a sample response from the :WAVEform? query. In this case, the query was issued following a *RST command.

```
:WAV:UNS 1;VIEW MAIN;BYT MSBF;FORM BYTE;POIN +1000;SOUR CHAN1;SOUR:SUBS
NONE
```


:WAVEform:BYTeorder

C (see [page 1730](#))

Command Syntax :WAVEform:BYTeorder <value>
 <value> ::= {LSBFirst | MSBFirst}

The :WAVEform:BYTeorder command sets the output sequence of the WORD data.

- MSBFirst – sets the most significant byte to be transmitted first.
- LSBFirst – sets the least significant byte to be transmitted first.

This command affects the transmitting sequence only when :WAVEform:FORMat WORD is selected.

The default setting is MSBFirst.

Query Syntax :WAVEform:BYTeorder?

The :WAVEform:BYTeorder query returns the current output sequence.

Return Format <value><NL>
 <value> ::= {LSBF | MSBF}

- See Also**
- ["Introduction to :WAVEform Commands"](#) on page 1516
 - [":WAVEform:DATA"](#) on page 1523
 - [":WAVEform:FORMat"](#) on page 1525
 - [":WAVEform:PREamble"](#) on page 1530

- Example Code**
- ["Example Code"](#) on page 1538
 - ["Example Code"](#) on page 1531

:WAVEform:COUNT

C (see [page 1730](#))

Query Syntax :WAVEform:COUNT?

The :WAVEform:COUNT? query returns the count used to acquire the current waveform. This may differ from current values if the unit has been stopped and its configuration modified. For all acquisition types except average, this value is 1.

Return Format <count_argument><NL>

<count_argument> ::= an integer from 1 to 65536 in NR1 format

- See Also**
- ["Introduction to :WAVEform Commands"](#) on page 1516
 - [":ACQUIRE:COUNT"](#) on page 306
 - [":ACQUIRE:TYPE"](#) on page 318

:WAVeform:DATA

C (see [page 1730](#))

Query Syntax :WAVeform:DATA?

The :WAVeform:DATA query returns the binary block of sampled data points transmitted using the IEEE 488.2 arbitrary block data format. The binary data is formatted according to the settings of the :WAVeform:UNSIGNED, :WAVeform:BYTEORDER, :WAVeform:FORMAT, and :WAVeform:SOURCE commands. The number of points returned is controlled by the :WAVeform:POINTS command.

In BYTE or WORD waveform formats, these data values have special meaning:

- 0x00 or 0x0000 – Hole. Holes are locations where data has not yet been acquired.

Another situation where there can be zeros in the data, incorrectly, is when programming over telnet port 5024. Port 5024 provides a command prompt and is intended for ASCII transfers. Use telnet port 5025 instead.

- 0x01 or 0x0001 – Clipped low. These are locations where the waveform is clipped at the bottom of the oscilloscope display.
- 0xFF or 0xFFFF – Clipped high. These are locations where the waveform is clipped at the top of the oscilloscope display.

Return Format <binary block data><NL>

- See Also**
- For a more detailed description of the data returned for different acquisition types, see: "[Introduction to :WAVeform Commands](#)" on page 1516
 - "[:WAVeform:UNSIGNED](#)" on page 1543
 - "[:WAVeform:BYTEORDER](#)" on page 1521
 - "[:WAVeform:FORMAT](#)" on page 1525
 - "[:WAVeform:POINTS](#)" on page 1526
 - "[:WAVeform:PREAmble](#)" on page 1530
 - "[:WAVeform:SOURce](#)" on page 1537
 - "[:WAVeform:TYPE](#)" on page 1542

Example Code

```
' QUERY_WAVE_DATA - Outputs waveform data that is stored in a buffer.
'
' Query the oscilloscope for the waveform data.
myScope.WriteString ":WAV:DATA?"

' READ_WAVE_DATA - The wave data consists of two parts: the header,
' and the actual waveform data followed by a new line (NL) character.
' The query data has the following format:
'
'     <header><waveform_data><NL>
'
' Where:
```

```

' <header> = #800001000 (This is an example header)
' The "#8" may be stripped off of the header and the remaining
' numbers are the size, in bytes, of the waveform data block. The
' size can vary depending on the number of points acquired for the
' waveform. You can then read that number of bytes from the
' oscilloscope and the terminating NL character.
'
Dim lngI As Long
Dim lngDataValue As Long

varQueryResult = myScope.ReadIEEEBlock(BinaryType_UI1)
' Unsigned integer bytes.
For lngI = 0 To UBound(varQueryResult) - 1 Step (UBound(varQueryResult) / 20) ' 20 points.
    If intBytesPerData = 2 Then
        lngDataValue = varQueryResult(lngI) * 256 + varQueryResult(lngI + 1) ' 16-bit value.
    Else
        lngDataValue = varQueryResult(lngI) ' 8-bit value.
    End If
    strOutput = strOutput + "Data point " + CStr(lngI / intBytesPerData) + ", " + FormatNumber((lngDataValue - lngYReference) * sngYIncrement + sngYOrigin) + " V, " + FormatNumber(((lngI / intBytesPerData - lngXReference) * sngXIncrement + dblXOrigin) * 1000000) + " us" + vbCrLf
Next lngI
MsgBox "Waveform data:" + vbCrLf + strOutput

```

See complete example programs at: [Chapter 50](#), "Programming Examples," starting on page 1739

:WAVeform:FORMat

C (see [page 1730](#))

Command Syntax :WAVeform:FORMat <value>

<value> ::= {WORD | BYTE | ASCii}

The :WAVeform:FORMat command sets the data transmission mode for waveform data points. This command controls how the data is formatted when sent from the oscilloscope.

- ASCII formatted data converts the internal integer data values to real Y-axis values. Values are transferred as ASCII digits in floating point notation, separated by commas.
ASCII formatted data is transferred ASCII text.
- WORD formatted data transfers 16-bit data as two bytes. The :WAVeform:BYTeorder command can be used to specify whether the upper or lower byte is transmitted first. The default (no command sent) is that the upper byte transmitted first.
- BYTE formatted data is transferred as 8-bit bytes.

When the :WAVeform:SOURce is the serial decode bus (SBUS1 or SBUS2), ASCII is the only waveform format allowed.

When the :WAVeform:SOURce is one of the digital channel buses (BUS1 or BUS2), ASCII and WORD are the only waveform formats allowed.

Query Syntax :WAVeform:FORMat?

The :WAVeform:FORMat query returns the current output format for the transfer of waveform data.

Return Format <value><NL>

<value> ::= {WORD | BYTE | ASC}

- See Also**
- ["Introduction to :WAVeform Commands"](#) on page 1516
 - [":WAVeform:BYTeorder"](#) on page 1521
 - [":WAVeform:SOURce"](#) on page 1537
 - [":WAVeform:DATA"](#) on page 1523
 - [":WAVeform:PREamble"](#) on page 1530

Example Code • ["Example Code"](#) on page 1538

:WAVEform:POINts

C (see [page 1730](#))

Command Syntax :WAVEform:POINts <wfm_points>
 <wfm_points> ::= {<#_points> | <points_mode>}
 <#_points> ::= an integer between 100 and 10000000
 <points_mode> ::= {NORMal | MAXimum | RAW}

NOTE

The <points_mode> option is deprecated. Use the :WAVEform:POINts:MODE command instead.

The :WAVEform:POINts command sets the desired number of analog channel waveform points to be transferred with the :WAVEform:DATA? query. (The number of digital channel waveform points cannot be specified.) This value represents the points contained in the waveform selected with the :WAVEform:SOURce command.

For the analog or digital sources, the records that can be transferred depend on the waveform points mode. The maximum number of points returned for math (function) waveforms is determined by the NORMal waveform points mode. See the :WAVEform:POINts:MODE command (see [page 1528](#)) for more information.

To get the maximum number of points possible, you can set the waveform points mode to MAXimum and ask for 10,000,000 points, which is the command's request limit (not the maximum memory depth of the oscilloscope).

Only data visible on the display will be returned.

When the :WAVEform:SOURce is the serial decode bus (SBUS1 or SBUS2), this command is ignored, and all available serial decode bus data is returned.

Query Syntax :WAVEform:POINts?

The :WAVEform:POINts query returns the number of waveform points to be transferred when using the :WAVEform:DATA? query. Setting the points mode will affect what data is transferred (see the :WAVEform:POINts:MODE command (see [page 1528](#)) for more information).

In any waveform points mode, the oscilloscope returns as close to the requested number of points as possible, but the actual number of points available depends on oscilloscope settings.

When the :WAVEform:SOURce is the serial decode bus (SBUS1 or SBUS2), this query returns the number of messages that were decoded.

Return Format <#_points><NL>
 <#_points> ::= an integer number of waveform points

- See Also
- ["Introduction to :WAVeform Commands"](#) on page 1516
 - [":ACQuire:POINts"](#) on page 310
 - [":WAVeform:DATA"](#) on page 1523
 - [":WAVeform:SOURce"](#) on page 1537
 - [":WAVeform:VIEW"](#) on page 1544
 - [":WAVeform:PREamble"](#) on page 1530
 - [":WAVeform:POINts:MODE"](#) on page 1528

Example Code

```
' WAVE_POINTS - Specifies the number of points to be transferred
' using the ":WAVeform:DATA?" query.
myScope.WriteString ":WAVeform:POINTS 1000"
```

See complete example programs at: [Chapter 50](#), "Programming Examples," starting on page 1739

:WAVEform:POINts:MODE

N (see [page 1730](#))

Command Syntax :WAVEform:POINts:MODE <points_mode>

<points_mode> ::= {NORMal | MAXimum | RAW}

The :WAVEform:POINts:MODE command sets the data record to be transferred with the :WAVEform:DATA? query.

For the analog or digital sources, there are three different records that can be transferred:

- The first is the raw acquisition record. The maximum number of points available in this record is returned by the :ACQUIRE:POINts? query. The raw acquisition record can only be retrieved from the analog or digital sources.
- The second is referred to as the *measurement record* and is a 65,535-point (maximum) representation of the raw acquisition record. The measurement record can be retrieved, when :SYSTEM:PRECision is OFF, from any source.
- The third is referred to as the *precision analysis record* and is a user-selectable 100k-point to 1M-point (maximum) representation of the raw acquisition record. The precision analysis record can be retrieved when :SYSTEM:PRECision is ON, from analog sources.

If the <points_mode> is NORMal and :SYSTEM:PRECision is OFF, the measurement record is retrieved.

If the <points_mode> is NORMal and :SYSTEM:PRECision is ON, the precision analysis record is retrieved.

If the <points_mode> is RAW, the raw acquisition record is used. Under some conditions, this data record is unavailable.

If the <points_mode> is MAXimum, whichever record contains the maximum amount of points is used. Usually, this is the raw acquisition record. But, the measurement record may have more data. If data is being retrieved as the oscilloscope is stopped and as the data displayed is changing, the data being retrieved can switch between the measurement and raw acquisition records.

NOTE

If the :WAVEform:SOURce is not an analog or digital source, the only valid parameters for WAVEform:POINts:MODE is NORMal or MAXimum.

Considerations for MAXimum or RAW data retrieval

- The instrument must be stopped (see the :STOP command (see [page 298](#)) or the :DIGitize command (see [page 270](#)) in the root subsystem) in order to return more than the *measurement record* or *precision analysis record*.
- :TIMEbase:MODE must be set to MAIN.
- :ACQUIRE:TYPE must be set to NORMal, AVERage, or HRESolution.

- MAXimum or RAW will allow up to 4,000,000 points to be returned. The number of points returned will vary as the instrument's configuration is changed. Use the :WAVEform:POINts? MAXimum query to determine the maximum number of points that can be retrieved at the current settings.

Query Syntax :WAVEform:POINts:MODE?

The :WAVEform:POINts:MODE? query returns the current points mode. Setting the points mode will affect what data is transferred. See the discussion above.

Return Format <points_mode><NL>

<points_mode> ::= {NORMal | MAXimum | RAW}

- See Also**
- ["Introduction to :WAVEform Commands"](#) on page 1516
 - [":WAVEform:DATA"](#) on page 1523
 - [":ACQuire:POINts"](#) on page 310
 - [":SYSTem:PRECision"](#) on page 1393
 - [":WAVEform:VIEW"](#) on page 1544
 - [":WAVEform:PREamble"](#) on page 1530
 - [":WAVEform:POINts"](#) on page 1526
 - [":TIMEbase:MODE"](#) on page 1413
 - [":ACQuire:TYPE"](#) on page 318
 - [":ACQuire:COUNT"](#) on page 306
 - [":SYSTem:PRECision"](#) on page 1393
 - [":SYSTem:PRECision:LENGth"](#) on page 1394

:WAVEform:PREamble

C (see [page 1730](#))

Query Syntax :WAVEform:PREamble?

The :WAVEform:PREamble query requests the preamble information for the selected waveform source. The preamble data contains information concerning the vertical and horizontal scaling of the data of the corresponding channel.


Return Format <preamble_block><NL>

```
<preamble_block> ::= <format 16-bit NR1>,
                    <type 16-bit NR1>,
                    <points 32-bit NR1>,
                    <count 32-bit NR1>,
                    <xincrement 64-bit floating point NR3>,
                    <xorigin 64-bit floating point NR3>,
                    <xreference 32-bit NR1>,
                    <yincrement 32-bit floating point NR3>,
                    <yorigin 32-bit floating point NR3>,
                    <yreference 32-bit NR1>
```

<format> ::= 0 for BYTE format, 1 for WORD format, 4 for ASCII format; an integer in NR1 format (format set by :WAVEform:FORMat).

<type> ::= 3 for HRESolution type, 2 for AVERAge type, 0 for NORMAl type, 1 for PEAK detect type; an integer in NR1 format (type set by :ACQuire:TYPE).

<count> ::= Average count or 1 if PEAK or NORMAL; an integer in NR1 format (count set by :ACQuire:COUNT).



- See Also**
- ["Introduction to :WAVEform Commands"](#) on page 1516
 - [":ACQuire:COUNT"](#) on page 306
 - [":ACQuire:POINts"](#) on page 310

- ":ACQuire:TYPE" on page 318
- ":DIGitize" on page 270
- ":WAVEform:COUNT" on page 1522
- ":WAVEform:DATA" on page 1523
- ":WAVEform:FORMat" on page 1525
- ":WAVEform:POINts" on page 1526
- ":WAVEform:TYPE" on page 1542
- ":WAVEform:XINCrement" on page 1545
- ":WAVEform:XORigin" on page 1546
- ":WAVEform:XREFerence" on page 1547
- ":WAVEform:YINCrement" on page 1548
- ":WAVEform:YORigin" on page 1549
- ":WAVEform:YREFerence" on page 1550

Example Code

```
' GET_PREAMBLE - The preamble block contains all of the current
' WAVEFORM settings. It is returned in the form <preamble_block><NL>
' where <preamble_block> is:
'   FORMAT      : int16 - 0 = BYTE, 1 = WORD, 4 = ASCII.
'   TYPE        : int16 - 0 = NORM, 1 = PEAK, 2 = AVER, 3 = HRES
'   POINTS      : int32 - number of data points transferred.
'   COUNT       : int32 - 1 and is always 1.
'   XINCREMENT  : float64 - time difference between data points.
'   XORIGIN     : float64 - always the first data point in memory.
'   XREFERENCE  : int32 - specifies the data point associated with
'                   x-origin.
'   YINCREMENT  : float32 - voltage diff between data points.
'   YORIGIN     : float32 - value is the voltage at center screen.
'   YREFERENCE  : int32 - specifies the data point where y-origin
'                   occurs.

Dim Preamble()
Dim intFormat As Integer
Dim intType As Integer
Dim lngPoints As Long
Dim lngCount As Long
Dim dblXIncrement As Double
Dim dblXOrigin As Double
Dim lngXReference As Long
Dim sngYIncrement As Single
Dim sngYOrigin As Single
Dim lngYReference As Long
Dim strOutput As String

myScope.WriteString ":WAVEFORM:PREAMBLE?" ' Query for the preamble.
Preamble() = myScope.ReadList ' Read preamble information.
intFormat = Preamble(0)
intType = Preamble(1)
lngPoints = Preamble(2)
lngCount = Preamble(3)
dblXIncrement = Preamble(4)
```

```
dblXOrigin = Preamble(5)
lngXReference = Preamble(6)
sngYIncrement = Preamble(7)
sngYOrigin = Preamble(8)
lngYReference = Preamble(9)
```

See complete example programs at: [Chapter 50](#), “Programming Examples,” starting on page 1739

:WAVEform:SEGMENTed:ALL

N (see [page 1730](#))

Command Syntax :WAVEform:SEGMENTed:ALL {0 | OFF} | {1 | ON}}

The :WAVEform:SEGMENTed:ALL command enables or disables the "waveform data for all segments" setting:

- ON – The :WAVEform:DATA? query returns data for all segments.
ON is available only when the :WAVEform:SOURce is an analog input channel.
When ON, the :WAVEform:DATA? query returns data for the number of segments multiplied by the number of points in a segment (which is the points value returned by the :WAVEform:POINTs? or :WAVEform:PREAmble? queries).
- OFF – The :WAVEform:DATA? query returns data for the current segment.

The ability to get waveform data for all segments is faster and more convenient than iterating over multiple segments and retrieving each one separately.

The performance improvement comes primarily when raw acquisition record data is being retrieved (:WAVEform:POINTs:MODE RAW) instead of the measurement record data (:WAVEform:POINTs:MODE NORMAl).

One corner case where you may want to retrieve the measurement record data is when the acquired data for a segment is less than the screen resolution and the measurement record is interpolated.

Most often though, the acquired data for a segment is enough to fill the screen, and less than the maximum measurement record size, so the segmented raw acquisition data and the measurement record data are the same.

If the number of segments is small, the raw acquisition segment size is greater than the measurement record size.

Query Syntax :WAVEform:SEGMENTed:ALL?

The :WAVEform:SEGMENTed:ALL? query returns the "waveform data for all segments" setting.

Return Format <setting><NL>

<setting> ::= {0 | 1}

- See Also**
- [":WAVEform:DATA"](#) on page 1523
 - [":WAVEform:SEGMENTed:XLISt"](#) on page 1536
 - [":WAVEform:POINTs:MODE"](#) on page 1528
 - [":WAVEform:POINTs"](#) on page 1526
 - [":WAVEform:PREAmble"](#) on page 1530

:WAVeform:SEGMented:COUNT

N (see [page 1730](#))

Query Syntax :WAVeform:SEGMented:COUNT?

The :WAVeform:SEGMented:COUNT query returns the number of memory segments in the acquired data. You can use the :WAVeform:SEGMented:COUNT? query while segments are being acquired (although :DIGitize blocks subsequent queries until the full segmented acquisition is complete).

The segmented memory acquisition mode is enabled with the :ACQUIRE:MODE command. The number of segments to acquire is set using the :ACQUIRE:SEGMented:COUNT command, and data is acquired using the :DIGitize, :SINGLE, or :RUN commands.

Return Format <count> ::= an integer from 2 to 1000 in NR1 format (count set by :ACQUIRE:SEGMented:COUNT).

- See Also**
- [":ACQUIRE:MODE"](#) on page 308
 - [":ACQUIRE:SEGMented:COUNT"](#) on page 313
 - [":DIGitize"](#) on page 270
 - [":SINGLE"](#) on page 296
 - [":RUN"](#) on page 294
 - ["Introduction to :WAVeform Commands"](#) on page 1516

Example Code • ["Example Code"](#) on page 314

:WAVEform:SEGMented:TTAG

N (see [page 1730](#))

Query Syntax :WAVEform:SEGMented:TTAG?

The :WAVEform:SEGMented:TTAG? query returns the time tag of the currently selected segmented memory index. The index is selected using the :ACQUIRE:SEGMented:INDEX command.

Return Format <time_tag> ::= in NR3 format

- See Also**
- [":ACQUIRE:SEGMented:INDEX"](#) on page 314
 - ["Introduction to :WAVEform Commands"](#) on page 1516

Example Code • ["Example Code"](#) on page 314

:WAVEform:SEGMented:XLISt

N (see [page 1730](#))

Query Syntax :WAVEform:SEGMented:XLISt? <xlist_type>

<xlist_type> ::= {RELXorigin | ABSXorigin | TTAG}

The :WAVEform:SEGMented:XLISt? query returns the X (time) information for all segments at once. The <xlist_type> option specifies the type of information that is returned:

- RELXorigin – The relative X-origin for each segment (the value returned by the :WAVEform:XORigin? query) is returned.
- TTAG – The time tag for each segment (the value returned by the :WAVEform:SEGMented:TTAG? query) will be returned.
- ABSXorigin – The sum of the values of the RELXorigin and TTAG types is returned for each segment.

This command is useful when getting the waveform data for all segments at once (see :WAVEform:SEGMented:ALL).

Return Format <return_value><NL>

<return_value> ::= binary block data in IEEE 488.2 # format, contains comma-separated string with X-info for all segments

- See Also**
- [":WAVEform:XORigin"](#) on page 1546
 - [":WAVEform:SEGMented:TTAG"](#) on page 1535
 - [":WAVEform:SEGMented:ALL"](#) on page 1533

:WAVEform:SOURce

C (see [page 1730](#))

Command Syntax

```
:WAVEform:SOURce <source>
```

```
<source> ::= {CHANnel<n> | FUNction<m> | MATH<m> | WMEMory<r>
             | SBUS{1 | 2}} for DSO models
```

```
<source> ::= {CHANnel<n> | POD{1 | 2} | BUS{1 | 2} | FUNction<m>
             | MATH<m> | WMEMory<r> | SBUS{1 | 2}}
             for MSO models
```

```
<n> ::= 1 to (# analog channels) in NR1 format
```

```
<m> ::= 1 to (# math functions) in NR1 format
```

```
<r> ::= 1 to (# ref waveforms) in NR1 format
```

The :WAVEform:SOURce command selects the analog channel, function, digital pod, digital bus, reference waveform, or serial decode bus to be used as the source for the :WAVEform commands.

Function capabilities include add, subtract, multiply, integrate, differentiate, and FFT (Fast Fourier Transform) operations.

When the :WAVEform:SOURce is the serial decode bus (SBUS1 or SBUS2), ASCII is the only waveform format allowed, and the :WAVEform:DATA? query returns a string with timestamps and associated bus decode information.

With MSO oscilloscope models, you can choose a POD or BUS as the waveform source. There are some differences between POD and BUS when formatting and getting data from the oscilloscope:

- When POD1 or POD2 is selected as the waveform source, you can choose the BYTE, WORD, or ASCII formats (see **":WAVEform:FORMat"** on page 1525).

When the WORD format is chosen, every other data byte will be 0. The setting of :WAVEform:BYTeorder controls which byte is 0.

When the ASCII format is chosen, the :WAVEform:DATA? query returns a string with unsigned decimal values separated by commas.

- When BUS1 or BUS2 is selected as the waveform source, you can choose the WORD or ASCII formats (but not BYTE because bus values are always returned as 16-bit values).

When the ASCII format is chosen, the :WAVEform:DATA? query returns a string with hexadecimal bus values, for example: 0x1938,0xff38,...

Query Syntax

```
:WAVEform:SOURce?
```

The :WAVEform:SOURce? query returns the currently selected source for the WAVEform commands.

NOTE

MATH<m> is an alias for FUNCtion<m>. The :WAVEform:SOURce? query returns FUNC<m> if the source is FUNCtion<m> or MATH<m>.

Return Format

<source><NL>

<source> ::= {CHAN<n> | FUNC<m> | WMEM<r> | SBUS{1 | 2}} for DSO models

<source> ::= {CHAN<n> | POD{1 | 2} | BUS{1 | 2} | FUNC<m>
| WMEM<r> | SBUS{1 | 2}} for MSO models

<n> ::= 1 to (# analog channels) in NR1 format

<m> ::= 1 to (# math functions) in NR1 format

<r> ::= 1 to (# ref waveforms) in NR1 format

See Also

- ["Introduction to :WAVEform Commands"](#) on page 1516
- [":DIGitize"](#) on page 270
- [":WAVEform:FORMat"](#) on page 1525
- [":WAVEform:BYTeorder"](#) on page 1521
- [":WAVEform:DATA"](#) on page 1523
- [":WAVEform:PREamble"](#) on page 1530

Example Code

```
' WAVEFORM_DATA - To obtain waveform data, you must specify the
' WAVEFORM parameters for the waveform data prior to sending the
' ":WAVEFORM:DATA?" query. Once these parameters have been sent,
' the waveform data and the preamble can be read.
'
' WAVE_SOURCE - Selects the channel to be used as the source for
' the waveform commands.
myScope.WriteString ":WAVEFORM:SOURCE CHAN1"

' WAVE_POINTS - Specifies the number of points to be transferred
' using the ":WAVEFORM:DATA?" query.
myScope.WriteString ":WAVEFORM:POINTS 1000"

' WAVE_FORMAT - Sets the data transmission mode for the waveform
' data output. This command controls whether data is formatted in
' a word or byte format when sent from the oscilloscope.
Dim lngVSteps As Long
Dim intBytesPerData As Integer

' Data in range 0 to 65535.
myScope.WriteString ":WAVEFORM:FORMAT WORD"
lngVSteps = 65536
intBytesPerData = 2

' Data in range 0 to 255.
myScope.WriteString ":WAVEFORM:FORMAT BYTE"
lngVSteps = 256
intBytesPerData = 1

' GET_PREAMBLE - The preamble block contains all of the current
```

```

' WAVEFORM settings. It is returned in the form <preamble_block><NL>
' where <preamble_block> is:
'   FORMAT      : int16 - 0 = BYTE, 1 = WORD, 4 = ASCII.
'   TYPE        : int16 - 0 = NORMAL, 1 = PEAK DETECT, 2 = AVERAGE
'   POINTS      : int32 - number of data points transferred.
'   COUNT       : int32 - 1 and is always 1.
'   XINCREMENT  : float64 - time difference between data points.
'   XORIGIN     : float64 - always the first data point in memory.
'   XREFERENCE  : int32 - specifies the data point associated with
'                   x-origin.
'   YINCREMENT  : float32 - voltage diff between data points.
'   YORIGIN     : float32 - value is the voltage at center screen.
'   YREFERENCE  : int32 - specifies the data point where y-origin
'                   occurs.
Dim Preamble()
Dim intFormat As Integer
Dim intType As Integer
Dim lngPoints As Long
Dim lngCount As Long
Dim dblXIncrement As Double
Dim dblXOrigin As Double
Dim lngXReference As Long
Dim sngYIncrement As Single
Dim sngYOrigin As Single
Dim lngYReference As Long
Dim strOutput As String

myScope.WriteString ":WAVEFORM:PREAMBLE?" ' Query for the preamble.
Preamble() = myScope.ReadList ' Read preamble information.
intFormat = Preamble(0)
intType = Preamble(1)
lngPoints = Preamble(2)
lngCount = Preamble(3)
dblXIncrement = Preamble(4)
dblXOrigin = Preamble(5)
lngXReference = Preamble(6)
sngYIncrement = Preamble(7)
sngYOrigin = Preamble(8)
lngYReference = Preamble(9)
strOutput = ""
'strOutput = strOutput + "Format = " + CStr(intFormat) + vbCrLf
'strOutput = strOutput + "Type = " + CStr(intType) + vbCrLf
'strOutput = strOutput + "Points = " + CStr(lngPoints) + vbCrLf
'strOutput = strOutput + "Count = " + CStr(lngCount) + vbCrLf
'strOutput = strOutput + "X increment = " + _
'   FormatNumber(dblXIncrement * 1000000) + " us" + vbCrLf
'strOutput = strOutput + "X origin = " + _
'   FormatNumber(dblXOrigin * 1000000) + " us" + vbCrLf
'strOutput = strOutput + "X reference = " + _
'   CStr(lngXReference) + vbCrLf
'strOutput = strOutput + "Y increment = " + _
'   FormatNumber(sngYIncrement * 1000) + " mV" + vbCrLf
'strOutput = strOutput + "Y origin = " + _
'   FormatNumber(sngYOrigin) + " V" + vbCrLf
'strOutput = strOutput + "Y reference = " + _
'   CStr(lngYReference) + vbCrLf
strOutput = strOutput + "Volts/Div = " + _

```

```

        FormatNumber(lngVSteps * sngYIncrement / 8) + _
        " V" + vbCrLf
strOutput = strOutput + "Offset = " + _
        FormatNumber((lngVSteps / 2 - lngYReference) * _
        sngYIncrement + sngYOrigin) + " V" + vbCrLf
strOutput = strOutput + "Sec/Div = " + _
        FormatNumber(lngPoints * dblXIncrement / 10 * _
        1000000) + " us" + vbCrLf
strOutput = strOutput + "Delay = " + _
        FormatNumber(((lngPoints / 2 - lngXReference) * _
        dblXIncrement + dblXOrigin) * 1000000) + " us" + vbCrLf

' QUERY_WAVE_DATA - Outputs waveform data that is stored in a buffer.

' Query the oscilloscope for the waveform data.
myScope.WriteString ":WAV:DATA?"

' READ_WAVE_DATA - The wave data consists of two parts: the header,
' and the actual waveform data followed by a new line (NL) character.
' The query data has the following format:
'
'   <header><waveform_data><NL>
'
' Where:
'   <header> = #800001000 (This is an example header)
' The "#8" may be stripped off of the header and the remaining
' numbers are the size, in bytes, of the waveform data block. The
' size can vary depending on the number of points acquired for the
' waveform. You can then read that number of bytes from the
' oscilloscope and the terminating NL character.
'
Dim lngI As Long
Dim lngDataValue As Long

' Unsigned integer bytes.
varQueryResult = myScope.ReadIEEEBlock(BinaryType_UI1)

For lngI = 0 To UBound(varQueryResult) _
    Step (UBound(varQueryResult) / 20) ' 20 points.
    If intBytesPerData = 2 Then
        lngDataValue = varQueryResult(lngI) * 256 _
            + varQueryResult(lngI + 1) ' 16-bit value.
    Else
        lngDataValue = varQueryResult(lngI) ' 8-bit value.
    End If
    strOutput = strOutput + "Data point " + _
        CStr(lngI / intBytesPerData) + ", " + _
        FormatNumber((lngDataValue - lngYReference) _
            * sngYIncrement + sngYOrigin) + " V, " + _
        FormatNumber(((lngI / intBytesPerData - lngXReference) _
            * sngXIncrement + dblXOrigin) * 1000000) + " us" + vbCrLf
Next lngI
MsgBox "Waveform data:" + vbCrLf + strOutput

```

See complete example programs at: [Chapter 50](#), "Programming Examples," starting on page 1739

:WAVeform:SOURce:SUBSource

C (see [page 1730](#))

Command Syntax :WAVeform:SOURce:SUBSource <subsource>

```
<subsource> ::= {{SUB0 | RX | MOSI | FAST}
                | {SUB1 | TX | MISO | SLOW}}
```

If the :WAVeform:SOURce is SBUS<n> (serial decode), more than one data set may be available, and this command lets you choose from the available data sets.

When using UART serial decode, this option lets you get "TX" data. (TX is an alias for SUB1.) The default, SUB0, specifies "RX" data. (RX is an alias for SUB0.)

When using SPI serial decode, this option lets you get "MISO" data. (MISO is an alias for SUB1.) The default, SUB0, specifies "MOSI" data. (MOSI is an alias for SUB0.)

When using SENT serial decode, this option lets you get "SLOW" data. (SLOW is an alias for SUB1.) The default, SUB0, specifies "FAST" data. (FAST is an alias for SUB0.)

If the :WAVeform:SOURce is not SBUS, or the :SBUS<n>:MODE is not UART, SPI, or SENT, the only valid subsource is SUB0.

Query Syntax :WAVeform:SOURce:SUBSource?

The :WAVeform:SOURce:SUBSource? query returns the current waveform subsource setting.

Return Format <subsource><NL>

```
<subsource> ::= {SUB0 | SUB1}
```

- See Also**
- ["Introduction to :WAVeform Commands"](#) on page 1516
 - [":WAVeform:SOURce"](#) on page 1537

:WAVeform:TYPE

C (see [page 1730](#))

Query Syntax :WAVeform:TYPE?

The :WAVeform:TYPE? query returns the acquisition mode associated with the currently selected waveform. The acquisition mode is set by the :ACQuire:TYPE command.

Return Format <mode><NL>

<mode> ::= {NORM | PEAK | AVER | HRES}

NOTE

If the :WAVeform:SOURce is POD1, POD2, or SBUS1, SBUS2, the type is always NORM.

-
- See Also**
- ["Introduction to :WAVeform Commands"](#) on page 1516
 - [":ACQuire:TYPE"](#) on page 318
 - [":WAVeform:DATA"](#) on page 1523
 - [":WAVeform:PREamble"](#) on page 1530
 - [":WAVeform:SOURce"](#) on page 1537

:WAVEform:UNSigned

C (see [page 1730](#))

Command Syntax :WAVEform:UNSigned <unsigned>

<unsigned> ::= {{0 | OFF} | {1 | ON}}

The :WAVEform:UNSigned command turns unsigned mode on or off for the currently selected waveform. Use the WAVEform:UNSigned command to control whether data values are sent as unsigned or signed integers. This command can be used to match the instrument's internal data type to the data type used by the programming language. This command has no effect if the data format is ASCII.

If :WAVEform:SOURce is set to POD1, POD2, BUS1, or BUS2, WAVEform:UNSigned must be set to ON.

Query Syntax :WAVEform:UNSigned?

The :WAVEform:UNSigned? query returns the status of unsigned mode for the currently selected waveform.

Return Format <unsigned><NL>

<unsigned> ::= {0 | 1}

- See Also**
- ["Introduction to :WAVEform Commands"](#) on page 1516
 - [":WAVEform:SOURce"](#) on page 1537

:WAVEform:VIEW

C (see [page 1730](#))

Command Syntax :WAVEform:VIEW <view>

<view> ::= {MAIN}

The :WAVEform:VIEW command sets the view setting associated with the currently selected waveform. Currently, the only legal value for the view setting is MAIN.

Query Syntax :WAVEform:VIEW?

The :WAVEform:VIEW? query returns the view setting associated with the currently selected waveform.

Return Format <view><NL>

<view> ::= {MAIN}

- See Also**
- ["Introduction to :WAVEform Commands"](#) on page 1516
 - [":WAVEform:POINts"](#) on page 1526

:WAVEform:XINCrement

C (see [page 1730](#))

Query Syntax :WAVEform:XINCrement?

The :WAVEform:XINCrement? query returns the x-increment value for the currently specified source. This value is the time difference between consecutive data points in seconds.

Return Format <value><NL>

<value> ::= x-increment in the current preamble in 64-bit floating point NR3 format

- See Also**
- ["Introduction to :WAVEform Commands"](#) on page 1516
 - [":WAVEform:PREamble"](#) on page 1530

Example Code

- ["Example Code"](#) on page 1531

:WAVEform:XORigin

C (see [page 1730](#))

Query Syntax :WAVEform:XORigin?

The :WAVEform:XORigin? query returns the x-origin value for the currently specified source. XORigin is the X-axis value of the data point specified by the :WAVEform:XREFerence value. In this product, that is always the X-axis value of the first data point (XREFerence = 0).

Return Format <value><NL>

<value> ::= x-origin value in the current preamble in 64-bit floating point NR3 format

- See Also**
- ["Introduction to :WAVEform Commands"](#) on page 1516
 - [":WAVEform:PREamble"](#) on page 1530
 - [":WAVEform:XREFerence"](#) on page 1547

Example Code • ["Example Code"](#) on page 1531

:WAVeform:XREFerence

C (see [page 1730](#))

Query Syntax :WAVeform:XREFerence?

The :WAVeform:XREFerence? query returns the x-reference value for the currently specified source. This value specifies the index of the data point associated with the x-origin data value. In this product, the x-reference point is the first point displayed and XREFerence is always 0.

Return Format <value><NL>

<value> ::= x-reference value = 0 in 32-bit NR1 format

- See Also**
- ["Introduction to :WAVeform Commands"](#) on page 1516
 - [":WAVeform:PREamble"](#) on page 1530
 - [":WAVeform:XORigin"](#) on page 1546

Example Code • ["Example Code"](#) on page 1531

:WAVeform:YINCrement

C (see [page 1730](#))

Query Syntax :WAVeform:YINCrement?

The :WAVeform:YINCrement? query returns the y-increment value in volts for the currently specified source. This value is the voltage difference between consecutive data values. The y-increment for digital waveforms is always "1".

Return Format <value><NL>

<value> ::= y-increment value in the current preamble in 32-bit floating point NR3 format

- See Also**
- ["Introduction to :WAVeform Commands"](#) on page 1516
 - [":WAVeform:PREamble"](#) on page 1530

Example Code

- ["Example Code"](#) on page 1531

:WAVeform:YORigin

C (see [page 1730](#))

Query Syntax :WAVeform:YORigin?

The :WAVeform:YORigin? query returns the y-origin value for the currently specified source. This value is the Y-axis value of the data value specified by the :WAVeform:YREFerence value. For this product, this is the Y-axis value of the center of the screen.

Return Format <value><NL>

<value> ::= y-origin in the current preamble in 32-bit floating point NR3 format

- See Also**
- ["Introduction to :WAVeform Commands"](#) on page 1516
 - [":WAVeform:PREamble"](#) on page 1530
 - [":WAVeform:YREFerence"](#) on page 1550

Example Code • ["Example Code"](#) on page 1531

:WAVEform:YREFerence

C (see [page 1730](#))

Query Syntax :WAVEform:YREFerence?

The :WAVEform:YREFerence? query returns the y-reference value for the currently specified source. This value specifies the data point value where the y-origin occurs. In this product, this is the data point value of the center of the screen. It is undefined if the format is ASCII.

Return Format <value><NL>

<value> ::= y-reference value in the current preamble in 32-bit
NR1 format

- See Also**
- ["Introduction to :WAVEform Commands"](#) on page 1516
 - [":WAVEform:PREamble"](#) on page 1530
 - [":WAVEform:YORigin"](#) on page 1549

Example Code • ["Example Code"](#) on page 1531

43 :WGEN<w> Commands

When the built-in waveform generator is licensed (WAVEGEN license), you can use it to output sine, square, ramp, pulse, DC, noise, sine cardinal, exponential rise, exponential fall, cardiac, and gaussian pulse waveforms. The :WGEN<w> commands are used to select the waveform function and parameters. See "[Introduction to :WGEN<w> Commands](#)" on page 1555.

Table 176 :WGEN<w> Commands Summary

Command	Query	Options and Query Returns
:WGEN<w>:ARbitrary:BYTeorder <order> (see page 1556)	:WGEN<w>:ARbitrary:BYTeorder? (see page 1556)	<order> ::= {MSBFirst LSBFirst} <w> ::= 1 to (# WaveGen outputs) in NR1 format
:WGEN<w>:ARbitrary:DATA {<binary> <value>, <value> ...} (see page 1557)	n/a	<binary> ::= floating point values between -1.0 to +1.0 in IEEE 488.2 binary block format <value> ::= floating point values between -1.0 to +1.0 in comma-separated format <w> ::= 1 to (# WaveGen outputs) in NR1 format
n/a	:WGEN<w>:ARbitrary:DATA:ATTRIBUTE:POINTS? (see page 1560)	<points> ::= number of points in NR1 format <w> ::= 1 to (# WaveGen outputs) in NR1 format
:WGEN<w>:ARbitrary:DATA:CLEar (see page 1561)	n/a	<w> ::= 1 to (# WaveGen outputs) in NR1 format

Table 176 :WGEN<w> Commands Summary (continued)

Command	Query	Options and Query Returns
:WGEN<w>:ARbitrary:DATA:DAC {<binary> <value>, <value> ...} (see page 1562)	n/a	<binary> ::= decimal 16-bit integer values between -512 to +511 in IEEE 488.2 binary block format <value> ::= decimal integer values between -512 to +511 in comma-separated NR1 format <w> ::= 1 to (# WaveGen outputs) in NR1 format
:WGEN<w>:ARbitrary:INTerpolate {{0 OFF} {1 ON}} (see page 1563)	:WGEN<w>:ARbitrary:INTerpolate? (see page 1563)	{0 1} <w> ::= 1 to (# WaveGen outputs) in NR1 format
:WGEN<w>:ARbitrary:STORe <source> (see page 1564)	n/a	<source> ::= {CHANnel<n> WMEMemory<r> FUNctIon<m> MATH<m>} <n> ::= 1 to (# analog channels) in NR1 format <r> ::= 1 to (# ref waveforms) in NR1 format <m> ::= 1 to (# math functions) in NR1 format <w> ::= 1 to (# WaveGen outputs) in NR1 format
:WGEN<w>:FREQuency <frequency> (see page 1565)	:WGEN<w>:FREQuency? (see page 1565)	<frequency> ::= frequency in Hz in NR3 format <w> ::= 1 to (# WaveGen outputs) in NR1 format
:WGEN<w>:FUNctIon <signal> (see page 1566)	:WGEN<w>:FUNctIon? (see page 1569)	<signal> ::= {SINusoid SQUare RAMP PULSe NOISe DC SINC EXPRise EXPFall CARDiac GAUSSian ARBitary} <w> ::= 1 to (# WaveGen outputs) in NR1 format
:WGEN<w>:FUNctIon:PULSe:WIDTh <width> (see page 1570)	:WGEN<w>:FUNctIon:PULSe:WIDTh? (see page 1570)	<width> ::= pulse width in seconds in NR3 format <w> ::= 1 to (# WaveGen outputs) in NR1 format

Table 176 :WGEN<w> Commands Summary (continued)

Command	Query	Options and Query Returns
:WGEN<w>:FUNCTION:RAMP:SYMMetry <percent> (see page 1571)	:WGEN<w>:FUNCTION:RAMP:SYMMetry? (see page 1571)	<percent> ::= symmetry percentage from 0% to 100% in NR1 format <w> ::= 1 to (# WaveGen outputs) in NR1 format
:WGEN<w>:FUNCTION:SQUARE:DCYCLE <percent> (see page 1572)	:WGEN<w>:FUNCTION:SQUARE:DCYCLE? (see page 1572)	<percent> ::= duty cycle percentage from 20% to 80% in NR1 format <w> ::= 1 to (# WaveGen outputs) in NR1 format
:WGEN<w>:MODULATION:AM:DEPTH <percent> (see page 1573)	:WGEN<w>:MODULATION:AM:DEPTH? (see page 1573)	<percent> ::= AM depth percentage from 0% to 100% in NR1 format <w> ::= 1 in NR1 format
:WGEN<w>:MODULATION:AM:FREQUENCY <frequency> (see page 1574)	:WGEN<w>:MODULATION:AM:FREQUENCY? (see page 1574)	<frequency> ::= modulating waveform frequency in Hz in NR3 format <w> ::= 1 in NR1 format
:WGEN<w>:MODULATION:FM:DEVIATION <frequency> (see page 1575)	:WGEN<w>:MODULATION:FM:DEVIATION? (see page 1575)	<frequency> ::= frequency deviation in Hz in NR3 format <w> ::= 1 in NR1 format
:WGEN<w>:MODULATION:FM:FREQUENCY <frequency> (see page 1576)	:WGEN<w>:MODULATION:FM:FREQUENCY? (see page 1576)	<frequency> ::= modulating waveform frequency in Hz in NR3 format <w> ::= 1 in NR1 format
:WGEN<w>:MODULATION:FSKEY:FREQUENCY <percent> (see page 1577)	:WGEN<w>:MODULATION:FSKEY:FREQUENCY? (see page 1577)	<frequency> ::= hop frequency in Hz in NR3 format <w> ::= 1 in NR1 format
:WGEN<w>:MODULATION:FSKEY:RATE <rate> (see page 1578)	:WGEN<w>:MODULATION:FSKEY:RATE? (see page 1578)	<rate> ::= FSK modulation rate in Hz in NR3 format <w> ::= 1 in NR1 format
:WGEN<w>:MODULATION:FUNCTION <shape> (see page 1579)	:WGEN<w>:MODULATION:FUNCTION? (see page 1579)	<shape> ::= {SINusoid SQUARE RAMP} <w> ::= 1 in NR1 format
:WGEN<w>:MODULATION:FUNCTION:RAMP:SYMMetry <percent> (see page 1580)	:WGEN<w>:MODULATION:FUNCTION:RAMP:SYMMetry? (see page 1580)	<percent> ::= symmetry percentage from 0% to 100% in NR1 format <w> ::= 1 in NR1 format

Table 176 :WGEN<w> Commands Summary (continued)

Command	Query	Options and Query Returns
:WGEN<w>:MODulation:NOISe <percent> (see page 1581)	:WGEN<w>:MODulation:NOISe? (see page 1581)	<percent> ::= 0 to 100 <w> ::= 1 in NR1 format
:WGEN<w>:MODulation:STATe {{0 OFF} {1 ON}} (see page 1582)	:WGEN<w>:MODulation:STATe? (see page 1582)	{0 1} <w> ::= 1 in NR1 format
:WGEN<w>:MODulation:TYPe <type> (see page 1583)	:WGEN<w>:MODulation:TYPe? (see page 1583)	<type> ::= {AM FM FSK} <w> ::= 1 in NR1 format
:WGEN<w>:OUTPut {{0 OFF} {1 ON}} (see page 1585)	:WGEN<w>:OUTPut? (see page 1585)	{0 1} <w> ::= 1 to (# WaveGen outputs) in NR1 format
:WGEN<w>:OUTPut:LOAD <impedance> (see page 1586)	:WGEN<w>:OUTPut:LOAD? (see page 1586)	<impedance> ::= {ONEMeg FIFTy} <w> ::= 1 to (# WaveGen outputs) in NR1 format
:WGEN<w>:OUTPut:MODE <mode> (see page 1587)	:WGEN<w>:OUTPut:MODE? (see page 1587)	<mode> ::= {NORMal SINGLe}
:WGEN<w>:OUTPut:POLarity <polarity> (see page 1588)	:WGEN<w>:OUTPut:POLarity? (see page 1588)	<polarity> ::= {NORMal INVerted} <w> ::= 1 to (# WaveGen outputs) in NR1 format
:WGEN<w>:OUTPut:SINGLe (see page 1589)	n/a	n/a
:WGEN<w>:PERiod <period> (see page 1590)	:WGEN<w>:PERiod? (see page 1590)	<period> ::= period in seconds in NR3 format <w> ::= 1 to (# WaveGen outputs) in NR1 format
:WGEN<w>:RST (see page 1591)	n/a	<w> ::= 1 to (# WaveGen outputs) in NR1 format
:WGEN<w>:TRACk {{0 OFF} {1 ON}} (see page 1592)	:WGEN<w>:TRACk? (see page 1592)	{0 1} <w> ::= 1 to (# WaveGen outputs) in NR1 format
:WGEN<w>:TRACk:AMPLitUde {{0 OFF} {1 ON}} (see page 1593)	:WGEN<w>:TRACk:AMPLitUde? (see page 1593)	{0 1} <w> ::= 1 to (# WaveGen outputs) in NR1 format
:WGEN<w>:TRACk:CSIGNal (see page 1594)	n/a	<w> ::= 1 to (# WaveGen outputs) in NR1 format

Table 176 :WGEN<w> Commands Summary (continued)

Command	Query	Options and Query Returns
:WGEN<w>:TRACk:FREQue ncy {{0 OFF} {1 ON}} (see page 1595)	:WGEN<w>:TRACk:FREQue ncy? (see page 1595)	{0 1} <w> ::= 1 to (# WaveGen outputs) in NR1 format
:WGEN<w>:TRACk:PHASe <phase> (see page 1596)	:WGEN<w>:TRACk:PHASe? (see page 1596)	<w> ::= 1 to (# WaveGen outputs) in NR1 format <phase> ::= -360 to +360 in NR1 format
:WGEN<w>:VOLTage <amplitude> (see page 1597)	:WGEN<w>:VOLTage? (see page 1597)	<amplitude> ::= amplitude in volts in NR3 format <w> ::= 1 to (# WaveGen outputs) in NR1 format
:WGEN<w>:VOLTage:HIGH <high> (see page 1598)	:WGEN<w>:VOLTage:HIGH ? (see page 1598)	<high> ::= high-level voltage in volts, in NR3 format <w> ::= 1 to (# WaveGen outputs) in NR1 format
:WGEN<w>:VOLTage:LOW <low> (see page 1599)	:WGEN<w>:VOLTage:LOW? (see page 1599)	<low> ::= low-level voltage in volts, in NR3 format <w> ::= 1 to (# WaveGen outputs) in NR1 format
:WGEN<w>:VOLTage:OFFS et <offset> (see page 1600)	:WGEN<w>:VOLTage:OFFS et? (see page 1600)	<offset> ::= offset in volts in NR3 format <w> ::= 1 to (# WaveGen outputs) in NR1 format

Introduction to :WGEN<w> Commands

The :WGEN<w> subsystem provides commands to select the waveform generator function and parameters.

In the :WGEN<w> commands, the <w> can be 1 or 2, and :WGEN is equivalent to :WGEN1

Reporting the Setup

Use :WGEN<w>? to query setup information for the WGEN<w> subsystem.

Return Format

The following is a sample response from the :WGEN? query. In this case, the query was issued following the *RST command.

```
:WGEN1:FUNC SIN;OUTP 0;FREQ +1.0000E+03;VOLT +500.0E-03;VOLT:OFFS  
+0.0E+00;:WGEN1:OUTP:LOAD ONEM
```

:WGEN<w>:ARbitrary:BYTeorder

N (see [page 1730](#))

Command Syntax :WGEN<w>:ARbitrary:BYTeorder <order>

<w> ::= 1 to (# WaveGen outputs) in NR1 format

<order> ::= {MSBFirst | LSBFirst}

The :WGEN<w>:ARbitrary:BYTeorder command selects the byte order for binary transfers.

Query Syntax :WGEN<w>:ARbitrary:BYTeorder?

The :WGEN<w>:ARbitrary:BYTeorder query returns the current byte order selection.

Return Format <order><NL>

<order> ::= {MSBFirst | LSBFirst}

- See Also**
- [":WGEN<w>:ARbitrary:DATA"](#) on page 1557
 - [":WGEN<w>:ARbitrary:DATA:DAC"](#) on page 1562

:WGEN<w>:ARbitrary:DATA

N (see [page 1730](#))

Command Syntax :WGEN<w>:ARbitrary:DATA {<binary> | <value>, <value> ...}

<w> ::= 1 to (# WaveGen outputs) in NR1 format

<binary> ::= floating point values between -1.0 to +1.0
in IEEE 488.2 binary block format

<value> ::= floating point values between -1.0 to +1.0
in comma-separated format

The :WGEN<w>:ARbitrary:DATA command downloads an arbitrary waveform in floating-point values format.

- See Also**
- [":WGEN<w>:ARbitrary:DATA:DAC"](#) on page 1562
 - [":SAVE:ARbitrary\[:START\]"](#) on page 947
 - [":RECall:ARbitrary\[:START\]"](#) on page 928

Example Code ' Waveform generator arbitrary data commands example.

```
' -----
Option Explicit

Public myMgr As VisaComLib.ResourceManager
Public myScope As VisaComLib.FormattedIO488
Public varQueryResult As Variant
Public strQueryResult As String

Private Declare Sub Sleep Lib "kernel32" (ByVal dwMilliseconds As Long)
Private Declare Sub CopyMemory Lib "kernel32" Alias "RtlMoveMemory" ( _
    dest As Any, _
    source As Any, _
    ByVal bytes As Long)

Sub Main()

    On Error GoTo VisaComError

    ' Create the VISA COM I/O resource.
    Set myMgr = New VisaComLib.ResourceManager
    Set myScope = New VisaComLib.FormattedIO488
    Set myScope.IO = _
        myMgr.Open("TCPIP0::a-mx4154a-60014.cos.is.keysight.com::inst0::
INSTR")
    myScope.IO.Clear ' Clear the interface.

    ' Turn on arbitrary waveform generator function.
    myScope.WriteString ":WGEN1:OUTPut ON"
    myScope.WriteString ":WGEN1:FUNCTION ARbitrary"
    myScope.WriteString ":WGEN1:FUNCTION?"
    strQueryResult = myScope.ReadString
    Debug.Print "WaveGen1 function: " + strQueryResult
```

```

DefaultArbitraryWaveform

' Download comma-separated floating-point values.
myScope.WriteString ":WGEN1:ARbitrary:DATA 0.0, 0.5, 1.0, 0.5, 0.0, -0
.5, -1.0, -0.5"
Debug.Print "WaveGen1 CSV floating-point values downloaded."
Sleep 5000

DefaultArbitraryWaveform

' Download comma-separated 16-bit integer (DAC) values.
myScope.WriteString ":WGEN1:ARbitrary:DATA:DAC 0, 255, 511, 255, 0, -2
56, -512, -256"
Debug.Print "WaveGen1 CSV 16-bit integer (DAC) values downloaded."
Sleep 5000

' Set the byte order for binary data.
myScope.WriteString ":WGEN1:ARbitrary:BYTeorder LSBFirst"
myScope.WriteString ":WGEN1:ARbitrary:BYTeorder?"
strQueryResult = myScope.ReadString
Debug.Print "WaveGen1 byte order for binary data: " + strQueryResult

DefaultArbitraryWaveform

' Download binary floating-point values.
Dim mySingleArray(8) As Single
mySingleArray(0) = 0!
mySingleArray(1) = 0.5!
mySingleArray(2) = 1!
mySingleArray(3) = 0.5!
mySingleArray(4) = 0!
mySingleArray(5) = -0.5!
mySingleArray(6) = -1!
mySingleArray(7) = -0.5!

Dim myByteArray(32) As Byte
CopyMemory myByteArray(0), mySingleArray(0), 32 * LenB(myByteArray(0))

myScope.WriteIEEEBlock ":WGEN1:ARbitrary:DATA", myByteArray, True
Debug.Print "WaveGen1 binary floating-point values downloaded."
Sleep 5000

DefaultArbitraryWaveform

' Download binary 16-bit integer (DAC) values.
Dim myIntegerArray(8) As Integer
myIntegerArray(0) = 0
myIntegerArray(1) = 255
myIntegerArray(2) = 511
myIntegerArray(3) = 255
myIntegerArray(4) = 0
myIntegerArray(5) = -256
myIntegerArray(6) = -512
myIntegerArray(7) = -256

Dim myByteArray2(16) As Byte

```

```

    CopyMemory myByteArray2(0), myIntegerArray(0), 16 * LenB(myByteArray2(
0))

    myScope.WriteIEEEBlock ":WGEN1:ARbitrary:DATA:DAC", myByteArray2, True
    Debug.Print "WaveGen1 binary 16-bit integer (DAC) values downloaded."
    Sleep 5000

    Exit Sub

VisaComError:
    MsgBox "VISA COM Error:" + vbCrLf + Err.Description

End Sub

'
' Initialize WaveGen1 to a known state.
' -----
Private Sub DefaultArbitraryWaveform()

    On Error GoTo VisaComError

    ' Load default arbitrary waveform.
    myScope.WriteString ":WGEN1:ARbitrary:DATA:CLear"
    Debug.Print "WaveGen1 default arbitrary waveform loaded."
    Sleep 5000

    Exit Sub

VisaComError:
    MsgBox "VISA COM Error:" + vbCrLf + Err.Description
    End

End Sub

```

:WGEN<w>:ARBitrary:DATA:ATTRibute:POINts

N (see [page 1730](#))

Query Syntax :WGEN<w>:ARBitrary:DATA:ATTRibute:POINts?

<w> ::= 1 to (# WaveGen outputs) in NR1 format

The :WGEN<w>:ARBitrary:DATA:ATTRibute:POINts query returns the number of points used by the current arbitrary waveform.

Return Format <points> ::= number of points in NR1 format

- See Also**
- [":WGEN<w>:ARBitrary:DATA"](#) on page 1557
 - [":WGEN<w>:ARBitrary:DATA:DAC"](#) on page 1562
 - [":SAVE:ARBitrary\[:START\]"](#) on page 947
 - [":RECall:ARBitrary\[:START\]"](#) on page 928

:WGEN<w>:ARbitrary:DATA:CLEar

N (see [page 1730](#))

Command Syntax :WGEN<w>:ARbitrary:DATA:CLEar

<w> ::= 1 to (# WaveGen outputs) in NR1 format

The :WGEN<w>:ARbitrary:DATA:CLEar command clears the arbitrary waveform memory and loads it with the default waveform.

- See Also**
- [":WGEN<w>:ARbitrary:DATA"](#) on page 1557
 - [":WGEN<w>:ARbitrary:DATA:DAC"](#) on page 1562
 - [":SAVE:ARbitrary\[:START\]"](#) on page 947
 - [":RECall:ARbitrary\[:START\]"](#) on page 928

- Example Code**
- ["Example Code"](#) on page 1557

:WGEN<w>:ARbitrary:DATA:DAC

N (see [page 1730](#))

Command Syntax :WGEN<w>:ARbitrary:DATA:DAC {<binary> | <value>, <value> ...}

<w> ::= 1 to (# WaveGen outputs) in NR1 format

<binary> ::= decimal 16-bit integer values between -512 to +511
in IEEE 488.2 binary block format

<value> ::= decimal integer values between -512 to +511
in comma-separated NR1 format

The :WGEN<w>:ARbitrary:DATA:DAC command downloads an arbitrary waveform using 16-bit integer (DAC) values.

- See Also**
- [":WGEN<w>:ARbitrary:DATA"](#) on page 1557
 - [":SAVE:ARbitrary\[:START\]"](#) on page 947
 - [":RECall:ARbitrary\[:START\]"](#) on page 928

- Example Code**
- ["Example Code"](#) on page 1557

:WGEN<w>:ARbitrary:INTerpolate

N (see [page 1730](#))

Command Syntax :WGEN<w>:ARbitrary:INTerpolate {{0 | OFF} | {1 | ON}}

<w> ::= 1 to (# WaveGen outputs) in NR1 format

The :WGEN<w>:ARbitrary:INTerpolate command enables or disables the Interpolation control.

Interpolation specifies how lines are drawn between arbitrary waveform points:

- When ON, lines are drawn between points in the arbitrary waveform. Voltage levels change linearly between one point and the next.
- When OFF, all line segments in the arbitrary waveform are horizontal. The voltage level of one point remains until the next point.

Query Syntax :WGEN<w>:ARbitrary:INTerpolate?

The :WGEN<w>:ARbitrary:INTerpolate query returns the current interpolation setting.

Return Format {0 | 1}

- See Also**
- [":WGEN<w>:ARbitrary:DATA"](#) on page 1557
 - [":WGEN<w>:ARbitrary:DATA:DAC"](#) on page 1562
 - [":SAVE:ARbitrary\[:START\]"](#) on page 947
 - [":RECall:ARbitrary\[:START\]"](#) on page 928

:WGEN<w>:ARbitrary:STORe

N (see [page 1730](#))

Command Syntax :WGEN<w>:ARbitrary:STORe <source>

<w> ::= 1 to (# WaveGen outputs) in NR1 format

<source> ::= {CHANnel<n> | WMEMory<r> | FUNction<m> | MATH<m>}

<n> ::= 1 to (# analog channels) in NR1 format

<r> ::= 1 to (# ref waveforms) in NR1 format

<m> ::= 1 to (# math functions) in NR1 format

The :WGEN<w>:ARbitrary:STORe command stores the source's waveform into the arbitrary waveform memory.

- See Also**
- [":WGEN<w>:ARbitrary:DATA"](#) on page 1557
 - [":WGEN<w>:ARbitrary:DATA:DAC"](#) on page 1562
 - [":SAVE:ARbitrary\[:START\]"](#) on page 947
 - [":RECall:ARbitrary\[:START\]"](#) on page 928

:WGEN<w>:FREQuency

N (see [page 1730](#))

Command Syntax :WGEN<w>:FREQuency <frequency>

<w> ::= 1 to (# WaveGen outputs) in NR1 format

<frequency> ::= frequency in Hz in NR3 format

For all waveforms except Noise and DC, the :WGEN<w>:FREQuency command specifies the frequency of the waveform.

You can also specify the frequency indirectly using the :WGEN<w>:PERiod command.

Query Syntax :WGEN<w>:FREQuency?

The :WGEN<w>:FREQuency? query returns the currently set waveform generator frequency.

Return Format <frequency><NL>

<frequency> ::= frequency in Hz in NR3 format

- See Also**
- ["Introduction to :WGEN<w> Commands"](#) on page 1555
 - [":WGEN<w>:FUNction"](#) on page 1566
 - [":WGEN<w>:PERiod"](#) on page 1590

:WGEN<w>:FUNCTION

N (see [page 1730](#))

Command Syntax :WGEN<w>:FUNCTION <signal>

<w> ::= 1 to (# WaveGen outputs) in NR1 format

<signal> ::= {SINusoid | SQUare | RAMP | PULSe | DC | NOISe | SINC
| EXPRise | EXPFall | CARDiac | GAUSSian | ARBitary}

The :WGEN<w>:FUNCTION command selects the type of waveform:

Waveform Type	Characteristics	Frequency Range	Max. Amplitude ² (High-Z) ¹	Offset ² (High-Z) ¹
SINusoid	Use these commands to set the sine signal parameters: <ul style="list-style-type: none"> ▪ ":WGEN<w>:FREQuency" on page 1565 ▪ ":WGEN<w>:PERiod" on page 1590 ▪ ":WGEN<w>:VOLTage" on page 1597 ▪ ":WGEN<w>:VOLTage:OFFSet" on page 1600 ▪ ":WGEN<w>:VOLTage:HIGH" on page 1598 ▪ ":WGEN<w>:VOLTage:LOW" on page 1599 	100 mHz to 20 MHz	20 mVpp to 10 Vpp	±4.00 V
SQUare	Use these commands to set the square wave signal parameters: <ul style="list-style-type: none"> ▪ ":WGEN<w>:FREQuency" on page 1565 ▪ ":WGEN<w>:PERiod" on page 1590 ▪ ":WGEN<w>:VOLTage" on page 1597 ▪ ":WGEN<w>:VOLTage:OFFSet" on page 1600 ▪ ":WGEN<w>:VOLTage:HIGH" on page 1598 ▪ ":WGEN<w>:VOLTage:LOW" on page 1599 ▪ ":WGEN<w>:FUNCTION:SQUare:DCYClE" on page 1572 The duty cycle can be adjusted from 20% to 80%.	100 mHz to 10 MHz	20 mVpp to 10 Vpp	±5.00 V

Waveform Type	Characteristics	Frequency Range	Max. Amplitude ² (High-Z) ¹	Offset ² (High-Z) ¹
RAMP	<p>Use these commands to set the ramp signal parameters:</p> <ul style="list-style-type: none"> ▪ ":WGEN<w>:FREQuency" on page 1565 ▪ ":WGEN<w>:PERiod" on page 1590 ▪ ":WGEN<w>:VOLTage" on page 1597 ▪ ":WGEN<w>:VOLTage:OFFSet" on page 1600 ▪ ":WGEN<w>:VOLTage:HIGH" on page 1598 ▪ ":WGEN<w>:VOLTage:LOW" on page 1599 ▪ ":WGEN<w>:FUNction:RAMP:SYMMetry" on page 1571 <p>Symmetry represents the amount of time per cycle that the ramp waveform is rising and can be adjusted from 0% to 100%.</p>	100 mHz to 200 kHz	20 mVpp to 10 Vpp	±5.00 V
PULSe	<p>Use these commands to set the pulse signal parameters:</p> <ul style="list-style-type: none"> ▪ ":WGEN<w>:FREQuency" on page 1565 ▪ ":WGEN<w>:PERiod" on page 1590 ▪ ":WGEN<w>:VOLTage" on page 1597 ▪ ":WGEN<w>:VOLTage:OFFSet" on page 1600 ▪ ":WGEN<w>:VOLTage:HIGH" on page 1598 ▪ ":WGEN<w>:VOLTage:LOW" on page 1599 ▪ ":WGEN<w>:FUNction:PULSe:WIDTh" on page 1570 <p>The pulse width can be adjusted from 20 ns to the period minus 20 ns.</p>	100 mHz to 10 MHz.	20 mVpp to 10 Vpp	±5.00 V
DC	<p>Use this command to set the DC level:</p> <ul style="list-style-type: none"> ▪ ":WGEN<w>:VOLTage:OFFSet" on page 1600 	n/a	n/a	±10.00 V
NOISe	<p>Use these commands to set the noise signal parameters:</p> <ul style="list-style-type: none"> ▪ ":WGEN<w>:VOLTage" on page 1597 ▪ ":WGEN<w>:VOLTage:OFFSet" on page 1600 ▪ ":WGEN<w>:VOLTage:HIGH" on page 1598 ▪ ":WGEN<w>:VOLTage:LOW" on page 1599 	n/a	20 mVpp to 10 Vpp	±5.00 V

Waveform Type	Characteristics	Frequency Range	Max. Amplitude ² (High-Z) ¹	Offset ² (High-Z) ¹
SINC	Use these commands to set the sine cardinal signal parameters: <ul style="list-style-type: none"> ▪ <code>":WGEN<w>:FREQuency"</code> on page 1565 ▪ <code>":WGEN<w>:PERiod"</code> on page 1590 ▪ <code>":WGEN<w>:VOLTagE"</code> on page 1597 ▪ <code>":WGEN<w>:VOLTagE:OFFSet"</code> on page 1600 	100 mHz to 1 MHz	20 mVpp to 9 Vpp	±2.50 V
EXPRise	Use these commands to set the exponential rise signal parameters: <ul style="list-style-type: none"> ▪ <code>":WGEN<w>:FREQuency"</code> on page 1565 ▪ <code>":WGEN<w>:PERiod"</code> on page 1590 ▪ <code>":WGEN<w>:VOLTagE"</code> on page 1597 ▪ <code>":WGEN<w>:VOLTagE:OFFSet"</code> on page 1600 ▪ <code>":WGEN<w>:VOLTagE:HIGH"</code> on page 1598 ▪ <code>":WGEN<w>:VOLTagE:LOW"</code> on page 1599 	100 mHz to 5 MHz	20 mVpp to 10 Vpp	±5.00 V
EXPFall	Use these commands to set the exponential fall signal parameters: <ul style="list-style-type: none"> ▪ <code>":WGEN<w>:FREQuency"</code> on page 1565 ▪ <code>":WGEN<w>:PERiod"</code> on page 1590 ▪ <code>":WGEN<w>:VOLTagE"</code> on page 1597 ▪ <code>":WGEN<w>:VOLTagE:OFFSet"</code> on page 1600 ▪ <code>":WGEN<w>:VOLTagE:HIGH"</code> on page 1598 ▪ <code>":WGEN<w>:VOLTagE:LOW"</code> on page 1599 	100 mHz to 5 MHz	20 mVpp to 10 Vpp	±5.00 V
CARDiac	Use these commands to set the cardiac signal parameters: <ul style="list-style-type: none"> ▪ <code>":WGEN<w>:FREQuency"</code> on page 1565 ▪ <code>":WGEN<w>:PERiod"</code> on page 1590 ▪ <code>":WGEN<w>:VOLTagE"</code> on page 1597 ▪ <code>":WGEN<w>:VOLTagE:OFFSet"</code> on page 1600 	100 mHz to 200 kHz	20 mVpp to 9 Vpp	±2.50 V

Waveform Type	Characteristics	Frequency Range	Max. Amplitude ² (High-Z) ¹	Offset ² (High-Z) ¹
GAUSSian	Use these commands to set the gaussian pulse signal parameters: <ul style="list-style-type: none"> ▪ ":WGEN<w>:FREQUency" on page 1565 ▪ ":WGEN<w>:PERiod" on page 1590 ▪ ":WGEN<w>:VOLTage" on page 1597 ▪ ":WGEN<w>:VOLTage:OFFSet" on page 1600 	100 mHz to 5 MHz	20 mVpp to 7.5 Vpp	±2.50 V
ARBitrary	Use these commands to set the arbitrary signal parameters: <ul style="list-style-type: none"> ▪ ":WGEN<w>:FREQUency" on page 1565 ▪ ":WGEN<w>:PERiod" on page 1590 ▪ ":WGEN<w>:VOLTage" on page 1597 ▪ ":WGEN<w>:VOLTage:OFFSet" on page 1600 ▪ ":WGEN<w>:VOLTage:HIGh" on page 1598 ▪ ":WGEN<w>:VOLTage:LOW" on page 1599 	100 mHz to 12 MHz	20 mVpp to 10 Vpp	±5.00 V

¹When the output load is 50 Ω, these values are halved.

²The minimum amplitude is limited to 40 mVpp if the offset is greater than 500 mV or less than -500 mV. Likewise, the offset is limited to +/-500 mV if the amplitude is less than 40 mVpp.

Query Syntax :WGEN<w>:FUNctIon?

The :WGEN<w>:FUNctIon? query returns the currently selected signal type.

Return Format <signal><NL>

<signal> ::= {SIN | SQU | RAMP | PULS | DC | NOIS | SINC | EXPR | EXPF
| CARD | GAUS | ARB}

- See Also**
- **"Introduction to :WGEN<w> Commands"** on page 1555
 - **":WGEN<w>:MODulation:NOISe"** on page 1581

:WGEN<w>:FUNCTION:PULSE:WIDTH

N (see [page 1730](#))

Command Syntax :WGEN<w>:FUNCTION:PULSE:WIDTH <width>

<w> ::= 1 to (# WaveGen outputs) in NR1 format

<width> ::= pulse width in seconds in NR3 format

For Pulse waveforms, the :WGEN<w>:FUNCTION:PULSE:WIDTH command specifies the width of the pulse.

The pulse width can be adjusted from 20 ns to the period minus 20 ns.

Query Syntax :WGEN<w>:FUNCTION:PULSE:WIDTH?

The :WGEN<w>:FUNCTION:PULSE:WIDTH? query returns the currently set pulse width.

Return Format <width><NL>

<width> ::= pulse width in seconds in NR3 format

- See Also**
- ["Introduction to :WGEN<w> Commands"](#) on page 1555
 - [":WGEN<w>:FUNCTION"](#) on page 1566

:WGEN<w>:FUNCTION:RAMP:SYMMetry

N (see [page 1730](#))

Command Syntax :WGEN<w>:FUNCTION:RAMP:SYMMetry <percent>

<w> ::= 1 to (# WaveGen outputs) in NR1 format

<percent> ::= symmetry percentage from 0% to 100% in NR1 format

For Ramp waveforms, the :WGEN<w>:FUNCTION:RAMP:SYMMetry command specifies the symmetry of the waveform.

Symmetry represents the amount of time per cycle that the ramp waveform is rising.

Query Syntax :WGEN<w>:FUNCTION:RAMP:SYMMetry?

The :WGEN<w>:FUNCTION:RAMP:SYMMetry? query returns the currently set ramp symmetry.

Return Format <percent><NL>

<percent> ::= symmetry percentage from 0% to 100% in NR1 format

- See Also**
- ["Introduction to :WGEN<w> Commands"](#) on page 1555
 - [":WGEN<w>:FUNCTION"](#) on page 1566

:WGEN<w>:FUNCTION:SQUare:DCYClE

N (see [page 1730](#))

Command Syntax :WGEN<w>:FUNCTION:SQUare:DCYClE <percent>

<w> ::= 1 to (# WaveGen outputs) in NR1 format

<percent> ::= duty cycle percentage from 20% to 80% in NR1 format

For Square waveforms, the :WGEN<w>:FUNCTION:SQUare:DCYClE command specifies the square wave duty cycle.

Duty cycle is the percentage of the period that the waveform is high.

Query Syntax :WGEN<w>:FUNCTION:SQUare:DCYClE?

The :WGEN<w>:FUNCTION:SQUare:DCYClE? query returns the currently set square wave duty cycle.

Return Format <percent><NL>

<percent> ::= duty cycle percentage from 20% to 80% in NR1 format

- See Also**
- ["Introduction to :WGEN<w> Commands"](#) on page 1555
 - [":WGEN<w>:FUNCTION"](#) on page 1566

:WGEN<w>:MODulation:AM:DEPTH

N (see [page 1730](#))

Command Syntax :WGEN<w>:MODulation:AM:DEPTH <percent>

<w> ::= 1 in NR1 format

<percent> ::= AM depth percentage from 0% to 100% in NR1 format

The :WGEN<w>:MODulation:AM:DEPTH command specifies the amount of amplitude modulation.

AM Depth refers to the portion of the amplitude range that will be used by the modulation. For example, a depth setting of 80% causes the output amplitude to vary from 10% to 90% (90% – 10% = 80%) of the original amplitude as the modulating signal goes from its minimum to maximum amplitude.

Query Syntax :WGEN<w>:MODulation:AM:DEPTH?

The :WGEN<w>:MODulation:AM:DEPTH? query returns the AM depth percentage setting.

Return Format <percent><NL>

<percent> ::= AM depth percentage from 0% to 100% in NR1 format

- See Also**
- [":WGEN<w>:MODulation:AM:FREQuency"](#) on page 1574
 - [":WGEN<w>:MODulation:FM:DEVIation"](#) on page 1575
 - [":WGEN<w>:MODulation:FM:FREQuency"](#) on page 1576
 - [":WGEN<w>:MODulation:FSKey:FREQuency"](#) on page 1577
 - [":WGEN<w>:MODulation:FSKey:RATE"](#) on page 1578
 - [":WGEN<w>:MODulation:FUNCTion"](#) on page 1579
 - [":WGEN<w>:MODulation:FUNCTion:RAMP:SYMMetry"](#) on page 1580
 - [":WGEN<w>:MODulation:STATe"](#) on page 1582
 - [":WGEN<w>:MODulation:TYPE"](#) on page 1583

:WGEN<w>:MODulation:AM:FREQuency

N (see [page 1730](#))

Command Syntax :WGEN<w>:MODulation:AM:FREQuency <frequency>

<w> ::= 1 in NR1 format

<frequency> ::= modulating waveform frequency in Hz in NR3 format

The :WGEN<w>:MODulation:AM:FREQuency command specifies the frequency of the modulating signal.

Query Syntax :WGEN<w>:MODulation:AM:FREQuency?

The :WGEN<w>:MODulation:AM:FREQuency? query returns the frequency of the modulating signal.

Return Format <frequency><NL>

<frequency> ::= modulating waveform frequency in Hz in NR3 format

- See Also**
- [":WGEN<w>:MODulation:AM:DEPTH"](#) on page 1573
 - [":WGEN<w>:MODulation:FM:DEVIation"](#) on page 1575
 - [":WGEN<w>:MODulation:FM:FREQuency"](#) on page 1576
 - [":WGEN<w>:MODulation:FSKey:FREQuency"](#) on page 1577
 - [":WGEN<w>:MODulation:FSKey:RATE"](#) on page 1578
 - [":WGEN<w>:MODulation:FUNCTion"](#) on page 1579
 - [":WGEN<w>:MODulation:FUNCTion:RAMP:SYMMetry"](#) on page 1580
 - [":WGEN<w>:MODulation:STATe"](#) on page 1582
 - [":WGEN<w>:MODulation:TYPE"](#) on page 1583

:WGEN<w>:MODulation:FM:DEVIation

N (see [page 1730](#))

Command Syntax :WGEN<w>:MODulation:FM:DEVIation <frequency>

<w> ::= 1 in NR1 format

<frequency> ::= frequency deviation in Hz in NR3 format

The :WGEN<w>:MODulation:FM:DEVIation command specifies the frequency deviation from the original carrier signal frequency.

When the modulating signal is at its maximum amplitude, the output frequency is the carrier signal frequency plus the deviation amount, and when the modulating signal is at its minimum amplitude, the output frequency is the carrier signal frequency minus the deviation amount.

The frequency deviation cannot be greater than the original carrier signal frequency.

Also, the sum of the original carrier signal frequency and the frequency deviation must be less than or equal to the maximum frequency for the selected waveform generator function plus 100 kHz.

Query Syntax :WGEN<w>:MODulation:FM:DEVIation?

The :WGEN<w>:MODulation:FM:DEVIation? query returns the frequency deviation setting.

Return Format <frequency><NL>

<frequency> ::= frequency deviation in Hz in NR3 format

- See Also**
- [":WGEN<w>:MODulation:AM:DEPTH"](#) on page 1573
 - [":WGEN<w>:MODulation:AM:FREQuency"](#) on page 1574
 - [":WGEN<w>:MODulation:FM:FREQuency"](#) on page 1576
 - [":WGEN<w>:MODulation:FSKey:FREQuency"](#) on page 1577
 - [":WGEN<w>:MODulation:FSKey:RATE"](#) on page 1578
 - [":WGEN<w>:MODulation:FUNction"](#) on page 1579
 - [":WGEN<w>:MODulation:FUNction:RAMP:SYMMetry"](#) on page 1580
 - [":WGEN<w>:MODulation:STATe"](#) on page 1582
 - [":WGEN<w>:MODulation:TYPE"](#) on page 1583

:WGEN<w>:MODulation:FM:FREQuency

N (see [page 1730](#))

Command Syntax :WGEN<w>:MODulation:FM:FREQuency <frequency>

<w> ::= 1 in NR1 format

<frequency> ::= modulating waveform frequency in Hz in NR3 format

The :WGEN<w>:MODulation:FM:FREQuency command specifies the frequency of the modulating signal.

Query Syntax :WGEN<w>:MODulation:FM:FREQuency?

The :WGEN<w>:MODulation:FM:FREQuency? query returns the frequency of the modulating signal.

Return Format <frequency><NL>

<frequency> ::= modulating waveform frequency in Hz in NR3 format

- See Also**
- [":WGEN<w>:MODulation:AM:DEPTH"](#) on page 1573
 - [":WGEN<w>:MODulation:AM:FREQuency"](#) on page 1574
 - [":WGEN<w>:MODulation:FM:DEViation"](#) on page 1575
 - [":WGEN<w>:MODulation:FSKey:FREQuency"](#) on page 1577
 - [":WGEN<w>:MODulation:FSKey:RATE"](#) on page 1578
 - [":WGEN<w>:MODulation:FUNCTion"](#) on page 1579
 - [":WGEN<w>:MODulation:FUNCTion:RAMP:SYMMetry"](#) on page 1580
 - [":WGEN<w>:MODulation:STATe"](#) on page 1582
 - [":WGEN<w>:MODulation:TYPE"](#) on page 1583

:WGEN<w>:MODulation:FSKey:FREQuency

N (see [page 1730](#))

Command Syntax :WGEN<w>:MODulation:FSKey:FREQuency <frequency>

<w> ::= 1 in NR1 format

<frequency> ::= hop frequency in Hz in NR3 format

The :WGEN<w>:MODulation:FSKey:FREQuency command specifies the "hop frequency".

The output frequency "shifts" between the original carrier frequency and this "hop frequency".

Query Syntax :WGEN<w>:MODulation:FSKey:FREQuency?

The :WGEN<w>:MODulation:FSKey:FREQuency? query returns the "hop frequency" setting.

Return Format <frequency><NL>

<frequency> ::= hop frequency in Hz in NR3 format

- See Also**
- [":WGEN<w>:MODulation:AM:DEPTH"](#) on page 1573
 - [":WGEN<w>:MODulation:AM:FREQuency"](#) on page 1574
 - [":WGEN<w>:MODulation:FM:DEVIation"](#) on page 1575
 - [":WGEN<w>:MODulation:FM:FREQuency"](#) on page 1576
 - [":WGEN<w>:MODulation:FSKey:RATE"](#) on page 1578
 - [":WGEN<w>:MODulation:FUNCTion"](#) on page 1579
 - [":WGEN<w>:MODulation:FUNCTion:RAMP:SYMMetry"](#) on page 1580
 - [":WGEN<w>:MODulation:STATe"](#) on page 1582
 - [":WGEN<w>:MODulation:TYPE"](#) on page 1583

:WGEN<w>:MODulation:FSKey:RATE

N (see [page 1730](#))

Command Syntax :WGEN<w>:MODulation:FSKey:RATE <rate>

<w> ::= 1 in NR1 format

<rate> ::= FSK modulation rate in Hz in NR3 format

The :WGEN<w>:MODulation:FSKey:RATE command specifies the rate at which the output frequency "shifts".

The FSK rate specifies a digital square wave modulating signal.

Query Syntax :WGEN<w>:MODulation:FSKey:RATE?

The :WGEN<w>:MODulation:FSKey:RATE? query returns the FSK rate setting.

Return Format <rate><NL>

<rate> ::= FSK modulation rate in Hz in NR3 format

- See Also**
- [":WGEN<w>:MODulation:AM:DEPTH"](#) on page 1573
 - [":WGEN<w>:MODulation:AM:FREQUENCY"](#) on page 1574
 - [":WGEN<w>:MODulation:FM:DEVIATION"](#) on page 1575
 - [":WGEN<w>:MODulation:FM:FREQUENCY"](#) on page 1576
 - [":WGEN<w>:MODulation:FSKey:FREQUENCY"](#) on page 1577
 - [":WGEN<w>:MODulation:FUNCTION"](#) on page 1579
 - [":WGEN<w>:MODulation:FUNCTION:RAMP:SYMMETRY"](#) on page 1580
 - [":WGEN<w>:MODulation:STATE"](#) on page 1582
 - [":WGEN<w>:MODulation:TYPE"](#) on page 1583

:WGEN<w>:MODulation:FUNction

N (see [page 1730](#))

Command Syntax :WGEN<w>:MODulation:FUNction <shape>

<w> ::= 1 in NR1 format

<shape> ::= {SINusoid | SQUare| RAMP}

The :WGEN<w>:MODulation:FUNction command specifies the shape of the modulating signal.

When the RAMP shape is selected, you can specify the amount of time per cycle that the ramp waveform is rising with the :WGEN<w>:MODulation:FUNction:RAMP:SYMMetry command.

This command applies to AM and FM modulation. (The FSK modulation signal is a square wave shape.)

Query Syntax :WGEN<w>:MODulation:FUNction?

The :WGEN<w>:MODulation:FUNction? query returns the specified modulating signal shape.

Return Format <shape><NL>

<shape> ::= {SIN | SQU| RAMP}

- See Also**
- [":WGEN<w>:MODulation:AM:DEPTH"](#) on page 1573
 - [":WGEN<w>:MODulation:AM:FREQUENCY"](#) on page 1574
 - [":WGEN<w>:MODulation:FM:DEVIATION"](#) on page 1575
 - [":WGEN<w>:MODulation:FM:FREQUENCY"](#) on page 1576
 - [":WGEN<w>:MODulation:FSKey:FREQUENCY"](#) on page 1577
 - [":WGEN<w>:MODulation:FSKey:RATE"](#) on page 1578
 - [":WGEN<w>:MODulation:FUNction:RAMP:SYMMetry"](#) on page 1580
 - [":WGEN<w>:MODulation:STATE"](#) on page 1582
 - [":WGEN<w>:MODulation:TYPE"](#) on page 1583

:WGEN<w>:MODulation:FUNction:RAMP:SYMMetry

N (see [page 1730](#))

Command Syntax :WGEN<w>:MODulation:FUNction:RAMP:SYMMetry <percent>

<w> ::= 1 in NR1 format

<percent> ::= symmetry percentage from 0% to 100% in NR1 format

The :WGEN<w>:MODulation:FUNction:RAMP:SYMMetry command specifies the amount of time per cycle that the ramp waveform is rising. The ramp modulating waveform shape is specified with the :WGEN<w>:MODulation:FUNction command.

Query Syntax :WGEN<w>:MODulation:FUNction:RAMP:SYMMetry?

The :WGEN<w>:MODulation:FUNction:RAMP:SYMMetry? query returns ramp symmetry percentage setting.

Return Format <percent><NL>

<percent> ::= symmetry percentage from 0% to 100% in NR1 format

- See Also**
- [":WGEN<w>:MODulation:AM:DEPTH"](#) on page 1573
 - [":WGEN<w>:MODulation:AM:FREQuency"](#) on page 1574
 - [":WGEN<w>:MODulation:FM:DEViation"](#) on page 1575
 - [":WGEN<w>:MODulation:FM:FREQuency"](#) on page 1576
 - [":WGEN<w>:MODulation:FSKey:FREQuency"](#) on page 1577
 - [":WGEN<w>:MODulation:FSKey:RATE"](#) on page 1578
 - [":WGEN<w>:MODulation:FUNction"](#) on page 1579
 - [":WGEN<w>:MODulation:STATe"](#) on page 1582
 - [":WGEN<w>:MODulation:TYPE"](#) on page 1583

:WGEN<w>:MODulation:NOISe

N (see [page 1730](#))

Command Syntax :WGEN<w>:MODulation:NOISe <percent>

<w> ::= 1 in NR1 format

<percent> ::= 0 to 100

The :WGEN<w>:MODulation:NOISe command adds noise to the currently selected signal. The sum of the amplitude between the original signal and injected noise is limited to the regular amplitude limit (for example, 5 Vpp in 1 MOhm), so the range for <percent> varies according to current amplitude.

Note that adding noise affects edge triggering on the waveform generator source as well as the waveform generator sync pulse output signal (which can be sent to TRIG OUT). This is because the trigger comparator is located after the noise source.

Query Syntax :WGEN<w>:MODulation:NOISe?

The :WGEN<w>:MODulation:NOISe query returns the percent of added noise.

Return Format <percent><NL>

<percent> ::= 0 to 100

See Also • [":WGEN<w>:FUNCTION"](#) on page 1566

:WGEN<w>:MODulation:STATe

N (see [page 1730](#))

Command Syntax :WGEN<w>:MODulation:STATe <setting>

<w> ::= 1 in NR1 format

<setting> ::= {{OFF | 0} | {ON | 1}}

The :WGEN<w>:MODulation:STATe command enables or disables modulated waveform generator output.

You can enable modulation for all waveform generator function types except pulse, DC, and noise.

Query Syntax :WGEN<w>:MODulation:STATe?

The :WGEN<w>:MODulation:STATe? query returns whether the modulated waveform generator output is enabled or disabled.

Return Format <setting><NL>

<setting> ::= {0 | 1}

- See Also**
- [":WGEN<w>:MODulation:AM:DEPTH"](#) on page 1573
 - [":WGEN<w>:MODulation:AM:FREQUENCY"](#) on page 1574
 - [":WGEN<w>:MODulation:FM:DEVIATION"](#) on page 1575
 - [":WGEN<w>:MODulation:FM:FREQUENCY"](#) on page 1576
 - [":WGEN<w>:MODulation:FSKey:FREQUENCY"](#) on page 1577
 - [":WGEN<w>:MODulation:FSKey:RATE"](#) on page 1578
 - [":WGEN<w>:MODulation:FUNCTION"](#) on page 1579
 - [":WGEN<w>:MODulation:FUNCTION:RAMP:SYMMETRY"](#) on page 1580
 - [":WGEN<w>:MODulation:TYPE"](#) on page 1583

:WGEN<w>:MODulation:TYPE

N (see [page 1730](#))

Command Syntax :WGEN<w>:MODulation:TYPE <type>

<w> ::= 1 in NR1 format

<type> ::= {AM | FM | FSK}

The :WGEN<w>:MODulation:TYPE command selects the modulation type:

- AM (amplitude modulation) – the amplitude of the original carrier signal is modified according to the amplitude of the modulating signal.

Use the :WGEN<w>:MODulation:AM:FREQuency command to set the modulating signal frequency.

Use the :WGEN<w>:MODulation:AM:DEPTH command to specify the amount of amplitude modulation.

- FM (frequency modulation) – the frequency of the original carrier signal is modified according to the amplitude of the modulating signal.

Use the :WGEN<w>:MODulation:FM:FREQuency command to set the modulating signal frequency.

Use the :WGEN<w>:MODulation:FM:DEVIation command to specify the frequency deviation from the original carrier signal frequency.

- FSK (frequency-shift keying modulation) – the output frequency "shifts" between the original carrier frequency and a "hop frequency" at the specified FSK rate.

The FSK rate specifies a digital square wave modulating signal.

Use the :WGEN<w>:MODulation:FSKey:FREQuency command to specify the "hop frequency".

Use the :WGEN<w>:MODulation:FSKey:RATE command to specify the rate at which the output frequency "shifts".

Query Syntax :WGEN<w>:MODulation:TYPE?

The :WGEN<w>:MODulation:TYPE? query returns the selected modulation type.

Return Format <type><NL>

<type> ::= {AM | FM | FSK}

- See Also**
- [":WGEN<w>:MODulation:AM:DEPTH"](#) on page 1573
 - [":WGEN<w>:MODulation:AM:FREQuency"](#) on page 1574
 - [":WGEN<w>:MODulation:FM:DEVIation"](#) on page 1575
 - [":WGEN<w>:MODulation:FM:FREQuency"](#) on page 1576

- **":WGEN<w>:MODulation:FSKey:FREQuency"** on page 1577
- **":WGEN<w>:MODulation:FSKey:RATE"** on page 1578
- **":WGEN<w>:MODulation:FUNcTion"** on page 1579
- **":WGEN<w>:MODulation:FUNcTion:RAMP:SYMMetry"** on page 1580
- **":WGEN<w>:MODulation:STATe"** on page 1582

:WGEN<w>:OUTPut

N (see [page 1730](#))

Command Syntax :WGEN<w>:OUTPut <on_off>

<w> ::= 1 to (# WaveGen outputs) in NR1 format

<on_off> ::= {{1 | ON} | {0 | OFF}}

The :WGEN<w>:OUTPut command specifies whether the waveform generator signal output is ON (1) or OFF (0).

Query Syntax :WGEN<w>:OUTPut?

The :WGEN<w>:OUTPut? query returns the current state of the waveform generator output setting.

Return Format <on_off><NL>

<on_off> ::= {1 | 0}

See Also • ["Introduction to :WGEN<w> Commands"](#) on page 1555

:WGEN<w>:OUTPut:LOAD

N (see [page 1730](#))

Command Syntax :WGEN<w>:OUTPut:LOAD <impedance>

<w> ::= 1 to (# WaveGen outputs) in NR1 format

<impedance> ::= {ONEMeg | FIFTy}

The :WGEN<w>:OUTPut:LOAD command selects the expected output load impedance.

The output impedance of the Gen Out BNC is fixed at 50 ohms. However, the output load selection lets the waveform generator display the correct amplitude and offset levels for the expected output load.

If the actual load impedance is different than the selected value, the displayed amplitude and offset levels will be incorrect.

Query Syntax :WGEN<w>:OUTPut:LOAD?

The :WGEN<w>:OUTPut:LOAD? query returns the current expected output load impedance.

Return Format <impedance><NL>

<impedance> ::= {ONEM | FIFT}

See Also • ["Introduction to :WGEN<w> Commands"](#) on page 1555

:WGEN<w>:OUTPut:MODE

N (see [page 1730](#))

Command Syntax :WGEN<w>:OUTPut:MODE <mode>

<mode> ::= {NORMal | SINGle}

The :WGEN<w>:OUTPut:MODE command specifies whether the defined waveform is output continuously or as a single cycle (single-shot):

- NORMal – the defined waveform is output continuously.
- SINGle – one cycle of the defined waveform is output when you send the :WGEN<w>:OUTPut:SINGle command.

Not all waveform types allow single-shot output.

Query Syntax :WGEN<w>:OUTPut:MODE?

The :WGEN<w>:OUTPut:MODE? query returns the output mode setting.

Return Format <mode><NL>

<mode> ::= {NORMal | SINGle}

See Also • [":WGEN<w>:OUTPut:SINGle"](#) on page 1589

:WGEN<w>:OUTPut:POLarity

N (see [page 1730](#))

Command Syntax :WGEN<w>:OUTPut:POLarity <polarity>

<w> ::= 1 to (# WaveGen outputs) in NR1 format

<polarity> ::= {NORMAL | INVERTed}

The :WGEN<w>:OUTPut:POLarity command specifies whether the waveform generator output is inverted..

Query Syntax :WGEN<w>:OUTPut:POLarity?

The :WGEN<w>:OUTPut:POLarity? query returns the specified output polarity.

Return Format <polarity><NL>

<polarity> ::= {NORM | INV}

See Also • ["Introduction to :WGEN<w> Commands"](#) on page 1555

:WGEN<w>:OUTPut:SINGle

N (see [page 1730](#))

Command Syntax :WGEN<w>:OUTPut:SINGle

When the single-shot output mode is selected (by the :WGEN<w>:OUTPut:MODE command), the :WGEN<w>:OUTPut:SINGle command causes a single cycle of the defined waveform to be output.

Sending this command multiple times will interrupt a slow signal output before the cycle is completed.

See Also • [":WGEN<w>:OUTPut:MODE"](#) on page 1587

:WGEN<w>:PERiod

N (see [page 1730](#))

Command Syntax :WGEN<w>:PERiod <period>

<w> ::= 1 to (# WaveGen outputs) in NR1 format

<period> ::= period in seconds in NR3 format

For all waveforms except Noise and DC, the :WGEN<w>:PERiod command specifies the period of the waveform.

You can also specify the period indirectly using the :WGEN<w>:FREQuency command.

Query Syntax :WGEN<w>:PERiod?

The :WGEN<w>:PERiod? query returns the currently set waveform generator period.

Return Format <period><NL>

<period> ::= period in seconds in NR3 format

- See Also**
- ["Introduction to :WGEN<w> Commands"](#) on page 1555
 - [":WGEN<w>:FUNction"](#) on page 1566
 - [":WGEN<w>:FREQuency"](#) on page 1565

:WGEN<w>:RST

N (see [page 1730](#))

Command Syntax :WGEN<w>:RST

<w> ::= 1 to (# WaveGen outputs) in NR1 format

The :WGEN<w>:RST command restores the waveform generator factory default settings (1 kHz sine wave, 500 mVpp, 0 V offset).

- See Also**
- ["Introduction to :WGEN<w> Commands"](#) on page 1555
 - [":WGEN<w>:FUNCTION"](#) on page 1566
 - [":WGEN<w>:FREQUENCY"](#) on page 1565

:WGEN<w>:TRACk

N (see [page 1730](#))

Command Syntax :WGEN<w>:TRACk <on_off>

<w> ::= 1 to (# WaveGen outputs) in NR1 format

<on_off> ::= {{1 | ON} | {0 | OFF}}

The :WGEN<w>:TRACk ON command causes frequency, amplitude, offset, and duty cycle adjustments to this waveform generator output signal to be tracked by the other waveform generator output.

Not all waveform shapes can be frequency tracked. When :WGEN<w>:TRACk or :WGEN<w>:TRACk:FREQuency is enabled, the other generator's waveform selections (:WGEN<w>:FUNction) must be in the same group as this generator's waveform:

Group 1	Group 2	Group 3	Group 4
SINusoid	SQUare	EXPRise	ARBitrary
RAMP	PULSe	EXPFall	
SINC			
CARDiac			
GAUSSian			

When tracking is enabled, adjustments for tracked settings in the other waveform generator become unavailable.

Query Syntax :WGEN<w>:TRACk?

The :WGEN<w>:TRACk? query returns whether tracking is on or off.

Return Format <on_off><NL>

<on_off> ::= {1 | 0}

- See Also**
- [":WGEN<w>:FUNction"](#) on page 1566
 - [":WGEN<w>:TRACk:AMPLitude"](#) on page 1593
 - [":WGEN<w>:TRACk:FREQuency"](#) on page 1595
 - [":WGEN<w>:TRACk:PHASe"](#) on page 1596
 - [":WGEN<w>:TRACk:CSIGnal"](#) on page 1594

:WGEN<w>:TRACk:AMPLitude

N (see [page 1730](#))

Command Syntax :WGEN<w>:TRACk:AMPLitude <on_off>

<w> ::= 1 to (# WaveGen outputs) in NR1 format

<on_off> ::= {1 | ON} | {0 | OFF}

The :WGEN<w>:TRACk:AMPLitude ON command causes amplitude and offset adjustments to this waveform generator output signal to be tracked by the other waveform generator output.

Also, when tracking is enabled, adjustments for tracked settings in the other waveform generator become unavailable (ghosted).

Query Syntax :WGEN<w>:TRACk:AMPLitude?

The :WGEN<w>:TRACk:AMPLitude? query returns whether amplitude tracking is on or off.

Return Format <on_off><NL>

<on_off> ::= {1 | 0}

- See Also**
- [":WGEN<w>:TRACk"](#) on page 1592
 - [":WGEN<w>:TRACk:FREQuency"](#) on page 1595
 - [":WGEN<w>:TRACk:PHASe"](#) on page 1596
 - [":WGEN<w>:TRACk:CSIGnal"](#) on page 1594

:WGEN<w>:TRACk:CSIGnal

N (see [page 1730](#))

Command Syntax :WGEN<w>:TRACk:CSIGnal

The :WGEN<w>:TRACk:CSIGnal command sets the other waveform generator output to be identical to this waveform generator output (except that the shape of either output may be inverted).

If the signal selected is ARB, the ARB waveform is copied as well.

- See Also**
- [":WGEN<w>:TRACk"](#) on page 1592
 - [":WGEN<w>:TRACk:AMPLitude"](#) on page 1593
 - [":WGEN<w>:TRACk:FREQuency"](#) on page 1595
 - [":WGEN<w>:TRACk:PHASe"](#) on page 1596

:WGEN<w>:TRACk:FREQuency

N (see [page 1730](#))

Command Syntax :WGEN<w>:TRACk:FREQuency <on_off>

<w> ::= 1 to (# WaveGen outputs) in NR1 format

<on_off> ::= {1 | ON} | {0 | OFF}

The :WGEN<w>:TRACk:FREQuency ON command causes frequency adjustments to this waveform generator output signal to be tracked by the other waveform generator output.

Not all waveform shapes can be frequency tracked. When :WGEN<w>:TRACk or :WGEN<w>:TRACk:FREQuency is enabled, the other generator's waveform selections (:WGEN<w>:FUNction) must be in the same group as this generator's waveform:

Group 1	Group 2	Group 3	Group 4
SINusoid	SQUare	EXPRise	ARBitrary
RAMP	PULSe	EXPFall	
SINC			
CARDiac			
GAUSSian			

When tracking is enabled, adjustments for tracked settings in the other waveform generator become unavailable.

Query Syntax :WGEN<w>:TRACk:FREQuency?

The :WGEN<w>:TRACk:FREQuency? query returns whether frequency tracking is on or off.

Return Format <on_off><NL>

<on_off> ::= {1 | 0}

- See Also**
- [":WGEN<w>:TRACk:PHASe"](#) on page 1596
 - [":WGEN<w>:FUNction"](#) on page 1566
 - [":WGEN<w>:TRACk"](#) on page 1592
 - [":WGEN<w>:TRACk:AMPLitude"](#) on page 1593
 - [":WGEN<w>:TRACk:CSIGnal"](#) on page 1594

:WGEN<w>:TRACk:PHASe

N (see [page 1730](#))

Command Syntax :WGEN<w>:TRACk:PHASe <phase>

<w> ::= 1 to (# WaveGen outputs) in NR1 format

<phase> ::= -360 to +360 in NR1 format

The :WGEN<w>:TRACk:PHASe command sets the phase relationship of a frequency-tracked waveform generator output.

Query Syntax :WGEN<w>:TRACk:PHASe?

The :WGEN<w>:TRACk:PHASe? query returns the frequency-tracked waveform phase relationship setting.

Return Format <phase><NL>

<phase> ::= -360 to +360 in NR1 format

- See Also**
- [":WGEN<w>:TRACk"](#) on page 1592
 - [":WGEN<w>:TRACk:AMPLitude"](#) on page 1593
 - [":WGEN<w>:TRACk:FREQuency"](#) on page 1595
 - [":WGEN<w>:TRACk:CSIGNal"](#) on page 1594

:WGEN<w>:VOLTage

N (see [page 1730](#))

Command Syntax :WGEN<w>:VOLTage <amplitude>

<w> ::= 1 to (# WaveGen outputs) in NR1 format

<amplitude> ::= amplitude in volts in NR3 format

For all waveforms except DC, the :WGEN<w>:VOLTage command specifies the waveform's amplitude. Use the :WGEN<w>:VOLTage:OFFSet command to specify the offset voltage or DC level.

You can also specify the amplitude and offset indirectly using the :WGEN<w>:VOLTage:HIGH and :WGEN<w>:VOLTage:LOW commands. For example, an amplitude of 5 V and an offset of 1 V is the same as a high-level voltage of 4 V and a low-level voltage of -1 V.

NOTE

When the amplitude is below 40 mV, the offset is limited to ± 500 mV.

Query Syntax :WGEN<w>:VOLTage?

The :WGEN<w>:VOLTage? query returns the currently specified waveform amplitude.

Return Format <amplitude><NL>

<amplitude> ::= amplitude in volts in NR3 format

- See Also**
- ["Introduction to :WGEN<w> Commands"](#) on page 1555
 - [":WGEN<w>:FUNCTION"](#) on page 1566
 - [":WGEN<w>:VOLTage:OFFSet"](#) on page 1600
 - [":WGEN<w>:VOLTage:HIGH"](#) on page 1598
 - [":WGEN<w>:VOLTage:LOW"](#) on page 1599

:WGEN<w>:VOLTage:HIGH

N (see [page 1730](#))

Command Syntax :WGEN<w>:VOLTage:HIGH <high>

<w> ::= 1 to (# WaveGen outputs) in NR1 format

<high> ::= high-level voltage in volts, in NR3 format

For all waveforms except DC, the :WGEN<w>:VOLTage:HIGH command specifies the waveform's high-level voltage. Use the :WGEN<w>:VOLTage:LOW command to specify the low-level voltage.

You can also specify the high-level and low-level voltages indirectly using the :WGEN<w>:VOLTage and :WGEN<w>:VOLTage:OFFSet commands. For example, a high-level voltage of 4 V and a low-level voltage of -1 V is the same as an amplitude of 5 V and an offset of 1 V.

NOTE

When the amplitude is below 40 mV, the offset is limited to ± 500 mV.

Query Syntax :WGEN<w>:VOLTage:HIGH?

The :WGEN<w>:VOLTage:HIGH? query returns the currently specified waveform high-level voltage.

Return Format <high><NL>

<high> ::= high-level voltage in volts, in NR3 format

- See Also**
- ["Introduction to :WGEN<w> Commands"](#) on page 1555
 - [":WGEN<w>:FUNCTION"](#) on page 1566
 - [":WGEN<w>:VOLTage:LOW"](#) on page 1599
 - [":WGEN<w>:VOLTage"](#) on page 1597
 - [":WGEN<w>:VOLTage:OFFSet"](#) on page 1600

:WGEN<w>:VOLTage:LOW

N (see [page 1730](#))

Command Syntax :WGEN<w>:VOLTage:LOW <low>

<w> ::= 1 to (# WaveGen outputs) in NR1 format

<low> ::= low-level voltage in volts, in NR3 format

For all waveforms except DC, the :WGEN<w>:VOLTage:LOW command specifies the waveform's low-level voltage. Use the :WGEN<w>:VOLTage:HIGH command to specify the high-level voltage.

You can also specify the high-level and low-level voltages indirectly using the :WGEN<w>:VOLTage and :WGEN<w>:VOLTage:OFFSet commands. For example, a high-level voltage of 4 V and a low-level voltage of -1 V is the same as an amplitude of 5 V and an offset of 1 V.

NOTE

When the amplitude is below 40 mV, the offset is limited to ± 500 mV.

Query Syntax :WGEN<w>:VOLTage:LOW?

The :WGEN<w>:VOLTage:LOW? query returns the currently specified waveform low-level voltage.

Return Format <low><NL>

<low> ::= low-level voltage in volts, in NR3 format

- See Also**
- ["Introduction to :WGEN<w> Commands"](#) on page 1555
 - [":WGEN<w>:FUNCTION"](#) on page 1566
 - [":WGEN<w>:VOLTage:LOW"](#) on page 1599
 - [":WGEN<w>:VOLTage"](#) on page 1597
 - [":WGEN<w>:VOLTage:OFFSet"](#) on page 1600

:WGEN<w>:VOLTage:OFFSet

N (see [page 1730](#))

Command Syntax :WGEN<w>:VOLTage:OFFSet <offset>
 <w> ::= 1 to (# WaveGen outputs) in NR1 format
 <offset> ::= offset in volts in NR3 format

The :WGEN<w>:VOLTage:OFFSet command specifies the waveform's offset voltage or the DC level. Use the :WGEN<w>:VOLTage command to specify the amplitude.

You can also specify the amplitude and offset indirectly using the :WGEN<w>:VOLTage:HIGH and :WGEN<w>:VOLTage:LOW commands. For example, an amplitude of 5 V and an offset of 1 V is the same as a high-level voltage of 4 V and a low-level voltage of -1 V.

NOTE

When the amplitude is below 40 mV, the offset is limited to ± 500 mV.

Query Syntax :WGEN<w>:VOLTage:OFFSet?

The :WGEN<w>:VOLTage:OFFSet? query returns the currently specified waveform offset voltage.

Return Format <offset><NL>
 <offset> ::= offset in volts in NR3 format

- See Also**
- ["Introduction to :WGEN<w> Commands"](#) on page 1555
 - [":WGEN<w>:FUNCTION"](#) on page 1566
 - [":WGEN<w>:VOLTage"](#) on page 1597
 - [":WGEN<w>:VOLTage:HIGH"](#) on page 1598
 - [":WGEN<w>:VOLTage:LOW"](#) on page 1599

44 :WMEMemory<r> Commands

Control reference waveforms.

Table 177 :WMEMemory<r> Commands Summary

Command	Query	Options and Query Returns
:WMEMemory<r>:CLEar (see page 1603)	n/a	<r> ::= 1 to (# ref waveforms) in NR1 format
:WMEMemory<r>:DISPlay { {0 OFF} {1 ON} } (see page 1604)	:WMEMemory<r>:DISPlay? (see page 1604)	<r> ::= 1 to (# ref waveforms) in NR1 format {0 1}
:WMEMemory<r>:LABel <string> (see page 1605)	:WMEMemory<r>:LABel? (see page 1605)	<r> ::= 1 to (# ref waveforms) in NR1 format <string> ::= any series of 10 or less ASCII characters enclosed in quotation marks
:WMEMemory<r>:SAVE <source> (see page 1606)	n/a	<r> ::= 1 to (# ref waveforms) in NR1 format <source> ::= {CHANnel<n> FUNCTION<m> MATH<m>} <n> ::= 1 to (# analog channels) in NR1 format <m> ::= 1 to (# math functions) in NR1 format NOTE: Math functions whose x-axis is not frequency can be saved as reference waveforms.
:WMEMemory<r>:SKEW <skew> (see page 1607)	:WMEMemory<r>:SKEW? (see page 1607)	<r> ::= 1 to (# ref waveforms) in NR1 format <skew> ::= time in seconds in NR3 format

Table 177 :WMEemory<r> Commands Summary (continued)

Command	Query	Options and Query Returns
:WMEemory<r>:YOFFset <offset>[suffix] (see page 1608)	:WMEemory<r>:YOFFset? (see page 1608)	<r> ::= 1 to (# ref waveforms) in NR1 format <offset> ::= vertical offset value in NR3 format [suffix] ::= {V mV}
:WMEemory<r>:YRANge <range> (see page 1609)	:WMEemory<r>:YRANge? (see page 1609)	<r> ::= 1 to (# ref waveforms) in NR1 format <range> ::= vertical full-scale range value in NR3 format
:WMEemory<r>:YSCale <scale> (see page 1610)	:WMEemory<r>:YSCale? (see page 1610)	<r> ::= 1 to (# ref waveforms) in NR1 format <scale> ::= vertical units per division value in NR3 format

:WMEemory<r>:CLEar

N (see [page 1730](#))

Command Syntax :WMEemory<r>:CLEar

<r> ::= 1 to (# ref waveforms) in NR1 format

The :WMEemory<r>:CLEar command clears the specified reference waveform location.

- See Also**
- [Chapter 44](#), “:WMEemory<r> Commands,” starting on page 1601
 - [":WMEemory<r>:SAVE"](#) on page 1606
 - [":WMEemory<r>:DISPlay"](#) on page 1604

:WMEemory<r>:DISPlay

N (see [page 1730](#))

Command Syntax :WMEemory<r>:DISPlay <on_off>

<r> ::= 1 to (# ref waveforms) in NR1 format

<on_off> ::= {{1 | ON} | {0 | OFF}}

The :WMEemory<r>:DISPlay command turns the display of the specified reference waveform on or off.

There are two reference waveform locations, but only one reference waveform can be displayed at a time. That means, if :WMEemory1:DISPlay is ON, sending the :WMEemory2:DISPlay ON command will automatically set :WMEemory1:DISPlay OFF.

Query Syntax :WMEemory<r>:DISPlay?

The :WMEemory<r>:DISPlay? query returns the current display setting for the reference waveform.

Return Format <on_off><NL>

<on_off> ::= {1 | 0}

- See Also**
- [Chapter 44](#), “:WMEemory<r> Commands,” starting on page 1601
 - [":WMEemory<r>:CLEar"](#) on page 1603
 - [":WMEemory<r>:LABel"](#) on page 1605

:WMEemory<r>:LABel

N (see [page 1730](#))

Command Syntax :WMEemory<r>:LABel <string>
 <r> ::= 1 to (# ref waveforms) in NR1 format
 <string> ::= quoted ASCII string

NOTE

Label strings are 10 characters or less, and may contain any commonly used ASCII characters. Labels with more than 10 characters are truncated to 10 characters. Lower case characters are converted to upper case.

The :WMEemory<r>:LABel command sets the reference waveform label to the string that follows.

Setting a label for a reference waveform also adds the name to the label list in non-volatile memory (replacing the oldest label in the list).

Query Syntax :WMEemory<r>:LABel?

The :WMEemory<r>:LABel? query returns the label associated with a particular reference waveform.

Return Format <string><NL>
 <string> ::= quoted ASCII string

- See Also**
- [Chapter 44](#), “:WMEemory<r> Commands,” starting on page 1601
 - [":WMEemory<r>:DISPlay"](#) on page 1604

:WMEemory<r>:SAVE

N (see [page 1730](#))

Command Syntax :WMEemory<r>:SAVE <source>

<r> ::= 1 to (# ref waveforms) in NR1 format

<source> ::= {CHANnel<n> | FUNction<m> | MATH<m>}

<n> ::= 1 to (# analog channels) in NR1 format

<m> ::= 1 to (# math functions) in NR1 format

The :WMEemory<r>:SAVE command copies the analog channel or math function waveform to the specified reference waveform location.

NOTE

Math functions whose x-axis is not frequency can be saved as reference waveforms.

-
- See Also**
- [Chapter 44](#), “:WMEemory<r> Commands,” starting on page 1601
 - [":WMEemory<r>:DISPlay"](#) on page 1604

:WMEemory<r>:SKEW

N (see [page 1730](#))

Command Syntax :WMEemory<r>:SKEW <skew>

<r> ::= 1 to (# ref waveforms) in NR1 format

<skew> ::= time in seconds in NR3 format

The :WMEemory<r>:SKEW command sets the skew factor for the specified reference waveform.

Query Syntax :WMEemory<r>:SKEW?

The :WMEemory<r>:SKEW? query returns the current skew setting for the selected reference waveform.

Return Format <skew><NL>

<skew> ::= time in seconds in NR3 format

- See Also**
- [Chapter 44](#), “:WMEemory<r> Commands,” starting on page 1601
 - [":WMEemory<r>:DISPlay"](#) on page 1604
 - [":WMEemory<r>:YOFFset"](#) on page 1608
 - [":WMEemory<r>:YRANge"](#) on page 1609
 - [":WMEemory<r>:YSCale"](#) on page 1610

:WMemory<r>:YOFFset

N (see [page 1730](#))

Command Syntax :WMemory<r>:YOFFset <offset> [<suffix>]

<r> ::= 1 to (# ref waveforms) in NR1 format

<offset> ::= vertical offset value in NR3 format

<suffix> ::= {V | mV}

The :WMemory<r>:YOFFset command sets the value that is represented at center screen for the selected reference waveform.

The range of legal values varies with the value set by the :WMemory<r>:YRANge or :WMemory<r>:YSCale commands. If you set the offset to a value outside of the legal range, the offset value is automatically set to the nearest legal value. Legal values are affected by the probe attenuation setting.

Query Syntax :WMemory<r>:YOFFset?

The :WMemory<r>:YOFFset? query returns the current offset value for the selected reference waveform.

Return Format <offset><NL>

<offset> ::= vertical offset value in NR3 format

- See Also**
- [Chapter 44](#), “:WMemory<r> Commands,” starting on page 1601
 - [":WMemory<r>:DISPlay"](#) on page 1604
 - [":WMemory<r>:YRANge"](#) on page 1609
 - [":WMemory<r>:YSCale"](#) on page 1610
 - [":WMemory<r>:SKEW"](#) on page 1607

:WMEemory<r>:YRANge

N (see [page 1730](#))

Command Syntax :WMEemory<r>:YRANge <range>

<r> ::= 1 to (# ref waveforms) in NR1 format

<range> ::= vertical full-scale range value in NR3 format

The :WMEemory<r>:YRANge command defines the full-scale vertical axis of the selected reference waveform.

Legal values for the range are copied from the original source waveform (that is, the analog channel or math function waveform that was originally saved as a reference waveform).

Query Syntax :WMEemory<r>:YRANge?

The :WMEemory<r>:YRANge? query returns the current full-scale range setting for the specified reference waveform.

Return Format <range><NL>

<range> ::= vertical full-scale range value in NR3 format

- See Also**
- [Chapter 44](#), “:WMEemory<r> Commands,” starting on page 1601
 - [":WMEemory<r>:DISPlay"](#) on page 1604
 - [":WMEemory<r>:YOFFset"](#) on page 1608
 - [":WMEemory<r>:SKEW"](#) on page 1607
 - [":WMEemory<r>:YSCale"](#) on page 1610

:WMEemory<r>:YScale

N (see [page 1730](#))

Command Syntax :WMEemory<r>:YScale <scale>

<r> ::= 1 to (# ref waveforms) in NR1 format

<scale> ::= vertical units per division in NR3 format

The :WMEemory<r>:YScale command sets the vertical scale, or units per division, of the selected reference waveform.

Legal values for the scale are copied from the original source waveform (that is, the analog channel or math function waveform that was originally saved as a reference waveform).

Query Syntax :WMEemory<r>:YScale?

The :WMEemory<r>:YScale? query returns the current scale setting for the specified reference waveform.

Return Format <scale><NL>

<scale> ::= vertical units per division in NR3 format

- See Also**
- [Chapter 44](#), “:WMEemory<r> Commands,” starting on page 1601
 - [":WMEemory<r>:DISPlay"](#) on page 1604
 - [":WMEemory<r>:YOFFset"](#) on page 1608
 - [":WMEemory<r>:YRANge"](#) on page 1609
 - [":WMEemory<r>:SKEW"](#) on page 1607

45 Obsolete and Discontinued Commands

Obsolete commands are older forms of commands that are provided to reduce customer rework for existing systems and programs (see "**Obsolete Commands**" on page 1730).

Obsolete Command	Current Command Equivalent	Behavior Differences
ANALog<n>:BWLimit	:CHANnel<n>:BWLimit (see page 355)	
ANALog<n>:COUPling	:CHANnel<n>:COUPling (see page 356)	
ANALog<n>:INVert	:CHANnel<n>:INVert (see page 359)	
ANALog<n>:LABel	:CHANnel<n>:LABel (see page 360)	
ANALog<n>:OFFSet	:CHANnel<n>:OFFSet (see page 361)	
ANALog<n>:PROBe	:CHANnel<n>:PROBe (see page 362)	
ANALog<n>:PMODE	none	
ANALog<n>:RANGe	:CHANnel<n>:RANGe (see page 378)	
:CHANnel:ACTivity (see page 1618)	:ACTivity (see page 261)	
:CHANnel:LABel (see page 1619)	:CHANnel<n>:LABel (see page 360) or :DIGital<n>:LABel (see page 424)	use CHANnel<n>:LABel for analog channels and use DIGital<n>:LABel for digital channels

Obsolete Command	Current Command Equivalent	Behavior Differences
:CHANnel:THReshold (see page 1620)	:POD<n>:THReshold (see page 819) or :DIGital<d>:THReshold (see page 427)	
:CHANnel2:SKEW (see page 1621)	:CHANnel<n>:PROBe:SKEW (see page 374)	
:CHANnel<n>:INPut (see page 1622)	:CHANnel<n>:IMPedance (see page 358)	
:CHANnel<n>:PMODE (see page 1623)	none	
:DISPlay:CONNect (see page 1624)	:DISPlay:VECTors (see page 454)	
:DISPlay:ORDer (see page 1625)	none	
:ERASe (see page 1626)	:DISPlay:CLEar (see page 439)	
:EXTernal:PMODE (see page 1627)	none	
FUNcTion1, FUNcTion2	:FUNcTion Commands (see page 483)	ADD not included
:FUNcTion Commands	:FUNcTion2 Commands (see page 483)	:FUNcTion commands (with no <m> number) map to :FUNcTion2. This allows legacy programs to work without change.
:FUNcTion:GOFT:OPERation (see page 1628)	:FUNcTion1:OPERation (see page 521)	GOFT maps to FUNcTion1.
:FUNcTion:GOFT:SOURce1 (see page 1629)	:FUNcTion1:SOURce1 (see page 535)	GOFT maps to FUNcTion1.
:FUNcTion:GOFT:SOURce2 (see page 1630)	:FUNcTion1:SOURce2 (see page 537)	GOFT maps to FUNcTion1.
:FUNcTion:SOURce (see page 1631)	:FUNcTion:SOURce1 (see page 535)	Obsolete command has ADD, SUBTract, and MULTiPLY parameters; current command has GOFT parameter.
:FUNcTion:VIEW (see page 1632)	:FUNcTion:DISPlay (see page 497)	
:HARDcopy:DESTination (see page 1633)	:HARDcopy:FILEname (see page 1634)	

Obsolete Command	Current Command Equivalent	Behavior Differences
:HARDcopy:FILENAME (see page 1634)	:RECall:FILENAME (see page 930) :SAVE:FILENAME (see page 930)	
:HARDcopy:GRAYscale (see page 1635)	:HARDcopy:PALette (see page 554)	
:HARDcopy:IGColors (see page 1636)	:HARDcopy:INKSaver (see page 546)	
:HARDcopy:PDRiver (see page 1637)	:HARDcopy:APRinter (see page 543)	
:MEASure:LOWer (see page 1638)	:MEASure:DEFine:THResholds (see page 671)	MEASure:DEFine:THResholds can define absolute values or percentage
:MEASure:SCRatch (see page 1639)	:MEASure:CLEar (see page 664)	
:MEASure:TDELta (see page 1640)	:MARKer:XDELta (see page 624)	
:MEASure:THResholds (see page 1641)	:MEASure:DEFine:THResholds (see page 671)	MEASure:DEFine:THResholds can define absolute values or percentage
:MEASure:TMAX (see page 1642)	:MEASure:XMAX (see page 754)	
:MEASure:TMIN (see page 1643)	:MEASure:XMIN (see page 755)	
:MEASure:TSTArt (see page 1644)	:MARKer:X1Position (see page 619)	
:MEASure:TSTOp (see page 1645)	:MARKer:X2Position (see page 622)	
:MEASure:TVOLt (see page 1646)	:MEASure:TVALue (see page 742)	TVALue measures additional values such as db, Vs, etc.
:MEASure:UPPer (see page 1647)	:MEASure:DEFine:THResholds (see page 671)	MEASure:DEFine:THResholds can define absolute values or percentage
:MEASure:VDELta (see page 1648)	:MARKer:YDELta (see page 631)	
:MEASure:VSTArt (see page 1649)	:MARKer:Y1Position (see page 628)	
:MEASure:VSTOp (see page 1650)	:MARKer:Y2Position (see page 630)	

Obsolete Command	Current Command Equivalent	Behavior Differences
:MEASure:VTime (see page 1651)	:MEASure:YATX (see page 756)	With :MEASure:YATX, there is a command for installing the measurement on the oscilloscope's display. :MEASure:VTime had no command, only a query.
:MTESt:AMASK:{SAVE STORE} (see page 1652)	:SAVE:MASK[:START] (see page 956)	
:MTESt:AVERAge (see page 1653)	:ACQuire:TYPE AVERAge (see page 318)	
:MTESt:AVERAge:COUNT (see page 1654)	:ACQuire:COUNT (see page 306)	
:MTESt:LOAD (see page 1655)	:RECall:MASK[:START] (see page 932)	
:MTESt:RUMode (see page 1656)	:MTESt:RMODE (see page 800)	
:MTESt:RUMode:SOFailure (see page 1657)	:MTESt:RMODE:FACTion:STOP (see page 804)	
:MTESt:{START STOP} (see page 1658)	:RUN (see page 294) or :STOP (see page 298)	
:MTESt:TRIGger:SOURce (see page 1659)	:TRIGger Commands (see page 1425)	There are various commands for setting the source with different types of triggers.
:PRINT? (see page 1660)	:DISPlay:DATA? (see page 440)	
:SAVE:IMAGe:AREA (see page 1662)	none	
:TIMEbase:DElay (see page 1666)	:TIMEbase:POSition (see page 1414) or :TIMEbase:WINDow:POSition (see page 1421)	TIMEbase:POSition is position value of main time base; TIMEbase:WINDow:POSition is position value of zoomed (delayed) time base window.
:SBUS<n>:LIN:SIGNal:DEFinitio n (see page 1663)	none	
:SBUS<n>:SPI:SOURce:DATA (see page 1664)	:SBUS<n>:SPI:SOURce:MOSI (see page 1207)	
:SYSTem:MENU (see page 1665)	:DISPlay:MENU (see page 448)	No change in behavior.

Obsolete Command	Current Command Equivalent	Behavior Differences
:TRIGger:THReshold (see page 1667)	:POD<n>:THReshold (see page 819) or :DIGital<d>:THReshold (see page 427)	
:TRIGger:TV:TVMode (see page 1668)	:TRIGger:TV:MODE (see page 1498)	

Discontinued Commands

Discontinued commands are commands that were used by previous oscilloscopes, but are not supported by the InfiniiVision 6000 X-Series oscilloscopes. Listed below are the Discontinued commands and the nearest equivalent command available (if any).

Discontinued Command	Current Command Equivalent	Comments
ASTore	:DISPlay:PERsistence INFinite (see page 450)	
CHANnel:MATH	:FUNctio:n:OPERation (see page 521)	ADD not included
CHANnel<n>:PROTect	:CHANnel<n>:PROTectio:n (see page 377)	Previous form of this command was used to enable/disable 50Ω protection. The new command resets a tripped protect and the query returns the status of TRIPed or NORMal.
DISPlay:INVerse	none	
DISPlay:COLumn	none	
DISPlay:FREeze	none	
DISPlay:GRID	none	
DISPlay:LINE	none	
DISPlay:PIXel	none	
DISPlay:POSition	none	
DISPlay:ROW	none	
DISPlay:TEXT	none	
FUNctio:n:MOVE	none	
FUNctio:n:PEAKs	none	
HARDcopy:ADDRes	none	Only parallel printer port is supported. GPIB printing not supported

Discontinued Command	Current Command Equivalent	Comments
MASK	none	All commands discontinued, feature not available
:POWer:SIGNals:CYCLes	:POWer:SIGNals:CYCLes:HARMonics (see page 893) :POWer:SIGNals:CYCLes:QUALiTy (see page 894)	This command was separated into several other commands for specific types of power analysis.
:POWer:SIGNals:DURation	:POWer:SIGNals:DURation:EFFiCiency (see page 895) :POWer:SIGNals:DURation:MOdulation (see page 896) :POWer:SIGNals:DURation:ONOff:OFF (see page 897) :POWer:SIGNals:DURation:ONOff:ON (see page 898) :POWer:SIGNals:DURation:RIPle (see page 899) :POWer:SIGNals:DURation:TRANsient (see page 900)	This command was separated into several other commands for specific types of power analysis.
:POWer:SIGNals:VMAXimum	:POWer:SIGNals:VMAXimum:INRush (see page 903) :POWer:SIGNals:VMAXimum:ONOff:OFF (see page 904) :POWer:SIGNals:VMAXimum:ONOff:ON (see page 905)	This command was separated into several other commands for specific types of power analysis.
:POWer:SIGNals:VSTeady	:POWer:SIGNals:VSTeady:ONOff:OFF (see page 906) :POWer:SIGNals:VSTeady:ONOff:ON (see page 907) :POWer:SIGNals:VSTeady:TRANsient (see page 908)	This command was separated into several other commands for specific types of power analysis.
:POWer:SLEW:VALue	none	Slew rate values are now displayed using max and min measurements of a differentiate math function signal.
:PWRenable	none	The Power Event Enable Register does not exist in the 6000 X-Series oscilloscopes.
:PWRRegister[:EVENT]	none	The Power Event Event Register does not exist in the 6000 X-Series oscilloscopes.

Discontinued Command	Current Command Equivalent	Comments
SYSTem:KEY	none	
TEST:ALL	*TST (Self Test) (see page 255)	
TRACE subsystem	none	All commands discontinued, feature not available
TRIGger:ADVanced subsystem		Use new GLITch, PATtern, or TV trigger modes
TRIGger:TV:FIELD	:TRIGger:TV:MODE (see page 1498)	
TRIGger:TV:TVHFrej		
TRIGger:TV:VIR	none	
:TRIGger:USB:SOURce:DMINus	none	These USB trigger commands are superseded by commands that are available with the USB 2.0 Full/Low Speed or USB 2.0 High Speed serial decode and triggering licenses. See " :SBUS<n>:USB Commands " on page 1236.
:TRIGger:USB:SOURce:DPLus	none	
:TRIGger:USB:SPEed	none	
:TRIGger:USB:TRIGger	none	
VAUToscale	none	

Discontinued Parameters

Some previous oscilloscope queries returned control setting values of OFF and ON. The InfiniiVision 6000 X-Series oscilloscopes only return the enumerated values 0 (for off) and 1 (for on).

:CHANnel:ACTivity

O (see [page 1730](#))

Command Syntax :CHANnel:ACTivity

The :CHANnel:ACTivity command clears the cumulative edge variables for the next activity query.

NOTE

The :CHANnel:ACTivity command is an obsolete command provided for compatibility to previous oscilloscopes. Use the :ACTivity command (see [page 261](#)) instead.

Query Syntax :CHANnel:ACTivity?

The :CHANnel:ACTivity? query returns the active edges since the last clear, and returns the current logic levels.

Return Format <edges>, <levels><NL>

<edges> ::= presence of edges (32-bit integer in NR1 format).

<levels> ::= logical highs or lows (32-bit integer in NR1 format).

NOTE

A bit equal to zero indicates that no edges were detected at the specified threshold since the last clear on that channel. Edges may have occurred that were not detected because of the threshold setting.

A bit equal to one indicates that edges have been detected at the specified threshold since the last clear on that channel.

:CHANnel:LABel

O (see [page 1730](#))

Command Syntax :CHANnel:LABel <source_text><string>
 <source_text> ::= {CHANnel1 | CHANnel2 | DIGital<d>}
 <d> ::= 0 to (# digital channels - 1) in NR1 format
 <string> ::= quoted ASCII string

The :CHANnel:LABel command sets the source text to the string that follows. Setting a channel will also result in the name being added to the label list.

NOTE

The :CHANnel:LABel command is an obsolete command provided for compatibility to previous oscilloscopes. Use the :CHANnel<n>:LABel command (see [page 360](#)) or :DIGital<n>:LABel command (see [page 424](#)).

Query Syntax :CHANnel:LABel?

The :CHANnel:LABel? query returns the label associated with a particular analog channel.

Return Format <string><NL>
 <string> ::= quoted ASCII string

:CHANnel:THReshold

O (see [page 1730](#))

Command Syntax :CHANnel:THReshold <channel group>, <threshold type> [, <value>]

<channel group> ::= {POD1 | POD2}

<threshold type> ::= {CMOS | ECL | TTL | USERdef}

<value> ::= voltage for USERdef in NR3 format [volt_type]

[volt_type] ::= {V | mV (-3) | uV (-6)}

The :CHANnel:THReshold command sets the threshold for a group of channels. The threshold is either set to a predefined value or to a user-defined value. For the predefined value, the voltage parameter is ignored.

NOTE

The :CHANnel:THReshold command is an obsolete command provided for compatibility to previous oscilloscopes. Use the :POD<n>:THReshold command (see [page 819](#)) or :DIGital<n>:THReshold command (see [page 427](#)).

Query Syntax :CHANnel:THReshold? <channel group>

The :CHANnel:THReshold? query returns the voltage and threshold text for a specific group of channels.

Return Format <threshold type> [, <value>]<NL>

<threshold type> ::= {CMOS | ECL | TTL | USERdef}

<value> ::= voltage for USERdef (float 32 NR3)

NOTE

- CMOS = 2.5V
- TTL = 1.5V
- ECL = -1.3V
- USERdef ::= -6.0V to 6.0V

:CHANnel2:SKEW

O (see [page 1730](#))

Command Syntax :CHANnel2:SKEW <skew value>
 <skew value> ::= skew time in NR3 format
 <skew value> ::= -100 ns to +100 ns

The :CHANnel2:SKEW command sets the skew between channels 1 and 2. The maximum skew is +/-100 ns. You can use the oscilloscope's analog probe skew control to remove cable delay errors between channel 1 and channel 2.

NOTE

The :CHANnel2:SKEW command is an obsolete command provided for compatibility to previous oscilloscopes. Use the :CHANnel<n>:PROBe:SKEW command (see [page 374](#)) instead.

NOTE

This command is only valid for the two channel oscilloscope models.

Query Syntax :CHANnel2:SKEW?

The :CHANnel2:SKEW? query returns the current probe skew setting for the selected channel.

Return Format <skew value><NL>
 <skew value> ::= skew value in NR3 format

See Also • ["Introduction to :CHANnel<n> Commands"](#) on page 352

`:CHANnel<n>:INPut`

O (see [page 1730](#))

Command Syntax `:CHANnel<n>:INPut <impedance>`

`<impedance> ::= {ONEMeg | FIFTy}`

`<n> ::= 1 to (# analog channels) in NR1 format`

The `:CHANnel<n>:INPut` command selects the input impedance setting for the specified channel. The legal values for this command are ONEMeg (1 M Ω) and FIFTy (50 Ω).

NOTE

The `:CHANnel<n>:INPut` command is an obsolete command provided for compatibility to previous oscilloscopes. Use the `:CHANnel<n>:IMPedance` command (see [page 358](#)) instead.

Query Syntax `:CHANnel<n>:INPut?`

The `:CHANnel<n>:INPut?` query returns the current input impedance setting for the specified channel.

Return Format `<impedance value><NL>`

`<impedance value> ::= {ONEM | FIFT}`

`:CHANnel<n>:PMODE`

O (see [page 1730](#))

Command Syntax `:CHANnel<n>:PMODE <pmode value>`
`<pmode value> ::= {AUTO | MANual}`
`<n> ::= 1 to (# analog channels) in NR1 format`

The probe sense mode is controlled internally and cannot be set. If a probe with sense is connected to the specified channel, auto sensing is enabled; otherwise, the mode is manual.

If the PMODE sent matches the oscilloscope's setting, the command will be accepted. Otherwise, a setting conflict error is generated.

NOTE

The `:CHANnel<n>:PMODE` command is an obsolete command provided for compatibility to previous oscilloscopes.

Query Syntax `:CHANnel<n>:PMODE?`

The `:CHANnel<n>:PMODE?` query returns AUT if an autosense probe is attached and MAN otherwise.

Return Format `<pmode value><NL>`
`<pmode value> ::= {AUT | MAN}`

:DISPlay:CONNect

O (see [page 1730](#))

Command Syntax :DISPlay:CONNect <connect>
 <connect> ::= {{ 1 | ON} | {0 | OFF}}

The :DISPlay:CONNect command turns vectors on and off. When vectors are turned on, the oscilloscope displays lines connecting sampled data points. When vectors are turned off, only the sampled data is displayed.

NOTE

The :DISPlay:CONNect command is an obsolete command provided for compatibility to previous oscilloscopes. Use the :DISPlay:VECTors command (see [page 454](#)) instead.

Query Syntax :DISPlay:CONNect?

The :DISPlay:CONNect? query returns the current state of the vectors setting.

Return Format <connect><NL>
 <connect> ::= {1 | 0}

See Also • [":DISPlay:VECTors"](#) on page 454

:DISPlay:ORDer

O (see [page 1730](#))

Query Syntax :DISPlay:ORDer?

The :DISPlay:ORDer? query returns a list of digital channel numbers in screen order, from top to bottom, separated by commas. Busing is displayed as digital channels with no separator. For example, in the following list, the bus consists of digital channels 4 and 5: DIG1, DIG4 DIG5, DIG7.

NOTE

The :DISPlay:ORDer command is an obsolete command provided for compatibility to previous oscilloscopes. This command is only available on the MSO models.

Return Format

```
<order><NL>
<order> ::= Unquoted ASCII string
```

NOTE

A return value is included for each digital channel. A return value of NONE indicates that a channel is turned off.

See Also • [":DIGital<d>:POSition"](#) on page 425

Example Code

```
' DISP_ORDER - Set the order the channels are displayed on the
' analyzer. You can enter between 1 and 32 channels at one time.
' If you leave out channels, they will not be displayed.

' Display ONLY channel 0 and channel 10 in that order.
myScope.WriteString ":DISPLAY:ORDER 0,10"
```

See complete example programs at: [Chapter 50](#), "Programming Examples," starting on page 1739

:ERASe

O (see [page 1730](#))

Command Syntax :ERASe

The :ERASe command erases the screen.

NOTE

The :ERASe command is an obsolete command provided for compatibility to previous oscilloscopes. Use the :DISplay:CLEar command (see [page 439](#)) instead.

:EXternal:PMODE

O (see [page 1730](#))

Command Syntax :EXternal:PMODE <pmode value>
<pmode value> ::= {AUTO | MANual}

The probe sense mode is controlled internally and cannot be set. If a probe with sense is connected to the specified channel, auto sensing is enabled; otherwise, the mode is manual.

If the pmode sent matches the oscilloscope's setting, the command will be accepted. Otherwise, a setting conflict error is generated.

NOTE

The :EXternal:PMODE command is an obsolete command provided for compatibility to previous oscilloscopes.

Query Syntax :EXternal:PMODE?

The :EXternal:PMODE? query returns AUT if an autosense probe is attached and MAN otherwise.

Return Format <pmode value><NL>
<pmode value> ::= {AUT | MAN}

:FUNction:GOFT:OPERation

O (see [page 1730](#))

Command Syntax :FUNction:GOFT:OPERation <operation>

<operation> ::= {ADD | SUBTract | MULTiPLY}

The :FUNction:GOFT:OPERation command sets the math operation for the g(t) source that can be used as the input to transform or filter functions (if available):

- ADD – Source1 + source2.
- SUBTract – Source1 - source2.
- MULTiPLY – Source1 * source2.

The :FUNction:GOFT:SOURce1 and :FUNction:GOFT:SOURce2 commands are used to select source1 and source2.

:FUNction:GOFT:SOURce1

O (see [page 1730](#))

Command Syntax :FUNction:GOFT:SOURce1 <value>

<value> ::= CHANnel<n>

<n> ::= {1 | 2 | 3 | 4} for 4ch models

<n> ::= {1 | 2} for 2ch models

The :FUNction:GOFT:SOURce1 command selects the first input channel for the g(t) source that can be used as the input to transform or filter functions (if available).

Query Syntax :FUNction:GOFT:SOURce1?

The :FUNction:GOFT:SOURce1? query returns the current selection for the first input channel for the g(t) source.

Return Format <value><NL>

<value> ::= CHAN<n>

<n> ::= {1 | 2 | 3 | 4} for the 4ch models

<n> ::= {1 | 2} for the 2ch models

- See Also**
- ["Introduction to :FUNction<m> Commands"](#) on page 489
 - [":FUNction:GOFT:SOURce2"](#) on page 1630
 - [":FUNction:GOFT:OPERation"](#) on page 1628

:FUNCTION:GOFT:SOURce2

O (see [page 1730](#))

Command Syntax :FUNCTION:GOFT:SOURce2 <value>

<value> ::= CHANnel<n>

<n> ::= {1 | 2 | 3 | 4} for 4ch models

<n> ::= {1 | 2} for 2ch models

The :FUNCTION:GOFT:SOURce2 command selects the second input channel for the g(t) source that can be used as the input to transform or filter functions (if available).

Query Syntax :FUNCTION:GOFT:SOURce2?

The :FUNCTION:GOFT:SOURce2? query returns the current selection for the second input channel for the g(t) source.

Return Format <value><NL>

<value> ::= CHAN<n>

<n> ::= {1 | 2 | 3 | 4} for 4ch models

<n> ::= {1 | 2} for 2ch models

- See Also**
- ["Introduction to :FUNCTION<m> Commands"](#) on page 489
 - [":FUNCTION:GOFT:SOURce1"](#) on page 1629
 - [":FUNCTION:GOFT:OPERation"](#) on page 1628

:FUNCTION:SOURce

O (see [page 1730](#))

Command Syntax :FUNCTION:SOURce <value>
 <value> ::= {CHANnel<n> | ADD | SUBTract | MULTiply}
 <n> ::= 1 to (# analog channels) in NR1 format

The :FUNCTION:SOURce command is only used when an FFT (Fast Fourier Transform), DIFF, or INT operation is selected (see the :FUNCTION:OPERation command for more information about selecting an operation). The :FUNCTION:SOURce command selects the source for function operations. Choose CHANnel<n>, or ADD, SUBT, or MULT to specify the desired source for function DIFF (differentiate), INTegrate, and FFT operations specified by the :FUNCTION:OPERation command.

NOTE

The :FUNCTION:SOURce command is an obsolete command provided for compatibility to previous oscilloscopes. Use the :FUNCTION:SOURce1 command (see [page 535](#)) instead.

Query Syntax :FUNCTION:SOURce?

The :FUNCTION:SOURce? query returns the current source for function operations.

Return Format <value><NL>
 <value> ::= {CHAN<n> | ADD | SUBT | MULT}
 <n> ::= 1 to (# analog channels) in NR1 format

See Also

- ["Introduction to :FUNCTION<m> Commands"](#) on page 489
- [":FUNCTION<m>:OPERation"](#) on page 521

:FUNCTION:VIEW

O (see [page 1730](#))

Command Syntax :FUNCTION:VIEW <view>
 <view> ::= {{1 | ON} | (0 | OFF}}

The :FUNCTION:VIEW command turns the selected function on or off. When ON is selected, the function performs as specified using the other FUNCTION commands. When OFF is selected, function is neither calculated nor displayed.

NOTE

The :FUNCTION:VIEW command is provided for backward compatibility to previous oscilloscopes. Use the :FUNCTION:DISPLAY command (see [page 497](#)) instead.

Query Syntax :FUNCTION:VIEW?

The :FUNCTION:VIEW? query returns the current state of the selected function.

Return Format <view><NL>
 <view> ::= {1 | 0}

:HARDcopy:DESTination

O (see [page 1730](#))

Command Syntax :HARDcopy:DESTination <destination>
 <destination> ::= {CENTronics | FLOppy}

The :HARDcopy:DESTination command sets the hardcopy destination.

NOTE

The :HARDcopy:DESTination command is an obsolete command provided for compatibility to previous oscilloscopes. Use the :HARDcopy:FILENAME command (see [page 1634](#)) instead.

Query Syntax :HARDcopy:DESTination?

The :HARDcopy:DESTination? query returns the selected hardcopy destination.

Return Format <destination><NL>
 <destination> ::= {CENT | FLOP}

See Also • ["Introduction to :HARDcopy Commands"](#) on page 540

:HARDcopy:FILEname

O (see [page 1730](#))

Command Syntax :HARDcopy:FILEname <string>
<string> ::= quoted ASCII string

The :HARDcopy:FILEname command sets the output filename for those print formats whose output is a file.

NOTE

The :HARDcopy:FILEname command is an obsolete command provided for compatibility to previous oscilloscopes. Use the :SAVE:FILEname command (see [page 949](#)) and :RECall:FILEname command (see [page 930](#)) instead.

Query Syntax :HARDcopy:FILEname?

The :HARDcopy:FILEname? query returns the current hardcopy output filename.

Return Format <string><NL>
<string> ::= quoted ASCII string

See Also • ["Introduction to :HARDcopy Commands"](#) on page 540

:HARDcopy:GRAYscale

O (see [page 1730](#))

Command Syntax :HARDcopy:GRAYscale <gray>
<gray> ::= {{OFF | 0} | {ON | 1}}

The :HARDcopy:GRAYscale command controls whether grayscaling is performed in the hardcopy dump.

NOTE

The :HARDcopy:GRAYscale command is an obsolete command provided for compatibility to previous oscilloscopes. Use the :HARDcopy:PALETTE command (see [page 554](#)) instead. (":HARDcopy:GRAYscale ON" is the same as ":HARDcopy:PALETTE GRAYscale" and ":HARDcopy:GRAYscale OFF" is the same as ":HARDcopy:PALETTE COLOR".)

Query Syntax :HARDcopy:GRAYscale?

The :HARDcopy:GRAYscale? query returns a flag indicating whether grayscaling is performed in the hardcopy dump.

Return Format <gray><NL>
<gray> ::= {0 | 1}

See Also • ["Introduction to :HARDcopy Commands"](#) on page 540

:HARDcopy:IGColors

Q (see [page 1730](#))

Command Syntax :HARDcopy:IGColors <value>
<value> ::= {{OFF | 0} | {ON | 1}}

The :HARDcopy:IGColors command controls whether the graticule colors are inverted or not.

NOTE

The :HARDcopy:IGColors command is an obsolete command provided for compatibility to previous oscilloscopes. Use the :HARDcopy:INKSaver (see [page 546](#)) command instead.

Query Syntax :HARDcopy:IGColors?

The :HARDcopy:IGColors? query returns a flag indicating whether graticule colors are inverted or not.

Return Format <value><NL>
<value> ::= {0 | 1}

See Also • ["Introduction to :HARDcopy Commands"](#) on page 540

:HARDcopy:PDRiver

O (see [page 1730](#))

Command Syntax :HARDcopy:PDRiver <driver>

```
<driver> ::= {AP2Xxx | AP21xx | {AP2560 | AP25} | {DJ350 | DJ35} |
             DJ6xx | {DJ630 | DJ63} | DJ6Special | DJ6Photo |
             DJ8Special | DJ8xx | DJ9Vip | OJPRokx50 | DJ9xx | GVIP |
             DJ55xx | {PS470 | PS47} {PS100 | PS10} | CLASer |
             MLASer | LJFastraster | POSTscript}
```

The HARDcopy:PDRiver command sets the hardcopy printer driver used for the selected printer.

If the correct driver for the selected printer can be identified, it will be selected and cannot be changed.

NOTE

The :HARDcopy:PDRiver command is an obsolete command provided for compatibility to previous oscilloscopes. Use the :HARDcopy:APRinter (see [page 543](#)) command instead.

Query Syntax :HARDcopy:PDRiver?

The :HARDcopy:PDRiver? query returns the selected hardcopy printer driver.

Return Format <driver><NL>

```
<driver> ::= {AP2X | AP21 | AP25 | DJ35 | DJ6 | DJ63 | DJ6S | DJ6P |
             DJ8S | DJ8 | DJ9V | OJPR | DJ9 | GVIP | DJ55 | PS10 |
             PS47 | CLAS | MLAS | LJF | POST}
```

See Also • ["Introduction to :HARDcopy Commands"](#) on page 540

:MEASure:LOWer

O (see [page 1730](#))

Command Syntax :MEASure:LOWer <voltage>

The :MEASure:LOWer command sets the lower measurement threshold value. This value and the UPPer value represent absolute values when the thresholds are ABSolute and percentage when the thresholds are PERCent as defined by the :MEASure:DEFine THResholds command.

NOTE

The :MEASure:LOWer command is obsolete and is provided for backward compatibility to previous oscilloscopes. Use the :MEASure:DEFine THResholds command (see [page 671](#)) instead.

Query Syntax :MEASure:LOWer?

The :MEASure:LOWer? query returns the current lower threshold level.

Return Format <voltage><NL>

<voltage> ::= the user-defined lower threshold in volts in NR3 format

- See Also**
- ["Introduction to :MEASure Commands"](#) on page 658
 - [":MEASure:THResholds"](#) on page 1641
 - [":MEASure:UPPer"](#) on page 1647

:MEASure:SCRatch

O (see [page 1730](#))

Command Syntax :MEASure:SCRatch

The :MEASure:SCRatch command clears all selected measurements and markers from the screen.

NOTE

The :MEASure:SCRatch command is obsolete and is provided for backward compatibility to previous oscilloscopes. Use the :MEASure:CLEar command (see [page 664](#)) instead.

:MEASure:TDELta

O (see [page 1730](#))

Query Syntax :MEASure:TDELta?

The :MEASure:TDELta? query returns the time difference between the Tstop marker (X2 cursor) and the Tstart marker (X1 cursor).

$T_{\text{delta}} = T_{\text{stop}} - T_{\text{start}}$

Tstart is the time at the start marker (X1 cursor) and Tstop is the time at the stop marker (X2 cursor). No measurement is made when the :MEASure:TDELta? query is received by the oscilloscope. The delta time value that is output is the current value. This is the same value as the front-panel cursors delta X value.

NOTE

The :MEASure:TDELta command is an obsolete command provided for compatibility to previous oscilloscopes. Use the :MARKer:XDELta command (see [page 624](#)) instead.

Return Format <value><NL>

<value> ::= time difference between start and stop markers in NR3 format

- See Also**
- ["Introduction to :MARKer Commands"](#) on page 615
 - ["Introduction to :MEASure Commands"](#) on page 658
 - [":MARKer:X1Position"](#) on page 619
 - [":MARKer:X2Position"](#) on page 622
 - [":MARKer:XDELta"](#) on page 624
 - [":MEASure:TSTArt"](#) on page 1644
 - [":MEASure:TSTOp"](#) on page 1645

:MEASure:THResholds

O (see [page 1730](#))

Command Syntax :MEASure:THResholds {T1090 | T2080 | VOLTage}

The :MEASure:THResholds command selects the thresholds used when making time measurements.

NOTE

The :MEASure:THResholds command is obsolete and is provided for backward compatibility to previous oscilloscopes. Use the :MEASure:DEFine THResholds command (see [page 671](#)) instead.

Query Syntax :MEASure:THResholds?

The :MEASure:THResholds? query returns the current thresholds selected when making time measurements.

Return Format {T1090 | T2080 | VOLTage}<NL>

{T1090} uses the 10% and 90% levels of the selected waveform.

{T2080} uses the 20% and 80% levels of the selected waveform.

{VOLTage} uses the upper and lower voltage thresholds set by the UPPer and LOWer commands on the selected waveform.

- See Also**
- ["Introduction to :MEASure Commands"](#) on page 658
 - [":MEASure:LOWer"](#) on page 1638
 - [":MEASure:UPPer"](#) on page 1647

:MEASure:TMAX

O (see [page 1730](#))

Command Syntax :MEASure:TMAX [<source>]

<source> ::= {CHANnel<n> | FUNction | MATH}

<n> ::= 1 to (# analog channels) in NR1 format

The :MEASure:TMAX command installs a screen measurement and starts an X-at-Max-Y measurement on the selected waveform. If the optional source is specified, the current source is modified.

NOTE

The :MEASure:TMAX command is obsolete and is provided for backward compatibility to previous oscilloscopes. Use the :MEASure:XMAX command (see [page 754](#)) instead.

Query Syntax :MEASure:TMAX? [<source>]

The :MEASure:TMAX? query returns the horizontal axis value at which the maximum vertical value occurs on the current source. If the optional source is specified, the current source is modified.

Return Format <value><NL>

<value> ::= time at maximum in NR3 format

- See Also**
- ["Introduction to :MEASure Commands"](#) on page 658
 - [":MEASure:TMIN"](#) on page 1643
 - [":MEASure:XMAX"](#) on page 754
 - [":MEASure:XMIN"](#) on page 755

:MEASure:TMIN

O (see [page 1730](#))

Command Syntax :MEASure:TMIN [<source>]
 <source> ::= {CHANnel<n> | FUNction | MATH}
 <n> ::= 1 to (# analog channels) in NR1 format

The :MEASure:TMIN command installs a screen measurement and starts an X-at-Min-Y measurement on the selected waveform. If the optional source is specified, the current source is modified.

NOTE

The :MEASure:TMIN command is obsolete and is provided for backward compatibility to previous oscilloscopes. Use the :MEASure:XMIN command (see [page 755](#)) instead.

Query Syntax :MEASure:TMIN? [<source>]

The :MEASure:TMIN? query returns the horizontal axis value at which the minimum vertical value occurs on the current source. If the optional source is specified, the current source is modified.

Return Format <value><NL>
 <value> ::= time at minimum in NR3 format

- See Also**
- ["Introduction to :MEASure Commands"](#) on page 658
 - [":MEASure:TMAX"](#) on page 1642
 - [":MEASure:XMAX"](#) on page 754
 - [":MEASure:XMIN"](#) on page 755

:MEASure:TSTArt

O (see [page 1730](#))

Command Syntax :MEASure:TSTArt <value> [suffix]

<value> ::= time at the start marker in seconds

[suffix] ::= {s | ms | us | ns | ps}

The :MEASure:TSTArt command moves the start marker (X1 cursor) to the specified time with respect to the trigger time.

NOTE

The short form of this command, TSTA, does not follow the defined Long Form to Short Form Truncation Rules (see [page 1732](#)). The normal short form "TST" would be the same for both TSTArt and TSTOp, so sending TST for the TSTArt command produces an error.

NOTE

The :MEASure:TSTArt command is an obsolete command provided for compatibility to previous oscilloscopes. Use the :MARKer:X1Position command (see [page 619](#)) instead.

Query Syntax :MEASure:TSTArt?

The :MEASure:TSTArt? query returns the time at the start marker (X1 cursor).

Return Format <value><NL>

<value> ::= time at the start marker in NR3 format

- See Also**
- ["Introduction to :MARKer Commands"](#) on page 615
 - ["Introduction to :MEASure Commands"](#) on page 658
 - [":MARKer:X1Position"](#) on page 619
 - [":MARKer:X2Position"](#) on page 622
 - [":MARKer:XDELta"](#) on page 624
 - [":MEASure:TDELta"](#) on page 1640
 - [":MEASure:TSTOp"](#) on page 1645

:MEASure:TSTOp

O (see [page 1730](#))

Command Syntax :MEASure:TSTOp <value> [suffix]
<value> ::= time at the stop marker in seconds
[suffix] ::= {s | ms | us | ns | ps}

The :MEASure:TSTOp command moves the stop marker (X2 cursor) to the specified time with respect to the trigger time.

NOTE

The short form of this command, TSTO, does not follow the defined Long Form to Short Form Truncation Rules (see [page 1732](#)). The normal short form "TST" would be the same for both TSTArt and TSTOp, so sending TST for the TSTOp command produces an error.

NOTE

The :MEASure:TSTOp command is an obsolete command provided for compatibility to previous oscilloscopes. Use the :MARKer:X2Position command (see [page 622](#)) instead.

Query Syntax :MEASure:TSTOp?

The :MEASure:TSTOp? query returns the time at the stop marker (X2 cursor).

Return Format <value><NL>

<value> ::= time at the stop marker in NR3 format

- See Also**
- ["Introduction to :MARKer Commands"](#) on page 615
 - ["Introduction to :MEASure Commands"](#) on page 658
 - [":MARKer:X1Position"](#) on page 619
 - [":MARKer:X2Position"](#) on page 622
 - [":MARKer:XDELta"](#) on page 624
 - [":MEASure:TDELta"](#) on page 1640
 - [":MEASure:TSTArt"](#) on page 1644

:MEASure:TVOLt

O (see [page 1730](#))

Query Syntax :MEASure:TVOLt? <value>, [<slope>]<occurrence>[,<source>]

<value> ::= the voltage level that the waveform must cross.

<slope> ::= direction of the waveform. A rising slope is indicated by a plus sign (+). A falling edge is indicated by a minus sign (-).

<occurrence> ::= the transition to be reported. If the occurrence number is one, the first crossing is reported. If the number is two, the second crossing is reported, etc.

<source> ::= {<digital channels> | CHANnel<n> | FUNction | MATH}

<digital channels> ::= {DIGital<d>} for the MSO models

<n> ::= 1 to (# analog channels) in NR1 format

<d> ::= 0 to (# digital channels - 1) in NR1 format

When the :MEASure:TVOLt? query is sent, the displayed signal is searched for the specified voltage level and transition. The time interval between the trigger event and this defined occurrence is returned as the response to the query.

The specified voltage can be negative or positive. To specify a negative voltage, use a minus sign (-). The sign of the slope selects a rising (+) or falling (-) edge. If no sign is specified for the slope, it is assumed to be the rising edge.

The magnitude of the occurrence defines the occurrence to be reported. For example, +3 returns the time for the third time the waveform crosses the specified voltage level in the positive direction. Once this voltage crossing is found, the oscilloscope reports the time at that crossing in seconds, with the trigger point (time zero) as the reference.

If the specified crossing cannot be found, the oscilloscope reports +9.9E+37. This value is returned if the waveform does not cross the specified voltage, or if the waveform does not cross the specified voltage for the specified number of times in the direction specified.

If the optional source parameter is specified, the current source is modified.

NOTE

The :MEASure:TVOLt command is obsolete and is provided for backward compatibility to previous oscilloscopes. Use the :MEASure:TVALue command (see [page 742](#)).

Return Format <value><NL>

<value> ::= time in seconds of the specified voltage crossing
in NR3 format

:MEASure:UPPer

O (see [page 1730](#))

Command Syntax :MEASure:UPPer <value>

The :MEASure:UPPer command sets the upper measurement threshold value. This value and the LOWer value represent absolute values when the thresholds are ABSolute and percentage when the thresholds are PERCent as defined by the :MEASure:DEFine THResholds command.

NOTE

The :MEASure:UPPer command is obsolete and is provided for backward compatibility to previous oscilloscopes. Use the :MEASure:DEFine THResholds command (see [page 671](#)) instead.

Query Syntax :MEASure:UPPer?

The :MEASure:UPPer? query returns the current upper threshold level.

Return Format <value><NL>

<value> ::= the user-defined upper threshold in NR3 format

- See Also**
- ["Introduction to :MEASure Commands"](#) on page 658
 - [":MEASure:LOWer"](#) on page 1638
 - [":MEASure:THResholds"](#) on page 1641

:MEASure:VDELta

O (see [page 1730](#))

Query Syntax :MEASure:VDELta?

The :MEASure:VDELta? query returns the voltage difference between vertical marker 1 (Y1 cursor) and vertical marker 2 (Y2 cursor). No measurement is made when the :MEASure:VDELta? query is received by the oscilloscope. The delta value that is returned is the current value. This is the same value as the front-panel cursors delta Y value.

VDELta = value at marker 2 - value at marker 1

NOTE

The :MEASure:VDELta command is an obsolete command provided for compatibility to previous oscilloscopes. Use the :MARKer:YDELta command (see [page 631](#)) instead.

Return Format <value><NL>

<value> ::= delta V value in NR1 format

- See Also**
- ["Introduction to :MARKer Commands"](#) on page 615
 - ["Introduction to :MEASure Commands"](#) on page 658
 - [":MARKer:Y1Position"](#) on page 628
 - [":MARKer:Y2Position"](#) on page 630
 - [":MARKer:YDELta"](#) on page 631
 - [":MEASure:TDELta"](#) on page 1640
 - [":MEASure:TSTArt"](#) on page 1644

:MEASure:VSTArt

O (see [page 1730](#))

Command Syntax :MEASure:VSTArt <vstart_argument>
 <vstart_argument> ::= value for vertical marker 1

The :MEASure:VSTArt command moves the vertical marker (Y1 cursor) to the specified value corresponding to the selected source. The source can be selected by the MARKer:X1Y1source command.

NOTE

The short form of this command, VSTA, does not follow the defined Long Form to Short Form Truncation Rules (see [page 1732](#)). The normal short form, VST, would be the same for both VSTArt and VSTOp, so sending VST for the VSTArt command produces an error.

NOTE

The :MEASure:VSTArt command is an obsolete command provided for compatibility to previous oscilloscopes. Use the :MARKer:Y1Position command (see [page 628](#)) instead.

Query Syntax :MEASure:VSTArt?

The :MEASure:VSTArt? query returns the current value of the Y1 cursor.

Return Format <value><NL>
 <value> ::= voltage at voltage marker 1 in NR3 format

- See Also**
- ["Introduction to :MARKer Commands"](#) on page 615
 - ["Introduction to :MEASure Commands"](#) on page 658
 - [":MARKer:Y1Position"](#) on page 628
 - [":MARKer:Y2Position"](#) on page 630
 - [":MARKer:YDELta"](#) on page 631
 - [":MARKer:X1Y1source"](#) on page 620
 - [":MEASure:SOURce"](#) on page 727
 - [":MEASure:TDELta"](#) on page 1640
 - [":MEASure:TSTArt"](#) on page 1644

:MEASure:VSTOp

O (see [page 1730](#))

Command Syntax :MEASure:VSTOp <vstop_argument>
<vstop_argument> ::= value for Y2 cursor

The :MEASure:VSTOp command moves the vertical marker 2 (Y2 cursor) to the specified value corresponding to the selected source. The source can be selected by the MARKer:X2Y2source command.

NOTE

The short form of this command, VSTO, does not follow the defined Long Form to Short Form Truncation Rules (see [page 1732](#)). The normal short form, VST, would be the same for both VSTArt and VSTOp, so sending VST for the VSTOp command produces an error.

NOTE

The :MEASure:VSTOp command is an obsolete command provided for compatibility to previous oscilloscopes. Use the :MARKer:Y2Position command (see [page 630](#)) instead.

Query Syntax :MEASure:VSTOp?

The :MEASure:VSTOp? query returns the current value of the Y2 cursor.

Return Format <value><NL>
<value> ::= value of the Y2 cursor in NR3 format

- See Also**
- "[Introduction to :MARKer Commands](#)" on page 615
 - "[Introduction to :MEASure Commands](#)" on page 658
 - "[:MARKer:Y1Position](#)" on page 628
 - "[:MARKer:Y2Position](#)" on page 630
 - "[:MARKer:YDELta](#)" on page 631
 - "[:MARKer:X2Y2source](#)" on page 623
 - "[:MEASure:SOURce](#)" on page 727
 - "[:MEASure:TDELta](#)" on page 1640
 - "[:MEASure:TSTArt](#)" on page 1644

:MEASure:VTime

O (see [page 1730](#))

Query Syntax :MEASure:VTime? <vtime_argument>[, <source>]
 <vtime_argument> ::= time from trigger in seconds
 <source> ::= {<digital channels> | CHANnel<n> | FUNction<m> | MATH<m>
 | WMEMory<r>}
 <digital channels> ::= DIGital<d> for the MSO models
 <d> ::= 0 to (# digital channels - 1) in NR1 format
 <n> ::= 1 to (# of analog channels) in NR1 format
 <m> ::= 1 to (# math functions) in NR1 format
 <r> ::= 1 to (# ref waveforms) in NR1 format

The :MEASure:VTime? query returns the vertical value at a specified horizontal value on the source specified (see also :MEASure:SOURce). The specified horizontal value must be on the screen; when it is a time value, it is referenced to the trigger event. If the optional source parameter is specified, the measurement source is modified.

NOTE

When the source is an FFT (Fast Fourier Transform) waveform, the <vtime_argument> is a frequency value instead of a time value.

Return Format <value><NL>
 <value> ::= vertical value at the specified horizontal location
 in NR3 format

- See Also**
- ["Introduction to :MEASure Commands"](#) on page 658
 - [":MEASure:SOURce"](#) on page 727
 - [":MEASure:TEDGe"](#) on page 735
 - [":MEASure:TVALue"](#) on page 742

:MTESt:AMASk:{SAVE | STORE}

O (see [page 1730](#))

Command Syntax :MTESt:AMASk:{SAVE | STORE} "<filename>"

The :MTESt:AMASk:SAVE command saves the automask generated mask to a file. If an automask has not been generated, an error occurs.

The <filename> parameter is an MS-DOS compatible name of the file, a maximum of 254 characters long (including the path name, if used). The filename assumes the present working directory if a path does not precede the file name.

NOTE

The :MTESt:AMASk:{SAVE | STORE} command is obsolete and is provided for backward compatibility to previous oscilloscopes. Use the :SAVE:MASK[:START] command (see [page 956](#)) instead.

See Also · ["Introduction to :MTESt Commands"](#) on page 783

:MTESt:AVERAge

O (see [page 1730](#))

Command Syntax :MTESt:AVERAge <on_off>
<on_off> ::= {{1 | ON} | {0 | OFF}}

The :MTESt:AVERAge command enables or disables averaging. When ON, the oscilloscope acquires multiple data values for each time bucket, and averages them. When OFF, averaging is disabled. To set the number of averages, use the :MTESt:AVERAge:COUNT command described next.

NOTE

The :MTESt:AVERAge command is obsolete and is provided for backward compatibility to previous oscilloscopes. Use the :ACQure:TYPE AVERAge command (see [page 318](#)) instead.

Query Syntax :MTESt:AVERAge?

The :MTESt:AVERAge? query returns the current setting for averaging.

Return Format <on_off><NL>
<on_off> ::= {1 | 0}

- See Also**
- ["Introduction to :MTESt Commands"](#) on page 783
 - [":MTESt:AVERAge:COUNT"](#) on page 1654

:MTESt:AVERAge:COUNT

O (see [page 1730](#))

Command Syntax :MTESt:AVERAge:COUNT <count>

<count> ::= an integer from 2 to 65536 in NR1 format

The :MTESt:AVERAge:COUNT command sets the number of averages for the waveforms. With the AVERAge acquisition type, the :MTESt:AVERAge:COUNT command specifies the number of data values to be averaged for each time bucket before the acquisition is considered complete for that time bucket.

NOTE

The :MTESt:AVERAge:COUNT command is obsolete and is provided for backward compatibility to previous oscilloscopes. Use the :ACQure:COUNT command (see [page 306](#)) instead.

Query Syntax :MTESt:AVERAge:COUNT?

The :MTESt:AVERAge:COUNT? query returns the currently selected count value.

Return Format <count><NL>

<count> ::= an integer from 2 to 65536 in NR1 format

- See Also**
- ["Introduction to :MTESt Commands"](#) on page 783
 - [":MTESt:AVERAge"](#) on page 1653

:MTEST:LOAD

O (see [page 1730](#))

Command Syntax :MTEST:LOAD "<filename>"

The :MTEST:LOAD command loads the specified mask file.

The <filename> parameter is an MS-DOS compatible name of the file, a maximum of 254 characters long (including the path name, if used).

NOTE

The :MTEST:LOAD command is obsolete and is provided for backward compatibility to previous oscilloscopes. Use the :RECall:MASK[:START] command (see [page 932](#)) instead.

- See Also**
- ["Introduction to :MTEST Commands"](#) on page 783
 - [":MTEST:AMASK:{SAVE | STORE}"](#) on page 1652

:MTEST:RUMode

O (see [page 1730](#))

Command Syntax :MTEST:RUMode {FORever | TIME,<seconds> | {WAVEforms,<wfm_count>}}

<seconds> ::= from 1 to 86400 in NR3 format

<wfm_count> ::= number of waveforms in NR1 format
from 1 to 1,000,000,000

The :MTEST:RUMode command determines the termination conditions for the mask test. The choices are FORever, TIME, or WAVEforms.

- FORever – runs the Mask Test until the test is turned off.
- TIME – sets the amount of time in seconds that a mask test will run before it terminates. The <seconds> parameter is a real number from 1 to 86400 seconds.
- WAVEforms – sets the maximum number of waveforms that are required before the mask test terminates. The <wfm_count> parameter indicates the number of waveforms that are to be acquired; it is an integer from 1 to 1,000,000,000.

NOTE

The :MTEST:RUMode command is obsolete and is provided for backward compatibility to previous oscilloscopes. Use the :MTEST:RMODE command (see [page 800](#)) instead.

Query Syntax :MTEST:RUMode?

The :MTEST:RUMode? query returns the currently selected termination condition and value.

Return Format {FOR | TIME,<seconds> | {WAV,<wfm_count>}}<NL>

<seconds> ::= from 1 to 86400 in NR3 format

<wfm_count> ::= number of waveforms in NR1 format
from 1 to 1,000,000,000

- See Also**
- ["Introduction to :MTEST Commands"](#) on page 783
 - [":MTEST:RUMode:SOFailure"](#) on page 1657

:MTESt:RUMode:SOFailure

O (see [page 1730](#))

Command Syntax :MTESt:RUMode:SOFailure <on_off>
 <on_off> ::= {{1 | ON} | {0 | OFF}}

The :MTESt:RUMode:SOFailure command enables or disables the Stop On Failure run until criteria. When a mask test is run and a mask violation is detected, the mask test is stopped and the acquisition system is stopped.

NOTE

The :MTESt:RUMode:SOFailure command is obsolete and is provided for backward compatibility to previous oscilloscopes. Use the :MTESt:RMODE:FACTion:STOP command (see [page 804](#)) instead.

Query Syntax :MTESt:RUMode:SOFailure?

The :MTESt:RUMode:SOFailure? query returns the current state of the Stop on Failure control.

Return Format <on_off><NL>
 <on_off> ::= {1 | 0}

- See Also**
- ["Introduction to :MTESt Commands"](#) on page 783
 - [":MTESt:RUMode"](#) on page 1656

`:MTEST:{START | STOP}`

O (see [page 1730](#))

Command Syntax `:MTEST:{START | STOP}`

The `:MTEST:{START | STOP}` command starts or stops the acquisition system.

NOTE

The `:MTEST:START` and `:MTEST:STOP` commands are obsolete and are provided for backward compatibility to previous oscilloscopes. Use the `:RUN` command (see [page 294](#)) and `:STOP` command (see [page 298](#)) instead.

See Also · ["Introduction to :MTEST Commands"](#) on page 783

:MTESt:TRIGger:SOURce

O (see [page 1730](#))

Command Syntax :MTESt:TRIGger:SOURce <source>

<source> ::= CHANnel<n>

<n> ::= 1 to (# analog channels) in NR1 format

The :MTESt:TRIGger:SOURce command sets the channel to use as the trigger.

NOTE

The :MTESt:TRIGger:SOURce command is obsolete and is provided for backward compatibility to previous oscilloscopes. Use the trigger source commands (see [page 1425](#)) instead.

Query Syntax :MTESt:TRIGger:SOURce?

The :MTESt:TRIGger:SOURce? query returns the currently selected trigger source.

Return Format <source> ::= CHAN<n>

<n> ::= 1 to (# analog channels) in NR1 format

See Also • ["Introduction to :MTESt Commands"](#) on page 783

:PRINT?

O (see [page 1730](#))

Query Syntax :PRINT? [<options>]

<options> ::= [<print option>][,...,<print option>]

<print option> ::= {COLor | GRAYscale | BMP8bit | BMP}

The :PRINT? query pulls image data back over the bus for storage.

NOTE

The :PRINT command is an obsolete command provided for compatibility to previous oscilloscopes. Use the :DISPlay:DATA command (see [page 440](#)) instead.

Print Option	:PRINt command	:PRINt? query	Query Default
COLor	Sets palette=COLor		
GRAYscale	Sets palette=GRAYscale		palette=COLor
PRINter0,1	Causes the USB printer #0,1 to be selected as destination (if connected)	Not used	N/A
BMP8bit	Sets print format to 8-bit BMP	Selects 8-bit BMP formatting for query	N/A
BMP	Sets print format to BMP	Selects BMP formatting for query	N/A
FACTors	Selects outputting of additional settings information for :PRINT	Not used	N/A
NOFactors	Deselects outputting of additional settings information for :PRINT	Not used	N/A

Old Print Option:	Is Now:
HIRes	COLor
LORes	GRAYscale
PARallel	PRINter0
DISK	invalid
PCL	invalid

NOTE

The PRINT? query is not a core command.

- See Also**
- ["Introduction to Root \(:\) Commands"](#) on page 260
 - ["Introduction to :HARDcopy Commands"](#) on page 540
 - [":HARDcopy:FACTors"](#) on page 544
 - [":HARDcopy:GRAYscale"](#) on page 1635
 - [":DISPlay:DATA"](#) on page 440

:SAVE:IMAGe:AREA

Q (see [page 1730](#))

Query Syntax `:SAVE:IMAGe:AREA?`

The `:SAVE:IMAGe:AREA?` query returns the selected image area.

When saving images, this query returns SCR (screen). When saving setups or waveform data, this query returns GRAT (graticule) even though graticule images are not saved.

Return Format `<area><NL>`

`<area> ::= {GRAT | SCR}`

- See Also**
- ["Introduction to :SAVE Commands"](#) on page 946
 - [":SAVE:IMAGe\[:START\]"](#) on page 950
 - [":SAVE:IMAGe:FACTors"](#) on page 951
 - [":SAVE:IMAGe:FORMat"](#) on page 952
 - [":SAVE:IMAGe:INKSaver"](#) on page 953
 - [":SAVE:IMAGe:PALette"](#) on page 954

:SBUS<n>:LIN:SIGNal:DEFinition

O (see [page 1730](#))

Command Syntax :SBUS<n>:LIN:SIGNal:DEFinition <value>

<value> ::= {LIN | RX | TX}

The :SBUS<n>:LIN:SIGNal:DEFinition command sets the LIN signal type. These signals can be set to:

Dominant low signals:

- LIN – the actual LIN single-end bus signal line.
- RX – the Receive signal from the LIN bus transceiver.
- TX – the Transmit signal to the LIN bus transceiver.

NOTE

This command is available, but the only legal value is LIN.

Query Syntax :SBUS<n>:LIN:SIGNal:DEFinition?

The :SBUS<n>:LIN:SIGNal:DEFinition? query returns the current LIN signal type.

Return Format <value><NL>

<value> ::= LIN

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":TRIGger:MODE"](#) on page 1439
 - [":SBUS<n>:LIN:SIGNal:BAUDrate"](#) on page 1102
 - [":SBUS<n>:LIN:SOURce"](#) on page 1103

:SBUS<n>:SPI:SOURce:DATA

O (see [page 1730](#))

Command Syntax :SBUS<n>:SPI:SOURce:DATA <source>

<source> ::= {CHANnel<n> | EXTernal} for the DSO models

<source> ::= {CHANnel<n> | DIGital<d>} for the MSO models

<n> ::= 1 to (# analog channels) in NR1 format

<d> ::= 0 to (# digital channels - 1) in NR1 format

The :SBUS<n>:SPI:SOURce:DATA command sets the source for the SPI serial MOSI data.

This command is the same as the :SBUS<n>:SPI:SOURce:MOSI command.

Query Syntax :SBUS<n>:SPI:SOURce:DATA?

The :SBUS<n>:SPI:SOURce:DATA? query returns the current source for the SPI serial MOSI data.

Return Format <source><NL>

- See Also**
- ["Introduction to :TRIGger Commands"](#) on page 1425
 - [":SBUS<n>:SPI:SOURce:MOSI"](#) on page 1207
 - [":SBUS<n>:SPI:SOURce:MISO"](#) on page 1206
 - [":SBUS<n>:SPI:SOURce:CLOCK"](#) on page 1204
 - [":SBUS<n>:SPI:SOURce:FRAMe"](#) on page 1205
 - [":SBUS<n>:SPI:TRIGger:PATtern:MISO:DATA"](#) on page 1208
 - [":SBUS<n>:SPI:TRIGger:PATtern:MOSI:DATA"](#) on page 1210
 - [":SBUS<n>:SPI:TRIGger:PATtern:MISO:WIDTh"](#) on page 1209
 - [":SBUS<n>:SPI:TRIGger:PATtern:MOSI:WIDTh"](#) on page 1211

:SYSTem:MENU

O (see [page 1730](#))

Command Syntax :SYSTem:MENU <menu>

<menu> ::= {MASK | MEASure | SEGmented | LISTer | POWer}

The :SYSTem:MENU command changes the front panel softkey menu.

:TIMEbase:DElay

O (see [page 1730](#))

Command Syntax :TIMEbase:DElay <delay_value>

<delay_value> ::= time in seconds from trigger to the delay reference point on the screen.

The valid range for delay settings depends on the time/division setting for the main time base.

The :TIMEbase:DElay command sets the main time base delay. This delay is the time between the trigger event and the delay reference point on the screen. The delay reference point is set with the :TIMEbase:REference command (see [page 1417](#)).

NOTE

The :TIMEbase:DElay command is obsolete and is provided for backward compatibility to previous oscilloscopes. Use the :TIMEbase:POSition command (see [page 1414](#)) instead.

Query Syntax :TIMEbase:DElay?

The :TIMEbase:DElay query returns the current delay value.

Return Format <delay_value><NL>

<delay_value> ::= time from trigger to display reference in seconds in NR3 format.

Example Code

```
' TIMEBASE_DELAY - Sets the time base delay. This delay
' is the internal time between the trigger event and the
' onscreen delay reference point.
```

```
' Set time base delay to 0.0.
myScope.WriteString ":TIMEBASE:DELAY 0.0"
```

See complete example programs at: [Chapter 50](#), "Programming Examples," starting on page 1739

:TRIGger:THReshold

O (see [page 1730](#))

Command Syntax :TRIGger:THReshold <channel group>, <threshold type> [, <value>]
 <channel group> ::= {POD1 | POD2}
 <threshold type> ::= {CMOS | ECL | TTL | USERdef}
 <value> ::= voltage for USERdef (floating-point number) [Volt type]
 [Volt type] ::= {V | mV | uV}

The :TRIGger:THReshold command sets the threshold (trigger level) for a pod of 8 digital channels (either digital channels 0 through 7 or 8 through 15). The threshold can be set to a predefined value or to a user-defined value. For the predefined value, the voltage parameter is not required.

NOTE

This command is only available on the MSO models.

NOTE

The :TRIGger:THReshold command is an obsolete command provided for compatibility to previous oscilloscopes. Use the :POD<n>:THReshold command (see [page 819](#)), :DIGital<d>:THReshold command (see [page 427](#)), or :TRIGger[:EDGE]:LEVel command (see [page 1457](#)).

Query Syntax :TRIGger:THReshold? <channel group>

The :TRIGger:THReshold? query returns the voltage and threshold text for analog channel 1 or 2, or POD1 or POD2.

Return Format

<threshold type>[, <value>]<NL>
 <threshold type> ::= {CMOS | ECL | TTL | USER}
 CMOS ::= 2.5V
 TTL ::= 1.5V
 ECL ::= -1.3V
 USERdef ::= range from -8.0V to +8.0V.
 <value> ::= voltage for USERdef (a floating-point number in NR1).

:TRIGger:TV:TVMode

O (see [page 1730](#))

Command Syntax :TRIGger:TV:TVMode <mode>

```
<mode> ::= {FIEld1 | FIEld2 | AFIElds | ALINes | LINE | VERTical
           | LFIeld1 | LFIeld2 | LALTernate | LVERTical}
```

The :TRIGger:TV:MODE command selects the TV trigger mode and field. The LVERTical parameter is only available when :TRIGger:TV:STANdard is GENERIC. The LALTernate parameter is not available when :TRIGger:TV:STANdard is GENERIC (see [page 1501](#)).

Old forms for <mode> are accepted:

<mode>	Old Forms Accepted
FIEld1	F1
FIEld2	F2
AFIEld	ALLFields, ALLFLDS
ALINes	ALLLines
LFIeld1	LINEF1, LINEFIELD1
LFIeld2	LINEF2, LINEFIELD2
LALTernate	LINEAlt
LVERTical	LINEVert

NOTE

The :TRIGger:TV:TVMode command is an obsolete command provided for compatibility to previous oscilloscopes. Use the :TRIGger:TV:MODE command (see [page 1498](#)) instead.

Query Syntax :TRIGger:TV:TVMode?

The :TRIGger:TV:TVMode? query returns the TV trigger mode.

Return Format <value><NL>

```
<value> ::= {FIE1 | FIE2 | AF1 | ALIN | LINE | VERT | LFI1 | LFI2
           | LALT | LVER}
```

46 Error Messages

-440, Query UNTERMINATED after indefinite response

-430, Query DEADLOCKED

-420, Query UNTERMINATED

-410, Query INTERRUPTED

-400, Query error

-340, Calibration failed

-330, Self-test failed

-321, Out of memory

-320, Storage fault

-315, Configuration memory lost

-314, Save/recall memory lost

-313, Calibration memory lost

-311, Memory error

-310, System error

-300, Device specific error

-278, Macro header not found

-277, Macro redefinition not allowed

-276, Macro recursion error

-273, Illegal macro label

-272, Macro execution error

-258, Media protected

-257, File name error

-256, File name not found

-255, Directory full

-254, Media full

-253, Corrupt media

-252, Missing media

-251, Missing mass storage

-250, Mass storage error

-241, Hardware missing

This message can occur when a feature is unavailable or unlicensed.

-240, Hardware error

-231, Data questionable

-230, Data corrupt or stale

-224, Illegal parameter value

-223, Too much data

-222, Data out of range

-221, Settings conflict

-220, Parameter error

-200, Execution error

-183, Invalid inside macro definition

-181, Invalid outside macro definition

-178, Expression data not allowed

-171, Invalid expression

-170, Expression error

-168, Block data not allowed

-161, Invalid block data

-158, String data not allowed

-151, Invalid string data

- 150, String data error
- 148, Character data not allowed
- 138, Suffix not allowed
- 134, Suffix too long
- 131, Invalid suffix
- 128, Numeric data not allowed
- 124, Too many digits
- 123, Exponent too large
- 121, Invalid character in number
- 120, Numeric data error
- 114, Header suffix out of range
- 113, Undefined header
- 112, Program mnemonic too long

-109, Missing parameter

-108, Parameter not allowed

-105, GET not allowed

-104, Data type error

-103, Invalid separator

-102, Syntax error

-101, Invalid character

-100, Command error

+10, Software Fault Occurred

+100, File Exists

+101, End-Of-File Found

+102, Read Error

+103, Write Error

+104, Illegal Operation

+105, Print Canceled

+106, Print Initialization Failed

+107, Invalid Trace File

+108, Compression Error

+109, No Data For Operation

A remote operation wants some information, but there is no information available. For example, you may request a stored TIFF image using the :DISPlay:DATA? query, but there may be no image stored.

+112, Unknown File Type


+113, Directory Not Supported

47 Status Reporting

- Status Reporting Data Structures / 1679
- Status Byte Register (STB) / 1682
- Service Request Enable Register (SRE) / 1684
- Trigger Event Register (TER) / 1685
- Output Queue / 1686
- Message Queue / 1687
- (Standard) Event Status Register (ESR) / 1688
- (Standard) Event Status Enable Register (ESE) / 1689
- Error Queue / 1690
- Operation Status Event Register (:OPERRegister[:EVENT]) / 1691
- Operation Status Condition Register (:OPERRegister:CONDition) / 1693
- Arm Event Register (AER) / 1694
- Overload Event Register (:OVLRegister) / 1695
- Hardware Event Event Register (:HWERegister[:EVENT]) / 1696
- Hardware Event Condition Register (:HWERegister:CONDition) / 1697
- Mask Test Event Event Register (:MTERegister[:EVENT]) / 1698
- Clearing Registers and Queues / 1699
- Status Reporting Decision Chart / 1700
- Example: Checking for Armed Status / 1701

IEEE 488.2 defines data structures, commands, and common bit definitions for status reporting (for example, the Status Byte Register and the Standard Event Status Register). There are also instrument-defined structures and bits (for example, the Operation Status Event Register and the Overload Event Register).

An overview of the oscilloscope's status reporting structure is shown in the following block diagram. The status reporting structure allows monitoring specified events in the oscilloscope. The ability to monitor and report these events allows determination of such things as the status of an operation, the availability and reliability of the measured data, and more.




- To monitor an event, first clear the event; then, enable the event. All of the events are cleared when you initialize the instrument.
- To allow a service request (SRQ) interrupt to an external controller, enable at least one bit in the Status Byte Register (by setting, or unmasking, the bit in the Service Request Enable register).


The Status Byte Register, the Standard Event Status Register group, and the Output Queue are defined as the Standard Status Data Structure Model in IEEE 488.2-1987.

The bits in the status byte act as summary bits for the data structures residing behind them. In the case of queues, the summary bit is set if the queue is not empty. For registers, the summary bit is set if any enabled bit in the event register is set. The events are enabled with the corresponding event enable register. Events captured by an event register remain set until the register is read or cleared. Registers are read with their associated commands. The *CLS command clears all event registers and all queues except the output queue. If you send *CLS immediately after a program message terminator, the output queue is also cleared.

Status Reporting Data Structures

The following figure shows how the status register bits are masked and logically OR'ed to generate service requests (SRQ) on particular events.





The status register bits are described in more detail in the following tables:

- [Table 86](#)
- [Table 84](#)
- [Table 94](#)
- [Table 95](#)
- [Table 97](#)
- [Table 89](#)
- [Table 90](#)
- [Table 92](#)

The status registers picture above shows how the different status reporting data structures work together. To make it possible for any of the Standard Event Status Register bits to generate a summary bit, the bits must be enabled. These bits are enabled by using the *ESE common command to set the corresponding bit in the Standard Event Status Enable Register.

To generate a service request (SRQ) interrupt to an external controller, at least one bit in the Status Byte Register must be enabled. These bits are enabled by using the *SRE common command to set the corresponding bit in the Service Request Enable Register. These enabled bits can then set RQS and MSS (bit 6) in the Status Byte Register.

Status Byte Register (STB)

The Status Byte Register is the summary-level register in the status reporting structure. It contains summary bits that monitor activity in the other status registers and queues. The Status Byte Register is a live register. That is, its summary bits are set and cleared by the presence and absence of a summary bit from other event registers or queues.

If the Status Byte Register is to be used with the Service Request Enable Register to set bit 6 (RQS/MSS) and to generate an SRQ, at least one of the summary bits must be enabled, then set. Also, event bits in all other status registers must be specifically enabled to generate the summary bit that sets the associated summary bit in the Status Byte Register.

The Status Byte Register can be read using either the *STB? Common Command or the programming interface serial poll command. Both commands return the decimal-weighted sum of all set bits in the register. The difference between the two methods is that the serial poll command reads bit 6 as the Request Service (RQS) bit and clears the bit which clears the SRQ interrupt. The *STB? command reads bit 6 as the Master Summary Status (MSS) and does not clear the bit or have any affect on the SRQ interrupt. The value returned is the total bit weights of all of the bits that are set at the present time.

The use of bit 6 can be confusing. This bit was defined to cover all possible computer interfaces, including a computer that could not do a serial poll. The important point to remember is that, if you are using an SRQ interrupt to an external computer, the serial poll command clears bit 6. Clearing bit 6 allows the oscilloscope to generate another SRQ interrupt when another enabled event occurs.

No other bits in the Status Byte Register are cleared by either the *STB? query or the serial poll, except the Message Available bit (bit 4). If there are no other messages in the Output Queue, bit 4 (MAV) can be cleared as a result of reading the response to the *STB? command.

If bit 4 (weight = 16) and bit 5 (weight = 32) are set, the program prints the sum of the two weights. Since these bits were not enabled to generate an SRQ, bit 6 (weight = 64) is not set.

The following example uses the *STB? query to read the contents of the oscilloscope's Status Byte Register.

```
myScope.WriteString "*STB?"
varQueryResult = myScope.ReadNumber
MsgBox "Status Byte Register, Read: 0x" + Hex(varQueryResult)
```

The next program prints 0xD1 and clears bit 6 (RQS) and bit 4 (MAV) of the Status Byte Register. The difference in the output value between this example and the previous one is the value of bit 6 (weight = 64). Bit 6 is set when the first enabled summary bit is set and is cleared when the Status Byte Register is read by the serial poll command.

Example The following example uses the resource session object's ReadSTB method to read the contents of the oscilloscope's Status Byte Register.

```
varQueryResult = myScope.IO.ReadSTB  
MsgBox "Status Byte Register, Serial Poll: 0x" + Hex(varQueryResult)
```

NOTE

Use Serial Polling to Read Status Byte Register. Serial polling is the preferred method to read the contents of the Status Byte Register because it resets bit 6 and allows the next enabled event that occurs to generate a new SRQ interrupt.

See Also · ["*STB \(Read Status Byte\)"](#) on page 252

Service Request Enable Register (SRE)

Setting the Service Request Enable Register bits enable corresponding bits in the Status Byte Register. These enabled bits can then set RQS and MSS (bit 6) in the Status Byte Register.

Bits are set in the Service Request Enable Register using the *SRE command and the bits that are set are read with the *SRE? query.

Example The following example sets bit 4 (MAV) and bit 5 (ESB) in the Service Request Enable Register.

```
myScope.WriteString "*SRE " + CStr(CInt("&H30"))
```

This example uses the decimal parameter value of 48, the string returned by CStr(CInt("&H30")), to enable the oscilloscope to generate an SRQ interrupt under the following conditions:

- When one or more bytes in the Output Queue set bit 4 (MAV).
- When an enabled event in the Standard Event Status Register generates a summary bit that sets bit 5 (ESB).

See Also • **"*SRE (Service Request Enable)"** on page 250

Trigger Event Register (TER)

This register sets the TRG bit in the status byte when a trigger event occurs.

The TER event register stays set until it is cleared by reading the register or using the *CLS command. If your application needs to detect multiple triggers, the TER event register must be cleared after each one.

If you are using the Service Request to interrupt a program or controller operation, you must clear the event register each time the trigger bit is set.

See Also · [":TER \(Trigger Event Register\)"](#) on page 299

Output Queue

The output queue stores the oscilloscope-to-controller responses that are generated by certain instrument commands and queries. The output queue generates the Message Available summary bit when the output queue contains one or more bytes. This summary bit sets the MAV bit (bit 4) in the Status Byte Register.

When using the Keysight VISA COM library, the output queue may be read with the FormattedIO488 object's ReadString, ReadNumber, ReadList, or ReadIEEEBlock methods.

Message Queue

The message queue contains the text of the last message written to the advisory line on the screen of the oscilloscope. The length of the oscilloscope's message queue is 1. Note that messages sent with the :SYSTem:DSP command do not set the MSG status bit in the Status Byte Register.

(Standard) Event Status Register (ESR)

The (Standard) Event Status Register (ESR) monitors the following oscilloscope status events:

- PON - Power On
- URQ - User Request
- CME - Command Error
- EXE - Execution Error
- DDE - Device Dependent Error
- QYE - Query Error
- RQC - Request Control
- OPC - Operation Complete

When one of these events occur, the event sets the corresponding bit in the register. If the bits are enabled in the Standard Event Status Enable Register, the bits set in this register generate a summary bit to set bit 5 (ESB) in the Status Byte Register.

You can read the contents of the Standard Event Status Register and clear the register by sending the *ESR? query. The value returned is the total bit weights of all of the bits that are set at the present time.

Example The following example uses the *ESR query to read the contents of the Standard Event Status Register.

```
myScope.WriteString "*ESR?"
varQueryResult = myScope.ReadNumber
MsgBox "Standard Event Status Register: 0x" + Hex(varQueryResult)
```

If bit 4 (weight = 16) and bit 5 (weight = 32) are set, the program prints the sum of the two weights.

See Also • ["*ESR \(Standard Event Status Register\)"](#) on page 238

(Standard) Event Status Enable Register (ESE)

To allow any of the (Standard) Event Status Register (ESR) bits to generate a summary bit, you must first enable that bit. Enable the bit by using the *ESE (Event Status Enable) common command to set the corresponding bit in the (Standard) Event Status Enable Register (ESE).

Set bits are read with the *ESE? query.

Example Suppose your application requires an interrupt whenever any type of error occurs. The error related bits in the (Standard) Event Status Register are bits 2 through 5 (hexadecimal value 0x3C). Therefore, you can enable any of these bits to generate the summary bit by sending:

```
myScope.WriteString "*ESE " + CStr(CInt("&H3C"))
```

Whenever an error occurs, it sets one of these bits in the (Standard) Event Status Register. Because all the error related bits are enabled, a summary bit is generated to set bit 5 (ESB) in the Status Byte Register.

If bit 5 (ESB) in the Status Byte Register is enabled (via the *SRE command), an SRQ service request interrupt is sent to the controller PC.

NOTE

Disabled (Standard) Event Status Register bits respond but do not generate a summary bit. (Standard) Event Status Register bits that are not enabled still respond to their corresponding conditions (that is, they are set if the corresponding event occurs). However, because they are not enabled, they do not generate a summary bit to the Status Byte Register.

See Also · ["*ESE \(Standard Event Status Enable\)"](#) on page 236

Error Queue

As errors are detected, they are placed in an error queue. This queue is first in, first out. If the error queue overflows, the last error in the queue is replaced with error 350, Queue overflow. Any time the queue overflows, the least recent errors remain in the queue, and the most recent error is discarded. The length of the oscilloscope's error queue is 30 (29 positions for the error messages, and 1 position for the Queue overflow message).

The error queue is read with the `:SYSTEM:ERRor?` query. Executing this query reads and removes the oldest error from the head of the queue, which opens a position at the tail of the queue for a new error. When all the errors have been read from the queue, subsequent error queries return "0, No error".

The error queue is cleared when:

- the instrument is powered up,
- the instrument receives the `*CLS` common command, or
- the last item is read from the error queue.

Operation Status Event Register (:OPERRegister[:EVENT])

The Operation Status Event Register register hosts these bits:

Name	Location	Description
RUN bit	bit 3	Is set whenever the instrument goes from a stop state to a single or running state.
RUI Enab bit	bit 4	<p>The remote user interface has gone from a disabled state to an enabled state.</p> <p>The front-panel graphical user interface can disable most of the remote interface, including the *OPC syntax, for example when:</p> <ul style="list-style-type: none"> ▪ a modal dialog box is open ▪ the user is being prompted ▪ all segments are being analyzed ▪ there is a channel overload ▪ certain compliance applications are running <p>When disabled, commands or queries are accepted, but "settings conflict" errors are returned. The status model is the only part of the remote user interface that is enabled.</p> <p>To determine when the remote interface is re-enabled, you can read this bit or wait for the event that gets generated when its status goes from disabled to enabled.</p>
WAIT TRIG bit	bit 5	Is set by the Trigger Armed Event Register and indicates that the trigger is armed.
MTE bit	bit 9	Comes from the Mask Test Event Registers.
OVL bit	bit 11	Is set whenever a 50Ω input overload occurs.
HWE bit	bit 12	Comes from the Hardware Event Registers.
IOC bit	bit 13	Is set when any IO operation completes. IO operations are any remote data request using any interface (USB, LAN, or GPIB). For example, if you connect to an oscilloscope using the USB interface and then request waveform data, the IOC bit will be set when the IO operation completes.
IOF bit	bit 14	Is set only when something causes the IO operation to fail, like disconnecting a USB device or interrupting the operation from the oscilloscope's front panel.

If any of these bits are set, the OPER bit (bit 7) of the Status Byte Register is set. The Operation Status Event Register is read and cleared with the :OPERRegister[:EVENT]? query. The register output is enabled or disabled using the mask value supplied with the OPEE command.

See Also · [":OPERRegister\[:EVENT\] \(Operation Status Event Register\)"](#) on page 285

Operation Status Condition Register (:OPERRegister:CONDition)

The Operation Status Condition Register register hosts these bits:

Name	Location	Description
RUN bit	bit 3	Is set whenever the instrument is not stopped.
RUI Enab bit	bit 4	Shows whether the remote user interface is enabled. The front-panel graphical user interface can disable most of the remote interface, including the *OPC syntax, for example when: <ul style="list-style-type: none"> ▪ a modal dialog box is open ▪ the user is being prompted ▪ all segments are being analyzed ▪ there is a channel overload ▪ certain compliance applications are running When disabled, commands or queries are accepted, but "settings conflict" errors are returned. The status model is the only part of the remote user interface that is enabled. <p>To determine when the remote interface is re-enabled, you can read this bit or wait for the event that gets generated when its status goes from disabled to enabled.</p>
WAIT TRIG bit	bit 5	Is set by the Trigger Armed Event Register and indicates that the trigger is armed.
MTE bit	bit 9	Comes from the Mask Test Event Registers.
OVL bit	bit 11	Is set whenever a 50Ω input overload occurs.
HWE bit	bit 12	Comes from the Hardware Event Registers.
IOC bit	bit 13	Is set when any IO operation completes. IO operations are any remote data request using any interface (USB, LAN, or GPIB). For example, if you connect to an oscilloscope using the USB interface and then request waveform data, the IOC bit will be set when the IO operation completes.
IOF bit	bit 14	Is set only when something causes the IO operation to fail, like disconnecting a USB device or interrupting the operation from the oscilloscope's front panel.

The :OPERRegister:CONDition? query returns the value of the Operation Status Condition Register.

See Also • [":OPERRegister:CONDition \(Operation Status Condition Register\)"](#) on page 282

Arm Event Register (AER)

This register sets bit 5 (Wait Trig bit) in the Operation Status Register and the OPER bit (bit 7) in the Status Byte Register when the instrument becomes armed.

The ARM event register stays set until it is cleared by reading the register with the AER? query or using the *CLS command. If your application needs to detect multiple triggers, the ARM event register must be cleared after each one.

If you are using the Service Request to interrupt a program or controller operation when the trigger bit is set, then you must clear the event register after each time it has been set.

See Also · [":AER \(Arm Event Register\)"](#) on page 262

Overload Event Register (:OVLRegister)

The Overload Event Register register hosts these bits:

Name	Location	Description
Channel 1 OVL	bit 0	Overload has occurred on Channel 1 input.
Channel 2 OVL	bit 1	Overload has occurred on Channel 2 input.
Channel 3 OVL	bit 2	Overload has occurred on Channel 3 input.
Channel 4 OVL	bit 3	Overload has occurred on Channel 4 input.
External Trigger OVL	bit 4	Overload has occurred on External Trigger input.
Channel 1 Fault	bit 6	Fault has occurred on Channel 1 input.
Channel 2 Fault	bit 7	Fault has occurred on Channel 2 input.
Channel 3 Fault	bit 8	Fault has occurred on Channel 3 input.
Channel 4 Fault	bit 9	Fault has occurred on Channel 4 input.
External Trigger Fault	bit 10	Fault has occurred on External Trigger input.

See Also · [":OVLRegister \(Overload Event Register\)"](#) on page 290

Hardware Event Event Register (:HWERegister[:EVENT])

This register hosts the PLL LOCKED bit (bit 12).

- The PLL LOCKED bit (bit 12) is for internal use and is not intended for general use.

See Also • [":HWERegister\[:EVENT\] \(Hardware Event Event Register\)"](#) on page 275

Hardware Event Condition Register (:HWERegister:CONDition)

This register hosts the PLL LOCKED bit (bit 12).

- The :HWERegister:CONDition? query returns the value of the Hardware Event Condition Register.
- The PLL LOCKED bit (bit 12) is for internal use and is not intended for general use.

See Also • [":HWERegister:CONDition \(Hardware Event Condition Register\)"](#) on page 274

Mask Test Event Event Register (:MTERRegister[:EVENT])

The Mask Test Event Event Register register hosts these bits:

Name	Location	Description
Complete	bit 0	Is set when the mask test is complete.
Fail	bit 1	Is set when there is a mask test failure.
Started	bit 8	Is set when mask testing is started.
Pass	bit 9	Is set when the mask test passes.
Auto Mask	bit 10	Is set when auto mask creation is completed.

The :MTERRegister[:EVENT]? query returns the value of, and clears, the Mask Test Event Event Register.


See Also · [":MTERRegister\[:EVENT\] \(Mask Test Event Event Register\)"](#) on page 278

Clearing Registers and Queues

The *CLS common command clears all event registers and all queues except the output queue. If *CLS is sent immediately after a program message terminator, the output queue is also cleared.

See Also · ["*CLS \(Clear Status\)"](#) on page 235

Status Reporting Decision Chart



Example: Checking for Armed Status

```

#!/python3
# -*- coding: utf-8 -*-

# *****
# This script using the Python language (http://www.python.org/) and
# the PyVISA package (http://pyvisa.readthedocs.org/) shows three
# methods to tell whether a Keysight InfiniiVision oscilloscope is
# armed.
# *****

# Import modules
# -----
import sys
import pyvisa
import time

# Initialization constants
# -----
# Get VISA address from Keysight IO Libraries Connection Expert
VISA_ADDRESS = \
    "TCPIP0::k-mx3104g-10104.cos.is.keysight.com::inst0::INSTR"
GLOBAL_TOUT = 20000 # IO timeout in milliseconds

# =====
# Method 1: Query the Armed Event Register with :AER?
# -----
# This method reads the 1-bit Armed Event Register using the :AER?
# query.
#
# The Armed Event Register bit goes low (0) when it is read using
# :AER? or when a *CLS command is issued.
# =====
def method_1():

    # Stop the oscilloscope.
    KsInfiniiVisionX.query(":STOP;*OPC?")

    # Method 1: Initiate capture using :SINGLE
    # -----
    print("Acquiring signal (Method 1, using :SINGLE)...\n")
    now = time.perf_counter()

    # Clear all status registers before checking for new events.
    KsInfiniiVisionX.write("*CLS")

    # Because the :AER? query will not work with :DIGitize (which is
    # blocking), use the :SINGLE command to start the acquisition.
    KsInfiniiVisionX.write(":SINGLE")

    # Method 1: Determine if armed using :AER? query.
    # -----
    # Define armed criteria.

```

```

ARMED = 1

# Test for armed.
ARMED_STATUS = int(KsInfiniiVisionX.query(":AER?"))

# Wait indefinitely until armed.
while ARMED_STATUS != ARMED:
    # Check the status again after small delay.
    time.sleep(0.1) # 100 ms delay to prevent excessive queries.
    ARMED_STATUS = int(KsInfiniiVisionX.query(":AER?"))

print("Oscilloscope is armed (method 1, using :AER? query)!")
print("It took " + str(time.perf_counter() - now) + \
      " seconds to arm.\n")

# =====
# Method 2: Read the Status Byte
# -----
# This method reads the Status Byte register's OPER bit (bit 7) using
# the "read status byte" function in VISA, which works during blocking
# commands and can therefore be used with the :DIGitize command.
#
# The Status Byte bits do NOT go low (0) when the register is read.
#
# The *CLS command will clear the Status Byte bits.
#
# CAUTION: The oscilloscope's status registers are not updated until
# the :DIGitize completes. So, while the ARM may go true midway
# through the :DIGitize, it does not get reported to the status model
# until the :DIGitize completes, and therefore the STB does not
# reflect it as true until the :DIGitize completes.
# =====
def method_2():

    # Stop the oscilloscope.
    KsInfiniiVisionX.query(":STOP;*OPC?")

    # Method 2: Initiate capture using :DIGitize or :SINGLE
    # -----
    print("Acquiring signal (Method 2, using :DIGitize)...\n")
    now = time.perf_counter()

    # Clear all status registers before checking for new events.
    KsInfiniiVisionX.write("*CLS")

    # Mask out all bits in the Operation Status Event Register except
    # for the ARM bit.
    KsInfiniiVisionX.write(":OPEE 32") # "Unmask" only the arm bit

    # Use the :DIGitize command to start the acquisition.
    KsInfiniiVisionX.write(":DIGitize")

    # Method 2: Determine if armed by reading the Status Byte.
    # -----
    # Define register bit masks for the Status Byte Register
    ARM_BIT = 7

```

```

# 1 leftshift 7 = 128 (bit 7 in the Status Byte Register)
ARM_MASK = 1 << ARM_BIT

# Define armed criteria.
ARMED = 1 << ARM_BIT # 1 leftshift 7 = 128

# Test for armed.
STATUS_BYTE = int(KsInfiniiVisionX.read_stb())
ARMED_STATUS = STATUS_BYTE & ARM_MASK
# Note that you could also do:
# ARMED_STATUS = int(KsInfiniiVisionX.query("*STB?"))
# BUT *STB? does not work with the blocking :DIGitize.

# Wait indefinitely until armed.
while ARMED_STATUS != ARMED:
    # Check the status again after small delay.
    time.sleep(0.1) # 100 ms delay to prevent excessive queries.
    STATUS_BYTE = int(KsInfiniiVisionX.read_stb())
    ARMED_STATUS = STATUS_BYTE & ARM_MASK

print("Oscilloscope is armed (method 2, using Read STB function)!")
print("It took " + str(time.perf_counter() - now) + \
      " seconds to arm.\n")

# =====
# Method 3: Query the Operation Status Event Register with :OPER?
# -----
# This method reads the Operation Status Event Register's Wait Trig
# bit (bit 5) using the :OPER? query.
#
# The Operation Status Event Register bits are cleared (0) when the
# register is read.
#
# Also, the Wait Trig bit does NOT go low (0) when the oscilloscope
# becomes unarmed by starting or stopping another acquisition (before
# the first one finishes) or by changing the time scale.
#
# The Wait Trig bit is cleared by a *CLS command, by reading the
# Operation Status Event Register with the :OPER? query, or by reading
# the Armed Event Register with the :AER? query.
# =====
def method_3():

    # Stop the oscilloscope.
    KsInfiniiVisionX.query(":STOP;*OPC?")

    # Method 3: Initiate capture using :SINGLE
    # -----
    print("Acquiring signal (Method 3, using :SINGLE)...\n")
    now = time.perf_counter()

    # Clear all status registers before checking for new events.
    KsInfiniiVisionX.write("*CLS")

    # Because the :OPER? query will not work with :DIGitize (which is
    # blocking), use the :SINGLE command to start the acquisition.

```

```

KsInfiniiVisionX.write(":SINGLE")

# Method 3: Determine if armed using :OPER? query.
# -----
# Define bit masks for the Operation Status Event Register
ARM_BIT = 5
# 1 leftshift 5 = 32 (bit 5 in the Operation Status Event
# Register)
ARM_MASK = 1 << ARM_BIT

# Define armed criteria.
ARMED = 1 << ARM_BIT # 1 leftshift 5 = 32

# Test for armed.
STATUS_REGISTER = int(KsInfiniiVisionX.query(":OPER?"))
ARMED_STATUS = STATUS_REGISTER & ARM_MASK

# Wait indefinitely until armed.
while ARMED_STATUS != ARMED:
    # Check the status again after small delay.
    time.sleep(0.1) # 100 ms delay to prevent excessive queries.
    STATUS_REGISTER = int(KsInfiniiVisionX.query(":OPER?"))
    ARMED_STATUS = STATUS_REGISTER & ARM_MASK

print("Oscilloscope is armed (method 3, using :OPER? query)!")
print("It took " + str(time.perf_counter() - now) + \
      " seconds to arm.\n")

# =====
# Main
# =====

# Connect and initialize oscilloscope
# -----
# Define VISA Resource Manager & Install directory
rm = pyvisa.ResourceManager('C:\\Windows\\System32\\visa64.dll')

# Define and open the oscilloscope using the VISA address
KsInfiniiVisionX = rm.open_resource(VISA_ADDRESS)

# Set the Global Timeout
KsInfiniiVisionX.timeout = GLOBAL_TOUT

# Clear the instrument bus
KsInfiniiVisionX.clear()

# Reset the oscilloscope.
KsInfiniiVisionX.write("*RST")

# Autoscale to set up vertical scale and trigger level on Probe Comp.
KsInfiniiVisionX.write(":CHANnel1:DISPlay OFF")
KsInfiniiVisionX.write(":CHANnel2:DISPlay ON")
KsInfiniiVisionX.write(":AUToscale:CHANnels DISPlayed")
KsInfiniiVisionX.write(":AUToscale")

# Ensure a "long" time to arm (5 seconds) and not trigger immediately.

```



```
# -----  
# 10 second total capture, with trigger point in the middle = 5s to arm  
KsInfiniiVisionX.write(":TIMEbase:RANGe 10")  
# Prevent Auto trigger.  
KsInfiniiVisionX.write(":TRIGger:SWEep NORMal")  
  
# Use the three methods to check whether the oscilloscope is armed.  
# -----  
method_1()  
method_2()  
method_3()  
  
# End of Script  
# -----  
KsInfiniiVisionX.clear() # Clear communications interface  
KsInfiniiVisionX.close() # Close communications interface  
print("All done.")
```

Example: Waiting for IO Operation Complete

NOTE

The IOC (IO Operation Complete) and IOF (IO Operation Failed) bits in the Operation Status Event Register identify when :WMemory<r>:SAVE and other :SAVE and :RECall commands are completely done. To determine when a IO operation is complete, you should use these bits instead of the OPC (Operation Complete) bit in the Standard Event Status Register or the *OPC? query.

```
#!/python3
# -*- coding: utf-8 -*-

# *****
# This script using the Python language (http://www.python.org/) and
# the PyVISA package (http://pyvisa.readthedocs.org/) shows how to
# wait for IO operation completion in a Keysight InfiniiVision
# oscilloscope.
# *****

# Import modules
# -----
import sys
import pyvisa
import time

# Initialization constants
# -----
# Get VISA address from Keysight IO Libraries Connection Expert
VISA_ADDRESS = \
    "TCPIP0::k-mx3104g-10104.cos.is.keysight.com::inst0::INSTR"
GLOBAL_TOUT = 20000 # IO timeout in milliseconds

# =====
# Check for IO Operation Complete using :OPER? query.
# -----
# This method reads the Operation Status Register's IOC bit
# (bit 13) using the :OPER? query.
#
# The Operation Status Event Register bits are cleared (0) when the
# register is read.
#
# All status bits are cleared by a *CLS command.
# =====
def wait_io_operation():

    # -----
    now = time.perf_counter()
    # Define bit masks for the Operation Status Event Register
    IOC_BIT = 13
    # 1 leftshift 13 = 8192 (bit 13 in the Operation Status Event
    # Register)
    IOC_MASK = 1 << IOC_BIT
```

```

# Define IO complete criteria.
IO_COMPLETE = 1 << IOC_BIT # 1 leftshift 13 = 8192

# Test for armed.
STATUS_REGISTER = int(KsInfiniiVisionX.query(":OPER?"))
IO_COMPLETE_STATUS = STATUS_REGISTER & IOC_MASK

# Wait indefinitely until armed.
while IO_COMPLETE_STATUS != IO_COMPLETE:
    # Check the status again after small delay.
    time.sleep(0.1) # 100 ms delay to prevent excessive queries.
    STATUS_REGISTER = int(KsInfiniiVisionX.query(":OPER?"))
    IO_COMPLETE_STATUS = STATUS_REGISTER & IOC_MASK

time_in_seconds = str(time.perf_counter() - now)
print("IO Operation Complete (from :OPER? query).")
print("It took %s seconds for IO operation to complete.\n" % \
      time_in_seconds)

# =====
# Main
# =====

# Connect and initialize oscilloscope
# -----
# Define VISA Resource Manager & Install directory
rm = pyvisa.ResourceManager('C:\\Windows\\System32\\visa64.dll')

# Define and open the oscilloscope using the VISA address
KsInfiniiVisionX = rm.open_resource(VISA_ADDRESS)

# Set the Global Timeout
KsInfiniiVisionX.timeout = GLOBAL_TOUT

# Clear the instrument bus
KsInfiniiVisionX.clear()

# Reset the oscilloscope.
# KsInfiniiVisionX.write("*RST")
# Or comment out to use the current oscilloscope setup.

# Autoscale to set up vertical scale and trigger level on channels 1 and
# 2.
KsInfiniiVisionX.write(":CHANnel1:DISPlay ON")
KsInfiniiVisionX.write(":CHANnel2:DISPlay ON")
KsInfiniiVisionX.write(":AUToscale:CHANnels DISPlayed")
KsInfiniiVisionX.write(":AUToscale")

# Between :WMEemory<r>:SAVE commands, wait for IO complete.
# -----
# Clear all status registers before checking for new events.
KsInfiniiVisionX.write("*CLS")

KsInfiniiVisionX.write(":WMEemory1:SAVE CHANnel1")
wait_io_operation()
KsInfiniiVisionX.write(":WMEemory2:SAVE CHANnel2")

```

```
wait_io_operation()

# End of Script
# -----
KsInfiniiVisionX.clear() # Clear communications interface
KsInfiniiVisionX.close() # Close communications interface
print("All done.")
```

48 Synchronizing Acquisitions

Synchronization in the Programming Flow / 1710

Blocking Synchronization / 1711

Polling Synchronization With Timeout / 1712

Synchronizing with a Single-Shot Device Under Test (DUT) / 1714

Synchronization with an Averaging Acquisition / 1716

Example: Blocking and Polling Synchronization / 1718

When remotely controlling an oscilloscope with programming commands, it is often necessary to know when the oscilloscope has finished the previous operation and is ready for the next command. The most common example is when an acquisition is started using the :DIGitize, :RUN, or :SINGle commands. Before a measurement result can be queried, the acquisition must complete. Too often fixed delays are used to accomplish this wait, but fixed delays often use excessive time or the time may not be long enough. A better solution is to use synchronous commands and status to know when the oscilloscope is ready for the next request.

Synchronization in the Programming Flow

Most remote programming follows these three general steps:

- 1 Set up the oscilloscope and device under test (see [page 1710](#)).
- 2 Acquire a waveform (see [page 1710](#)).
- 3 Retrieve results (see [page 1710](#)).

Set Up the Oscilloscope

Before making changes to the oscilloscope setup, it is best to make sure it is stopped using the :STOP command followed by the *OPC? query.

NOTE

It is not necessary to use *OPC?, hard coded waits, or status checking when setting up the oscilloscope. After the oscilloscope is configured, it is ready for an acquisition.

Acquire a Waveform

When acquiring a waveform there are two possible methods used to wait for the acquisition to complete. These methods are blocking and polling. The table below details when each method should be chosen and why.

	Blocking Wait	Polling Wait
Use When	You know the oscilloscope <i>will</i> trigger based on the oscilloscope setup and device under test.	You know the oscilloscope <i>may or may not</i> trigger on the oscilloscope setup and device under test.
Advantages	No need for polling. Fastest method.	Remote interface will not timeout No need for device clear if no trigger.
Disadvantages	Remote interface may timeout. Device clear only way to get control of oscilloscope if there is no trigger.	Slower method. Requires polling loop. Requires known maximum wait time.
Implementation Details	See " Blocking Synchronization " on page 1711.	See " Polling Synchronization With Timeout " on page 1712.

Retrieve Results

Once the acquisition is complete, it is safe to retrieve measurements and statistics.

Blocking Synchronization

Use the :DIGitize command to start the acquisition. This blocks subsequent queries until the acquisition and processing is complete. For example:

```
'
' Synchronizing acquisition using blocking.
' =====

Option Explicit

Public myMgr As VisaComLib.ResourceManager
Public myScope As VisaComLib.FormattedIO488
Public varQueryResult As Variant
Public strQueryResult As String

Sub Main()

    On Error GoTo VisaComError

    ' Create the VISA COM I/O resource.
    Set myMgr = New VisaComLib.ResourceManager
    Set myScope = New VisaComLib.FormattedIO488
    Set myScope.IO = myMgr.Open("TCPIP0::130.29.69.12::inst0::INSTR")
    myScope.IO.Clear ' Clear the interface.

    ' Set up.
    ' -----
    myScope.WriteString ":TRIGger:MODE EDGE"
    myScope.WriteString ":TRIGger:EDGE:LEVel 2"
    myScope.WriteString ":TIMEbase:SCALE 5e-8"

    ' Acquire.
    ' -----
    myScope.WriteString ":DIGitize"

    ' Get results.
    ' -----
    myScope.WriteString ":MEASure:RISetime"
    myScope.WriteString ":MEASure:RISetime?"
    varQueryResult = myScope.ReadNumber ' Read risetime.
    Debug.Print "Risetime: " + _
        FormatNumber(varQueryResult * 1000000000, 1) + " ns"

    Exit Sub

VisaComError:
    MsgBox "VISA COM Error:" + vbCrLf + Err.Description

End Sub
```

Polling Synchronization With Timeout

This example requires a timeout value so the operation can abort if an acquisition does not occur within the timeout period:

```
'
' Synchronizing acquisition using polling.
' =====

Option Explicit

Public myMgr As VisaComLib.ResourceManager
Public myScope As VisaComLib.FormattedIO488
Public varQueryResult As Variant
Public strQueryResult As String

Private Declare Sub Sleep Lib "kernel32" (ByVal dwMilliseconds As Long)

Sub Main()

    On Error GoTo VisaComError

    ' Create the VISA COM I/O resource.
    Set myMgr = New VisaComLib.ResourceManager
    Set myScope = New VisaComLib.FormattedIO488
    Set myScope.IO = myMgr.Open("TCPIP0::130.29.69.12::inst0::INSTR")
    myScope.IO.Clear    ' Clear the interface.

    ' Set up.
    ' -----
    ' Set up the trigger and horizontal scale.
    myScope.WriteString ":TRIGger:MODE EDGE"
    myScope.WriteString ":TRIGger:EDGE:LEVel 2"
    myScope.WriteString ":TIMEbase:SCALE 5e-8"

    ' Stop acquisitions and wait for the operation to complete.
    myScope.WriteString ":STOP"
    myScope.WriteString "*OPC?"
    strQueryResult = myScope.ReadString

    ' Acquire.
    ' -----
    ' Start a single acquisition.
    myScope.WriteString ":SINGle"

    ' Oscilloscope is armed and ready, enable DUT here.
    Debug.Print "Oscilloscope is armed and ready, enable DUT."

    ' Look for RUN bit = stopped (acquisition complete).
    Dim lngTimeout As Long    ' Max millisecs to wait for single-shot.
    Dim lngElapsed As Long
    lngTimeout = 10000    ' 10 seconds.
    lngElapsed = 0

    Do While lngElapsed <= lngTimeout
```



```

myScope.WriteString ":OPERRegister:CONDition?"
varQueryResult = myScope.ReadNumber
' Mask RUN bit (bit 3, &H8).
If (varQueryResult And &H8) = 0 Then
    Exit Do
Else
    Sleep 100 ' Small wait to prevent excessive queries.
    lngElapsed = lngElapsed + 100
End If
Loop

' Get results.
' -----
If lngElapsed < lngTimeout Then
    myScope.WriteString ":MEASure:RISetime"
    myScope.WriteString ":MEASure:RISetime?"
    varQueryResult = myScope.ReadNumber ' Read risetime.
    Debug.Print "Risetime: " + _
        FormatNumber(varQueryResult * 1000000000, 1) + " ns"
Else
    Debug.Print "Timeout waiting for single-shot trigger."
End If

Exit Sub

VisaComError:
    MsgBox "VISA COM Error:" + vbCrLf + Err.Description

End Sub

```

Synchronizing with a Single-Shot Device Under Test (DUT)

The examples in **"Blocking Synchronization"** on page 1711 and **"Polling Synchronization With Timeout"** on page 1712 assume the DUT is continually running and therefore the oscilloscope will have more than one opportunity to trigger. With a single shot DUT, there is only one opportunity for the oscilloscope to trigger, so it is necessary for the oscilloscope to be armed and ready before the DUT is enabled.

NOTE

The blocking :DIGitize command cannot be used for a single shot DUT because once the :DIGitize command is issued, the oscilloscope is blocked from any further commands until the acquisition is complete.

This example is the same **"Polling Synchronization With Timeout"** on page 1712 with the addition of checking for the armed event status.

```
'
' Synchronizing single-shot acquisition using polling.
' =====

Option Explicit

Public myMgr As VisaComLib.ResourceManager
Public myScope As VisaComLib.FormattedIO488
Public varQueryResult As Variant
Public strQueryResult As String

Private Declare Sub Sleep Lib "kernel32" (ByVal dwMilliseconds As Long)

Sub Main()

    On Error GoTo VisaComError

    ' Create the VISA COM I/O resource.
    Set myMgr = New VisaComLib.ResourceManager
    Set myScope = New VisaComLib.FormattedIO488
    Set myScope.IO = myMgr.Open("TCPIP0::130.29.69.12::inst0::INSTR")
    myScope.IO.Clear ' Clear the interface.

    ' Set up.
    ' -----
    ' Set up the trigger and horizontal scale.
    myScope.WriteString ":TRIGger:MODE EDGE"
    myScope.WriteString ":TRIGger:EDGE:LEVel 2"
    myScope.WriteString ":TIMEbase:SCALE 5e-8"

    ' Stop acquisitions and wait for the operation to complete.
    myScope.WriteString ":STOP"
    myScope.WriteString "*OPC?"
    strQueryResult = myScope.ReadString

    ' Acquire.
```

```

' -----
' Start a single acquisition.
myScope.WriteString ":SINGLE"

' Wait until the trigger system is armed.
Do
    Sleep 100 ' Small wait to prevent excessive queries.
    myScope.WriteString ":AER?"
    varQueryResult = myScope.ReadNumber
Loop Until varQueryResult = 1

' Oscilloscope is armed and ready, enable DUT here.
Debug.Print "Oscilloscope is armed and ready, enable DUT."

' Now, look for RUN bit = stopped (acquisition complete).
Dim lngTimeout As Long ' Max millisecs to wait for single-shot.
Dim lngElapsed As Long
lngTimeout = 10000 ' 10 seconds.
lngElapsed = 0

Do While lngElapsed <= lngTimeout
    myScope.WriteString ":OPERRegister:CONDITION?"
    varQueryResult = myScope.ReadNumber
    ' Mask RUN bit (bit 3, &H8).
    If (varQueryResult And &H8) = 0 Then
        Exit Do
    Else
        Sleep 100 ' Small wait to prevent excessive queries.
        lngElapsed = lngElapsed + 100
    End If
Loop

' Get results.
' -----
If lngElapsed < lngTimeout Then
    myScope.WriteString ":MEASure:RISetime"
    myScope.WriteString ":MEASure:RISetime?"
    varQueryResult = myScope.ReadNumber ' Read risetime.
    Debug.Print "Risetime: " + _
        FormatNumber(varQueryResult * 1000000000, 1) + " ns"
Else
    Debug.Print "Timeout waiting for single-shot trigger."
End If

Exit Sub

VisaComError:
    MsgBox "VISA COM Error:" + vbCrLf + Err.Description

End Sub

```

Synchronization with an Averaging Acquisition

When averaging, it is necessary to know when the average count has been reached. The :SINGle command does not average.

If it is known that a trigger will occur, a :DIGitize will acquire the complete number of averages, but if the number of averages is large, a timeout on the connection can occur.

The example below polls during the :DIGitize to prevent a timeout on the connection.

```
'
' Synchronizing in averaging acquisition mode.
' =====

Option Explicit

Public myMgr As VisaComLib.ResourceManager
Public myScope As VisaComLib.FormattedIO488
Public varQueryResult As Variant
Public strQueryResult As String

Private Declare Sub Sleep Lib "kernel32" (ByVal dwMilliseconds As Long)

Sub Main()

    On Error GoTo VisaComError

    ' Create the VISA COM I/O resource.
    Set myMgr = New VisaComLib.ResourceManager
    Set myScope = New VisaComLib.FormattedIO488
    Set myScope.IO = myMgr.Open("TCPIP0::130.29.69.12::inst0::INSTR")
    myScope.IO.Clear ' Clear the interface.
    myScope.IO.Timeout = 5000

    ' Set up.
    ' -----
    ' Set up the trigger and horizontal scale.
    myScope.WriteString ":TRIGger:SWEEp NORMal"
    myScope.WriteString ":TRIGger:MODE EDGE"
    myScope.WriteString ":TRIGger:EDGE:LEVel 2"
    myScope.WriteString ":TIMEbase:SCALE 5e-8"

    ' Stop acquisitions and wait for the operation to complete.
    myScope.WriteString ":STOP"
    myScope.WriteString "*OPC?"
    strQueryResult = myScope.ReadString

    ' Set up average acquisition mode.
    Dim lngAverages As Long
    lngAverages = 256
    myScope.WriteString ":ACQuire:COUNT " + CStr(lngAverages)
    myScope.WriteString ":ACQuire:TYPE AVERAge"
```

```

' Save *ESE (Standard Event Status Enable register) mask
' (so it can be restored later).
Dim varInitialESE As Variant
myScope.WriteString "*ESE?"
varInitialESE = myScope.ReadNumber

' Set *ESE mask to allow only OPC (Operation Complete) bit.
myScope.WriteString "*ESE " + CStr(CInt("&H01"))

' Acquire using :DIGitize. Set up OPC bit to be set when the
' operation is complete.
' -----
myScope.WriteString ":DIGitize"
myScope.WriteString "*OPC"

' Assume the oscilloscope will trigger, if not put a check here.

' Wait until OPC becomes true (bit 5 of Status Byte register, STB,
' from Standard Event Status register, ESR, is set). STB can be
' read during :DIGitize without generating a timeout.
Do
  Sleep 4000 ' Poll more often than the timeout setting.
  varQueryResult = myScope.IO.ReadSTB
Loop While (varQueryResult And &H20) = 0

' Clear ESR and restore previously saved *ESE mask.
myScope.WriteString "*ESR?" ' Clear ESR by reading it.
varQueryResult = myScope.ReadNumber
myScope.WriteString "*ESE " + CStr(varInitialESE)

' Get results.
' -----
myScope.WriteString ":WAVEform:COUNT?"
varQueryResult = myScope.ReadNumber
Debug.Print "Averaged waveforms: " + CStr(varQueryResult)

myScope.WriteString ":MEASure:RISetime"
myScope.WriteString ":MEASure:RISetime?"
varQueryResult = myScope.ReadNumber ' Read risetime.
Debug.Print "Risetime: " + _
  FormatNumber(varQueryResult * 1000000000, 1) + " ns"

Exit Sub

VisaComError:
  MsgBox "VISA COM Error:" + vbCrLf + Err.Description

End Sub

```

Example: Blocking and Polling Synchronization

```

#!/python3
# -*- coding: utf-8 -*-

# *****
# This script using the Python language (http://www.python.org/) and
# the PyVISA package (http://pyvisa.readthedocs.org/) shows the two
# best synchronization methods for InfiniiVision oscilloscopes.
# Benefits and drawbacks of each method are described. No error
# handling is provided except in the actual synchronization methods.
# *****

# Import modules
# -----
import sys
import pyvisa
import time

# Initialization constants
# -----
# Get VISA address from Keysight IO Libraries Connection Expert
VISA_ADDRESS = \
    "TCPIP0::k-mx3104g-10104.cos.is.keysight.com::inst0::INSTR"
GLOBAL_TOUT = 10000 # IO timeout in milliseconds

TIME_TO_TRIGGER = 10 # Time in seconds
# -----
# This is the time until the FIRST trigger event.
#
# While the script calculates a general timeout for the given setup,
# it cannot know when a trigger event will occur. Thus, you must
# still set this value.
#
# This time is in addition to the calculated minimum timeout... so, if
# an oscilloscope might take say, 1 us to arm and acquire data, the
# signal might take 100 seconds before it occurs... this accounts for
# that.
#
# The SCOPE_ACQUISITION_TIME_OUT calculation pads this by 1.1.
# -----

TIME_BETWEEN_TRIGGERS = 0.025 # Time in seconds - for Average,
# Segmented, and Equivalent Time modes, else set to 0
# -----
# In Average, Segmented, and Equivalent Time modes, the oscilloscope
# makes repeated acquisitions. This is similar to the above
# TIME_TO_TRIGGER, but it is the time BETWEEN triggers. For example,
# it might take 10 seconds for the first trigger event, and then they
# might start occurring regularly at say, 1 ms intervals. In that
# scenario, 15 seconds (a conservative number for 10s) would be good
# for TIME_TO_TRIGGER, and 2 ms (again conservative) would be good for
# TIME_BETWEEN_TRIGGERS.
#
# The default in this sample script is 0.025 seconds. This is to make

```

```

# the sample work for the LINE trigger used in this script when the
# oscilloscope is in Average, Segmented, and Equivalent Time modes to
# force a trigger off of the AC input line (:TRIGger:EDGE:SOURce LINE)
# which runs at 50 or 60 Hz in most of the world (1/50 Hz -> 20 ms, so
# use 25 ms to be conservative).
#
# The SCOPE_ACQUISITION_TIME_OUT calculation pads this by 1.1.
# -----

# =====
# Define a simple and fast function utilizing the blocking :DIGitize
# command in conjunction with *OPC?.
# -----
#
# Benefits of this method:
#
# - Fastest, compact
# - Only way for Average Acquisition type:
#   - The :SINGLE command does not do a complete average.
#   - Counting triggers with :RUN is much too slow.
# - Allows for easy synchronization with math functions
# - Don't have to deal with the status registers, which can be
#   confusing.
# - Potentially faster than polling_method(), for better throughput
# - Because it's faster, one can retrieve more accurate acquisition
#   times than with a polling method.
# - Works best for segmented memory if any post processing is done
#   on the oscilloscope, for example, measurements, lister, math,
#   as this does not come back until the processing is all done
#   - In this scenario, :DIGitize does not reduce the sample
#     rate or memory depth.
#
# Drawbacks of this method:
#
# - Usually does not fill acquisition memory to the maximum
#   available, usually only on-screen data.
#
# - May not be at the highest sample rate (compared with the
#   polling_method).
#
# - Requires a well-chosen, hard-set timeout that will cover the
#   time to arm, trigger, and finish acquisition.
#
# - Requires Exception handling and a device_clear() for a
#   possible timeout (no trigger event).
#
# - Socket connection cannot do device_clear()
#
# - Because :DIGitize is a "specialized form of the :RUN" command,
#   on these oscilloscopes, that results in:
#
#   - the sample rate MAY be reduced from using :SINGLE -
#     usually at longer time scales - typically only acquires
#     what is on screen, though at the fastest time scales,
#     more than on screen data may be acquired. Thus, for max
#     memory and max sample rate, use the polling_method(),

```

```

#           which uses :SINGLE.
#
# How it works:
#
# - The :DIGitize command is a blocking command, and thus, all
#   other SCPI commands are blocked until :DIGitize is completely
#   done. This includes any subsequent processing that is already
#   set up, such as math and measurements.
#
#   KEY POINT: However, :DIGitize does not prevent additional
#   commands from being sent to the queue or cause the remote
#   program to wait. For example, if your program does something
#   like:
#
#       KsInfiniiVisionX.write(":DIGitize")
#       print("Signal acquired.\n")
#
#   The "Signal acquired" message will be written immediately
#   after the :DIGitize is sent, not after the acquisition and
#   processing is complete.
#
#   To pause the program until the :DIGitize is complete, you must
#   wait for a query result after the :DIGitize. For example, in
#   this case:
#
#       query_result = KsInfiniiVisionX.query(":DIGitize;*OPC?")
#       print("Signal acquired.\n")
#
#   The "Signal acquired" message will be written after the
#   acquisition and processing is complete. The *OPC? query is
#   appended to :DIGitize with a semi-colon (;), which
#   essentially ties it to the same thread in the parser. It is
#   immediately dealt with once :DIGitize finishes and gives a "1"
#   back to the program (whether the program uses it or not),
#   allowing the program to move on.
#
# Other Notes:
#
# - If you DO NOT know when a trigger will occur, you should set a
#   very long timeout.
#
# - The timeout should be adjusted before and after the :DIGitize
#   operation, though this is not absolutely required.
#
# - A :DIGitize can be aborted with a device clear, which also
#   stops the oscilloscope:
#   KsInfiniiVisionX.clear()
#
# - :DIGitize disables the anti-aliasing feature (sample rate
#   dither) on all InfiniiVision and InfiniiVision X-Series
#   oscilloscopes.
#
# - :DIGitize temporarily blocks the front panel, and all front
#   panel presses are queued until :DIGitize is done. So if you
#   change the vertical scale, it will not happen until the
#   acquisition is done.
#
#

```



```

# The exception is that the Run/Stop button on the front panel
# is NOT blocked (unless the front panel is otherwise locked by
# ":SYSTem:LOCK ON").
# =====
def blocking_method():

    KsInfiniiVisionX.timeout = SCOPE_ACQUISITION_TIME_OUT
    # Time in milliseconds (PyVISA uses ms) to wait for the
    # oscilloscope to arm, trigger, finish acquisition, and finish
    # any processing.
    #
    # Note that this is a property of the device interface,
    # KsInfiniiVisionX.
    #
# If doing repeated acquisitions, this should be done BEFORE the
# loop, and changed again after the loop if the goal is to
# achieve the best throughput.

print("Acquiring signal(s)...")
# Set up a try/except block to catch a possible timeout and exit.
try:
    KsInfiniiVisionX.query(":DIGitize;*OPC?")
    # Acquire the signal(s) with :DIGitize (blocking) and wait
    # until *OPC? comes back with a one.
    print("Signal acquired.")

    # Reset timeout back to what it was, GLOBAL_TOUT.
    KsInfiniiVisionX.timeout = GLOBAL_TOUT

# Catch a possible timeout and exit.
except Exception:
    print("The acquisition timed out, most likely due to no " \
          "trigger or improper setup causing no trigger. " \
          "Properly closing the oscilloscope connection and " \
          "exiting script.\n")
    KsInfiniiVisionX.clear() # Clear communications interface;
                            # A device clear also aborts digitize.
    KsInfiniiVisionX.close() # Close communications interface
    sys.exit("Exiting script.")

# =====
# Define a function using the non-blocking :SINGLE command and polling
# on the Operation Status Condition Register
# -----
#
# Benefits of this method:
#
# - Don't have to worry about interface timeouts.
# - Easy to expand to know when the oscilloscope is armed.
# - Don't have to worry about interface timeouts
# - Easy to expand to know when scope is armed, and triggered
# - MAY result in a higher sample rate than the blocking method
# - Always fills max available memory
# - Can use with a socket connection if desired
#
#

```

```

# Drawbacks of this method:
#
# - Slow, as you don't want to poll the oscilloscope too fast.
#
# - DOES NOT work for Equivalent time mode. MUST use the blocking
#   method.
#
# - Slow
#
# - Does NOT work for Average Acquisition type
#   - :SINGLE does not do a complete average
#     - It does a single acquisition as if it were in NORMAL
#       acq. type
#     - Counting triggers in :RUN is much too slow
#
# - Works for Segmented Memory, BUT if any post processing is done
#   on the oscilloscope, for example measurements, lister, math, as
#   this reports that the acquisition is done, which is correct,
#   BUT the processing is NOT done, and it will take an indefinite
#   amount of time to wait for that, though there is no way to tell
#   if it is done. Use the blocking_method for Segmented Memory.
#
# - Can't be used effectively for synchronizing math functions
#
#   It can be done by applying an additional hard coded wait after
#   the acquisition is done. At least 200 ms is suggested, more
#   may be required.
#
#   However, as long as the timeout is not excessively short, the
#   math happens fast enough that once :OPERRegister:CONDition?
#   comes back as done that one can just wait for it when it is
#   time to pull the math waveform. The exception would be for eye
#   or jitter mode on a 6000 X-Series oscilloscope, where the
#   processing time can be long.
#
# - Still need some maximum timeout (here MAX_TIME_TO_WAIT),
#   ideally, or the script will sit in the while loop forever if
#   there is no trigger event
#
#   Max timeout (here MAX_TIME_TO_WAIT) must also account for any
#   processing done (see comments on math above)
#
#   Max timeout (here MAX_TIME_TO_WAIT) must also account for time
#   to arm the scope and finish the acquisition
#
#   This arm/trigger/finish part is accounted for in the main script.
#
# How it works:
#
# - What really matters is the RUN bit in the Operation Condition
#   (not Event) Register. This bit changes based on the
#   oscilloscope state.
#
#   If the oscilloscope is running, it is high (8), and low (0) if
#   it is stopped.
#
#   The only (best) way to get at this bit is with the

```

```

# :OPERation:CONDition? query. The Operation Condition Register
# can reflect states for other oscilloscope properties, for
# example, if the oscilloscope is armed, thus it can produce
# values other than 0 (stopped) or 8 (running).
#
# To handle that, the result of :OPERation:Condition? is bitwise
# ANDed (& in Python) with an 8. This is called "unmasking".
#
# Here, the "unmasking" is done in the script. On the other
# hand, it is possible to "mask" which bits get passed to the
# summary bit to the next register below on the instrument
# itself. However, this method is typically only used when
# working with the Status Byte, and not used here.
#
# - Why 8 = running = not done?
#
# The Run bit is the 4th bit of the Operation Status Condition
# (and Event) Registers.
#
# The registers are binary and start counting at zero, thus the
# 4th bit is bit number 3, and  $2^3 = 8$ , and thus it returns an
# 8 for high and a 0 for low.
#
# - Why the CONDITION and NOT the EVENT register?
#
# The Condition register reflects the CURRENT state, while the
# EVENT register reflects the first event that occurred since it
# was cleared or read (as in: has it EVER happened?), thus the
# CONDITION register is used.
#
# Note that with this method using :SINGLE, for InfiniiVision
# X-Series oscilloscopes only, :SINGLE itself forces the trigger
# sweep mode into NORMAL. This does not happen with the blocking
# method, using :DIGitize, or on the InfiniiVision notXs.
# =====
def polling_method():
    MAX_TIME_TO_WAIT = SCOPE_ACQUISITION_TIME_OUT/float(1000)
    # Time in seconds to wait for the oscilloscope to arm, trigger,
    # and finish acquisition.
    #
    # Note that this is NOT a property of the device interface,
    # KsInfiniiVisionX, but rather some constant in the script to be
    # used later with the Python module "time", and will be used with
    # time.perf_counter().

    # Define "mask" bits.
    #
    # Mask condition for Run state in the Operation Status Condition
    # (and Event) Register.
    #
    # Refer to Programmer's Guide chapters on Status Reporting and
    # Synchronizing Acquisitions.
    RUN_BIT = 3
    # The run bit is the 4th bit (see next set of comments @
    # Completion Criteria).
    RUN_MASK = 1<<RUN_BIT

```

```

# This basically means: 2^3 = 8, or rather, in Python 2**3
# (<< is a left shift; left shift is fastest); this is used later
# to "unmask" the result of the Operation Status Event Register
# as there is no direct access to the RUN bit.

# Define completion criterion:
ACQ_DONE = 0
# Means the oscilloscope is stopped
ACQ_NOT_DONE = 1<<RUN_BIT
# Means the oscilloscope is running; value is 8. This is the
# 4th bit of the Operation Status Condition (and Event) Register.
# The registers are binary and start counting at zero, thus the
# 4th bit (4th position in a binary representation of decimal
# 8 = 2^3 = (1 left shift 3). This is either High (running = 8)
# or low (stopped and therefore done with acquisition = 0).

print("Acquiring signal(s)...")

# Define acquisition start time. This is in seconds.
StartTime = time.perf_counter()

# Begin Acquisition with *CLS and the non-blocking :SINGLE
# command, concatenated together. The *CLS clears all (non-mask)
# registers & sets them to 0;
KsInfiniiVisionX.write("*CLS;:SINGLE")

# Initialize the loop entry condition (assume Acq. is not done).
Acq_State = ACQ_NOT_DONE

# Poll the oscilloscope until Acq_State is a one. (This is NOT a
# "Serial Poll.")
while Acq_State == ACQ_NOT_DONE and (time.perf_counter() - StartTime
                                     <= MAX_TIME_TO_WAIT):

    # Ask oscilloscope if it is done with the acquisition via the
    # Operation Status Condition (not Event) Register.
    # The Condition register reflects the CURRENT state, while
    # the EVENT register reflects the first event that occurred
    # since it was cleared or read, thus the CONDITION register
    # is used.
    #
    # DO NOT do:
    # KsInfiniiVisionX.query("*CLS;SINGLE;OPERRegister:CONDition?")
    # as putting :OPERRegister:CONDition? right after :SINGLE
    # does not work reliably
    #
    # The oscilloscope SHOULD trigger, but it sits there with the
    # Single hard key on the oscilloscope lit yellow; pressing
    # this key causes a trigger.
    Status = int(KsInfiniiVisionX.query(":OPERRegister:CONDition?"))

    # Bitwise AND of the Status and RUN_MASK. This exposes ONLY
    # the 4th bit, which is either High (running = 8) or low
    # (stopped and therefore done with acquisition = 0)
    Acq_State = (Status & RUN_MASK)
    if Acq_State == ACQ_DONE:
        break # Break out of while loop so that the 100 ms pause

```

```

        # below is not incurred if done.
time.sleep(0.1) # Pause 100 ms to prevent excessive queries
# This can actually be set a little faster, at 0.045. The
# point here is that:
#
# 1. If there are other things being controlled, going too
#    fast can tie up the bus.
# 2. Going faster does not work on all scopes. The
#    symptom of this not working is:
#
# The oscilloscope SHOULD trigger, but it sits there with the
# Single hard key on the oscilloscope lit yellow; pressing
# this key causes a trigger.
#
# The pause should be at the end of the loop, so that the
# oscilloscope is immediately asked if it is done.
#
# Loop exits when Acq_State != NOT_DONE, that is, it exits
# the loop when it is DONE or if the max wait time is
# exceeded.

if Acq_State == ACQ_DONE: # Acquisition fully completed
    print("Signal acquired.")
else: # Acquisition failed for some reason
    print("Max wait time exceeded.")
    print("This happens if there was no trigger event.")
    print("Adjust settings accordingly.\n")
    print("Properly closing oscilloscope connection and exiting " \
          "script.\n")
    KsInfiniiVisionX.clear() # Clear communications interface
    KsInfiniiVisionX.query(":STOP;*OPC?")
    # Stop the oscilloscope
    KsInfiniiVisionX.close() # Close communications interface
    sys.exit("Exiting script.")

# =====
# Do Something with data... save, export, additional analysis...
# =====
def do_something_with_data():

    # For example, make a peak-peak voltage measurement on channel 1:
    Vpp_Ch1 = \
        str(KsInfiniiVisionX.query("MEASure:VPP? CHANnel1")).strip("\n")
    # The result has a newline, so remove it with .strip("\n")
    print("Vpp Ch1 = " + Vpp_Ch1 + " V\n")

# =====
# Main code
# =====

# Connect and initialize oscilloscope
# -----
# Define VISA Resource Manager & Install directory
rm = pyvisa.ResourceManager('C:\\Windows\\System32\\visa64.dll')
```

```

# Define and open the oscilloscope using the VISA address
try:
    KsInfiniiVisionX = rm.open_resource(VISA_ADDRESS)
except Exception:
    print("Unable to connect to oscilloscope at " + str(VISA_ADDRESS)\
          + ". Aborting script.\n")
    sys.exit()

# Set the Global Timeout
KsInfiniiVisionX.timeout = GLOBAL_TOUT

# Clear the instrument bus
KsInfiniiVisionX.clear()

# Clear all status registers and errors
KsInfiniiVisionX.write("*CLS")

try:

    # Set up the oscilloscope
    # -----
    # Note that you would normally perform a reset (default setup) if
    # you were to create the setup from scratch... But here we will
    # use the oscilloscope "as is" for the most part.
    # KsInfiniiVisionX.query("*RST;*OPC?") # Resets the oscilloscope

    # Always stop the oscilloscope when making any changes.
    KsInfiniiVisionX.query(":STOP;*OPC?")

    # For this example, the oscilloscope will be forced to trigger on
    # the # (AC input power) LINE voltage so something happens.
    # Always use normal trigger sweep, never auto.
    KsInfiniiVisionX.write(":TRIGger:SWEep NORMAL")
    # This line simply gives the oscilloscope something to trigger on.
    KsInfiniiVisionX.query(":TRIGger:EDGE:SOURce LINE;*OPC?")

    # Clear the display (so you can see the waveform being acquired -
    # otherwise, there is no need for this).
    KsInfiniiVisionX.write(":CDISplay")

    # Calculate acquisition timeout/wait time by short, overestimate
    # method
    # -----

    # Create some default variables
    N_AVERAGES = 1
    N_SEGMENTS = 1

    # Get some info about the scope time base setup
    HO = float(KsInfiniiVisionX.query(":TRIGger:HOLDoff?"))
    T_RANGE = float(KsInfiniiVisionX.query(":TIMEbase:RANGE?"))
    T_POSITION = float(KsInfiniiVisionX.query(":TIMEbase:POSition?"))

    # Determine Acquisition Type and Mode:
    ACQ_TYPE = str(KsInfiniiVisionX.query(":ACQuire:TYPE?").strip("\n"))
    ACQ_MODE = str(KsInfiniiVisionX.query(":ACQuire:MODE?").strip("\n"))

```

```

if ACQ_MODE == "SEGM":
    N_SEGMENTS = \
        float(KsInfiniiVisionX.query(":ACquire:SEGmented:COUNT?"))
    # Note that if there are a lot of analysis associated segments,
    # for example, serial data decode, the timeout will likely need
    # to be longer than calculated.
    #
    # You are encouraged to manually set up the oscilloscope in
    # this case, as it will be used, time it, and use that, with
    # a little overhead.
    #
    # Blocking method is recommended for Segmented Memory mode.
elif ACQ_TYPE == "AVER":
    N_AVERAGES = float(KsInfiniiVisionX.query(":ACquire:COUNT?"))

# Calculate acquisition timeout by overestimate method:
# Recall that PyVISA timeouts are in ms, so multiply by 1000.
SCOPE_ACQUISITION_TIME_OUT = (float(TIME_TO_TRIGGER)*1.1 +
    (T_RANGE*2.0 + abs(T_POSITION)*2.0 + HO*1.1 +
    float(TIME_BETWEEN_TRIGGERS)*1.1)*N_SEGMENTS*N_AVERAGES)*1000.0

## Ensure the timeout is no less than 10 seconds
if SCOPE_ACQUISITION_TIME_OUT < 10000.0:
    SCOPE_ACQUISITION_TIME_OUT = 10000.0

# What about Equivalent Time Mode and other odd modes such as
# Jitter or Eye (the last two only being found on the
# 6000 X-Series), and math functions?
#
# In most cases, the padding and 10 second minimum timeout will
# take care of this.
#
# Equivalent Time Mode has effects only at the fastest time
# scales, so it really does not make a difference as long as a
# trigger signal is present. If trigger signal occurs rarely,
# adjust the TIME_BETWEEN_TRIGGERS constant accordingly.
#
# For math, the math will happen fast enough that the "padding"
# in the timeout calculation takes care of this.
#
# For jitter mode on the 6000 X-Series, you can try this method,
# typically there is always a signal present, and the 10 second
# minimum should work out. If not, make it bigger, or increase
# padding.
#
# For Eye mode on the 6000 X-Series, none of this works anyway,
# and you have to use :RUN (or :RTEye:ACquire) and :STOP.

# Acquire Signal
# -----
# Choose blocking_method or polling_method. These were defined as
# functions in case you want to use them repeatedly.
blocking_method()
# If Acquisition Type is Average, always use blocking_method() to
# get complete average.
do_something_with_data()

```

```

    polling_method()
    do_something_with_data()

    # Done - cleanup
    KsInfiniiVisionX.clear() # Clear communications interface
    KsInfiniiVisionX.close() # Close communications interface
except KeyboardInterrupt:
    KsInfiniiVisionX.clear()
    KsInfiniiVisionX.query(":STOP;*OPC?")
    KsInfiniiVisionX.write(":SYSTem:LOCK OFF")
    KsInfiniiVisionX.clear()
    KsInfiniiVisionX.close()
    sys.exit("User Interrupt. Properly closing oscilloscope and "
            "aborting script.")
except Exception:
    KsInfiniiVisionX.clear()
    KsInfiniiVisionX.query(":STOP;*OPC?")
    KsInfiniiVisionX.write(":SYSTem:LOCK OFF")
    KsInfiniiVisionX.clear()
    KsInfiniiVisionX.close()
    sys.exit("Something went wrong. Properly closing oscilloscope "
            "and aborting script.")

# End of Script
# -----
print("Done.")

```


49 More About Oscilloscope Commands

Command Classifications / 1730

Valid Command/Query Strings / 1731

Query Return Values / 1737

Command Classifications

To help you use existing programs with your oscilloscope, or use current programs with the next generation of Keysight InfiniiVision oscilloscopes, commands are classified by the following categories:

- **"Core Commands"** on page 1730
- **"Non-Core Commands"** on page 1730
- **"Obsolete Commands"** on page 1730

C Core Commands

Core commands are a common set of commands that provide basic oscilloscope functionality on this oscilloscope and future Keysight InfiniiVision oscilloscopes. Core commands are unlikely to be modified in the future. If you restrict your programs to core commands, the programs should work across product offerings in the future, assuming appropriate programming methods are employed.

N Non-Core Commands

Non-core commands are commands that provide specific features, but are not universal across all Keysight InfiniiVision oscilloscope models. Non-core commands may be modified or deleted in the future. With a command structure as complex as the one for your oscilloscope, some evolution over time is inevitable. Keysight's intent is to continue to expand command subsystems, such as the rich and evolving trigger feature set.

O Obsolete Commands

Obsolete commands are older forms of commands that are provided to reduce customer rework for existing systems and programs. Generally, these commands are mapped onto some of the Core and Non-core commands, but may not strictly have the same behavior as the new command. None of the obsolete commands are guaranteed to remain functional in future products. New systems and programs should use the Core (and Non-core) commands. Obsolete commands are listed in:


- **Chapter 45**, "Obsolete and Discontinued Commands," starting on page 1611

Valid Command/Query Strings

- **"Program Message Syntax"** on page 1731
- **"Duplicate Mnemonics"** on page 1735
- **"Tree Traversal Rules and Multiple Commands"** on page 1735

Program Message Syntax

To program the instrument remotely, you must understand the command format and structure expected by the instrument. The IEEE 488.2 syntax rules govern how individual elements such as headers, separators, program data, and terminators may be grouped together to form complete instructions. Syntax definitions are also given to show how query responses are formatted. The following figure shows the main syntactical parts of a typical program statement.



Instructions (both commands and queries) normally appear as a string embedded in a statement of your host language, such as Visual Basic or C/C++. The only time a parameter is not meant to be expressed as a string is when the instruction's syntax definition specifies `<block data>`, such as `<learn string>`. There are only a few instructions that use block data.

Program messages can have long or short form commands (and data in some cases – see **"Long Form to Short Form Truncation Rules"** on page 1732), and upper and/or lower case ASCII characters may be used. (Query responses, however, are always returned in upper case.)

Instructions are composed of two main parts:

- The header, which specifies the command or query to be sent.
- The program data, which provide additional information needed to clarify the meaning of the instruction.

Instruction Header

The instruction header is one or more mnemonics separated by colons (:) that represent the operation to be performed by the instrument.

`":DISPlay:LABel ON"` is a command. Queries are indicated by adding a question mark (?) to the end of the header, for example, `":DISPlay:LABel?"`. Many instructions can be used as either commands or queries, depending on whether or

not you have included the question mark. The command and query forms of an instruction usually have different program data. Many queries do not use any program data.

There are three types of headers:

- **"Simple Command Headers"** on page 1733
- **"Compound Command Headers"** on page 1733
- **"Common Command Headers"** on page 1733

White Space (Separator) White space is used to separate the instruction header from the program data. If the instruction does not require any program data parameters, you do not need to include any white space. White space is defined as one or more space characters. ASCII defines a space to be character 32 (in decimal).

Program Data Program data are used to clarify the meaning of the command or query. They provide necessary information, such as whether a function should be on or off, or which waveform is to be displayed. Each instruction's syntax definition shows the program data, as well as the values they accept. **"Program Data Syntax Rules"** on page 1734 describes all of the general rules about acceptable values.

When there is more than one data parameter, they are separated by commas(,). Spaces can be added around the commas to improve readability.

Program Message Terminator The program instructions within a data message are executed after the program message terminator is received. The terminator may be either an NL (New Line) character, an EOI (End-Or-Identify) asserted in the programming interface, or a combination of the two. Asserting the EOI sets the EOI control line low on the last byte of the data message. The NL character is an ASCII linefeed (decimal 10).

NOTE

New Line Terminator Functions. The NL (New Line) terminator has the same function as an EOS (End Of String) and EOT (End Of Text) terminator.

Long Form to Short Form Truncation Rules

To get the short form of a command/keyword:

- When the command/keyword is longer than four characters, use the first four characters of the command/keyword unless the fourth character is a vowel; when the fourth character is a vowel, use the first three characters of the command/keyword.
- When the command/keyword is four or fewer characters, use all of the characters.

Long Form	Short form
RANGe	RANG
PATTern	PATT

Long Form	Short form
TIMebase	TIM
DELAy	DEL
TYPE	TYPE

In the oscilloscope programmer's documentation, the short form of a command is indicated by uppercase characters.

Programs written in long form are easily read and are almost self-documenting. The short form syntax conserves the amount of controller memory needed for program storage and reduces I/O activity.

Simple Command Headers

Simple command headers contain a single mnemonic. :AUToscale and :DIGitize are examples of simple command headers typically used in the oscilloscope. The syntax is:

```
<program mnemonic><terminator>
```

Simple command headers must occur at the beginning of a program message; if not, they must be preceded by a colon.

When program data must be included with the simple command header (for example, :DIGitize CHANnel1), white space is added to separate the data from the header. The syntax is:

```
<program mnemonic><separator><program data><terminator>
```

Compound Command Headers

Compound command headers are a combination of two or more program mnemonics. The first mnemonic selects the subsystem, and the second mnemonic selects the function within that subsystem. The mnemonics within the compound message are separated by colons. For example, to execute a single function within a subsystem:

```
:<subsystem>:<function><separator><program data><terminator>
```

For example, :CHANnel1:BWLimit ON

Common Command Headers

Common command headers control IEEE 488.2 functions within the instrument (such as clear status). Their syntax is:

```
*<command header><terminator>
```

No space or separator is allowed between the asterisk (*) and the command header. *CLS is an example of a common command header.

Program Data Syntax Rules

Program data is used to convey a parameter information related to the command header. At least one space must separate the command header or query header from the program data.

```
<program mnemonic><separator><data><terminator>
```

When a program mnemonic or query has multiple program data, a comma separates sequential program data.

```
<program mnemonic><separator><data>,<data><terminator>
```

For example, :MEASure:DELay CHANnel1,CHANnel2 has two program data: CHANnel1 and CHANnel2.

Two main types of program data are used in commands: character and numeric.

Character Program Data

Character program data is used to convey parameter information as alpha or alphanumeric strings. For example, the :TIMEbase:MODE command can be set to normal, zoomed (delayed), XY, or ROLL. The character program data in this case may be MAIN, WINDow, XY, or ROLL. The command :TIMEbase:MODE WINDow sets the time base mode to zoomed.

The available mnemonics for character program data are always included with the command's syntax definition.

When sending commands, you may either the long form or short form (if one exists). Uppercase and lowercase letters may be mixed freely.

When receiving query responses, uppercase letters are used exclusively.

Numeric Program Data

Some command headers require program data to be expressed numerically. For example, :TIMEbase:RANGe requires the desired full scale range to be expressed numerically.

For numeric program data, you have the option of using exponential notation or using suffix multipliers to indicate the numeric value. The following numbers are all equal:

$$28 = 0.28E2 = 280e-1 = 28000m = 0.028K = 28e-3K.$$

When a syntax definition specifies that a number is an integer, that means that the number should be whole. Any fractional part will be ignored, truncating the number. Numeric data parameters accept fractional values are called real numbers.

All numbers must be strings of ASCII characters. Thus, when sending the number 9, you would send a byte representing the ASCII code for the character 9 (which is 57). A three-digit number like 102 would take up three bytes (ASCII codes 49, 48, and 50). This is handled automatically when you include the entire instruction in a string.

Duplicate Mnemonics

Identical function mnemonics can be used in more than one subsystem. For example, the function mnemonic RANGe may be used to change the vertical range or to change the horizontal range:

```
:CHANnel1:RANGe .4
```

Sets the vertical range of channel 1 to 0.4 volts full scale.

```
:TIMEbase:RANGe 1
```

Sets the horizontal time base to 1 second full scale.

:CHANnel1 and :TIMEbase are subsystem selectors and determine which range is being modified.

Tree Traversal Rules and Multiple Commands

Command headers are created by traversing down the command tree. A legal command header would be :TIMEbase:RANGe. This is referred to as a *compound header*. A compound header is a header made of two or more mnemonics separated by colons. The mnemonic created contains no spaces.

The following rules apply to traversing the tree:

- A leading colon (<NL> or EOI true on the last byte) places the parser at the root of the command tree. A leading colon is a colon that is the first character of a program header. Executing a subsystem command lets you access that subsystem until a leading colon or a program message terminator (<NL>) or EOI true is found.
- In the command tree, use the last mnemonic in the compound header as the reference point (for example, RANGe). Then find the last colon above that mnemonic (TIMEbase:). That is the point where the parser resides. Any command below that point can be sent within the current program message without sending the mnemonics which appear above them (for example, POSition).

The output statements in the examples are written using the Keysight VISA COM library in Visual Basic. The quoted string is placed on the bus, followed by a carriage return and linefeed (CRLF).

To execute more than one function within the same subsystem, separate the functions with a semicolon (;):

```
:<subsystem>:<function><separator><data>;<function><separator><data><terminator>
```

For example:

```
myScope.WriteString ":TIMEbase:RANGe 0.5;POSition 0"
```

NOTE

The colon between TIMEbase and RANGE is necessary because TIMEbase:RANGE is a compound command. The semicolon between the RANGE command and the POSition command is the required program message unit separator. The POSition command does not need TIMEbase preceding it because the TIMEbase:RANGE command sets the parser to the TIMEbase node in the tree.

Example 2:
Program Message
Terminator Sets
Parser Back to
Root

```
myScope.WriteString ":TIMEbase:REfERENCE CENTER;POSition 0.00001"
or
myScope.WriteString ":TIMEbase:REfERENCE CENTER"
myScope.WriteString ":TIMEbase:POSition 0.00001"
```

NOTE

In the first line of example 2, the subsystem selector is implied for the POSition command in the compound command. The POSition command must be in the same program message as the REfERENCE command because the program message terminator places the parser back at the root of the command tree.

A second way to send these commands is by placing TIMEbase: before the POSition command as shown in the second part of example 2. The space after POSition is required.

Example 3:
Selecting Multiple
Subsystems

You can send multiple program commands and program queries for different subsystems on the same line by separating each command with a semicolon. The colon following the semicolon enables you to enter a new subsystem. For example:

```
<program mnemonic><data>;:<program mnemonic><data><terminator>
```

For example:

```
myScope.WriteString ":TIMEbase:REfERENCE CENTER;:DISPlay:VECTors ON"
```

NOTE

The leading colon before DISPlay:VECTors ON tells the parser to go back to the root of the command tree. The parser can then see the DISPlay:VECTors ON command. The space between REfERENCE and CENTer is required; so is the space between VECTors and ON.

Multiple commands may be any combination of compound and simple commands.

Query Return Values

Command headers immediately followed by a question mark (?) are queries. Queries are used to get results of measurements made by the instrument or to find out how the instrument is currently configured.

After receiving a query, the instrument interrogates the requested function and places the answer in its output queue. The answer remains in the output queue until it is read or another command is issued.

When read, the answer is transmitted across the bus to the designated listener (typically a controller). For example, the query :TIMEbase:RANGe? places the current time base setting in the output queue. When using the Keysight VISA COM library in Visual Basic, the controller statements:

```
Dim strQueryResult As String
myScope.WriteString ":TIMEbase:RANGe?"
strQueryResult = myScope.ReadString
```

pass the value across the bus to the controller and place it in the variable strQueryResult.

NOTE

Read Query Results Before Sending Another Command. Sending another command or query before reading the result of a query clears the output buffer (the current response) and places a Query INTERRUPTED error in the error queue.

Infinity Representation	The representation of infinity is +9.9E+37. This is also the value returned when a measurement cannot be made.
--------------------------------	--

50 Programming Examples

VISA COM Examples / 1740

VISA Examples / 1774

VISA.NET Examples / 1821

SICL Examples / 1840

SCPI.NET Examples / 1860

The example programs in this manual are ASCII text files that can be cut from the help file and pasted into your favorite text editor.

- See Also**
- You can find additional programming examples for the InfiniiVision 6000 X-Series oscilloscopes on the Keysight Technologies website at: www.keysight.com/find/6000X-Series-examples

VISA COM Examples

- ["VISA COM Example in Visual Basic"](#) on page 1740
- ["VISA COM Example in C#"](#) on page 1749
- ["VISA COM Example in Visual Basic .NET"](#) on page 1758
- ["VISA COM Example in Python"](#) on page 1766

VISA COM Example in Visual Basic

To run this example in Visual Basic for Applications (VBA):

- 1 Start the application that provides Visual Basic for Applications (for example, Microsoft Excel).
- 2 Press ALT+F11 to launch the Visual Basic editor.
- 3 Reference the Keysight VISA COM library:
 - a Choose **Tools > References...** from the main menu.
 - b In the References dialog, check the "VISA COM 5.9 Type Library".
 - c Click **OK**.
- 4 Choose **Insert > Module**.
- 5 Cut-and-paste the code that follows into the editor.
- 6 Edit the program to use the VISA address of your oscilloscope, and save the changes.
- 7 Run the program.

```
'
' Keysight VISA COM Example in Visual Basic
' -----
' This program illustrates a few commonly-used programming
' features of your Keysight oscilloscope.
' -----

Option Explicit

Public myMgr As VisaComLib.ResourceManager
Public myScope As VisaComLib.FormattedIO488
Public varQueryResult As Variant
Public strQueryResult As String

' For Sleep subroutine.
Private Declare Sub Sleep Lib "kernel32" (ByVal dwMilliseconds As Long)

'
' Main Program
' -----

Sub Main()
```

```

On Error GoTo VisaComError

' Create the VISA COM I/O resource.
Set myMgr = New VisaComLib.ResourceManager
Set myScope = New VisaComLib.FormattedIO488
Set myScope.IO = _
    myMgr.Open("USB0::0x0957::0x17A6::US50210029::0::INSTR")
myScope.IO.Clear ' Clear the interface.
myScope.IO.Timeout = 10000 ' Set I/O communication timeout.

' Initialize - start from a known state.
Initialize

' Capture data.
Capture

' Analyze the captured waveform.
Analyze

Exit Sub

VisaComError:
MsgBox "VISA COM Error:" + vbCrLf + Err.Description
End

End Sub

'
' Initialize the oscilloscope to a known state.
' -----

Private Sub Initialize()

On Error GoTo VisaComError

' Get and display the device's *IDN? string.
strQueryResult = DoQueryString("*IDN?")
Debug.Print "Identification string: " + strQueryResult

' Clear status and load the default setup.
DoCommand "*CLS"
DoCommand "*RST"

Exit Sub

VisaComError:
MsgBox "VISA COM Error:" + vbCrLf + Err.Description
End

End Sub

'
' Capture the waveform.
' -----

Private Sub Capture()

```

```

On Error GoTo VisaComError

' Use auto-scale to automatically configure oscilloscope.
' -----
DoCommand ":AUToscale"

' Set trigger mode (EDGE, PULSe, PATtern, etc., and input source.
DoCommand ":TRIGger:MODE EDGE"
Debug.Print "Trigger mode: " + _
    DoQueryString(":TRIGger:MODE?")

' Set EDGE trigger parameters.
DoCommand ":TRIGger:EDGE:SOURce CHANnel1"
Debug.Print "Trigger edge source: " + _
    DoQueryString(":TRIGger:EDGE:SOURce?")

DoCommand ":TRIGger:EDGE:LEVel 1.5"
Debug.Print "Trigger edge level: " + _
    DoQueryString(":TRIGger:EDGE:LEVel?")

DoCommand ":TRIGger:EDGE:SLOPe POSitive"
Debug.Print "Trigger edge slope: " + _
    DoQueryString(":TRIGger:EDGE:SLOPe?")

' Save oscilloscope configuration.
' -----
varQueryResult = DoQueryIEEEBlock_UI1(":SYSTem:SETup?")

' Output setup string to a file:
Dim strPath As String
strPath = "c:\scope\config\setup.dat"
Dim hFile As Long
hFile = FreeFile
Open strPath For Binary Access Write Lock Write As hFile
Put hFile, , varQueryResult ' Write data.
Close hFile ' Close file.
Debug.Print "Setup bytes saved: " + CStr(LenB(varQueryResult))

' Change settings with individual commands:
' -----

' Set vertical scale and offset.
DoCommand ":CHANnel1:SCALe 0.05"
Debug.Print "Channel 1 vertical scale: " + _
    DoQueryString(":CHANnel1:SCALe?")

DoCommand ":CHANnel1:OFFSet -1.5"
Debug.Print "Channel 1 vertical offset: " + _
    DoQueryString(":CHANnel1:OFFSet?")

' Set horizontal scale and offset.
DoCommand ":TIMEbase:SCALe 0.0002"
Debug.Print "Timebase scale: " + _
    DoQueryString(":TIMEbase:SCALe?")

DoCommand ":TIMEbase:POSition 0.0"
Debug.Print "Timebase position: " + _

```

```

        DoQueryString(":TIMEbase:POSition?")

' Set the acquisition type (NORMAL, PEAK, AVERAGE, or HRESolution).
DoCommand ":ACQUIRE:TYPE NORMAL"
Debug.Print "Acquire type: " + _
        DoQueryString(":ACQUIRE:TYPE?")

' Or, configure by loading a previously saved setup.
' -----
Dim varSetupString As Variant
strPath = "c:\scope\config\setup.dat"
Open strPath For Binary Access Read As hFile ' Open file for input.
Get hFile, , varSetupString ' Read data.
Close hFile ' Close file.
' Write learn string back to oscilloscope using ":SYSTEM:SETup"
' command:
DoCommandIEEEBlock ":SYSTEM:SETup", varSetupString
Debug.Print "Setup bytes restored: " + CStr(LenB(varSetupString))

' Capture an acquisition using :DIGitize.
' -----
DoCommand ":DIGitize CHANnel1"

Exit Sub

VisaComError:
MsgBox "VISA COM Error:" + vbCrLf + Err.Description
End

End Sub

'
' Analyze the captured waveform.
' -----

Private Sub Analyze()

On Error GoTo VisaComError

' Make a couple of measurements.
' -----
DoCommand ":MEASure:SOURce CHANnel1"
Debug.Print "Measure source: " + _
        DoQueryString(":MEASure:SOURce?")

DoCommand ":MEASure:FREQuency"
varQueryResult = DoQueryNumber(":MEASure:FREQuency?")
MsgBox "Frequency:" + vbCrLf + _
        FormatNumber(varQueryResult / 1000, 4) + " kHz"

DoCommand ":MEASure:VAMPlitude"
varQueryResult = DoQueryNumber(":MEASure:VAMPlitude?")
MsgBox "Vertical amplitude:" + vbCrLf + _
        FormatNumber(varQueryResult, 4) + " V"

' Download the screen image.

```

```

' -----
' Get screen image.
DoCommand ":HARDcopy:INKSaver OFF"
Dim byteData() As Byte
byteData = DoQueryIEEEBlock_UI1(":DISPlay:DATA? PNG, COlor")

' Save screen image to a file.
Dim strPath As String
strPath = "c:\scope\data\screen.png"
If Len(Dir(strPath)) Then
    Kill strPath ' Remove file if it exists.
End If

Dim hFile As Long
hFile = FreeFile
Open strPath For Binary Access Write Lock Write As hFile
Put hFile, , byteData ' Write data.
Close hFile ' Close file.
MsgBox "Screen image (" + CStr(UBound(byteData) + 1) + _
    " bytes) written to " + strPath

' Download waveform data.
' -----

' Set the waveform points mode.
DoCommand ":WAVEform:POINts:MODE RAW"
Debug.Print "Waveform points mode: " + _
    DoQueryString(":WAVEform:POINts:MODE?")

' Get the number of waveform points available.
Debug.Print "Waveform points available: " + _
    DoQueryString(":WAVEform:POINts?")

' Set the waveform source.
DoCommand ":WAVEform:SOURce CHANnel1"
Debug.Print "Waveform source: " + _
    DoQueryString(":WAVEform:SOURce?")

' Choose the format of the data returned (WORD, BYTE, ASCII):
DoCommand ":WAVEform:FORMat BYTE"
Debug.Print "Waveform format: " + _
    DoQueryString(":WAVEform:FORMat?")

' Display the waveform settings:
Dim Preamble()
Dim intFormat As Integer
Dim intType As Integer
Dim lngPoints As Long
Dim lngCount As Long
Dim dblXIncrement As Double
Dim dblXOrigin As Double
Dim lngXReference As Long
Dim sngYIncrement As Single
Dim sngYOrigin As Single
Dim lngYReference As Long

```



```

Preamble() = DoQueryNumbers(":WAVEform:PREamble?")

intFormat = Preamble(0)
intType = Preamble(1)
lngPoints = Preamble(2)
lngCount = Preamble(3)
dblXIncrement = Preamble(4)
dblXOrigin = Preamble(5)
lngXReference = Preamble(6)
sngYIncrement = Preamble(7)
sngYOrigin = Preamble(8)
lngYReference = Preamble(9)

If intFormat = 0 Then
    Debug.Print "Waveform format: BYTE"
ElseIf intFormat = 1 Then
    Debug.Print "Waveform format: WORD"
ElseIf intFormat = 4 Then
    Debug.Print "Waveform format: ASCii"
End If

If intType = 0 Then
    Debug.Print "Acquisition type: NORMAl"
ElseIf intType = 1 Then
    Debug.Print "Acquisition type: PEAK"
ElseIf intType = 2 Then
    Debug.Print "Acquisition type: AVERAge"
ElseIf intType = 3 Then
    Debug.Print "Acquisition type: HRESolution"
End If

Debug.Print "Waveform points: " + _
    FormatNumber(lngPoints, 0)

Debug.Print "Waveform average count: " + _
    FormatNumber(lngCount, 0)

Debug.Print "Waveform X increment: " + _
    Format(dblXIncrement, "Scientific")

Debug.Print "Waveform X origin: " + _
    Format(dblXOrigin, "Scientific")

Debug.Print "Waveform X reference: " + _
    FormatNumber(lngXReference, 0)

Debug.Print "Waveform Y increment: " + _
    Format(sngYIncrement, "Scientific")

Debug.Print "Waveform Y origin: " + _
    FormatNumber(sngYOrigin, 0)

Debug.Print "Waveform Y reference: " + _
    FormatNumber(lngYReference, 0)

' Get the waveform data
varQueryResult = DoQueryIEEEBlock_UI1(":WAVEform:DATA?")

```

```

Debug.Print "Number of data values: " + _
    CStr(UBound(varQueryResult) + 1)

' Set up output file:
strPath = "c:\scope\data\waveform_data.csv"

' Open file for output.
Open strPath For Output Access Write Lock Write As hFile

' Output waveform data in CSV format.
Dim lngDataValue As Long
Dim lngI As Long

For lngI = 0 To UBound(varQueryResult)
    lngDataValue = varQueryResult(lngI)

    ' Write time value, voltage value.
    Print #hFile, _
        FormatNumber(dblXOrigin + (lngI * dblXIncrement), 9) + _
        ", " + _
        FormatNumber(((lngDataValue - lngYReference) * _
            sngYIncrement) + sngYOrigin)

Next lngI

' Close output file.
Close hFile ' Close file.
MsgBox "Waveform format BYTE data written to " + _
    "c:\scope\data\waveform_data.csv."

Exit Sub

VisaComError:
MsgBox "VISA COM Error:" + vbCrLf + Err.Description
End

End Sub

Private Sub DoCommand(command As String)

    On Error GoTo VisaComError

    myScope.WriteString command
    CheckInstrumentErrors

Exit Sub

VisaComError:
MsgBox "VISA COM Error: " + vbCrLf + CStr(Err.Number) + ", " + _
    Err.Source + ", " + _
    Err.Description, vbExclamation, "VISA COM Error"
End

End Sub

Private Sub DoCommandIEEEBlock(command As String, data As Variant)

```

```

On Error GoTo VisaComError

Dim strErrors As String

myScope.WriteIEEEBlock command, data
CheckInstrumentErrors

Exit Sub

VisaComError:
MsgBox "VISA COM Error: " + vbCrLf + CStr(Err.Number) + ", " + _
    Err.Source + ", " + _
    Err.Description, vbExclamation, "VISA COM Error"
End

End Sub

Private Function DoQueryString(query As String) As String

On Error GoTo VisaComError

myScope.WriteString query
DoQueryString = myScope.ReadString
CheckInstrumentErrors

Exit Function

VisaComError:
MsgBox "VISA COM Error: " + vbCrLf + CStr(Err.Number) + ", " + _
    Err.Source + ", " + _
    Err.Description, vbExclamation, "VISA COM Error"
End

End Function

Private Function DoQueryNumber(query As String) As Variant

On Error GoTo VisaComError

myScope.WriteString query
DoQueryNumber = myScope.ReadNumber
CheckInstrumentErrors

Exit Function

VisaComError:
MsgBox "VISA COM Error: " + vbCrLf + CStr(Err.Number) + ", " + _
    Err.Source + ", " + _
    Err.Description, vbExclamation, "VISA COM Error"
End

End Function

Private Function DoQueryNumbers(query As String) As Variant()

On Error GoTo VisaComError

```

```

Dim strErrors As String

myScope.WriteString query
DoQueryNumbers = myScope.ReadList
CheckInstrumentErrors

Exit Function

VisaComError:
MsgBox "VISA COM Error: " + vbCrLf + CStr(Err.Number) + ", " + _
    Err.Source + ", " + _
    Err.Description, vbExclamation, "VISA COM Error"
End

End Function

Private Function DoQueryIEEEBlock_UI1(query As String) As Variant

On Error GoTo VisaComError

myScope.WriteString query
DoQueryIEEEBlock_UI1 = myScope.ReadIEEEBlock(BinaryType_UI1)
CheckInstrumentErrors

Exit Function

VisaComError:
MsgBox "VISA COM Error: " + vbCrLf + CStr(Err.Number) + ", " + _
    Err.Source + ", " + _
    Err.Description, vbExclamation, "VISA COM Error"
End

End Function

Private Sub CheckInstrumentErrors()

On Error GoTo VisaComError

Dim strErrVal As String
Dim strOut As String

myScope.WriteString ":SYSTem:ERror?" ' Query any errors data.
strErrVal = myScope.ReadString ' Read: Errnum,"Error String".
While Val(strErrVal) <> 0 ' End if find: 0,"No Error".
    strOut = strOut + "INST Error: " + strErrVal
    myScope.WriteString ":SYSTem:ERror?" ' Request error message.
    strErrVal = myScope.ReadString ' Read error message.
Wend

If Not strOut = "" Then
    MsgBox strOut, vbExclamation, "INST Error Messages"
    myScope.FlushWrite (False)
    myScope.FlushRead

End If

Exit Sub

```

```

VisaComError:
    MsgBox "VISA COM Error: " + vbCrLf + Err.Description

End Sub

```

VISA COM Example in C#

To compile and run this example in Microsoft Visual Studio 2008:

- 1 Open Visual Studio.
- 2 Create a new Visual C#, Windows, Console Application project.
- 3 Cut-and-paste the code that follows into the C# source file.
- 4 Edit the program to use the VISA address of your oscilloscope.
- 5 Add a reference to the VISA COM 5.9 Type Library:
 - a Right-click the project you wish to modify (not the solution) in the Solution Explorer window of the Microsoft Visual Studio environment.
 - b Choose **Add Reference...**
 - c In the Add Reference dialog, select the **COM** tab.
 - d Select **VISA COM 5.9 Type Library**; then click **OK**.
- 6 Build and run the program.

For more information, see the VISA COM Help that comes with Keysight IO Libraries Suite.

```

/*
 * Keysight VISA COM Example in C#
 * -----
 * This program illustrates a few commonly used programming
 * features of your Keysight oscilloscope.
 * -----
 */

using System;
using System.IO;
using System.Text;
using Ivi.Visa.Interop;
using System.Runtime.InteropServices;

namespace InfiniiVision
{
    class VisaComInstrumentApp
    {
        private static VisaComInstrument myScope;

        public static void Main(string[] args)
        {
            try
            {
                myScope = new

```

```

        VisaComInstrument("USB0::0x0957::0x17A6::US50210029::0::INSTR"
);
myScope.SetTimeoutSeconds(10);

// Initialize - start from a known state.
Initialize();

// Capture data.
Capture();

// Analyze the captured waveform.
Analyze();
}
catch (System.ApplicationException err)
{
    Console.WriteLine("*** VISA COM Error : " + err.Message);
}
catch (System.SystemException err)
{
    Console.WriteLine("*** System Error Message : " + err.Message);
}
catch (System.Exception err)
{
    System.Diagnostics.Debug.Fail("Unexpected Error");
    Console.WriteLine("*** Unexpected Error : " + err.Message);
}
finally
{
    myScope.Close();
}
}

/*
 * Initialize the oscilloscope to a known state.
 * -----
 */
private static void Initialize()
{
    string strResults;

    // Get and display the device's *IDN? string.
    strResults = myScope.DoQueryString("*IDN?");
    Console.WriteLine("*IDN? result is: {0}", strResults);

    // Clear status and load the default setup.
    myScope.DoCommand("*CLS");
    myScope.DoCommand("*RST");
}

/*
 * Capture the waveform.
 * -----
 */
private static void Capture()
{
    // Use auto-scale to automatically configure oscilloscope.
    myScope.DoCommand(":AUToscale");
}

```

```

// Set trigger mode (EDGE, PULSe, PATTeRn, etc., and input source.
myScope.DoCommand(":TRIGger:MODE EDGE");
Console.WriteLine("Trigger mode: {0}",
    myScope.DoQueryString(":TRIGger:MODE?"));

// Set EDGE trigger parameters.
myScope.DoCommand(":TRIGger:EDGE:SOURce CHANnel1");
Console.WriteLine("Trigger edge source: {0}",
    myScope.DoQueryString(":TRIGger:EDGE:SOURce?"));

myScope.DoCommand(":TRIGger:EDGE:LEVel 1.5");
Console.WriteLine("Trigger edge level: {0}",
    myScope.DoQueryString(":TRIGger:EDGE:LEVel?"));

myScope.DoCommand(":TRIGger:EDGE:SLOPe POSitive");
Console.WriteLine("Trigger edge slope: {0}",
    myScope.DoQueryString(":TRIGger:EDGE:SLOPe?"));

// Save oscilloscope configuration.
byte[] ResultsArray; // Results array.
int nLength; // Number of bytes returned from instrument.
string strPath;

// Query and read setup string.
ResultsArray = myScope.DoQueryIEEEBlock(":SYSTem:SETup?");
nLength = ResultsArray.Length;

// Write setup string to file.
strPath = "c:\\scope\\config\\setup.stp";
FileStream fStream = File.Open(strPath, FileMode.Create);
fStream.Write(ResultsArray, 0, nLength);
fStream.Close();
Console.WriteLine("Setup bytes saved: {0}", nLength);

// Change settings with individual commands:

// Set vertical scale and offset.
myScope.DoCommand(":CHANnel1:SCALe 0.05");
Console.WriteLine("Channel 1 vertical scale: {0}",
    myScope.DoQueryString(":CHANnel1:SCALe?"));

myScope.DoCommand(":CHANnel1:OFFSet -1.5");
Console.WriteLine("Channel 1 vertical offset: {0}",
    myScope.DoQueryString(":CHANnel1:OFFSet?"));

// Set horizontal scale and offset.
myScope.DoCommand(":TIMebase:SCALe 0.0002");
Console.WriteLine("Timebase scale: {0}",
    myScope.DoQueryString(":TIMebase:SCALe?"));

myScope.DoCommand(":TIMebase:POSition 0.0");
Console.WriteLine("Timebase position: {0}",
    myScope.DoQueryString(":TIMebase:POSition?"));

// Set the acquisition type (NORMal, PEAK, AVERage, or HRESolution
).

```

```

myScope.DoCommand(":ACQUIRE:TYPE NORMAL");
Console.WriteLine("Acquire type: {0}",
    myScope.DoQueryString(":ACQUIRE:TYPE?"));

// Or, configure by loading a previously saved setup.
byte[] dataArray;
int nBytesWritten;

// Read setup string from file.
strPath = "c:\\scope\\config\\setup.stp";
dataArray = File.ReadAllBytes(strPath);
nBytesWritten = dataArray.Length;

// Restore setup string.
myScope.DoCommandIIEEEBlock(":SYSTEM:SETUP", dataArray);
Console.WriteLine("Setup bytes restored: {0}", nBytesWritten);

// Capture an acquisition using :DIGITIZE.
myScope.DoCommand(":DIGITIZE CHANNEL1");
}

/*
 * Analyze the captured waveform.
 * -----
 */
private static void Analyze()
{
    byte[] resultsArray; // Results array.
    int nLength; // Number of bytes returned from instrument.
    string strPath;

    // Make a couple of measurements.
    // -----
    myScope.DoCommand(":MEASURE:SOURCE CHANNEL1");
    Console.WriteLine("Measure source: {0}",
        myScope.DoQueryString(":MEASURE:SOURCE?"));

    double fResult;
    myScope.DoCommand(":MEASURE:FREQUENCY");
    fResult = myScope.DoQueryNumber(":MEASURE:FREQUENCY?");
    Console.WriteLine("Frequency: {0:F4} kHz", fResult / 1000);

    myScope.DoCommand(":MEASURE:VAMPLITUDE");
    fResult = myScope.DoQueryNumber(":MEASURE:VAMPLITUDE?");
    Console.WriteLine("Vertical amplitude: {0:F2} V", fResult);

    // Download the screen image.
    // -----
    myScope.DoCommand(":HARDCOPY:INKSAVER OFF");

    // Get the screen data.
    resultsArray =
        myScope.DoQueryIEEEBlock(":DISPLAY:DATA? PNG, COLOR");
    nLength = resultsArray.Length;

    // Store the screen data to a file.
    strPath = "c:\\scope\\data\\screen.png";
}

```



```

FileStream fStream = File.Open(strPath, FileMode.Create);
fStream.Write(ResultsArray, 0, nLength);
fStream.Close();
Console.WriteLine("Screen image ({0} bytes) written to {1}",
    nLength, strPath);

// Download waveform data.
// -----

// Set the waveform points mode.
myScope.DoCommand(":WAVEform:POINTs:MODE RAW");
Console.WriteLine("Waveform points mode: {0}",
    myScope.DoQueryString(":WAVEform:POINTs:MODE?"));

// Get the number of waveform points available.
Console.WriteLine("Waveform points available: {0}",
    myScope.DoQueryString(":WAVEform:POINTs?"));

// Set the waveform source.
myScope.DoCommand(":WAVEform:SOURce CHANnel1");
Console.WriteLine("Waveform source: {0}",
    myScope.DoQueryString(":WAVEform:SOURce?"));

// Choose the format of the data returned (WORD, BYTE, ASCII):
myScope.DoCommand(":WAVEform:FORMat BYTE");
Console.WriteLine("Waveform format: {0}",
    myScope.DoQueryString(":WAVEform:FORMat?"));

// Display the waveform settings:
double[] fResultsArray;
fResultsArray = myScope.DoQueryNumbers(":WAVEform:PREAmble?");

double fFormat = fResultsArray[0];
if (fFormat == 0.0)
{
    Console.WriteLine("Waveform format: BYTE");
}
else if (fFormat == 1.0)
{
    Console.WriteLine("Waveform format: WORD");
}
else if (fFormat == 2.0)
{
    Console.WriteLine("Waveform format: ASCii");
}

double fType = fResultsArray[1];
if (fType == 0.0)
{
    Console.WriteLine("Acquire type: NORMAl");
}
else if (fType == 1.0)
{
    Console.WriteLine("Acquire type: PEAK");
}
else if (fType == 2.0)
{

```

```

        Console.WriteLine("Acquire type: AVERage");
    }
    else if (fType == 3.0)
    {
        Console.WriteLine("Acquire type: HRESolution");
    }

    double fPoints = fResultsArray[2];
    Console.WriteLine("Waveform points: {0:e}", fPoints);

    double fCount = fResultsArray[3];
    Console.WriteLine("Waveform average count: {0:e}", fCount);

    double fXincrement = fResultsArray[4];
    Console.WriteLine("Waveform X increment: {0:e}", fXincrement);

    double fXorigin = fResultsArray[5];
    Console.WriteLine("Waveform X origin: {0:e}", fXorigin);

    double fXreference = fResultsArray[6];
    Console.WriteLine("Waveform X reference: {0:e}", fXreference);

    double fYincrement = fResultsArray[7];
    Console.WriteLine("Waveform Y increment: {0:e}", fYincrement);

    double fYorigin = fResultsArray[8];
    Console.WriteLine("Waveform Y origin: {0:e}", fYorigin);

    double fYreference = fResultsArray[9];
    Console.WriteLine("Waveform Y reference: {0:e}", fYreference);

    // Read waveform data.
    ResultsArray = myScope.DoQueryIEEEBlock(":WAVEform:DATA?");
    nLength = ResultsArray.Length;
    Console.WriteLine("Number of data values: {0}", nLength);

    // Set up output file:
    strPath = "c:\\scope\\data\\waveform_data.csv";
    if (File.Exists(strPath)) File.Delete(strPath);

    // Open file for output.
    StreamWriter writer = File.CreateText(strPath);

    // Output waveform data in CSV format.
    for (int i = 0; i < nLength - 1; i++)
        writer.WriteLine("{0:f9}, {1:f6}",
            fXorigin + ((float)i * fXincrement),
            (((float)ResultsArray[i] - fYreference)
            * fYincrement) + fYorigin);

    // Close output file.
    writer.Close();
    Console.WriteLine("Waveform format BYTE data written to {0}",
        strPath);
}
}

```

```

class VisaComInstrument
{
    private ResourceManagerClass m_ResourceManager;
    private FormattedIO488Class m_IoObject;
    private string m_strVisaAddress;

    // Constructor.
    public VisaComInstrument(string strVisaAddress)
    {
        // Save VISA address in member variable.
        m_strVisaAddress = strVisaAddress;

        // Open the default VISA COM IO object.
        OpenIo();

        // Clear the interface.
        m_IoObject.IO.Clear();
    }

    public void DoCommand(string strCommand)
    {
        // Send the command.
        m_IoObject.WriteString(strCommand, true);

        // Check for inst errors.
        CheckInstrumentErrors(strCommand);
    }

    public void DoCommandIEEEBlock(string strCommand,
        byte[] DataArray)
    {
        // Send the command to the device.
        m_IoObject.WriteIEEEBlock(strCommand, DataArray, true);

        // Check for inst errors.
        CheckInstrumentErrors(strCommand);
    }

    public string DoQueryString(string strQuery)
    {
        // Send the query.
        m_IoObject.WriteString(strQuery, true);

        // Get the result string.
        string strResults;
        strResults = m_IoObject.ReadString();

        // Check for inst errors.
        CheckInstrumentErrors(strQuery);

        // Return results string.
        return strResults;
    }

    public double DoQueryNumber(string strQuery)
    {
        // Send the query.

```

```

    m_IoObject.WriteString(strQuery, true);

    // Get the result number.
    double fResult;
    fResult = (double)m_IoObject.ReadNumber(
        IEEEASCIIType.ASCIIType_R8, true);

    // Check for inst errors.
    CheckInstrumentErrors(strQuery);

    // Return result number.
    return fResult;
}

public double[] DoQueryNumbers(string strQuery)
{
    // Send the query.
    m_IoObject.WriteString(strQuery, true);

    // Get the result numbers.
    double[] fResultsArray;
    fResultsArray = (double[])m_IoObject.ReadList(
        IEEEASCIIType.ASCIIType_R8, ",;");

    // Check for inst errors.
    CheckInstrumentErrors(strQuery);

    // Return result numbers.
    return fResultsArray;
}

public byte[] DoQueryIEEEBlock(string strQuery)
{
    // Send the query.
    m_IoObject.WriteString(strQuery, true);

    // Get the results array.
    System.Threading.Thread.Sleep(2000); // Delay before reading.
    byte[] ResultsArray;
    ResultsArray = (byte[])m_IoObject.ReadIEEEBlock(
        IEEEBinaryType.BinaryType_UI1, false, true);

    // Check for inst errors.
    CheckInstrumentErrors(strQuery);

    // Return results array.
    return ResultsArray;
}

private void CheckInstrumentErrors(string strCommand)
{
    // Check for instrument errors.
    string strInstrumentError;
    bool bFirstError = true;

    do // While not "0,No error".
    {

```

```

        m_IoObject.WriteString(":SYSTEM:ERRor?", true);
        strInstrumentError = m_IoObject.ReadString();

        if (!strInstrumentError.ToString().StartsWith("+0, "))
        {
            if (bFirstError)
            {
                Console.WriteLine("ERROR(s) for command '{0}': ",
                    strCommand);
                bFirstError = false;
            }
            Console.Write(strInstrumentError);
        }
    } while (!strInstrumentError.ToString().StartsWith("+0, "));
}

private void OpenIo()
{
    m_ResourceManager = new ResourceManagerClass();
    m_IoObject = new FormattedIO488Class();

    // Open the default VISA COM IO object.
    try
    {
        m_IoObject.IO =
            (IMessage)m_ResourceManager.Open(m_strVisaAddress,
                AccessMode.NO_LOCK, 0, "");
    }
    catch (Exception e)
    {
        Console.WriteLine("An error occurred: {0}", e.Message);
    }
}

public void SetTimeoutSeconds(int nSeconds)
{
    m_IoObject.IO.Timeout = nSeconds * 1000;
}

public void Close()
{
    try
    {
        m_IoObject.IO.Close();
    }
    catch { }

    try
    {
        Marshal.ReleaseComObject(m_IoObject);
    }
    catch { }

    try
    {
        Marshal.ReleaseComObject(m_ResourceManager);
    }
}

```

```

        catch { }
    }
}

```

VISA COM Example in Visual Basic .NET

To compile and run this example in Microsoft Visual Studio 2008:

- 1 Open Visual Studio.
- 2 Create a new Visual Basic, Windows, Console Application project.
- 3 Cut-and-paste the code that follows into the Visual Basic .NET source file.
- 4 Edit the program to use the VISA address of your oscilloscope.
- 5 Add a reference to the VISA COM 5.9 Type Library:
 - a Right-click the project you wish to modify (not the solution) in the Solution Explorer window of the Microsoft Visual Studio environment.
 - b Choose **Add Reference...**
 - c In the Add Reference dialog, select the **COM** tab.
 - d Select **VISA COM 5.9 Type Library**; then click **OK**.
 - e Right-click the project you wish to modify (not the solution) in the Solution Explorer window of the Microsoft Visual Studio environment and choose **Properties**; then, select "InfiniiVision.VisaComInstrumentApp" as the **Startup object**.
- 6 Build and run the program.

For more information, see the VISA COM Help that comes with Keysight IO Libraries Suite.

```

'
' Keysight VISA COM Example in Visual Basic .NET
' -----
' This program illustrates a few commonly used programming
' features of your Keysight oscilloscope.
' -----

Imports System
Imports System.IO
Imports System.Text
Imports Ivi.Visa.Interop
Imports System.Runtime.InteropServices

Namespace InfiniiVision
    Class VisaComInstrumentApp
        Private Shared myScope As VisaComInstrument

        Public Shared Sub Main(ByVal args As String())
            Try
                myScope = New _
                    VisaComInstrument("USB0::0x0957::0x17A6::US50210029::0::INSTR")
            Catch ex As Exception
                Console.WriteLine(ex.Message)
            End Try
        End Sub
    End Class
End Namespace

```

```

)
    myScope.SetTimeoutSeconds(10)

    ' Initialize - start from a known state.
    Initialize()

    ' Capture data.
    Capture()

    ' Analyze the captured waveform.
    Analyze()

Catch err As System.ApplicationException
    Console.WriteLine("*** VISA Error Message : " + err.Message)
Catch err As System.SystemException
    Console.WriteLine("*** System Error Message : " + err.Message)
Catch err As System.Exception
    System.Diagnostics.Debug.Fail("Unexpected Error")
    Console.WriteLine("*** Unexpected Error : " + err.Message)
Finally
    myScope.Close()
End Try
End Sub

' Initialize the oscilloscope to a known state.
' -----

Private Shared Sub Initialize()
    Dim strResults As String

    ' Get and display the device's *IDN? string.
    strResults = myScope.DoQueryString("*IDN?")
    Console.WriteLine("*IDN? result is: {0}", strResults)

    ' Clear status and load the default setup.
    myScope.DoCommand("*CLS")
    myScope.DoCommand("*RST")

End Sub

' Capture the waveform.
' -----

Private Shared Sub Capture()

    ' Use auto-scale to automatically configure oscilloscope.
    myScope.DoCommand(":AUToscale")

    ' Set trigger mode (EDGE, PULSe, PATtern, etc., and input source.
    myScope.DoCommand(":TRIGger:MODE EDGE")
    Console.WriteLine("Trigger mode: {0}", _
        myScope.DoQueryString(":TRIGger:MODE?"))

    ' Set EDGE trigger parameters.
    myScope.DoCommand(":TRIGger:EDGE:SOURce CHANnel1")
    Console.WriteLine("Trigger edge source: {0}", _
        myScope.DoQueryString(":TRIGger:EDGE:SOURce?"))

```

```

myScope.DoCommand(":TRIGger:EDGE:LEVel 1.5")
Console.WriteLine("Trigger edge level: {0}", _
    myScope.DoQueryString(":TRIGger:EDGE:LEVel?"))

myScope.DoCommand(":TRIGger:EDGE:SLOPe POSitive")
Console.WriteLine("Trigger edge slope: {0}", _
    myScope.DoQueryString(":TRIGger:EDGE:SLOPe?"))

' Save oscilloscope configuration.
Dim ResultsArray As Byte() ' Results array.
Dim nLength As Integer ' Number of bytes returned from inst.
Dim strPath As String
Dim fStream As FileStream

' Query and read setup string.
ResultsArray = myScope.DoQueryIEEEBlock(":SYSTem:SETup?")
nLength = ResultsArray.Length

' Write setup string to file.
strPath = "c:\scope\config\setup.stp"
fStream = File.Open(strPath, FileMode.Create)
fStream.Write(ResultsArray, 0, nLength)
fStream.Close()
Console.WriteLine("Setup bytes saved: {0}", nLength)

' Change settings with individual commands:

' Set vertical scale and offset.
myScope.DoCommand(":CHANnel1:SCALe 0.05")
Console.WriteLine("Channel 1 vertical scale: {0}", _
    myScope.DoQueryString(":CHANnel1:SCALe?"))

myScope.DoCommand(":CHANnel1:OFFSet -1.5")
Console.WriteLine("Channel 1 vertical offset: {0}", _
    myScope.DoQueryString(":CHANnel1:OFFSet?"))

' Set horizontal scale and offset.
myScope.DoCommand(":TIMEbase:SCALe 0.0002")
Console.WriteLine("Timebase scale: {0}", _
    myScope.DoQueryString(":TIMEbase:SCALe?"))

myScope.DoCommand(":TIMEbase:POSition 0.0")
Console.WriteLine("Timebase position: {0}", _
    myScope.DoQueryString(":TIMEbase:POSition?"))

' Set the acquisition type (NORMal, PEAK, AVERAge, or HRESolution)

myScope.DoCommand(":ACQuire:TYPE NORMal")
Console.WriteLine("Acquire type: {0}", _
    myScope.DoQueryString(":ACQuire:TYPE?"))

' Or, configure by loading a previously saved setup.
Dim dataArray As Byte()
Dim nBytesWritten As Integer

' Read setup string from file.

```



```

strPath = "c:\scope\config\setup.stp"
dataArray = File.ReadAllBytes(strPath)
nBytesWritten = dataArray.Length

' Restore setup string.
myScope.DoCommandIEEEBlock(":SYSTem:SETup", dataArray)
Console.WriteLine("Setup bytes restored: {0}", nBytesWritten)

' Capture an acquisition using :DIGitize.
myScope.DoCommand(":DIGitize CHANnel1")

End Sub

' Analyze the captured waveform.
' -----

Private Shared Sub Analyze()

    Dim fResult As Double
    Dim ResultsArray As Byte() ' Results array.
    Dim nLength As Integer ' Number of bytes returned from inst.
    Dim strPath As String

    ' Make a couple of measurements.
    ' -----
    myScope.DoCommand(":MEASure:SOURce CHANnel1")
    Console.WriteLine("Measure source: {0}", _
        myScope.DoQueryString(":MEASure:SOURce?"))

    myScope.DoCommand(":MEASure:FREQuency")
    fResult = myScope.DoQueryNumber(":MEASure:FREQuency?")
    Console.WriteLine("Frequency: {0:F4} kHz", fResult / 1000)

    myScope.DoCommand(":MEASure:VAMPlitude")
    fResult = myScope.DoQueryNumber(":MEASure:VAMPlitude?")
    Console.WriteLine("Vertical amplitude: {0:F2} V", fResult)

    ' Download the screen image.
    ' -----
    myScope.DoCommand(":HARDcopy:INKSaver OFF")

    ' Get the screen data.
    ResultsArray = myScope.DoQueryIEEEBlock(":DISPlay:DATA? PNG, COLor
")
    nLength = ResultsArray.Length

    ' Store the screen data to a file.
    strPath = "c:\scope\data\screen.png"
    Dim fStream As FileStream
    fStream = File.Open(strPath, FileMode.Create)
    fStream.Write(ResultsArray, 0, nLength)
    fStream.Close()
    Console.WriteLine("Screen image ({0} bytes) written to {1}", _
        nLength, strPath)

    ' Download waveform data.
    ' -----

```

```

' Set the waveform points mode.
myScope.DoCommand(":WAVEform:POINTs:MODE RAW")
Console.WriteLine("Waveform points mode: {0}", _
    myScope.DoQueryString(":WAVEform:POINTs:MODE?"))

' Get the number of waveform points available.
Console.WriteLine("Waveform points available: {0}", _
    myScope.DoQueryString(":WAVEform:POINTs?"))

' Set the waveform source.
myScope.DoCommand(":WAVEform:SOURce CHANnel")
Console.WriteLine("Waveform source: {0}", _
    myScope.DoQueryString(":WAVEform:SOURce?"))

' Choose the format of the data returned (WORD, BYTE, ASCII):
myScope.DoCommand(":WAVEform:FORMat BYTE")
Console.WriteLine("Waveform format: {0}", _
    myScope.DoQueryString(":WAVEform:FORMat?"))

' Display the waveform settings:
Dim fResultsArray As Double()
fResultsArray = myScope.DoQueryNumbers(":WAVEform:PREamble?")

Dim fFormat As Double = fResultsArray(0)
If fFormat = 0 Then
    Console.WriteLine("Waveform format: BYTE")
ElseIf fFormat = 1 Then
    Console.WriteLine("Waveform format: WORD")
ElseIf fFormat = 2 Then
    Console.WriteLine("Waveform format: ASCii")
End If

Dim fType As Double = fResultsArray(1)
If fType = 0 Then
    Console.WriteLine("Acquire type: NORMAl")
ElseIf fType = 1 Then
    Console.WriteLine("Acquire type: PEAK")
ElseIf fType = 2 Then
    Console.WriteLine("Acquire type: AVERAge")
ElseIf fType = 3 Then
    Console.WriteLine("Acquire type: HRESolution")
End If

Dim fPoints As Double = fResultsArray(2)
Console.WriteLine("Waveform points: {0:e}", fPoints)

Dim fCount As Double = fResultsArray(3)
Console.WriteLine("Waveform average count: {0:e}", fCount)

Dim fXincrement As Double = fResultsArray(4)
Console.WriteLine("Waveform X increment: {0:e}", fXincrement)

Dim fXorigin As Double = fResultsArray(5)
Console.WriteLine("Waveform X origin: {0:e}", fXorigin)

Dim fXreference As Double = fResultsArray(6)

```

```

Console.WriteLine("Waveform X reference: {0:e}", fXreference)

Dim fYincrement As Double = fResultsArray(7)
Console.WriteLine("Waveform Y increment: {0:e}", fYincrement)

Dim fYorigin As Double = fResultsArray(8)
Console.WriteLine("Waveform Y origin: {0:e}", fYorigin)

Dim fYreference As Double = fResultsArray(9)
Console.WriteLine("Waveform Y reference: {0:e}", fYreference)

' Get the waveform data.
ResultsArray = myScope.DoQueryIEEEBlock(":WAVEform:DATA?")
nLength = ResultsArray.Length
Console.WriteLine("Number of data values: {0}", nLength)

' Set up output file:
strPath = "c:\scope\data\waveform_data.csv"
If File.Exists(strPath) Then
    File.Delete(strPath)
End If

' Open file for output.
Dim writer As StreamWriter = File.CreateText(strPath)

' Output waveform data in CSV format.
For index As Integer = 0 To nLength - 1
    ' Write time value, voltage value.
    writer.WriteLine("{0:f9}, {1:f6}", _
        fXorigin + (CSng(index) * fXincrement), _
        ((CSng(ResultsArray(index)) - fYreference) _
        * fYincrement) + fYorigin)
Next

' Close output file.
writer.Close()
Console.WriteLine("Waveform format BYTE data written to {0}", _
    strPath)

End Sub

End Class

Class VisaComInstrument
Private m_ResourceManager As ResourceManagerClass
Private m_IOException As FormattedIO488Class
Private m_strVisaAddress As String

' Constructor.
Public Sub New(ByVal strVisaAddress As String)

    ' Save VISA address in member variable.
    m_strVisaAddress = strVisaAddress

    ' Open the default VISA COM IO object.
    OpenIo()

```

```

    ' Clear the interface.
    m_IoObject.IO.Clear()

End Sub

Public Sub DoCommand(ByVal strCommand As String)

    ' Send the command.
    m_IoObject.WriteString(strCommand, True)

    ' Check for inst errors.
    CheckInstrumentErrors(strCommand)

End Sub

Public Sub DoCommandIEEEBlock(ByVal strCommand As String, _
    ByVal dataArray As Byte())

    ' Send the command to the device.
    m_IoObject.WriteIEEEBlock(strCommand, dataArray, True)

    ' Check for inst errors.
    CheckInstrumentErrors(strCommand)

End Sub

Public Function DoQueryString(ByVal strQuery As String) As String
    ' Send the query.
    m_IoObject.WriteString(strQuery, True)

    ' Get the result string.
    Dim strResults As String
    strResults = m_IoObject.ReadString()

    ' Check for inst errors.
    CheckInstrumentErrors(strQuery)

    ' Return results string.
    Return strResults
End Function

Public Function DoQueryNumber(ByVal strQuery As String) As Double
    ' Send the query.
    m_IoObject.WriteString(strQuery, True)

    ' Get the result number.
    Dim fResult As Double
    fResult = _
        CDb1(m_IoObject.ReadNumber(IEEEASCIIType.ASCIIType_R8, True))

    ' Check for inst errors.
    CheckInstrumentErrors(strQuery)

    ' Return result number.
    Return fResult
End Function

```

```

Public Function DoQueryNumbers(ByVal strQuery As String) As _
    Double()
    ' Send the query.
    m_JsonObject.WriteString(strQuery, True)

    ' Get the result numbers.
    Dim fResultsArray As Double()
    fResultsArray = _
        m_JsonObject.ReadList(IEEEASCIIType.ASCIIType_R8, ",;")

    ' Check for inst errors.
    CheckInstrumentErrors(strQuery)

    ' Return result numbers.
    Return fResultsArray
End Function

Public _
    Function DoQueryIEEEBlock(ByVal strQuery As String) As Byte()
    ' Send the query.
    m_JsonObject.WriteString(strQuery, True)

    ' Get the results array.
    System.Threading.Thread.Sleep(2000) ' Delay before reading data.
    Dim ResultsArray As Byte()
    ResultsArray = _
        m_JsonObject.ReadIEEEBlock(IEEEBinaryType.BinaryType_UI1, _
            False, True)

    ' Check for inst errors.
    CheckInstrumentErrors(strQuery)

    ' Return results array.
    Return ResultsArray
End Function

Private Sub CheckInstrumentErrors(ByVal strCommand As String)
    ' Check for instrument errors.
    Dim strInstrumentError As String
    Dim bFirstError As Boolean = True
    Do ' While not "0,No error".
        m_JsonObject.WriteString(":SYSTem:ERRor?", True)
        strInstrumentError = m_JsonObject.ReadString()

        If Not strInstrumentError.ToString().StartsWith("+0,") Then
            If bFirstError Then
                Console.WriteLine("ERROR(s) for command '{0}': ", _
                    strCommand)
                bFirstError = False
            End If
            Console.WriteLine(strInstrumentError)
        End If
    Loop While Not strInstrumentError.ToString().StartsWith("+0,")
End Sub

Private Sub OpenIo()
    m_ResourceManager = New ResourceManagerClass()

```

```

    m_IoObject = New FormattedIO488Class()

    ' Open the default VISA COM IO object.
    Try
        m_IoObject.IO = _
            DirectCast(m_ResourceManager.Open(m_strVisaAddress, _
                AccessMode.NO_LOCK, 0, ""), IMessage)
    Catch e As Exception
        Console.WriteLine("An error occurred: {0}", e.Message)
    End Try
End Sub

Public Sub SetTimeoutSeconds(ByVal nSeconds As Integer)
    m_IoObject.IO.Timeout = nSeconds * 1000
End Sub

Public Sub Close()
    Try
        m_IoObject.IO.Close()
    Catch
    End Try

    Try
        Marshal.ReleaseComObject(m_IoObject)
    Catch
    End Try

    Try
        Marshal.ReleaseComObject(m_ResourceManager)
    Catch
    End Try
End Sub
End Class
End Namespace

```

VISA COM Example in Python

You can use the Python programming language with the "comtypes" package to control Keysight oscilloscopes.

The Python language and "comtypes" package can be downloaded from the web at <http://www.python.org/> and <https://pypi.org/project/comtypes/>, respectively.

To run this example with Python and "comtypes":

- 1 Cut-and-paste the code that follows into a file named "example.py".
- 2 Edit the program to use the VISA address of your oscilloscope.
- 3 If "python.exe" can be found via your PATH environment variable, open a Command Prompt window; then, change to the folder that contains the "example.py" file, and enter:

```

python example.py

#!python3
# -*- coding: utf-8 -*-

```

```

# Keysight VISA COM Example in Python using "comtypes"
# *****
# This program illustrates a few commonly-used programming
# features of your Keysight oscilloscope.
# *****

# Import Python modules.
# -----
import sys
import array

from comtypes.client import GetModule
from comtypes.client import CreateObject

# Run GetModule once to generate comtypes.gen.VisaComLib.
if not hasattr(sys, "frozen"):
    GetModule("C:\Program Files (x86)\IVI Foundation\VISA\VisaCom\
GlobMgr.dll")

import comtypes.gen.VisaComLib as VisaComLib

# Global variables.
# -----
# input_channel = "CHANnel1"
input_channel = "CHANnel2"
setup_file_name = "setup.scp"
screen_image_file_name = "screen_image.png"
waveform_data_file_name = "waveform_data.csv"
# wfm_fmt = "BYTE"
wfm_fmt = "WORD"

# =====
# Initialize:
# =====
def initialize():

    # Get and display the device's *IDN? string.
    idn_string = do_query_string("*IDN?")
    print(f"Identification string: '{idn_string}'")

    # Clear status and load the default setup.
    do_command("*CLS")
    do_command("*RST")

# =====
# Capture:
# =====
def capture():

    # Use auto-scale to automatically set up oscilloscope.
    print("Autoscale.")
    do_command(":AUToscale")

```

```

# Set trigger mode.
do_command(":TRIGger:MODE EDGE")
qresult = do_query_string(":TRIGger:MODE?")
print(f"Trigger mode: {qresult}")

# Set EDGE trigger parameters.
do_command(f":TRIGger:EDGE:SOURce {input_channel}")
qresult = do_query_string(":TRIGger:EDGE:SOURce?")
print(f"Trigger edge source: {qresult}")

do_command(":TRIGger:EDGE:LEVel 1.5")
qresult = do_query_string(":TRIGger:EDGE:LEVel?")
print(f"Trigger edge level: {qresult}")

do_command(":TRIGger:EDGE:SLOPe POSitive")
qresult = do_query_string(":TRIGger:EDGE:SLOPe?")
print(f"Trigger edge slope: {qresult}")

# Save oscilloscope setup.
setup_bytes = do_query_ieee_block(":SYSTem:SETup?")
setup_bytes_length = len(setup_bytes)
f = open(setup_file_name, "wb")
f.write(bytearray(setup_bytes))
f.close()
print(f"Setup bytes saved: {setup_bytes_length}")

# Change oscilloscope settings with individual commands:

# Set vertical scale and offset.
do_command(f":{input_channel}:SCALE 0.05")
qresult = do_query_string(f":{input_channel}:SCALE?")
print(f"{input_channel} vertical scale: {qresult}")

do_command(f":{input_channel}:OFFSet -1.5")
qresult = do_query_string(f":{input_channel}:OFFSet?")
print(f"{input_channel} offset: {qresult}")

# Set horizontal scale and offset.
do_command(":TIMEbase:SCALE 0.0002")
qresult = do_query_string(":TIMEbase:SCALE?")
print(f"Timebase scale: {qresult}")

do_command(":TIMEbase:POSition 0.0")
qresult = do_query_string(":TIMEbase:POSition?")
print(f"Timebase position: {qresult}")

# Set the acquisition type.
do_command(":ACQuire:TYPE NORMal")
qresult = do_query_string(":ACQuire:TYPE?")
print(f"Acquire type: {qresult}")

# Or, set up oscilloscope by loading a previously saved setup.
f = open(setup_file_name, "rb")
setup_bytes = f.read()
f.close()
do_command_ieee_block(":SYSTem:SETup", array.array('B', setup_bytes))
print(f"Setup bytes restored: {len(setup_bytes)}")

```



```

# Capture an acquisition using :DIGitize.
do_command(f":DIGitize {input_channel}")

# =====
# Analyze:
# =====
def analyze():

    # Make measurements.
    # -----
    do_command(f":MEASure:SOURce {input_channel}")
    qresult = do_query_string(":MEASure:SOURce?")
    print(f"Measure source: {qresult}")

    do_command(":MEASure:FREQuency")
    qresult = do_query_string(":MEASure:FREQuency?")
    print(f"Measured frequency on {input_channel}: {qresult}")

    do_command(":MEASure:VAMPlitude")
    qresult = do_query_string(":MEASure:VAMPlitude?")
    print(f"Measured vertical amplitude on {input_channel}: {qresult}")

    # Download the screen image.
    # -----
    do_command(":HARDcopy:INKSaver OFF")

    screen_bytes = do_query_ieee_block(":DISPlay:DATA? PNG, COLor")

    # Save display data values to file.
    f = open(screen_image_file_name, "wb")
    f.write(bytearray(screen_bytes))
    f.close()
    print(f"Screen image written to {screen_image_file_name}.")

    # Download waveform data.
    # -----

    # Set the waveform source.
    do_command(f":WAVEform:SOURce {input_channel}")
    qresult = do_query_string(":WAVEform:SOURce?")
    print(f"Waveform source: {qresult}")

    # Set the waveform points mode.
    do_command(":WAVEform:POINts:MODE RAW")
    qresult = do_query_string(":WAVEform:POINts:MODE?")
    print(f"Waveform points mode: {qresult}")

    # Get the number of waveform points available.
    do_command(":WAVEform:POINts 10240")
    qresult = do_query_string(":WAVEform:POINts?")
    print(f"Waveform points available: {qresult}")

    # Choose the format of the data returned (BYTE or WORD):
    do_command(f":WAVEform:FORMat {wfm_fmt}")
    qresult = do_query_string(":WAVEform:FORMat?")

```

```

print(f"Waveform format: {qresult}")

# Display the waveform settings from preamble:
wav_form_dict = {
    0 : "BYTE",
    1 : "WORD",
    4 : "AScii",
}
acq_type_dict = {
    0 : "NORMal",
    1 : "PEAK",
    2 : "AVERage",
    3 : "HRESolution",
}

(
    wav_form,
    acq_type,
    wfmpnts,
    avgcnt,
    x_increment,
    x_origin,
    x_reference,
    y_increment,
    y_origin,
    y_reference
) = do_query_numbers(":WAVEform:PREamble?")

print(f"Waveform format: {wav_form_dict[int(wav_form)]}")
print(f"Acquire type: {acq_type_dict[int(acq_type)]}")
print(f"Waveform points desired: {wfmpnts}")
print(f"Waveform average count: {avgcnt}")
print(f"Waveform X reference: {x_reference}") # Always 0.

# Get numeric values for later calculations.
x_increment = do_query_number(":WAVEform:XINCrement?")
print(f"Waveform X increment: {x_increment}")
x_origin = do_query_number(":WAVEform:XORigin?")
print(f"Waveform X origin: {x_origin}")
y_increment = do_query_number(":WAVEform:YINCrement?")
print(f"Waveform Y increment: {y_increment}")
y_origin = do_query_number(":WAVEform:YORigin?")
print(f"Waveform Y origin: {y_origin}")
y_reference = do_query_number(":WAVEform:YREFerence?")
print(f"Waveform Y reference: {y_reference}")

# Specify the byte order in WORD data.
if wfm_fmt == "WORD":
    do_command(":WAVEform:BYTeorder LSBF")
    qresult = do_query_string(":WAVEform:BYTeorder?")
    print(f"Waveform byte order for WORD data: {qresult}")

# Get the waveform data bytes.
data_bytes = do_query_ieee_block(":WAVEform:DATA?")
data_bytes_length = len(data_bytes)
print(f"Byte count: {data_bytes_length}")

```

```

# Get the waveform data values.
if wfm_fmt == "BYTE":
    values = data_bytes
elif wfm_fmt == "WORD":
    data_bytes_array = array.array('B', data_bytes) # Array of unsigned
bytes.
    values = array.array('H') # Interpret as array of unsigned shorts.
    values.frombytes(data_bytes_array)
print(f"Number of data values: {len(values)}")

# Save waveform data values to CSV file.
f = open(waveform_data_file_name, "w")

for i in range(0, len(values) - 1):
    time_val = x_origin + (i * x_increment)
    voltage = ((values[i] - y_reference) * y_increment) + y_origin
    f.write(f"{time_val:E}, {voltage:f}\n")

# Close output file.
f.close()
print(f"Waveform format {wfm_fmt} data written to {waveform_data_file_n
ame}.")

# =====
# Send a command and check for errors:
# =====
def do_command(command):
    myScope.WriteString(f"{command}", True)
    check_instrument_errors(command)

# =====
# Send a command and check for errors:
# =====
def do_command_ieee_block(command, data):
    myScope.WriteIEEEBlock(command, data, True)
    check_instrument_errors(command)

# =====
# Send a query, check for errors, return string:
# =====
def do_query_string(query):
    myScope.WriteString(f"{query}", True)
    result = myScope.ReadString()
    check_instrument_errors(query)
    return result.strip()

# =====
# Send a query, check for errors, return string:
# =====
def do_query_ieee_block(query):
    myScope.WriteString(f"{query}", True)
    result = myScope.ReadIEEEBlock(VisaComLib.BinaryType_UI1, \
        False, True)

```

```

    check_instrument_errors(query)
    return result

# =====
# Send a query, check for errors, return values:
# =====
def do_query_number(query):
    myScope.WriteString(f"{query}", True)
    result = myScope.ReadNumber(VisaComLib.ASCIIType_R8, True)
    check_instrument_errors(query)
    return result

# =====
# Send a query, check for errors, return values:
# =====
def do_query_numbers(query):
    myScope.WriteString(f"{query}", True)
    result = myScope.ReadList(VisaComLib.ASCIIType_R8, ",;")
    check_instrument_errors(query)
    return result

# =====
# Check for instrument errors:
# =====
def check_instrument_errors(command):

    while True:
        myScope.WriteString(":SYSTem:ERRor?", True)
        error_string = myScope.ReadString()
        if error_string: # If there is an error string value.

            if error_string.find("+0,", 0, 3) == -1: # Not "No error".
                print(f"ERROR: {error_string}, command: '{command}'")
                print("Exited because of error.")
                sys.exit(1)

            else: # "No error"
                break

        else: # :SYSTem:ERRor? should always return string.
            print("ERROR: :SYSTem:ERRor? returned nothing, command: '%s' \
                % command)
            print("Exited because of error.")
            sys.exit(1)

# =====
# Main program:
# =====
rm = CreateObject("VISA.GlobalRM", \
    interface=VisaComLib.IResourceManager)
myScope = CreateObject("VISA.BasicFormattedIO", \
    interface=VisaComLib.IFormattedIO488)
myScope.IO = \

```

```
rm.Open("TCPIP0::k-mx3104g-10104.cos.is.keysight.com::inst0::INSTR")

# Clear the interface.
myScope.IO.Clear()
print("Interface cleared.")

# Set the Timeout to 15 seconds.
myScope.IO.Timeout = 15000 # 15 seconds.
print("Timeout set to 15000 milliseconds.")

# Initialize the oscilloscope, capture data, and analyze.
initialize()
capture()
analyze()

myScope.IO.Close()
print("End of program.")
sys.exit()
```

VISA Examples

- ["VISA Example in C"](#) on page 1774
- ["VISA Example in Visual Basic"](#) on page 1783
- ["VISA Example in C#"](#) on page 1793
- ["VISA Example in Visual Basic .NET"](#) on page 1804
- ["VISA Example in Python"](#) on page 1814

VISA Example in C

To compile and run this example in Microsoft Visual Studio 2008:

- 1 Open Visual Studio.
- 2 Create a new Visual C++, Win32, Win32 Console Application project.
- 3 In the Win32 Application Wizard, click **Next >**. Then, check **Empty project**, and click **Finish**.
- 4 Cut-and-paste the code that follows into a file named "example.c" in the project directory.
- 5 In Visual Studio 2008, right-click the Source Files folder, choose **Add > Add Existing Item...**, select the example.c file, and click **Add**.
- 6 Edit the program to use the VISA address of your oscilloscope.
- 7 Choose **Project > Properties....** In the Property Pages dialog, update these project settings:
 - a Under Configuration Properties, Linker, Input, add "visa32.lib" to the Additional Dependencies field.
 - b Under Configuration Properties, C/C++, Code Generation, select Multi-threaded DLL for the Runtime Library field.
 - c Click **OK** to close the Property Pages dialog.
- 8 Add the include files and library files search paths:
 - a Choose **Tools > Options....**
 - b In the Options dialog, under Projects and Solutions, select **VC++ Directories**.
 - c Show directories for **Include files**, and add the include directory (for example, Program Files (x86)\IVI Foundation\VISA\WinNT\Include).
 - d Show directories for **Library files**, and add the library files directory (for example, Program Files (x86)\IVI Foundation\VISA\WinNT\lib\msc).
 - e Click **OK** to close the Options dialog.
- 9 Build and run the program.

```
/*
 * Keysight VISA Example in C
 * -----
```

```

* This program illustrates a few commonly-used programming
* features of your Keysight oscilloscope.
*/

#include <stdio.h>           /* For printf(). */
#include <string.h>         /* For strcpy(), strcat(). */
#include <time.h>           /* For clock(). */
#include <visa.h>           /* Keysight VISA routines. */

#define VISA_ADDRESS "USB0::0x0957::0x17A6::US50210029::0::INSTR"
#define IEEEEBLOCK_SPACE 500000

/* Function prototypes */
void initialize(void);      /* Initialize to known state. */
void capture(void);        /* Capture the waveform. */
void analyze(void);        /* Analyze the captured waveform. */

void do_command(char *command); /* Send command. */
int do_command_ieeeblock(char *command); /* Command w/IEEE block. */
void do_query_string(char *query); /* Query for string. */
void do_query_number(char *query); /* Query for number. */
void do_query_numbers(char *query); /* Query for numbers. */
int do_query_ieeeblock(char *query); /* Query for IEEE block. */
void check_instrument_errors(); /* Check for inst errors. */
void error_handler(); /* VISA error handler. */

/* Global variables */
ViSession defaultRM, vi; /* Device session ID. */
ViStatus err; /* VISA function return value. */
char str_result[256] = {0}; /* Result from do_query_string(). */
double num_result; /* Result from do_query_number(). */
unsigned char ieeeblock_data[IEEEBLOCK_SPACE]; /* Result from
do_query_ieeeblock(). */
double dbl_results[10]; /* Result from do_query_numbers(). */

/* Main Program
* ----- */
void main(void)
{
    /* Open the default resource manager session. */
    err = viOpenDefaultRM(&defaultRM);
    if (err != VI_SUCCESS) error_handler();

    /* Open the session using the oscilloscope's VISA address. */
    err = viOpen(defaultRM, VISA_ADDRESS, VI_NULL, VI_NULL, &vi);
    if (err != VI_SUCCESS) error_handler();

    /* Set the I/O timeout to fifteen seconds. */
    err = viSetAttribute(vi, VI_ATTR_TMO_VALUE, 15000);
    if (err != VI_SUCCESS) error_handler();

    /* Initialize - start from a known state. */
    initialize();

    /* Capture data. */
    capture();
}

```

```

    /* Analyze the captured waveform. */
    analyze();

    /* Close the vi session and the resource manager session. */
    viClose(vi);
    viClose(defaultRM);
}

/* Initialize the oscilloscope to a known state.
 * ----- */
void initialize (void)
{
    /* Clear the interface. */
    err = viClear(vi);
    if (err != VI_SUCCESS) error_handler();

    /* Get and display the device's *IDN? string. */
    do_query_string("*IDN?");
    printf("Oscilloscope *IDN? string: %s\n", str_result);

    /* Clear status and load the default setup. */
    do_command("*CLS");
    do_command("*RST");
}

/* Capture the waveform.
 * ----- */
void capture (void)
{
    int num_bytes;
    FILE *fp;

    /* Use auto-scale to automatically configure oscilloscope. */
    do_command(":AUToscale");

    /* Set trigger mode (EDGE, PULSe, PATtern, etc., and input source. */
    do_command(":TRIGger:MODE EDGE");
    do_query_string(":TRIGger:MODE?");
    printf("Trigger mode: %s\n", str_result);

    /* Set EDGE trigger parameters. */
    do_command(":TRIGger:EDGE:SOURce CHANnel1");
    do_query_string(":TRIGger:EDGE:SOURce?");
    printf("Trigger edge source: %s\n", str_result);

    do_command(":TRIGger:EDGE:LEVel 1.5");
    do_query_string(":TRIGger:EDGE:LEVel?");
    printf("Trigger edge level: %s\n", str_result);

    do_command(":TRIGger:EDGE:SLOPe POSitive");
    do_query_string(":TRIGger:EDGE:SLOPe?");
    printf("Trigger edge slope: %s\n", str_result);

    /* Save oscilloscope configuration. */

    /* Read system setup. */
    num_bytes = do_query_ieeeblock(":SYSTem:SETup?");

```



```

printf("Read setup string query (%d bytes).\n", num_bytes);

/* Write setup string to file. */
fp = fopen ("c:\\scope\\config\\setup.stp", "wb");
num_bytes = fwrite(ieeeblock_data, sizeof(unsigned char), num_bytes,
    fp);
fclose (fp);
printf("Wrote setup string (%d bytes) to ", num_bytes);
printf("c:\\scope\\config\\setup.stp.\n");

/* Change settings with individual commands:

/* Set vertical scale and offset. */
do_command(":CHANnel1:SCALE 0.05");
do_query_string(":CHANnel1:SCALE?");
printf("Channel 1 vertical scale: %s\n", str_result);

do_command(":CHANnel1:OFFSet -1.5");
do_query_string(":CHANnel1:OFFSet?");
printf("Channel 1 offset: %s\n", str_result);

/* Set horizontal scale and offset. */
do_command(":TIMEbase:SCALE 0.0002");
do_query_string(":TIMEbase:SCALE?");
printf("Timebase scale: %s\n", str_result);

do_command(":TIMEbase:POSition 0.0");
do_query_string(":TIMEbase:POSition?");
printf("Timebase position: %s\n", str_result);

/* Set the acquisition type (NORMAL, PEAK, AVERAGE, or HRESOLUTION). *
/
do_command(":ACquire:TYPE NORMAL");
do_query_string(":ACquire:TYPE?");
printf("Acquire type: %s\n", str_result);

/* Or, configure by loading a previously saved setup. */

/* Read setup string from file. */
fp = fopen ("c:\\scope\\config\\setup.stp", "rb");
num_bytes = fread (ieeeblock_data, sizeof(unsigned char),
    IEEEBLOCK_SPACE, fp);
fclose (fp);
printf("Read setup string (%d bytes) from file ", num_bytes);
printf("c:\\scope\\config\\setup.stp.\n");

/* Restore setup string. */
num_bytes = do_command_ieeeblock(":SYSTEM:SETup", num_bytes);
printf("Restored setup string (%d bytes).\n", num_bytes);

/* Capture an acquisition using :DIGitize. */
do_command(":DIGitize CHANnel1");
}

/* Analyze the captured waveform.
* ----- */
void analyze (void)

```

```

{
double wav_format;
double acq_type;
double wav_points;
double avg_count;
double x_increment;
double x_origin;
double x_reference;
double y_increment;
double y_origin;
double y_reference;

FILE *fp;
int num_bytes; /* Number of bytes returned from instrument. */
int i;

/* Make a couple of measurements.
 * ----- */
do_command(":MEASure:SOURce CHANnel1");
do_query_string(":MEASure:SOURce?");
printf("Measure source: %s\n", str_result);

do_command(":MEASure:FREQuency");
do_query_number(":MEASure:FREQuency?");
printf("Frequency: %.4f kHz\n", num_result / 1000);

do_command(":MEASure:VAMPlitude");
do_query_number(":MEASure:VAMPlitude?");
printf("Vertical amplitude: %.2f V\n", num_result);

/* Download the screen image.
 * ----- */
do_command(":HARDcopy:INKSaver OFF");

/* Read screen image. */
num_bytes = do_query_ieeeblock(":DISPlay:DATA? PNG, COLor");
printf("Screen image bytes: %d\n", num_bytes);

/* Write screen image bytes to file. */
fp = fopen("c:\\scope\\data\\screen.png", "wb");
num_bytes = fwrite(ieeeblock_data, sizeof(unsigned char), num_bytes,
fp);
fclose(fp);
printf("Wrote screen image (%d bytes) to ", num_bytes);
printf("c:\\scope\\data\\screen.png.\n");

/* Download waveform data.
 * ----- */

/* Set the waveform points mode. */
do_command(":WAVEform:POINTs:MODE RAW");
do_query_string(":WAVEform:POINTs:MODE?");
printf("Waveform points mode: %s\n", str_result);

/* Get the number of waveform points available. */
do_query_string(":WAVEform:POINTs?");
printf("Waveform points available: %s\n", str_result);

```

```

/* Set the waveform source. */
do_command(":WAVEform:SOURce CHANnel1");
do_query_string(":WAVEform:SOURce?");
printf("Waveform source: %s\n", str_result);

/* Choose the format of the data returned (WORD, BYTE, ASCII): */
do_command(":WAVEform:FORMat BYTE");
do_query_string(":WAVEform:FORMat?");
printf("Waveform format: %s\n", str_result);

/* Display the waveform settings: */
do_query_numbers(":WAVEform:PREAmble?");

wav_format = dbl_results[0];
if (wav_format == 0.0)
{
    printf("Waveform format: BYTE\n");
}
else if (wav_format == 1.0)
{
    printf("Waveform format: WORD\n");
}
else if (wav_format == 2.0)
{
    printf("Waveform format: ASCii\n");
}

acq_type = dbl_results[1];
if (acq_type == 0.0)
{
    printf("Acquire type: NORMal\n");
}
else if (acq_type == 1.0)
{
    printf("Acquire type: PEAK\n");
}
else if (acq_type == 2.0)
{
    printf("Acquire type: AVERage\n");
}
else if (acq_type == 3.0)
{
    printf("Acquire type: HRESolution\n");
}

wav_points = dbl_results[2];
printf("Waveform points: %e\n", wav_points);

avg_count = dbl_results[3];
printf("Waveform average count: %e\n", avg_count);

x_increment = dbl_results[4];
printf("Waveform X increment: %e\n", x_increment);

x_origin = dbl_results[5];
printf("Waveform X origin: %e\n", x_origin);

```

```

x_reference = dbl_results[6];
printf("Waveform X reference: %e\n", x_reference);

y_increment = dbl_results[7];
printf("Waveform Y increment: %e\n", y_increment);

y_origin = dbl_results[8];
printf("Waveform Y origin: %e\n", y_origin);

y_reference = dbl_results[9];
printf("Waveform Y reference: %e\n", y_reference);

/* Read waveform data. */
num_bytes = do_query_ieeeblock(":WAVEform:DATA?");
printf("Number of data values: %d\n", num_bytes);

/* Open file for output. */
fp = fopen("c:\\scope\\data\\waveform_data.csv", "wb");

/* Output waveform data in CSV format. */
for (i = 0; i < num_bytes - 1; i++)
{
    /* Write time value, voltage value. */
    fprintf(fp, "%9f, %6f\n",
        x_origin + ((float)i * x_increment),
        (((float)ieeeblock_data[i] - y_reference) * y_increment)
        + y_origin);
}

/* Close output file. */
fclose(fp);
printf("Waveform format BYTE data written to ");
printf("c:\\scope\\data\\waveform_data.csv.\n");
}

/* Send a command to the instrument.
 * ----- */
void do_command(command)
char *command;
{
    char message[80];

    strcpy(message, command);
    strcat(message, "\n");
    err = viPrintf(vi, message);
    if (err != VI_SUCCESS) error_handler();

    check_instrument_errors();
}

/* Command with IEEE definite-length block.
 * ----- */
int do_command_ieeeblock(command, num_bytes)
char *command;
int num_bytes;
{

```

```

char message[80];
int data_length;

strcpy(message, command);
strcat(message, " #8%08d");
err = viPrintf(vi, message, num_bytes);
if (err != VI_SUCCESS) error_handler();

err = viBufWrite(vi, ieeeblock_data, num_bytes, &data_length);
if (err != VI_SUCCESS) error_handler();

check_instrument_errors();

return(data_length);
}

/* Query for a string result.
 * ----- */
void do_query_string(query)
char *query;
{
    char message[80];

    strcpy(message, query);
    strcat(message, "\n");

    err = viPrintf(vi, message);
    if (err != VI_SUCCESS) error_handler();

    err = viScanf(vi, "%t", str_result);
    if (err != VI_SUCCESS) error_handler();

    check_instrument_errors();
}

/* Query for a number result.
 * ----- */
void do_query_number(query)
char *query;
{
    char message[80];

    strcpy(message, query);
    strcat(message, "\n");

    err = viPrintf(vi, message);
    if (err != VI_SUCCESS) error_handler();

    err = viScanf(vi, "%lf", &num_result);
    if (err != VI_SUCCESS) error_handler();

    check_instrument_errors();
}

/* Query for numbers result.
 * ----- */
void do_query_numbers(query)

```

```

char *query;
{
    char message[80];

    strcpy(message, query);
    strcat(message, "\n");

    err = viPrintf(vi, message);
    if (err != VI_SUCCESS) error_handler();

    err = viScanf(vi, "%,10lf\n", dbl_results);
    if (err != VI_SUCCESS) error_handler();

    check_instrument_errors();
}

/* Query for an IEEE definite-length block result.
 * ----- */
int do_query_ieeeblock(query)
char *query;
{
    char message[80];
    int data_length;

    strcpy(message, query);
    strcat(message, "\n");
    err = viPrintf(vi, message);
    if (err != VI_SUCCESS) error_handler();

    data_length = IEEEBLOCK_SPACE;
    err = viScanf(vi, "%#b\n", &data_length, ieeeblock_data);
    if (err != VI_SUCCESS) error_handler();

    if (data_length == IEEEBLOCK_SPACE )
    {
        printf("IEEE block buffer full: ");
        printf("May not have received all data.\n");
    }

    check_instrument_errors();

    return(data_length);
}

/* Check for instrument errors.
 * ----- */
void check_instrument_errors()
{
    char str_err_val[256] = {0};
    char str_out[800] = "";

    err = viQueryf(vi, ":SYSTem:ERRor?\n", "%t", str_err_val);
    if (err != VI_SUCCESS) error_handler();
    while(strncmp(str_err_val, "+0,No error", 3) != 0 )
    {
        strcat(str_out, ", ");
        strcat(str_out, str_err_val);
    }
}

```

```

    err = viQueryf(vi, ":SYSTEM:ERROR?\n", "%t", str_err_val);
    if (err != VI_SUCCESS) error_handler();
}

if (strcmp(str_out, "") != 0)
{
    printf("INST Error%s\n", str_out);
    err = viFlush(vi, VI_READ_BUF);
    if (err != VI_SUCCESS) error_handler();
    err = viFlush(vi, VI_WRITE_BUF);
    if (err != VI_SUCCESS) error_handler();
}
}

/* Handle VISA errors.
 * ----- */
void error_handler()
{
    char err_msg[1024] = {0};

    viStatusDesc(vi, err, err_msg);
    printf("VISA Error: %s\n", err_msg);
    if (err < VI_SUCCESS)
    {
        exit(1);
    }
}

```

VISA Example in Visual Basic

To run this example in Visual Basic for Applications:

- 1 Start the application that provides Visual Basic for Applications (for example, Microsoft Excel).
- 2 Press ALT+F11 to launch the Visual Basic editor.
- 3 Add the visa32.bas file to your project:
 - a Choose **File > Import File...**
 - b Navigate to the header file, visa32.bas (installed with Keysight IO Libraries Suite and found in the Program Files (x86)\IVI Foundation\VISA\WinNT\Include), select it, and click **Open**.
- 4 Choose **Insert > Module**.
- 5 Cut-and-paste the code that follows into the editor.
- 6 Edit the program to use the VISA address of your oscilloscope, and save the changes.
- 7 Run the program.

```

'
' Keysight VISA Example in Visual Basic
' -----
' This program illustrates a few commonly-used programming

```

```

' features of your Keysight oscilloscope.
' -----

Option Explicit

Public err As Long    ' Error returned by VISA function calls.
Public drm As Long    ' Session to Default Resource Manager.
Public vi As Long     ' Session to instrument.

' Declare variables to hold numeric values returned by
' viVScanf/viVQueryf.
Public dblQueryResult As Double
Public Const ByteArraySize = 5000000
Public retCount As Long
Public byteArray(ByteArraySize) As Byte
Public paramsArray(2) As Long
Public Const DblArraySize = 20
Public dblArray(DblArraySize) As Double

' Declare fixed length string variable to hold string value returned
' by viVScanf/viVQueryf.
Public strQueryResult As String * 200

' For Sleep subroutine.
Private Declare Sub Sleep Lib "kernel32" (ByVal dwMilliseconds As Long)

'
' Main Program
' -----

Sub Main()

    ' Open the default resource manager session.
    err = viOpenDefaultRM(drm)
    If (err <> VI_SUCCESS) Then HandleVISAError drm

    ' Open the session using the oscilloscope's VISA address.
    err = viOpen(drm, _
        "USB0::0x0957::0x17A6::US50210029::0::INSTR", 0, 15000, vi)
    If (err <> VI_SUCCESS) Then HandleVISAError drm

    ' Set the I/O timeout to ten seconds.
    err = viSetAttribute(vi, VI_ATTR_TMO_VALUE, 10000)
    If (err <> VI_SUCCESS) Then HandleVISAError vi

    ' Initialize - start from a known state.
    Initialize

    ' Capture data.
    Capture

    ' Analyze the captured waveform.
    Analyze

    ' Close the vi session and the resource manager session.
    err = viClose(vi)
    err = viClose(drm)

```



```

End Sub

'
' Initialize the oscilloscope to a known state.
' -----

Private Sub Initialize()

    ' Clear the interface.
    err = viClear(vi)
    If Not (err = VI_SUCCESS) Then HandleVISAError vi

    ' Get and display the device's *IDN? string.
    strQueryResult = DoQueryString("*IDN?")
    MsgBox "*IDN? string: " + strQueryResult, vbOKOnly, "*IDN? Result"

    ' Clear status and load the default setup.
    DoCommand "*CLS"
    DoCommand "*RST"

End Sub

'
' Capture the waveform.
' -----

Private Sub Capture()

    ' Use auto-scale to automatically configure oscilloscope.
    ' -----
    DoCommand ":AUToscale"

    ' Set trigger mode (EDGE, PULSe, PATtern, etc., and input source.
    DoCommand ":TRIGger:MODE EDGE"
    Debug.Print "Trigger mode: " + _
        DoQueryString(":TRIGger:MODE?")

    ' Set EDGE trigger parameters.
    DoCommand ":TRIGger:EDGE:SOURce CHANnel1"
    Debug.Print "Trigger edge source: " + _
        DoQueryString(":TRIGger:EDGE:SOURce?")

    DoCommand ":TRIGger:EDGE:LEVel 1.5"
    Debug.Print "Trigger edge level: " + _
        DoQueryString(":TRIGger:EDGE:LEVel?")

    DoCommand ":TRIGger:EDGE:SLOPe POSitive"
    Debug.Print "Trigger edge slope: " + _
        DoQueryString(":TRIGger:EDGE:SLOPe?")

    ' Save oscilloscope configuration.
    ' -----
    Dim lngSetupStringSize As Long
    lngSetupStringSize = DoQueryIEEEBlock_Bytes(":SYSTem:SETup?")
    Debug.Print "Setup bytes saved: " + CStr(lngSetupStringSize)

```

```

' Output setup string to a file:
Dim strPath As String
strPath = "c:\scope\config\setup.dat"
If Len(Dir(strPath)) Then
    Kill strPath ' Remove file if it exists.
End If

' Open file for output.
Dim hFile As Long
hFile = FreeFile
Open strPath For Binary Access Write Lock Write As hFile
Dim lngI As Long
For lngI = 0 To lngSetupStringSize - 1
    Put hFile, , byteArray(lngI) ' Write data.
Next lngI
Close hFile ' Close file.

' Change settings with individual commands:
' -----

' Set vertical scale and offset.
DoCommand ":CHANnel1:SCALE 0.05"
Debug.Print "Channel 1 vertical scale: " + _
    DoQueryString(":CHANnel1:SCALE?")

DoCommand ":CHANnel1:OFFSet -1.5"
Debug.Print "Channel 1 vertical offset: " + _
    DoQueryString(":CHANnel1:OFFSet?")

' Set horizontal scale and position.
DoCommand ":TIMEbase:SCALE 0.0002"
Debug.Print "Timebase scale: " + _
    DoQueryString(":TIMEbase:SCALE?")

DoCommand ":TIMEbase:POSition 0.0"
Debug.Print "Timebase position: " + _
    DoQueryString(":TIMEbase:POSition?")

' Set the acquisition type (NORMAL, PEAK, AVERAGE, or HRESOLUTION).
DoCommand ":ACQuire:TYPE NORMAL"
Debug.Print "Acquire type: " + _
    DoQueryString(":ACQuire:TYPE?")

' Or, configure by loading a previously saved setup.
' -----
strPath = "c:\scope\config\setup.dat"
Open strPath For Binary Access Read As hFile ' Open file for input.
Dim lngSetupFileSize As Long
lngSetupFileSize = LOF(hFile) ' Length of file.
Get hFile, , byteArray ' Read data.
Close hFile ' Close file.
' Write learn string back to oscilloscope using ":SYSTEM:SETup"
' command:
Dim lngRestored As Long
lngRestored = DoCommandIEEEBlock(":SYSTEM:SETup", lngSetupFileSize)
Debug.Print "Setup bytes restored: " + CStr(lngRestored)

```

```

' Capture an acquisition using :DIGitize.
' -----
DoCommand ":DIGitize CHANnel1"

End Sub

'
' Analyze the captured waveform.
' -----

Private Sub Analyze()

' Make a couple of measurements.
' -----
DoCommand ":MEASure:SOURce CHANnel1"
Debug.Print "Measure source: " + _
    DoQueryString(":MEASure:SOURce?")

DoCommand ":MEASure:FREQuency"
dblQueryResult = DoQueryNumber(":MEASure:FREQuency?")
MsgBox "Frequency:" + vbCrLf + _
    FormatNumber(dblQueryResult / 1000, 4) + " kHz"

DoCommand ":MEASure:VAMPlitude"
dblQueryResult = DoQueryNumber(":MEASure:VAMPlitude?")
MsgBox "Vertical amplitude:" + vbCrLf + _
    FormatNumber(dblQueryResult, 4) + " V"

' Download the screen image.
' -----
DoCommand ":HARDcopy:INKSaver OFF"

' Get screen image.
Dim lngBlockSize As Long
lngBlockSize = DoQueryIEEEBlock_Bytes(":DISPlay:DATA? PNG, COlor")
Debug.Print "Screen image bytes: " + CStr(lngBlockSize)

' Save screen image to a file:
Dim strPath As String
strPath = "c:\scope\data\screen.png"
If Len(Dir(strPath)) Then
    Kill strPath ' Remove file if it exists.
End If
Dim hFile As Long
hFile = FreeFile
Open strPath For Binary Access Write Lock Write As hFile
Dim lngI As Long
For lngI = 0 To lngBlockSize - 1
    Put hFile, , byteArray(lngI) ' Write data.
Next lngI
Close hFile ' Close file.
MsgBox "Screen image written to " + strPath

' Download waveform data.
' -----

```

```

' Set the waveform points mode.
DoCommand ":WAVEform:POINTs:MODE RAW"
Debug.Print "Waveform points mode: " + _
    DoQueryString(":WAVEform:POINTs:MODE?")

' Get the number of waveform points available.
Debug.Print "Waveform points available: " + _
    DoQueryString(":WAVEform:POINTs?")

' Set the waveform source.
DoCommand ":WAVEform:SOURce CHANnel1"
Debug.Print "Waveform source: " + _
    DoQueryString(":WAVEform:SOURce?")

' Choose the format of the data returned (WORD, BYTE, ASCII):
DoCommand ":WAVEform:FORMat BYTE"
Debug.Print "Waveform format: " + _
    DoQueryString(":WAVEform:FORMat?")

' Display the waveform settings:
Dim intFormat As Integer
Dim intType As Integer
Dim lngPoints As Long
Dim lngCount As Long
Dim dblXIncrement As Double
Dim dblXOrigin As Double
Dim lngXReference As Long
Dim sngYIncrement As Single
Dim lngYOrigin As Long
Dim lngYReference As Long
Dim strOutput As String

Dim lngNumNumbers As Long
lngNumNumbers = DoQueryNumbers(":WAVEform:PREamble?")

intFormat = dblArray(0)
intType = dblArray(1)
lngPoints = dblArray(2)
lngCount = dblArray(3)
dblXIncrement = dblArray(4)
dblXOrigin = dblArray(5)
lngXReference = dblArray(6)
sngYIncrement = dblArray(7)
lngYOrigin = dblArray(8)
lngYReference = dblArray(9)

If intFormat = 0 Then
    Debug.Print "Waveform format: BYTE"
ElseIf intFormat = 1 Then
    Debug.Print "Waveform format: WORD"
ElseIf intFormat = 2 Then
    Debug.Print "Waveform format: ASCii"
End If

If intType = 0 Then
    Debug.Print "Acquisition type: NORMal"

```

```

ElseIf intType = 1 Then
    Debug.Print "Acquisition type: PEAK"
ElseIf intType = 2 Then
    Debug.Print "Acquisition type: AVERage"
ElseIf intType = 3 Then
    Debug.Print "Acquisition type: HRESolution"
End If

Debug.Print "Waveform points: " + _
    FormatNumber(lngPoints, 0)

Debug.Print "Waveform average count: " + _
    FormatNumber(lngCount, 0)

Debug.Print "Waveform X increment: " + _
    Format(dblXIncrement, "Scientific")

Debug.Print "Waveform X origin: " + _
    Format(dblXOrigin, "Scientific")

Debug.Print "Waveform X reference: " + _
    FormatNumber(lngXReference, 0)

Debug.Print "Waveform Y increment: " + _
    Format(sngYIncrement, "Scientific")

Debug.Print "Waveform Y origin: " + _
    FormatNumber(lngYOrigin, 0)

Debug.Print "Waveform Y reference: " + _
    FormatNumber(lngYReference, 0)

' Get the waveform data
Dim lngNumBytes As Long
lngNumBytes = DoQueryIEEEBlock_Bytes(":WAVEform:DATA?")
Debug.Print "Number of data values: " + CStr(lngNumBytes)

' Set up output file:
strPath = "c:\scope\data\waveform_data.csv"

' Open file for output.
Open strPath For Output Access Write Lock Write As hFile

' Output waveform data in CSV format.
Dim lngDataValue As Long

For lngI = 0 To lngNumBytes - 1
    lngDataValue = CLng(byteArray(lngI))

    ' Write time value, voltage value.
    Print #hFile, _
        FormatNumber(dblXOrigin + (lngI * dblXIncrement), 9) + _
        ", " + _
        FormatNumber(((lngDataValue - lngYReference) _
            * sngYIncrement) + lngYOrigin)
Next lngI

```

```

    ' Close output file.
    Close hFile ' Close file.
    MsgBox "Waveform format BYTE data written to " + _
        "c:\scope\data\waveform_data.csv."

End Sub

Private Sub DoCommand(command As String)

    err = viVPrintf(vi, command + vbLf, 0)
    If (err <> VI_SUCCESS) Then HandleVISAError vi

    CheckInstrumentErrors

End Sub

Private Function DoCommandIEEEBlock(command As String, _
    lngBlockSize As Long)

    retCount = lngBlockSize

    Dim strCommandAndLength As String
    strCommandAndLength = command + " %#" + _
        Format(lngBlockSize) + "b"

    err = viVPrintf(vi, strCommandAndLength + vbLf, paramsArray(1))
    If (err <> VI_SUCCESS) Then HandleVISAError vi

    DoCommandIEEEBlock = retCount

    CheckInstrumentErrors

End Function

Private Function DoQueryString(query As String) As String

    Dim strResult As String * 200

    err = viVPrintf(vi, query + vbLf, 0)
    If (err <> VI_SUCCESS) Then HandleVISAError vi

    err = viVScanf(vi, "%t", strResult)
    If (err <> VI_SUCCESS) Then HandleVISAError vi

    DoQueryString = strResult

    CheckInstrumentErrors

End Function

Private Function DoQueryNumber(query As String) As Variant

    Dim dblResult As Double

    err = viVPrintf(vi, query + vbLf, 0)
    If (err <> VI_SUCCESS) Then HandleVISAError vi

```

```

    err = viVScanf(vi, "%lf" + vbLf, VarPtr(dblResult))
    If (err <> VI_SUCCESS) Then HandleVISAError vi

    DoQueryNumber = dblResult

    CheckInstrumentErrors

End Function

Private Function DoQueryNumbers(query As String) As Long

    Dim dblResult As Double

    ' Send query.
    err = viVPrintf(vi, query + vbLf, 0)
    If (err <> VI_SUCCESS) Then HandleVISAError vi

    ' Set up paramsArray for multiple parameter query returning array.
    paramsArray(0) = VarPtr(retCount)
    paramsArray(1) = VarPtr(dblArray(0))

    ' Set retCount to max number of elements array can hold.
    retCount = DblArraySize

    ' Read numbers.
    err = viVScanf(vi, "%,#lf" + vbLf, paramsArray(0))
    If (err <> VI_SUCCESS) Then HandleVISAError vi

    ' retCount is now actual number of values returned by query.
    DoQueryNumbers = retCount

    CheckInstrumentErrors

End Function

Private Function DoQueryIEEEBlock_Bytes(query As String) As Long

    ' Send query.
    err = viVPrintf(vi, query + vbLf, 0)
    If (err <> VI_SUCCESS) Then HandleVISAError vi

    ' Set up paramsArray for multiple parameter query returning array.
    paramsArray(0) = VarPtr(retCount)
    paramsArray(1) = VarPtr(byteArray(0))

    ' Set retCount to max number of elements array can hold.
    retCount = ByteArraySize

    ' Get unsigned integer bytes.
    err = viVScanf(vi, "%#b" + vbLf, paramsArray(0))
    If (err <> VI_SUCCESS) Then HandleVISAError vi

    err = viFlush(vi, VI_READ_BUF)
    If (err <> VI_SUCCESS) Then HandleVISAError vi

    err = viFlush(vi, VI_WRITE_BUF)

```

```

    If (err <> VI_SUCCESS) Then HandleVISAError vi

    ' retCount is now actual number of bytes returned by query.
    DoQueryIEEEBlock_Bytes = retCount

    CheckInstrumentErrors

End Function

Private Sub CheckInstrumentErrors()

    On Error GoTo ErrorHandler

    Dim strErrVal As String * 200
    Dim strOut As String

    err = viVPrintf(vi, ":SYSTEM:ERROR?" + vbLf, 0) ' Query any errors.
    If (err <> VI_SUCCESS) Then HandleVISAError vi

    err = viVScanf(vi, "%t", strErrVal) ' Read: Errnum,"Error String".
    If (err <> VI_SUCCESS) Then HandleVISAError vi

    While Val(strErrVal) <> 0 ' End if find: 0,"No Error".
        strOut = strOut + "INST Error: " + strErrVal

        err = viVPrintf(vi, ":SYSTEM:ERROR?" + vbLf, 0) ' Request error.
        If (err <> VI_SUCCESS) Then HandleVISAError vi

        err = viVScanf(vi, "%t", strErrVal) ' Read error message.
        If (err <> VI_SUCCESS) Then HandleVISAError vi

    Wend

    If Not strOut = "" Then
        MsgBox strOut, vbExclamation, "INST Error Messages"

        err = viFlush(vi, VI_READ_BUF)
        If (err <> VI_SUCCESS) Then HandleVISAError vi

        err = viFlush(vi, VI_WRITE_BUF)
        If (err <> VI_SUCCESS) Then HandleVISAError vi

    End If

    Exit Sub

ErrorHandler:

    MsgBox "*** Error : " + Error, vbExclamation
    End

End Sub

Private Sub HandleVISAError(session As Long)

    Dim strVisaErr As String * 200
    Call viStatusDesc(session, err, strVisaErr)

```



```

MsgBox "*** VISA Error : " + strVisaErr, vbExclamation

' If the error is not a warning, close the session.
If err < VI_SUCCESS Then
    If session <> 0 Then Call viClose(session)
    End
End If

End Sub

```

VISA Example in C#

To compile and run this example in Microsoft Visual Studio 2008:

- 1 Open Visual Studio.
- 2 Create a new Visual C#, Windows, Console Application project.
- 3 Cut-and-paste the code that follows into the C# source file.
- 4 Edit the program to use the VISA address of your oscilloscope.
- 5 Add Keysight's VISA header file to your project:
 - a Right-click the project you wish to modify (not the solution) in the Solution Explorer window of the Microsoft Visual Studio environment.
 - b Click **Add** and then click **Add Existing Item...**
 - c Navigate to the header file, visa32.cs (installed with Keysight IO Libraries Suite and found in the Program Files (x86)\IVI Foundation\VISA\WinNT\Include directory), select it, but *do not click the Open button*.
 - d Click the down arrow to the right of the **Add** button, and choose **Add as Link**.

You should now see the file underneath your project in the Solution Explorer. It will have a little arrow icon in its lower left corner, indicating that it is a link.
- 6 Build and run the program.

For more information, see the tutorial on using VISA in Microsoft .NET in the VISA Help that comes with Keysight IO Libraries Suite.

```

/*
 * Keysight VISA Example in C#
 * -----
 * This program illustrates a few commonly used programming
 * features of your Keysight oscilloscope.
 * -----
 */

using System;
using System.IO;
using System.Text;

namespace InfiniiVision
{
    class VisaInstrumentApp

```

```

{
    private static VisaInstrument myScope;

    public static void Main(string[] args)
    {
        try
        {
            myScope = new
                VisaInstrument("USB0::0x0957::0x17A6::US50210029::0::INSTR");
            myScope.SetTimeoutSeconds(10);

            // Initialize - start from a known state.
            Initialize();

            // Capture data.
            Capture();

            // Analyze the captured waveform.
            Analyze();

        }
        catch (System.ApplicationException err)
        {
            Console.WriteLine("*** VISA Error Message : " + err.Message);
        }
        catch (System.SystemException err)
        {
            Console.WriteLine("*** System Error Message : " + err.Message);
        }
        catch (System.Exception err)
        {
            System.Diagnostics.Debug.Fail("Unexpected Error");
            Console.WriteLine("*** Unexpected Error : " + err.Message);
        }
        finally
        {
            myScope.Close();
        }
    }
}

/*
 * Initialize the oscilloscope to a known state.
 * -----
 */
private static void Initialize()
{
    StringBuilder strResults;

    // Get and display the device's *IDN? string.
    strResults = myScope.DoQueryString("*IDN?");
    Console.WriteLine("*IDN? result is: {0}", strResults);

    // Clear status and load the default setup.
    myScope.DoCommand("*CLS");
    myScope.DoCommand("*RST");
}

```

```

/*
 * Capture the waveform.
 * -----
 */
private static void Capture()
{
    // Use auto-scale to automatically configure oscilloscope.
    myScope.DoCommand(":AUToscale");

    // Set trigger mode (EDGE, PULSe, PATtern, etc., and input source.
    myScope.DoCommand(":TRIGger:MODE EDGE");
    Console.WriteLine("Trigger mode: {0}",
        myScope.DoQueryString(":TRIGger:MODE?"));

    // Set EDGE trigger parameters.
    myScope.DoCommand(":TRIGger:EDGE:SOURce CHANnel1");
    Console.WriteLine("Trigger edge source: {0}",
        myScope.DoQueryString(":TRIGger:EDGE:SOURce?"));

    myScope.DoCommand(":TRIGger:EDGE:LEVel 1.5");
    Console.WriteLine("Trigger edge level: {0}",
        myScope.DoQueryString(":TRIGger:EDGE:LEVel?"));

    myScope.DoCommand(":TRIGger:EDGE:SLOPe POSitive");
    Console.WriteLine("Trigger edge slope: {0}",
        myScope.DoQueryString(":TRIGger:EDGE:SLOPe?"));

    // Save oscilloscope configuration.
    byte[] ResultsArray; // Results array.
    int nLength; // Number of bytes returned from instrument.
    string strPath;

    // Query and read setup string.
    nLength = myScope.DoQueryIEEEBlock(":SYSTem:SETup?",
        out ResultsArray);

    // Write setup string to file.
    strPath = "c:\\scope\\config\\setup.stp";
    FileStream fStream = File.Open(strPath, FileMode.Create);
    fStream.Write(ResultsArray, 0, nLength);
    fStream.Close();
    Console.WriteLine("Setup bytes saved: {0}", nLength);

    // Change settings with individual commands:

    // Set vertical scale and offset.
    myScope.DoCommand(":CHANnel1:SCALe 0.05");
    Console.WriteLine("Channel 1 vertical scale: {0}",
        myScope.DoQueryString(":CHANnel1:SCALe?"));

    myScope.DoCommand(":CHANnel1:OFFSet -1.5");
    Console.WriteLine("Channel 1 vertical offset: {0}",
        myScope.DoQueryString(":CHANnel1:OFFSet?"));

    // Set horizontal scale and position.
    myScope.DoCommand(":TIMEbase:SCALe 0.0002");
    Console.WriteLine("Timebase scale: {0}",

```

```

        myScope.DoQueryString(":TIMEbase:SCALE?"));

myScope.DoCommand(":TIMEbase:POSition 0.0");
Console.WriteLine("Timebase position: {0}",
    myScope.DoQueryString(":TIMEbase:POSition?"));

// Set the acquisition type (NORMal, PEAK, AVERage, or HRESolution
).
myScope.DoCommand(":ACquire:TYPE NORMal");
Console.WriteLine("Acquire type: {0}",
    myScope.DoQueryString(":ACquire:TYPE?"));

// Or, configure by loading a previously saved setup.
byte[] dataArray;
int nBytesWritten;

// Read setup string from file.
strPath = "c:\\scope\\config\\setup.stp";
dataArray = File.ReadAllBytes(strPath);

// Restore setup string.
nBytesWritten = myScope.DoCommandIEEEBlock(":SYSTEM:SETup",
    dataArray);
Console.WriteLine("Setup bytes restored: {0}", nBytesWritten);

// Capture an acquisition using :DIGitize.
myScope.DoCommand(":DIGitize CHANnel1");
}

/*
 * Analyze the captured waveform.
 * -----
 */
private static void Analyze()
{
    byte[] ResultsArray; // Results array.
    int nLength; // Number of bytes returned from instrument.
    string strPath;

    // Make a couple of measurements.
    // -----
    myScope.DoCommand(":MEASure:SOURce CHANnel1");
    Console.WriteLine("Measure source: {0}",
        myScope.DoQueryString(":MEASure:SOURce?"));

    double fResult;
    myScope.DoCommand(":MEASure:FREquency");
    fResult = myScope.DoQueryNumber(":MEASure:FREquency?");
    Console.WriteLine("Frequency: {0:F4} kHz", fResult / 1000);

    myScope.DoCommand(":MEASure:VAMplitude");
    fResult = myScope.DoQueryNumber(":MEASure:VAMplitude?");
    Console.WriteLine("Vertical amplitude: {0:F2} V", fResult);

    // Download the screen image.
    // -----
    myScope.DoCommand(":HARDcopy:INKSaver OFF");

```

```

// Get the screen data.
nLength = myScope.DoQueryIEEEBlock(":DISPlay:DATA? PNG, COLor",
    out ResultsArray);

// Store the screen data to a file.
strPath = "c:\\scope\\data\\screen.png";
FileStream fStream = File.Open(strPath, FileMode.Create);
fStream.Write(ResultsArray, 0, nLength);
fStream.Close();
Console.WriteLine("Screen image ({0} bytes) written to {1}",
    nLength, strPath);

// Download waveform data.
// -----

// Set the waveform points mode.
myScope.DoCommand(":WAVEform:POINts:MODE RAW");
Console.WriteLine("Waveform points mode: {0}",
    myScope.DoQueryString(":WAVEform:POINts:MODE?"));

// Get the number of waveform points available.
myScope.DoCommand(":WAVEform:POINts 10240");
Console.WriteLine("Waveform points available: {0}",
    myScope.DoQueryString(":WAVEform:POINts?"));

// Set the waveform source.
myScope.DoCommand(":WAVEform:SOURce CHANnel1");
Console.WriteLine("Waveform source: {0}",
    myScope.DoQueryString(":WAVEform:SOURce?"));

// Choose the format of the data returned (WORD, BYTE, ASCII):
myScope.DoCommand(":WAVEform:FORMat BYTE");
Console.WriteLine("Waveform format: {0}",
    myScope.DoQueryString(":WAVEform:FORMat?"));

// Display the waveform settings:
double[] fResultsArray;
fResultsArray = myScope.DoQueryNumbers(":WAVEform:PREAmble?");

double fFormat = fResultsArray[0];
if (fFormat == 0.0)
{
    Console.WriteLine("Waveform format: BYTE");
}
else if (fFormat == 1.0)
{
    Console.WriteLine("Waveform format: WORD");
}
else if (fFormat == 2.0)
{
    Console.WriteLine("Waveform format: ASCii");
}

double fType = fResultsArray[1];
if (fType == 0.0)
{

```

```

    Console.WriteLine("Acquire type: NORMAl");
}
else if (fType == 1.0)
{
    Console.WriteLine("Acquire type: PEAK");
}
else if (fType == 2.0)
{
    Console.WriteLine("Acquire type: AVERAge");
}
else if (fType == 3.0)
{
    Console.WriteLine("Acquire type: HRESolution");
}

double fPoints = fResultsArray[2];
Console.WriteLine("Waveform points: {0:e}", fPoints);

double fCount = fResultsArray[3];
Console.WriteLine("Waveform average count: {0:e}", fCount);

double fXincrement = fResultsArray[4];
Console.WriteLine("Waveform X increment: {0:e}", fXincrement);

double fXorigin = fResultsArray[5];
Console.WriteLine("Waveform X origin: {0:e}", fXorigin);

double fXreference = fResultsArray[6];
Console.WriteLine("Waveform X reference: {0:e}", fXreference);

double fYincrement = fResultsArray[7];
Console.WriteLine("Waveform Y increment: {0:e}", fYincrement);

double fYorigin = fResultsArray[8];
Console.WriteLine("Waveform Y origin: {0:e}", fYorigin);

double fYreference = fResultsArray[9];
Console.WriteLine("Waveform Y reference: {0:e}", fYreference);

// Read waveform data.
nLength = myScope.DoQueryIEEEBlock(":WAVEform:DATA?",
    out ResultsArray);
Console.WriteLine("Number of data values: {0}", nLength);

// Set up output file:
strPath = "c:\\scope\\data\\waveform_data.csv";
if (File.Exists(strPath)) File.Delete(strPath);

// Open file for output.
StreamWriter writer = File.CreateText(strPath);

// Output waveform data in CSV format.
for (int i = 0; i < nLength - 1; i++)
    writer.WriteLine("{0:f9}, {1:f6}",
        fXorigin + ((float)i * fXincrement),
        (((float)ResultsArray[i] - fYreference) *
        fYincrement) + fYorigin);

```

```

        // Close output file.
        writer.Close();
        Console.WriteLine("Waveform format BYTE data written to {0}",
            strPath);
    }
}

class VisaInstrument
{
    private int m_nResourceManager;
    private int m_nSession;
    private string m_strVisaAddress;

    // Constructor.
    public VisaInstrument(string strVisaAddress)
    {
        // Save VISA address in member variable.
        m_strVisaAddress = strVisaAddress;

        // Open the default VISA resource manager.
        OpenResourceManager();

        // Open a VISA resource session.
        OpenSession();

        // Clear the interface.
        int nViStatus;
        nViStatus = visa32.viClear(m_nSession);
    }

    public void DoCommand(string strCommand)
    {
        // Send the command.
        VisaSendCommandOrQuery(strCommand);

        // Check for inst errors.
        CheckInstrumentErrors(strCommand);
    }

    public int DoCommandIEEEBlock(string strCommand,
        byte[] dataArray)
    {
        // Send the command to the device.
        string strCommandAndLength;
        int nViStatus, nLength, nBytesWritten;

        nLength = dataArray.Length;
        strCommandAndLength = String.Format("{0} #8%08d",
            strCommand);

        // Write first part of command to formatted I/O write buffer.
        nViStatus = visa32.viPrintf(m_nSession, strCommandAndLength,
            nLength);
        CheckVisaStatus(nViStatus);

        // Write the data to the formatted I/O write buffer.
    }
}

```

```

        nViStatus = visa32.viBufWrite(m_nSession, dataArray, nLength,
            out nBytesWritten);
        CheckVisaStatus(nViStatus);

        // Check for inst errors.
        CheckInstrumentErrors(strCommand);

        return nBytesWritten;
    }

    public StringBuilder DoQueryString(string strQuery)
    {
        // Send the query.
        VisaSendCommandOrQuery(strQuery);

        // Get the result string.
        StringBuilder strResults = new StringBuilder(1000);
        strResults = VisaGetResultString();

        // Check for inst errors.
        CheckInstrumentErrors(strQuery);

        // Return string results.
        return strResults;
    }

    public double DoQueryNumber(string strQuery)
    {
        // Send the query.
        VisaSendCommandOrQuery(strQuery);

        // Get the result string.
        double fResults;
        fResults = VisaGetResultNumber();

        // Check for inst errors.
        CheckInstrumentErrors(strQuery);

        // Return string results.
        return fResults;
    }

    public double[] DoQueryNumbers(string strQuery)
    {
        // Send the query.
        VisaSendCommandOrQuery(strQuery);

        // Get the result string.
        double[] fResultsArray;
        fResultsArray = VisaGetResultNumbers();

        // Check for inst errors.
        CheckInstrumentErrors(strQuery);

        // Return string results.
        return fResultsArray;
    }
}

```



```

public int DoQueryIEEEBlock(string strQuery,
    out byte[] ResultsArray)
{
    // Send the query.
    VisaSendCommandOrQuery(strQuery);

    // Get the result string.
    int length; // Number of bytes returned from instrument.
    length = VisaGetResultIEEEBlock(out ResultsArray);

    // Check for inst errors.
    CheckInstrumentErrors(strQuery);

    // Return string results.
    return length;
}

private void VisaSendCommandOrQuery(string strCommandOrQuery)
{
    // Send command or query to the device.
    string strWithNewline;
    strWithNewline = String.Format("{0}\n", strCommandOrQuery);
    int nViStatus;
    nViStatus = visa32.viPrintf(m_nSession, strWithNewline);
    CheckVisaStatus(nViStatus);
}

private StringBuilder VisaGetResultString()
{
    StringBuilder strResults = new StringBuilder(1000);

    // Read return value string from the device.
    int nViStatus;
    nViStatus = visa32.viScanf(m_nSession, "%1000t", strResults);
    CheckVisaStatus(nViStatus);

    return strResults;
}

private double VisaGetResultNumber()
{
    double fResults = 0;

    // Read return value string from the device.
    int nViStatus;
    nViStatus = visa32.viScanf(m_nSession, "%lf", out fResults);
    CheckVisaStatus(nViStatus);

    return fResults;
}

private double[] VisaGetResultNumbers()
{
    double[] fResultsArray;
    fResultsArray = new double[10];
}

```

```

    // Read return value string from the device.
    int nViStatus;
    nViStatus = visa32.viScanf(m_nSession, "%,10lf\n",
        fResultsArray);
    CheckVisaStatus(nViStatus);

    return fResultsArray;
}

private int VisaGetResultIEEEBlock(out byte[] ResultsArray)
{
    // Results array, big enough to hold a PNG.
    ResultsArray = new byte[300000];
    int length; // Number of bytes returned from instrument.

    // Set the default number of bytes that will be contained in
    // the ResultsArray to 300,000 (300kB).
    length = 300000;

    // Read return value string from the device.
    int nViStatus;
    nViStatus = visa32.viScanf(m_nSession, "%#b", ref length,
        ResultsArray);
    CheckVisaStatus(nViStatus);

    // Write and read buffers need to be flushed after IEEE block?
    nViStatus = visa32.viFlush(m_nSession, visa32.VI_WRITE_BUF);
    CheckVisaStatus(nViStatus);

    nViStatus = visa32.viFlush(m_nSession, visa32.VI_READ_BUF);
    CheckVisaStatus(nViStatus);

    return length;
}

private void CheckInstrumentErrors(string strCommand)
{
    // Check for instrument errors.
    StringBuilder strInstrumentError = new StringBuilder(1000);
    bool bFirstError = true;

    do // While not "0,No error"
    {
        VisaSendCommandOrQuery(":SYSTem:ERRor?");
        strInstrumentError = VisaGetResultString();

        if (!strInstrumentError.ToString().StartsWith("+0, "))
        {
            if (bFirstError)
            {
                Console.WriteLine("ERROR(s) for command '{0}': ",
                    strCommand);
                bFirstError = false;
            }
            Console.Write(strInstrumentError);
        }
    } while (!strInstrumentError.ToString().StartsWith("+0, "));
}

```

```

    }

    private void OpenResourceManager()
    {
        int nViStatus;
        nViStatus =
            visa32.viOpenDefaultRM(out this.m_nResourceManager);
        if (nViStatus < visa32.VI_SUCCESS)
            throw new
                ApplicationException("Failed to open Resource Manager");
    }

    private void OpenSession()
    {
        int nViStatus;
        nViStatus = visa32.viOpen(this.m_nResourceManager,
            this.m_strVisaAddress, visa32.VI_NO_LOCK,
            visa32.VI_TMO_IMMEDIATE, out this.m_nSession);
        CheckVisaStatus(nViStatus);
    }

    public void SetTimeoutSeconds(int nSeconds)
    {
        int nViStatus;
        nViStatus = visa32.viSetAttribute(this.m_nSession,
            visa32.VI_ATTR_TMO_VALUE, nSeconds * 1000);
        CheckVisaStatus(nViStatus);
    }

    public void CheckVisaStatus(int nViStatus)
    {
        // If VISA error, throw exception.
        if (nViStatus < visa32.VI_SUCCESS)
        {
            StringBuilder strError = new StringBuilder(256);
            visa32.viStatusDesc(this.m_nResourceManager, nViStatus,
                strError);
            throw new ApplicationException(strError.ToString());
        }
    }

    public void Close()
    {
        if (m_nSession != 0)
            visa32.viClose(m_nSession);
        if (m_nResourceManager != 0)
            visa32.viClose(m_nResourceManager);
    }
}
}

```

VISA Example in Visual Basic .NET

To compile and run this example in Microsoft Visual Studio 2008:

- 1 Open Visual Studio.
- 2 Create a new Visual Basic, Windows, Console Application project.
- 3 Cut-and-paste the code that follows into the Visual Basic .NET source file.
- 4 Edit the program to use the VISA address of your oscilloscope.
- 5 Add Keysight's VISA header file to your project:
 - a Right-click the project you wish to modify (not the solution) in the Solution Explorer window of the Microsoft Visual Studio environment.
 - b Choose **Add** and then choose **Add Existing Item...**
 - c Navigate to the header file, visa32.vb (installed with Keysight IO Libraries Suite and found in the Program Files (x86)\IVI Foundation\VISA\WinNT\Include directory), select it, but *do not click the Open button*.
 - d Click the down arrow to the right of the **Add** button, and choose **Add as Link**.

You should now see the file underneath your project in the Solution Explorer. It will have a little arrow icon in its lower left corner, indicating that it is a link.

 - e Right-click the project again and choose **Properties**; then, select "InfiniiVision.VisaInstrumentApp" as the **Startup object**.
- 6 Build and run the program.

For more information, see the tutorial on using VISA in Microsoft .NET in the VISA Help that comes with Keysight IO Libraries Suite.

```
'
' Keysight VISA Example in Visual Basic .NET
' -----
' This program illustrates a few commonly-used programming
' features of your Keysight oscilloscope.
' -----

Imports System
Imports System.IO
Imports System.Text

Namespace InfiniiVision
  Class VisaInstrumentApp
    Private Shared myScope As VisaInstrument

    Public Shared Sub Main(ByVal args As String())
      Try
        myScope = _
          New VisaInstrument("USB0::0x0957::0x17A6::US50210029::0::INSTR
")
        myScope.SetTimeoutSeconds(10)
      End Try
    End Sub
  End Class
End Namespace
```

```

' Initialize - start from a known state.
Initialize()

' Capture data.
Capture()

' Analyze the captured waveform.
Analyze()

Catch err As System.ApplicationException
    Console.WriteLine("*** VISA Error Message : " + err.Message)
Catch err As System.SystemException
    Console.WriteLine("*** System Error Message : " + err.Message)
Catch err As System.Exception
    Debug.Fail("Unexpected Error")
    Console.WriteLine("*** Unexpected Error : " + err.Message)
End Try
End Sub

'
' Initialize the oscilloscope to a known state.
' -----

Private Shared Sub Initialize()
    Dim strResults As StringBuilder

    ' Get and display the device's *IDN? string.
    strResults = myScope.DoQueryString("*IDN?")
    Console.WriteLine("*IDN? result is: {0}", strResults)

    ' Clear status and load the default setup.
    myScope.DoCommand("*CLS")
    myScope.DoCommand("*RST")

End Sub

'
' Capture the waveform.
' -----

Private Shared Sub Capture()

    ' Use auto-scale to automatically configure oscilloscope.
    myScope.DoCommand(":AUToscale")

    ' Set trigger mode (EDGE, PULSe, PATtern, etc., and input source.
    myScope.DoCommand(":TRIGger:MODE EDGE")
    Console.WriteLine("Trigger mode: {0}", _
        myScope.DoQueryString(":TRIGger:MODE?"))

    ' Set EDGE trigger parameters.
    myScope.DoCommand(":TRIGger:EDGE:SOURce CHANnel1")
    Console.WriteLine("Trigger edge source: {0}", _
        myScope.DoQueryString(":TRIGger:EDGE:SOURce?"))

    myScope.DoCommand(":TRIGger:EDGE:LEVel 1.5")
    Console.WriteLine("Trigger edge level: {0}", _

```

```

        myScope.DoQueryString(":TRIGger:EDGE:LEVel?")

myScope.DoCommand(":TRIGger:EDGE:SLOPe POSitive")
Console.WriteLine("Trigger edge slope: {0}", _
    myScope.DoQueryString(":TRIGger:EDGE:SLOPe?"))

' Save oscilloscope configuration.
Dim ResultsArray As Byte() ' Results array.
Dim nLength As Integer ' Number of bytes returned from inst.
Dim strPath As String
Dim fStream As FileStream

' Query and read setup string.
nLength = myScope.DoQueryIEEEBlock(":SYSTem:SETUp?", _
    ResultsArray)

' Write setup string to file.
strPath = "c:\scope\config\setup.stp"
fStream = File.Open(strPath, FileMode.Create)
fStream.Write(ResultsArray, 0, nLength)
fStream.Close()
Console.WriteLine("Setup bytes saved: {0}", nLength)

' Change settings with individual commands:

' Set vertical scale and offset.
myScope.DoCommand(":CHANnel1:SCALe 0.05")
Console.WriteLine("Channel 1 vertical scale: {0}", _
    myScope.DoQueryString(":CHANnel1:SCALe?"))

myScope.DoCommand(":CHANnel1:OFFSet -1.5")
Console.WriteLine("Channel 1 vertical offset: {0}", _
    myScope.DoQueryString(":CHANnel1:OFFSet?"))

' Set horizontal scale and position.
myScope.DoCommand(":TIMebase:SCALe 0.0002")
Console.WriteLine("Timebase scale: {0}", _
    myScope.DoQueryString(":TIMebase:SCALe?"))

myScope.DoCommand(":TIMebase:POSition 0.0")
Console.WriteLine("Timebase position: {0}", _
    myScope.DoQueryString(":TIMebase:POSition?"))

' Set the acquisition type (NORMal, PEAK, AVERAge, or HRESolution)

myScope.DoCommand(":ACQuire:TYPE NORMal")
Console.WriteLine("Acquire type: {0}", _
    myScope.DoQueryString(":ACQuire:TYPE?"))

' Or, configure by loading a previously saved setup.
Dim dataArray As Byte()
Dim nBytesWritten As Integer

' Read setup string from file.
strPath = "c:\scope\config\setup.stp"
dataArray = File.ReadAllBytes(strPath)

```

```

' Restore setup string.
nBytesWritten = myScope.DoCommandIEEEBlock(":SYSTem:SETup", _
    dataArray)
Console.WriteLine("Setup bytes restored: {0}", nBytesWritten)

' Capture an acquisition using :DIGitize.
myScope.DoCommand(":DIGitize CHANnel1")

End Sub

'
' Analyze the captured waveform.
' -----

Private Shared Sub Analyze()

    Dim fResult As Double
    Dim ResultsArray As Byte() ' Results array.
    Dim nLength As Integer ' Number of bytes returned from inst.
    Dim strPath As String

    ' Make a couple of measurements.
    ' -----
myScope.DoCommand(":MEASure:SOURce CHANnel1")
Console.WriteLine("Measure source: {0}", _
    myScope.DoQueryString(":MEASure:SOURce?"))

myScope.DoCommand(":MEASure:FREQuency")
fResult = myScope.DoQueryNumber(":MEASure:FREQuency?")
Console.WriteLine("Frequency: {0:F4} kHz", fResult / 1000)

myScope.DoCommand(":MEASure:VAMplitude")
fResult = myScope.DoQueryNumber(":MEASure:VAMplitude?")
Console.WriteLine("Vertical amplitude: {0:F2} V", fResult)

    ' Download the screen image.
    ' -----
myScope.DoCommand(":HARDcopy:INKSaver OFF")

    ' Get the screen data.
nLength = myScope.DoQueryIEEEBlock(":DISPlay:DATA? PNG, COLor", _
    ResultsArray)

    ' Store the screen data to a file.
strPath = "c:\scope\data\screen.png"
Dim fStream As FileStream
fStream = File.Open(strPath, FileMode.Create)
fStream.Write(ResultsArray, 0, nLength)
fStream.Close()
Console.WriteLine("Screen image ({0} bytes) written to {1}", _
    nLength, strPath)

    ' Download waveform data.
    ' -----

    ' Set the waveform points mode.
myScope.DoCommand(":WAVEform:POINTs:MODE RAW")

```

```

Console.WriteLine("Waveform points mode: {0}", _
    myScope.DoQueryString(":WAVEform:POINTs:MODE?"))

' Get the number of waveform points available.
myScope.DoCommand(":WAVEform:POINTs 10240")
Console.WriteLine("Waveform points available: {0}", _
    myScope.DoQueryString(":WAVEform:POINTs?"))

' Set the waveform source.
myScope.DoCommand(":WAVEform:SOURce CHANnel1")
Console.WriteLine("Waveform source: {0}", _
    myScope.DoQueryString(":WAVEform:SOURce?"))

' Choose the format of the data returned (WORD, BYTE, ASCII):
myScope.DoCommand(":WAVEform:FORMat BYTE")
Console.WriteLine("Waveform format: {0}", _
    myScope.DoQueryString(":WAVEform:FORMat?"))

' Display the waveform settings:
Dim fResultsArray As Double()
fResultsArray = myScope.DoQueryNumbers(":WAVEform:PREAmble?")

Dim fFormat As Double = fResultsArray(0)
If fFormat = 0 Then
    Console.WriteLine("Waveform format: BYTE")
ElseIf fFormat = 1 Then
    Console.WriteLine("Waveform format: WORD")
ElseIf fFormat = 2 Then
    Console.WriteLine("Waveform format: ASCii")
End If

Dim fType As Double = fResultsArray(1)
If fType = 0 Then
    Console.WriteLine("Acquire type: NORMAl")
ElseIf fType = 1 Then
    Console.WriteLine("Acquire type: PEAK")
ElseIf fType = 2 Then
    Console.WriteLine("Acquire type: AVERAge")
ElseIf fType = 3 Then
    Console.WriteLine("Acquire type: HRESolution")
End If

Dim fPoints As Double = fResultsArray(2)
Console.WriteLine("Waveform points: {0:e}", fPoints)

Dim fCount As Double = fResultsArray(3)
Console.WriteLine("Waveform average count: {0:e}", fCount)

Dim fXincrement As Double = fResultsArray(4)
Console.WriteLine("Waveform X increment: {0:e}", fXincrement)

Dim fXorigin As Double = fResultsArray(5)
Console.WriteLine("Waveform X origin: {0:e}", fXorigin)

Dim fXreference As Double = fResultsArray(6)
Console.WriteLine("Waveform X reference: {0:e}", fXreference)

```



```

Dim fYincrement As Double = fResultsArray(7)
Console.WriteLine("Waveform Y increment: {0:e}", fYincrement)

Dim fYorigin As Double = fResultsArray(8)
Console.WriteLine("Waveform Y origin: {0:e}", fYorigin)

Dim fYreference As Double = fResultsArray(9)
Console.WriteLine("Waveform Y reference: {0:e}", fYreference)

' Get the waveform data.
nLength = myScope.DoQueryIEEEBlock(":WAVEform:DATA?", _
    ResultsArray)
Console.WriteLine("Number of data values: {0}", nLength)

' Set up output file:
strPath = "c:\scope\data\waveform_data.csv"
If File.Exists(strPath) Then
    File.Delete(strPath)
End If

' Open file for output.
Dim writer As StreamWriter = File.CreateText(strPath)

' Output waveform data in CSV format.
For index As Integer = 0 To nLength - 1
    ' Write time value, voltage value.
    writer.WriteLine("{0:f9}, {1:f6}", _
        fXorigin + (CSng(index) * fXincrement), _
        ((CSng(ResultsArray(index)) - fYreference) _
        * fYincrement) + fYorigin)
Next

' Close output file.
writer.Close()
Console.WriteLine("Waveform format BYTE data written to {0}", _
    strPath)

End Sub

End Class

Class VisaInstrument
Private m_nResourceManager As Integer
Private m_nSession As Integer
Private m_strVisaAddress As String

' Constructor.
Public Sub New(ByVal strVisaAddress As String)
    ' Save VISA address in member variable.
    m_strVisaAddress = strVisaAddress

    ' Open the default VISA resource manager.
    OpenResourceManager()

    ' Open a VISA resource session.
    OpenSession()

```

```

    ' Clear the interface.
    Dim nViStatus As Integer
    nViStatus = visa32.viClear(m_nSession)
End Sub

Public Sub DoCommand(ByVal strCommand As String)
    ' Send the command.
    VisaSendCommandOrQuery(strCommand)

    ' Check for inst errors.
    CheckInstrumentErrors(strCommand)

End Sub

Public Function DoCommandIEEEBlock(ByVal strCommand As String, _
    ByVal dataArray As Byte()) As Integer

    ' Send the command to the device.
    Dim strCommandAndLength As String
    Dim nViStatus As Integer
    Dim nLength As Integer
    Dim nBytesWritten As Integer

    nLength = dataArray.Length
    strCommandAndLength = [String].Format("{0} #8{1:D8}", _
        strCommand, nLength)

    ' Write first part of command to formatted I/O write buffer.
    nViStatus = visa32.viPrintf(m_nSession, strCommandAndLength)
    CheckVisaStatus(nViStatus)

    ' Write the data to the formatted I/O write buffer.
    nViStatus = visa32.viBufWrite(m_nSession, dataArray, nLength, _
        nBytesWritten)
    CheckVisaStatus(nViStatus)

    ' Check for inst errors.
    CheckInstrumentErrors(strCommand)

    Return nBytesWritten
End Function

Public Function DoQueryString(ByVal strQuery As String) _
    As StringBuilder
    ' Send the query.
    VisaSendCommandOrQuery(strQuery)

    ' Get the result string.
    Dim strResults As New StringBuilder(1000)
    strResults = VisaGetResultString()

    ' Check for inst errors.
    CheckInstrumentErrors(strQuery)

    ' Return string results.
    Return strResults
End Function

```

```

Public Function DoQueryNumber(ByVal strQuery As String) As Double
    ' Send the query.
    VisaSendCommandOrQuery(strQuery)

    ' Get the result string.
    Dim fResults As Double
    fResults = VisaGetResultNumber()

    ' Check for inst errors.
    CheckInstrumentErrors(strQuery)

    ' Return string results.
    Return fResults
End Function

Public Function DoQueryNumbers(ByVal strQuery As String) _
    As Double()
    ' Send the query.
    VisaSendCommandOrQuery(strQuery)

    ' Get the result string.
    Dim fResultsArray As Double()
    fResultsArray = VisaGetResultNumbers()

    ' Check for instrument errors (another command and result).
    CheckInstrumentErrors(strQuery)

    ' Return string results.
    Return fResultsArray
End Function

Public Function DoQueryIEEEBlock(ByVal strQuery As String, _
    ByRef ResultsArray As Byte()) As Integer
    ' Send the query.
    VisaSendCommandOrQuery(strQuery)

    ' Get the result string.
    System.Threading.Thread.Sleep(2000) ' Delay before reading data.
    Dim length As Integer
    ' Number of bytes returned from instrument.
    length = VisaGetResultIEEEBlock(ResultsArray)

    ' Check for inst errors.
    CheckInstrumentErrors(strQuery)

    ' Return string results.
    Return length
End Function

Private Sub VisaSendCommandOrQuery(ByVal strCommandOrQuery _
    As String)
    ' Send command or query to the device.
    Dim strWithNewline As String
    strWithNewline = [String].Format("{0}" & Chr(10) & "", _
        strCommandOrQuery)
    Dim nViStatus As Integer

```

```

        nViStatus = visa32.viPrintf(m_nSession, strWithNewline)
        CheckVisaStatus(nViStatus)
    End Sub

Private Function VisaGetResultString() As StringBuilder
    Dim strResults As New StringBuilder(1000)

    ' Read return value string from the device.
    Dim nViStatus As Integer
    nViStatus = visa32.viScanf(m_nSession, "%1000t", strResults)
    CheckVisaStatus(nViStatus)

    Return strResults
End Function

Private Function VisaGetResultNumber() As Double
    Dim fResults As Double = 0

    ' Read return value string from the device.
    Dim nViStatus As Integer
    nViStatus = visa32.viScanf(m_nSession, "%lf", fResults)
    CheckVisaStatus(nViStatus)

    Return fResults
End Function

Private Function VisaGetResultNumbers() As Double()
    Dim fResultsArray As Double()
    fResultsArray = New Double(9) {}

    ' Read return value string from the device.
    Dim nViStatus As Integer
    nViStatus = visa32.viScanf(m_nSession, _
        "%,10lf" & Chr(10) & "", fResultsArray)
    CheckVisaStatus(nViStatus)

    Return fResultsArray
End Function

Private Function VisaGetResultIEEEBlock(ByRef ResultsArray _
    As Byte()) As Integer
    ' Results array, big enough to hold a PNG.
    ResultsArray = New Byte(299999) {}
    Dim length As Integer
    ' Number of bytes returned from instrument.
    ' Set the default number of bytes that will be contained in
    ' the ResultsArray to 300,000 (300kB).
    length = 300000

    ' Read return value string from the device.
    Dim nViStatus As Integer
    nViStatus = visa32.viScanf(m_nSession, "%#b", length, _
        ResultsArray)
    CheckVisaStatus(nViStatus)

    ' Write and read buffers need to be flushed after IEEE block?
    nViStatus = visa32.viFlush(m_nSession, visa32.VI_WRITE_BUF)

```

```

    CheckVisaStatus(nViStatus)

    nViStatus = visa32.viFlush(m_nSession, visa32.VI_READ_BUF)
    CheckVisaStatus(nViStatus)

    Return length
End Function

Private Sub CheckInstrumentErrors(ByVal strCommand As String)
    ' Check for instrument errors.
    Dim strInstrumentError As New StringBuilder(1000)
    Dim bFirstError As Boolean = True
    Do ' While not "0,No error"
        VisaSendCommandOrQuery(":SYSTem:ERRor?")
        strInstrumentError = VisaGetResultString()

        If Not strInstrumentError.ToString().StartsWith("+0,") Then
            If bFirstError Then
                Console.WriteLine("ERROR(s) for command '{0}': ", _
                    strCommand)
                bFirstError = False
            End If
            Console.Write(strInstrumentError)
        End If
    Loop While Not strInstrumentError.ToString().StartsWith("+0,")
End Sub

Private Sub OpenResourceManager()
    Dim nViStatus As Integer
    nViStatus = visa32.viOpenDefaultRM(Me.m_nResourceManager)
    If nViStatus < visa32.VI_SUCCESS Then
        Throw New _
            ApplicationException("Failed to open Resource Manager")
    End If
End Sub

Private Sub OpenSession()
    Dim nViStatus As Integer
    nViStatus = visa32.viOpen(Me.m_nResourceManager, _
        Me.m_strVisaAddress, visa32.VI_NO_LOCK, _
        visa32.VI_TMO_IMMEDIATE, Me.m_nSession)
    CheckVisaStatus(nViStatus)
End Sub

Public Sub SetTimeoutSeconds(ByVal nSeconds As Integer)
    Dim nViStatus As Integer
    nViStatus = visa32.viSetAttribute(Me.m_nSession, _
        visa32.VI_ATTR_TMO_VALUE, nSeconds * 1000)
    CheckVisaStatus(nViStatus)
End Sub

Public Sub CheckVisaStatus(ByVal nViStatus As Integer)
    ' If VISA error, throw exception.
    If nViStatus < visa32.VI_SUCCESS Then
        Dim strError As New StringBuilder(256)
        visa32.viStatusDesc(Me.m_nResourceManager, nViStatus, strError)
        Throw New ApplicationException(strError.ToString())
    End If
End Sub

```

```

        End If
    End Sub

    Public Sub Close()
        If m_nSession <> 0 Then
            visa32.viClose(m_nSession)
        End If
        If m_nResourceManager <> 0 Then
            visa32.viClose(m_nResourceManager)
        End If
    End Sub
End Class
End Namespace

```

VISA Example in Python

You can use the Python programming language with the PyVISA package to control Keysight InfiniiVision Series oscilloscopes.

The Python language and PyVISA package can be downloaded from the web at <http://www.python.org/> and <http://pyvisa.readthedocs.io/>, respectively.

To run this example with Python and PyVISA:

- 1 Cut-and-paste the code that follows into a file named "example.py".
- 2 Edit the program to use the VISA address of your oscilloscope.
- 3 If "python.exe" can be found via your PATH environment variable, open a Command Prompt window; then, change to the folder that contains the "example.py" file, and enter:

```

python example.py

#!python3
# -*- coding: utf-8 -*-

# *****
# This program illustrates a few commonly-used programming
# features of your Keysight oscilloscope.
# *****

# Import modules.
# -----
import pyvisa
import struct
import sys

# Global variables.
# -----
# input_channel = "CHANnel1"
input_channel = "CHANnel2"
setup_file_name = "setup.scp"
screen_image_file_name = "screen_image.png"
waveform_data_file_name = "waveform_data.csv"
# wfm_fmt = "BYTE"
wfm_fmt = "WORD"

```

```

debug = False

# =====
# Initialize:
# =====
def initialize():

    # Get and display the device's *IDN? string.
    idn_string = do_query_string("*IDN?")
    print(f"Identification string: '{idn_string}'")

    # Clear status and load the default setup.
    do_command("*CLS")
    do_command("*RST")

# =====
# Capture:
# =====
def capture():

    # Use auto-scale to automatically set up oscilloscope.
    print("Autoscale.")
    do_command(":AUToscale")

    # Set trigger mode.
    do_command(":TRIGger:MODE EDGE")
    qresult = do_query_string(":TRIGger:MODE?")
    print(f"Trigger mode: {qresult}")

    # Set EDGE trigger parameters.
    do_command(f":TRIGger:EDGE:SOURce {input_channel}")
    qresult = do_query_string(":TRIGger:EDGE:SOURce?")
    print(f"Trigger edge source: {qresult}")

    do_command(":TRIGger:EDGE:LEVel 1.5")
    qresult = do_query_string(":TRIGger:EDGE:LEVel?")
    print(f"Trigger edge level: {qresult}")

    do_command(":TRIGger:EDGE:SLOPe POSitive")
    qresult = do_query_string(":TRIGger:EDGE:SLOPe?")
    print(f"Trigger edge slope: {qresult}")

    # Save oscilloscope setup.
    setup_bytes = do_query_ieee_block(":SYSTem:SETup?")

    f = open(setup_file_name, "wb")
    f.write(setup_bytes)
    f.close()
    print(f"Setup bytes saved: {len(setup_bytes)}")

    # Change oscilloscope settings with individual commands:

    # Set vertical scale and offset.
    do_command(f":{input_channel}:SCALE 0.05")
    qresult = do_query_string(f":{input_channel}:SCALE?")

```

```

print(f"{input_channel} vertical scale: {qresult}")

do_command(f":{input_channel}:OFFSet -1.5")
qresult = do_query_string(f":{input_channel}:OFFSet?")
print(f"{input_channel} offset: {qresult}")

# Set horizontal scale and offset.
do_command(":TIMEbase:SCALE 0.0002")
qresult = do_query_string(":TIMEbase:SCALE?")
print(f"Timebase scale: {qresult}")

do_command(":TIMEbase:POSition 0.0")
qresult = do_query_string(":TIMEbase:POSition?")
print(f"Timebase position: {qresult}")

# Set the acquisition type.
do_command(":ACquire:TYPE NORMAL")
qresult = do_query_string(":ACquire:TYPE?")
print(f"Acquire type: {qresult}")

# Or, set up oscilloscope by loading a previously saved setup.
setup_bytes = ""
f = open(setup_file_name, "rb")
setup_bytes = f.read()
f.close()
do_command_ieee_block(":SYSTEM:SETup", setup_bytes)
print(f"Setup bytes restored: {len(setup_bytes)}")

# Capture an acquisition using :DIGitize.
do_command(f":DIGitize {input_channel}")

# =====
# Analyze:
# =====
def analyze():

    # Make measurements.
    # -----
    do_command(f":MEASure:SOURce {input_channel}")
    qresult = do_query_string(":MEASure:SOURce?")
    print(f"Measure source: {qresult}")

    do_command(":MEASure:FREquency")
    qresult = do_query_string(":MEASure:FREquency?")
    print(f"Measured frequency on {input_channel}: {qresult}")

    do_command(":MEASure:VAMplitude")
    qresult = do_query_string(":MEASure:VAMplitude?")
    print(f"Measured vertical amplitude on {input_channel}: {qresult}")

    # Download the screen image.
    # -----
    do_command(":HARDcopy:INKSaver OFF")

    screen_bytes = do_query_ieee_block(":DISPlay:DATA? PNG, COLor")

```



```

# Save display data values to file.
f = open(screen_image_file_name, "wb")
f.write(screen_bytes)
f.close()
print(f"Screen image written to {screen_image_file_name}.")

# Download waveform data.
# -----

# Set the waveform source.
do_command(f":WAVeform:SOURce {input_channel}")
qresult = do_query_string(":WAVeform:SOURce?")
print(f"Waveform source: {qresult}")

# Set the waveform points mode.
do_command(":WAVeform:POINts:MODE RAW")
qresult = do_query_string(":WAVeform:POINts:MODE?")
print(f"Waveform points mode: {qresult}")

# Get the number of waveform points available.
do_command(":WAVeform:POINts 10240")
qresult = do_query_string(":WAVeform:POINts?")
print(f"Waveform points available: {qresult}")

# Choose the format of the data returned (BYTE or WORD):
do_command(f":WAVeform:FORMat {wfm_fmt}")
qresult = do_query_string(":WAVeform:FORMat?")
print(f"Waveform format: {qresult}")

# Specify the byte order in WORD data.
if wfm_fmt == "WORD":
    do_command(":WAVeform:BYTeorder LSBF")
    qresult = do_query_string(":WAVeform:BYTeorder?")
    print(f"Waveform byte order for WORD data: {qresult}")

# Display the waveform settings from preamble:
wav_form_dict = {
    0 : "BYTE",
    1 : "WORD",
    4 : "AScii",
}
acq_type_dict = {
    0 : "NORMal",
    1 : "PEAK",
    2 : "AVERage",
    3 : "HRESolution",
}

preamble_string = do_query_string(":WAVeform:PREamble?")
(
    wav_form, acq_type, wfmpmts, avgcnt, x_increment, x_origin,
    x_reference, y_increment, y_origin, y_reference
) = preamble_string.split(",")

print(f"Waveform format: {wav_form_dict[int(wav_form)]}")
print(f"Acquire type: {acq_type_dict[int(acq_type)]}")
print(f"Waveform points desired: {wfmpmts}")

```

```

print(f"Waveform average count: {avgcnt}")
print(f"Waveform X increment: {x_increment}")
print(f"Waveform X origin: {x_origin}")
print(f"Waveform X reference: {x_reference}") # Always 0.
print(f"Waveform Y increment: {y_increment}")
print(f"Waveform Y origin: {y_origin}")
print(f"Waveform Y reference: {y_reference}")

# Get numeric values for later calculations.
x_increment = do_query_number(":WAVEform:XINCrement?")
x_origin = do_query_number(":WAVEform:XORigin?")
y_increment = do_query_number(":WAVEform:YINCrement?")
y_origin = do_query_number(":WAVEform:YORigin?")
y_reference = do_query_number(":WAVEform:YREFerence?")

# Get the waveform data.
data_bytes = do_query_ieee_block(":WAVEform:DATA?")
data_bytes_length = len(data_bytes)
print(f"Byte count: {data_bytes_length}")

if wfm_fmt == "BYTE":
    block_points = data_bytes_length
elif wfm_fmt == "WORD":
    block_points = data_bytes_length / 2

# Unpack or split into list of data values.
if wfm_fmt == "BYTE":
    values = struct.unpack("%dB" % block_points, data_bytes)
elif wfm_fmt == "WORD":
    values = struct.unpack("%dH" % block_points, data_bytes)
print(f"Number of data values: {len(values)}")

# Save waveform data values to CSV file.
f = open(waveform_data_file_name, "w")

for i in range(0, len(values) - 1):
    time_val = x_origin + (i * x_increment)
    voltage = ((values[i] - y_reference) * y_increment) + y_origin
    f.write(f"{time_val:E}, {voltage:f}\n")

# Close output file.
f.close()
print(f"Waveform format {wfm_fmt} data written to {waveform_data_file_name}.")

# =====
# Send a command and check for errors:
# =====
def do_command(command, hide_params=False):

    if hide_params:
        (header, data) = command.split(" ", 1)
        if debug:
            print(f"Cmd = '{header}'")
    else:
        if debug:

```

```

    print(f"Cmd = '{command}'")

InfiniiVision.write(f"{command}")

if hide_params:
    check_instrument_errors(header)
else:
    check_instrument_errors(command)

# =====
# Send a command and binary values and check for errors:
# =====
def do_command_ieee_block(command, values):
    if debug:
        print(f"Cmb = '{command}'")
    InfiniiVision.write_binary_values(f"{command} ", values, datatype='B')
    check_instrument_errors(command)

# =====
# Send a query, check for errors, return string:
# =====
def do_query_string(query):
    if debug:
        print(f"Qys = '{query}'")
    result = InfiniiVision.query(f"{query}")
    check_instrument_errors(query)
    return result.strip()

# =====
# Send a query, check for errors, return floating-point value:
# =====
def do_query_number(query):
    if debug:
        print(f"Qyn = '{query}'")
    results = InfiniiVision.query(f"{query}")
    check_instrument_errors(query)
    return float(results)

# =====
# Send a query, check for errors, return binary values:
# =====
def do_query_ieee_block(query):
    if debug:
        print(f"Qyb = '{query}'")
    result = InfiniiVision.query_binary_values(f"{query}", datatype='s', co
ntainer=bytes)
    check_instrument_errors(query)
    return result

# =====
# Check for instrument errors:
# =====

```

```

def check_instrument_errors(command):

    while True:
        error_string = InfiniiVision.query(":SYSTem:ERRor?")
        if error_string: # If there is an error string value.

            if error_string.find("+0,", 0, 3) == -1: # Not "No error".

                print(f"ERROR: {error_string}, command: '{command}'")
                print("Exited because of error.")
                sys.exit(1)

            else: # "No error"
                break

        else: # :SYSTem:ERRor? should always return string.
            print(f"ERROR: :SYSTem:ERRor? returned nothing, command: '{command}'")
    )
    print("Exited because of error.")
    sys.exit(1)

# =====
# Main program:
# =====

rm = pyvisa.ResourceManager("C:\\Windows\\System32\\visa64.dll")
InfiniiVision = rm.open_resource("TCPIP0::k-mx3104g-10104.cos.is.keysigh
t.com::inst0::INSTR")

InfiniiVision.timeout = 15000
InfiniiVision.clear()

# Initialize the oscilloscope, capture data, and analyze.
initialize()
capture()
analyze()

InfiniiVision.close()
print("End of program.")
sys.exit()

```

VISA.NET Examples

These programming examples show how to use the VISA.NET drivers that come with Keysight IO Libraries Suite.

- ["VISA.NET Example in C#" on page 1821](#)
- ["VISA.NET Example in Visual Basic .NET" on page 1827](#)
- ["VISA.NET Example in Python" on page 1833](#)

VISA.NET Example in C#

To compile and run this example in Microsoft Visual Studio 2013:

- 1 Open Visual Studio.
- 2 Choose **FILE > New > Project...**
- 3 In the New Project dialog box, select **.NET Framework 4.5.2**.
- 4 Create a new Visual C#, Console Application project.
- 5 Cut-and-paste the code that follows into the C# source file.
- 6 Edit the program to use the VISA address of your oscilloscope.
- 7 Add a reference to the VISA.NET driver:
 - a Right-click the project you wish to modify (not the solution) in the Solution Explorer window of the Microsoft Visual Studio environment.
 - b Choose **Add Reference...**
 - c In the Reference Manager dialog box, under **Assemblies**, select **Extensions**.
 - d In the "Targeting: .NET Framework 4.5.2" list, select the **Ivi.Visa Assembly** check box; then, click **OK**.
- 8 Build and run the program.

For more information, see the VISA.NET Help that comes with Keysight IO Libraries Suite.

```

/*
 * Keysight VISA.NET Example in C#
 * -----
 * This program illustrates a few commonly used programming
 * features of your Keysight InfiniiVision oscilloscope.
 * -----
 */

using System;
using System.IO;
using System.Collections.Generic;
using System.Text;

using Ivi.Visa;
using Ivi.Visa.FormattedIO;

```

```

namespace Example
{
    class Program
    {
        static void Main(string[] args)
        {
            // Change this variable to the address of your instrument
            string VISA_ADDRESS = "TCPIP0::141.121.230.6::inst0::INSTR";

            // Create a connection (session) to the instrument
            IMessageBasedSession session;
            try
            {
                session = GlobalResourceManager.Open(VISA_ADDRESS) as
                    IMessageBasedSession;
            }
            catch (NativeVisaException visaException)
            {
                Console.WriteLine("Couldn't connect.");
                Console.WriteLine("Error is:\r\n{0}\r\n", visaException);
                Console.WriteLine("Press any key to exit...");
                Console.ReadKey();
                return;
            }

            // Create a formatted I/O object which will help us format the
            // data we want to send/receive to/from the instrument
            MessageBasedFormattedIO myScope =
                new MessageBasedFormattedIO(session);

            // For Serial and TCP/IP socket connections enable the read
            // Termination Character, or read's will timeout
            if (session.ResourceName.Contains("ASRL") ||
                session.ResourceName.Contains("SOCKET"))
                session.TerminationCharacterEnabled = true;

            session.TimeoutMilliseconds = 20000;

            // Initialize - start from a known state.
            // =====
            string strResults;
            FileStream fStream;

            // Get and display the device's *IDN? string.
            myScope.WriteLine("*IDN?");
            strResults = myScope.ReadLine();
            Console.WriteLine("*IDN? result is: {0}", strResults);

            // Clear status and load the default setup.
            myScope.WriteLine("*CLS");
            myScope.WriteLine("*RST");

            // Capture data.
            // =====

```

```

// Use auto-scale to automatically configure oscilloscope.
myScope.WriteLine(":AUToscale");

// Set trigger mode (EDGE, PULSe, PATTeRn, etc., and input source.
myScope.WriteLine(":TRIGger:MODE EDGE");
myScope.WriteLine(":TRIGger:MODE?");
strResults = myScope.ReadLine();
Console.WriteLine("Trigger mode: {0}", strResults);

// Set EDGE trigger parameters.
myScope.WriteLine(":TRIGger:EDGE:SOURce CHANnel1");
myScope.WriteLine(":TRIGger:EDGE:SOURce?");
strResults = myScope.ReadLine();
Console.WriteLine("Trigger edge source: {0}", strResults);

myScope.WriteLine(":TRIGger:EDGE:LEVel 1.5");
myScope.WriteLine(":TRIGger:EDGE:LEVel?");
strResults = myScope.ReadLine();
Console.WriteLine("Trigger edge level: {0}", strResults);

myScope.WriteLine(":TRIGger:EDGE:SLOPe POSitive");
myScope.WriteLine(":TRIGger:EDGE:SLOPe?");
strResults = myScope.ReadLine();
Console.WriteLine("Trigger edge slope: {0}", strResults);

// Save oscilloscope configuration.
byte[] ResultsArray; // Results array.
int nLength; // Number of bytes returned from instrument.
string strPath;

// Query and read setup string.
myScope.WriteLine(":SYSTem:SETUp?");
ResultsArray = myScope.ReadLineBinaryBlockOfByte();
nLength = ResultsArray.Length;

// Write setup string to file.
strPath = "c:\\scope\\config\\setup.stp";
fStream = File.Open(strPath, FileMode.Create);
fStream.Write(ResultsArray, 0, nLength);
fStream.Close();
Console.WriteLine("Setup bytes saved: {0}", nLength);

// Change settings with individual commands:

// Set vertical scale and offset.
myScope.WriteLine(":CHANnel1:SCALe 0.05");
myScope.WriteLine(":CHANnel1:SCALe?");
strResults = myScope.ReadLine();
Console.WriteLine("Channel 1 vertical scale: {0}", strResults);

myScope.WriteLine(":CHANnel1:OFFSet -1.5");
myScope.WriteLine(":CHANnel1:OFFSet?");
strResults = myScope.ReadLine();
Console.WriteLine("Channel 1 vertical offset: {0}", strResults);

// Set horizontal scale and offset.
myScope.WriteLine(":TIMEbase:SCALe 0.0002");

```

```

myScope.WriteLine(":TIMEbase:SCALE?");
strResults = myScope.ReadLine();
Console.WriteLine("Timebase scale: {0}", strResults);

myScope.WriteLine(":TIMEbase:POSition 0.0");
myScope.WriteLine(":TIMEbase:POSition?");
strResults = myScope.ReadLine();
Console.WriteLine("Timebase position: {0}", strResults);

// Set the acquisition type (NORMAL, PEAK, AVERAGE, or HRESOLUTION
).
myScope.WriteLine(":ACQUIRE:TYPE NORMAL");
myScope.WriteLine(":ACQUIRE:TYPE?");
strResults = myScope.ReadLine();
Console.WriteLine("Acquire type: {0}", strResults);

// Or, configure by loading a previously saved setup.
byte[] dataArray;
int nBytesWritten;

// Read setup string from file.
strPath = "c:\\scope\\config\\setup.stp";
dataArray = File.ReadAllBytes(strPath);
nBytesWritten = dataArray.Length;

// Restore setup string.
myScope.Write(":SYSTEM:SETUP ");
myScope.WriteBinary(dataArray);
myScope.WriteLine("");
Console.WriteLine("Setup bytes restored: {0}", nBytesWritten);

// Capture an acquisition using :DIGITIZE.
myScope.WriteLine(":DIGITIZE CHANNEL1");

// Analyze the captured waveform.
// =====

// Make a couple of measurements.
// -----
myScope.WriteLine(":MEASURE:SOURCE CHANNEL1");
myScope.WriteLine(":MEASURE:SOURCE?");
strResults = myScope.ReadLine();
Console.WriteLine("Measure source: {0}", strResults);

double fResult;
myScope.WriteLine(":MEASURE:FREQUENCY");
myScope.WriteLine(":MEASURE:FREQUENCY?");
fResult = myScope.ReadLineDouble();
Console.WriteLine("Frequency: {0:F4} kHz", fResult / 1000);

myScope.WriteLine(":MEASURE:VAMPLITUDE");
myScope.WriteLine(":MEASURE:VAMPLITUDE?");
fResult = myScope.ReadLineDouble();
Console.WriteLine("Vertical amplitude: {0:F2} V", fResult);

// Download the screen image.
// -----

```



```

myScope.WriteLine(":HARDcopy:INKSaver OFF");

// Get the screen data.
myScope.WriteLine(":DISPlay:DATA? PNG, COLOr");
ResultsArray = myScope.ReadLineBinaryBlockOfByte();
nLength = ResultsArray.Length;

// Store the screen data to a file.
strPath = "c:\\scope\\data\\screen.png";
fStream = File.Open(strPath, FileMode.Create);
fStream.Write(ResultsArray, 0, nLength);
fStream.Close();
Console.WriteLine("Screen image ({0} bytes) written to {1}",
    nLength, strPath);

// Download waveform data.
// -----

// Set the waveform points mode.
myScope.WriteLine(":WAVEform:POINts:MODE RAW");
myScope.WriteLine(":WAVEform:POINts:MODE?");
strResults = myScope.ReadLine();
Console.WriteLine("Waveform points mode: {0}", strResults);

// Get the number of waveform points available.
myScope.WriteLine(":WAVEform:POINts?");
strResults = myScope.ReadLine();
Console.WriteLine("Waveform points available: {0}", strResults);

// Set the waveform source.
myScope.WriteLine(":WAVEform:SOURce CHANnel1");
myScope.WriteLine(":WAVEform:SOURce?");
strResults = myScope.ReadLine();
Console.WriteLine("Waveform source: {0}", strResults);

// Choose the format of the data returned (WORD, BYTE, ASCII):
myScope.WriteLine(":WAVEform:FORMat BYTE");
myScope.WriteLine(":WAVEform:FORMat?");
strResults = myScope.ReadLine();
Console.WriteLine("Waveform format: {0}", strResults);

// Display the waveform settings:
double[] fResultsArray;
myScope.WriteLine(":WAVEform:PREAmble?");
fResultsArray = myScope.ReadLineListOfDouble();

double fFormat = fResultsArray[0];
if (fFormat == 0.0)
{
    Console.WriteLine("Waveform format: BYTE");
}
else if (fFormat == 1.0)
{
    Console.WriteLine("Waveform format: WORD");
}
else if (fFormat == 2.0)
{

```

```

    Console.WriteLine("Waveform format: ASCii");
}

double fType = fResultsArray[1];
if (fType == 0.0)
{
    Console.WriteLine("Acquire type: NORMAl");
}
else if (fType == 1.0)
{
    Console.WriteLine("Acquire type: PEAK");
}
else if (fType == 2.0)
{
    Console.WriteLine("Acquire type: AVERAge");
}
else if (fType == 3.0)
{
    Console.WriteLine("Acquire type: HRESolution");
}

double fPoints = fResultsArray[2];
Console.WriteLine("Waveform points: {0:e}", fPoints);

double fCount = fResultsArray[3];
Console.WriteLine("Waveform average count: {0:e}", fCount);

double fXincrement = fResultsArray[4];
Console.WriteLine("Waveform X increment: {0:e}", fXincrement);

double fXorigin = fResultsArray[5];
Console.WriteLine("Waveform X origin: {0:e}", fXorigin);

double fXreference = fResultsArray[6];
Console.WriteLine("Waveform X reference: {0:e}", fXreference);

double fYincrement = fResultsArray[7];
Console.WriteLine("Waveform Y increment: {0:e}", fYincrement);

double fYorigin = fResultsArray[8];
Console.WriteLine("Waveform Y origin: {0:e}", fYorigin);

double fYreference = fResultsArray[9];
Console.WriteLine("Waveform Y reference: {0:e}", fYreference);

// Read waveform data.
myScope.WriteLine(":WAVEform:DATA?");
ResultsArray = myScope.ReadLineBinaryBlockOfByte();
nLength = ResultsArray.Length;
Console.WriteLine("Number of data values: {0}", nLength);

// Set up output file:
strPath = "c:\\scope\\data\\waveform_data.csv";
if (File.Exists(strPath)) File.Delete(strPath);

// Open file for output.
StreamWriter writer = File.CreateText(strPath);

```

```

// Output waveform data in CSV format.
for (int i = 0; i < nLength - 1; i++)
    writer.WriteLine("{0:f9}, {1:f6}",
        fXorigin + ((float)i * fXincrement),
        (((float)ResultsArray[i] - fYreference)
        * fYincrement) + fYorigin);

// Close output file.
writer.Close();
Console.WriteLine("Waveform format BYTE data written to {0}",
    strPath);

// Close the connection to the instrument
// -----
session.Dispose();

Console.WriteLine("Press any key to exit...");
Console.ReadKey();

    }
}
}

```

VISA.NET Example in Visual Basic .NET

To compile and run this example in Microsoft Visual Studio 2013:

- 1 Open Visual Studio.
- 2 Choose **FILE > New > Project...**
- 3 In the New Project dialog box, select **.NET Framework 4.5.2**.
- 4 Create a new Visual Basic, Console Application project.
- 5 Cut-and-paste the code that follows into the Visual Basic .NET source file.
- 6 Edit the program to use the VISA address of your oscilloscope.
- 7 Add a reference to the VISA.NET driver:
 - a Right-click the project you wish to modify (not the solution) in the Solution Explorer window of the Microsoft Visual Studio environment.
 - b Choose **Add Reference...**
 - c In the Reference Manager dialog box, under **Assemblies**, select **Extensions**.
 - d In the "Targeting: .NET Framework 4.5.2" list, select the **Ivi.Visa Assembly** check box; then, click **OK**.

- 8 Specify the Startup object:
 - a Right-click the project you wish to modify (not the solution) in the Solution Explorer window of the Microsoft Visual Studio environment.
 - b Choose **Properties**.
 - c In the Properties dialog box, under **Application**, select the **Startup object:** field and choose **Sub Main**.
 - d Save your change and close the Properties dialog box.
- 9 Build and run the program.

For more information, see the VISA.NET driver help that comes with Keysight Command Expert.

```
'
' Keysight VISA.NET Example in VB.NET
' -----
' This program illustrates a few commonly used programming
' features of your Keysight InfiniiVision oscilloscope.
' -----

Imports System
Imports System.IO
Imports System.Collections.Generic
Imports System.Text

Imports Ivi.Visa
Imports Ivi.Visa.FormattedIO

Namespace Example
  Class Program

    Public Shared Sub Main(args As String())
      ' Change this variable to the address of your instrument
      Dim VISA_ADDRESS As String = "TCPIP0::141.121.230.6::inst0::INSTR"

      ' Create a connection (session) to the instrument
      Dim session As IMessageBasedSession
      Try
        session = TryCast(GlobalResourceManager.Open(VISA_ADDRESS), _
          IMessageBasedSession)
      Catch visaException As NativeVisaException
        Console.WriteLine("Couldn't connect.")
        Console.WriteLine("Error is:" & vbCr & vbLf & "{0}" _
          & vbCr & vbLf, visaException)
        Console.WriteLine("Press any key to exit...")
        Console.ReadKey()
        Return
      End Try

      ' Create a formatted I/O object which will help us format the
      ' data we want to send/receive to/from the instrument
      Dim myScope As New MessageBasedFormattedIO(session)
    End Sub
  End Class
End Namespace
```

```

' For Serial and TCP/IP socket connections enable the read
' Termination Character, or read's will timeout
If session.ResourceName.Contains("ASRL") OrElse _
    session.ResourceName.Contains("SOCKET") Then
    session.TerminationCharacterEnabled = True
End If

session.TimeoutMilliseconds = 20000

' Initialize - start from a known state.
' =====
Dim strResults As String
Dim fStream As FileStream

' Get and display the device's *IDN? string.
myScope.WriteLine("*IDN?")
strResults = myScope.ReadLine()
Console.WriteLine("*IDN? result is: {0}", strResults)

' Clear status and load the default setup.
myScope.WriteLine("*CLS")
myScope.WriteLine("*RST")

' Capture data.
' =====
' Use auto-scale to automatically configure oscilloscope.
myScope.WriteLine(":AUToscale")

' Set trigger mode (EDGE, PULSe, PATtern, etc., and input source.
myScope.WriteLine(":TRIGger:MODE EDGE")
myScope.WriteLine(":TRIGger:MODE?")
strResults = myScope.ReadLine()
Console.WriteLine("Trigger mode: {0}", strResults)

' Set EDGE trigger parameters.
myScope.WriteLine(":TRIGger:EDGE:SOURce CHANnel1")
myScope.WriteLine(":TRIGger:EDGE:SOURce?")
strResults = myScope.ReadLine()
Console.WriteLine("Trigger edge source: {0}", strResults)

myScope.WriteLine(":TRIGger:EDGE:LEVel 1.5")
myScope.WriteLine(":TRIGger:EDGE:LEVel?")
strResults = myScope.ReadLine()
Console.WriteLine("Trigger edge level: {0}", strResults)

myScope.WriteLine(":TRIGger:EDGE:SLOPe POSitive")
myScope.WriteLine(":TRIGger:EDGE:SLOPe?")
strResults = myScope.ReadLine()
Console.WriteLine("Trigger edge slope: {0}", strResults)

' Save oscilloscope configuration.
Dim ResultsArray As Byte()
' Results array.
Dim nLength As Integer
' Number of bytes returned from instrument.
Dim strPath As String

```

```

' Query and read setup string.
myScope.WriteLine(":SYSTEM:SETup?")
ResultsArray = myScope.ReadLineBinaryBlockOfByte()
nLength = ResultsArray.Length

' Write setup string to file.
strPath = "c:\scope\config\setup.stp"
fStream = File.Open(strPath, FileMode.Create)
fStream.Write(ResultsArray, 0, nLength)
fStream.Close()
Console.WriteLine("Setup bytes saved: {0}", nLength)

' Change settings with individual commands:

' Set vertical scale and offset.
myScope.WriteLine(":CHANnel1:SCALe 0.05")
myScope.WriteLine(":CHANnel1:SCALe?")
strResults = myScope.ReadLine()
Console.WriteLine("Channel 1 vertical scale: {0}", strResults)

myScope.WriteLine(":CHANnel1:OFFSet -1.5")
myScope.WriteLine(":CHANnel1:OFFSet?")
strResults = myScope.ReadLine()
Console.WriteLine("Channel 1 vertical offset: {0}", strResults)

' Set horizontal scale and offset.
myScope.WriteLine(":TIMebase:SCALe 0.0002")
myScope.WriteLine(":TIMebase:SCALe?")
strResults = myScope.ReadLine()
Console.WriteLine("Timebase scale: {0}", strResults)

myScope.WriteLine(":TIMebase:POSition 0.0")
myScope.WriteLine(":TIMebase:POSition?")
strResults = myScope.ReadLine()
Console.WriteLine("Timebase position: {0}", strResults)

' Set the acquisition type (NORMal, PEAK, AVERAge, or HRESolution)

myScope.WriteLine(":ACQuire:TYPE NORMal")
myScope.WriteLine(":ACQuire:TYPE?")
strResults = myScope.ReadLine()
Console.WriteLine("Acquire type: {0}", strResults)

' Or, configure by loading a previously saved setup.
Dim dataArray As Byte()
Dim nBytesWritten As Integer

' Read setup string from file.
strPath = "c:\scope\config\setup.stp"
dataArray = File.ReadAllBytes(strPath)
nBytesWritten = dataArray.Length

' Restore setup string.
myScope.Write(":SYSTEM:SETup ")
myScope.WriteBinary(dataArray)
myScope.WriteLine("")
Console.WriteLine("Setup bytes restored: {0}", nBytesWritten)

```

```

' Capture an acquisition using :DIGitize.
myScope.WriteLine(":DIGitize CHANnel1")

' Analyze the captured waveform.
' =====

' Make a couple of measurements.
' -----
myScope.WriteLine(":MEASure:SOURce CHANnel1")
myScope.WriteLine(":MEASure:SOURce?")
strResults = myScope.ReadLine()
Console.WriteLine("Measure source: {0}", strResults)

Dim fResult As Double
myScope.WriteLine(":MEASure:FREQuency")
myScope.WriteLine(":MEASure:FREQuency?")
fResult = myScope.ReadLineDouble()
Console.WriteLine("Frequency: {0:F4} kHz", fResult / 1000)

myScope.WriteLine(":MEASure:VAMPlitude")
myScope.WriteLine(":MEASure:VAMPlitude?")
fResult = myScope.ReadLineDouble()
Console.WriteLine("Vertical amplitude: {0:F2} V", fResult)

' Download the screen image.
' -----
myScope.WriteLine(":HARDcopy:INKSaver OFF")

' Get the screen data.
myScope.WriteLine(":DISPlay:DATA? PNG, COLor")
ResultsArray = myScope.ReadLineBinaryBlockOfByte()
nLength = ResultsArray.Length

' Store the screen data to a file.
strPath = "c:\scope\data\screen.png"
fStream = File.Open(strPath, FileMode.Create)
fStream.Write(ResultsArray, 0, nLength)
fStream.Close()
Console.WriteLine("Screen image ({0} bytes) written to {1}", _
    nLength, strPath)

' Download waveform data.
' -----

' Set the waveform points mode.
myScope.WriteLine(":WAVEform:POINts:MODE RAW")
myScope.WriteLine(":WAVEform:POINts:MODE?")
strResults = myScope.ReadLine()
Console.WriteLine("Waveform points mode: {0}", strResults)

' Get the number of waveform points available.
myScope.WriteLine(":WAVEform:POINts?")
strResults = myScope.ReadLine()
Console.WriteLine("Waveform points available: {0}", strResults)

' Set the waveform source.

```

```

myScope.WriteLine(":WAVEform:SOURce CHANnel1")
myScope.WriteLine(":WAVEform:SOURce?")
strResults = myScope.ReadLine()
Console.WriteLine("Waveform source: {0}", strResults)

' Choose the format of the data returned (WORD, BYTE, ASCII):
myScope.WriteLine(":WAVEform:FORMat BYTE")
myScope.WriteLine(":WAVEform:FORMat?")
strResults = myScope.ReadLine()
Console.WriteLine("Waveform format: {0}", strResults)

' Display the waveform settings:
Dim fResultsArray As Double()
myScope.WriteLine(":WAVEform:PREamble?")
fResultsArray = myScope.ReadLineListOfDouble()

Dim fFormat As Double = fResultsArray(0)
If fFormat = 0.0 Then
    Console.WriteLine("Waveform format: BYTE")
ElseIf fFormat = 1.0 Then
    Console.WriteLine("Waveform format: WORD")
ElseIf fFormat = 2.0 Then
    Console.WriteLine("Waveform format: ASCii")
End If

Dim fType As Double = fResultsArray(1)
If fType = 0.0 Then
    Console.WriteLine("Acquire type: NORMAl")
ElseIf fType = 1.0 Then
    Console.WriteLine("Acquire type: PEAK")
ElseIf fType = 2.0 Then
    Console.WriteLine("Acquire type: AVERAge")
ElseIf fType = 3.0 Then
    Console.WriteLine("Acquire type: HRESolution")
End If

Dim fPoints As Double = fResultsArray(2)
Console.WriteLine("Waveform points: {0:e}", fPoints)

Dim fCount As Double = fResultsArray(3)
Console.WriteLine("Waveform average count: {0:e}", fCount)

Dim fXincrement As Double = fResultsArray(4)
Console.WriteLine("Waveform X increment: {0:e}", fXincrement)

Dim fXorigin As Double = fResultsArray(5)
Console.WriteLine("Waveform X origin: {0:e}", fXorigin)

Dim fXreference As Double = fResultsArray(6)
Console.WriteLine("Waveform X reference: {0:e}", fXreference)

Dim fYincrement As Double = fResultsArray(7)
Console.WriteLine("Waveform Y increment: {0:e}", fYincrement)

Dim fYorigin As Double = fResultsArray(8)
Console.WriteLine("Waveform Y origin: {0:e}", fYorigin)

```



```

Dim fYreference As Double = fResultsArray(9)
Console.WriteLine("Waveform Y reference: {0:e}", fYreference)

' Read waveform data.
myScope.WriteLine(":WAVEform:DATA?")
ResultsArray = myScope.ReadLineBinaryBlockOfByte()
nLength = ResultsArray.Length
Console.WriteLine("Number of data values: {0}", nLength)

' Set up output file:
strPath = "c:\scope\data\waveform_data.csv"
If File.Exists(strPath) Then
    File.Delete(strPath)
End If

' Open file for output.
Dim writer As StreamWriter = File.CreateText(strPath)

' Output waveform data in CSV format.
For i As Integer = 0 To nLength - 2
    writer.WriteLine("{0:f9}, {1:f6}", _
        fXorigin + (CSng(i) * fXincrement), _
        ((CSng(ResultsArray(i)) - fYreference) *
        fYincrement) + fYorigin)
Next

' Close output file.
writer.Close()
Console.WriteLine("Waveform format BYTE data written to {0}", _
    strPath)

' Close the connection to the instrument
' -----
session.Dispose()

Console.WriteLine("Press any key to exit...")
Console.ReadKey()

End Sub
End Class
End Namespace

```

VISA.NET Example in Python

You can use the Python programming language with the "Python.NET" package (or IronPython) to control Keysight oscilloscopes.

The Python language and "Python.NET" package can be downloaded from the web at <http://www.python.org/> and <http://pythonnet.github.io/>, respectively.

To run this example with Python and "Python.NET":

- 1 Cut-and-paste the code that follows into a file named "example.py".
- 2 Edit the program to use the VISA address of your oscilloscope.

- 3 If "python.exe" can be found via your PATH environment variable, open a Command Prompt window; then, change to the folder that contains the "example.py" file, and enter:

```
python example.py

#!python3
# -*- coding: utf-8 -*-

# Keysight VISA.NET Example in Python.NET or IronPython
# *****
# This program illustrates a few commonly-used programming
# features of your Keysight InfiniiVision oscilloscope.
# *****

# Import Python modules.
# -----
import sys
sys.path.append("C:\\Program Files\\IVI Foundation\\VISA\\Microsoft.NET\\
\\Framework64\\v2.0.50727\\VISA.NET Shared Components 5.8.0")

# Import .NET modules.
# -----
import clr
clr.AddReference("Ivi.Visa")
from Ivi.Visa import *
from Ivi.Visa.FormattedIO import *
from System import *
from System.IO import *

# Global variables.
# -----
visa_addr = "TCPIP0::k-mx3104g-10104.cos.is.keysight.com::inst0::INSTR"
io_timeout_ms = 20000
# input_channel = "CHANnel1"
input_channel = "CHANnel2"
setup_file_name = "setup.scp"
screen_image_file_name = "screen_image.png"
waveform_data_file_name = "waveform_data.csv"
# wfm_fmt = "BYTE"
wfm_fmt = "WORD"

# =====
# Check for instrument errors:
# =====
def check_instrument_errors(when):

    errors_found = False
    while True:
        # Keep reading errors until "No error".
        myScope.WriteLine(":SYSTem:ERRor?")
        error_string = myScope.ReadLine().strip()
        if error_string: # If there is an error string value.

            if error_string.find("+0,", 0, 3) == -1: # Not "No error".
                errors_found = True
```

```

        print(f"ERROR: {error_string}")

    else:    # "No error"
        break

    else:    # :SYSTem:ERROr? should always return string.
        errors_found = True
        print("ERROR: ':SYSTem:ERROr?' empty.")
        break

if errors_found:
    print(f"Exited because error(s) found when: '{when}'")
    sys.exit(1)

# =====
# Initialize:
# =====
def initialize():

    # Get and display the device's *IDN? string.
    myScope.WriteLine("*IDN?")
    idn_string = myScope.ReadLine().strip()
    print(f"Identification string: '{idn_string}'")

    # Clear status and load the default setup.
    myScope.WriteLine("*CLS")
    myScope.WriteLine("*RST")

# =====
# Capture:
# =====
def capture():

    # Display the input channel.
    myScope.WriteLine(":CHANnel1:DISPlay OFF")
    myScope.WriteLine(f":{input_channel}:DISPlay ON")

    # Use auto-scale to automatically set up oscilloscope.
    print("Autoscale.")
    myScope.WriteLine(":AUToscale:CHANnels DISPlayed")
    myScope.WriteLine(":AUToscale")

    # Set trigger mode.
    myScope.WriteLine(":TRIGger:MODE EDGE")
    myScope.WriteLine(":TRIGger:MODE?")
    qresult = myScope.ReadLine().strip()
    print(f"Trigger mode: {qresult}")

    # Set EDGE trigger parameters.
    myScope.WriteLine(f":TRIGger:EDGE:SOURce {input_channel}")
    myScope.WriteLine(":TRIGger:EDGE:SOURce?")
    qresult = myScope.ReadLine().strip()
    print(f"Trigger edge source: {qresult}")

    myScope.WriteLine(":TRIGger:EDGE:LEVel 1.5")

```

```

myScope.WriteLine(":TRIGger:EDGE:LEVel?")
qresult = myScope.ReadLine().strip()
print(f"Trigger edge level: {qresult}")

myScope.WriteLine(":TRIGger:EDGE:SLOPe POSitive")
myScope.WriteLine(":TRIGger:EDGE:SLOPe?")
qresult = myScope.ReadLine().strip()
print(f"Trigger edge slope: {qresult}")

# Save oscilloscope setup to file.
myScope.WriteLine(":SYSTem:SETup?")
setup_bytes = myScope.ReadLineBinaryBlockOfByte()
File.WriteAllBytes(setup_file_name, setup_bytes)
print(f"Setup bytes saved: {len(setup_bytes)}")

# Change settings with individual commands:

# Set vertical scale and offset.
myScope.WriteLine(f":{input_channel}:SCALE 0.05")
myScope.WriteLine(f":{input_channel}:SCALE?")
qresult = myScope.ReadLine().strip()
print(f"{input_channel} vertical scale: {qresult}")

myScope.WriteLine(f":{input_channel}:OFFSet -1.5")
myScope.WriteLine(f":{input_channel}:OFFSet?")
qresult = myScope.ReadLine().strip()
print(f"{input_channel} offset: {qresult}")

# Set horizontal scale and offset.
myScope.WriteLine(":TIMEbase:SCALE 0.0002")
myScope.WriteLine(":TIMEbase:SCALE?")
qresult = myScope.ReadLine().strip()
print(f"Timebase scale: {qresult}")

myScope.WriteLine(":TIMEbase:POSition 0.0")
myScope.WriteLine(":TIMEbase:POSition?")
qresult = myScope.ReadLine().strip()
print(f"Timebase position: {qresult}")

# Set the acquisition type.
myScope.WriteLine(":ACQuire:TYPE NORMAL")
myScope.WriteLine(":ACQuire:TYPE?")
qresult = myScope.ReadLine().strip()
print(f"Acquire type: {qresult}")

# Or, configure by loading a previously saved setup.

# Read setup string from file.
setup_bytes = File.ReadAllBytes(setup_file_name)

# Restore setup string.
myScope.Write(":SYSTem:SETup ")
write_binary = myScope.WriteBinary.Overloads[Array[Byte]]
write_binary(setup_bytes)
myScope.WriteLine("")
print(f"Setup bytes restored: {len(setup_bytes)}")

```

```

# Capture an acquisition using :DIGitize.
myScope.WriteLine(f":DIGitize {input_channel}")

# =====
# Analyze:
# =====
def analyze():

    # Make measurements.
    # -----
    myScope.WriteLine(f":MEASure:SOURce {input_channel}")
    myScope.WriteLine(":MEASure:SOURce?")
    qresult = myScope.ReadLine().strip()
    print(f"Measure source: {qresult}")

    myScope.WriteLine(":MEASure:FREQuency")
    myScope.WriteLine(":MEASure:FREQuency?")
    qresult = myScope.ReadLineDouble()
    print(f"Measured frequency on {input_channel}: {qresult:f}")

    myScope.WriteLine(":MEASure:VAMPlitude")
    myScope.WriteLine(":MEASure:VAMPlitude?")
    qresult = myScope.ReadLineDouble()
    print(f"Measured vertical amplitude on {input_channel}: {qresult:f}")

    # Download the screen image.
    # -----
    myScope.WriteLine(":HARDcopy:INKSaver OFF")

    # Get the screen data.
    myScope.WriteLine(":DISPlay:DATA? PNG, COLor")
    image_bytes = myScope.ReadLineBinaryBlockOfByte()
    image_bytes_length = len(image_bytes)
    fStream = File.Open(screen_image_file_name, FileMode.Create)
    fStream.Write(image_bytes, 0, image_bytes_length)
    fStream.Close()
    print(f"Screen image written to {screen_image_file_name}.")

    # Download waveform data.
    # -----

    # Set the waveform source.
    myScope.WriteLine(f":WAVeform:SOURce {input_channel}")
    myScope.WriteLine(":WAVeform:SOURce?")
    qresult = myScope.ReadLine().strip()
    print(f"Waveform source: {qresult}")

    # Set the waveform points mode.
    myScope.WriteLine(":WAVeform:POINts:MODE RAW")
    myScope.WriteLine(":WAVeform:POINts:MODE?")
    qresult = myScope.ReadLine().strip()
    print(f"Waveform points mode: {qresult}")

    # Get the number of waveform points available.
    myScope.WriteLine(":WAVeform:POINts 10240")
    myScope.WriteLine(":WAVeform:POINts?")

```

```

qresult = myScope.ReadLine().strip()
print(f"Waveform points available: {qresult}")

# Choose the format of the data returned (BYTE or WORD):
myScope.WriteLine(f":WAVEform:FORMat {wfm_fmt}")
myScope.WriteLine(":WAVEform:FORMat?")
qresult = myScope.ReadLine().strip()
print(f"Waveform format: {qresult}")

# Display the waveform settings from preamble:
wav_form_dict = {
    0 : "BYTE",
    1 : "WORD",
    4 : "AScii",
}
acq_type_dict = {
    0 : "NORMal",
    1 : "PEAK",
    2 : "AVERage",
    3 : "HRESolution",
}

myScope.WriteLine(":WAVEform:PREAmble?")
(
    wav_form, acq_type, wfmppts, avgcnt, x_increment, x_origin,
    x_reference, y_increment, y_origin, y_reference
) = myScope.ReadLine().split(",")

print(f"Waveform format: {wav_form_dict[int(wav_form)]}")
print(f"Acquire type: {acq_type_dict[int(acq_type)]}")
print(f"Waveform points desired: {wfmppts}")
print(f"Waveform average count: {avgcnt}")
print(f"Waveform X reference: {x_reference}") # Always 0.

# Get numeric values for later calculations.
myScope.WriteLine(":WAVEform:XINCrement?")
x_increment = myScope.ReadLineDouble()
print(f"Waveform X increment: {x_increment}")
myScope.WriteLine(":WAVEform:XORigin?")
x_origin = myScope.ReadLineDouble()
print(f"Waveform X origin: {x_origin}")
myScope.WriteLine(":WAVEform:YINCrement?")
y_increment = myScope.ReadLineDouble()
print(f"Waveform Y increment: {y_increment}")
myScope.WriteLine(":WAVEform:YORigin?")
y_origin = myScope.ReadLineDouble()
print(f"Waveform Y origin: {y_origin}")
myScope.WriteLine(":WAVEform:YREFerence?")
y_reference = myScope.ReadLineDouble()
print(f"Waveform Y reference: {y_reference}")

# Specify the byte order in WORD data.
if wfm_fmt == "WORD":
    myScope.WriteLine(":WAVEform:BYTeorder MSBF")
    myScope.WriteLine(":WAVEform:BYTeorder?")
    qresult = myScope.ReadLine().strip()
    print(f"Waveform byte order for WORD data: {qresult}")

```

```

# Get the waveform data values.
myScope.WriteLine(":WAVEform:DATA?")
if wfm_fmt == "BYTE":
    values = myScope.ReadLineBinaryBlockOfByte()
elif wfm_fmt == "WORD":
    values = myScope.ReadLineBinaryBlockOfUInt16()
values_length = len(values)
print(f"Number of data values: {values_length}")

# Open file for output.
writer = File.CreateText(waveform_data_file_name)

# Output waveform data in CSV format.
for i in range(0, values_length - 1):
    time_val = x_origin + i * x_increment
    voltage = (values[i] - y_reference) * y_increment + y_origin
    writer.WriteLine(f"{time_val:E}, {voltage:f}")

# Close output file.
writer.Close()
print(f"Waveform format {wfm_fmt} data written to {waveform_data_file_name}.")

# =====
# Main program:
# =====
session = GlobalResourceManager.Open(visa_addr)
session.TimeoutMilliseconds = io_timeout_ms
myScope = MessageBasedFormattedIO(session)

# Initialize the oscilloscope, capture data, and analyze.
initialize()
capture()
analyze()

# Check for oscilloscope instrument errors.
check_instrument_errors("End of program")

# Close the connection to the instrument
session.Dispose()
print("End of program.")

# Wait for a key press before exiting.
print("Press any key to exit...")
Console.ReadKey(True)

```

SICL Examples

- **"SICL Example in C"** on page 1840
- **"SICL Example in Visual Basic"** on page 1849

SICL Example in C

To compile and run this example in Microsoft Visual Studio 2008:

- 1 Open Visual Studio.
- 2 Create a new Visual C++, Win32, Win32 Console Application project.
- 3 In the Win32 Application Wizard, click **Next >**. Then, check **Empty project**, and click **Finish**.
- 4 Cut-and-paste the code that follows into a file named "example.c" in the project directory.
- 5 In Visual Studio 2008, right-click the Source Files folder, choose **Add > Add Existing Item...**, select the example.c file, and click **Add**.
- 6 Edit the program to use the SICL address of your oscilloscope.
- 7 Choose **Project > Properties....** In the Property Pages dialog, update these project settings:
 - a Under Configuration Properties, Linker, Input, add "sicl32.lib" to the Additional Dependencies field.
 - b Under Configuration Properties, C/C++, Code Generation, select Multi-threaded DLL for the Runtime Library field.
 - c Click **OK** to close the Property Pages dialog.
- 8 Add the include files and library files search paths:
 - a Choose **Tools > Options....**
 - b In the Options dialog, select **VC++ Directories** under Projects and Solutions.
 - c Show directories for **Include files**, and add the include directory (for example, Program Files\Agilent\IO Libraries Suite\include).
 - d Show directories for **Library files**, and add the library files directory (for example, Program Files\Agilent\IO Libraries Suite\lib).
 - e Click **OK** to close the Options dialog.
- 9 Build and run the program.

```

/*
 * Keysight SICL Example in C
 * -----
 * This program illustrates a few commonly-used programming
 * features of your Keysight oscilloscope.
 */

#include <stdio.h>                                /* For printf(). */

```



```

#include <string.h>          /* For strcpy(), strcat(). */
#include <time.h>           /* For clock(). */
#include <sicl.h>           /* Keysight SICL routines. */

#define SICL_ADDRESS       "usb0[2391::6054::US50210029::0]"
#define TIMEOUT           5000
#define IEEEBLOCK_SPACE   300000

/* Function prototypes */
void initialize(void);      /* Initialize to known state. */
void capture(void);        /* Capture the waveform. */
void analyze(void);        /* Analyze the captured waveform. */

void do_command(char *command); /* Send command. */
int do_command_ieeeblock(char *command); /* Command w/IEEE block. */
void do_query_string(char *query); /* Query for string. */
void do_query_number(char *query); /* Query for number. */
void do_query_numbers(char *query); /* Query for numbers. */
int do_query_ieeeblock(char *query); /* Query for IEEE block. */
void check_instrument_errors(); /* Check for inst errors. */

/* Global variables */
INST id; /* Device session ID. */
char str_result[256] = {0}; /* Result from do_query_string(). */
double num_result; /* Result from do_query_number(). */
unsigned char ieeeblock_data[IEEBLOCK_SPACE]; /* Result from
do_query_ieeeblock(). */
double dbl_results[10]; /* Result from do_query_numbers(). */

/* Main Program
* ----- */
void main(void)
{
    /* Install a default SICL error handler that logs an error message
    * and exits. On Windows 98SE or Windows Me, view messages with
    * the SICL Message Viewer. For Windows 2000 or XP, use the Event
    * Viewer.
    */
    ionerror(I_ERROR_EXIT);

    /* Open a device session using the SICL_ADDRESS */
    id = iopen(SICL_ADDRESS);

    if (id == 0)
    {
        printf ("Oscilloscope iopen failed!\n");
    }
    else
    {
        printf ("Oscilloscope session opened!\n");
    }

    /* Initialize - start from a known state. */
    initialize();

    /* Capture data. */
    capture();

```

```

/* Analyze the captured waveform. */
analyze();

/* Close the device session to the instrument. */
fclose(id);
printf ("Program execution is complete...\n");

/* For WIN16 programs, call _siclcleanup before exiting to release
 * resources allocated by SICL for this application. This call is
 * a no-op for WIN32 programs.
 */
_siclcleanup();
}

/* Initialize the oscilloscope to a known state.
 * ----- */
void initialize (void)
{
/* Set the I/O timeout value for this session to 5 seconds. */
itimeout(id, TIMEOUT);

/* Clear the interface. */
iclear(id);

/* Get and display the device's *IDN? string. */
do_query_string("*IDN?");
printf("Oscilloscope *IDN? string: %s\n", str_result);

/* Clear status and load the default setup. */
do_command("*CLS");
do_command("*RST");
}

/* Capture the waveform.
 * ----- */
void capture (void)
{
int num_bytes;
FILE *fp;

/* Use auto-scale to automatically configure oscilloscope.
 * ----- */
do_command(":AUToscale");

/* Set trigger mode (EDGE, PULSe, PATtern, etc., and input source. */
do_command(":TRIGger:MODE EDGE");
do_query_string(":TRIGger:MODE?");
printf("Trigger mode: %s\n", str_result);

/* Set EDGE trigger parameters. */
do_command(":TRIGger:EDGE:SOURce CHANnel1");
do_query_string(":TRIGger:EDGE:SOURce?");
printf("Trigger edge source: %s\n", str_result);

do_command(":TRIGger:EDGE:LEVel 1.5");
do_query_string(":TRIGger:EDGE:LEVel?");
}

```

```

printf("Trigger edge level: %s\n", str_result);

do_command(":TRIGger:EDGE:SLOPe POSitive");
do_query_string(":TRIGger:EDGE:SLOPe?");
printf("Trigger edge slope: %s\n", str_result);

/* Save oscilloscope configuration.
 * ----- */

/* Read system setup. */
num_bytes = do_query_ieeeblock(":SYSTem:SETup?");
printf("Read setup string query (%d bytes).\n", num_bytes);

/* Write setup string to file. */
fp = fopen ("c:\\scope\\config\\setup.stp", "wb");
num_bytes = fwrite(ieeeblock_data, sizeof(unsigned char), num_bytes,
    fp);
fclose (fp);
printf("Wrote setup string (%d bytes) to ", num_bytes);
printf("c:\\scope\\config\\setup.stp.\n");

/* Change settings with individual commands:
 * ----- */

/* Set vertical scale and offset. */
do_command(":CHANnel1:SCALe 0.05");
do_query_string(":CHANnel1:SCALe?");
printf("Channel 1 vertical scale: %s\n", str_result);

do_command(":CHANnel1:OFFSet -1.5");
do_query_string(":CHANnel1:OFFSet?");
printf("Channel 1 offset: %s\n", str_result);

/* Set horizontal scale and position. */
do_command(":TIMEbase:SCALe 0.0002");
do_query_string(":TIMEbase:SCALe?");
printf("Timebase scale: %s\n", str_result);

do_command(":TIMEbase:POSition 0.0");
do_query_string(":TIMEbase:POSition?");
printf("Timebase position: %s\n", str_result);

/* Set the acquisition type (NORMAL, PEAK, AVERage, or HRESolution). *
/
do_command(":ACQuire:TYPE NORMAl");
do_query_string(":ACQuire:TYPE?");
printf("Acquire type: %s\n", str_result);

/* Or, configure by loading a previously saved setup.
 * ----- */

/* Read setup string from file. */
fp = fopen ("c:\\scope\\config\\setup.stp", "rb");
num_bytes = fread (ieeeblock_data, sizeof(unsigned char),
    IEEEBLOCK_SPACE, fp);
fclose (fp);
printf("Read setup string (%d bytes) from file ", num_bytes);

```

```

printf("c:\\scope\\config\\setup.stp.\n");

/* Restore setup string. */
num_bytes = do_command_ieeeblock(":SYSTEM:SETup", num_bytes);
printf("Restored setup string (%d bytes).\n", num_bytes);

/* Capture an acquisition using :DIGitize.
 * ----- */
do_command(":DIGitize CHANnel1");
}

/* Analyze the captured waveform.
 * ----- */
void analyze (void)
{
    double wav_format;
    double acq_type;
    double wav_points;
    double avg_count;
    double x_increment;
    double x_origin;
    double x_reference;
    double y_increment;
    double y_origin;
    double y_reference;

    FILE *fp;
    int num_bytes; /* Number of bytes returned from instrument. */
    int i;

    /* Make a couple of measurements.
     * ----- */
    do_command(":MEASure:SOURce CHANnel1");
    do_query_string(":MEASure:SOURce?");
    printf("Measure source: %s\n", str_result);

    do_command(":MEASure:FREQuency");
    do_query_number(":MEASure:FREQuency?");
    printf("Frequency: %.4f kHz\n", num_result / 1000);

    do_command(":MEASure:VAMPlitude");
    do_query_number(":MEASure:VAMPlitude?");
    printf("Vertical amplitude: %.2f V\n", num_result);

    /* Download the screen image.
     * ----- */
    do_command(":HARDcopy:INKSaver OFF");

    /* Read screen image. */
    num_bytes = do_query_ieeeblock(":DISPlay:DATA? PNG, COLor");
    printf("Screen image bytes: %d\n", num_bytes);

    /* Write screen image bytes to file. */
    fp = fopen ("c:\\scope\\data\\screen.png", "wb");
    num_bytes = fwrite(ieeeblock_data, sizeof(unsigned char), num_bytes,
        fp);
    fclose (fp);

```

```

printf("Wrote screen image (%d bytes) to ", num_bytes);
printf("c:\\scope\\data\\screen.png.\n");

/* Download waveform data.
 * ----- */

/* Set the waveform points mode. */
do_command(":WAVEform:POINTs:MODE RAW");
do_query_string(":WAVEform:POINTs:MODE?");
printf("Waveform points mode: %s\n", str_result);

/* Get the number of waveform points available. */
do_command(":WAVEform:POINTs 10240");
do_query_string(":WAVEform:POINTs?");
printf("Waveform points available: %s\n", str_result);

/* Set the waveform source. */
do_command(":WAVEform:SOURce CHANnel1");
do_query_string(":WAVEform:SOURce?");
printf("Waveform source: %s\n", str_result);

/* Choose the format of the data returned (WORD, BYTE, ASCII): */
do_command(":WAVEform:FORMat BYTE");
do_query_string(":WAVEform:FORMat?");
printf("Waveform format: %s\n", str_result);

/* Display the waveform settings: */
do_query_numbers(":WAVEform:PREAmble?");

wav_format = dbl_results[0];
if (wav_format == 0.0)
{
    printf("Waveform format: BYTE\n");
}
else if (wav_format == 1.0)
{
    printf("Waveform format: WORD\n");
}
else if (wav_format == 2.0)
{
    printf("Waveform format: ASCii\n");
}

acq_type = dbl_results[1];
if (acq_type == 0.0)
{
    printf("Acquire type: NORMal\n");
}
else if (acq_type == 1.0)
{
    printf("Acquire type: PEAK\n");
}
else if (acq_type == 2.0)
{
    printf("Acquire type: AVERage\n");
}
else if (acq_type == 3.0)

```

```

    {
        printf("Acquire type: HRESolution\n");
    }

    wav_points = dbl_results[2];
    printf("Waveform points: %e\n", wav_points);

    avg_count = dbl_results[3];
    printf("Waveform average count: %e\n", avg_count);

    x_increment = dbl_results[4];
    printf("Waveform X increment: %e\n", x_increment);

    x_origin = dbl_results[5];
    printf("Waveform X origin: %e\n", x_origin);

    x_reference = dbl_results[6];
    printf("Waveform X reference: %e\n", x_reference);

    y_increment = dbl_results[7];
    printf("Waveform Y increment: %e\n", y_increment);

    y_origin = dbl_results[8];
    printf("Waveform Y origin: %e\n", y_origin);

    y_reference = dbl_results[9];
    printf("Waveform Y reference: %e\n", y_reference);

    /* Read waveform data. */
    num_bytes = do_query_ieeeblock(":WAVEform:DATA?");
    printf("Number of data values: %d\n", num_bytes);

    /* Open file for output. */
    fp = fopen("c:\\scope\\data\\waveform_data.csv", "wb");

    /* Output waveform data in CSV format. */
    for (i = 0; i < num_bytes - 1; i++)
    {
        /* Write time value, voltage value. */
        fprintf(fp, "%9f, %6f\n",
            x_origin + ((float)i * x_increment),
            (((float)ieeeblock_data[i] - y_reference) * y_increment)
            + y_origin);
    }

    /* Close output file. */
    fclose(fp);
    printf("Waveform format BYTE data written to ");
    printf("c:\\scope\\data\\waveform_data.csv.\n");
}

/* Send a command to the instrument.
 * ----- */
void do_command(command)
char *command;
{
    char message[80];

```

```

    strcpy(message, command);
    strcat(message, "\n");
    iprintf(id, message);

    check_instrument_errors();
}

/* Command with IEEE definite-length block.
 * ----- */
int do_command_ieeeblock(command, num_bytes)
char *command;
int num_bytes;
{
    char message[80];
    int data_length;

    strcpy(message, command);
    strcat(message, " #8%08d");
    iprintf(id, message, num_bytes);
    ifwrite(id, ieeeblock_data, num_bytes, 1, &data_length);

    check_instrument_errors();

    return(data_length);
}

/* Query for a string result.
 * ----- */
void do_query_string(query)
char *query;
{
    char message[80];

    strcpy(message, query);
    strcat(message, "\n");
    iprintf(id, message);

    iscanf(id, "%t\n", str_result);

    check_instrument_errors();
}

/* Query for a number result.
 * ----- */
void do_query_number(query)
char *query;
{
    char message[80];

    strcpy(message, query);
    strcat(message, "\n");
    iprintf(id, message);

    iscanf(id, "%lf", &num_result);

    check_instrument_errors();
}

```

```

}

/* Query for numbers result.
 * ----- */
void do_query_numbers(query)
char *query;
{
    char message[80];

    strcpy(message, query);
    strcat(message, "\n");
    fprintf(id, message);

    iscanf(id, "%,10lf\n", dbl_results);

    check_instrument_errors();
}

/* Query for an IEEE definite-length block result.
 * ----- */
int do_query_ieeeblock(query)
char *query;
{
    char message[80];
    int data_length;

    strcpy(message, query);
    strcat(message, "\n");
    fprintf(id, message);

    data_length = IEEEBLOCK_SPACE;
    iscanf(id, "%#b", &data_length, ieeeblock_data);

    if (data_length == IEEEBLOCK_SPACE )
    {
        printf("IEEE block buffer full: ");
        printf("May not have received all data.\n");
    }

    check_instrument_errors();

    return(data_length);
}

/* Check for instrument errors.
 * ----- */
void check_instrument_errors()
{
    char str_err_val[256] = {0};
    char str_out[800] = "";

    ipromptf(id, ":SYSTem:ERRor?\n", "%t", str_err_val);
    while(strncmp(str_err_val, "+0,No error", 3) != 0 )
    {
        strcat(str_out, ", ");
        strcat(str_out, str_err_val);
        ipromptf(id, ":SYSTem:ERRor?\n", "%t", str_err_val);
    }
}

```



```

    }

    if (strcmp(str_out, "") != 0)
    {
        printf("INST Error%s\n", str_out);
        iflush(id, I_BUF_READ | I_BUF_WRITE);
    }
}

```

SICL Example in Visual Basic

To run this example in Visual Basic for Applications:

- 1 Start the application that provides Visual Basic for Applications (for example, Microsoft Excel).
- 2 Press ALT+F11 to launch the Visual Basic editor.
- 3 Add the sicl32.bas file to your project:
 - a Choose **File > Import File...**
 - b Navigate to the header file, sicl32.bas (installed with Keysight IO Libraries Suite and found in the Program Files\Agilent\IO Libraries Suite\include directory), select it, and click **Open**.
- 4 Choose **Insert > Module**.
- 5 Cut-and-paste the code that follows into the editor.
- 6 Edit the program to use the SICL address of your oscilloscope, and save the changes.
- 7 Run the program.

```

'
' Keysight SICL Example in Visual Basic
' -----
' This program illustrates a few commonly-used programming
' features of your Keysight oscilloscope.
' -----

Option Explicit

Public id As Integer ' Session to instrument.

' Declare variables to hold numeric values returned by
' ivscanf/ifread.
Public dblQueryResult As Double
Public Const ByteArraySize = 5000000
Public retCount As Long
Public byteArray(ByteArraySize) As Byte

' Declare fixed length string variable to hold string value returned
' by ivscanf.
Public strQueryResult As String * 200

' For Sleep subroutine.

```

```

Private Declare Sub Sleep Lib "kernel32" (ByVal dwMilliseconds As Long)

'
' Main Program
' -----

Sub Main()

    On Error GoTo ErrorHandler

    ' Open a device session using the SICL_ADDRESS.
    id = iopen("usb0[2391::6054::US50210029::0]")
    Call itimeout(id, 5000)

    ' Initialize - start from a known state.
    Initialize

    ' Capture data.
    Capture

    ' Analyze the captured waveform.
    Analyze

    ' Close the vi session and the resource manager session.
    Call iclose(id)

    Exit Sub

ErrorHandler:

    MsgBox "*** Error : " + Error, vbExclamation
    End

End Sub

'
' Initialize the oscilloscope to a known state.
' -----

Private Sub Initialize()

    On Error GoTo ErrorHandler

    ' Clear the interface.
    Call iclear(id)

    ' Get and display the device's *IDN? string.
    strQueryResult = DoQueryString("*IDN?")
    MsgBox "Result is: " + RTrim(strQueryResult), vbOKOnly, "*IDN? Result"

    ' Clear status and load the default setup.
    DoCommand "*CLS"
    DoCommand "*RST"

    Exit Sub

ErrorHandler:

```

```

MsgBox "*** Error : " + Error, vbExclamation
End

End Sub

'
' Capture the waveform.
' -----

Private Sub Capture()

    On Error GoTo ErrorHandler

    ' Use auto-scale to automatically configure oscilloscope.
    ' -----
    DoCommand ":AUToscale"

    ' Set trigger mode (EDGE, PULSe, PATtern, etc., and input source.
    DoCommand ":TRIGger:MODE EDGE"
    Debug.Print "Trigger mode: " + _
        DoQueryString(":TRIGger:MODE?")

    ' Set EDGE trigger parameters.
    DoCommand ":TRIGger:EDGE:SOURce CHANnel1"
    Debug.Print "Trigger edge source: " + _
        DoQueryString(":TRIGger:EDGE:SOURce?")

    DoCommand ":TRIGger:EDGE:LEVel 1.5"
    Debug.Print "Trigger edge level: " + _
        DoQueryString(":TRIGger:EDGE:LEVel?")

    DoCommand ":TRIGger:EDGE:SLOPe POSitive"
    Debug.Print "Trigger edge slope: " + _
        DoQueryString(":TRIGger:EDGE:SLOPe?")

    ' Save oscilloscope configuration.
    ' -----
    Dim lngSetupStringSize As Long
    lngSetupStringSize = DoQueryIEEEBlock_Bytes(":SYSTem:SETup?")
    Debug.Print "Setup bytes saved: " + CStr(lngSetupStringSize)

    ' Output setup string to a file:
    Dim strPath As String
    strPath = "c:\scope\config\setup.dat"
    If Len(Dir(strPath)) Then
        Kill strPath ' Remove file if it exists.
    End If

    ' Open file for output.
    Dim hFile As Long
    hFile = FreeFile
    Open strPath For Binary Access Write Lock Write As hFile
    Dim lngI As Long
    For lngI = 0 To lngSetupStringSize - 1
        Put hFile, , byteArray(lngI) ' Write data.
    Next lngI

```

```

Close hFile    ' Close file.

' Change settings with individual commands:
' -----

' Set vertical scale and offset.
DoCommand ":CHANnel1:SCALE 0.05"
Debug.Print "Channel 1 vertical scale: " + _
    DoQueryString(":CHANnel1:SCALE?")

DoCommand ":CHANnel1:OFFSet -1.5"
Debug.Print "Channel 1 vertical offset: " + _
    DoQueryString(":CHANnel1:OFFSet?")

' Set horizontal scale and position.
DoCommand ":TIMEbase:SCALE 0.0002"
Debug.Print "Timebase scale: " + _
    DoQueryString(":TIMEbase:SCALE?")

DoCommand ":TIMEbase:POSition 0.0"
Debug.Print "Timebase position: " + _
    DoQueryString(":TIMEbase:POSition?")

' Set the acquisition type (NORMAL, PEAK, AVERAGE, or HRESOLUTION).
DoCommand ":ACquire:TYPE NORMAL"
Debug.Print "Acquire type: " + _
    DoQueryString(":ACquire:TYPE?")

' Or, configure by loading a previously saved setup.
' -----
strPath = "c:\scope\config\setup.dat"
Open strPath For Binary Access Read As hFile    ' Open file for input.
Dim lngSetupFileSize As Long
lngSetupFileSize = LOF(hFile)    ' Length of file.
Get hFile, , byteArray    ' Read data.
Close hFile    ' Close file.
' Write setup string back to oscilloscope using ":SYSTEM:SETup"
' command:
Dim lngRestored As Long
lngRestored = DoCommandIEEEBlock(":SYSTEM:SETup", lngSetupFileSize)
Debug.Print "Setup bytes restored: " + CStr(lngRestored)

' Capture an acquisition using :DIGitize.
' -----
DoCommand ":DIGitize CHANnel1"

Exit Sub

ErrorHandler:

MsgBox "*** Error : " + Error, vbExclamation
End

End Sub

'
' Analyze the captured waveform.

```

```

' -----
Private Sub Analyze()

    On Error GoTo ErrorHandler

    ' Make a couple of measurements.
    ' -----
    DoCommand ":MEASure:SOURce CHANnel1"
    Debug.Print "Measure source: " + _
        DoQueryString(":MEASure:SOURce?")

    DoCommand ":MEASure:FREQuency"
    dblQueryResult = DoQueryNumber(":MEASure:FREQuency?")
    MsgBox "Frequency:" + vbCrLf + _
        FormatNumber(dblQueryResult / 1000, 4) + " kHz"

    DoCommand ":MEASure:VAMPlitude"
    dblQueryResult = DoQueryNumber(":MEASure:VAMPlitude?")
    MsgBox "Vertical amplitude:" + vbCrLf + _
        FormatNumber(dblQueryResult, 4) + " V"

    ' Download the screen image.
    ' -----
    DoCommand ":HARDcopy:INKSaver OFF"

    ' Get screen image.
    Dim lngBlockSize As Long
    lngBlockSize = DoQueryIEEEBlock_Bytes(":DISPlay:DATA? PNG, COlor")
    Debug.Print "Screen image bytes: " + CStr(lngBlockSize)

    ' Save screen image to a file:
    Dim strPath As String
    strPath = "c:\scope\data\screen.png"
    If Len(Dir(strPath)) Then
        Kill strPath ' Remove file if it exists.
    End If
    Dim hFile As Long
    hFile = FreeFile
    Open strPath For Binary Access Write Lock Write As hFile
    Dim lngI As Long
    ' Skip past header.
    For lngI = CInt(Chr(byteArray(1))) + 2 To lngBlockSize - 1
        Put hFile, , byteArray(lngI) ' Write data.
    Next lngI
    Close hFile ' Close file.
    MsgBox "Screen image written to " + strPath

    ' Download waveform data.
    ' -----

    ' Set the waveform points mode.
    DoCommand ":WAVEform:POINts:MODE RAW"
    Debug.Print "Waveform points mode: " + _
        DoQueryString(":WAVEform:POINts:MODE?")

    ' Get the number of waveform points available.

```

```

DoCommand ":WAVeform:POINts 10240"
Debug.Print "Waveform points available: " + _
    DoQueryString(":WAVeform:POINts?")

' Set the waveform source.
DoCommand ":WAVeform:SOURce CHANnel1"
Debug.Print "Waveform source: " + _
    DoQueryString(":WAVeform:SOURce?")

' Choose the format of the data returned (WORD, BYTE, ASCII):
DoCommand ":WAVeform:FORMat BYTE"
Debug.Print "Waveform format: " + _
    DoQueryString(":WAVeform:FORMat?")

' Display the waveform settings:
Dim Preamble() As Double
Dim intFormat As Integer
Dim intType As Integer
Dim lngPoints As Long
Dim lngCount As Long
Dim dblXIncrement As Double
Dim dblXOrigin As Double
Dim lngXReference As Long
Dim sngYIncrement As Single
Dim sngYOrigin As Single
Dim lngYReference As Long

Preamble() = DoQueryNumbers(":WAVeform:PREAmble?")

intFormat = Preamble(0)
intType = Preamble(1)
lngPoints = Preamble(2)
lngCount = Preamble(3)
dblXIncrement = Preamble(4)
dblXOrigin = Preamble(5)
lngXReference = Preamble(6)
sngYIncrement = Preamble(7)
sngYOrigin = Preamble(8)
lngYReference = Preamble(9)

If intFormat = 0 Then
    Debug.Print "Waveform format: BYTE"
ElseIf intFormat = 1 Then
    Debug.Print "Waveform format: WORD"
ElseIf intFormat = 2 Then
    Debug.Print "Waveform format: ASCii"
End If

If intType = 0 Then
    Debug.Print "Acquisition type: NORMal"
ElseIf intType = 1 Then
    Debug.Print "Acquisition type: PEAK"
ElseIf intType = 2 Then
    Debug.Print "Acquisition type: AVERage"
ElseIf intType = 3 Then
    Debug.Print "Acquisition type: HRESolution"
End If

```

```

Debug.Print "Waveform points: " + _
    FormatNumber(lngPoints, 0)

Debug.Print "Waveform average count: " + _
    FormatNumber(lngCount, 0)

Debug.Print "Waveform X increment: " + _
    Format(dblXIncrement, "Scientific")

Debug.Print "Waveform X origin: " + _
    Format(dblXOrigin, "Scientific")

Debug.Print "Waveform X reference: " + _
    FormatNumber(lngXReference, 0)

Debug.Print "Waveform Y increment: " + _
    Format(sngYIncrement, "Scientific")

Debug.Print "Waveform Y origin: " + _
    FormatNumber(sngYOrigin, 0)

Debug.Print "Waveform Y reference: " + _
    FormatNumber(lngYReference, 0)

' Get the waveform data
Dim lngNumBytes As Long
lngNumBytes = DoQueryIEEEBlock_Bytes(":WAVEform:DATA?")
Debug.Print "Number of data values: " + _
    CStr(lngNumBytes - CInt(Chr(byteArray(1))) - 2)

' Set up output file:
strPath = "c:\scope\data\waveform_data.csv"

' Open file for output.
Open strPath For Output Access Write Lock Write As hFile

' Output waveform data in CSV format.
Dim lngDataValue As Long

' Skip past header.
For lngI = CInt(Chr(byteArray(1))) + 2 To lngNumBytes - 2
    lngDataValue = CLng(byteArray(lngI))

    ' Write time value, voltage value.
    Print #hFile, _
        FormatNumber(dblXOrigin + (lngI * dblXIncrement), 9) + _
        ", " + _
        FormatNumber(((lngDataValue - lngYReference) * _
            sngYIncrement) + sngYOrigin)

Next lngI

' Close output file.
Close hFile ' Close file.
MsgBox "Waveform format BYTE data written to " + _
    "c:\scope\data\waveform_data.csv."

```

```

        Exit Sub

ErrorHandler:

    MsgBox "*** Error : " + Error, vbExclamation
    End

End Sub

Private Sub DoCommand(command As String)

    On Error GoTo ErrorHandler

    Call ivprintf(id, command + vbLf)

    CheckInstrumentErrors

    Exit Sub

ErrorHandler:

    MsgBox "*** Error : " + Error, vbExclamation
    End

End Sub

Private Function DoCommandIEEEBlock(command As String, _
    lngBlockSize As Long)

    On Error GoTo ErrorHandler

    ' Send command part.
    Call ivprintf(id, command + " ")

    ' Write definite-length block bytes.
    Call ifwrite(id, byteArray(), lngBlockSize, vbNull, retCount)

    ' retCount is now actual number of bytes written.
    DoCommandIEEEBlock = retCount

    CheckInstrumentErrors

    Exit Function

ErrorHandler:

    MsgBox "*** Error : " + Error, vbExclamation
    End

End Function

Private Function DoQueryString(query As String) As String

    Dim actual As Long

    On Error GoTo ErrorHandler

```



```

Dim strResult As String * 200

Call ivprintf(id, query + vbLf)
Call ivscanf(id, "%200t", strResult)
DoQueryString = strResult

CheckInstrumentErrors

Exit Function

ErrorHandler:

MsgBox "*** Error : " + Error, vbExclamation
End

End Function

Private Function DoQueryNumber(query As String) As Double

On Error GoTo ErrorHandler

Dim dblResult As Double

Call ivprintf(id, query + vbLf)
Call ivscanf(id, "%lf" + vbLf, dblResult)
DoQueryNumber = dblResult

CheckInstrumentErrors

Exit Function

ErrorHandler:

MsgBox "*** Error : " + Error, vbExclamation
End

End Function

Private Function DoQueryNumbers(query As String) As Double()

On Error GoTo ErrorHandler

Dim dblResults(10) As Double

Call ivprintf(id, query + vbLf)
Call ivscanf(id, "%,10lf" + vbLf, dblResults)
DoQueryNumbers = dblResults

CheckInstrumentErrors

Exit Function

ErrorHandler:

MsgBox "*** Error : " + Error, vbExclamation
End

```

```

End Function

Private Function DoQueryIEEEBlock_Bytes(query As String) As Long

    On Error GoTo ErrorHandler

    ' Send query.
    Call ivprintf(id, query + vbCrLf)

    ' Read definite-length block bytes.
    Sleep 2000 ' Delay before reading data.
    Call ifread(id, byteArray(), ByteArraySize, vbNull, retCount)

    ' Get number of block length digits.
    Dim intLengthDigits As Integer
    intLengthDigits = CInt(Chr(byteArray(1)))

    ' Get block length from those digits.
    Dim strBlockLength As String
    strBlockLength = ""
    Dim i As Integer
    For i = 2 To intLengthDigits + 1
        strBlockLength = strBlockLength + Chr(byteArray(i))
    Next

    ' Return number of bytes in block plus header.
    DoQueryIEEEBlock_Bytes = CLng(strBlockLength) + intLengthDigits + 2

    CheckInstrumentErrors

    Exit Function

ErrorHandler:

    MsgBox "*** Error : " + Error, vbExclamation
    End

End Function

Private Sub CheckInstrumentErrors()

    On Error GoTo ErrorHandler

    Dim strErrVal As String * 200
    Dim strOut As String

    Call ivprintf(id, ":SYSTem:ERRor?" + vbCrLf) ' Query any errors data.
    Call ivscanf(id, "%200t", strErrVal) ' Read: Errnum,"Error String".
    While Val(strErrVal) <> 0 ' End if find: +0,"No Error".
        strOut = strOut + "INST Error: " + strErrVal
        Call ivprintf(id, ":SYSTem:ERRor?" + vbCrLf) ' Request error message
    .
        Call ivscanf(id, "%200t", strErrVal) ' Read error message.
    Wend

    If Not strOut = "" Then

```

```
    MsgBox strOut, vbExclamation, "INST Error Messages"  
    Call iflush(id, I_BUF_READ Or I_BUF_WRITE)  
  
End If  
  
Exit Sub  
  
ErrorHandler:  
  
    MsgBox "*** Error : " + Error, vbExclamation  
    End  
  
End Sub
```

SCPI.NET Examples

You can also program the oscilloscope using the SCPI.NET drivers that come with Keysight's free Command Expert software.

While you can write code manually using the SCPI.NET drivers, you can also use the Command Expert software to:

- Connect to instruments and control them interactively using SCPI command sets.
- Quickly prototype and test command sequences.
- Generate C#, VB.NET, or C/C++ code for command sequences.
- Find, download, and install SCPI command sets.
- Browse command trees, search for commands, and view command descriptions.

The Command Expert suite also comes with Add-ons for easy instrument control and measurement data retrieval in NI LabVIEW, Microsoft Excel, Keysight VEE, and Keysight SystemVue.

To download the Keysight Command Expert software, see:

<http://www.keysight.com/find/commandexpert>

For more on programming with the SCPI.NET drivers, see "Using SCPI.NET Drivers" in the help that comes with Keysight Command Expert.

Index

Symbols

*ESR? (Event Status Register) query, [87](#)
*OPC (Operation Complete) query, [87](#)
+9.9E+37, infinity representation, [1737](#)
+9.9E+37, measurement error, [659](#)
+Width to +Width jitter measurement, [669](#)

Numerics

0 (zero) values in waveform data, [1523](#)
1 (one) values in waveform data, [1523](#)
10 MHz REF BNC,
 enabling/disabling, [1416](#)
10 MHz reference signal, [311](#)
4000 X-Series oscilloscopes, command
 differences from, [60](#)
82350B GPIB interface, [6](#)

A

A429 SEARCh commands, [1304](#)
A429 serial bus commands, [982](#)
absolute value math function, [522](#)
AC coupling, trigger edge, [1456](#)
AC input coupling for specified
 channel, [356](#)
AC RMS measured on waveform, [682](#), [751](#)
accumulate activity, [261](#)
ACquire commands, [301](#)
acquire data, [270](#), [318](#)
acquire mode on autoscale, [265](#)
acquire reset conditions, [246](#), [1395](#)
acquire sample rate, [317](#)
ACquire subsystem, [79](#)
acquired data points, [310](#)
acquisition anti-alias control, [304](#)
acquisition count, [306](#)
acquisition mode, [302](#), [308](#), [1542](#)
acquisition type, [302](#), [318](#)
acquisition types, [1516](#)
acquisitions, real-time eye analysis, [938](#)
active edges, [261](#)
active printer, [543](#)
activity logic levels, [261](#)
activity on digital channels, [261](#)
add function, [1537](#)
add math function, [521](#)
add math function as g(t) source, [1628](#)
address field size, IIC serial decode, [1088](#)

address of network printer, [548](#)
address value, USB search, [1368](#)
address value, USB trigger, [1245](#)
address, IIC trigger pattern, [1091](#)
Addresses softkey, [68](#)
Adjacent Channel Power Ratio (ACPR), FFT
 analysis measurement, [685](#)
adjacent signal source, USB 2.0 signal
 quality test, [393](#)
AER (Arm Event Register), [262](#), [282](#), [285](#),
 [1694](#)
Agilent Flash directory, [933](#), [959](#)
alignment, I2S trigger, [1070](#)
all (snapshot) measurement, [660](#)
all edges, measure, [588](#)
ALL segments waveform save option, [973](#)
all segments, :WAVEform:DATA?, [1533](#)
AM demo signal, [414](#)
AM depth, waveform generator
 modulation, [1573](#)
AM modulation type, waveform
 generator, [1583](#)
amplitude profile, Control Loop Response
 (Bode) power analysis, [846](#)
amplitude profile, frequency response
 analysis, [482](#)
amplitude profile, Power Supply Rejection
 Ratio (PSRR) power analysis, [889](#)
amplitude tracking, dual channel waveform
 generator, [1593](#), [1595](#)
amplitude, vertical, [678](#), [744](#)
amplitude, waveform generator, [481](#), [1597](#)
analog channel coupling, [356](#)
analog channel display, [357](#)
analog channel impedance, [358](#)
analog channel input, [1622](#)
analog channel inversion, [359](#)
analog channel labels, [360](#), [447](#)
analog channel offset, [361](#)
analog channel protection lock, [1398](#)
analog channel range, [378](#)
analog channel scale, [379](#)
analog channel source for glitch, [1469](#)
analog channel units, [368](#), [380](#)
analog channels only oscilloscopes, [6](#)
analog probe attenuation, [362](#)
analog probe head type, [369](#)
analog probe sensing, [1623](#)
analog probe skew, [374](#), [1621](#)
analysis results, save, [960](#)
analyzing captured data, [75](#)
angle brackets, [226](#)
annotate channels, [360](#)

annotation background, display, [433](#)
annotation color, display, [434](#)
annotation text, display, [435](#)
annotation X1 position, [436](#)
annotation Y1 position, [437](#)
annotation, display, [432](#)
anti-alias control, [304](#)
apparent power, [763](#)
apply network printer connection
 settings, [549](#)
arbitrary waveform generator output, [1569](#)
arbitrary waveform, byte order, [1556](#)
arbitrary waveform, capturing from other
 sources, [1564](#)
arbitrary waveform, clear, [1561](#)
arbitrary waveform, download DAC
 values, [1562](#)
arbitrary waveform, download floating-point
 values, [1557](#)
arbitrary waveform, interpolation, [1563](#)
arbitrary waveform, points, [1560](#)
arbitrary waveform, recall, [928](#)
arbitrary waveform, save, [947](#)
area for hardcopy print, [542](#)
area for saved image, [1662](#)
area measurement, [661](#), [677](#)
ARINC 429 auto setup, [984](#)
ARINC 429 base, [985](#)
ARINC 429 demo signal, [416](#)
ARINC 429 signal speed, [993](#)
ARINC 429 signal type, [991](#)
ARINC 429 source, [992](#)
ARINC 429 trigger data pattern, [995](#), [1307](#)
ARINC 429 trigger label, [994](#), [998](#), [1305](#)
ARINC 429 trigger SDI pattern, [996](#), [1308](#)
ARINC 429 trigger SSM pattern, [997](#), [1309](#)
ARINC 429 trigger type, [999](#), [1306](#)
ARINC 429 user-defined baud rate, [986](#)
ARINC 429 word and error counters,
 reset, [988](#)
ARINC 429 word format, [990](#)
Arm Event Register (AER), [262](#), [282](#), [285](#),
 [1694](#)
armed status, checking for, [1701](#)
arming edge slope, Edge Then Edge
 trigger, [1443](#)
arming edge source, Edge Then Edge
 trigger, [1444](#)
arrange waveforms, [1625](#)
ASCII format, [1525](#)
ASCII format for data transfer, [1519](#)
ASCII string, quoted, [226](#)
ASCIixy waveform data format, [970](#)

assign channel names, 360
 attenuation factor (external trigger)
 probe, 463
 attenuation for oscilloscope probe, 362
 audio channel, I2S trigger, 1079
 AUT option for probe sense, 1623, 1627
 Auto Range capability for DVM, 456
 auto set up, trigger level, 1436
 auto set up, USB 2.0 signal quality
 test, 390
 auto setup (ARINC 429), 984
 auto setup for M1553 trigger, 1117
 auto setup for power analysis signals, 892
 auto trigger sweep mode, 1425
 automask create, 787
 automask source, 788
 automask units, 789
 automatic measurements constants, 362
 automatic probe type detection, 1623,
 1627
 autoscale, 263
 autoscale acquire mode, 265
 autoscale channels, 266
 AUToscale command, 78
 autoset for FLEXray event trigger, 1060
 autosetup for FLEXray decode, 1050
 average math function, clear, 496
 average value measurement, 679, 745
 Average, power modulation analysis, 869
 averaged value math function, 522
 averaging acquisition type, 302, 1517
 averaging, synchronizing with, 1716
 Ax + B math function, 522

B

backlight, display, 438
 band pass filter math function, 522
 band-pass filter math function, center
 frequency, 512
 band-pass filter math function, frequency
 width, 513
 bandwidth filter limits, 353, 462
 bandwidth limit, 355
 bar chart of current harmonics results, 853
 BARTlett window, 511, 586
 base 10 exponential math function, 522
 base value measurement, 680, 746
 base, ARINC 429, 985
 base, I2S serial decode, 1071
 base, MIL-STD-1553 serial decode, 1118
 base, SENT decode, 1166
 base, UART trigger, 1229
 base, USB decode, 1239
 basic instrument functions, 233
 baud rate, 1014, 1102, 1218
 baud rate, CAN FD, 1016
 baud rate, user-defined, ARINC 429, 986
 begin acquisition, 270, 294, 296
 BHARis window for minimal spectral
 leakage, 511, 586

Bin Size, FFT, 498
 binary block data, 226, 440, 557, 1406,
 1523
 BINary waveform data format, 970
 bind levels for masks, 808
 bit order, 1219
 bit order, SPI decode, 1199
 bit rate measurement, 662
 bit selection command, bus, 323
 bit weights, 238
 bitmap display, 440, 558
 bits in Service Request Enable
 Register, 251
 bits in Standard Event Status Enable
 Register, 236
 bits in Status Byte Register, 253
 bits selection command, bus, 324
 blank, 268
 block data, 226, 241, 1406
 block response data, 82
 blocking commands, 87
 blocking synchronization, 1711
 blocking synchronization example, 1718
 blocking wait, 1710
 BMP format screen image data, 440, 558
 braces, 225
 built-in measurements, 75
 burst data demo signal, 415
 burst width measurement, 663
 burst, minimum time before next, 1451
 bus bit selection command, 323
 bus bits selection commands, 324
 bus clear command, 326
 bus commands, 322
 BUS data format, 1520
 bus display, 327
 bus label command, 328
 bus mask command, 329
 BUS<n> commands, 321
 button disable, 1390
 button, calibration protect, 336
 byte format for data transfer, 1519, 1525
 BYTeorder, 1521

C

C, SICL library example, 1840
 C, VISA library example, 1774
 C#, VISA COM example, 1749
 C#, VISA example, 1793
 C#, VISA.NET example, 1821
 CAL PROTECT button, 336
 CAL PROTECT switch, 332
 calculating preshoot of waveform, 716
 calculating the waveform overshoot, 710
 calibrate, 333, 334, 336, 340
 CALibrate commands, 331
 calibrate date, 333
 calibrate introduction, 332
 calibrate label, 334
 calibrate output, 335
 calibrate start, 337
 calibrate status, 338
 calibrate switch, 336
 calibrate temperature, 339
 calibrate time, 340
 CAN acknowledge, 1013
 CAN and LIN demo signal, 416
 CAN baud rate, 1014
 CAN demo signal, 415
 CAN FD baud rate, 1016
 CAN FD data triggers, starting byte
 position, 1025
 CAN frame counters, reset, 1006
 CAN SEARCh commands, 1310
 CAN serial bus commands, 1001
 CAN serial search, data, 1313
 CAN serial search, data length, 1314
 CAN serial search, ID, 1315
 CAN serial search, ID mode, 1316
 CAN serial search, mode, 1311
 CAN signal definition, 1015
 CAN source, 1017
 CAN symbolic data display, 1010
 CAN symbolic data, recall, 929
 CAN trigger, 1018, 1024
 CAN trigger data pattern, 1022
 CAN trigger ID pattern, 1026
 CAN trigger pattern id mode, 1027
 CAN trigger, ID filter for, 1021
 CAN triggering, 978
 capture data, 270
 capturing data, 74
 cardiac waveform generator output, 1568
 center frequency set, 499, 521
 center of screen, 1550
 center screen, vertical value at, 520, 527
 center time base reference, 1417
 CFD demo signal, 417
 channel, 300, 360, 1618, 1620
 channel coupling, 356
 channel display, 357
 channel input impedance, 358
 channel inversion, 359
 channel label, 360, 1619
 channel labels, 446, 447
 channel numbers, 1625
 channel overload, 377
 Channel Power, FFT analysis
 measurement, 686
 channel protection, 377
 channel reset conditions, 246, 1395
 channel selected to produce trigger, 1469,
 1500
 channel signal type, 375
 channel skew for oscilloscope probe, 374,
 1621
 channel status, 297, 1625
 channel threshold, 1620
 channel vernier, 381
 channel, stop displaying, 268
 CHANnel<n> commands, 349, 352
 channels to autoscale, 266

- channels, how autoscale affects, 263
- characters to display, 1388
- chart logic bus state math function, 523
- chart logic bus state, clock edge, 492
- chart logic bus state, clock source, 491
- chart logic bus timing math function, 523
- chart logic bus, units, 495
- chart logic bus, value for data = 0, 494
- chart logic bus, value for data increment, 493
- chart serial signal math function, 524
- Chart Serial Signal math function, serial bus source, 529
- Chart Serial Signal math function, time mode, 530
- Chart Serial Signal math function, time offset, 533
- Chart Serial Signal math function, time range, 532
- classes of input signals, 511
- classifications, command, 1730
- clear, 439
- clear bus command, 326
- clear cumulative edge variables, 1618
- clear markers, 664, 1639
- clear measurement, 664, 1639
- clear message from display, 449
- clear message queue, 235
- Clear method, 77
- clear persistence data from display, 451
- clear reference waveforms, 1603
- clear screen, 1626
- clear status, 235
- clear waveform area, 431
- clipped high waveform data value, 1523
- clipped low waveform data value, 1523
- clock, 1089, 1200, 1204
- Clock Extension Peripheral Interface (CXPI), 1031
- clock period, SENT signal, 1164
- clock recovery commands, 383
- clock recovery math function, 524
- clock recovery method, 386
- clock slope, I2S, 1072
- CLOCK source, I2S, 1074
- clock source, setup and hold trigger, 1487
- Clock TIE jitter measurement, 740
- clock timeout, SPI, 1201
- clock with infrequent glitch demo signal, 414
- clock, recovered, displaying, 385
- CLS (Clear Status), 235
- CME (Command Error) status bit, 236, 238
- CMOS threshold voltage for digital channels, 427, 1620
- CMOS trigger threshold voltage, 1667
- code, :ACQUIRE:COMPLETE, 305
- code, :ACQUIRE:SEGMENTED, 314
- code, :ACQUIRE:TYPE, 319
- code, :AUTOSCALE, 264
- code, :CHANNEL<n>:LABEL, 360
- code, :CHANNEL<n>:PROBE, 362
- code, :CHANNEL<n>:RANGE, 378
- code, :DIGITIZE, 271
- code, :DISPLAY:DATA, 440
- code, :DISPLAY:LABEL, 446
- code, :DISPLAY:ORDER, 1625
- code, :MEASURE:PERIOD, 728
- code, :MEASURE:RESULTS, 718
- code, :MEASURE:TEDGE, 736
- code, :MTEST, 783
- code, :POD<n>:THRESHOLD, 819
- code, :RUN/:STOP, 294
- code, :SYSTEM:SETUP, 1406
- code, :TIMEBASE:DELAY, 1666
- code, :TIMEBASE:MODE, 1413
- code, :TIMEBASE:RANGE, 1415
- code, :TIMEBASE:REFERENCE, 1417
- code, :TRIGGER:MODE, 1439
- code, :TRIGGER:SLOPE, 1459
- code, :TRIGGER:SOURCE, 1460
- code, :VIEW and :BLANK, 300
- code, :WAVEFORM, 1538
- code, :WAVEFORM:DATA, 1523
- code, :WAVEFORM:POINTS, 1527
- code, :WAVEFORM:PREEMBLE, 1531
- code, :WAVEFORM:SEGMENTED, 314
- code, :WGEN:ARBITRARY:DATA, 1557
- code, *RST, 248
- code, SICL library example in C, 1840
- code, SICL library example in Visual Basic, 1849
- code, VISA COM library example in C#, 1749
- code, VISA COM library example in Python, 1766
- code, VISA COM library example in Visual Basic, 1740
- code, VISA COM library example in Visual Basic .NET, 1758
- code, VISA library example in C, 1774
- code, VISA library example in C#, 1793
- code, VISA library example in Python, 1814
- code, VISA library example in Visual Basic, 1783
- code, VISA library example in Visual Basic .NET, 1804
- code, VISA.NET library example in C#, 1821
- code, VISA.NET library example in Python, 1833
- code, VISA.NET library example in Visual Basic .NET, 1827
- colon, root commands prefixed by, 260
- color grade bin counts, saving, 961
- color grade commands, 341
- color grade levels display, 344
- color grade reset, 345
- color grade theme, 346
- color grade waveform display, 348
- color grade waveform source, 347
- color palette for hardcopy, 554
- color palette for image, 954
- Comma Separated Values (CSV) waveform data format, 970
- command classifications, 1730
- command differences from 4000 X-Series oscilloscopes, 60
- command errors detected in Standard Event Status, 238
- Command Expert, 1821, 1860
- command header, 1731
- command headers, common, 1733
- command headers, compound, 1733
- command headers, simple, 1733
- command strings, valid, 1731
- commands quick reference, 89
- commands sent over interface, 233
- commands, more about, 1729
- commands, obsolete and discontinued, 1611
- common (*) commands, 3, 229, 233
- common command headers, 1733
- common logarithm math function, 522
- completion criteria for an acquisition, 305, 306
- COMPLIANCE commands, 389
- compound command headers, 1733
- compound header, 1735
- computer control examples, 1739
- concurrent commands, 87
- conditions for external trigger, 461
- conditions, reset, 246, 1395
- conduction calculation method for switching loss, 914
- Config softkey, 68
- configurations, oscilloscope, 241, 245, 249, 1406
- Configure softkey, 68
- connect oscilloscope, 67
- connect sampled data points, 1624
- Connection Expert, 69
- connection type, hi-speed, USB 2.0 signal quality test, 398
- constant frequency clock recovery, 386
- constants for making automatic measurements, 362
- constants for scaling display factors, 362
- constants for setting trigger levels, 362
- Control Loop Response (Bode) power analysis settings, 829
- control loop response (Bode) power analysis, apply, 830
- control loop response power analysis, single frequency, 837
- control loop response power analysis, sweep start frequency, 838
- control loop response power analysis, sweep stop frequency, 839
- controller initialization, 74
- conversion type of power supply, 866
- copy display, 292
- copy signal, dual channel waveform generator, 1594
- copyright, 2

- core commands, 1730
 - count, 1522
 - count totalize, gating enable/disable, 409
 - count values, 306
 - count, averaged value math function, 490
 - count, Edge Then Edge trigger, 1446
 - count, Nth edge of burst, 1450
 - counter, 402, 665
 - counter commands, 401
 - counter mode, 405
 - counter source, 407
 - counter totalize, clear, 408
 - counter totalize, gating polarity, 410
 - counter totalize, gating signal source, 411
 - counter totalize, slope, 412
 - counter, digits of resolution, 406
 - counter, enable/disable, 404
 - coupling, 1456
 - COUPLing demo signal, 417
 - coupling for channels, 356
 - CRC format, SENT, 1165
 - CRC value, USB search, 1369
 - CRC value, USB trigger, 1246
 - create automask, 787
 - crest factor, 765
 - CSV (Comma Separated Values) waveform data format, 970
 - CT bits (CXPI), triggering on, 1045
 - cumulative edge activity, 1618
 - current harmonics analysis fail count, 854
 - current harmonics analysis results, save, 958
 - current harmonics analysis run count, 859
 - current harmonics analysis, apply, 851
 - current harmonics results data, 852
 - current harmonics results display, 853
 - current logic levels on digital channels, 261
 - current oscilloscope configuration, 241, 245, 249, 1406
 - current probe, 368, 380, 465
 - CURRent segment waveform save option, 973
 - current source, 909
 - cursor display setting, X1, 618
 - cursor display setting, X2, 621
 - cursor display setting, Y1, 627
 - cursor display setting, Y2, 629
 - cursor mode, 617
 - cursor position, 616, 619, 622, 624, 628, 631
 - cursor readout, 1640, 1644, 1645
 - cursor reset conditions, 246, 1395
 - cursor source, 620, 623
 - cursor time, 1640, 1644, 1645
 - cursor units, X, 625, 626
 - cursor units, Y, 632, 633
 - cursor values, saving, 962
 - cursors track measurements, 725
 - cursors, how autoscale affects, 263
 - cursors, X1, X2, Y1, Y2, 615
 - custom time base reference, 1417
 - custom time base reference location, 1418
 - CXPI demo signal, 416
 - CXPI frame data value, 1041
 - CXPI parity bit display, 1034
 - CXPI serial bus commands, 1031
 - CXPI signal baud rate, 1033
 - CXPI signal source, 1035
 - CXPI signal tolerance, 1036
 - CXPI trigger mode, 1037
 - CXPI triggering, 978
 - cycle count base, FLEXray frame trigger, 1063
 - cycle count repetition, FLEXray frame trigger, 1064
 - cycle measured, 683, 705
 - cycle time, 713
 - cycles analyzed, number of, 893, 894
- ## D
- D- source, USB 2.0 signal quality test, 395
 - D- USB signal source, 1240
 - D+ source, USB 2.0 signal quality test, 396
 - D+ USB signal source, 1241
 - damping factor (second-order PLL), clock recovery, 386
 - data, 1090, 1092, 1523
 - data (waveform) maximum length, 972
 - data 2, 1093
 - data acquisition types, 1516
 - data conversion, 1518
 - data format for transfer, 1518
 - data length, USB search, 1371
 - data length, USB trigger, 1248
 - data output order, 1521
 - data pattern length, 1024, 1111
 - data pattern, ARINC 429 trigger, 995, 1307
 - data pattern, CAN trigger, 1022
 - data PID, USB search, 1376
 - data PID, USB trigger, 1254
 - data point index, 1547
 - data points, 310
 - data record, deep analysis, 1393
 - data record, measurement, 1393, 1528
 - data record, precision analysis, 1528
 - data record, raw acquisition, 1528
 - data required to fill time buckets, 305
 - DATA source, I2S, 1075
 - data source, setup and hold trigger, 1488
 - data structures, status reporting, 1679
 - Data TIE jitter measurement, 738
 - data value, USB search, 1370
 - data value, USB trigger, 1247
 - data, saving and recalling, 431
 - date, calibration, 333
 - date, system, 1386
 - DC coupling for edge trigger, 1456
 - DC input coupling for specified channel, 356
 - DC offset correction for integrate input, 517
 - DC RMS measured on waveform, 682, 751
 - DC waveform generator output, 1567
 - DCMotor demo signal, 417
 - DDE (Device Dependent Error) status bit, 236, 238
 - decision chart, status reporting, 1700
 - deep analysis record, 1393
 - default conditions, 246, 1395
 - define channel labels, 360
 - define delay measurement parameters, 676
 - define glitch trigger, 1467
 - define logic thresholds, 1620
 - define measurement, 672
 - define measurement source, 727
 - define trigger, 1468, 1476, 1477, 1479
 - defined as, 225
 - definite-length block query response, 82
 - definite-length block response data, 226
 - degauss probe, 364
 - delay bits, SPI MISO stream, 1202
 - delay measured to calculate phase, 714
 - delay measurement, 672, 674
 - delay measurement parameters, define, 676
 - delay measurements, 736
 - delay time, Edge Then Edge trigger, 1445
 - DElay trigger commands, 1442
 - delay, how autoscale affects, 263
 - delayed time base, 1413
 - delayed window horizontal scale, 1423
 - delete mask, 797
 - delta time, 1640
 - delta voltage measurement, 1648
 - delta X cursor, 615
 - delta Y cursor, 615
 - demo, 413
 - DEMO commands, 413
 - demo signal, 415
 - demo signal function, 414
 - demo signal phase angle, 419
 - demo signals output control, 420
 - deskew for power measurements, 847
 - destination, remote command logging, 1400
 - detecting probe types, 1623, 1627
 - Device Clear to abort a sequential (blocking) command, 88
 - device-defined error queue clear, 235
 - DIFF source for function, 1631
 - differences from 4000 X-Series oscilloscope commands, 60
 - differential D+ and D- USB signal source, 1242
 - differential probe heads, 369
 - differential probe source, USB 2.0 signal quality test, 394
 - differential signal type, 375
 - differentiate math function, 307, 521, 1537

- digital channel commands, 422, 423, 424, 425, 427
 - digital channel data, 1520
 - digital channel labels, 447
 - digital channel order, 1625
 - digital channel source for glitch trigger, 1469
 - digital channels, 6
 - digital channels, activity and logic levels on, 261
 - digital channels, groups of, 815, 817, 819
 - digital pod, stop displaying, 268
 - digital reset conditions, 247, 1396
 - DIGital<d> commands, 421
 - digitize channels, 270
 - DIGitize command, 74, 79, 1516
 - digits, 226
 - disable anti-alias mode, 307
 - disable front panel, 1390
 - disable function, 1632
 - disabling calibration, 336
 - disabling channel display, 357
 - disabling status register bits, 236, 250
 - discontinued and obsolete commands, 1611
 - display annotation, 432
 - display annotation background, 433
 - display annotation color, 434
 - display annotation text, 435
 - display channel labels, 446
 - display clear, 439
 - DISPlay commands, 429
 - display commands introduction, 431
 - display connect, 1624
 - display date, 1386
 - display factors scaling, 362
 - display for channels, 357
 - display frequency span, 508
 - display measurements, 658, 725
 - display order, 1625
 - display persistence, 450
 - display reference, 1414
 - display reference waveforms, 1604
 - display reset conditions, 247, 1396
 - display serial number, 295
 - display transparent, 453
 - display vectors, 454
 - display wave position, 1625
 - display, lister, 597
 - display, measurement statistics on/off, 730
 - display, oscilloscope, 423, 450, 497, 817, 1388
 - display, serial decode bus, 980
 - displaying a baseline, 1441
 - displaying unsynchronized signal, 1441
 - divide math function, 521
 - DLC data length code (CXPI), triggering on, 1046
 - DLC value in CAN FD trigger, 1023
 - DNS IP, 68
 - domain, 68
 - domain, network printer, 550
 - driver, printer, 1637
 - DSO models, 6
 - duplicate mnemonics, 1735
 - duration, 1476, 1477, 1479
 - duration for glitch trigger, 1463, 1464, 1468
 - duration of power analysis, 895, 896, 897, 898, 899, 900
 - duration qualifier, trigger, 1476, 1477
 - duration triggering, 1426
 - duty cycle measurement, 75, 658, 683, 705
 - Duty Cycle, power modulation analysis, 869
 - DVM commands, 455
 - DVM displayed value, 457
 - DVM enable/disable, 458
 - DVM input source, 460
 - DVM mode, 459
- ## E
- EBURst trigger commands, 1449
 - ECL channel threshold, 1620
 - ECL threshold voltage for digital channels, 427
 - ECL trigger threshold voltage, 1667
 - edge activity, 1618
 - edge counter, Edge Then Edge trigger, 1446
 - edge counter, Nth edge of burst, 1450
 - edge coupling, 1456
 - edge fall time, 684
 - edge preshoot measured, 716
 - edge rise time, 721
 - EDGE SEARCh commands, 1279
 - edge search slope, 1280
 - edge search source, 1281
 - edge slew rate, 726
 - edge slope, 1459
 - edge source, 1460
 - edge string for OR'ed edge trigger, 1471
 - EDGE trigger commands, 1454
 - edge triggering, 1426
 - edges (activity) on digital channels, 261
 - edges in measurement, 672
 - edges, measure all, 588
 - efficiency, 766
 - efficiency power analysis, apply, 848
 - elapsed time in mask test, 794
 - ellipsis, 226
 - enable channel labels, 446
 - enabling calibration, 336
 - enabling channel display, 357
 - enabling status register bits, 236, 250
 - end of string (EOS) terminator, 1732
 - end of text (EOT) terminator, 1732
 - end or identify (EOI), 1732
 - endpoint value, USB search, 1372
 - endpoint value, USB trigger, 1249
 - energy loss, 767
 - envelope math function, 523
 - EOI (end or identify), 1732
 - EOS (end of string) terminator, 1732
 - EOT (end of text) terminator, 1732
 - equivalent time acquisition mode, 308
 - erase data, 439
 - erase measurements, 1639
 - erase screen, 1626
 - error counter (ARINC 429), 987
 - error counter (ARINC 429), reset, 988
 - error frame count (CAN), 1004
 - error frame count (UART), 1220
 - error messages, 1389, 1669
 - error number, 1389
 - error queue, 1389, 1690
 - error, measurement, 658
 - ESB (Event Status Bit), 251, 253
 - ESE (Standard Event Status Enable Register), 236, 1689
 - ESR (Standard Event Status Register), 238, 1688
 - ET value, USB search, 1373
 - ET value, USB trigger, 1250
 - ETE demo signal, 415
 - event status conditions occurred, 253
 - Event Status Enable Register (ESE), 236, 1689
 - Event Status Register (ESR), 238, 299, 1688
 - example code, :ACQuire:COMPLete, 305
 - example code, :ACQuire:SEGMENTed, 314
 - example code, :ACQuire:TYPE, 319
 - example code, :AUToscale, 264
 - example code, :CHANnel<n>:LABel, 360
 - example code, :CHANnel<n>:PROBE, 362
 - example code, :CHANnel<n>:RANGE, 378
 - example code, :DIGitize, 271
 - example code, :DISPlay:DATA, 440
 - example code, :DISPlay:LABel, 446
 - example code, :DISPlay:ORDER, 1625
 - example code, :MEASure:PERiod, 728
 - example code, :MEASure:RESults, 718
 - example code, :MEASure:TEDGe, 736
 - example code, :MTEST, 783
 - example code, :POD<n>:THReshold, 819
 - example code, :RUN/:STOP, 294
 - example code, :SYSTem:SETup, 1406
 - example code, :TIMebase:DELay, 1666
 - example code, :TIMebase:MODE, 1413
 - example code, :TIMebase:RANGE, 1415
 - example code, :TIMebase:REFerence, 1417
 - example code, :TRIGger:MODE, 1439
 - example code, :TRIGger:SLOPe, 1459
 - example code, :TRIGger:SOURce, 1460
 - example code, :VIEW and :BLANK, 300
 - example code, :WAVEform, 1538
 - example code, :WAVEform:DATA, 1523
 - example code, :WAVEform:POINts, 1527
 - example code, :WAVEform:PREamble, 1531
 - example code, :WAVEform:SEGMENTed, 314

example code,
:WGEN:ARbitrary:DATA, 1557
example code, *RST, 248
example programs, 6, 1739
examples on the website, 1739
excursion delta for FFT peak search, 1290
EXE (Execution Error) status bit, 236, 238
execution error detected in Standard Event Status, 238
explicit clock recovery, 386
exponential fall waveform generator output, 1568
exponential math function, 522
exponential notation, 225
exponential rise waveform generator output, 1568
extended video triggering license, 1501
external glitch trigger source, 1469
external range, 464
External Scaling, enable/disable, 366
External Scaling, gain, 367
external trigger, 461, 463, 1460
EXTernal trigger commands, 461
EXTernal trigger level, 1457
external trigger probe attenuation factor, 463
external trigger probe sensing, 1627
EXTernal trigger source, 1460
external trigger units, 465

F

fail count, current harmonics analysis, 854
fail/pass status (overall) for current harmonics analysis, 861
failed waveforms in mask test, 792
failure, self test, 255
fall time measurement, 658, 684
Fall Time, power modulation analysis, 869
falling edge count measurement, 706
falling pulse count measurement, 708
FAST data, SENT, 1541
Fast Fourier Transform (FFT)
functions, 499, 508, 511, 521, 1631
FF values in waveform data, 1523
FFT (Fast Fourier Transform) functions, 499, 508, 511, 521, 1631
FFT (Fast Fourier Transform)
operation, 1537
FFT bin size/RBW/sample rate readout, 507
FFT detector decimation type, 501
FFT detector points, 500
FFT math function, 307
FFT vertical units, 510
FFTPHase (Fast Fourier Transform)
functions, 521
fifty ohm impedance, disable setting, 1398
filename for hardcopy, 1634
filename for recall, 930, 1565
filename for save, 949

filter CXPI trigger by ID, 1039
filter for frequency reject, 1458
filter for high frequency reject, 1430
filter for noise reject, 1440
filter used to limit bandwidth, 462
filters to Fast Fourier Transforms, 511
filters, math, 522
fine horizontal adjustment (vernier), 1420
fine vertical adjustment (vernier), 381
finish pending device operations, 242
first point displayed, 1547
first-order PLL clock recovery, 386
FLATtop window for amplitude measurements, 511, 586
FLEXray autoseg for event trigger, 1060
FLEXray autoseg, 1050
FlexRay demo signal, 416
FlexRay frame counters, reset, 1054
FLEXray SEARCh commands, 1320
FlexRay serial search, cycle, 1321
FlexRay serial search, data, 1322
FlexRay serial search, data length, 1323
FlexRay serial search, frame, 1324
FlexRay serial search, mode, 1325
FLEXray source, 1057
FLEXray trigger, 1058
FLEXray trigger commands, 1048
FM burst demo signal, 415
FM modulation type, waveform generator, 1583
force trigger, 1429
format, 1525, 1530
format (word), ARINC 429, 990
format for block data, 241
format for generic video, 1497, 1501
format for hardcopy, 1633
format for image, 952
format for waveform data, 970
FormattedIO488 object, 77
formfeed for hardcopy, 540, 545
formulas for data conversion, 1518
frame, 1205
frame counters (CAN), error, 1004
frame counters (CAN), overload, 1005
frame counters (CAN), reset, 1006
frame counters (CAN), total, 1008
frame counters (FlexRay), null, 1053, 1055
frame counters (FlexRay), reset, 1054
frame counters (FlexRay), total, 1056
frame counters (UART), error, 1220
frame counters (UART), reset, 1221
frame counters (UART), Rx frames, 1222
frame counters (UART), Tx frames, 1223
frame ID, CXPI trigger, 1044
frame ID, FLEXray BSS event trigger, 1061
frame ID, FLEXray frame trigger, 1065
frame type, FLEXray frame trigger, 1066
frame value, USB search, 1374
frame value, USB trigger, 1251
framing, 1203
FRANalysis commands, 467

frequency deviation, waveform generator FM modulation, 1575
frequency measurement, 75, 658, 689
frequency measurements with X cursors, 625
frequency mode, Control Loop Response (Bode) power analysis, 836
frequency mode, Power Supply Rejection Ratio (PSRR) power analysis, 881
frequency resolution, 511
frequency response analysis, data, 469
frequency response analysis, enable, 470
frequency response analysis, run, 476
frequency response analysis, single frequency, 472
frequency response analysis, sweep start frequency, 473
frequency response analysis, sweep stop frequency, 474
frequency span of display, 508
Frequency, power modulation analysis, 869
front panel mode, 1441
front panel Single key, 296
front panel Stop key, 298
front-panel lock, 1390
FSK modulation type, waveform generator, 1583
FSK rate, waveform generator modulation, 1578
full-scale horizontal time, 1415, 1422
full-scale vertical axis defined, 526
function, 497, 499, 508, 511, 520, 521, 526, 527, 528, 1631, 1632
FUNCTION commands, 483
function memory, 297
function turned on or off, 1632
function, demo signal, 414
function, first source input, 535
function, second source input, 537
function, waveform generator, 1566
functions, 1537

G

g(t) source, first input channel, 1629
g(t) source, math operation, 1628
g(t) source, second input channel, 1630
gain data, including in control loop response results, 843
gain data, including in FRA results, 479
gain data, including in PSRR results, 886
gain for Ax + B math operation, 518
gated measurement window, 753
gateway IP, 68
gating, FFT math function, 504
gaussian pulse waveform generator output, 1569
general SBUS<n> commands, 979
general SEARCh commands, 1274
general trigger commands, 1427
GENeric, 1497, 1501

- generic video format, [1497, 1501](#)
 - Generic video trigger, edge number, [1502](#)
 - Generic video trigger, greater than sync pulse width time, [1505](#)
 - Generic video trigger, horizontal sync control, [1503](#)
 - Generic video trigger, horizontal sync pulse time, [1504](#)
 - glitch demo signal, [414](#)
 - glitch duration, [1468](#)
 - glitch qualifier, [1467](#)
 - GLITCh SEARCh commands, [1282](#)
 - glitch search, greater than value, [1283](#)
 - glitch search, less than value, [1284](#)
 - glitch search, polarity, [1285](#)
 - glitch search, qualifier, [1286](#)
 - glitch search, range, [1287](#)
 - glitch search, source, [1288](#)
 - glitch source, [1469](#)
 - GLITCh trigger commands, [1461](#)
 - glitch trigger duration, [1463](#)
 - glitch trigger polarity, [1466](#)
 - glitch trigger source, [1463](#)
 - graticule area for hardcopy print, [542](#)
 - graticule axis labels, [442](#)
 - graticule colors, invert for hardcopy, [546, 1636](#)
 - graticule colors, invert for image, [953](#)
 - graticule intensity, [443](#)
 - graticule type, [444](#)
 - grayscale palette for hardcopy, [554](#)
 - grayscale palette for image, [954](#)
 - grayscale on hardcopy, [1635](#)
 - greater than qualifier, [1467](#)
 - greater than time, [1463, 1468, 1476, 1479](#)
 - greater than value for glitch search, [1283](#)
 - grid axis labels, [442](#)
 - grid intensity, [443](#)
 - grid type, [444](#)
 - groups of digital channels, [815, 817, 819, 1620](#)
- ## H
- handshake PID, USB search, [1377](#)
 - handshake PID, USB trigger, [1255](#)
 - HANNing window for frequency resolution, [511, 586](#)
 - hardcopy, [292, 540](#)
 - HARDcopy commands, [539](#)
 - hardcopy factors, [544, 951](#)
 - hardcopy filename, [1634](#)
 - hardcopy format, [1633](#)
 - hardcopy formfeed, [545](#)
 - hardcopy grayscale, [1635](#)
 - hardcopy invert graticule colors, [546, 1636](#)
 - hardcopy layout, [547](#)
 - hardcopy palette, [554](#)
 - hardcopy print, area, [542](#)
 - hardcopy printer driver, [1637](#)
 - Hardware Event Condition Register (:HWERegister:CONDition), [274](#)
 - Hardware Event Condition Register (:OPERRegister:CONDition), [1697](#)
 - Hardware Event Enable Register (HWEEnable), [272](#)
 - Hardware Event Event Register (:HWERegister[:EVENT]), [275, 1696](#)
 - HARMonics demo signal, [417](#)
 - HCOPY commands, [539](#)
 - head type, probe, [369](#)
 - header, [1731](#)
 - high pass filter math function, [522](#)
 - high resolution acquisition type, [1518](#)
 - high trigger level, [1437](#)
 - high-frequency reject filter, [1430, 1458](#)
 - high-level voltage, waveform generator, [1598](#)
 - high-pass filter cutoff frequency, [514](#)
 - high-resolution acquisition type, [302](#)
 - histogram axis, [562](#)
 - histogram commands, [559](#)
 - histogram display, [563](#)
 - histogram measurement, [564](#)
 - histogram mode, [565](#)
 - histogram reset, [566](#)
 - histogram size, [567](#)
 - histogram statistics, saving, [963](#)
 - histogram type, [568](#)
 - histogram window, bottom limit, [569](#)
 - histogram window, left limit, [570](#)
 - histogram window, right limit, [571](#)
 - histogram window, source, [572](#)
 - histogram window, top limit, [573](#)
 - histogram, bin width, [690](#)
 - histogram, delta value between max and min, [701](#)
 - histogram, maximum value, [695](#)
 - histogram, mean value, [696](#)
 - histogram, median value, [697](#)
 - histogram, minimum value, [698](#)
 - histogram, mode value, [699](#)
 - histogram, number of hits in max bin, [700](#)
 - histogram, number of total hits, [691](#)
 - histogram, pct of hits within +/- 1 std dev, [692](#)
 - histogram, pct of hits within +/- 2 std dev, [693](#)
 - histogram, pct of hits within +/- 3 std dev, [694](#)
 - histogram, standard deviation, [702](#)
 - hold time, setup and hold trigger, [1489](#)
 - hold until operation complete, [242](#)
 - holdoff time, [1431](#)
 - holes in waveform data, [1523](#)
 - hop frequency, waveform generator FSK modulation, [1577](#)
 - horizontal adjustment, fine (vernier), [1420](#)
 - horizontal histogram, [562](#)
 - horizontal position, [1421](#)
 - horizontal scale, [1419, 1423](#)
 - horizontal scaling, [1530](#)
 - horizontal time, [1415, 1422, 1640](#)
 - Host ID of oscilloscope, [1387](#)
 - Host name softkey, [68](#)
 - hostname, [68](#)
 - hub address value, USB search, [1375](#)
 - hub address value, USB trigger, [1252](#)
 - hubs, USB 2.0 signal quality, [391](#)
 - HWEEnable (Hardware Event Enable Register), [272](#)
 - HWERegister:CONDition (Hardware Event Condition Register), [274, 1697](#)
 - HWERegister[:EVENT] (Hardware Event Event Register), [275, 1696](#)
- ## I
- I1080L50HZ, [1497, 1501](#)
 - I1080L60HZ, [1497, 1501](#)
 - I2C demo signal, [415](#)
 - I2S alignment, [1070](#)
 - I2S audio channel, [1079](#)
 - I2S clock slope, [1072](#)
 - I2S CLOCk source, [1074](#)
 - I2S DATA source, [1075](#)
 - I2S demo signal, [416](#)
 - I2S pattern data, [1080](#)
 - I2S pattern format, [1082](#)
 - I2S range, [1083](#)
 - I2S receiver width, [1073](#)
 - I2S SEARCh commands, [1326](#)
 - I2S serial bus commands, [1067](#)
 - I2S serial decode base, [1071](#)
 - I2S serial search, audio channel, [1327](#)
 - I2S serial search, data, [1329](#)
 - I2S serial search, format, [1330](#)
 - I2S serial search, mode, [1328](#)
 - I2S serial search, range, [1331](#)
 - I2S transmit word size, [1084](#)
 - I2S trigger operator, [1077](#)
 - I2S triggering, [978](#)
 - I2S word select (WS) low, [1085](#)
 - I2S word select (WS) source, [1076](#)
 - ID filter for CAN trigger, [1021](#)
 - id mode, [1027](#)
 - ID pattern, CAN trigger, [1026](#)
 - identification number, [240](#)
 - identification of options, [243](#)
 - identifier, LIN, [1108](#)
 - idle, [1451](#)
 - idle state, SENT bus, [1170](#)
 - idle until operation complete, [242](#)
 - IDN (Identification Number), [240](#)
 - IEC 61000-3-2 standard for current harmonics analysis, [860](#)
 - IEEE 488.2 standard, [233](#)
 - IIC address, [1091](#)
 - IIC clock, [1089](#)
 - IIC data, [1090, 1092](#)
 - IIC data 2, [1093](#)
 - IIC SEARCh commands, [1332](#)

- IIC serial decode address field size, 1088
 - IIC serial search, address, 1335
 - IIC serial search, data, 1336
 - IIC serial search, data2, 1337
 - IIC serial search, mode, 1333
 - IIC serial search, qualifier, 1338
 - IIC trigger commands, 1086
 - IIC trigger qualifier, 1094
 - IIC trigger type, 1095
 - IIC triggering, 978
 - image format, 952
 - image invert graticule colors, 953
 - image memory, 297
 - image palette, 954
 - image, save, 950
 - image, save with inksaver, 953
 - impedance, 358
 - infinity representation, 1737
 - initial load current, transient response analysis, 921
 - initialization, 74, 77
 - initialize, 246, 1395
 - initialize label list, 447
 - initiate acquisition, 270
 - inksaver, save image with, 953
 - input coupling for channels, 356
 - input for integrate, DC offset correction, 517
 - input impedance for channels, 358, 1622
 - input inversion for specified channel, 359
 - input power, 769
 - input source, Control Loop Response (Bode) power analysis, 841
 - input source, Power Supply Rejection Ratio (PSRR) power analysis, 884
 - inrush current, 773
 - inrush current analysis, 863, 864, 865
 - inrush current expected, 901
 - insert label, 360
 - installed options identified, 243
 - instruction header, 1731
 - instrument number, 240
 - instrument options identified, 243
 - instrument requests service, 253
 - instrument serial number, 295
 - instrument settings, 540
 - instrument status, 84
 - instrument type, 240
 - integrate DC offset correction, 517
 - integrate math function, 521, 1537
 - Integrate math function, Initial Condition, 516
 - INTegrate source for function, 1631
 - intensity color grade scheme, 343
 - intensity, waveform, 445
 - internal low-pass filter, 353, 462
 - introduction to :ACQuire commands, 302
 - introduction to :BUS<n> commands, 322
 - introduction to :CALibrate commands, 332
 - introduction to :CHANnel<n> commands, 352
 - introduction to :COUNter commands, 402
 - introduction to :DEMO commands, 413
 - introduction to :DIGital<d> commands, 422
 - introduction to :DISPlay commands, 431
 - introduction to :EXternal commands, 461
 - introduction to :FRANalysis commands, 468
 - introduction to :FUNctIon commands, 489
 - introduction to :HARDcopy commands, 540
 - introduction to :LISTer commands, 595
 - introduction to :LTEST commands, 600
 - introduction to :MARKer commands, 615
 - introduction to :MEASure commands, 658
 - introduction to :POD<n> commands, 815
 - introduction to :RECall commands, 926
 - introduction to :SAVE commands, 946
 - introduction to :SBUS commands, 977
 - introduction to :SYSTem commands, 1385
 - introduction to :TIMEbase commands, 1412
 - introduction to :TRIGger commands, 1425
 - introduction to :WAVEform commands, 1516
 - introduction to :WGEN<w> commands, 1555
 - introduction to :WMEMory<r> commands, 1601
 - introduction to common (*) commands, 233
 - introduction to root (:) commands, 260
 - invert graticule colors for hardcopy, 546, 1636
 - invert graticule colors for image, 953
 - inverted masks, bind levels, 808
 - inverting input for channels, 359
 - IO library, referencing, 76
 - IO operation complete, waiting for, 1706
 - IP address, 68
- ## J
- jitter analysis, enable/disable, 588
 - jitter analysis, histogram, 577
 - jitter analysis, spectrum, 580
 - jitter analysis, spectrum, horizontal range (center), 581
 - jitter analysis, spectrum, horizontal range (span), 582
 - jitter analysis, spectrum, vertical range, 583, 584
 - jitter analysis, spectrum, vertical units, 585
 - jitter analysis, spectrum, window, 586
 - jitter analysis, trend, 590
 - jitter analysis, trend smoothing, 591
 - jitter analysis, trend smoothing points, 592
 - jitter analysis, trend, vertical offset, 593
 - jitter analysis, trend, vertical range, 594
 - jitter commands, 575
 - JITTer demo signal, 417
 - jitter measurement, 578
 - Jitter-Free Trigger disable/enable, 1435
- ## K
- key disable, 1390
 - key press detected in Standard Event Status Register, 238
 - KEYSight demo signal, 418
 - Keysight Interactive IO application, 71
 - Keysight IO Control icon, 69
 - Keysight IO Libraries Suite, 6, 65, 76, 78
 - Keysight IO Libraries Suite, installing, 66
 - knob disable, 1390
 - known state, 246, 1395
- ## L
- label, 1619
 - label command, bus, 328
 - label list, 360, 447
 - label reference waveforms, 1605
 - label, ARINC 429 trigger, 994, 998, 1305
 - label, digital channel, 424
 - labels, 360, 446, 447
 - labels to store calibration information, 334
 - labels, specifying, 431
 - LAN instrument, 70
 - LAN interface, 67, 69
 - LAN Settings softkey, 68
 - landscape layout for hardcopy, 547
 - language for program examples, 73
 - layout for hardcopy, 547
 - leakage into peak spectrum, 511
 - learn string, 241, 1406
 - least significant byte first, 1521
 - left time base reference, 1417
 - legal values for channel offset, 361
 - legal values for frequency span, 508
 - legal values for offset, 520, 527
 - length for waveform data, 971
 - length of data, CXPI trigger, 1042
 - less than qualifier, 1467
 - less than time, 1464, 1468, 1477, 1479
 - less than value for glitch search, 1284
 - level for trigger voltage, 1457, 1465
 - LF coupling, 1456
 - license information, 243
 - limit bandwidth, 353, 355
 - limits for line number, 1497
 - LIN acknowledge, 1101
 - LIN baud rate, 1102
 - LIN demo signal, 415
 - LIN identifier, 1108
 - LIN pattern data, 1109
 - LIN pattern format, 1112
 - LIN SEARCh commands, 1339
 - LIN serial decode bus parity bits, 1100
 - LIN serial search, data, 1342
 - LIN serial search, data format, 1344
 - LIN serial search, data length, 1343

- LIN serial search, frame ID, 1340
 - LIN serial search, mode, 1341
 - LIN source, 1103
 - LIN standard, 1104
 - LIN symbolic data display, 1099
 - LIN symbolic data, recall, 931
 - LIN sync break, 1105
 - LIN trigger, 1106, 1111
 - LIN trigger commands, 1097
 - LIN trigger definition, 1663
 - LIN triggering, 978
 - line frequency setting for current harmonics analysis, 855
 - line glitch trigger source, 1469
 - line number for TV trigger, 1497
 - line terminator, 225
 - LINE trigger level, 1457
 - LINE trigger source, 1460
 - Linear units for FFT (Magnitude), 510
 - list of channel labels, 447
 - LISter commands, 595
 - lister display, 597
 - lister time reference, 598
 - ln math function, 522
 - load utilization (CAN), 1009
 - local lockout, 1390
 - location, custom time base reference location, 1418
 - lock, 1390
 - lock mask to signal, 799
 - lock, analog channel protection, 1398
 - lockout message, 1390
 - log file name, remote command logging, 1399, 1402
 - log math function, 522
 - Logarithmic units for FFT (Magnitude), 510
 - logic level activity, 1618
 - long form, 1732
 - loop bandwidth (PLL), clock recovery, 386
 - low frequency sine with glitch demo signal, 415
 - low pass filter math function, 522
 - low trigger level, 1438
 - lower threshold, 713
 - lower threshold voltage for measurement, 1638
 - lowercase characters in commands, 1731
 - low-frequency reject filter, 1458
 - low-level voltage, waveform generator, 1599
 - low-pass filter cutoff frequency, 515
 - low-pass filter used to limit bandwidth, 353, 462
 - LRN (Learn Device Setup), 241
 - lsbfirst, 1521
 - LTEST commands, 599
- ## M
- M1553 SEARCh commands, 1348
 - M1553 trigger commands, 1116
 - M1553 trigger type, 1122
 - magnify math function, 523
 - magnitude of occurrence, 742
 - main sweep range, 1421
 - main time base, 1666
 - main time base mode, 1413
 - making measurements, 658
 - MAN option for probe sense, 1623, 1627
 - Manchester baud rate, 1126
 - Manchester bit order, 1127
 - Manchester bit values trigger, data value, 1138
 - Manchester bit values trigger, data width, 1139
 - Manchester bus display format, 1128
 - Manchester decode base, 1125
 - Manchester idle time in bits, 1131
 - Manchester number of bits in header field, 1130
 - Manchester number of bits in trailer field, 1140
 - Manchester number of bits per word in data field, 1141
 - Manchester number of words in data field, 1129
 - Manchester polarity, 1132
 - MANChEster serial bus commands, 1123
 - Manchester signal source, 1133
 - Manchester signal tolerance, 1136
 - Manchester starting edge, 1135
 - Manchester sync size, 1134
 - Manchester trigger mode, 1137
 - Manchester/NRZ demo signal, 416
 - manual cursor mode, 617
 - manufacturer string, 1391, 1392
 - MARKer commands, 613
 - marker mode, 628
 - marker position, 630
 - marker readout, 1644, 1645
 - marker set for voltage measurement, 1649, 1650
 - marker sets start time, 1641
 - marker time, 1640
 - markers for delta voltage measurement, 1648
 - markers track measurements, 725
 - markers, command overview, 615
 - markers, mode, 617
 - markers, time at start, 1645
 - markers, time at stop, 1644
 - markers, X delta, 616, 624
 - markers, X1 position, 619
 - markers, X1Y1 source, 620
 - markers, X2 position, 622
 - markers, X2Y2 source, 623
 - markers, Y delta, 631
 - markers, Y1 position, 628
 - markers, Y2 position, 630
 - mask, 236, 250
 - mask command, bus, 329
 - mask statistics, reset, 793
 - mask statistics, saving, 964
 - mask test commands, 781
 - Mask Test Event Enable Register (MTEenable), 276
 - mask test event event register, 278
 - Mask Test Event Register (:MTERegister[:EVENT]), 278, 1698
 - mask test run mode, 800
 - mask test termination conditions, 800
 - mask test, all channels, 786
 - mask test, enable/disable, 798
 - mask, delete, 797
 - mask, get as binary block data, 796
 - mask, load from binary block data, 796
 - mask, lock to signal, 799
 - mask, recall, 932
 - mask, save, 955, 956
 - masks, bind levels, 808
 - master summary status bit, 253
 - math filters, 522
 - math function, stop displaying, 268
 - math operators, 521
 - math transforms, 521
 - math visualizations, 523
 - MAV (Message Available), 235, 251, 253
 - max hold math function, 523
 - max update rate sampling mode, 308
 - maximum duration, 1464, 1476, 1477
 - maximum math function, 523
 - maximum number of peaks for FFT peak search, 1291
 - maximum position, 1414
 - maximum random trigger holdoff time, 1432
 - maximum range for zoomed window, 1422
 - maximum scale for zoomed window, 1423
 - maximum vertical value measurement, 747
 - maximum vertical value, time of, 754, 1642
 - maximum waveform data length, 972
 - measure all edges, 588
 - MEASure commands, 635
 - measure mask test failures, 801
 - measure overshoot, 710
 - measure period, 713
 - measure phase between channels, 714
 - MEASure power commands, 757
 - measure preshoot, 716
 - measure start voltage, 1649
 - measure stop voltage, 1650
 - measure value at a specified time, 756, 1651
 - measure value at top of waveform, 752
 - measurement error, 658
 - measurement limit test, copy all limits from results, 602
 - measurement limit test, copy limit from results, 601
 - measurement limit test, enable, 604
 - measurement limit test, enable/disable, 610
 - measurement limit test, fail condition, 605

measurement limit test, lower limit, **606, 611**
 measurement limit test, margin when copying from results, **603**
 measurement limit test, measurement source, **607**
 measurement limit test, results, **608**
 measurement limit test, stop on failure, **609**
 measurement record, **1393, 1528**
 measurement results, saving, **965**
 measurement setup, **658, 727**
 measurement source, **727**
 measurement statistics results, **718**
 measurement statistics, display on/off, **730**
 measurement trend math function, **523**
 measurement window, **753**
 measurements, AC RMS, **682, 751**
 measurements, area, **661, 677**
 measurements, average value, **679, 745**
 measurements, base value, **680, 746**
 measurements, built-in, **75**
 measurements, burst width, **663**
 measurements, clear, **664, 1639**
 measurements, command overview, **658**
 measurements, counter, **665**
 measurements, DC RMS, **682, 751**
 measurements, definition setup, **672**
 measurements, fall time, **684**
 measurements, falling edge count, **706**
 measurements, falling pulse count, **708**
 measurements, frequency, **689**
 measurements, how autoscale affects, **263**
 measurements, lower threshold level, **1638**
 measurements, maximum vertical value, **747**
 measurements, maximum vertical value, time of, **754, 1642**
 measurements, minimum vertical value, **748**
 measurements, minimum vertical value, time of, **755, 1643**
 measurements, negative duty cycle, **705**
 measurements, overshoot, **710**
 measurements, period, **713**
 measurements, phase, **714**
 measurements, positive duty cycle, **683**
 measurements, preshoot, **716**
 measurements, pulse width, negative, **709**
 measurements, pulse width, positive, **717**
 measurements, ratio of AC RMS values, **750**
 measurements, rise time, **721**
 measurements, rising edge count, **712**
 measurements, rising pulse count, **715**
 measurements, show, **725**
 measurements, slew rate, **726**
 measurements, snapshot all, **660**
 measurements, source channel, **727**
 measurements, standard deviation, **724**
 measurements, start marker time, **1644**
 measurements, stop marker time, **1645**

measurements, thresholds, **1641**
 measurements, time between start and stop markers, **1640**
 measurements, time between trigger and edge, **735**
 measurements, time between trigger and vertical value, **742**
 measurements, time between trigger and voltage level, **1646**
 measurements, upper threshold value, **1647**
 measurements, vertical amplitude, **678, 744**
 measurements, vertical peak-to-peak, **681, 749**
 measurements, voltage difference, **1648**
 memory setup, **249, 1406**
 menu, display, **448**
 menu, system, **1665**
 message available bit, **253**
 message available bit clear, **235**
 message decode/triggering format, SENT, **1168**
 message displayed, **253**
 message error, **1669**
 message queue, **1687**
 message, CAN symbolic search, **1317**
 message, CAN symbolic trigger, **1028**
 message, clear from display, **449**
 message, LIN symbolic search, **1345**
 message, LIN symbolic trigger, **1113**
 messages ready, **253**
 method of clock recovery, **386**
 midpoint of thresholds, **713**
 MIL-STD-1553 demo signal, **416**
 MIL-STD-1553 serial decode base, **1118**
 MIL-STD-1553 serial search, data, **1350**
 MIL-STD-1553 serial search, mode, **1349**
 MIL-STD-1553 serial search, Remote Terminal Address, **1351**
 MIL-STD-1553, dual demo signal, **417**
 min hold math function, **523**
 minimum duration, **1463, 1476, 1477, 1479**
 minimum math function, **523**
 minimum random trigger holdoff time, **1433**
 minimum vertical value measurement, **748**
 minimum vertical value, time of, **755, 1643**
 MISO data pattern width, **1209**
 MISO data pattern, SPI trigger, **1208**
 MISO data source, SPI trigger, **1206**
 MISO data, SPI, **1541**
 mixed-signal demo signals, **415**
 mixed-signal oscilloscopes, **6**
 mnemonics, duplicate, **1735**
 mode, **617, 1413, 1498**
 mode, serial decode, **981**
 model number, **240**
 models, oscilloscope, **3**
 modes for triggering, **1439**
 Modify softkey, **68**

modulating signal frequency, waveform generator, **1574, 1576**
 modulation (waveform generator), enabling/disabling, **1582**
 modulation analysis, **867**
 modulation analysis source (voltage or current), **868**
 modulation analysis, type of, **869**
 modulation type, waveform generator, **1583**
 MOSI data pattern width, **1211**
 MOSI data pattern, SPI trigger, **1210**
 MOSI data source, SPI trigger, **1207, 1664**
 most significant byte first, **1521**
 move cursors, **1644, 1645**
 msbfirst, **1521**
 MSG (Message), **251, 253**
 MSO models, **6**
 MSS (Master Summary Status), **253**
 MTEEnable (Mask Test Event Enable Register), **276**
 MTERegister[:EVENT] (Mask Test Event Event Register), **278, 1698**
 MTESt commands, **781**
 multi-channel waveform data, save, **957**
 multiple commands, **1735**
 multiple queries, **83**
 multiplier value for SENT Fast Channel Signal, **1177**
 multiply math function, **521, 1537**
 multiply math function as g(t) source, **1628**

N

N275xA InfiniiMode probe mode, **372**
 N275xA InfiniiMode probe quick-action button, **363, 365**
 N2820A high sensitivity current probe, **677, 678, 679, 680, 681, 682**
 N8900A Infiniium Offline oscilloscope analysis software, **957**
 name channels, **360**
 name list, **447**
 natural logarithm math function, **522**
 negative glitch trigger polarity, **1466**
 negative pulse width, **709**
 negative pulse width measurement, **75**
 negative pulse width, power modulation analysis, **869**
 negative slope, **1200, 1459**
 negative slope, Nth edge in burst, **1452**
 negative TV trigger polarity, **1499**
 network domain password, **551**
 network domain user name, **553**
 network printer address, **548**
 network printer domain, **550**
 network printer slot, **552**
 network printer, apply connection settings, **549**
 new line (NL) terminator, **225, 1732**

new load current, transient response analysis, [922](#)
 nibble order for SENT Fast Channel Signal, [1181](#)
 NL (new line) terminator, [225](#), [1732](#)
 NM bits (CXPI), triggering on, [1047](#)
 NMONotonic demo signal, [417](#)
 noise floor, [915](#), [918](#)
 noise reject filter, [1440](#)
 noise waveform generator output, [1567](#)
 noise, adding to waveform generator output, [1581](#)
 noisy sine waveform demo signal, [414](#)
 nominal data rate, clock recovery, [386](#)
 non-core commands, [1730](#)
 non-interlaced GENeric mode, [1501](#)
 non-volatile memory, label list, [328](#), [424](#), [447](#)
 normal acquisition type, [302](#), [1517](#)
 normal trigger sweep mode, [1425](#)
 notices, [2](#)
 N-Period jitter measurement, [707](#)
 N-Period to N-Period jitter measurement, [703](#)
 NR1 number format, [225](#)
 NR3 number format, [225](#)
 NRZ baud rate, [1145](#)
 NRZ bit order, [1146](#)
 NRZ bit values trigger, data value, [1157](#)
 NRZ bit values trigger, data width, [1158](#)
 NRZ bus display format, [1147](#)
 NRZ decode base, [1144](#)
 NRZ frame size, [1149](#)
 NRZ idle state level, [1152](#)
 NRZ idle time in bits, [1151](#)
 NRZ number of bits in header field, [1150](#)
 NRZ number of bits in trailer field, [1159](#)
 NRZ number of bits per word in data field, [1160](#)
 NRZ number of start bits, [1155](#)
 NRZ number of words in data field, [1148](#)
 NRZ polarity, [1153](#)
 NRZ serial bus commands, [1142](#)
 NRZ signal source, [1154](#)
 NRZ trigger mode, [1156](#)
 Nth edge burst trigger source, [1453](#)
 Nth edge burst triggering, [1426](#)
 Nth edge in a burst idle, [1451](#)
 Nth edge in burst slope, [1452](#)
 Nth edge of burst counter, [1450](#)
 Nth edge of Edge Then Edge trigger, [1446](#)
 NTSC, [1497](#), [1501](#)
 null frame count (FlexRay), [1053](#)
 null offset, [915](#)
 NULL string, [1388](#)
 number format, [225](#)
 number of nibbles, SENT message, [1171](#)
 number of points, [310](#), [1526](#), [1528](#)
 number of time buckets, [1526](#), [1528](#)
 numeric variables, [82](#)
 numeric variables, reading query results into multiple, [84](#)

nwidth, [709](#)

O

obsolete and discontinued commands, [1611](#)
 obsolete commands, [1730](#)
 Occupied Bandwidth, FFT analysis measurement, [687](#)
 occurrence reported by magnitude, [1646](#)
 offset, [489](#)
 offset for Ax + B math operation, [519](#)
 offset value for channel voltage, [361](#)
 offset value for selected function, [520](#), [527](#)
 offset value for SENT Fast Channel Signal, [1179](#)
 offset, waveform generator, [1600](#)
 one values in waveform data, [1523](#)
 OPC (Operation Complete) command, [242](#)
 OPC (Operation Complete) status bit, [236](#), [238](#)
 OPEE (Operation Status Enable Register), [280](#)
 Open method, [77](#)
 operating configuration, [241](#), [1406](#)
 operating state, [249](#)
 operation complete, [242](#)
 operation status condition register, [282](#)
 Operation Status Condition Register (:OPERRegister:CONDition), [282](#), [1693](#)
 operation status conditions occurred, [253](#)
 Operation Status Enable Register (OPEE), [280](#)
 operation status event register, [285](#)
 Operation Status Event Register (:OPERRegister[:EVENT]), [285](#), [1691](#)
 operations for function, [521](#)
 operators, math, [521](#)
 OPERRegister:CONDition (Operation Status Condition Register), [282](#), [1693](#)
 OPERRegister[:EVENT] (Operation Status Event Register), [285](#), [1691](#)
 OPT (Option Identification), [243](#)
 optional syntax terms, [225](#)
 options, [243](#)
 OR trigger commands, [1470](#)
 order of digital channels on display, [1625](#)
 order of output, [1521](#)
 oscilloscope connection, opening, [77](#)
 oscilloscope connection, verifying, [69](#)
 oscilloscope external trigger, [461](#)
 oscilloscope models, [3](#)
 oscilloscope rate, [317](#)
 oscilloscope, connecting, [67](#)
 oscilloscope, initialization, [74](#)
 oscilloscope, operation, [6](#)
 oscilloscope, program structure, [74](#)
 oscilloscope, setting up, [67](#)
 oscilloscope, setup, [78](#)
 output control, demo signals, [420](#)
 output control, waveform generator, [1585](#)

output load impedance, waveform generator, [480](#), [1586](#)
 output messages ready, [253](#)
 output polarity, waveform generator, [1588](#)
 output power, [772](#)
 output queue, [242](#), [1686](#)
 output queue clear, [235](#)
 output ripple, [778](#)
 output ripple analysis, [891](#)
 output sequence, [1521](#)
 output source, Control Loop Response (Bode) power analysis, [842](#)
 output source, Power Supply Rejection Ratio (PSRR) power analysis, [885](#)
 overall pass/fail status for current harmonics analysis, [861](#)
 overlapped commands, [87](#)
 overload, [377](#)
 Overload Event Enable Register (OVL), [288](#)
 Overload Event Register (:OVLRegister), [1695](#)
 Overload Event Register (OVLr), [290](#)
 overload frame count (CAN), [1005](#)
 overload protection, [288](#), [290](#)
 overshoot of waveform, [710](#)
 overshoot percent for transient response analysis, [902](#)
 overvoltage, [377](#)
 OVL (Overload Event Enable Register), [288](#)
 OVLr (Overload Event Register), [290](#)
 OVLr bit, [282](#), [285](#)
 OVLRegister (Overload Event Register), [1695](#)

P

P1080L24HZ, [1497](#), [1501](#)
 P1080L25HZ, [1497](#), [1501](#)
 P1080L30HZ, [1501](#)
 P1080L50HZ, [1497](#), [1501](#)
 P1080L60HZ, [1497](#), [1501](#)
 P480L60HZ, [1497](#), [1501](#)
 P567L50HZ, [1501](#)
 P720L50HZ, [1501](#)
 P720L60HZ, [1497](#), [1501](#)
 PAL, [1497](#), [1501](#)
 palette for hardcopy, [554](#)
 palette for image, [954](#)
 PAL-M, [1497](#), [1501](#)
 parametric measurements, [658](#)
 parity, [1225](#)
 parity bits, LIN serial decode bus, [1100](#)
 parser, [260](#), [1735](#)
 pass, self test, [255](#)
 pass/fail status (overall) for current harmonics analysis, [861](#)
 password, network domain, [551](#)
 path information, recall, [933](#)
 path information, save, [959](#)
 pattern, [1091](#), [1092](#), [1093](#)
 pattern data, I2S, [1080](#)

- pattern data, LIN, 1109
 - pattern duration, 1463, 1464, 1476, 1477
 - pattern for pattern trigger, 1473
 - pattern format, I2S, 1082
 - pattern format, LIN, 1112
 - pattern length, 1024, 1111
 - PATtern trigger commands, 1472
 - pattern trigger format, 1475
 - pattern trigger qualifier, 1478
 - pattern triggering, 1426
 - pattern width, 1209, 1211
 - pause pulse, SENT messages, 1172
 - peak current, 773
 - peak data, 1517
 - peak detect, 318
 - peak detect acquisition type, 302, 1517
 - PEAK SEARCh commands, 1289
 - peak-peak math function, 523
 - peak-to-peak vertical value measurement, 681, 749
 - pending operations, 242
 - percent of waveform overshoot, 710
 - percent thresholds, 672
 - period measured to calculate phase, 714
 - period measurement, 75, 658, 713
 - Period, power modulation analysis, 869
 - period, waveform generator, 1590
 - persistence data, clear from display, 451
 - persistence, waveform, 431, 450
 - phase angle, demo signals, 419
 - phase data, including in control loop response results, 843
 - phase data, including in FRA results, 479
 - phase measured between channels, 714
 - phase measurements, 736
 - phase measurements with X cursors, 625
 - phase relationship of frequency-tracked waveform, 1596
 - phase shifted demo signals, 414
 - PID check value, USB trigger, 1253
 - PLL Locked bit, 274
 - PNG format screen image data, 440, 558
 - pod, 815, 817, 818, 819, 1537, 1620
 - POD commands, 815
 - POD data format, 1520
 - pod, stop displaying, 268
 - points, 310, 1526, 1528
 - points in waveform data, 1516
 - points per decade, Control Loop Response (Bode) power analysis, 840
 - points per decade, frequency response analysis, 475
 - points per decade, Power Supply Rejection Ratio (PSRR) power analysis, 883
 - polarity, 1226, 1499
 - polarity for glitch search, 1285
 - polarity for glitch trigger, 1466
 - polarity, runt search, 1295
 - polarity, runt trigger, 1481
 - polling synchronization example, 1718
 - polling synchronization with timeout, 1712
 - polling wait, 1710
 - PON (Power On) status bit, 236, 238
 - port value, USB search, 1380
 - port value, USB trigger, 1258
 - portrait layout for hardcopy, 547
 - position, 425, 622, 1414, 1421
 - position cursors, 1644, 1645
 - position in zoomed view, 1421
 - position waveforms, 1625
 - positive glitch trigger polarity, 1466
 - positive pulse width, 717
 - positive pulse width measurement, 75
 - positive pulse width, power modulation analysis, 869
 - positive slope, 1200, 1459
 - positive slope, Nth edge in burst, 1452
 - positive TV trigger polarity, 1499
 - positive width, 717
 - power analysis, enabling, 850
 - POWer commands, 821
 - power factor, 768
 - power factor for IEC 61000-3-2 Standard Class C, 856
 - power loss, 774
 - power phase angle, 762
 - power quality analysis, 890
 - power supply rejection ratio (PSRR), 877, 879, 880, 882
 - Power Supply Rejection Ratio (PSRR) power analysis settings, 876
 - preamble data, 1530
 - preamble metadata, 1516
 - precision analysis, 1393
 - precision analysis record, 1528
 - precision analysis record length, 1394
 - precision measurements and math functions, 1393
 - precision measurements, jitter analysis and, 588
 - predefined logic threshold, 1620
 - predefined threshold voltages, 1667
 - present working directory, recall operations, 933
 - present working directory, save operations, 959
 - preset conditions, 1395
 - preshoot measured on waveform, 716
 - previously stored configuration, 245
 - print command, 292
 - print job, start, 556
 - print mask test failures, 802
 - print query, 1660
 - printer driver for hardcopy, 1637
 - printer, active, 543
 - printing, 540
 - printing in grayscale, 1635
 - probe, 1457
 - probe attenuation affects channel voltage range, 378
 - probe attenuation factor (external trigger), 463
 - probe attenuation factor for selected channel, 362
 - probe head type, 369
 - probe ID, 370
 - probe sense for oscilloscope, 1623, 1627
 - probe skew value, 374, 1621
 - process sigma, mask test run, 805
 - program data, 1732
 - program data syntax rules, 1734
 - program initialization, 74
 - program message, 77, 233
 - program message syntax, 1731
 - program message terminator, 1732
 - program structure, 74
 - programming examples, 6, 1739
 - protecting against calibration, 336
 - protection, 288, 290, 377
 - protection lock, 1398
 - PTYPE byte (CXPI), trigger when present, 1040
 - PTYPE frames, CXPI, 1037
 - pulse waveform generator output, 1567
 - pulse width, 709, 717
 - pulse width duration trigger, 1463, 1464, 1468
 - pulse width measurement, 75, 658
 - pulse width trigger, 1440
 - pulse width trigger level, 1465
 - pulse width triggering, 1426
 - pulse width, waveform generator, 1570
 - ewidth, 717
 - Python, VISA COM example, 1766
 - Python, VISA example, 1814
 - Python, VISA.NET example, 1833
 - PyVISA package, 1814
- ## Q
- qualifier, 1468
 - qualifier for glitch search, 1286
 - qualifier, runt search, 1296
 - qualifier, runt trigger, 1482
 - qualifier, transition search, 1300
 - qualifier, transition trigger, 1492
 - qualifier, trigger duration, 1476, 1477
 - qualifier, trigger pattern, 1478
 - queries, multiple, 83
 - query error detected in Standard Event Status, 238
 - query responses, block data, 82
 - query responses, reading, 81
 - query results, reading into numeric variables, 82
 - query results, reading into string variables, 82
 - query return values, 1737
 - query setup, 540, 615, 658, 1406
 - query subsystem, 322, 422
 - querying setup, 352
 - querying the subsystem, 1426
 - queues, clearing, 1699

quick reference, commands, [89](#)
 quoted ASCII string, [226](#)
 QYE (Query Error) status bit, [236, 238](#)

R

ramp symmetry, waveform generator, [1571](#)
 ramp symmetry, waveform generator
 modulating signal, [1580](#)
 ramp waveform generator output, [1567](#)
 random trigger holdoff, [1434](#)
 range, [489, 1422](#)
 range for channels, [378](#)
 range for duration trigger, [1479](#)
 range for external trigger, [464](#)
 range for full-scale vertical axis, [526](#)
 range for glitch search, [1287](#)
 range for glitch trigger, [1468](#)
 range for time base, [1415](#)
 range of offset values, [361](#)
 range qualifier, [1467](#)
 range, I2S, [1083](#)
 ranges, value, [226](#)
 rate, [317](#)
 ratio measurements with X cursors, [625](#)
 ratio measurements with Y cursors, [632](#)
 ratio of AC RMS values measured between
 channels, [750](#)
 Ratio, power modulation analysis, [869](#)
 raw acquisition record, [1528](#)
 RCL (Recall), [245](#)
 Rds (dynamic ON resistance)
 waveform, [914](#)
 Rds(on) power measurement, [775](#)
 Rds(on) value for conduction
 calculation, [916](#)
 reactive power, [776](#)
 read configuration, [241](#)
 ReadIEEEBlock method, [77, 81, 83](#)
 ReadList method, [77, 81](#)
 ReadNumber method, [77, 81](#)
 readout, [1640](#)
 ReadString method, [77, 81](#)
 real power, [777](#)
 Real Power source in Class D harmonics
 analysis, [857](#)
 real-time acquisition mode, [308](#)
 real-time eye analysis,
 enabling/disabling, [940](#)
 real-time eye commands, [937](#)
 Real-Time Eye demo signal, [417](#)
 real-time eye opening height, [722](#)
 real-time eye opening width, [723](#)
 recall, [245, 926, 1406](#)
 recall arbitrary waveform, [928](#)
 recall CAN symbolic data, [929](#)
 RECall commands, [925](#)
 recall filename, [930, 1565](#)
 recall LIN symbolic data, [931](#)
 recall mask, [932](#)
 recall path information, [933](#)

recall reference waveform, [935](#)
 recall setup, [934](#)
 recalling and saving data, [431](#)
 receiver width, I2S, [1073](#)
 recovered clock, displaying, [385](#)
 RECTangular window for transient
 signals, [511, 586](#)
 reference, [489](#)
 reference clock, [1416](#)
 reference for time base, [1666](#)
 reference point, FFT Phase, [505](#)
 reference signal (10 MHz), [311](#)
 reference signal mode, [1416](#)
 reference waveform save source, [974](#)
 reference waveform, recall, [935](#)
 reference waveform, save, [975](#)
 reference waveforms, clear, [1603](#)
 reference waveforms, display, [1604](#)
 reference waveforms, label, [1605](#)
 reference waveforms, save to, [1606](#)
 reference waveforms, skew, [1607](#)
 reference waveforms, Y offset, [1608](#)
 reference waveforms, Y range, [1609](#)
 reference waveforms, Y scale, [1610](#)
 reference, lister, [598](#)
 reference, time base, [1417](#)
 registers, [238, 245, 249, 262, 276, 278,](#)
 [280, 282, 285, 288, 290](#)
 registers, clearing, [1699](#)
 reject filter, [1458](#)
 reject high frequency, [1430](#)
 reject noise, [1440](#)
 relative standard deviation, [734](#)
 remote command logging,
 enable/disable, [1399, 1403](#)
 remote control examples, [1739](#)
 Remote Terminal Address (RTA), M1553
 trigger, [1121](#)
 remote user interface enabled/disabled
 status, [283, 286, 1691, 1693](#)
 remove cursor information, [617](#)
 remove labels, [446](#)
 remove message from display, [1388](#)
 reorder channels, [263](#)
 repetitive acquisitions, [294](#)
 report errors, [1389](#)
 report transition, [742](#)
 reporting status, [1677](#)
 reporting the setup, [1426](#)
 request service, [253](#)
 Request-for-OPC flag clear, [235](#)
 reset, [246](#)
 reset conditions, [246](#)
 reset defaults, waveform generator, [1591](#)
 reset mask statistics, [793](#)
 reset measurements, [439](#)
 Resolution Bandwidth, FFT, [506](#)
 resolution of printed copy, [1635](#)
 resource session object, [77](#)
 ResourceManager object, [77](#)
 restore configurations, [241, 245, 249,](#)
 [1406](#)

restore labels, [446](#)
 restore setup, [245](#)
 return values, query, [1737](#)
 returning acquisition type, [318](#)
 returning number of data points, [310](#)
 RF burst demo signal, [415](#)
 right time base reference, [1417](#)
 ringing pulse demo signal, [414](#)
 ripple (output) analysis, [891](#)
 ripple, output, [778](#)
 rise time measurement, [658](#)
 rise time of positive edge, [721](#)
 Rise Time, power modulation analysis, [869](#)
 rising edge count measurement, [712](#)
 rising pulse count measurement, [715](#)
 RMS - AC, power modulation analysis, [869](#)
 RMS value measurement, [682, 751](#)
 roll time base mode, [1413](#)
 root (:) commands, [257, 260](#)
 root level commands, [3](#)
 RQL (Request Control) status bit, [236, 238](#)
 RQS (Request Service), [253](#)
 RS-232/UART triggering, [978](#)
 R-sense resistor value, N2825A
 user-defined R-sense head, [373](#)
 RST (Reset), [246](#)
 rules, tree traversal, [1735](#)
 rules, truncation, [1732](#)
 run, [254, 294](#)
 Run bit, [282, 285](#)
 run count, current harmonics analysis, [859](#)
 run mode, mask test, [800](#)
 run state, [293](#)
 run, USB 2.0 signal quality test, [392](#)
 running configuration, [249, 1406](#)
 RUNT SEARCh commands, [1294](#)
 runt search polarity, [1295](#)
 runt search qualifier, [1296](#)
 runt search source, [1297](#)
 runt search, pulse time, [1298](#)
 RUNT trigger commands, [1480](#)
 runt trigger polarity, [1481](#)
 runt trigger qualifier, [1482](#)
 runt trigger source, [1483](#)
 runt trigger time, [1484](#)
 Rx frame count (UART), [1222](#)
 Rx source, [1227](#)

S

S and E or U value, USB search, [1382](#)
 S and E or U value, USB trigger, [1260](#)
 sample rate, [3, 317](#)
 Sample Rate, FFT, [509](#)
 sampled data, [1624](#)
 sampled data points, [1523](#)
 SAV (Save), [249](#)
 save, [249, 946](#)
 save arbitrary waveform, [947](#)
 SAVE commands, [943](#)

- save current harmonics analysis results, 958
- save filename, 949
- save image, 950
- save image with inksaver, 953
- save mask, 955, 956
- save mask test failures, 803
- save path information, 959
- save reference waveform, 975
- save setup, 968
- save to reference waveform location, 1606
- save waveform data, 969
- saved image, area, 1662
- saving and recalling data, 431
- SBUS A429 commands, 982
- SBUS CAN commands, 1001
- SBUS commands, 977
- SBUS CXPI commands, 1031
- SBUS I2S commands, 1067
- SBUS MANchester commands, 1123
- SBUS NRZ commands, 1142
- SBUS SENT commands, 1161
- SBUS USBPd commands, 1261
- SBUS<n> commands, general, 979
- SC value, USB search, 1381
- SC value, USB trigger, 1259
- scale, 528, 1419, 1423
- scale factors output on hardcopy, 544, 951
- scale for channels, 379
- scale units for channels, 368, 380
- scale units for external trigger, 465
- scaling display factors, 362
- scheme, color grade, 346
- SCPI commands, 85
- SCPI.NET examples, 1860
- scratch measurements, 1639
- screen area for hardcopy print, 542
- screen area for saved image, 1662
- screen display of logged remote commands, enable/disable, 1401
- screen image data, 440, 557
- SDI pattern, ARINC 429 trigger, 996, 1308
- SEARch commands, 1273
- SEARch commands, A429, 1304
- SEARch commands, CAN, 1310
- SEARch commands, EDGE, 1279
- SEARch commands, FLEXray, 1320
- SEARch commands, general, 1274
- SEARch commands, GLITch, 1282
- SEARch commands, I2S, 1326
- SEARch commands, IIC, 1332
- SEARch commands, LIN, 1339
- SEARch commands, M1553, 1348
- SEARch commands, PEAK, 1289
- SEARch commands, RUNT, 1294
- SEARch commands, SENT, 1352
- SEARch commands, SPI, 1357
- SEARch commands, TRANSition, 1299
- SEARch commands, UART, 1361
- SEARch commands, USB, 1365
- search event (found) times, saving, 966
- search for found event, 1276
- search mode, 1277
- search state, 1278
- search, edge slope, 1280
- search, edge source, 1281
- search, USB, 1367
- SECAM, 1497, 1501
- second-order PLL clock recovery, 386
- seconds per division, 1419
- segmented memory acquisition times, 967
- segmented waveform save option, 973
- segments, analyze, 312
- segments, count of waveform, 1534
- segments, setting number of memory, 313
- segments, setting the index, 314
- segments, time tag, 1535
- select measurement channel, 727
- self-test, 255
- sensing a channel probe, 1623
- sensing an external trigger probe, 1627
- sensitivity of oscilloscope input, 362
- SENT demo signal, 417
- SENT enhanced serial message ID and data lengths, 1195
- SENT fast channel data search value, 1353
- SENT fast channel data trigger setting, 1190
- SENT FAST data, 1541
- SENT input source, 1185
- SENT percent tolerance variation trigger, 1196
- SENT SEARch commands, 1352
- SENT search mode, 1354
- SENT serial bus commands, 1161
- SENT signal length setting, 1175
- SENT signals display setting, 1174
- SENT slow channel data search value, 1355
- SENT slow channel ID and data trigger data setting, 1191
- SENT slow channel ID search value, 1356
- SENT slow channel ID trigger setting, 1193
- SENT SLOW data, 1541
- SENT trigger mode, 1188
- SENT triggering, 978
- sequential commands, 87
- serial clock, 1089, 1204
- serial data, 1090
- serial decode bus, 977
- serial decode bus display, 980
- serial decode mode, 981
- serial frame, 1205
- serial jitter demo signal, 417
- serial number, 295
- service request, 253
- Service Request Enable Register (SRE), 251, 1684
- set center frequency, 499
- set cursors, 1644, 1645
- set date, 1386
- set time, 1408
- set up oscilloscope, 67
- setting digital display, 423
- setting digital label, 328, 424
- setting digital position, 425
- setting digital threshold, 427
- setting display, 497
- setting external trigger level, 461
- setting impedance for channels, 358
- setting inversion for channels, 359
- setting pod display, 817
- setting pod size, 818
- setting pod threshold, 819
- settings, 245, 249
- settings conflict errors, 283, 286, 1691, 1693
- settings, instrument, 540
- setup, 302, 322, 352, 422, 431, 540, 1406
- setup and hold trigger clock source, 1487
- setup and hold trigger data source, 1488
- setup and hold trigger hold time, 1489
- setup and hold trigger setup time, 1490
- setup and hold trigger slope, 1486
- setup configuration, 245, 249, 1406
- setup defaults, 246, 1395
- setup memory, 245
- setup reported, 1426
- setup time, setup and hold trigger, 1490
- setup, recall, 934
- setup, save, 968
- shape of modulation signal, waveform generator, 1579
- SHOLd trigger commands, 1485
- short form, 6, 1732
- show channel labels, 446
- show measurements, 658, 725
- SICL example in C, 1840
- SICL example in Visual Basic, 1849
- SICL examples, 1840
- sidebar, display, 452
- sigma, mask test run, 805
- signal speed, ARINC 429, 993
- signal type, 375
- signal type, ARINC 429, 991
- signal value, CAN symbolic search, 1319
- signal value, CAN symbolic trigger, 1030
- signal value, LIN symbolic search, 1347
- signal value, LIN symbolic trigger, 1115
- signal, CAN symbolic search, 1318
- signal, CAN symbolic trigger, 1029
- signal, LIN symbolic search, 1346
- signal, LIN symbolic trigger, 1114
- signed data, 1519
- simple command headers, 1733
- sine cardinal waveform generator output, 1568
- sine waveform demo signal, 414
- sine waveform generator output, 1566
- single acquisition, 296
- single frequency, frequency response analysis, 471
- single-ended probe heads, 369
- single-ended signal type, 375
- single-shot demo signal, 414

- single-shot DUT, synchronizing with, 1714
 - single-shot waveform generator
 - output, 1589
 - size, 818
 - size, digital channels, 426
 - skew, 374, 1621
 - skew reference waveform, 1607
 - slew rate of an edge, 726
 - slew rate power analysis, 911
 - slope, 1200, 1459
 - slope (direction) of waveform, 1646
 - slope not valid in TV trigger mode, 1459
 - slope, arming edge, Edge Then Edge trigger, 1443
 - slope, Nth edge in burst, 1452
 - slope, setup and hold trigger, 1486
 - slope, transition search, 1301
 - slope, transition trigger, 1493
 - slope, trigger edge, Edge Then Edge trigger, 1447
 - slot, network printer, 552
 - SLOW data, SENT, 1541
 - smoothing acquisition type, 1518
 - smoothing math function, 522
 - smoothing math function, number of points, 534
 - snapshot all measurement, 660
 - software version, 240
 - source, 727, 992, 1017, 1103
 - source (voltage or current) for slew rate analysis, 912
 - source channel, M1553, 1119
 - source for function, 1631
 - source for glitch search, 1288
 - source for Nth edge burst trigger, 1453
 - source for trigger, 1460
 - source for TV trigger, 1500
 - source function for FFT peak search, 1292
 - source input for function, first, 535
 - source input for function, second, 537
 - source, arming edge, Edge Then Edge trigger, 1444
 - source, automask, 788
 - source, FLEXray, 1057
 - source, mask test, 813
 - source, real-time eye analysis, 939
 - source, runt search, 1297
 - source, runt trigger, 1483
 - source, save reference waveform, 974
 - source, transition trigger, 1302, 1494
 - source, trigger edge, Edge Then Edge trigger, 1448
 - source, waveform, 1537
 - span, 521
 - span of frequency on display, 508
 - Spec error counter (CAN), 1007
 - special PID, USB search, 1378
 - special PID, USB trigger, 1256
 - specify measurement, 727
 - speed of ARINC 429 signal, 993
 - speed, USB decode, 1243
 - SPI, 1200
 - SPI clock timeout, 1201
 - SPI decode bit order, 1199
 - SPI decode word width, 1213
 - SPI demo signal, 416
 - SPI MISO data, 1541
 - SPI SEARCh commands, 1357
 - SPI serial search, data, 1359
 - SPI serial search, data width, 1360
 - SPI serial search, mode, 1358
 - SPI trigger, 1203, 1209, 1211
 - SPI trigger clock, 1204
 - SPI trigger commands, 1197
 - SPI trigger frame, 1205
 - SPI trigger MISO data pattern, 1208
 - SPI trigger MOSI data pattern, 1210
 - SPI trigger type, 1212
 - SPI trigger, MISO data source, 1206
 - SPI trigger, MOSI data source, 1207, 1664
 - SPI triggering, 978
 - square math function, 522
 - square root math function, 522
 - square wave duty cycle, waveform generator, 1572
 - square waveform generator output, 1566
 - SRE (Service Request Enable Register), 251, 1684
 - SRQ (Service Request interrupt), 272, 276, 280
 - SSM pattern, ARINC 429 trigger, 997, 1309
 - standard deviation measured on waveform, 724
 - Standard Event Status Enable Register (ESE), 236, 1689
 - Standard Event Status Register (ESR), 238, 1688
 - standard for CAN FD decode, 1012
 - standard for video, 1501
 - standard, LIN, 1104
 - start acquisition, 254, 270, 294, 296
 - start and stop edges, 672
 - start cursor, 1644
 - start frequency, FFT math function, 502
 - start measurement, 658
 - start print job, 556
 - start time, 1468, 1644
 - start time marker, 1641
 - starting bit for SENT Fast Channel Signal, 1183
 - starting byte of data, CXPI trigger, 1043
 - state memory, 249
 - state of instrument, 241, 1406
 - state, run, 293
 - statistics increment, 731
 - statistics reset, 733
 - statistics results, 718
 - statistics, max count, 732
 - statistics, relative standard deviation, 734
 - statistics, type of, 729
 - status, 252, 297, 299
 - Status Byte Register (STB), 250, 252, 253, 1682
 - status data structure clear, 235
 - status registers, 84
 - status reporting, 1677
 - STB (Status Byte Register), 250, 252, 253, 1682
 - steady state output voltage expected, 906, 907, 908
 - step size for frequency span, 508
 - stop, 270, 298
 - stop acquisition, 298
 - stop cursor, 1645
 - stop displaying channel, 268
 - stop displaying math function, 268
 - stop displaying pod, 268
 - stop frequency, FFT math function, 503
 - stop on mask test failure, 804
 - stop time, 1468, 1645
 - storage, 249
 - store instrument setup, 241, 249
 - store setup, 249
 - storing calibration information, 334
 - string variables, 82
 - string variables, reading multiple query results into, 83
 - string variables, reading query results into multiple, 83
 - string, quoted ASCII, 226
 - subnet mask, 68
 - subsource, waveform source, 1541
 - subsystem commands, 3, 1735
 - subtract math function, 521, 1537
 - subtract math function as g(t) source, 1628
 - sweep mode, trigger, 1425, 1441
 - sweep speed set to fast to measure fall time, 684
 - sweep speed set to fast to measure rise time, 721
 - switch disable, 1390
 - switching level, current, 915
 - switching level, voltage, 918
 - switching loss per cycle, 764
 - switching loss power analysis, 913
 - sync break, LIN, 1105
 - sync frame count (FlexRay), 1055
 - syntax elements, 225
 - syntax rules, program data, 1734
 - syntax, optional terms, 225
 - syntax, program message, 1731
 - SYSTem commands, 1383
 - system commands, 1386, 1388, 1389, 1390, 1406, 1408
 - system commands introduction, 1385
- ## T
- table of current harmonics results, 853
 - tdelta, 1640
 - Tektronix probe model number, 371
 - telnet ports 5024 and 5025, 1523
 - Telnet sockets, 85
 - temperature color grade scheme, 343

- temporary message, 1388
- TER (Trigger Event Register), 299, 1685
- termination conditions, mask test, 800
- test sigma, mask test run, 805
- test, self, 255
- test, USB 2.0 signal quality, 397
- text, writing to display, 1388
- THD (total harmonics distortion), 862
- theme, color grade, 346
- threshold, 427, 819, 1620, 1667
- threshold for FFT peak search, 1293
- threshold voltage (lower) for measurement, 1638
- threshold voltage (upper) for measurement, 1647
- thresholds, 672, 1641
- thresholds used to measure period, 713
- thresholds, how autoscale affects, 263
- time base, 1413, 1414, 1415, 1419, 1666
- time base commands introduction, 1412
- time base reference, 1417
- time base reset conditions, 247, 1396
- time base window, 1421, 1422, 1423
- time between points, 1640
- time buckets, 305, 306
- time delay, 1666
- time delay, Edge Then Edge trigger, 1445
- time delta, 1640
- time difference between data points, 1545
- time duration, 1468, 1476, 1477, 1479
- time holdoff for trigger, 1431
- time interval, 742, 1640
- time interval between trigger and occurrence, 1646
- time marker sets start time, 1641
- time measurements with X cursors, 625
- time per division, 1415
- time record, 511
- time reference, lister, 598
- time specified, 756, 1651
- time, calibration, 340
- time, mask test run, 806
- time, runt pulse search, 1298
- time, runt trigger, 1484
- time, start marker, 1644
- time, stop marker, 1645
- time, system, 1408
- time, transition search, 1303
- time, transition trigger, 1495
- time/div, how autoscale affects, 263
- time-at-max measurement, 1642
- time-at-min measurement, 1643
- TIMEbase commands, 1411
- timebase vernier, 1420
- TIMEbase:MODE, 80
- time-ordered label list, 447
- timeout, SPI clock, 1201
- timing measurement, 658
- title channels, 360
- title, mask test, 814
- token PID, USB search, 1379
- token PID, USB trigger, 1257
- tolerance for determining valid SENT sync pulses, 1187
- tolerance, automask, 790, 791
- top of waveform value measured, 752
- total frame count (CAN), 1008
- total frame count (FlexRay), 1056
- Total Harmonic Distortion, FFT analysis measurement, 688
- total harmonics distortion (THD), 862
- total waveforms in mask test, 795
- touchscreen on/off, 1409
- trace memory, 297
- track measurements, 725
- tracking, dual channel waveform generator, 1592
- transfer instrument state, 241, 1406
- transforms, math, 521
- transient response, 779
- transient response analysis, 919, 920, 923
- TRANSition SEARCh commands, 1299
- transition search qualifier, 1300
- transition search slope, 1301
- transition search time, 1303
- transition trigger qualifier, 1492
- transition trigger slope, 1493
- transition trigger source, 1302, 1494
- transition trigger time, 1495
- transmit word size, I2S, 1084
- transparent screen background, remote command logging, 1404
- transparent, display, 453
- tree traversal rules, 1735
- trend measurement, 538
- TRG (Trigger), 251, 253, 254
- TRIG OUT BNC, 335
- trigger armed event register, 282, 285
- trigger armed status, checking for, 1701
- trigger burst, UART, 1230
- trigger channel source, 1469, 1500
- TRIGger commands, 1425
- TRIGger commands, general, 1427
- trigger data, UART, 1231
- TRIGger DELay commands, 1442
- trigger duration, 1476, 1477
- TRIGger EBURst commands, 1449
- TRIGger EDGE commands, 1454
- trigger edge coupling, 1456
- trigger edge slope, 1459
- trigger edge slope, Edge Then Edge trigger, 1447
- trigger edge source, Edge Then Edge trigger, 1448
- trigger event bit, 299
- Trigger Event Register (TER), 1685
- TRIGger FLEXray commands, 1048
- TRIGger GLITCh commands, 1461
- trigger holdoff, 1431
- trigger idle, UART, 1232
- TRIGger IIC commands, 1086
- trigger level auto set up, 1436
- trigger level constants, 362
- trigger level voltage, 1457
- trigger level, high, 1437
- trigger level, low, 1438
- TRIGger LIN commands, 1097
- TRIGger M1553 commands, 1116
- trigger occurred, 253
- TRIGger OR commands, 1470
- TRIGger PATtern commands, 1472
- trigger pattern qualifier, 1478
- trigger qualifier, UART, 1233
- trigger reset conditions, 247, 1396
- TRIGger RUNT commands, 1480
- TRIGger SHOLd commands, 1485
- trigger SPI clock slope, 1200
- TRIGger SPI commands, 1197
- trigger status bit, 299
- trigger sweep mode, 1425
- TRIGger TV commands, 1491, 1496
- trigger type, ARINC 429, 999, 1306
- trigger type, SPI, 1212
- trigger type, UART, 1234
- TRIGger UART commands, 1214
- TRIGger USB commands, 1236
- TRIGger ZONE commands, 1506
- trigger, ARINC 429 source, 992
- trigger, CAN, 1018
- trigger, CAN FD sample point, 1011
- trigger, CAN pattern data length, 1024
- trigger, CAN pattern ID mode, 1027
- trigger, CAN sample point, 1013
- trigger, CAN signal baudrate, 1014
- trigger, CAN signal definition, 1015
- trigger, CAN source, 1017
- trigger, duration greater than, 1476
- trigger, duration less than, 1477
- trigger, duration range, 1479
- trigger, edge coupling, 1456
- trigger, edge level, 1457
- trigger, edge reject, 1458
- trigger, edge slope, 1459
- trigger, edge source, 1460
- trigger, FLEXray, 1058
- trigger, FLEXray error, 1059
- trigger, FLEXray event, 1062
- trigger, force a, 1429
- trigger, glitch greater than, 1463
- trigger, glitch less than, 1464
- trigger, glitch level, 1465
- trigger, glitch polarity, 1466
- trigger, glitch qualifier, 1467
- trigger, glitch range, 1468
- trigger, glitch source, 1469
- trigger, high frequency reject filter, 1430
- trigger, holdoff, 1431
- trigger, I2S, 1077
- trigger, I2S alignment, 1070
- trigger, I2S audio channel, 1079
- trigger, I2S clock slope, 1072
- trigger, I2S CLOCKsource, 1074
- trigger, I2S DATA source, 1075
- trigger, I2S pattern data, 1080
- trigger, I2S pattern format, 1082

- trigger, I2S range, 1083
 - trigger, I2S receiver width, 1073
 - trigger, I2S transmit word size, 1084
 - trigger, I2S word select (WS) low, 1085
 - trigger, I2S word select (WS) source, 1076
 - trigger, IIC clock source, 1089
 - trigger, IIC data source, 1090
 - trigger, IIC pattern address, 1091
 - trigger, IIC pattern data, 1092
 - trigger, IIC pattern data 2, 1093
 - trigger, IIC qualifier, 1094
 - trigger, IIC signal baudrate, 1102
 - trigger, IIC type, 1095
 - trigger, LIN, 1106
 - trigger, LIN pattern data, 1109
 - trigger, LIN pattern data length, 1111
 - trigger, LIN pattern format, 1112
 - trigger, LIN sample point, 1101
 - trigger, LIN signal definition, 1663
 - trigger, LIN source, 1103
 - trigger, mode, 1439
 - trigger, noise reject filter, 1440
 - trigger, Nth edge burst source, 1453
 - trigger, Nth edge in burst slope, 1452
 - trigger, Nth edge of burst count, 1450
 - trigger, Nth edge of Edge Then Edge trigger, 1446
 - trigger, SPI clock slope, 1200
 - trigger, SPI clock source, 1204
 - trigger, SPI clock timeout, 1201
 - trigger, SPI frame source, 1205
 - trigger, SPI framing, 1203
 - trigger, SPI pattern MISO width, 1209
 - trigger, SPI pattern MOSI width, 1211
 - trigger, sweep, 1441
 - trigger, threshold, 1667
 - trigger, TV line, 1497
 - trigger, TV mode, 1498, 1668
 - trigger, TV polarity, 1499
 - trigger, TV source, 1500
 - trigger, TV standard, 1501
 - trigger, UART base, 1229
 - trigger, UART baudrate, 1218
 - trigger, UART bit order, 1219
 - trigger, UART parity, 1225
 - trigger, UART polarity, 1226
 - trigger, UART Rx source, 1227
 - trigger, UART Tx source, 1228
 - trigger, UART width, 1235
 - trigger, USB, 1244
 - truncation rules, 1732
 - TST (Self Test), 255
 - tstart, 1644
 - tstop, 1645
 - TTL threshold voltage for digital channels, 427, 1620
 - TTL trigger threshold voltage, 1667
 - turn function on or off, 1632
 - turn off channel, 268
 - turn off channel labels, 446
 - turn off digital pod, 268
 - turn off math function, 268
 - turn off time, 770, 873, 874
 - turn on channel labels, 446
 - turn on channel number display, 1625
 - turn on time, 771, 873, 874
 - turn on/turn off analysis thresholds, 874
 - turn on/turn off time analysis, 870, 871, 872, 873
 - turning channel display on and off, 357
 - turning off/on function calculation, 497
 - turning vectors on or off, 1624
 - TV mode, 1498, 1668
 - TV trigger commands, 1491, 1496
 - TV trigger line number setting, 1497
 - TV trigger mode, 1500
 - TV trigger polarity, 1499
 - TV trigger standard setting, 1501
 - TV triggering, 1426
 - tvmode, 1668
 - Tx data, UART, 1541
 - Tx frame count (UART), 1223
 - Tx source, 1228
 - type of power being converted, efficiency measurement, 849
 - type, USB 2.0 signal quality test, 399
- ## U
- UART base, 1229
 - UART baud rate, 1218
 - UART bit order, 1219
 - UART frame counters, reset, 1221
 - UART parity, 1225
 - UART polarity, 1226
 - UART Rx source, 1227
 - UART SEARCh commands, 1361
 - UART serial search, data, 1362
 - UART serial search, data qualifier, 1364
 - UART serial search, mode, 1363
 - UART trigger burst, 1230
 - UART trigger commands, 1214
 - UART trigger data, 1231
 - UART trigger idle, 1232
 - UART trigger qualifier, 1233
 - UART trigger type, 1234
 - UART Tx data, 1541
 - UART Tx source, 1228
 - UART width, 1235
 - UART/RS232 demo signal, 415
 - UART/RS-232 triggering, 978
 - UI intervals total, real-time eye analysis, 941
 - units (vertical) for FFT, 510
 - units per division, 368, 379, 380, 465, 1419
 - units per division (vertical) for function, 379, 528
 - units, automask, 789
 - units, X cursor, 625, 626
 - units, Y cursor, 632, 633
 - unsigned data, 1519
 - unsigned mode, 1543
 - update rate, waveform, 1393
 - upper threshold, 713
 - upper threshold voltage for measurement, 1647
 - uppercase characters in commands, 1731
 - URQ (User Request) status bit, 236, 238
 - USB (Device) interface, 67
 - USB 2.0 signal quality test results, save, 948
 - USB 2.0 triggering, 978
 - USB demo signal, 417
 - USB PD demo signal, 418
 - USB PD trigger mode, 1263
 - USB PD trigger, control message type, 1266
 - USB PD trigger, data message type, 1268, 1269
 - USB PD trigger, header content trigger qualifier, 1272
 - USB PD trigger, header type, 1264
 - USB PD trigger, user-defined header value, 1271
 - USB PD triggering, 978
 - USB PD waveform source, 1262
 - USB SEARCh commands, 1365
 - USB storage device, recalling files from, 926
 - USB storage device, saving files to, 946
 - USB trigger commands, 1236
 - USB triggering, 1426
 - USBPD serial bus commands, 1261
 - user defined channel labels, 360
 - user defined threshold, 1620
 - user event conditions occurred, 253
 - User Files directory, 933, 959
 - user name, network domain, 553
 - User's Guide, 6
 - user-defined baud rate, ARINC 429, 986
 - user-defined Real Power in Class D harmonics analysis, 858
 - user-defined threshold voltage for digital channels, 427
 - user-defined trigger threshold, 1667
 - USR (User Event bit), 251, 253
 - utilization, CAN bus, 1009
- ## V
- valid command strings, 1731
 - valid pattern time, 1476, 1477
 - value, 742
 - value measured at base of waveform, 680, 746
 - value measured at specified time, 756, 1651
 - value measured at top of waveform, 752
 - value ranges, 226
 - values required to fill time buckets, 306
 - VBA, 76, 1740
 - Vce(sat) power measurement, 780

- Vce(sat) value for conduction calculation, 917
 - vectors turned on or off, 1624
 - vectors, display, 454
 - vectors, turning on or off, 431
 - vernier, channel, 381
 - vernier, horizontal, 1420
 - vertical adjustment, fine (vernier), 381
 - vertical amplitude measurement, 678, 744
 - vertical axis defined by RANGe, 526
 - vertical axis range for channels, 378
 - vertical histogram, 562
 - vertical offset for channels, 361
 - vertical peak-to-peak measured on waveform, 681, 749
 - vertical scale, 379, 528
 - vertical scaling, 1530
 - vertical threshold, 1620
 - vertical units for FFT, 510
 - vertical value at center screen, 520, 527
 - vertical value maximum measured on waveform, 747
 - vertical value measurements to calculate overshoot, 710
 - vertical value minimum measured on waveform, 748
 - video line to trigger on, 1497
 - video standard selection, 1501
 - view, 300, 1544, 1625
 - view turns function on or off, 1632
 - VISA COM example in C#, 1749
 - VISA COM example in Python, 1766
 - VISA COM example in Visual Basic, 1740
 - VISA COM example in Visual Basic .NET, 1758
 - VISA example in C, 1774
 - VISA example in C#, 1793
 - VISA example in Python, 1814
 - VISA example in Visual Basic, 1783
 - VISA example in Visual Basic .NET, 1804
 - VISA examples, 1740, 1774
 - VISA.NET example in C#, 1821
 - VISA.NET example in Python, 1833
 - VISA.NET example in Visual Basic .NET, 1827
 - VISA.NET examples, 1821
 - Visual Basic .NET, VISA COM example, 1758
 - Visual Basic .NET, VISA example, 1804
 - Visual Basic .NET, VISA.NET example, 1827
 - Visual Basic 6.0, 77
 - Visual Basic for Applications, 76, 1740
 - Visual Basic, SICL library example, 1849
 - Visual Basic, VISA COM example, 1740
 - Visual Basic, VISA example, 1783
 - visualizations, math, 523
 - voltage (waveform generator), frequency response analysis, 481
 - voltage crossing reported or not found, 1646
 - voltage difference between data points, 1548
 - voltage difference measured, 1648
 - voltage in, frequency response analysis, 477, 478
 - voltage level for active trigger, 1457
 - voltage marker used to measure waveform, 1649, 1650
 - voltage offset value for channels, 361
 - voltage probe, 368, 380, 465
 - voltage profile, frequency response analysis, 482
 - voltage ranges for channels, 378
 - voltage ranges for external trigger, 464
 - voltage source, 910
 - voltage threshold, 672
 - voltage, maximum expected input, 903, 904, 905
- ## W
- WAI (Wait To Continue), 256
 - wait, 256
 - wait for operation complete, 242
 - Wait Trig bit, 282, 285
 - warranty, 2
 - waveform base value measured, 680, 746
 - WAVeform command, 75
 - WAVeform commands, 1513
 - waveform data, 1516
 - waveform data format, 970
 - waveform data length, 971
 - waveform data length, maximum, 972
 - waveform data, save, 969
 - waveform generator, 1555
 - waveform generator amplitude, 481, 1597
 - waveform generator function, 1566
 - waveform generator high-level voltage, 1598
 - waveform generator load impedance, Control Loop Response (Bode) power analysis, 844
 - waveform generator load impedance, Power Supply Rejection Ratio (PSRR) power analysis, 887
 - waveform generator low-level voltage, 1599
 - waveform generator offset, 1600
 - waveform generator output control, 1585
 - waveform generator output load impedance, 480, 1586
 - waveform generator output mode, 1587
 - waveform generator output polarity, 1588
 - waveform generator period, 1590
 - waveform generator pulse width, 1570
 - waveform generator ramp symmetry, 1571
 - waveform generator reset defaults, 1591
 - waveform generator square wave duty cycle, 1572
 - waveform introduction, 1516
 - waveform maximum vertical value measured, 747
 - waveform minimum vertical value measured, 748
 - waveform must cross voltage level to be an occurrence, 1646
 - WAVeform parameters, 80
 - waveform peak-to-peak vertical value measured, 681, 749
 - waveform period, 713
 - waveform persistence, 431
 - waveform RMS value measured, 682, 751
 - waveform save option for segments, 973
 - waveform source, 1537
 - waveform source subsource, 1541
 - waveform standard deviation value measured, 724
 - waveform update rate, 1393
 - waveform vertical amplitude, 678, 744
 - waveform voltage measured at marker, 1649, 1650
 - waveform, byte order, 1521
 - waveform, count, 1522
 - waveform, data, 1523
 - waveform, format, 1525
 - waveform, points, 1526, 1528
 - waveform, preamble, 1530
 - waveform, type, 1542
 - waveform, unsigned, 1543
 - waveform, view, 1544
 - waveform, X increment, 1545
 - waveform, X origin, 1546
 - waveform, X reference, 1547
 - waveform, Y increment, 1548
 - waveform, Y origin, 1549
 - waveform, Y reference, 1550
 - WAVeform:FORMat, 80
 - waveforms, mask test run, 807
 - wavegen output amplitude(s), Control Loop Response (Bode) power analysis, 845
 - wavegen output amplitude(s), Power Supply Rejection Ratio (PSRR) power analysis, 888
 - Web control, 85
 - website, examples on, 1739
 - WGEN commands, 1551
 - WGEN trigger source, 1460
 - what's new, 41
 - width, 1235, 1468
 - Width to -Width jitter measurement, 667
 - window, 1421, 1422, 1423
 - window time, 1415
 - window time base mode, 1413
 - window, measurement, 753
 - windows, 511
 - windows as filters to Fast Fourier Transforms, 511
 - windows for Fast Fourier Transform functions, 511
 - WMEmory commands, 1601
 - word counter (ARINC 429), 989
 - word counter (ARINC 429), reset, 988
 - word format, 1525
 - word format for data transfer, 1519

word format, ARINC 429, [990](#)
 word select (WS) low, I2S trigger, [1085](#)
 word select (WS) source, I2S, [1076](#)
 word width, SPI decode, [1213](#)
 write mode, remote command
 logging, [1399, 1405](#)
 write text to display, [1388](#)
 WriteIEEEBlock method, [77, 83](#)
 WriteList method, [77](#)
 WriteNumber method, [77](#)
 WriteString method, [77](#)

X

X axis markers, [615](#)
 X cursor units, [625, 626](#)
 X delta, [616, 624](#)
 X delta, mask scaling, [810](#)
 X1 and X2 cursor value difference, [616, 624](#)
 X1 cursor, [615, 619, 620](#)
 X1, mask scaling, [809](#)
 X2 cursor, [615, 622, 623](#)
 X-axis functions, [1412](#)
 X-increment, [1545](#)
 X-of-max measurement, [754](#)
 X-of-min measurement, [755](#)
 X-origin, [1546](#)
 X-reference, [1547](#)
 X-Y mode, [1412, 1413](#)

Y

Y axis markers, [615](#)
 Y cursor units, [632, 633](#)
 Y offset, reference waveform, [1608](#)
 Y range, reference waveform, [1609](#)
 Y scale, reference waveform, [1610](#)
 Y1 and Y2 cursor value difference, [631](#)
 Y1 cursor, [615, 620, 628, 631](#)
 Y1, mask scaling, [811](#)
 Y2 cursor, [615, 623, 630, 631](#)
 Y2, mask scaling, [812](#)
 Y-axis value, [1549](#)
 Y-increment, [1548](#)
 Y-origin, [1549, 1550](#)
 Y-reference, [1550](#)

Z

zero values in waveform data, [1523](#)
 zone 1 or zone 2 mode, [1509](#)
 zone 1 or zone 2 placement, [1510](#)
 zone 1 or zone 2 state, [1512](#)
 zone 1 or zone 2 validity, [1511](#)
 zone qualified trigger source, [1507](#)
 zone qualified trigger state, [1508](#)
 ZONE trigger commands, [1506](#)

Zoom In/Out setting for N2820A
 channel, [376](#)
 zoomed time base, [1413](#)
 zoomed time base measurement
 window, [753](#)
 zoomed time base mode, how autoscale
 affects, [263](#)
 zoomed window horizontal scale, [1423](#)

