

Application note

Eliminating sensor errors in temperature control loop calibrations

Calibrating a loop is more than just 4 mA to 20 mA

Introduction


Temperature plays an important role in many industrial and commercial processes. Examples range from sterilization in pharmaceutical companies, metal heat-treatment to ensure optimal strength in aerospace applications, temperature verification in a cold storage warehouse, and atmospheric and oceanographic research. In all temperature measurement applications, the sensor strongly affects the results; unfortunately, many measurements are made without optimizing the system to get the best performance from the temperature transducer.

Significant performance improvement can be realized by optimizing the loop calibration measurement system to better accommodate the unique characteristics of the temperature sensing element. All temperature probes and their sensing elements are unique, with variations in materials, construction and usage, or exposure to different environments. This uniqueness continues throughout the useful life of the sensor, in the form of drift due to mechanical shock and vibration or to contamination of the materials when exposed to the material they are measuring. Only through periodic verification can these differences and changes be accommodated improving total measurement performance.

The majority of process temperature measurements are performed using a sensing element connected to a transmitter. Figure 1 shows a diagram of a common temperature loop.

In many applications, it is common to verify the elements of the measurement system separately, but in doing so, significant improvements made possible by considering the system as a whole are ignored. One of the main reasons the elements are verified or calibrated separately is

that it is often considered to be more efficient. Verifying the measurement component is done simply and quickly with an electronic thermocouple (TC) or resistance temperature detector (RTD) simulator. This approach does not verify the performance of the associated temperature probe, and assumes all probes are identical and closely follow some standard. In practice, no two probes are identical; they all vary from the ideal standard, and over time and usage their characteristics change. Understanding how probes vary from the ideal will allow you to optimize the measurement system to achieve the best performance.






Figure 2.




Figure 3. System accuracy improvement achieved with a calibrated Pt100 Sensor.

Optimizing Performance

Emerson uses the example provided in Table 1 for information on the possible performance improvement of their Model 644H Smart Temperature Transmitter. To achieve this performance improvement, the 644H is given Information (Callendar Van Dusen Coefficients) that allows it to correct for the unique performance of the temperature sensing element, in this case a standard IEC751 Pt100 sensor.

Dry-wells and micro-baths are good choices for verifying the performance of temperature probes and other related sensors. But they do not have the capability to calibrate the transmitter's output or readout and, by themselves, do not allow the entire measurement loop to be optimized. A heat source, combined with an intelligent electronic process calibrator that is capable of calibrating the transmitter and readout, is required if the above performance improvement is to be realized and maintained.

By combining the automating and documenting capabilities of the Fluke 754 Documenting Process Calibrator with Fluke Calibration's intelligent

System accuracy comparison measuring 150 °C using a Pt100 (IEC751) RTD with a transmitter span of 0 to 200 °C			
Standard RTD	Accuracy	Characterized RTD	Accuracy
Rosemount Model 644H	± 0.15 °C	Rosemount Model 644H	± 0.15 °C
Standard RTD	± 1.05 °C	Matched (calibrated) RTD	± 0.18 °C
Total system	± 1.06 °C	Total system	± 0.23 °C

Total system accuracy calculated using RSS statistical method.

Table 1

and stable family of field drywells and micro-baths, you have the capability to test the entire loop. This combination of equipment allows you to easily verify the characteristics of the temperature sensor and measurement electronics. Using this information, the entire loop can be adjusted to optimize system measurement performance. Below are some examples of how to optimize the performance of your measurement system using these instruments.

The Fluke 754 is connected to a Fluke Calibration dry-well or micro-bath by way of a serial RS-232 interface cable. The serial cable may be obtained from either your authorized Fluke distributor or directly from your Fluke Calibration representative. The heat source is connected to the 754 pressure port and is accessed by the 754 TC/RTD source key. Due to the length of these tests, it is recommended that a fully charged battery or battery eliminator for the 754 be used. A diagram of the connection of this equipment is pictured in Figure 4.

In many process applications, the instrumentation of choice for temperature measurements is a transmitter that accepts the output from the temperature sensor and drives a 4-20 mA signal back to the PLC, DCS or indicator. This example describes one method for verifying performance and offers to optimize this measurement to improve performance.




Figure 4. Connecting a Fluke 754 to a Fluke Calibration dry-well.

To perform this test, the RTD sensor is removed from the process and inserted in to the dry-block calibrator. The mA connections from the transmitter are connected directly to the 754 Documenting Process Calibrator (see Figure 5). In most applications, this solution provides adequate performance. But if your application includes a uniquely-shaped sensor, you might want to consider the use of a micro-bath. If increased heat source accuracy is needed, the use of a reference thermometer combined with the 754's User-Entered Values feature can be used. See application note 1263925 for more information on 754 User-Entered Values.

Once connections are made, you are ready to acquire transmitter configuration (if you have a transmitter with HART communications), set the test parameters, and configure the calibrator for mA measurement and dry-well control as the sourcing parameter.

Pressing the HART key on the 754 allows the calibrator to acquire the transmitter configuration from a transmitter with HART communication capability. Following is a sample of this acquired configuration information.

HART mA		LOOP	***
HART	Measure	7.798 mA	
	Source	Off	
	644 Temp	TT100	
	PV	23.7 °C	
	PVAO	7.7975 mA	
	PV LRV	0.0 °C	
	PV URV	100.0 °C	
Select operation for this device			
Abort	Service	Setup	Process

Pressing the HART key on the 754 again presents the following screen with several options for configuring the calibrator to the correct parameters for this test. For the purposes of this example, we'll use the transmitter configured to output a 4-20mA signal; therefore the correct configuration of the 754 is to measure mA and source temperature via the dry-well.

HART mA		LOOP	***
HART	Measure	7.798 mA	
	Source	Off	
TT100			
Select calibrator mode of operation			
Don't change calibrator mode MEAS mA, SOURCE PT100, a=385/4W MEAS PV, SOURCE PT100, a=385/4W MEAS mA, SOURCE Drywell MEAS PV, SOURCE Drywell			
Abort			

Pressing the AS FOUND soft key on the 754 provides access to parameters needed to configure an automated test. Below is a typical definition that will test the measurement system from 50°C to 150°C sourcing temperatures using a dry-well in ascending order.

HART mA		LOOP	***
MEASURE	0% Value	4.000 mA	
	100% Value	20.000 mA	
	Tolerance	0.25 %	
	Delay	10 s	
SOURCE		Hart 91 43	
	0% Value	50.0 °C	
	100% Value	150.0 °C	
	Test Strategy	51	
Abort	User Value	Custom Units	Done

After the test has been defined, the Fluke 754 will take over and run the test recording the sourced temperature, measured output of the transmitter, in mA. At the end of the test, the results will be displayed on the screen, allowing the test technician to evaluate the results and take corrective action if needed. Following is an example of the results.

HART mA		LOOP	***
SOURCE	MEASURE	ERROR %	
50.0 °C	4.005 mA	0.03	
75.0 °C	7.938 mA	0.39	
100.0 °C	12.125 mA	0.78	
124.9 °C	16.035 mA	0.32	
149.9 °C	20.225 mA	1.51	
Abort	Prev. Page	Next Page	Done

One method of optimizing this system to minimize error is to shift the URV or LRV of the transmitter to the values measured by the 754. With a transmitter with HART capabilities, this is easily done via the 754, by simply entering new values in the HART SETUP screen below.

HART mA		LOOP	***
HART	SETUP	Measure	20.162 mA
Enter Values			
	PV Unit		°C
	Lower Range Value		50.0
	Upper Range Value		151.5
Abort		Send	

With an analog transmitter, you will need to mechanically adjust the Zero and Span adjustments when sourcing the appropriate temperature values. The 754 has a convenient menu key that allows you to easily set the correct value on the dry-well with a single button press.

Calibrating and adjusting measurement systems using characterized sensors and calibration constants

Another method of reducing uncertainty and optimizing temperature measurement systems is to carefully characterize the temperature sensor, calculate correction coefficients and load these correction coefficients into the measurement equipment. This is the method used in the Rosemount 644H example on the previous page. This method does a better job of reducing the error in the measurement system that comes from the sensor. But it requires transmitters that have a correction or linearization algorithm that can accommodate the sensor. For example, Platinum RTDs typically use the Callendar-Van Dusen (CVD) equation for linearizing the sensor's output. A characterized sensor will provide unique CVD coefficients that can be input into the transmitter, allowing its conversion algorithm to more closely match the unique characteristics of the sensor.

The Fluke 754 connected with a dry-well can help to collect the necessary information to characterize the sensor, but additional software and resources will be needed to take this data and generate new CVD constants. Examples of the required software include Fluke Calibration's TableWare. Other software that could be used include Mathcad, Mathematica, Maple or Excel. But these packages require considerable knowledge of the equations used to linearize a sensor and the ability to perform curve-fitting of the collected data.

The method of characterizing a probe is similar to the procedure above, but rather than measuring the output of the transmitter, the output of the sensor is connected directly to the 754. An example of data collected by a 754 on a temperature sensor is shown below.

SOURCE	MEASURE	ERROR %
-25.0 °C	91.1 Ω	3.14
0.0 °C	101.1 Ω	6.71
25.0 °C	110.8 Ω	9.43
50.0 °C	120.6 Ω	12.43
75.0 °C	130.2 Ω	14.86

Abort Prev. Page Next Page Done

Data like this can be entered into Fluke Calibration's software using the screens in Figure 6 and then unique CVD constants calculated for that probe.

These coefficients can then be entered into a suitable measurement device that allows its linearizations to match the characteristics of the probe.




Figure 6. TableWare software from Fluke Calibration calculates unique CVD constants that match the characteristics of the probe.

Enhancing the accuracy of a dry well or portable bath

Dry blocks and micro-baths have sensing elements that measure the temperature the device is generating. This temperature measurement is not as accurate as measuring the temperature with a reference RTD probe and readout. By using an external RTD reference probe the known temperature of the dry block or bath can be enhanced significantly versus using the internal sensors. Many dry blocks like the Fluke 9144P have internal measurement circuitry that allows you to directly connect an RTD probe. If the dry well or bath does not have the ability to connect a reference probe, a precision readout with an RTD probe like the Fluke 1523 or 1524 can be used for this purpose. Use of an external reference probe can improve the accuracy setting of your dry block or bath over five times, depending on the accuracy of the reference probe.

Summary

Using a dry-well in combination with a process calibrator allows measurement systems to be verified and adjusted to optimize measurement performance. By verifying the entire measurement system, unique characteristics of the sensing element can be combined with the measurement electronics to minimize measurement error. This can result in a significant reduction in measurement errors. The Fluke 754 Documenting Process Calibrator, combined with a Fluke Calibration dry-well makes this process faster and easier.



Figure 5. Fluke 754 and Fluke Calibration 9144P dry-well calibrating a 4-20 mA transmitter and temperature sensor.

Fluke Calibration.

Electrical | RF | **Temperature** | Humidity | Pressure | Flow | Software

Fluke Calibration

PO Box 9090, Everett, WA 98206
U.S.A.

Fluke Europe B.V.

PO Box 1186, 5602 BD
Eindhoven, The Netherlands
Web access: <http://www.flukecal.eu>

For more information call

In the U.S.A. (877) 355-3225 or
Fax (425) 446-5716
In Europe/M-East/Africa +31 (0) 40 2675 200
or Fax +31 (0) 40 2675 222
In Canada (800)-36-FLUKE or
Fax (905) 890-6866
From other countries +1 (425) 446-6110 or
Fax +1 (425) 446-5716
Web access: <http://www.flukecal.com>

Modification of this document is not
permitted without written permission
from Fluke Calibration.

© 2004-2011, 2021 Fluke Calibration.
Specifications subject to change without notice.
Printed in U.S.A. 6/2021 210627 2148146D-en